

Field Assembly Instruction

HYDRAULIC
EXCAVATOR

PC750 -7 PC750LC-7
PC750SE-7
PC800 -7 PC800SE-7

SERIAL NUMBERS PC750-20001 and up
PC800-40001

KOMATSU

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL








- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

4 Divisions

Days	1				2									
Assembly unit Base machine ① Left track frame ② Right track frame ③ Axle assembly	 ④ Upper structure	 ⑤ Counterweight, ⑥ Platform group • Inspection of oil level and water level	 Loading shovel-type excavator ⑦ Assembling of work equipment	Backhoe Loading shovel-type excavator ⑦ Assembling of work equipment	Crane (Two) 343 kN (35 t) 343 kN (35 t) Min. 0.7 MPa Min. 1.5 m ³ /min	 343 kN (35 t) 343 kN (35 t)	 343 kN (35 t)	 343 kN (35 t)	 343 kN (35 t)	Worker Leader + 3 mechanics Start of assembling • Meeting with all workers	Completion of installation of unit assembly to body	Completion of body assembling	Completion of general assembling	Completion of general assembling

2. Tightening torque for pipe threads

Proper tightening torque for pipe threads depends on combination of the materials of the male screw and female screw. In this manual, however, select tightening torque from Table 2 and Table 3 on the basis of the material of the male screw. If tightening torque is specified specially in explanation, however, apply that tightening torque.

2.1 If the male screw is made of mild steel or cast iron, apply Table 2.

Table 2

Unit: Nm {kgm}

Nominal size (in) \ Material of female thread	Steel	Cast iron	Light alloy
1/8	3.9 – 6.9 {0.4 – 0.7}	2.9 – 5.9 {0.3 – 0.6}	2.0 – 3.9 {0.2 – 0.4}
1/4	5.9 – 11.8 {0.6 – 1.2}	4.9 – 9.8 {0.5 – 1.0}	3.9 – 7.8 {0.4 – 0.8}
3/8	16.7 – 26.5 {1.7 – 2.7}	13.7 – 21.6 {1.4 – 2.2}	9.8 – 16.7 {1.0 – 1.7}
1/2	32.3 – 52.9 {3.3 – 5.4}	26.5 – 43.1 {2.7 – 4.4}	19.6 – 32.3 {2.0 – 3.3}
3/4	51.0 – 85.3 {5.2 – 8.7}	42.1 – 70.6 {4.3 – 7.2}	31.4 – 52.9 {3.2 – 5.4}
1	86.2 – 173.5 {8.8 – 17.7}	72.5 – 146.0 {7.4 – 14.9}	54.9 – 111.7 {5.6 – 11.4}

2.2 If the male screw is made of refined steel (heat-treated hard steel), apply Table 3.

Table 3

Unit: Nm {kgm}

Nominal size (in) \ Material of female thread	Steel	Cast iron	Light alloy
1/8	16.7 – 29.4 {1.7 – 3.0}	9.8 – 19.6 {1.0 – 2.0}	6.9 – 14.7 {0.7 – 1.5}
1/4	19.6 – 44.1 {2.0 – 4.5}	16.7 – 37.2 {1.7 – 3.8}	12.7 – 28.4 {1.3 – 2.9}
3/8	44.1 – 93.1 {4.5 – 9.5}	37.2 – 77.4 {3.8 – 7.9}	27.4 – 58.8 {2.8 – 6.0}
1/2	98.0 – 188.2 {10.0 – 19.2}	83.3 – 157.8 {8.5 – 16.1}	60.8 – 115.6 {6.2 – 11.8}
3/4	170.5 – 316.5 {17.4 – 32.3}	141.1 – 247.0 {14.4 – 25.2}	105.8 – 186.2 {10.8 – 19.0}
1	367.5 – 612.5 {37.5 – 62.5}	309.7 – 514.5 {31.6 – 52.5}	235.2 – 392.0 {24.0 – 40.0}


Assembly Procedure No. A-2. Installation of Travel Pipe (3/3)

- (1) Arrange the pilot hoses ④ (L.H.), ⑤ (R.H.) for selecting machine speed and the drain hoses ③ (Figs 1, 2 and 3)
- (2) Arrange the main hoses ① and ② on the travel motor side (Figs 1, 2 and 3). Use new O-rings ⑥ out of the loose-supply items and use split flange, bolt and washer out of the travel motor parts.

Precautions						Tools used		Equipment used	
						Tool Name	Q'ty	Name	Q'ty
No.	Parts already installed to body	Q'ty	No.	Loose-supply items	Q'ty				
1	209-64-12131	2	6	07000-13032	4				
2	209-64-12141	2							
3	209-64-16670	2							
4	209-64-16660	1							
5	209-64-16650	1							
						Others			

Assembly Procedure No. A-7. Installation of Step


- (1) Install the steps ① and ② to the left outside of the track frame by using the bolt ③ and the washer ④.
- (2) Install the step ⑤ to the left side cover by using the bolt ⑥ and the washer ⑦.



Precautions					Tools used		Equipment used	
Remove the plugs for rust prevent set in the mounting tapped holes.					Tool Name	Q'ty	Name	Q'ty
					No.	Loose-supply items	Q'ty	No.
1	21M-30-12260	1						
2	209-30-61751	1						
3	01010-81640	8						
4	01643-31645	8						
5	209-54-63481	2						
6	01010-81230	4						
7	01643-31232	4						
					Others			



Assembly Procedure No. B-2. Installation of Boom Assembly

- (1) Lift the boom assembly with the crane and bring it to the body pin hole.

: Boom assembly
 7,400 kg (PC750, 750LC)
 6,840 kg (PC800)
 7,660 kg (PC750SE, PC800SE)


- (2) Fitting of Boom Foot Pin.
 Insert a boom foot pin (which had been fitted on the revolving side) in a hole one side first and bring the body to the pin hole on the other side. When the boom is inclined to the left or right at the time, balance it by using the jib crane.

- ★ Since four seals (209-72-11261, 4 pcs.) have been fitted to the boom foot as shown below, use care not to break them when inserting pins.



- ★ Check the clearance between the boom foot and the machine outside, decide the size and quantity of shim so that the clearance becomes below 1 mm and insert the shim between them. Use the adjustment shims (209-70-71640, 1.0 mm thick, and 209-70-71650, 1.5 mm thick) to decide their combination.
- ★ Adjust the clearance with shims at one place outside.
- ★ Do not insert any shim in the clearance on the inside of the chassis.

- (3) Insert the boom foot pins fully on both the left and right sides and fit lockplates there.


 Inside of pin hole : Lithium grease

Precautions					Tools used		Equipment used	
					Tool Name	Q'ty	Name	Q'ty
No.	Loose-supply items	Q'ty	No.					
	209-72-11261	4						
	209-70-71650	4						
	209-70-71640	2						
					Others			


Assembly Procedure No. B-11. Installation of Bucket Assembly

- (1) Push in the arm to bucket connection pin and adjust the clearance to the range from 0.5 to 1.0 mm by using the bushing (209-939-5410) and shim (209-939-5431 (t=1.0) 9 pcs. and 209-939-5441 (t = 0.5 mm) 2 pcs.) out of the loose-supply items. Then, tighten the cover mounting bolt (M24).

★ Inside bushing: anti-friction compound (LM-P).



- (2) Set two O-rings (21N-70-13150) for preventing earth and sand from penetrating into the bucket arm connection pin to the normal positions and fix a pin stopper.
- (3) Lift the link and align the bucket to link connection pin to the hole while operating the bucket cylinder.



- (4) Push in the link to bucket connection pin and adjust the clearance to less than 1 mm by using the shim (209-72-11220, 1 pc. t = 1 mm) out of the loose-supply items. Then, install O-rings (208-70-33181, 2 pcs.) for dust prevention to the proper position, and fix the pin stopper.

- ★ Since the seal (209-72-12211, 2 pcs.) to the boss on the link side (link to bucket connection), use care not to break them when inserting the pin.
- ★ Be sure to operate the cylinder slowly. Do not operate it quickly and do not bring it to the stroke end. Since air gathers inside the cylinder at the first time, the cylinder may not operate for 10 seconds or more, but do not move the lever to the full stroke.

Precautions					Tools used		Equipment used	
★ Refer to the Maintenance standard for the clearance of the connection.					Tool Name	Q'ty	Name	Q'ty
					No.	Loose-supply items	Q'ty	No.
	209-939-5410	1						
	209-939-5431	9						
	209-939-5441	2						
	21N-70-13150	2						
	209-72-11220	1						
	208-70-33181	2						
					Others			

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

C- 4 Installation of flushing piping between chassis and boom



- (1) Remove the plugs from the piping on the boom side and the hoses on the chassis side and install the hoses between the chassis and boom.

For bottom dump — Hose (07099-01219, 07099-01222, 2 pieces)
 O-ring (07000-13038, 4 pieces)
 Split flange (07371-51260, 8 pieces)
 Bolt (01010-51245, 16 pieces)
 Washer (01643-31232, 16 pieces)


For bucket — Hose (07098-01414, 2 pieces)
 O-ring (07000-13048, 4 pieces)
 Split flange (07371-51470, 8 pieces)
 Bolt (01010-81455, 16 pieces)
 Washer (01643-31445, 16 pieces)

Precautions	Part sent individually		
	No.	Part No.	Q' ty
1. Keep the flanges, O-rings, and heads used for transportation so that they can be reused. 2. When connecting each hose, take extreme care that the O-rings will not be caught. 3. When connecting each hose, take extreme care that dirt will not enter the circuit.			

M. PROCEDURE FOR INSPECTION AND MAINTENANCE AFTER COMPLETION OF ASSEMBLY

Category	Revision	Check item		Local assembly time	After hours of operation	Judgement standard	
Checks before assembly		Oil and water levels		Actual measurement			
		Cooling water	Soft water	[]			
			Yes/No	[]			
		Anti-freeze (A, B, C, D, E)	Density of anti-freeze	[]			A: -50 -- -40°C D: -20 -- -10°C B: -40 -- -30°C E: -10 -- 0°C C: -30 -- -20°C (Not necessary in summer)
		Engine oil	SAE10W CD SAE30 CD	[]			L-H +5mm (10 minutes after stopping engine)
		PTO oil	SAE10W CD SAE30 CD	[]			L+5 -H (10 minutes after stopping engine)
		Swing machinery gear case oil	SAE30 CD	[]			L+5 -H+10 (10 minutes after stopping engine)
		Final drive gear case oil	Right	SAE30 CD	[]		Bottom edge of level plug: 0 to -10 mm
			Left	SAE30 CD	[]		
		Hydraulic oil	SAE10W CD	[]			Between the H and L marks.
		Battery electrolyte	-	[]			Within 13 mm from bottom surface of filler port
		Engine No.	[]				
	Service meter	When accepted []	After check []				
	Revolving frame No.	[]				Must match Serial No.	
Checks during assembly							
		Loose, untightened lock bolts for connecting pins				There must be none.	
		Loose, untightened split flange bolts for work equipment piping				There must be none.	
		Forgotten, missing, catching O-rings for work equipment piping				There must be none.	
		Loose, twisted connections for grease piping				There must be none.	
		Shim adjustment for work equipment pins				Max. 1 mm (for locations, see assembly procedure manual)	
		Improperly inserted wiring, unconnected wiring				There must be none.	
		Loose, untightened ladder mounting bolts				There must be none.	

Category	Revision	Check item	Local assembly time	After hours of operation	Judgement standard
Check of switches, control levers		Operation of safety lock lever			Push down the lever up to apply the lock. This lock lever is a hydraulic lock, so even if it is in the lock position, the work equipment control lever and travel lever will move, but the work equipment, travel motor, and swing motor will not work.
		Operation of travel levers			FORWARD: The lever is pushed forward. (The pedal is angled forward) REVERSE: The lever is pulled back. (The pedal is angled back) N (Neutral): The machine stops.
		Operation of left work equipment control lever (with auto-deceleration device)			This lever is used to operate the arm and upper structure. Arm operation Swing operation Ⓐ Arm OUT Ⓒ Swing to right Ⓑ Arm IN Ⓓ Swing to left N (Neutral): When the lever in this position, the upper structure and the arm will be retained in the position in which they stop.
		Operation of right work equipment control lever (with auto-deceleration device)			This lever is used to operate the boom and bucket. Boom operation Bucket operation ① RAISE ③ DUMP ② LOWER ④ CURL N (Neutral): When the lever in this position, the boom and the bucket will be retained in the position in which they stop.

Category	Revision	Check item	Local assembly time	After hours of operation	Judgement standard
Check monitor		Monitor display 1. Check of monitor function When the starting switch is turned ON, the gauges, CHECK items, and all display items on the monitor should light up. At the same time the alarm buzzer should sound.			Display should be as on left.
		2. Check of gauges and CHECK items When starting switch is turned to ON (all lamps on), all display lamps should go out after approx. 3 sec. For another 2 seconds, only the gauges are displayed, and the CHECK and monitor items disappear.			
		3. Check of monitor items After starting the engine, the caution lamps should not light up and the alarm buzzer should not sound when the engine speed is low idling – high idling.			
		Operation of service meter			There should be no scratches or misting of the lens or variation in operation.
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>MONITOR</p>  </div> <div style="width: 50%;"> <ol style="list-style-type: none"> 1. — 2. Working mode select switch 3. Wiper monitor 4. Preheating monitor 5. Swing lock monitor 6. Coolant temperature monitor 7. Engine oil pressure monitor 8. Coolant temprature gauge 9. Battery charge monitor 10. Coolant level monitor 11. Working mode monitor 12. Hydraulic oil temperature monitor 13. Hydraulic oil temperature gauge 14. Maintenance interval monitor 15. Service meter 16. Travel speed monitor 17. Engine oil level monitor 18. Air cleaner clogging monitor 19. Fuel gauge 20. Fuel level monitor 21. Auto-deceleration monitor 22. Screen adjust switch 23. Input control switch 24. Window washer switch 25. Wiper switch 26. Maintenance switch 27. Travel speed selector switch 28. Auto-deceleration switch </div> </div> <p style="text-align: right; margin-top: 10px;">9JH03385</p>					

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL