

en

Operating instructions

Crawler loader
LR 634 with steering pedal
from S/N: 13743

Document identification

ORIGINAL OPERATING MANUAL

Id. No.: 9085119

Issue: 03/2014

Valid for: LR 634 from S/N. 13743 with steering pedal

Author: LWT / Technical Documentation Dept.

Product identification

Manufacturer: Liebherr Werk Telfs GMBH

Type: LR 634

Type No.: 992

Conformity: CE

Address

Address: LIEBHERR Werk Telfs GMBH

Hans Liebherr Straße 35,
A - 6410 TELFS

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

3.4.8	Land clearing operation	3 - 80
3.4.9	Ripper operation	3 - 82
3.5	Transporting the machine	3 - 83
3.6	Loading the machine with a crane	3 - 86
3.7	Installation instructions for the removal and installation of attachment parts	3 - 87
3.7.1	Removal and installation of the bucket	3 - 87
3.7.2	Removal and installation of 4 in 1 bucket	3 - 89
3.7.3	Removal and installation of ripper	3 - 91
3.8	Emergency operation	3 - 94
3.8.1	Towing the machine	3 - 94
3.8.2	Auxiliary starting procedure	3 - 102
4.	Operating problems	4 - 1
4.1	Problems and remedy	4 - 2
4.2	Problem remedy	4 - 8
4.2.1	Change the fuse	4 - 8
5.	Maintenance	5 - 1
5.1	Maintenance and inspection schedule	5 - 1
5.2	Quantities, Lubrication chart	5 - 6
5.2.1	Recommended lubricants and service items	5 - 6
5.2.2	Lubrication chart	5 - 7
5.2.3	Lubrication chart - symbols	5 - 9
5.3	Lubricants and service fluids	5 - 10
5.3.1	General data	5 - 10
5.3.2	Diesel fuels	5 - 10
5.3.3	Lube oils for Diesel engines	5 - 11
5.3.4	Coolant for Diesel engines	5 - 13
5.3.5	Hydraulic oil	5 - 15
5.3.6	Lube oils for splitterboxes	5 - 20
5.3.7	Lube oils for travel gears	5 - 20
5.3.8	Oil for slipping seal – travel gear	5 - 21
5.3.9	Oil for axle bearing	5 - 21
5.3.10	Grease and other lubricants	5 - 21
5.3.11	Oil for hinges and joints	5 - 22
5.3.12	Taking oil samples	5 - 23
5.4	Preparations for maintenance	5 - 27
5.4.1	Maintenance position	5 - 28
5.4.2	Open the cooler guard	5 - 31
5.4.3	Electrical system	5 - 32
5.5	Diesel engine	5 - 32
5.5.1	Check the engine oil level	5 - 32
5.5.2	Engine compartment	5 - 33
5.5.3	Change the engine oil	5 - 34

Performance

Generation 4 Liebherr crawler loaders provide exceptional handling performance even in difficult terrain. Fast work cycles, an optimum bucket capacity and outstanding machine handling under load give them optimum operating properties.

Excellent handling performance

Outstanding break-out forces

The excellent penetration characteristics of the bucket and the powerful Z-bar linkage ensure optimum loading performance.

Optimal bucket filling and high tipping load

The large tipping angle of the bucket and high stability ensure optimum filling capacity in every work cycle, especially when loading trucks.

Rapid work cycles

Rapid acceleration, short cycle times and semi-automatic operation result in a measurable productivity advantage.

Precision earthmoving

Optimal dozing properties

Excellent precision control of the load-sensing power hydraulics and the machine's smooth operation enable precise dozing work.

Good climbing ability

An extremely low centre of gravity means that steep inclines and travel on slopes, for instance when constructing embankments, do not pose a problem.

Impressive manoeuvrability

Even under the most confined conditions, the machine can be steered and positioned with precision, including counter-rotation.

Excellent dozing performance

High performance without interruption

The high power reserves of the diesel engine and hydrostatic travel drive offer maximum power in every situation. This is important during dumping tasks, backfilling and earthmoving.

High traction

The combination of a long track frame and continuously variable speed control afford high drawbar pull transmission and pushing power.

High bucket filling level

The high bucket filling level enables optimal topsoil removal and dozing of different material layers at all times.



A diversity of applications

- Numerous equipment options: 4in1 bucket, heavy-duty bucket, light materials bucket or standard bucket, towing hitch, winch, ripper, and more.
- Optional quick-release coupling: A wide range of attachments can be swapped easily and conveniently, making crawler loaders the ideal all-round machine.



Liebherr hydrostatic drive

- Hydraulic variable-displacement pumps and motors are connected independently in two closed circuits and efficiently transfer diesel engine power to both final drives.
- Steering behaviour is adapted to the travel speed. This ensures maximum machine productivity with a full bucket, even on turns.

Basic machine



Loader cycle times

	LR 624	LR 634
Lifting	6.3 s	6.4 s
Bucket dumping	1.3 s	2.2 s
Lowering ¹	2.7 s	2.8 s
Total cycle time ²	8.5 s	8.1 s


¹ Float position and empty bucket, ² lifting and dumping together



Refill capacities

	LR 624	LR 634
Fuel tank	279 l / 61.4 Imp. gal	360 l / 79.2 Imp. gal
Cooling system	36 l / 7.9 Imp. gal	36 l / 7.9 Imp. gal
Engine oil (with filter)	30 l / 6.6 Imp. gal	30 l / 6.6 Imp. gal
Splitter box	2.5 l / 0.5 Imp. gal	3.1 l / 0.7 Imp. gal
Hydraulic tank	76 l / 16.7 Imp. gal	83 l / 18.3 Imp. gal
Pivot shaft, each	5 l / 1.1 Imp. gal	5 l / 1.1 Imp. gal
Final drive, each	15 l / 3.3 Imp. gal	20 l / 4.4 Imp. gal
Duo cone seal, each	3.5 l / 0.8 Imp. gal	3.3 l / 0.7 Imp. gal

Dimensions




Dimensions		LR 624	LR 634
A	Height over cab	mm 3,150 ft in 10'4"	3,310 10'10"
B	Height over exhaust pipe	mm 2,806 ft in 9'2"	2,952 9'8"
C	Length to front of track	mm 4,600 ft in 15'1"	4,867 16'
D	Distance idler/sprocket center	mm 2,483 ft in 8'2"	2,564 8'5"
E	Ground clearance	mm 430 ft in 1'5"	458 1'6"
F	Track gauge	mm 1,740 ft in 5'9"	1,800 5'11"
G	Machine width,	mm 2,248	2,308
	with track shoes 508 mm / 20"	ft in 7'5"	7'7"
	Machine width,	mm 2,300	2,360
	with track shoes 560 mm / 22"	ft in 7'7"	7'9"
	Machine width,	mm —	2,410
	with track shoes 610 mm / 24"	ft in —	7'11"
H	Approach angle	30°	30°

1.2.2 Preload and tightening torques for screws with fine metric thread according to factory standard WN 4037 I

Fine metric thread	Preload value F_M based on grades in N			Tightening torques M_A based on grades in Nm			Wrench size for hex head screws		Wrench size for socket head screws	
	8.8	10.9	12.9	8.8	10.9	12.9	mm	inch	mm	inch
M 8 x 1	18 800	27 500	32 500	24,5	36	43	13	1/2	6	--
M 9 x 1	24 800	36 500	42 500	36	53	62	--	--	--	--
M 10 x 1	31 500	46 500	54 000	52	76	89	17	11/16	8	5/16
M 10 x 1,25	29 500	43 000	51 000	49	72	84	17	11/16	8	5/16
M 12 x 1,25	45 000	66 000	77 000	87	125	150	19	3/4	10	--
M 12 x 1,5	42 500	62 000	73 000	83	122	145	19	3/4	10	--
M 14 x 1,5	61 000	89 000	104 000	135	200	235	22	7/8	12	--
M 16 x 1,5	82 000	121 000	141 000	205	300	360	24	--	14	9/16
M 18 x 1,5	110 000	157 000	184 000	310	440	520	27	1 - 1/16	14	9/16
M 18 x 2	102 000	146 000	170 000	290	420	490	27	1 - 1/16	14	9/16
M 20 x 1,5	139 000	199 000	232 000	430	620	720	30	1 - 3/16	17	--
M 22 x 1,5	171 000	245 000	285 000	580	820	960	32	--	17	--
M 24 x 1,5	207 000	295 000	346 000	760	1 090	1 270	36	1 - 7/16	19	3/4
M 24 x 2	196 000	280 000	325 000	730	1 040	1 220	36	1 - 7/16	19	3/4
M 27 x 1,5	267 000	381 000	445 000	1 110	1 580	1 850	41	1 - 5/8	19	3/4
M 27 x 2	255 000	365 000	425 000	1 070	1 500	1 800	41	1 - 5/8	19	3/4
M 30 x 1,5	335 000	477 000	558 000	1 540	2 190	2 560	46	1 - 13/16	22	7/8
M 30 x 2	321 000	457 000	534 000	1 490	2 120	2 480	46	1 - 13/16	22	7/8
M 33 x 1,5	410 000	584 000	683 000	2 050	2 920	3 420	50	2	24	--
M 33 x 2	395 000	560 000	660 000	2 000	2 800	3 300	50	2	24	--
M 36 x 1,5	492 000	701 000	820 000	2 680	3 820	4 470	55	2 - 3/16	27	1 - 1/16
M 36 x 3	440 000	630 000	740 000	2 500	3 500	4 100	55	2 - 3/16	27	1 - 1/16
M 39 x 1,5	582 000	830 000	971 000	3 430	4 890	5 720	60	2 - 3/8	27	1 - 1/16
M 39 x 3	530 000	750 000	880 000	3 200	4 600	5 300	60	2 - 3/8	27	1 - 1/16

1.2.3 Tightening torques for cutting edges, end bits, bolt-on


Tightening torque / ft. lbs.	Tightening torque / Nm	inch	mm
200 +/- 30 ft. lbs.	270 +/- 40 Nm	5/8"	16 mm
350 +/- 45 ft. lbs.	475 +/- 60 Nm	3/4"	19 mm
550 +/- 65 ft. lbs.	750 +/- 90 Nm	7/8"	22 mm
825 +/- 110 ft. lbs.	1125 +/- 150 Nm	1"	25 mm
1350 +/- 220 ft. lbs.	1850 +/- 300 Nm	1-1/4"	32 mm



Sign Lubrication chart

Sign Lubrication chart


The sign is installed in the battery compartment. The lubrication chart shows all components which use oil or grease as well as the inspection and change intervals for these parts.



Sign Travel hydraulic

Sign Travel hydraulic

The sign is installed on the left front on the operator's platform. Shows the operation of the travel joystick for the travel functions of the machine.



Sign Working hydraulic

Sign Working hydraulic

The sign is installed on the right front on the operator's platform. Shows the operation of the working attachment on the machine.

- Remove all chains, wedges and blocks. Start the engine as noted in the Operating Manual.
- Carefully move from the trailer platform down the ramp.
- Hold the attachment as close as possible above the ground.
- Use a guide to signal you.

2.4.9 Machine towing safety

1. Always follow the correct procedure as noted in the "**Operating Manual**", see "Towing the machine".
2. Tow the machine only in exceptional cases, such as removing the machine from a dangerous area to have the machine repaired.
3. Be sure that all towing and pulling devices, such as cables, hooks, etc. are safe and adequate.
4. The cable or towing bar, which is used to tow the machine, must be adequate to pull the machine and must be connected to the appropriate bores or couplers. Any damage or accident which is the direct result of towing this machine is expressly excluded from the manufacturer's and / or Liebherr warranty.

Notes for towing with a cable:

- Make sure that no one is near the tensioned cable when pulling or towing the machine.
 - Keep the cable tight and free of kinks.
 - Carefully pull the cable tight, do not jerk!
 - A sudden jerk can cause a slack cable to snap.
5. When towing, keep the machine in the correct transport position, and maintain the permissible speed and route.
 6. When returning the machine to operation, proceed as noted in the Operating Manual.
 7. After towing the machine, and before continuing operation, be certain to return the machine to a safe operating condition.

2.4.10 Measures for safe maintenance

1. Do not carry out any maintenance or repair work which you do not know.
2. Keep the specified intervals or intervals as noted in the Operating instructions for recurring checks / inspections.
To carry out maintenance tasks, it is of utmost importance to have the proper shop equipment.
3. The chart in these Operating instructions clearly defines who must or may carry out what type of work. The operator may only carry out the work marked with OI in the maintenance and inspection schedule. The remaining work may only be carried out by expert personnel with corresponding training.
4. Spare parts must meet the technical requirements set forth by the manufacturer. This is always ensured by using Original spare parts. Spare parts, which do not meet the technical requirements of the manufacturer can impact the safety and function of the machine.
5. Always wear safe work clothing when maintaining the machine. For certain work, safety glasses and gloves are required, in addition to hardhat and safety shoes.
6. During maintenance, keep unauthorized personnel away from the machine.

3. Control, instrumentation

3.1 Location of controls and instrumentation



404390

Scroll key



53 Scroll key

- The service codes can be called up by pressing the scroll key, with the starter key in contact position. The Service codes are shown in the LC display. Maximum 10 service codes are shown in the display. The current service code moves the previous one back by one place. After 30 seconds, the display changes automatically to standard display (speed stage / RPM) or it can be switched manually to the standard display by pressing the scroll key for 3 seconds.



407697

Roof console, right



55 Switch - windshield wiper, front

Turn on / off




56 Switch - windshield wiper, rear

Turn on / off



57 Switch - windshield wiper intermittent / washer system

Stage 1: Continuous wipe



Adjustment - seat suspension


403031

7 Knob - Seat suspension

- Set the body weight of the operator with knob 7.

3.2.5 Operator's seat - air cushioned

(Optional equipment)



Operator's seat - main components and control elements

403040


- | | |
|---------------------------------|------------------------------------|
| 1 Armrest | 7 Lever - incline position - front |
| 2 Adjustment - armrest | 8 Lever - incline position- rear |
| 3 Backrest | 9 Button - seat suspension |
| 4 Seatbelt | 10 Button - back support |
| 5 Lever - horizontal adjustment | 11 Seat surface |
| 6 Lever - adjustment - backrest | |

Individual adjustment for ergonomic seat position

The operator's seat can be adjusted for optimum operator comfort.

Horizontal adjustment

The seat can be moved forward or backward with the lever 5 on the front of the operator's seat.




Interior light - reading lamp

- Interior light: Turn on / off with switch 1.
- Reading lamp: Turn on / off with switch 2.

3.2.12 Rear view mirror

Adjustment of mirror

The operator's cab is equipped with a rear view mirror.



Adjustment - mirror

- Adjust the mirror before operating the machine.

3.2.13 Electrical windshield wipe and washer system

The machine is equipped with an electrical windshield washer system for the front window and the rear window as well as for the doors.

It consists primarily of the control elements, the windshield wipers, the reservoir and the nozzles for the windshield washer fluid.


Make sure that the electrical system of the machine is turned on before actuating the windshield wiper and washer system.

In case of freezing temperatures, before turning the windshield wipers on for the first time, check if the windshield wiper blades are not frozen onto the windshield.

To avoid condensation in the fuel tank, always refuel after work or after a shift change.

Add Diesel fuel with the refueling pump

Special equipment



Refueling safety

403183

Danger



During refueling, there is a danger of fire and explosion.
 ! Do not smoke and avoid open flames when refueling.
 ! Add fuel only when the Diesel engine is turned off.

- Make sure to observe all safety guidelines for refueling. See also: Chapter Safety guidelines.



Access – refueling pump

Refueling procedure

The refueling pump is located on the right hand side in the step.

- Open the right step door 1.



Throttle control – full load

- Set the throttle control to full load.
 - Turn the throttle control to the stop to the right.
 - Work with the machine always at full engine RPM. Only in some cases should the machine be operated at reduced engine RPM. The machine has now ready to travel.

Caution

If the Diesel engine is operated without a load, then it will not reach the required operating temperature and the piston rings and cylinder bushings will not run in optimally.
! Turn the Diesel engine off when the machine is not operated.

Preselection of speed ranges

The machine is equipped with a pressure switch on the operator's platform to preselect the travel speed. Press to reduce the maximum travel speed, which can be obtained. The maximum travel speed, which can be obtained, is shown in the LC display.

- With the travel joystick in zero position or forward position, the display shows the maximum obtainable speed for forward travel.
- With the travel joystick in reverse position, the display shows the maximum obtainable speed for reverse travel.

The speed can also be selected while driving.

When shifting back from full travel speed, the machine is hydrostatically slowed down.



Low speed range

Caution


In constantly heavy push application and when working on slopes, switch to the lower speed range.
! Drive on slopes at no more than 4 km/hr.

Caution

Danger of accident if the machine stops suddenly.
The machine stops suddenly.
! Always wear the seat belt before operating the machine.

Stop the travel drive

In dangerous or unclear situations, the travel drive can be stopped by pressing the emergency off button.




Emergency off button

- Press the emergency off button
 - The travel drive is stopped abruptly, the Diesel engine continues to run. The attachment can still be moved.

Continue to work

- Move the travel joystick to neutral position.
- Lift the emergency off button until it engages.
- Deflect the travel joystick into the desired direction. See also section "Travel".

3.3.8 Guidelines for working in water



Lower edge - carrier roller


When driving through wet areas or when working in water, the maximum fording depth (lower edge of carrier roller 1) may not be exceeded.

- After working in water, lubricate all lube points.

- for all digging work
- to grasp bulky items
- to dump in open condition
- to doze
- for larger dumping height

The manufacturer (or supplier) is not responsible for any damage, which is the result of non-intended or inappropriate use (such example breaking out rocks, knocking in poles or attaching load tackle).

Control of the ripper



404977

- 1 Pull bar
- 2 Hydraulic cylinder

- 3 Ripper tooth

The ripper is operated via the ripper control lever on the right hand side of the operator's seat.



407811

Ripper control lever

Lower the ripper

- Push the ripper control lever to the front in direction - e -.
- The ripper is lowered.

Raise the ripper

- Pull the ripper control lever to the rear in direction - f -.
- The ripper is raised.

Rear winch operation


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



403166

*Cut roots***Felling of trees**


- Clear the surrounding area.
- Cut the tree roots on the opposite and parallel to the desired drop direction with the bucket.

Caution

Danger of accidents due to falling trees.

! As soon as the tree starts to fall, back up immediately!


! Do not move on top of the root system of the falling tree.



407034

Felling trees

- Slowly move towards the tree in the direction you want the tree to fall, with the bucket raised.



404999

Removal of tree stumps


- Remove the retaining plates of the bearing pin on the left and right hand side of the bucket arm.



Lock screws

- Loosen the lock screws on the bucket arm and drive out the bearing pin from the inside to the outside.
- Carefully move the machine backward until the bucket stands by itself. Install in reverse order.
 - If the attachment is to be stored for a longer period of time, protect all parts from corrosion.

3.7.3 Removal and installation of ripper



Lower the attachment to the ground

- Lower the ripper to the ground.




Hydraulic pressure

403281

If the indicator light – travel brake does not turn off, then the towing procedure must be repeated from the point where the air pressure cartridge was inserted.

- The pressure in the system is not sufficient to vent the brake.



Safety lever up

After the towing procedure

- Move the travel joystick to neutral position.
 - The parking brake is applied.
 - Indicator light – Travel brake must light up.
- Press the emergency off button.
- Move the safety lever up.
- Turn the ignition off



403281




Hydraulic pressure

Caution




- ! Before removing the brake adapter, relieve the hydraulic pressure in the system.
 - Relieve the pressure in the hydraulic system by moving the travel joystick several times in forward and reverse direction.
 - Carefully remove the brake adapter.

Working attachment

 Problem / error	 Cause	 Remedy
Cylinder gives way under load	Piston seal in cylinder defective	Overhaul cylinder
PR-chain scrapes on push frame	Blade adjustment imperfect	adjust correctly
Excessive bearing play on attachment	Bearing points worn	Replace bearing parts

Maintenance / inspection at operating hours							Work to be carried out	Performance guideline
at delivery	every 8 - 10	every 50	every 250	every 500	every 1000	every 2000		
							<p>by maintenance personnel</p> <p>■ first and only interval ● Repeat interval</p> <p>by authorized expert personnel</p> <p>□ first and only interval ○ Repeat interval</p> <p>OI - Operating instructions SM - Service Manual</p> <p>hrs. - Operating hours</p>	
Working attachment								
<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check cutting edges, end bits and ripper teeth for wear - make sure attachments are suited to application	OI
				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check all bearing points for play / wear	OI
		<input checked="" type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check screws, nuts and pin retainers for tight seating	OI
				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check attachment for intentional damage	OI
General								
<input type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Lubricate all lube points according to the lubrication chart - Shorten interval as necessary	OI
<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Check the entire machine for correct maintenance and proper condition	OI
<input type="checkbox"/>							Explain machine documentation, especially operating instructions / safety guidelines to operating personnel	OI

1) For oil specification and viscosity, refer to chapter "Lubricants and service items".

- Caution**  Improper mixing of various products can impair the properties of the coolant and damage the cooling system.
- Use only approved products, do not mix different products.
 - Never mix silicate containing and silicate free products.
 - If the Liebherr product is not available locally:
Consult with Liebherr Service; use products according to the "Coolant specification for Liebherr Diesel engines".


Approved corrosion inhibitors without antifreeze protection

In **exceptional cases** and in **constant ambient temperatures above freezing**, such as in tropical regions, where no approved corrosion inhibitor / antifreeze fluids are available, the water must be mixed with the following inhibitors for coolant:

- Product DCA 4 (Diesel Coolant Additives 4)
- Product Caltex / Chevron / Havoline / Total

In this case, the coolant must be changed annually.

Check the concentration during maintenance work and correct, if necessary.

- Caution**  Improper mixing of various products can impair the properties of the coolant and damage the cooling system.
- Use only approved products, do not mix different products.
 - Never mix silicate containing and silicate free products.
 - If the Liebherr product is not available locally:
Consult with Liebherr Service; use products according to the "Coolant specification for Liebherr Diesel engines".
 - Drain the entire coolant before changing from corrosion inhibitor antifreeze to corrosion inhibitor or vice versa.

Product description	Manufacturer
DCA 4 Diesel Coolant Additives	Fleetguard / Cummins Filtration
Caltex XL Corrosion Inhibitor Concentrate	Chevron Texaco
Chevron Heavy Duty Extended Life Corrosion Inhibitor Nitrite Free (ELC)	Chevron Texaco
Havoline Extended Life Corrosion Inhibitor (XLI)	Chevron Texaco
Total WT Supra	Total WT Supra




5.3.5 Hydraulic oil

According to the following data, the following oils can be used as hydraulic oil.

Maximum water content of hydraulic oil: less than 0.1 %

Liebherr Hydraulic oil

recommends the following hydraulic oils for the machines, depending on the temperature range:



Diesel engine oil dipstick tube


- a) with manual suction pump via dipstick tube or
- b) take oil sample during oil change from discharging oil flow.



Splitterbox - dipstick tube

Splitterbox

- a) With manual suction pump via dipstick tube or
- b) take oil sample during oil change from discharging oil flow.




Oil filler port

Travel gear

With manual suction pump via oil filler port


Oil analysis

An oil analysis should include at least the following data:




Oil drain valve

- Install the oil drain hose to the oil drain valve and drain the oil into the container.
- Remove the oil drain hose and reinstall the cap on the oil drain valve.
- To be able to drain the used engine oil completely from the Diesel engine, the oil must also be drained from the oil pan (small sump).



Plug

- Remove plug 2.
- Allow the oil (approx. 3 liter) to drain into the prepositioned container.
- Reinstall plug 2.
- Reinstall the belly pan cover.



Add oil

- Add clean oil via the filler neck 1 to the MAX mark on the dipstick.
- Clean the oil filler cap, place it on the oil filler neck 1 and tighten.

- Check the fan**
- Check the fan for damage.

5.6.4 Check the corrosion inhibitor / antifreeze fluid concentration in the coolant

The coolant must contain all year round at least 50 % but not more than 60 % of antifreeze concentration. This corresponds to an antifreeze protection to approx. -37°C.

Make sure that:

- the machine is in maintenance position,
- the engine compartment door is open,
- the testing tool is available,

Procedure to check the antifreeze

Caution



Danger of scalding due to splashing coolant!

! Open the cap of the expansion tank only when the Diesel engine has cooled off - the coolant temperature display on the segment field of the display unit should be in the lower third of the segment field.

- Carefully open the cap on the expansion tank.
- Take a coolant sample and check the antifreeze concentration with the testing tool.
- If the antifreeze concentration is not reached:
correct the mixing ratio of the antifreeze in the coolant.

Procedure to correct the antifreeze concentration

- For coolant fill quantity – see quantities in the chart.
- If the antifreeze concentration is too low:
Drain the coolant and refill clean antifreeze according to the diagram shown.


Caution



Danger of damage to the Diesel engine!


If the corrosion inhibitor / antifreeze fluid concentration is too high, then the cooling action is reduced. This in turn can cause damage to the Diesel engine!

! Never use more than 60% corrosion inhibitor / antifreeze fluid.



Front cover

- Fold the front cover forward very carefully.



Cleaning cover

- Remove the cleaning cover.
 - Check the O - ring on the cleaning cover and replace it, if necessary.
- Clean the fuel tank.
- Install the cleaning cover with O - ring.
- Fold the front cover up and attach with hex head screws.
- Fill the fuel tank.


5.7.4 Change the fuel filter cartridges

The fuel primary filter with water separator, water level sensor and integrated manual refueling pump is on the right hand side of the Diesel engine.

Depending on the Diesel engine assembly, the fuel primary filter is equipped with a fuel preheating system.

Make sure that:

- the machine is in maintenance position,
- the left engine compartment door is open,
- an original LIEBHERR filter cartridge is available.



Sight gauges

Check oil level

The sight gauges for the hydraulic tank are located on the right hand side in the step.


- Check the oil level on the sight gauges.
 - With retracted hydraulic cylinders, the oil level may not exceed the center of the upper sight gauge.
 - With extended hydraulic cylinders, the oil level may not drop below the center of the lower sight gauge.
- If the oil level is below the nominal height: Add hydraulic oil.
- Open the right cover door.



Hydraulic tank – breather screw

Add hydraulic oil


- Relieve tank pretension: Back the breather screw 1 on the hydraulic tank out by two turns.



Filter cover

- Remove plugs 2.

For arc welding, in addition to disconnecting the battery, also disconnect the electronic box on the Diesel engine.



Unplug the Diesel engine - electronic box

Unplug the Diesel engine - electronic box

The Diesel engine - electronic box is installed in the engine compartment on the left hand side on the Diesel engine.


- Unplug plug 2 on the Diesel engine - electronic box 1.

5.11.1 Check the indicator lights and illumination

For the location of the lights and the indicator lights on the indicator unit, see chapter "Operation".

- Start the Diesel engine and check the lights and indicator lights to ensure they work.

5.11.2 Batteries



Battery compartment

- Open the battery compartment door.

Check the fluid level and the terminals

The batteries are located in the battery compartment and are accessible after opening the battery compartment door.

For proper function of the machine, it is important that the batteries are always in proper condition.


Make sure that:

- the machine is in maintenance position,
- the battery compartment door is open,

- Place a container under the drain plug.
- Remove both oil filler plugs 2.
- Remove the oil drain plug 1.
- Drain the oil into the container.
- Check the oil for mechanical contamination.
- Clean and reinsert the oil drain plug 1.


– Note the tightening torque of 120 Nm!

To drain the gear oil completely from the gear, the oil must also be drained from the inside of the gear.




Travel gear - inside

- Clean the area around the oil drain plug 3.
 - Place a container under the oil drain plug 3.
 - Turn out the oil drain plug 3.
 - Let the oil drain into the container.
 - Check the oil for mechanical contaminants.
 - Clean the oil drain plug 3 and reinstall.
- Note the tightening torque of 120 Nm!



Travel gear


- Add oil to the lower edge of the filler port via the oil filler plug 2.
 - Clean the oil filler plug 2 and reinstall.
- Note the tightening torque of 120 Nm!



407097

Check the side play


- Measure the existing play between the track roller frame and the outer guide plate.



407098

Correct the side play

- If the maximum permissible play is being exceeded, remove inside and / or outer shims.
 - There may never be a difference of more than 1 shim between the number of inside shims and the number of outside shims.
 - If there are no more shims available, replace the guide plates.



407099

Lift the idler

Check / adjust the vertical play

- Drive onto a wooden block to lift the idler until the claws touch the guide rails.


5.14.6 Clean the tracks

Make sure that:

- the machine is in maintenance position.

DO NOT operate the machine, if rocks, wood or metal pieces, wires or cables are stuck in the tracks.

Dried or frozen mud as well as rocks or other foreign matter in the track sections can cause severe damage, if the machine is put in operation or if the operator tries to free the machine by force.



407109


Turning the machine off in freezing temperatures

If temperatures are below freezing, park the machine on wooden boards to prevent the chains from freezing to the ground.

If the machine is frozen to the ground, heat the track pads carefully to free the machine.

Never try to move a frozen machine by force, this can cause significant damage.

- Check the tracks, clean or repair as necessary.



407036

Wet cleaning

After cleaning the machine with hot water or steam, all grease points on the machine must be re-lubricated!

- Clean the machine with steam.
- Grease all lube points on the machine.

5.14.7 Check track wear

The tracks are maintenance free, except for the wear of some parts.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL