


## CALIFORNIA

### Proposition 65 Warning

**WARNING:** Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

**WARNING:** Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects, and other reproductive harm. **Wash hands after handling.**

# ***Datatronic CCD***



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 1.1 General

### 1.1.1 General

T003109

The on-board computer (Datatronic CCD) is a measuring and setting unit providing information that helps to make optimum use of the tractor. It is located on the armrest in the cab.

The Datatronic CCD comes on automatically when the tractor's ignition is switched on. The multi-colour LED (9) *fig. 1* lights up in green. When the ignition is switched off, the Datatronic CCD stores all the information.

The controller's front panel is fitted with switches that provide access to the various applications displayed on the screen.




Fig. 1.

1009066

The Datatronic CCD enables parameters to be set for the following applications:

- Settings
- Transmission
- Dyna-TM
- Headland
- Valves
- Instant
- Average
- Efficiency
- Rear linkage
- Front linkage
- Dual Control
- Pointes
- Memory name
- Isobus
- Task Controller
- Video

### Icon (3) *fig. 1* selected

When the icon corresponding to the Memory name application is selected (  ), the window *fig. 5* opens, providing access to this application.





Fig. 5.

1009012

### Icon (4) *fig. 1* selected

When the icon corresponding to the Settings application is selected (  ), the window *fig. 6* opens, providing access to this application.

If no keys are pressed for 10 seconds after start-up, the Tractor application opens automatically.



Fig. 6.

1009017

## 3. Settings application

<b>3.1</b>	<b>General</b> .....	33
3.1.1	General .....	33
<b>3.2</b>	<b>Description of the Settings application</b> .....	34
3.2.1	Description of the Settings application .....	34
<b>3.3</b>	<b>Modifying the settings in the Settings application</b> .....	36
3.3.1	Settings for units, language, decimal display, date and time. ....	36
3.3.2	Settings for brightness, sound and number of Isobus implements. ....	40
3.3.3	Settings for additional functions. ....	42



### Adjusting the sound

Turn the encoder to select the appropriate value between 0 and 100%.

Validate by pressing the  key or by pressing the encoder, or cancel by pressing the  key.




Fig. 13.

1008931

### Adjusting the brightness

Turn the encoder to select the appropriate value between 10 and 100%.

Validate by pressing the  key or by pressing the encoder, or cancel by pressing the  key.

There are 2 brightness settings (day and night). The Datatronic CCD automatically switches to night mode when the sidelights are switched on.




Fig. 14.

1008932

## 4.2 Dyna-TM application

### 4.2.1 General

T003114

This application displays and adjusts the settings for DTM mode (Dynamic Transmission Management).

This application makes it possible to adjust the following settings:


- Engine speed lower limit in DTM mode
- Engine speed upper limit in DTM mode
- Triggers where the limits are applied

### 4.2.2 Description of the Dyna-TM application

T003115

When the Dyna-TM application is selected, the screen *fig. 1* is displayed.

- (1) Engine speed lower limit
- (2) Engine speed upper limit
- (3) Triggers where the limits are applied

On the right-hand side of the screen, the icon  is displayed at the top of the Dyna-TM application. This accesses the window where the three different settings can be adjusted.





Fig. 1.

1008835

### 4.2.3 Modifying the settings in the Dyna-TM application

T003116

When the Dyna-TM application is selected, pressing the switch that corresponds to the icon  opens the various settings windows.

This window displays the following settings values.



Insert the distance to travel 1 m (3,28 ft) before the next action.



Insert the distance to travel 2 m (6,56 ft) before the next action.



Insert the distance to travel 3 m (9,84 ft) before the next action.



Insert the distance to travel 4 m (13,12 ft) before the next action.



Insert the distance to travel 5 m (16,40 ft) before the next action.



Stop additional relay control



Additional relay control



Place rear PTO in neutral



Select rear PTO 540 rpm speed



Select rear PTO economy speed



Select rear PTO 1000 rpm speed



Activate Auto-Guide



Deactivate Auto-Guide



Insert a pause



Activate camera

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 4.5 Instant counter application

### 4.5.1 General

T003117

This application provides the following information for a specified job:

- Area worked
- Area worked per hour
- Fuel consumption
- Fuel consumption per hour
- Distance covered
- Fuel consumption per area worked

These values are calculated instantly according to the forward speed and the working width.

### 4.5.2 Description of the Instant counter application

T003118

When the Instant Counter application is selected, the screen *fig. 1* is displayed.


- (1) Area worked
- (2) Area worked per hour
- (3) Fuel consumption
- (4) Fuel consumption per hour
- (5) Distance covered
- (6) Fuel consumption per area worked

On the right-hand side of the screen, there are three symbols displayed at the top of the Instant Counter application. These are used to select:



Memory name selection for counting.





**NOTE:** Apply the correct parameters (work trigger and implement width).



Manual counting. It is also possible to access automatic counting.



Implement real and instant working width. If the implement is not working over its entire width, the width can be modified in real time (in the case of points or overlaps).

The colour code representing the effective working width of the implement is divided into four sections: , , , and .





Fig. 1.

1008855

### 4.5.3 Modifying the settings in the Instant application

T003120

When the Instant application is selected, pressing the switch corresponding to the icon  opens the Memory name screen.

– 2<sup>nd</sup> zoom




Fig. 5.

1018963

– 3<sup>rd</sup> zoom




Fig. 6.

1018964

– 4<sup>th</sup> zoom




Fig. 7.

1018965

- Use the encoder to select the upper section of screen (B) [fig. 2](#), and press the encoder.




Fig. 2.

1009210

- The window [fig. 3](#) is displayed.
- Turn the encoder to select the required Dual mode and confirm by pressing the encoder.




Fig. 3.

1009211





## 4.11.3 Front Dual Control

### 4.11.3.1 Description of the Front Dual Control application

T003260

When the Front Dual Control application is selected, the window [fig. 4](#) is displayed.

- (A) Rear Dual Control mode selected
- (1) Value of the raised position of the implement lifting ram
- (2) Value of the current position of the implement lifting ram
- (3) Value of the lowered position of the implement lifting ram
- (4) Position of the spool valve control for the lifting implement ram

-  Dual Control activation
-  Dual Control deactivation
-  Storing the value
-  Recopy function: When this function is activated, modifications to the rear linkage depth during use are transferred to the front linkage.
-  Calibration




Fig. 16.

I019012

#### 4.11.5.2 Adjusting the rear implement position sensor

T007432

To ensure correct operation of the TIC, the rear implement depth wheel position sensor must be calibrated.

**IMPORTANT:** This operation must be performed on first use or as soon as work is carried out on the rear implement depth wheel position sensor.

Calibration is carried out via the Datatronic CCD calibration screen.

**IMPORTANT:** For efficient calibration, the rear implement depth wheel must be able to move from its highest position to its lowest position. To do this, lift the implement to prevent the shares from touching the soil when the implement is in low position.

The procedure for calibrating the implement sensor is identical to that described in the Rear Dual Control application, [see §4.11.4.2, page 96](#).


#### 4.11.5.3 Storing raised and lowered linkage positions of the trailed implement

T007433


##### General

For optimum operation, the Datatronic CCD must know the raised and lowered position of the implement. The hitched implement must be equipped with a position sensor connected to the rear of the tractor.





##### Storing the raised position

1. Place the implement in the raised position using the lift ram spool valve control. When the spool valve control is actuated, the raised position value varies.
2. Press the switch corresponding to the icon  to store the raised position.

##### Storing the lowered position

1. Place the implement in the lowered position using the lift ram spool valve control. When the spool valve control is actuated, the lowered position value varies.
2. Press the switch corresponding to the icon  to store the lowered position.

Use the encoder or the corresponding switch to select the required function to set:

- Storage setting A 
- Storage setting B 
- Maximum speed setting 
- Activation response time setting for the required speed 

### Storage setting A

This window is used to set the storage setting A for a speed that varies from 800 to 2100 rpm. Speeds can be set in increments of  $\pm 10$  rpm.




Fig. 3.

1026356

### Storage setting B

This window is used to set the storage setting B for a speed that varies from 800 to 2100 rpm. Speeds can be set in increments of  $\pm 10$  rpm.





Fig. 4.


1026357


This screen displays the eight memories and any names that have been assigned to them. Select one of the eight recorded memories by selecting the frame with the encoder.

For example *fig. 2*, memory 1 is named "BLUEBIRD 4M".

Press the encoder to select a memory on the screen.

To activate a memory, press the switch corresponding to the  icon.

To deactivate a memory, press the switch corresponding to the  icon.

When a memory is active, the  icon is displayed.









Fig. 2.

1026417

### Displaying the work values (A *fig. 1*)

This screen displays the work values for the selected memory, namely:

(1) Implement stored width

-  Surface area worked by the stored implement
-  Work consumption
-  Distance covered
-  Time spent
-  PTO operating time




Fig. 3.

1026434

- Always in forward travel




Fig. 22.

1027829

- External signal





Fig. 23.

1008970

### 5.3.2 Modifying the options and memories

T011268

When a memory is selected, pressing the switch that corresponds to the icon  opens a new window [fig. 24](#).

## 6.4 Using an Isobus joystick

### 6.4.1 Using an Isobus joystick

T003159

When using an Isobus implement that requires a joystick for certain functions, a joystick can be connected inside the cab to the connection (A) [fig. 1](#) which can be set via the Datatronic CCD.

The joystick will appear as an Isobus implement on the Datatronic CCD.

Follow the instructions in the joystick user manual to set the parameters as required.




Fig. 1.

1009064

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL