

# 544G, 544G LL, and 544G TC Loaders 624G Loader 644G Loader (Serial No. 553285— )



JOHN DEERE

## OPERATORS MANUAL

544G, 544G LL, and 544G TC Loaders 624G Loader  
644G Loader (Serial No. 553285— )

OMT158711 Issue L5 English

**John Deere Dubuque Works**

**OMT158711 Issue L5**

(Mark old manual OMT154907 L4 for  
machines up to Serial No. 553284)

LITHO IN U.S.A.  
ENGLISH



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# Safety

## RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC88

## UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88


## FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




DX,READ -19-03MAR93

TS201 -UN-23AUG88



## PROTECT AGAINST FLYING DEBRIS

When you drive connecting pins in or out, guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.




02T,05,J45 -19-30MAY90

T6642DK -UN-18OCT88

## WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR2 -19-03MAR93

TS206 -UN-23AUG88

## PROTECT AGAINST NOISE


Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




DX,NOISE -19-03MAR93

TS207 -UN-23AUG88

<b>⚠ DANGER/POISON</b>			
 <b>SHIELD EYES</b> EXPLOSIVE GASES CAN CAUSE BLINDNESS OR INJURY	 <b>NO SPARKS, FLAMES, OR SMOKING</b>	 <b>SULFURIC ACID CAN CAUSE BLINDNESS OR SEVERE BURNS</b>	 <b>FLUSH EYES IMMEDIATELY WITH WATER</b> <b>GET MEDICAL HELP FAST</b>
<b>KEEP OUT OF THE REACH OF CHILDREN. DO NOT TIP. KEEP VENT CAPS TIGHT AND LEVEL.</b>			

T7593AC -19-30AUG91

T6976AE -UN-30JAN89



TX,06,DH2949 -19-12MAY93

<b>⚠ CAUTION</b> This machine may be equipped with batteries on each side. Always disconnect both ground straps before working on electrical system. <small>T146438</small>
--

T146438

T7939AK -19-22MAR93



T8029AF -UN-15JUN93


TX,06,DH2950 -19-16JUN93

### ENGINE COOLANT TEMPERATURE GAUGE

The first arrow will flash until engine temperature warms to 38°C (100°F).

Audible alarm will sound once when temperature first reaches 99-103°C (210-217°F).

All the arrows will flash, STOP indicator light will flash, and audible alarm will sound when temperature reaches above 103°C (217°F). If all 9 arrows are ON but not flashing, system has a malfunction. Stop machine and allow engine to cool. Shut off engine and take corrective action.



T7747AU (CV)


-UN-19MAY92  
T7747AU

TX,10,JC244 -19-29NOV94

### FUEL GAUGE

First arrow will flash if fuel is low or system has a malfunction.

Always fill fuel tank at the end of the day to eliminate condensation in fuel tank.



T7747AV (CV)


-UN-19MAY92  
T7747AV

TX,10,DH2164 -19-29NOV94

### TRANSMISSION OIL TEMPERATURE GAUGE

Audible alarm will sound once when temperature first reaches 127-132°C (260-270°F).

All arrows will flash, STOP indicator light will flash, and audible alarm will sound when temperature reaches above 133°C (271°F). If all 9 arrows are ON but not flashing, system has a malfunction. Stop machine and allow engine to cool. Shut off engine and take corrective action.



T7747AW (CV)

-UN-19MAY92  
T7747AW

TX,10,JC245 -19-29NOV94

## OPERATING LIGHTS




Press light switch (A). Lights (E and I) will come on.

Press light switch (B). Lights (D and G) will come on.

Press turn signal switch to left or right position. One turn indicator light on monitor, if equipped, will be on. One front amber light (F) and one rear amber light (H) will be flashing.

Press hazard light switch (C). Both front amber lights (F) and both rear amber lights (H) will be flashing.

- A—Operating Light Switch
- B—Work Light Switch
- C—Hazard Light Switch
- D—Front Work Lights—If Equipped
- E—Headlights
- F—Turn Signals/Hazard Lights
- G—Rear Work Lights—If Equipped
- H—Turn Signals/Hazard Lights
- I—Tail Lights/Brake Lights



-UN-02DEC94  
T8373BD

-UN-10AUG92  
T7773AX

-UN-10AUG92  
T7773AY

TX,10,DH2144 -19-29NOV94

## STARTING FLUID—IF EQUIPPED (COLD WEATHER STARTING AID)

### • USING STARTING FLUID


**⚠ CAUTION:** Prevent possible injury from exploding container. Starting fluid is highly flammable. Keep container away from heat, sparks, and open flame. Contents are pressurized. **DO NOT** puncture or incinerate container. Remove container from machine if engine does not need starting fluid.



**IMPORTANT:** Prevent damage to engine. Use starting aid when temperatures are below 4°C (40°F) and only when engine is COLD.

1. Turn key switch clockwise to START position.

**IMPORTANT:** Excess starting fluid could damage engine; press starting aid button only when engine is cold and cranking. Starting aid fluid is being injected into engine as long as you press button.




2. After one or two revolutions of engine crankshaft, press starting aid button (A) at short intervals. Crank engine for 20 seconds maximum, then allow 2 minutes between cranking periods.

### • REPLACING STARTING AID CAN

1. Turn container (B) counterclockwise to remove the container and starting aid can.
2. Remove safety cap and spray button from new can.
3. Place new can in container.
4. Turn container clockwise in starting aid base (C) to install starting aid can.

T7527EF 



### • OPERATING MACHINE WITHOUT STARTING AID CAN INSTALLED

**IMPORTANT:** Protect starting aid components from possible damage. Install the starting aid can container upside down.

Remove container from base, turn upside down, and reinstall.

-UN-23AUG88

TS281

-UN-19MAY92

T7747BT

-UN-01AUG91

T7527EF

## RIDE CONTROL SWITCH—IF EQUIPPED


**CAUTION:** Prevent possible injury from unexpected boom movement. The bucket may “jump up” when ride control switch is turned ON.

Turn ride control switch ON to improve machine ride and reduce tire flexing when traveling over rough terrain at a high speed with loaded bucket.

If engine is stopped with ride control switch in ON position, ride control is automatically disengaged. Start the engine, press switch to OFF and then back to ON to engage ride control. Switch will be backlit when engaged (ON).

To discharge the energy in the ride control accumulator, do the following:

1. Make sure area around bucket is clear.
2. Lower bucket to ground.
3. Stop engine.
4. Turn key switch to ON.
5. Move hydraulic control lever to float detent position.
6. Cycle ride control switch from OFF to ON.
7. Push boom down switch to release accumulator pressure.




T7829AV -UN-08SEP92

TX,30,DH2505 -19-16JUN93

## STOPPING THE MACHINE

Depress left brake pedal (A) or right brake pedal (B) to stop the machine.

Left brake pedal also serves as a clutch cut-off pedal when clutch cut-off switch is in “clutch disengaged” position.



T7747BS -JUN-19MAY92


TX,30,DH2173 -19-31JUL92

## ADJUSTING RETURN-TO-DIG

1. Start engine.
2. Move control lever to return-to-dig detent position and release.

*NOTE: On 544G LL and 544G TC, the return-to-dig switch and magnet are located below the cylinder.*

3. After control lever returns to neutral, make a mark (B) on magnet and return-to-dig switch.
4. Position the boom and bucket in the desired return-to-dig position. Stop engine.
5. Loosen cap screws (D) and slide bar to align marks on magnet and return-to-dig switch.
6. Loosen cap screws (C) and adjust clearance (A) between magnet and return-to-dig switch to  $9 \pm 3$  mm ( $0.35 \pm 0.12$  in.).
7. Raise boom. Cycle bucket from full rollback to dump. Check return-to-dig for correct adjustment.



- A—Clearance
- B—Mark
- C—Cap Screws
- D—Cap Screws

T6599AD -JUN-21OCT88

TX,35,DH2184 -19-02OCT92


## LIFTING THE MACHINE

**⚠ CAUTION:** Prevent possible injury from unexpected machine movement. Clear all bystanders from lifting area. Select correct lifting cable strength for weight of machine. Test lift by raising machine 0.3 m (1 ft) off the ground.

### SPECIFICATIONS

Approximate machine weight (544G) . . . . .	10 262 kg (22,624 lb)
Approximate machine weight (LL) . . . . .	10 377 kg (22,881 lb)
Approximate machine weight (TC) . . . . .	10 466 kg (23,078 lb)
Approximate machine weight (624G) . . . . .	12 398 kg (27,338 lb)
Approximate machine weight (644G) . . . . .	15 666 kg (34,538 lb)

1. Attach cables (A) to machine so cables do not rub machine.
2. Attach a tether cable to machine to control machine as it is lifted.
3. Test lift by raising machine 0.3 m (1 ft) off the ground.
4. Lift machine and swing to unloading area.



TX,40,DH2187 -19-12SEP92

T7477AV -JUN-19MAR91

## PREPARE MACHINE FOR MAINTENANCE

Before performing maintenance procedures given in the following chapters, and before leaving the operator's seat, park the machine as described below unless another position is specified in the procedure.



1. Park machine on a level surface.
2. Lower bucket to ground.

*NOTE: Boom down switch (C) must be pushed while moving control lever forward to lower boom with engine stopped.*

3. Move transmission control lever (A) to neutral "N". Engage neutral lock (B).

**CAUTION:** Prevent possible injury from unexpected machine movement. Never rely on transmission control lever alone to keep machine from moving. Machine can unexpectedly roll or move under power, resulting in death or serious injury. Always engage park brake to hold machine.

4. Engage park brake.
5. Turn key switch to STOP. If maintenance must be performed with engine running, do not leave machine unattended.
6. Turn battery disconnect switch OFF, if equipped.



T7747BR -UN-19MAY92

-UN-02DEC94

T8375AM

Maintenance—As Required

644G

Tire Size	Type	Ply Rating	kPa	Operating Pressure*	
				bar	psi
16.0 X 24	G2	12	380	3.8	55
20.5 X 25	L2	12	275	2.8	40
20.5 x 25	L2	16	345	3.4	50
20.5 x 25	L3	16	345	3.4	50
20.5R x 25	L2 or L3 Equiv (I) Star		**Front 415	4.1	60
			**Rear 205	2.0	30
			Rear, alternate 310	3.1	45
23.5 x 25	L2	12	240	2.4	35
23.5 x 25	L3	16	310	3.1	45
23.5 x 25	L3	20	380	3.8	55
23.5R x 25	L2 or L3 Equiv (1) Star		**Front 275	2.8	40
			**Rear 205	2.0	30
			Rear, alternate 240	2.4	35
28L x 26	LS-2	14	170	1.7	25

\*Shipping pressure may vary from operating pressure.

\*\*These radial tire pressures are recommended for optimum traction and tire wear under typical conditions. If a higher rear tire pressure is used, it should not exceed the alternate pressure listed.

TX,55,DH2711 -19-12MAY93

**TIGHTEN WHEEL RETAINER CAP SCREWS**

*NOTE: Tighten cap screws after first 10 hours, then again after first 50 hours of loaded operation. After that, tighten as required.*

Tighten wheel cap screws to 542 N·m (400 lb-ft).

TX,55,DH2551 -19-16JUN93

## CHECK TRANSMISSION OIL LEVEL


**IMPORTANT: Prevent possible transmission damage. DO NOT operate engine when transmission oil level is low.**

1. Before starting engine, check oil level on dipstick (A). If oil is to upper mark when oil is cold, there is sufficient oil to start the engine.
2. If necessary, add oil to filler tube. (See Fuels and Lubricants chapter.)
3. Install dipstick.
4. Start engine.
5. Engage service brakes. Move clutch cut-off switch up, to disengaged position.
6. Release park brake.
7. Move transmission control lever to 3rd speed forward “F” position.

Operate engine at fast idle for 30 seconds. Reduce engine speed to slow idle and place transmission control lever in neutral “N”, for 15 seconds.

Repeat this step until transmission oil reaches normal operating temperature.

8. Move transmission control lever to neutral “N”, and engage neutral lock. Lower all equipment to ground.
9. Engage park brake.
10. Release service brakes.
11. Check oil level with engine at slow idle. Oil must be between marks on dipstick.



624G Shown

T7773CP  
-UN-21AUG92

TX,60,DH2214 -19-02OCT92

## CHECK RADIATOR COOLANT LEVEL

**⚠ CAUTION:** Prevent possible injury from hot spraying water. **DO NOT** remove radiator filler cap unless engine is cool. Then turn cap slowly to the stop. Release air to relieve all pressure before you remove cap.

1. Slowly remove cap. Coolant level must be at bottom of the filler neck.

*NOTE: If radiator coolant level is low, check for leaks on radiator cap, and hose connections between radiator and coolant recovery tank.*

2. Add coolant, if necessary.

3. Install filler cap.



T6642EK -UN-01NOV88

TX,75,DH3501 -19-29NOV94

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**CLEAN ENGINE CRANKCASE VENT TUBE  
(A)**




T7829AK -UN-31AUG92

544G Shown



T7829AL -UN-31AUG92

624G Shown



T7829AM -UN-31AUG92


644G Shown

TX,85,DH2230 -19-02OCT92

## LUBRICATE FRONT DRIVELINE SUPPORT BEARING

**⚠ CAUTION:** Prevent possible injury from unexpected machine movement. Install frame locking bar before lubricating.

Lubricate until grease escapes around seal. (See Fuels and Lubricants chapter.) Grease every 250 hours if operating in deep mud or water.



One Point

T7114AS -UN-23AUG89

TX,86,DH2553 -19-02OCT92

The DB4 Drive Gear Puller Kit now can be used on Stanadyne's DB4 and DB2 Injection Pumps. Earlier pumps displayed the metal plate (A) attached to the fuel injection pump's mounting flange.



TX,90,RR,249 -19-29AUG94

1. Park machine on a level surface.
2. Lower bucket to ground.
3. Move transmission control lever (A) to neutral "N". Engage neutral lock (B).

**⚠ CAUTION: Prevent possible injury from unexpected machine movement. Never rely on transmission control lever alone to keep machine from moving. Machine can unexpectedly roll or move under power, resulting in death or serious injury. Always engage park brake to hold machine.**

4. Engage park brake.

**IMPORTANT: Turbocharger may be damaged if engine is not properly shut down.**

5. Run engine at 1/2 speed without load for 2 minutes before stopping, to avoid damage to turbocharger. Release accelerator pedal to slow idle.
6. Turn key switch to STOP.
7. Turn battery disconnect switch OFF, if equipped.

TX,90,DH2967 -19-04AUG94

## USING BATTERY CHARGER

**⚠ CAUTION:** Prevent possible injury from exploding battery. Do not charge a battery if the battery is frozen or it may explode. Warm battery to 16°C (60°F). Disconnect battery ground (—) clamp before you charge batteries in the machine to prevent damage to electrical components.



**IMPORTANT:** Do not use a battery charger as a booster if a battery has a 1.150 specific gravity reading or lower. Turn off charger before connecting or disconnecting it.

A battery charger may be used as a booster to start engine.

TS204 -UN-23AUG88

TX,FF,121 -19-15MAR93

## REPLACING BATTERIES

Your machine is equipped with a negative ground electrical system. It uses one or two 12-volt batteries. If one of the two batteries fails, both batteries must be replaced. Use only batteries meeting following specifications.

BCI Group Size: 27

**544G, 624G:**

625 cold cranking amps at -18°C (0°F)  
160 minutes reserve capacity at 25 amps

**644G:**

925 cold cranking amps at -18°C (0°F)  
180 minutes reserve capacity at 25 amps

TX,90,DH2264 -19-16SEP92



## BLEEDING BRAKES

**⚠ CAUTION:** Escaping fluid under pressure can penetrate skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury or gangrene may result.

*NOTE: Two people are required to bleed brake system oil, one to operate brake valve and the other to open and close bleed screws.*


1. Install frame locking bar.
2. Start engine and run at slow idle.
3. Push and hold brake pedal down until brake bleeding procedure is complete.
4. Put a clear plastic tube on bleed screw (B) to route flow to hydraulic reservoir filler tube (A) or to a container.
5. Open one bleed screw on differential and axle assembly until hydraulic oil starts to flow. Close bleed screw when oil is free of air.
6. Repeat steps 2—4 for each bleed screw (two bleed screws on each differential).
7. Release brake pedal and stop engine.
8. Check hydraulic oil level. (See Maintenance—Every 10 Hours or Daily chapter.)



X9811 -JUN-23AUG88

T6522BR -JUN-20OCT88

**SERVICE RECOMMENDATIONS FOR INCH SERIES FOUR BOLT FLANGE FITTINGS**



**A—Sealing Surface**

**B—Split Flange**

**C—Pinched O-Ring**

**D—Single Piece Flange**

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install cap screws. Flange must

be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.

5. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.


DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

**TORQUE CHART\***

Nominal Flange Size	Cap Screw Size	N-m		lb-ft	
		Min	Max	Min	Max
1/2	5/16-18 UNC	20	31	15	23
3/4	3/8-16 UNC	28	54	21	40
1	3/8-16 UNC	37	54	27	40
1-1/4	7/16-14 UNC	47	85	35	63
1-1/2	1/2-13 UNC	62	131	46	97
2	1/2-13 UNC	73	131	54	97
2-1/2	1/2-13 UNC	107	131	79	97
3	5/8-11 UNC	158	264	117	195
3-1/2	5/8-11 UNC	158	264	117	195
4	5/8-11 UNC	158	264	117	195
5	5/8-11 UNC	158	264	117	195

\*Tolerance ± 10%. The torques given are enough for the given size connection with the recommended working pressure. Torques can be increased to the maximum shown for each cap screw size if desired. Increasing cap screw torque beyond this maximum will result in flange and cap screw bending and connection failures.

Operational Checkout



T7773BB -UN-21AUG92

*LOOK:* Seat belt indicator must go out after 5 seconds after engine starts.

*LOOK:* Monitor must display engine rpm and gauges must indicate only one reading.

Release park brake.

*LOOK:* Park brake indicator must go out.


*NOTE:* It is normal for Engine Oil Pressure, Brake Pressure, and Transmission Pressure indicators to stay on 4—6 seconds after engine starts.

**OK:** Go to next check  
**NOT OK:** Check for an unhooked wiring connector.  
**IF OK:** Go to your authorized dealer.

TX,95,DH2307 -19-07OCT92

**MONITOR PRIMARY AND SECONDARY LEVEL CHECKS**

Engine running.



T7747AG1 -UN-24AUG92

Engage park brake

*LOOK:* Park brake indicator must come ON.

Move transmission control lever to forward "F".

*LOOK:* Park brake indicator must remain ON and STOP indicator must come ON and flash at 1 second intervals.


Engage park brake.

**OK:** Go to next check  
**NOT OK:** Go to your authorized dealer.

TX,95,DH2308 -19-07OCT92

**TRANSMISSION TEMPERATURE GAUGE CHECK**

Engine running.



T7773B02 -UN-05AUG92

Release park brake.

Move clutch cut-off switch to the ON position.

Apply service brakes.

Move transmission control lever to 3rd gear forward.

Increase engine speed to fast idle for 30 seconds.

*LOOK:* Transmission temperature indicator arrow must move to the right.





T7773BF -UN-05AUG92





**OK:** Go to next check.  
**NOT OK:** If gauge shows solid arrows, check connector at sender.  
**IF OK:** Go to your authorized dealer.

TX,95,DH2309 -19-02OCT92

Operational Checkout

<p><b>RETURN-TO-DIG CHECK</b></p> <p>Run engine at slow idle.</p>	 <p>T7827A13 -UN-24AUG92</p> <p>Position bucket fully dumped just above ground level.</p> <p>Move control lever to return-to-dig detent position and release.</p> <p><i>LOOK: Bucket must rollback to the level position and control lever must return to neutral.</i></p> <p><i>NOTE: If bucket is in a rolled back position when key switch is turned ON, control lever must be returned to neutral manually if placed in the return-to-dig detent position. After bucket is dumped once, return-to-dig will work normally.</i></p>	<p><b>OK:</b> Go to next check</p> <p><b>NOT OK:</b> Check fuse. <b>IF OK:</b> Adjust switch. See Adjusting Return-To-Dig in Operating the Machine chapter.</p> <p>TX,95,DH2512 -19-04NOV92</p>
<p><b>BOOM HEIGHT KICKOUT CHECK—IF EQUIPPED</b></p> <p>Run engine at slow idle.</p>	 <p>T7825BL -UN-24AUG92</p> <p>Position bucket flat on ground.</p> <p>Move control lever to boom raise detent position and release.</p> <p><i>LOOK: Boom must raise to the set height and stop. Control lever must return to neutral.</i></p>	<p><b>OK:</b> Go to next check</p> <p><b>NOT OK:</b> Check fuse. <b>IF OK:</b> See Adjusting Boom Height Kickout in Operating the Machine chapter.</p> <p>TX,95,DH2513 -19-11SEP92</p>
<p><b>PIN DISCONNECT CYLINDER CHECK (544G-TC ONLY)</b></p> <p>Engine running.</p>	<p>Run engine at slow idle.</p> <p>Lower boom to ground.</p> <p>Push and hold down pin disconnect switch.</p> <p><i>LOOK: Pin disconnect cylinder must retract both pins, while switch is depressed.</i></p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Hold a screwdriver blade against the end of the solenoid valve and check for magnetism with the switch pushed.</p> <p>If the problem is electrical, check fuse. <b>IF OK:</b> Go to your authorized dealer.</p> <p>If the problem is hydraulic, go to your authorized dealer.</p> <p>TX,95,DH2514 -19-02OCT92</p>

Operational Checkout

<p><b>LOAD CENTER DOOR CHECK</b></p>	 <p>T7832AK -UN-27AUG92</p>	<p>Unlock and open door on right side of operator's station.</p> <p>Close and lock door.</p> <p><i>LOOK: Door must open and close smoothly.</i></p> <p><i>FEEL: Lock must operate freely and key MUST NOT stick in lock.</i></p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Lubricate hinges. Lubricate or repair lock.</p> <p>TX,95,DH2528 -19-18SEP92</p>
<p><b>ENGINE SIDE PANELS CHECK</b></p>	 <p>T6633AS -UN-18OCT88</p>	<p>Unlock and open side panel (A).</p> <p>Latch side panel in open position.</p> <p>Pull rear of panel up and slide out side panel (B).</p> <p>Install side panel (B).</p> <p>Close panel (A).</p> <p><i>LOOK: Panels must open and close smoothly.</i></p> <p><i>FEEL: Latch must operate freely and locking tab must be able to accept a padlock.</i></p> <p>Repeat with other side.</p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Lubricate hinges. Repair latch.</p> <p>TX,95,DH2529 -19-29AUG92</p>
<p><b>RADIATOR CAP ACCESS DOOR CHECK</b></p>	 <p>T6633AY -UN-18OCT88</p>	<p>Open and close access door on top of grille housing.</p> <p><i>LOOK: Door must move freely. Locking pin for padlock MUST NOT be bent.</i></p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Lubricate hinges. Repair door.</p> <p>TX,95,DH2530 -19-31AUG92</p>
<p><b>FRAME LOCKING BAR CHECK</b></p>	 <p>T7799CX -UN-23SEP92</p>	<p><i>LOOK: Red frame locking bar must be pinned to engine frame below left side cab step.</i></p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Order new parts and install new locking bar and pins.</p> <p>TX,95,DH2531 -19-18SEP92</p>
<p><b>BOOM LOCK CHECK</b></p>	<p><i>LOOK: Red boom lock must be fastened to front frame at hinge in vertical position.</i></p>	<p><b>OK:</b> Go to next check.</p> <p><b>NOT OK:</b> Order new parts and install new boom lock.</p> <p>TX,95,DH2532 -19-02OCT92</p>	

## *Troubleshooting*

<b>Symptom</b>	<b>Problem</b>	<b>Solution</b>
	Excessive connecting rod bearing clearance.	See your authorized dealer.
	Cracked cylinder block.	See your authorized dealer.
	Piston cooling orifice missing.	See your authorized dealer.
	Leakage at internal oil passage.	See your authorized dealer.
<b>High Oil Pressure</b>	Wrong viscosity oil (too thick).	Check for antifreeze in oil. Change oil.
	Oil pressure gauge or sender.	See your authorized dealer.
	Oil pressure regulating valve.	See your authorized dealer.
<b>Engine Overheats</b>	Low coolant level.	Fill cooling system and check for leaks.
	Low engine oil level.	Add oil.
	Loose or broken fan belt.	Tighten or replace belt.
	Fan on backwards, damaged, or wrong fan installed.	Check for correct fan installation.
	Radiator dirty, clogged, or fins damaged.	Check air flow. Clean radiator. Straighten fins.
	Radiator shroud missing, damaged, or baffles missing.	Inspect. Repair or replace.
	Engine overloaded.	Reduce load.
	Incorrect grade of fuel.	Drain fuel tank and add correct fuel.
	Radiator cap.	Replace cap.
	Faulty gauge or sender.	See your authorized dealer.
	Incorrect injection pump timing.	See your authorized dealer.
	Faulty thermostats (stuck).	See your authorized dealer.
	Thermostats missing.	See your authorized dealer.
	Cooling system coated with lime deposits.	Flush cooling system.

**Continued on next page**

## HYDRAULIC SYSTEM

Symptom	Problem	Solution
<b>Noisy Hydraulic Pump</b>	Low oil supply or wrong viscosity.	Fill reservoir with proper oil.
	Suction line clogged or pinched.	Clean or replace line.
	Air in oil.	Check for foamy oil. Tighten connections. Replace O-rings and/or lines.
	Clogged suction strainer.	Inspect and clean strainer in reservoir.
	Loose or missing hydraulic line clamps.	Tighten or replace clamps.
	Hydraulic lines in contact with frame.	Inspect and repair.
	Worn or damaged pump.	See your authorized dealer.
<b>Slow Hydraulic Functions</b>	Cold oil.	Warm the oil.
	Suction line air leak.	Check for foamy oil.
	Low oil supply.	Fill reservoir with recommended oil.
	Wrong oil viscosity.	Use recommended oil.
	Slow engine speed.	Adjust engine speed control linkage. Check fast idle speed. (See Maintenance—Every 1000 Hours chapter.)
	Oil leaking past cylinders or control valve.	See your authorized dealer.
	Blocked or damaged line.	Inspect lines.
	Misadjusted pressure reducing valve.	See your authorized dealer.
	Pilot control valve.	See your authorized dealer.
	Binding loader control valve spool.	See your authorized dealer.
	Secondary steering check valve leaking.	See your authorized dealer.
	Steering valve leaking.	See your authorized dealer.

**Continued on next page**

## Troubleshooting

Symptom	Problem	Solution
	Aerated oil.	Check and add oil.
	Low transmission pressure.	See your authorized dealer.
	Torque converter freewheel clutch.	See your authorized dealer.
	Warped transmission clutch.	See your authorized dealer.
	Brake drag.	See your authorized dealer.
	Clutch cut-off valve sticking.	See your authorized dealer.
	Low engine power.	See your authorized dealer.
<b>Torque Converter Stall RPM Too High</b>	Aerated oil.	See your authorized dealer.
	Converter relief valve stuck open.	See your authorized dealer.
	Torque converter seal leakage.	See your authorized dealer.
	Torque converter not transferring power (bent fins, broken stator).	See your authorized dealer.
<b>Torque Converter Stall RPM Too Low</b>	Low engine power.	See your authorized dealer.
	Mechanical malfunction.	See your authorized dealer.
<b>Transmission Pressure Light Comes On When Shifting From Forward To Reverse (All Other Gears OK)</b>	Low oil level.	Add oil.
	Cold oil.	Warm oil.
	Leak in reverse pack	See your authorized dealer.
<b>Transmission Pressure Light Comes On For Each Shift</b>	Cold oil.	Warm oil.
	No time delay in module.	See your authorized dealer.
	Shorted sensor.	See your authorized dealer.
	Stuck modulation valve.	See your authorized dealer.
	Low transmission pressure.	See your authorized dealer.
	Leak in transmission pressure circuit.	See your authorized dealer.
	Transmission pump.	See your authorized dealer.

Continued on next page

# Storage

## PREPARE MACHINE FOR STORAGE

1. Repair worn or damaged parts. Install new parts, if necessary, to avoid needless delays later.
2. Loosen alternator and fan belts.
3. Clean primary air cleaner element.



-UN-09NOV88

T47764

TX,105,FF1190 -19-03AUG92

**544G LL SPECIFICATIONS**

NOTE: Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with SAE standards. Except where otherwise noted, specifications are based on a machine equipped with all standard, 17.5—25, 12 PR, L3 tires, two rear counterweights, ROPS cab, full fuel tank, and 79 kg (175 lb) operator.

**Engine:**

John Deere 6059T (S.N. 553285— ) . . . . . 89 kW (120 hp)  
 Piston displacement . . . . . 5.884 L (359 cu in.)  
 Air cleaner . . . . . Dual stage dry type with restriction indicator  
 Electrical system . . . . . 12-volt battery with 95-amp alternator  
 Cold cranking capacity at -18°C (0°F) . . . . . 625 amps  
 Reserve capacity . . . . . 160 min.

Torque Converter . . . . . Single phase, single stage

Transmission . . . . . Countershaft, power shift, automatic

**Travel Speeds:**

<b>Forward Speeds:</b>	<b>km/h</b>	<b>mph</b>
1	0—7.4	0—4.6
2	0—12.3	0—7.7
3	0—27.2	0—16.9
4	0—38.4	0—23.8

<b>Reverse Speeds:</b>	<b>km/h</b>	<b>mph</b>
1	0—7.4	0—4.6
2	0—12.3	0—7.7
3	0—27.2	0—16.9

NOTE: All travel speeds are with 20.5—25 tires.

## Specifications

**Brakes, Service:**

- Power-actuated, 4-wheel, inboard-mounted, wet disk
- Foot-operated, by either pedal
- Left pedal also disconnects transmission (if selected by operator)
- External inspection
- Low brake pressure warning light and buzzer in monitor

**Brakes, Park:**

- Expanding shoe on transmission output shaft, foot-operated
- Transmission disconnects with park brake applied
- Warning light in monitor—Dual-level
  - Amber lights with transmission in neutral
  - Red STOP indicator lights, and buzzer sounds with transmission in gear

**Steering:**

- Turning radius (to centerline of outside tire) . . . . . 5.46 m (17 ft 11 in.)
- Rear axle oscillates 26° total

**Tires:**

- 20.5—25, 12 PR L2
- 20.5—25, 16 PR L2
- 20.5—25, 16 PR L3
- 20.5—25, Radial, One Star, L2 equivalent
- 20.5—25, Radial, One Star, L3 equivalent
- 23.5—25, 12 PR L2
- 23.5—25, 20 PR L3
- 23.5—25, Radial, One Star, L3 equivalent

TX,115,DH2354 -19-16JUN93

**DRAIN AND REFILL CAPACITIES:**

	Metric	U.S.
Cooling system . . . . .	28 L	29.5 qt
Fuel tank . . . . .	284 L	75 gal
Engine crankcase and filter . . . . .	24 L	25 qt
Transmission case and filter . . . . .	14.2 L	15 qt
Front differential . . . . .	28.4 L	30 qt
Rear differential . . . . .	28.4 L	30 qt
Hydraulic reservoir . . . . .	115 L	120 qt

TX,115,DH1819 -19-02OCT92

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL