

# 6.8 L OEM Diesel Engines (Final Tier 4/Stage IV/Stage V Platform)



## OPERATOR'S MANUAL

### 6.8 L OEM Diesel Engines (Final Tier 4/Stage IV/Stage V Platform)

OMRG39499 ISSUE 04APR18 (ENGLISH)

#### CALIFORNIA

#### Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:

### **⚠ WARNING**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Additional Proposition 65 Warnings can be found in this manual.

**John Deere Power Systems**

Worldwide Edition  
PRINTED IN U.S.A.

TP-6998 4/18



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Page	Page		
Replacing Air Filter Element.....	70-5	1500 Hours of Operation Service .....	90-2
Inspecting Primary Air Filter Element .....	70-6	1500 Hours of Operation or Every 36	
Air Filter Element Storage .....	70-6	Months Service .....	90-2
Cleaning the Exhaust Filter .....	70-7	2000 Hours of Operation or Every 24	
Replacing Fan Belt .....	70-8	Months Service .....	90-2
Checking Fuses.....	70-9	3000 Hours of Operation or Every 36	
Checking Electrical Wiring And Connections .....	70-9	Months Service .....	90-3
Bleeding Fuel System.....	70-9	4500 Hours of Operation or Every 60	
Checking Air Compressors (If Equipped) .....	70-9	Months Service .....	90-3
Checking Refrigerant (A/C)		6000 Hours of Operation or Every 72	
Compressor (If Equipped).....	70-9	Months Service .....	90-3
Replace Aftertreatment DEF Dosing		Service as Required .....	90-4
System Coolant Filter.....	70-10		
<b>Troubleshooting</b>		<b>Warranty</b>	
General Troubleshooting Information .....	75-1	John Deere Warranty in OEM Applications .....	95-1
Diagnostic Trouble Codes (DTCs) — Listing.....	75-2	Emissions Control System Certification Label.....	95-4
Diagnostic Trouble Codes (DTCs) —		Carbon Dioxide Emissions (CO <sub>2</sub> ) .....	95-5
Operation .....	75-4	EPA Non-road Emissions Control	
Intermittent Fault Diagnostics.....	75-5	Warranty Statement—Compression Ignition ..	95-6
Engine Troubleshooting.....	75-6	CARB Non-road Emissions Control	
Precautions for Electrical System		Warranty Statement—Compression Ignition ..	95-8
When Steam Cleaning Engine .....	75-17		
Engine Wiring Harness Layout.....	75-18		
Precautions For Welding .....	75-23		
6.8 L Wiring Diagram 1.....	75-24		
6.8 L Wiring Diagram 2.....	75-26		
6.8 L Wiring Diagram 3.....	75-28		
6.8 L Wiring Diagram 3A .....	75-30		
6.8 L Wiring Diagram 4.....	75-32		
6.8 L Wiring Diagram 4A .....	75-34		
6.8 L Wiring Diagram 5.....	75-36		
6.8 L Wiring Diagram 6.....	75-38		
6.8 L Wiring Diagram 7.....	75-40		
6.8 L Wiring Diagram 8.....	75-42		
6.8 L Wiring Diagram 9.....	75-44		
6.8 L Wiring Diagram 10.....	75-46		
6.8 L Wiring Diagram 11 .....	75-47		
6.8 L Wiring Diagram 12.....	75-50		
<b>Storage</b>			
Engine Storage Guidelines.....	80-1		
Preparing Engine for Long-Term Storage.....	80-2		
Removing Engine from Long-Term Storage .....	80-3		
<b>Specifications</b>			
General OEM Engine Specifications .....	85-1		
Engine Power and Speed Rating			
Specifications .....	85-2		
Engine Crankcase Oil Fill Quantities .....	85-3		
Unified Inch Bolt and Screw Torque Values.....	85-4		
Metric Bolt and Screw Torque Values.....	85-5		
<b>Lubrication and Maintenance Records</b>			
Using Lubrication and Maintenance Records.....	90-1		
Daily (Prestarting) Service.....	90-1		
500 Hours of Operation or Every 12			
Months Service .....	90-1		

### Handle Fuel Safely—Avoid Fires

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.

Use only an approved fuel container for transporting flammable liquids.

Never fill fuel container in pickup truck with plastic bed liner. Always place fuel container on ground before refueling. Touch fuel container with fuel dispenser nozzle before removing can lid. Keep fuel dispenser nozzle in contact with fuel container inlet when filling.



TS202 —UN—23AUG88

Do not store fuel container where there is an open flame, spark, or pilot light such as within a water heater or other appliance.


DX,FIRE1 -19-12OCT11-1/1

### Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 —UN—15APR13

DX,FIRE2 -19-03MAR93-1/1

### Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.

Do not use starting fluid on an engine equipped with glow plugs or an air intake heater.



TS1356 —UN—18MAR92

DX,FIRE3 -19-14MAR14-1/1

# Fuels, Lubricants, and Coolants

## Diesel Exhaust Fluid (DEF) — Use in Selective Catalytic Reduction (SCR) Equipped Engines

In order to maintain the emissions performance of the engine, it is essential to use and refill DEF in accordance with the specification.

Diesel exhaust fluid (DEF) is a high purity liquid that is injected into the exhaust system of engines equipped with selective catalytic reduction (SCR) systems. Maintaining the purity of DEF is important to avoid malfunctions in the SCR system. Engines requiring DEF shall use a product that meets the requirements for aqueous urea solution 32 (AUS 32) according to ISO 22241-1.

The use of John Deere Diesel Exhaust Fluid is recommended. John Deere Diesel Exhaust Fluid is available at your John Deere dealer in a variety of package sizes to suit your operational needs.

If John Deere Diesel Exhaust Fluid is not available, use DEF that is certified by the American Petroleum Institute (API) Diesel Exhaust Fluid Certification Program or by the AdBlue™ Diesel Exhaust Fluid Certification Program. Look for the API certification symbol or the AdBlue™ name on the container.

*AdBlue is a trademark of VDA, the German Association of the Automotive Industry.*

RG30211 —UN—08MAR18



In some cases, DEF is referred to by one or more of these names:

- Urea
- Aqueous Urea Solution 32
- AUS 32
- AdBlue™
- NOx Reduction Agent
- Catalyst Solution

DX,DEF -19-13JAN18-1/1

## Diesel Engine Oil — Interim Tier 4, Final Tier 4, Stage IIIB, Stage IV, and Stage V

Failure to follow applicable oil standards and drain intervals can result in severe engine damage that might not be covered under warranty. Warranties, including the emissions warranty, are not conditioned on the use of John Deere oils, parts, or service.

Use oil viscosity based on the expected air temperature range during the period between oil changes.

### John Deere Plus-50™ II is the recommended engine oil.

Extended service intervals may apply when John Deere Plus-50™ II engine oil is used. Refer to the engine oil drain interval table and consult your John Deere dealer for more information.

If John Deere Plus-50™ II engine oil is not available, engine oil meeting one or more of the following may be used:


- API Service Category CK-4
- API Service Category CJ-4
- ACEA Oil Sequence E9
- ACEA Oil Sequence E6

DO NOT use engine oil containing more than 1.0% sulfated ash, 0.12% phosphorus, or 0.4% sulfur.

### Multi-viscosity diesel engine oils are preferred.

Diesel fuel quality and fuel sulfur content must comply with all existing emissions regulations for the area in which the engine operates.

*Plus-50 is a trademark of Deere & Company*



Oil Viscosities for Air Temperature Ranges

**IMPORTANT: Use only ultra low sulfur diesel (ULSD) fuel with a maximum sulfur content of 15 mg/kg (15 ppm).**

TS1691 —JUN—18JUL07

DX,ENOil14 -19-14JAN18-1/1

## PV101 Diagnostic Gauge — Essential Menus

### Automatic Exhaust Filter Cleaning

To enable auto exhaust filter cleaning mode:

1. Press menu key on diagnostic gauge
2. Press arrow keys to scroll up or down to EXHAUST FILTER
3. Press select key
4. Press arrow keys to scroll up or down to AUTO EXH FLT CLEAN
5. Press select key to enable auto exhaust filter cleaning

### Manual/Parked Exhaust Filter Cleaning

To request a manual/parked exhaust filter cleaning:

1. Reduce engine speed to slow idle
2. Press menu key
3. Press arrow keys to scroll up or down to EXHAUST FILTER
4. Press select key
5. Press arrow keys to scroll up or down to REQUEST EXH FLT CLEAN
6. Press select key to request a manual/parked exhaust filter cleaning
7. Follow directions on display and ensure all conditions are met
8. Press select key to CONFIRM all conditions are met

### Disable Exhaust Filter Cleaning

To disable the auto exhaust filter cleaning mode:

1. Press menu key on diagnostic gauge
2. Press arrow keys to scroll up or down to EXHAUST FILTER
3. Press select key
4. Press arrow keys to scroll up or down to DISABLE EXH FLT CLEAN
5. Press select key to disable exhaust filter cleaning

### Fault Codes — Active

To view active fault code information:

1. Press menu key on diagnostic gauge
2. Press arrow keys to scroll up or down to FAULTS
3. Press select key
4. Press arrow keys to scroll up or down to ACTIVE FAULTS
5. Press select key
6. Press arrow keys to scroll through available faults

### Fault Codes — Stored

To view stored fault code information:

1. Press menu key on diagnostic gauge
2. Press arrow keys to scroll up or down to FAULTS
3. Press select key
4. Press arrow keys to scroll up or down to STORED FAULTS
5. Press select key
6. Press arrow keys to scroll up or down to VIEW
7. Press select key
8. Press arrow keys to scroll through available faults

BL90236,0000025 -19-02JUN16-1/1

## DG14 Diagnostic Gauge — Using


The diagnostic gauge (A) allows the operator to monitor engine functions, view diagnostic trouble codes (DTC's), and perform preliminary diagnostics. The gauge is linked to the electronic control system and sensors.

The (home) menu key (B) allows the operator to access the main menu of the diagnostic gauge. For more information see DG14 Diagnostic Gauge — Main Menu. This key also allows the operator to cancel an option and go back to the previous menu or home menu.

The arrow keys (C) allows the operator to scroll between menu items. The arrow keys automatically change from up and down, to left and right depending on the menu item to be selected.

The (check mark) select key (D) allows the operator to access menu items selected by the arrow keys (C) and confirm changes made by the operator.

The indicator lights (E) allows the operator to visually see the presence of an active trouble code.



Diagnostic Gauge

A—Diagnostic Gauge  
B—(Home) Menu Key  
C—Arrow Keys

D—(Check Mark) Select Key  
E—Indicator Light  
F—Display

RG27904—UN—25FEB16

BL90236,0000028 -19-02JUN16-1/1

## Starting the Engine


**NOTE:** The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.

The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network.

**CAUTION:** Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

**NOTE:** If temperature is below 0 °C (32 °F), it may be necessary to use cold weather starting aids. See *Cold Weather Operation* in the Engine Operation Section.

1. Perform all prestarting checks outlined in Lubrication & Maintenance/Daily Section later in this manual.



Use Proper Ventilation

2. Open the fuel supply shutoff valve, if equipped.
3. Disengage power (or clutch if equipped) to any engine drive lines.

RK80614,000000A -19-18AUG14-1/2

TSS220 —UN—15APR13

4. Set high-low speed select rocker switch (H) to slow (turtle), then push in on analog throttle handle or turn full counterclockwise to set analog throttle(s) to slow speed.


**IMPORTANT:** Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see *Engine Troubleshooting* in the Troubleshooting Section.

5. Turn the key start switch clockwise to the "ON" position. Wait until the Engine Preheater Indicator light turns off, then turn the key start switch (F) clockwise "START" position to crank the engine. In cold weather, preheater indicator light remains on longer while engine is warmed. See *Cold Weather Operation* in the Engine Operation Section. When the engine starts, release the key switch so that it returns to the "ON" position.

**IMPORTANT:** If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This prevents possible damage to the starter and/or flywheel.

6. After engine starts, idle engine at not more than 1200 rpm until warm. See *Warming Engine* in the Engine Operation Section.

Set either high-low speed select switch or analog throttle to slow speed, and set desired speed with remaining control. See *Changing Engine Speed* in the Engine Operation Section.



- |                    |                              |
|--------------------|------------------------------|
| A—Diagnostic Gauge | E—Exit Key                   |
| B—Arrow Keys       | F—Key Switch                 |
| C—Menu Key         | G—Cover                      |
| D—Select Key       | H—Speed Select Rocker Switch |


**NOTE:** Engine control unit (ECU) reads the higher of the high-low speed select rocker switch or the analog throttle speed settings.

7. Check all gauges for normal engine operation. If operation is not normal, stop the engine and determine the cause. For normal gauge pressures and temperatures, see *Break-In Service* in the Engine Operation Section.

RK80614,000000A -19-18AUG14-2/2

RG23644 —UN—27AUG13

### Selective Catalytic Reduction (SCR) System Overview



SCR System

A—SCR Catalyst  
B—DEF Dosing Injector

C—DEF Dosing Unit  
D—DEF Tank Header Assembly

E—DEF Tank

**IMPORTANT: Do not remove battery leads for at least 4 minutes after engine stops. The SCR system automatically purges itself of Diesel Exhaust Fluid (DEF) immediately after the engine is stopped. If adequate time is not allowed for lines to be purged, residual DEF can freeze and possibly damage components of the SCR system during cold-weather exposure.**

In order to comply with national and local emission requirements, this engine series contains a Selective Catalytic Reduction (SCR) system. The main components of the SCR system include the SCR catalyst (A), DEF dosing injector (B), DEF dosing unit (C), DEF tank header assembly (D), and DEF tank (E). The SCR system is effective at reducing the nitrogen oxides (NOx) emissions. NOx is a major component of smog and acid rain.

During combustion, NOx molecules are formed in the exhaust. DEF is injected into the exhaust stream before the SCR catalyst. Through a chemical reaction in the SCR, NOx is converted into nitrogen and water.

Water vapor is a normal by-product of combustion. During cold-weather operation at low exhaust temperatures, this water vapor can condense and resemble white smoke from the exhaust. This will dissipate as operating temperature increases and the water is further vaporized. This situation is considered normal.

A DEF solution begins to crystallize and freeze at -11 °C (12 °F). With climate temperatures that can range much colder than this, DEF is expected to freeze in the DEF tank. For this reason, the DEF tank contains a heating element that provides rapid thawing of DEF upon start-up. The heating element cycles to maintain fluidity during operation as needed. DEF is not dosed upon initial start-up, therefore it is not necessary to have liquid DEF at cold start-up.

If DEF quality deteriorates and it is no longer within specifications, the engine can derate. DEF should be crystal clear with a light ammonia smell. If DEF appears cloudy, has a colored tint, or has a profound ammonia smell, it is likely not within specification.

DX,SCR,OVERVIEW -19-05SEP14-1/1

RG22427 —UN—14FEB13

### Lubrication and Maintenance Service Interval Chart

Item	Lubrication and Maintenance Service Intervals								
	Daily- /Before Every Startup	500 Hours of Opera- tion or Every 12 Months	1500 Hours of Opera- tion	1500 Hours of Opera- tion or Every 36 Months	2000 Hours of Opera- tion or Every 24 Months	3000 Hours of Opera- tion or Every 36 Months	4500 Hours of Opera- tion or Every 60 Months	6000 Hours of Opera- tion or Every 72 Months	As Re- quired
Operate Engine at Rated Speed and 50%–70% Load a Minimum of 30 Minutes (Generator and Standby Engines Only)									
Check Engine Oil	•								
Check Coolant Level	•								
Drain Water From Fuel Filters	•								
Check Air Cleaner Dust Valve Restriction Indicator Gauges	•								
Perform Inspection of Engine Compartment	•								
Service Fire Extinguisher		•							
Service Battery		•							
Change Engine Oil And Replace Oil Filter <sup>a .b</sup>		•							
Check Coolant Pump Weep Hole		•							
Check Open Crankcase Vent (OCV) System		•							
Replace Fuel Filter Elements		•							
Check Belt Tensioner and Belt Wear		•							
Check Cooling System		•							
Pressure Test Cooling System		•							
Check Engine Speeds		•							
Check Engine Mounts		•							
Checking Engine Ground Connection		•							
Changing Open Crankcase Ventilation (OCV) Filter <sup>c</sup>			•						
Change DEF Dosing Unit Filter				•					
Replace DEF Tank Header Suction Screen				•					
Checking Crankshaft Vibration Damper					•				
Adjust Engine Valve Clearance						•			
Test Glow Plugs for Continuity						•			
Change Crankshaft Vibration Damper							•		
Flush and Refill Cooling System								•	
Test Thermostats								•	
Drain Water From Fuel Filters When Alarm Sounds									•
Add Coolant									•
Clean DEF Tank									•
Pre-Start Cleaning Guide									•
Service Air Cleaner Filter Elements									•
Clean Diesel Particulate Filter <sup>c</sup>									•
Replace Alternator/Fan Belt									•
Check Fuses									•
Check Electrical Wiring and Connections									•
Check Air Compressors (If Equipped)									•
Check Refrigerant (A/C) Compressor (If Equipped)									•


Continued on next page

ZE59858,00000B1 -19-20NOV17-1/2

### Checking Tensioner Spring Tension

A belt tension gauge will not give an accurate measure of the belt tension when automatic spring tensioner is used. Measure tensioner spring tension using a torque wrench and procedure outlined below:

1. Release tension on belt using a long-handled 1/2 inch drive tool in tensioner arm. Remove belt from pulleys.
2. Release tension on tensioner arm and remove drive tool.
3. Put a mark (A) on swing arm of tensioner as shown.
4. Measure 21 mm (0.83 in.) from mark (A) and put a mark (B) on tensioner mounting base.



Checking Belt Tension Spring Tension

A—Mark

B—Mark

ZE59858,00000B8 -19-26AUG13-1/2

RG24039 —UN—07AUG13


5. Rotate the swing arm using a torque wrench until marks (A and B) are aligned.
6. Record torque wrench measurement and compare with specification below. Replace tensioner assembly as required.

**Specification**

Spring—Tension..... 24—28 N·m (17—21 lb.-ft.)

A—Mark

B—Mark



Checking Belt Tensioner Spring Tension

ZE59858,00000B8 -19-26AUG13-2/2

RG24040 —UN—07AUG13

### Checking Cooling System

**CAUTION:** Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

**IMPORTANT:** Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug when all the air has been expelled. Cooling system must be free of air by time engine coolant temperature reaches 80 °C (176 °F) or damage to EGR cooler (if equipped) may result.



High Pressure Fluids

1. Check entire cooling system for leaks. Tighten all clamps securely.
2. Thoroughly inspect all cooling system hoses for hard, flimsy, or cracked conditions. Replace hoses if any of the above conditions are found.

RK80614,000002D -19-11JUL13-1/1

TS281 —UN—15APR13

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



## Testing Thermostat Opening Temperature

### Removing Thermostats

**⚠ CAUTION:** Explosive release of fluids from pressurized cooling system can cause serious burns. **DO NOT** drain coolant until it has cooled below operating temperature. Always loosen radiator pressure cap or drain valve slowly to relieve pressure.




High Pressure Fluids

ZE59858,0000D3 -19-26AUG13-1/4

T5281 —UN—15APR13

1. Visually inspect area around thermostat housing for leaks.
2. Remove radiator pressure cap and partially drain cooling system.
3. Remove thermostat cover. Clean and check cover for cracks or damage.
4. Remove both thermostats (A) from the housing.

**A—Thermostats**



Thermostats

Continued on next page

ZE59858,0000D3 -19-26AUG13-2/4

RG18563 —UN—25MAY10

### Checking Fuses

Check the following fuses located in the control panel wiring harness. Replace defective fuses.

- Control Panel fuse — 30 Amp

- Low-Pressure Fuel Pump fuse — 15 Amp
- JDLink — 10 Amp
- ECU fuse — 25 Amp (3 used)
- Battery Power fuse — 30 Amp

See [6.8 L Wiring Diagram 8](#) in the Troubleshooting Section.

ZE59858,00000D8 -19-21AUG13-1/1

### Checking Electrical Wiring And Connections

Check for loose or corroded wiring and connectors. Tighten connections or replace wiring as needed. See your authorized servicing dealer for repairs.

RK80614,0000043 -19-16OCT12-1/1

### Bleeding Fuel System

*NOTE: Normally the fuel system on these engines is self-priming and self-bleeding, and does not require a bleeding procedure by the operator.*

If engine will not start after filter changes, turn ignition key ON for 60 seconds to prime the fuel system. It may be necessary to turn the key off and on again to reprime the system before starting.


RK80614,0000044 -19-16OCT12-1/1

### Checking Air Compressors (If Equipped)

Air compressors are offered as options with John Deere OEM engines to provide compressed air to operate air-powered devices like vehicle air brakes.

Air compressors are engine-driven piston types. They are either air cooled or cooled with engine coolant. The compressors are lubricated with engine oil. The compressor runs continuously as gear or spline driven by the auxiliary drive of the engine but has “loaded” and “unloaded” operating modes. This is controlled by the vehicle's air system (refer to vehicle technical manual for complete air system checks and services).

See your John Deere engine distributor or servicing dealer for diagnostic and troubleshooting information. If diagnosis leads to an internal fault in the compressor, replace the complete compressor as a new or remanufactured unit.



Air Compressor (Optional)

RG12738 —UN—07NOV02

RK80614,0000045 -19-16OCT12-1/1

### Checking Refrigerant (A/C) Compressor (If Equipped)

Contact your authorized servicing dealer for any service or repairs to the air conditioning system.


RK80614,0000046 -19-16OCT12-1/1

## Troubleshooting

Symptom	Problem	Solution
	Turbocharger not functioning properly	Inspect turbocharger. See your authorized John Deere engine distributor or servicing dealer.
	Low engine temperature	Remove and check thermostat.
<b>Fuel in Oil</b>	Restricted fuel return line	Check and fix fuel return lines.
	Engine load too light	Increase engine load
	Leaking fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
<b>Low-Pressure Fuel System — Fuel Pressure Low</b>	Restricted fuel filter	Replace fuel filter.
	Restricted fuel line	Locate restriction, repair as required.
	Faulty transfer pump	See your authorized John Deere engine distributor or servicing dealer.
	Faulty high-pressure fuel pump	Remove fuel pump, repair/replace pump as required. See your authorized John Deere engine distributor or servicing dealer.
<b>Abnormal Engine Noise</b>	Worn main or connecting rod bearings	Determine bearing clearance. See your authorized John Deere engine distributor or servicing dealer.
	Excessive crankshaft end play	Check crankshaft end play. See your authorized John Deere engine distributor or servicing dealer.
	Loose main bearing caps	Check bearing clearance; replace bearings and bearing cap screws as required. See your authorized John Deere engine distributor or servicing dealer.
	Worn connecting rod bushings and piston pins	Inspect piston pins and bushings. See your authorized John Deere engine distributor or servicing dealer.
	Scored pistons	Inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Worn timing gears or excess backlash	Check timing gear back lash. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,00000CB -19-30JUL13-4/11



A—Fixed Turbocharger  
Compressor Outlet  
Temperature Sensor

B—Engine Coolant Temperature  
Sensor

C—Crankshaft Position Sensor

D—Low-Pressure Fuel Pressure  
Sensor

E—Fuel Temperature Sensor

Continued on next page

ZE59858,00000CC -19-22AUG13-2/5

RG24084 —UN—14AUG13

## Troubleshooting

AA— Aftertreatment Option Continued On 6.8 L Wiring Diagram 4	A5502-19— [5218 Gray] DEF Tank Fluid Temperature Sensor Signal	A5502-49— [5329 White] DEF Tank Fluid Level Sensor Signal	E5601— DEF Dosing Unit Pressure Line Heater
A5502— ECU Harness Connector 2	A5502-20— [5321 Brown] DEF Coolant Control Valve Drive Positive	A5502-51— [5324 Yellow] DEF Coolant Control Valve Drive Negative	E5602— DEF Dosing Unit Supply Line Heater
A5502-10— [5311 Brown] DEF Dosing Unit Pressure Line Heater Positive	A5502-39— [5313 Orange] DEF Dosing Unit Pressure Line Heater Negative	A5507— DEF Tank Header Assembly	E5603— DEF Dosing Unit Return Line Heater
A5502-11— [5314 Yellow] DEF Dosing Unit Supply Line Heater Positive	A5502-41— [5318 Gray] DEF Dosing Unit Return Line Heater Negative	B5211— DEF Tank Fluid Temperature Sensor	X5038— DEF Dosing System Interconnect
A5502-12— [5317 Violet] DEF Dosing Unit Return Line Heater Positive	A5502-42— [5315 Green] DEF Dosing Unit Supply Line Heater Negative	B5601— DEF Tank Fluid Level Sensor	Y5019— DEF Tank Coolant Control Valve
		D— [5625 Green] 5 V Sensor Supply #7 Return From 6.8 L Wiring Diagram 5	

ZE59858,0000109 -19-27APR16-2/2

## Troubleshooting

<p>A— [5658 Gray] Sensor Return #6 From 6.8 L Wiring Diagram 2</p> <p>A5501— ECU Harness Connector 1</p> <p>A5501-16— [5461 Brown] Engine Coolant Temperature Sensor Signal</p> <p>A5501-20— [5411 Brown] Fixed Turbocharger Compressor Outlet Temperature Sensor Signal</p> <p>A5501-21— [5643 Orange] Sensor Return #1</p> <p>A5501-32— [5671 Brown] Cold Start Aid Drive Positive</p>	<p>A5501-53— [5015 Green] Fan Speed Sensor Signal</p> <p>A5501-54— [5429 White] Cold Start Aid Signal</p> <p>A5502— ECU Harness Connector 2</p> <p>A5502-22— [5010 Black] Single Point Ground</p> <p>A5502-26— [5014 Yellow] Variable Speed Fan Reverse Drive Positive</p> <p>A5502-32— [5023 Orange] Variable Speed Fan Drive Positive</p> <p>A5502-36— [5624 Yellow] 5 V Sensor Supply #7 Positive</p>	<p>B5200— Fixed Turbocharger Compressor Outlet Temperature Sensor</p> <p>B5208— Engine Coolant Temperature Sensor</p> <p>B5303— Fan Speed Sensor</p> <p>F5010— Cold Start Aid Fuse (50 A)</p> <p>H— To 6.8 L Wiring Diagram 7</p> <p>I— To 6.8 L Wiring Diagram 8</p> <p>J— [5082 Red] Battery Power Positive From 6.8 L Wiring Diagram 8</p> <p>K5803— Cold Start Aid Relay</p>	<p>R5607— Cold Start Aid</p> <p>R5609— Cold Start Aid Resistor (1.5 K Ohm, 1 W)</p> <p>X5001— ECU Static Ground</p> <p>X5004— Cold Start Aid Interconnect</p> <p>Y5005— Variable Speed Fan</p> <p>Y5014— Fan Solenoid (Increase)</p> <p>Y5015— Fan Solenoid (Decrease)</p>
--	--	--	--


ZE59858,000010C -19-11SEP13-2/2



Specifications

**Metric Bolt and Screw Torque Values**

TS1670 —UN—01MAY03



Bolt or Screw Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated <sup>a</sup>		Dry <sup>b</sup>		Lubricated <sup>a</sup>		Dry <sup>b</sup>		Lubricated <sup>a</sup>		Dry <sup>b</sup>		Lubricated <sup>a</sup>		Dry <sup>b</sup>	
	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.
M6	4.7	42	6	53	8.9	79	11.3	100	13	115	16.5	146	15.5	137	19.5	172
M8	11.5	102	14.5	128	22	194	27.5	243	32	23.5	40	29.5	37	27.5	47	35
M10	23	204	29	21	43	32	55	40	63	46	80	59	75	55	95	70
M12	40	29.5	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	46	80	59	120	88	150	110	175	130	220	165	205	150	260	190
M16	100	74	125	92	190	140	240	175	275	200	350	255	320	235	400	300
M18	135	100	170	125	265	195	330	245	375	275	475	350	440	325	560	410
M20	190	140	245	180	375	275	475	350	530	390	675	500	625	460	790	580
M22	265	195	330	245	510	375	650	480	725	535	920	680	850	625	1080	800
M24	330	245	425	315	650	480	820	600	920	680	1150	850	1080	800	1350	1000
M27	490	360	625	460	950	700	1200	885	1350	1000	1700	1250	1580	1160	2000	1475
M30	660	490	850	625	1290	950	1630	1200	1850	1350	2300	1700	2140	1580	2700	2000
M33	900	665	1150	850	1750	1300	2200	1625	2500	1850	3150	2325	2900	2150	3700	2730
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2770	4750	3500

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For stainless steel fasteners or for nuts on U-bolts, see the tightening instructions for the specific application. Tighten plastic insert or crimped steel type lock nuts by turning the nut to the dry torque shown in the chart, unless different instructions are given for the specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class. Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

<sup>a</sup>"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or M20 and larger fasteners with JDM F13C, F13F or F13J zinc flake coating.

<sup>b</sup>"Dry" means plain or zinc plated without any lubrication, or M6 to M18 fasteners with JDM F13B, F13E or F13H zinc flake coating.

DX,TORQ2 -19-12JAN11-1/1

## EPA Non-road Emissions Control Warranty Statement—Compression Ignition

DXLOGOV1 —UN—28APR09



**JOHN DEERE**

### U.S. AND CANADA EMISSION CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emissions Control Information" label located on the engine. If the engine is operated in the United States or Canada and the Emissions Control information label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine conforms to US EPA nonroad compression-ignition regulations", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines", or "This engine conforms to US EPA and California nonroad compression-ignition emission regulations", also refer to the "California Emission Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

#### JOHN DEERE'S WARRANTY RESPONSIBILITY

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine including all parts of its emission-control system was designed, built and equipped so as to conform at the time of the sale with Section 213 of the Clean Air Act and is free from defects in materials and workmanship which would cause the engine to fail to conform with applicable US EPA regulations for a period of five years from the date the engine is placed into service or 3,000 hours of operation, whichever first occurs.

Where a warrantable condition exists, John Deere will repair or replace, as it elects, any part or component with a defect in materials or workmanship that would increase the engine's emissions of any regulated pollutant within the stated warranty period at no cost to you, including expenses related to diagnosing and repairing or replacing emission-related parts. Warranty coverage is subject to the limitations and exclusions set forth herein. Emission-related components include engine parts developed to control emissions related to the following:

Air-Induction System	Aftertreatment Devices
Fuel System	Crankcase Ventilation Valves
Ignition System	Sensors
Exhaust Gas Recirculation Systems	Engine Electronic Control Units

#### EMISSION WARRANTY EXCLUSIONS

John Deere may deny warranty claims for malfunctions or failures caused by:

- Non-performance of maintenance requirements listed in the Operator's Manual
- The use of the engine/equipment in a manner for which it was not designed
- Abuse, neglect, improper maintenance or unapproved modifications or alterations
- Accidents for which it does not have responsibility or by acts of God

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel can harm the emissions control system of the engine/equipment and is not approved for use.

To the extent permitted by law John Deere is not liable for damage to other engine components caused by a failure of an emission-related part, unless otherwise covered by standard warranty.

**THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. REMEDIES UNDER THIS WARRANTY ARE LIMITED TO THE PROVISIONS OF MATERIAL AND SERVICES AS SPECIFIED HEREIN. WHERE PERMITTED BY LAW, NEITHER JOHN DEERE NOR ANY AUTHORIZED JOHN DEERE ENGINE DISTRIBUTOR, DEALER, OR REPAIR FACILITY OR ANY COMPANY AFFILIATED WITH JOHN DEERE WILL BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

Emission\_CI\_EPA (18Dec09)

Continued on next page

DX,EMISSIONS,EPA -19-12DEC12-1/2

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL