

en

Operator's manual

Telescopic handler

Document ID

	ORIGINAL OPERATOR'S MANUAL
Order number:	93517492
Issued:	01.08.2019
Version:	02
Author:	LWT / Technical Documentation Department

Product ID

Manufacturer:	Liebherr-Werk Telfs GmbH
Type:	T 55-7 3AS
Type no.:	1708
From Serial no.:	16195

Contact

Liebherr-Werk Telfs GmbH
Hans Liebherr-Straße 35
A – 6410 Telfs

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

4.2	Problems - Cause - Remedy	322
4.2.1	Diesel engine	322
4.2.2	Hydraulic system	325
4.2.3	Steering system	325
4.2.4	Brake system	326
4.2.5	Electrical system	326
4.2.6	Heating system	326
4.2.9	Air filter system	329
4.2.10	Working attachment	329
4.2.11	Central lubrication system (option)	330
4.3	Problem remedy	332
4.3.1	Changing the fuses	332
4.3.2	Changing the relays	336
5	Maintenance	339
5.1	Maintenance and inspection schedule	339
5.2	Fill quantities, lubrication schedule	344
5.2.1	Recommended lubricants	344
5.2.2	Recommended fuel and operating fluids	344
5.2.3	Lubrication chart	345
5.2.4	Lubrication chart symbols	347
5.3	Lubricants and fuels	348
5.3.1	General information about lubricants and fuels	348
5.3.2	Diesel fuels	349
5.3.3	Engine oils	349
5.3.4	Coolant	350
5.3.5	Hydraulic oils	351
5.3.6	Lube oils for axles	353
5.3.7	Oil for the brake system	353
5.3.8	Lube oils for travel gearbox	353
5.3.9	Grease and other lubricants	354
5.3.10	Grease for the telescopic boom	356
5.3.11	Oil for hinges and joints	356
5.4	Preparatory maintenance tasks	357
5.4.1	Maintenance position	357

If a larger support is used instead of standard tyres, then the following formula is valid for the calculation of support surface:

Length (cm) x width (cm) x 0.8

Take the support load of installed working attachment from the respective load chart.

1.2.5 Trailer loads and support loads

To pull a trailer, the permissible trailer loads and support loads must be observed.

Permissible trailer load	Agricultural or forestry towing machine	Self-propelled machine	Maximum permissible support load
Trailer without brake	1000 kg	1000 kg	1000 kg
Trailer with overrun brake	8000 kg	8000 kg	1000 kg
Trailer with pneumatic or hydraulic brake including trailer brake overfeed	16000 kg	12000 kg	1000 kg ¹⁾
Towing device rear and front (maximum permissible pull force in kN)	45	45	not permissible

Tab. 4: Permissible trailer loads

1. Taking account of permissible axle loads and maximum operating weight, a maximum of 1500 kg is permissible.
2. Deviating regulations may apply on a country-specific basis. However, the values stated here must not be exceeded!

1.2.6 Load charts



Note

The load charts are valid exclusively for stationary machines on level and solid ground, horizontally positioned, which are equipped with an approved working attachment and approved tyres.

If other working attachments are used:

- ▶ Contact Liebherr customer service.

The weight of the working attachment and the load carried must not exceed the values specified in the load curve for the respective area!




DANGER

Machine tipping!
Danger to life.

- ▶ Make sure there are no unauthorised persons in danger area.
- ▶ Note appropriate load curve for the working attachment.
- ▶ Tyres are in good condition and filled with the prescribed pressure.

Load curve of lightweight bucket up to 3.00 m³ for T55-7

Load curve: Id. No. 12812667



Tab. 13: Load curve of lightweight bucket for T55-7

Load curve applies to buckets up to a maximum of 3.00 m³, maximum own weight of 1000 kg and width of 2.5 m.

Example: when using a 2.00 m³ bucket, material with a maximum density of 1250 kg/m³ may be used.

LWT193517492/02/01_08.2019/en

413945

Performance

Impressive High-flyer –
the Jack of all Trades of Recycling

Efficiency

Make the Right Choice –
Sustainable and Economical

T 46-7s

Lifting Height 7.0 m/23' ft in

Lifting Capacity 4.6 t

Engine Power 100 kW/136 HP

Hydraulics 200 l/min./35.2 Imp.gpm
Pump flow max.

T 55-7s

Lifting Height 7.0 m/23' ft in

Lifting Capacity 5.5 t

Engine Power 115 kW/156 HP

Hydraulics 200 l/min./35.2 Imp.gpm
Pump flow max.

T 60-9s

Lifting Height 9.0 m/26'6" ft in


Lifting Capacity 6.0 t

Engine Power 115 kW/156 HP

Hydraulics 200 l/min./35.2 Imp.gpm
Pump flow max.



Maintainability



Don't Settle for the Right Spare Part



When it comes to “service quality” Liebherr customers think short paths and quick response. This is why 98 per cent of our spare parts are not only stored in a central location but are dispatched in the shortest possible time. Our dense international service network, modern service stations as well as outstandingly trained technicians guarantee swift on-site support.

The prestressing forces and the tightening torques noted in the chart have been taken from the VDI (Association of German Engineers) guidelines 2230 of February 2003.

Assembly prestressing forces F_M and tightening torques M_A at 90% utilisation of the yield strength for shank bolts with standard or fine metric threads as per DIN ISO 262 (and DIN ISO 965-2); wrench sizes for hex head screw in accordance with DIN EN ISO 4014 to 4018, screws with external hexalobular driving feature according to DIN 34800 or socket head bolts according to DIN EN ISO 4762 and hole "middle" according to DIN EN 20273.

Note:

- Any tightening values noted in Liebherr service documentation drawings or documents must be adhered to and given preference over factory standards.
- For important screw connections, angle-controlled tightening can be advantageous. In this case, the necessary tightening values (joining moment, angle) must be determined by the technical customer service department for the individual case.
- When tightening in aluminium, with or without Helicoil insert and for weld nuts, the values for class 8.8 must be used. Any tightening values noted in Liebherr service documentation drawings or documents are binding, paramount and must be adhered to.

Metric standard thread and fine thread	Metric standard thread and fine thread
<p>At least one element of the screwed connection (screws, washers, nuts, ...) with following surface: flZn = zinc coating (LH standard 10021432, LH standard 10215295 flZnnc-480h-L valid ≥M6)</p>	<p>All elements of the screwed connection (screws, washers, nuts, ...) with following surface: black oxide or phosphated zinc plated (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)</p>
 <p>1: Zinc coating</p> <p style="text-align: right;">436762</p>	 <p>1: Black oxide, phosphated, burnished 2: Thick film passivation 3: Yellow chromated 4: Zinc plated Fe//ZnNi(12)5//Cn//T2</p> <p style="text-align: right;">436763</p>

Tab. 23: Screw types

LWT193517492/02/01_08_2019/en




Fig. 51: Danger area of the machine

1 Danger area

Make sure that there are no persons within the danger area **1** of the telescopic handler.

The operator may only carry out work with the telescopic handler if there are no persons in the danger area.

In the event of danger to persons, the operator must stop the dangerous movement and give warning signs.

The operator must give warning signs (e.g. sounding the horn, light signals) in the event of danger to persons.

The operator must suspend operation if persons do not leave the danger area despite the warning.

The operator may only swing the work equipment over occupied operator platforms, operating stations and work stations of other equipment if these areas are secured against work equipment or loads falling by means of resistant protective roofs.

2.3.5 Operating conditions

Temperature range (ambient temperature)	-20 °C to +45 °C
---	------------------

Tab. 28: Operating conditions

Safety belt sign




Fig. 57: Safety belt sign

The sign is located on the right-hand window in the operator's cab.

Indicates the importance of wearing the safety belt.

Meaning: **Always close the safety belt before putting the machine into service!**

ROPS/FOPS warning sign




Fig. 58: ROPS/FOPS sign

The sign is located on the left below the operator's seat.

Warns of risk of accidents potentially leading to death or very severe injuries.

Meaning: **Structural modifications (e.g. welding, drilling) on the ROPS/FOPS operator's cab without consulting with Liebherr customer service are not permitted!**

Tyre inflation pressure sign



Fig. 77: Tyre inflation pressure sign

The sign is located on the front window in the operator's cab.
Denotes the permissible inflation pressure for the tyres.

Brake oil sign




Fig. 78: Brake oil sign

The sign is located inside on the front console of operator's cab.
Denotes the brake oil specifications.

Load chart sign




Fig. 79: Load chart sign

41. The machine must be utilized, driven and operated in such way that the stability is ensured and that there is no danger of tipping over.
42. Avoid any working movements which could cause the machine to tip over. However, if the machine does begin to tip or slide, retract the telescopic boom while simultaneously lowering the working attachment and turn the machine uphill. If possible, always work downhill or uphill, never sideways on a slope.
43. Always move slowly and carefully on rocky or slippery ground or on a slope.
44. Always adapt the travel speed to the working conditions.
45. Never travel on slopes which exceed the maximum permissible gradeability.
46. Only travel downhill at the permitted speed or you could lose control over the machine.
47. When loading a truck, make sure that the truck driver leaves the truck, even if the cab is FOPS protected.
48. For terrain which is difficult to gain an overview of and whenever necessary, ask for the assistance of a guide. Have only one person signal you.
49. Only permit experienced personnel to secure loads and signal the machine operators. The signaller must position himself within the view of the operator or be in voice contact with him.

2.6.7 Working in the vicinity of electrical overhead lines

1. When working with telescopic handlers near electrical overhead lines and overhead contact lines, a safety distance depending on the nominal voltage of the overhead lines between them and the telescopic handlers and its working equipment must be observed to avoid current transfer. This also applies for the distance between lines and accessory equipment as well as attached loads.
2. When approaching electrical overhead wires, consider all working movements of the telescopic handler, such as boom position, oscillation of ropes and dimensions of attached loads. Also observe ground unevenness, which can incline the telescopic handler and therefore move it closer to the overhead wires.
3. In case of wind, overhead wires as well as working equipment can swing out and thereby reduce the distance.
4. If a sufficient distance from electrical overhead wires and contact wires cannot be retained, then the operator must carry out other safety measures in consultation with the owner or operator of the lines to avoid current transfer. Other safety measures against current transfer can include the following:
 - Turning the current off,
 - Rerouting the overhead wires,
 - Cabling,
 - Limitation of working range of telescopic handlers.
5. In case of a current transfer, the operator of the telescopic handler must try to move the telescopic handler from the electric danger zone by lifting or lowering the working equipment, by driving or swinging out. If this is not possible, the following rules apply for the operator:
 - Do not leave the machine;
 - Warn people in the vicinity not to approach or touch the machine;
 - Have the power turned off!

The following safety distances must be adhered to:

Rated voltage	Safety distance
to 1000 V	1.0 m
from 1 kV to 110 kV	3.0 m

**WARNING**

Some installations and equipment can limit the visibility of the machine operator. Danger of accident!

- ▶ Pay attention to limitations in the visibility field and to blind spots.
- ▶ Use the aid of a guide if necessary.

Observe national regulations regarding visibility in the operator's cab. For countries within the European Economic Area, the Standard EN 15830 describes the test and evaluation methods for the visibility field of machine operator. Visibility field is tested in this case with standard equipment. Changes to the machine, such as installation or modification of components may not impact the visibility field. When changes impact the visibility field, then a test according to EN 15830 or the regulations valid on the job site must be carried out. Appropriate measures are to be taken, depending on the test result. The machine operator must be informed about the changes.

Field of vision

The field of vision describes the visible range the driver can see from the operator's seat.

The field of vision is determined according to EN 15830.

The figures below illustrate the field of vision in the near field and in the 12 m radius of driver from the operator's seat.

Not all areas of machine are located in the direct field of view.

**WARNING**

Danger of accident due to limited field of vision! It can lead to severe injuries or death.

- ▶ Adjust the mirror.
- ▶ Adjust the visual aids {additional mirror (option) and/or camera (option)}.
- ▶ When working attachments are used that limit the field of view, measures must be taken to make sure that the machine is operated safely.
- ▶ Remove any obstacles in the work area.
- ▶ Make sure that no persons are within the danger zone.
- ▶ Do not move a load with raised telescopic boom.
- ▶ Move a load exclusively in transport position.

The machine operator and construction site management must take measures to ensure that the obscured field of vision does not cause a safety hazard during operation.

Restriction of field of vision for T46-7 and T55-7**Restriction of field of vision with load**

The graphic describes the existing visual shadows with forklift device at retracted and raised telescopic boom of A = 450 mm and load in the field of vision radius of 12 metres.

52 Tipping cylinder lock switch (option)

Press top part of switch: *Tipping cylinder lock* function is deactivated.
 Press bottom part of switch: *Tipping cylinder lock* function is activated.
Tipping cylinder lock indicator light lights up on the display unit.

54 Auto Power switch (option)

Press top part of switch: *Auto Power* function is deactivated.
 Press bottom part of switch: *Auto Power* function is activated.
Auto Power symbol is shown on the display.

56 Side window windscreen washer system switch (option)

Press top part of switch: *Side window windscreen wiper* is deactivated.
 Press bottom part of switch: *Side window windscreen wiper* is activated.
 Press bottom part of switch and hold (touch function): Side window windscreen washer system is activated.

57 Trailer brake button (option)














Parking brake switch is activated.
 Press button down and hold it: Trailer brake is released.
 Release button: Trailer brake is activated.

Control elements - roof console right

Fig. 117: Control elements - roof console right

60 Parking light and driving light switch

Press top part of switch: Parking light, driving light and side marker lights are switched off.
 Switch in centre position: Parking light and side marker lights are switched on.
 Press bottom part of switch: Driving light and side marker lights are switched on.

Status symbols	Name
 413640	Maintenance display Contact Liebherr customer service
 412233	Forward travel direction (For more information see: Forward travel , page 172)
 412234	Reverse travel direction (For more information see: Reverse travel , page 173)
 412227	Neutral position (For more information see: Before travel , page 172)
 412238	Front wheel steering (For more information see: Selecting front wheel steering mode , page 178)
 412240	All wheel steering (For more information see: Selecting all-wheel steering mode , page 179)
 412239	Crab steering (For more information see: Selecting crab steering mode , page 179)
 412237	One-sided crab steering (For more information see: Selecting one-sided crab steering mode , page 180)
 412244	Hoist gear suspension ^{A)} (For more information see: Hoist gear suspension (option) , page 209)
 412245	Auto hoist gear suspension ^{A)} (For more information see: Hoist gear suspension (option) , page 209)
 412268	Slow travel stage (For more information see: Travel speed ranges , page 174)
 412270	Middle travel stage (For more information see: Travel speed ranges , page 174)
 412269	Fast travel stage (For more information see: Travel speed ranges , page 174)

- ▶ Unlock door lock **2** with ignition key.
- ▶ Open cab door **1** with door handle **3**.
- ▶ Enter operator's cab.
- ▶ Before putting machine into service, close the cab door.
 - ▷ The cab door engages in the door lock.

3.2.2 Emergency exit

Enter and leave the operator's cab always through the cab door.




Fig. 153: Emergency exit

Use the rear cab window as an emergency exit.




Fig. 154: Emergency hammer

The emergency hammer is located in the operator's cab on the centre left window rail.

- ▶ In emergency situations, use the emergency hammer to break the rear cab window or another cab window, depending on the situation!

Adjusting backrest incline




Fig. 173: Adjusting backrest incline

12 Backrest inclination handle

- ▶ Pull *Backrest inclination handle 12* up.
- ▶ Adjust backrest to desired incline.
- ▶ Release *Backrest inclination handle 12*.

Adjusting horizontal suspension

Impact loads in travel direction can be absorbed better through the horizontal suspension.




Fig. 174: Adjusting horizontal suspension

- | | | | |
|---|---------------------------|----|-------------------------------------|
| 1 | Horizontal suspension OFF | 13 | <i>Horizontal suspension handle</i> |
| 2 | Horizontal suspension ON | | |

- ▶ Move *Horizontal suspension handle 13* to Horizontal suspension ON 2.
 - ▷ Horizontal suspension is activated.
- ▶ Move *Horizontal suspension handle 13* to Horizontal suspension OFF 1.
 - ▷ Horizontal suspension is deactivated.

Troubleshooting

Can operator's seat be moved to a different position when horizontal suspension is deactivated?

- ▶ Contact Liebherr customer service.

413378

413379

Armrest: horizontal adjustment




Fig. 193: Horizontal adjustment

- ▶ Loosen lever 1 or lever 2.
- ▶ Adjust the armrest horizontally.
- ▶ Tighten lever 1 or lever 2 again.

Armrest: adjusting the incline and depth




Fig. 194: Adjusting the incline and depth

- ▶ Loosen lever 3.
- ▶ Adjust the incline and depth.
- ▶ Tighten lever 3 again.

3.2.7 Steering column and steering wheel

By changing the steering column, the steering wheel distance to the body, the steering wheel height and the steering wheel incline can be changed. The adjustments are infinitely variable.



WARNING

Improper steering mode change!
Injury.

- ▶ Set steering mode exclusively when machine is at a standstill.




Fig. 214: Interior mirror

- ▶ Adjust the interior mirror before starting to work.




Fig. 215: Exterior mirror, front

- ▶ Adjust the exterior mirror at the front before starting to work.





Fig. 216: Outside mirror, rear

- ▶ Adjust the outside mirror on the rear before starting to work.

3.2.14 Trailer mirror (option)

The trailer mirror needs to be installed if using a trailer coupling.

Refuelling with diesel



413838

Fig. 235: Fuel display

- ▶ Set starting switch to contact position.
- ▶ Check whether there is enough diesel fuel in the fuel tank on the fuel display.



406952

Fig. 236: Safety when refuelling




DANGER

Highly flammable fuel and operating fluids!
Danger to life.

- ▶ Smoking, naked lights and fire are prohibited.
 - ▶ Exclusively refuel when diesel engine is switched off.
-
- ▶ Adhere to the safety regulations for refuelling. (For more information see: [2.6.3 Safety guidelines for fire and explosion prevention, page 78](#))

Preparing for travel mode




413210

Fig. 255: Raising working attachment

- ▶ Raise working attachment so that no obstacles are touched.

Releasing parking brake



413820

Fig. 256: Releasing parking brake

- ▶ Press *parking brake* switch **30** up.
 - ▷ After the machine starts to travel, the *parking brake* symbol goes out on the monitor.

Bringing machine to operating temperature

If hydraulic oil is too cold, the machine will react sluggishly.

- ▶ Repeatedly actuate working hydraulic cylinder against stop.
 - ▷ The hydraulic oil is thereby brought to operating temperature.

3.3.5 Driving

The machine's travel speed should be adapted to suit driving conditions and the load in question.

When driving with a load, drive at low travel speed to retain the manoeuvrability and avoid excessive strain.

When driving with a load, match the travel speed to the respective conditions.

Prior to commencing on-road travel, make sure you are informed about:


- Whether the necessary conditions for permission to drive on public roads have been met (by the vehicle owner).
- The operating permit.
- Working attachments subsequently mounted to the machine, which may require a separate operating permit.
- The validity of vehicle documentation.
- Special authorisations and resulting requirements and conditions for operation on public roads.
- The relevant safety regulations.
- Instructions for safe travel.
- The road traffic regulations applicable in the country of use.

Prior to commencing on-road travel, take the following precautions:

- Remove the mounted front guard.
- Remove the guard mounted on the front headlights.
- Switch off working headlights.
- Drive exclusively with air-filled tyres.
- Do not tow any trailers or working attachments with the rear coupling (towing coupling).
- Install country-specific packages.
- Unlock the floating axle lock⁸⁾ prior to travel mode.

Preparing for on-road travel

Stow the safety devices listed below on board, in accordance with the provisions of **German road traffic licensing regulations (STVZO)**.



406953

Fig. 277: Safety equipment

- Warning triangle
- Safety vest
- Beacon
- First aid kit
- Chock(s)
- Number plate

⁸⁾ Option

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




Fig. 296: Starting switch - park position

- ▶ Turn the starting switch to park position.
 - ▷ The radio is operational.



DANGER

Unauthorised starting up of the machine!
Risk of fatal injury.

- ▶ Secured the machine against being started unauthorisedly.

When you leave the machine:

- ▶ Turn starting switch to zero position and pull ignition key out.

3.3.9 Working with the working attachment

Preparations for working with the working attachment

When working with the working attachment, do not exceed the permitted load rating of the machine.

To ensure that the lifting process is safe, the load curve is binding.

Should the maximum permitted rated load of the working attachment exceed that of the machine, the rated load of the machine is always binding, taking into account possible differences in weight.




Fig. 297: Hazardous situation

Setting the flow volume




Fig. 314: Setting control circuit III flow volume

10 Control circuit III rocker switch **39** Control circuit III switch

- ▶ Put control circuit III switch **39** into middle position.
 - ▷ Control circuit III symbol is shown on the display.
 - ▷ The preset flow volume is displayed and flashes on the display.
- ▶ Press control circuit III rocker switch **10** on control lever to the right (+) or left (-).
 - ▷ The flow volume changes in 1% increments.
 - ▷ The flow volume is displayed and flashes on the display.

Saving and activating the flow volume

- ▶ Press control circuit III rocker switch **10** on control lever to the right or left.
- ▶ Press Control circuit III switch **39** downwards.
- ▶ Release Control circuit III rocker switch **10** on the control lever.
 - ▷ Control circuit III AUTO symbol is shown on the display.
 - ▷ The set flow volume is shown on the display.
 - ▷ The set flow volume is stored and archived.

Deactivating the flow volume

- ▶ Press Control circuit III switch **39** again.
 - ▷ Control circuit III symbol is shown on the display.
 - ▷ The set flow volume is deactivated.
 - ▷ The set flow volume flashes on the display.
- ▶ Press control circuit III rocker switch **10** on control lever to the right or left.
 - ▷ Control circuit III symbol is shown on the display.
 - ▷ The set flow volume is deactivated.
 - ▷ The set flow volume flashes on the display.

Control circuit III change over (option)

For working attachments with additional hydraulic functions.




Fig. 330: Tipping cylinder lock

52 Tipping cylinder lock switch

Activating the tipping cylinder lock

- ▶ Press *tipping cylinder lock* switch **52** down.
 - ▷ The *tipping cylinder lock* symbol is shown on the display.
 - ▷ Tilting the working attachment in and out is deactivated.

Deactivating the tipping cylinder lock

- ▶ Press *tipping cylinder lock* switch **52** up.
 - ▷ *Tipping cylinder lock* symbol goes out on the display.
 - ▷ Tilting the working attachment in and out is activated.

Shake/vibrate function (option)

Activating the shake/vibrate function

Ensure that following requirements are met:

- The working hydraulics are unlocked.
- The bucket is not in the end position.



Fig. 331: Activating the shake/vibrate function

- ▶ Deflect the joystick repeatedly to the left and to the right via the tilt axle.
- ▶ Keep the joystick deflected.
 - ▷ The shake/vibrate function is activated.
 - ▷ *Shake/vibrate function* symbol is shown on the display.

- ▶ Lower the pull device.
- ▶ Swing hold-down device **1** back into travel direction.
 - ▷ Hold-down device **1** is above the ball head **5**.
- ▶ Secure hold-down device **1** with pins **6** and locking pins **7**.
- ▶ Check whether the pull device of trailer is securely locked in the trailer coupling.
- ▶ Connect the hydraulic connections, compressed air connections and electrical connections.

Disconnecting the trailer

Ensure that following requirements are met:

- Trailer is secured against rolling away.
- ▶ Loosen the hydraulic connections, compressed air connections and electrical connections.
- ▶ Loosen upper locking pin **7**.
- ▶ Pull out upper pin **6**.
- ▶ Swing hold-down device **1** to side by 90°.
- ▶ Raise pull device with a suitable device.
- ▶ Slowly move machine forward.

Cuna trailer coupling, height adjustable

Height adjustment of trailer coupling

Adjust the Cuna trailer coupling to height of trailer prior to attachment.




Fig. 345: Cuna trailer coupling, height adjustable

- | | | | |
|----------|------------|----------|--------------|
| 1 | Cotter pin | 3 | Locking pin |
| 2 | Handle | 4 | Coupling pin |

- ▶ Pull handle **2** up and to the right.
 - ▷ Locking pins **3** are retracted.
- ▶ Move the trailer coupling up or down.

Once the desired height is reached:

- ▶ Let go of handle **2**.
 - ▷ The locking pins **3** lock in place in the receptacle plate.

Connecting the compressed air hoses




Fig. 356: Coupling heads, air brake system

- ▶ Attach the trailer to the trailer coupling .
- ▶ Clean the coupling heads on the compressed air hoses and compressed air connections.



WARNING

Incorrect connection of compressed air hoses!
Danger to life.

Connection of compressed air hoses:

- ▶ Always start by connecting to the yellow coupling head.
-
- ▶ First connect the compressed air hose to the yellow coupling head a.
 - ▶ Then connect the compressed air hose to the red coupling head b.


Pressure gauge for air brake system

The air brake system is not ready for use until an air pressure of between 6.5 and 8.5 bar is displayed.



Fig. 357: Air brake system pressure gauge

- ▶ Allow the diesel engine to run at a standstill until the air brake system is filled.
- ▶ Read air pressure off of pressure gauge 1.
 - ▷ Air pressure is reached: Put the air brake system into service.



413260

Fig. 375: Empty the bucket

- ▶ Tilt the bucket out.

Troubleshooting

If material sticks to the inside of the bucket:

- ▶ Tilt the bucket in and out quickly and retract and extend the tilt cylinder completely while doing so.
- ▶ Activate the shake/vibrate function.


Grading work

During grading, hold the bottom of the bucket horizontally.

NOTICE

Incorrect use of working attachment!
Damage to machine.

- ▶ Do not grade in forward travel direction with working attachment tilted out.



413257

Fig. 376: Grading

- ▶ Align the bottom of the bucket again so that it is parallel to the ground.
- ▶ Drive forward.

- The telescopic boom is completely retracted.
- The working attachment lies flat on the ground.

Installing the working attachment



WARNING

Working attachment falling over!
Risk of injury.

- ▶ Make sure the working attachment is secured against falling over or rolling away.




Fig. 391: Tilt the mechanical quick coupler.

- ▶ Tilt the mechanical quick coupler to the front.




Fig. 392: Release the lock

1 Cotter pin

- ▶ Pull the cotter pin 1 out of the locking mechanism.



412627


Fig. 412: Relieving hydraulic pressures

10 Control circuit III rocker switch

- ▶ Turn *Control circuit III* rocker switch **10** to the right and left.
 - ▷ The pressure in the hydraulic lines is relieved.

Control circuit III pressure relief (option)

For quickly relieving pressure in the control circuit III and control circuit III high flow hydraulic lines.



413831

Fig. 413: Pressure relief button

40 Control circuit III pressure relief button

- ▶ Press *Control circuit III pressure relief* button **40** for 5 to 10 seconds.
 - ▷ *Control circuit III pressure relief* symbol is shown on the display.
 - ▷ The pressure in the hydraulic lines is relieved.

OR


Front socket (option)

Fig. 432: Location of front socket

D Front socket**69** Front socket switch

- ▶ Press front socket switch **69** up.
 - ▷ The front socket **D** is without current.
- ▶ Disconnect cables for working attachment from front socket **D**.

Unlocking and disconnecting working attachment**WARNING**

Working attachment falling over!
Risk of injury.

- ▶ Make sure the working attachment is secured against falling over or rolling away.




Fig. 433: Hydraulic quick coupler button

75 Hydraulic quick coupler button

- ▶ Press and hold Hydraulic quick coupler button **75**.
 - ▷ Hydraulic quick coupler indicator light **10** lights up on display unit.




Fig. 451: Loosening the counter nut

- ▶ Loosen the locknut 1.
- ▶ Screw in the counter nut 1 8 mm in the direction of the screw head.




Fig. 452: Releasing parking brake

- ▶ Screw in the screw 2 until the counter nut 1 touches the attachment point.
- ▶ However, do not tighten the counter nut 1 by more than one turn.




Fig. 453: Hex head screws on the front axles

- ▶ Carry out this procedure for all 4 hex head screws on the front axle.
 - ▷ The parking brake is released.
 - ▷ The machine is unbraked.

SPN	FMI	Component	Problem detected	Possible cause	Effect	Remedy
001619	02	Joystick travel direction switch	Value: measured travel direction signals are implausible (two directions simultaneously); Prof.: redundant CAN signal faulty	Value: travel direction switch defective; Prof.: faulty CAN communication	Machine response: limited mode	Contact Liebherr customer service.
001619	11	Travel stage adjustment joystick / CAN 1 - communication I	Error in corresponding CAN signal reported or redundant CAN signal faulty	Error detected on the joystick (joystick also sends error code); or communication error on CAN	Travel stage cannot be adjusted	Contact Liebherr customer service.
001638	00	Hydraulic oil temperature sensor	Calculated hydraulic oil temperature higher than safety threshold (95 °C) for 4000 ms	Hydraulic oil cooling defective; heat sink contaminated; excessive use of all sections simultaneously;	No machine response	Contact Liebherr customer service.
001638	03	Hydraulic oil temperature sensor	Measured resistance too high (>2420 Ohm)	Cable break; temperature higher than 200 °C	No machine response; temperature measurement not functioning; 214 °C is assumed; fan rotates at maximum speed	Contact Liebherr customer service.
001638	04	Hydraulic oil temperature sensor	Measured resistance too low (<730 Ohm)	Short circuit to ground; temperature lower than -50 °C	No machine response; temperature measurement not functioning; 214 °C is assumed; fan rotates at maximum speed	Contact Liebherr customer service.
001638	16	Hydraulic oil temperature sensor	Calculated hydraulic oil temperature higher than warning threshold (90 °C) for 4000 ms	Hydraulic oil cooling defective; heat sink contaminated; excessive use of all sections simultaneously;	No machine response	Contact Liebherr customer service.
001815	02	Relay, brake light	Measured output signal does not correspond to the command	Short circuit or broken cable	Brake light cannot be controlled	Contact Liebherr customer service.

LWT193517492/02/01_08.2019/en

SPN	FMI	Component	Problem detected	Possible cause	Effect	Remedy
520239	04	Manual throttle, mini-joystick	Measured voltage too low: <300 mV	Broken cable; short circuit to ground	Manual throttle not available	Contact Liebherr customer service.
520240	09	CAN 1 / communication I	No communication between the display and work control	CAN line to work control disconnected; work control not supplied	No machine response; various displays not available	Contact Liebherr customer service.
520241	02	Resistance circuit	Resistance value not in defined range for more than 500 ms; defined ranges: 1.4 to 1.6 kOhm; 2.81 to 3.2 kOhm; 6 to 6.42 kOhm; 7.4 to 8.02 kOhm	One of the resistances faulty; temperature of the resistances outside of range -40 to +80 °C	Continuous function working circuit not available	Contact Liebherr customer service.
520241	03	Resistance circuit	Resistance value higher than 8020 Ohm for more than 500 ms	Cable break	Continuous function working circuit not available	Contact Liebherr customer service.
520241	04	Resistance circuit	Resistance value lower than 1400 Ohm for more than 500 ms	Short circuit to ground	Continuous function working circuit not available	Contact Liebherr customer service.
520242	05	Rear axle floating blocking solenoid valves	Measured current lower than 220 mA / overload detected at the control unit output for more than 2000 ms	Cable break / current load at the output too high	Rear axle floating blocking permanently active!	Contact Liebherr customer service.
520242	06	Rear axle floating blocking solenoid valves	Measured output signal does not correspond to the command for more than 2000 ms	Short circuit to supply	Rear axle floating blocking permanently active!	Contact Liebherr customer service.
520242	14	Rear axle floating blocking solenoid valves	Shut off detected in control unit safety circuit	Short circuit to supply; error in the control unit safety circuit; error in the output end stage; internal supply to the control unit output defective	Rear axle floating blocking permanently active!	Contact Liebherr customer service.

LWT193517492/02/01_08_2019/en

SPN	FMI	Component	Problem detected	Possible cause	Effect	Remedy
520263 B)	05	Fan reversing valve	Measured current lower than 220 mA / overload detected at the control unit output for more than 2000 ms	Cable break / current load at the output too high	Reverse fan not available	Contact Liebherr customer service.
520263 A)	05	Fan reversing valve	Measured current too low for more than 2000 ms	Broken cable / short circuit to supply	Reverse fan not available	Contact Liebherr customer service.
520263 B)	06	Fan reversing valve	Measured output signal does not correspond to the command for more than 2000 ms	Short circuit to supply	Reverse fan not available	Contact Liebherr customer service.
520263 A)	06	Fan reversing valve	Measured overload at the control unit output: greater than 5 A	Current load at the output too high	Reverse fan not available	Contact Liebherr customer service.
520263	14	Fan reversing valve	Shut off detected in control unit safety circuit	Short circuit to supply; error in the control unit safety circuit; error in the output end stage; internal supply to the control unit output defective	Reverse fan not available	Contact Liebherr customer service.
520264	02	Additional control circuit 5 A proportional valve	Measured current too high or too low: by 100 mA (by 10 mA in idle state) too high/too low for 2000 ms	Broken cable; short circuit to ground	Additional control circuit 5 side A not available	Contact Liebherr customer service.
520264	06	Additional control circuit 5 A proportional valve	Overload detected at the control unit output: greater than 5 A	Current load at the output too high	Additional control circuit 5 side A not available	Contact Liebherr customer service.
520264	14	Additional control circuit 5 A proportional valve	Shut off detected in control unit safety circuit	Short circuit to supply; error in the control unit safety circuit; error in the output end stage; internal supply to the control unit output defective	Additional control circuit 5 side A not available	Contact Liebherr customer service.

LWT/93517492/02/01_08.2019/en

SPN	FMI	Component	Problem detected	Possible cause	Effect	Remedy
521311	00	Joystick	CAN (BJM) timeout error detected		Joystick safe state	Contact Liebherr customer service.
521312	00	Joystick	CAN (EJM) timeout error detected		Joystick safe state	Contact Liebherr customer service.
521317	00	Joystick	Stack overflow error detected		Joystick safe state	Contact Liebherr customer service.
521318	00	Joystick	Logic program flow monitoring error detected		Joystick safe state	Contact Liebherr customer service.
521319	00	Joystick	Temporal program flow monitoring error detected		Joystick safe state	Contact Liebherr customer service.
521320	00	Joystick	Measured supply voltage 1 (5 V) too high or too low		Joystick safe state	Contact Liebherr customer service.
521322	00	Joystick	Measured supply voltage 2 (5 V) too high or too low		Joystick safe state	Contact Liebherr customer service.

Tab. 35: Service codes

- A) T32-7S-T55-7S, T35-6S, T33-10S, T60-9S
 B) T32-7-T41-7, T35-6, T33-10

Malfunction / error	Cause	Remedy
The function of the pump (pump operating time or cycle time) does not correspond to the values set in the protective window of the control system	The operating mode or adjustment range of the control system was changed but the sticker in the protective window was not replaced	Create a diagnostic analysis using the BEKA-DiSys diagnostics software
		Adjust the setting according to the sticker in the protective window of the control system or replace the sticker

Customer:..... Machine type:..... Serial no.:..... Operating hours:..... Date:.....

Maintenance / inspection after service hours							Tasks to be performed				
On handover	All 8-10 h	All 50 h	All 500 h	All 1000 h	All 2000 h	Other intervals	Additional labelling	By maintenance staff	By authorised specialist staff	Confirm tasks	See page
								■ Once-only activity ● Repeat interval † If necessary ✱ Annually before the winter Additional labelling ††† Assistance required † Have this task carried out exclusively by a certified electrician	□ Once-only activity ○ Repeat interval ✧ If necessary		
			○	○	○	✧		Fuel: change filter cartridges			
						†		Fuel tank: draining condensation and sediments			375
			○	○	○			Check the fuel system for leaks and condition			
Air filter system											
			○	○	○	†		Change air filter main filter element (when the indicator light lights up, at least once a year)			376
						†		Change air filter safety element (after 3 exchanges of main element)			376
	●	●	○	○	○			Air filter: cleaning the service cover and dust discharge valve			379
Hydraulic system											
□	●	●	○	○	○			Checking the oil level in the hydraulic tank and topping up oil			381
					○			Changing the tank vent filter on the hydraulic tank			
			□	○	○			Change return filter insert (when the indicator light lights up with hydraulic oil at operating temperature)			
			○	○	○			Hydraulic system: change supply circuit filter			
□			□	○	○			Check the hydraulic system for leaks			
						○3000 h		Hydraulic tank - Change Liebherr hydraulic oil. Pay attention to the notes for oil analysis and dust intensive application!			
					○			Hydraulic tank - Change hydraulic oil of third party manufacturers. Pay attention to the notes for oil analysis and dust intensive application!			
			□	○	○			Hydraulic system: checking and adjusting hydraulic pressures according to adjustment check list			
Electrical system											
□	●	●	○	○	○			Check lighting			383
				○	○			Checking the battery connections for tight seating			
				○	○	✧		Check battery fluid level (at least 1 x a year)			
			○	○	○			Battery: checking the condition and correct routing of the degassing hose			
□	●	●	○	○	○			Electrical system: Checking function of load torque limitation			383
			□	○	○			Check control system of travel hydraulics and working hydraulic according to adjustment check list			

LWT93517492/02/01_08.2019/en

Ambient temperature	Mixing ratio
Up to -50 °C	40 % Water / 60 % anti-freeze and corrosion protection agent
Up to -37 °C	50 % Water / 50 % anti-freeze and corrosion protection agent

Tab. 50: Mixing ratio

Minimum quality requirement

Specification
LH-01-COL3A

Tab. 51: Minimum quality requirement

When using coolants of third party manufacturers, information about the change intervals is to be obtained from respective manufacturer or supplier.

5.3.5 Hydraulic oils

Liebherr recommendation

Ambient temperature	Name
	Liebherr Mineral oil
15 to 55 °C	Liebherr Hydraulic Basic 100
10 to 45 °C	Liebherr Hydraulic Basic 68
-20 to 40 °C	Liebherr Hydraulic HVI
	Liebherr PAO¹⁸⁾ biodegradable
-25 to 45 °C	Liebherr Hydraulic Plus
-40 to 30 °C	Liebherr Hydraulic Plus Arctic

Tab. 52: Liebherr recommendation

Minimum quality requirement

Specification
EMT LH-00-Minimum-HYE

Tab. 53: Minimum quality requirement

When using hydraulic oils or filters of third party manufacturers, information about the change intervals is to be obtained from the respective manufacturer or supplier.

¹⁷⁾ Premix = prepared mix (50 % water and 50 % anti-freeze and corrosion protection agent)

¹⁸⁾ PAO = Poly-alpha-olefin



Fig. 497: Opening engine bonnet

- ▶ Unlock the lock with the key.



WARNING

Faulty gas cylinders!
Injury.

- ▶ Ensure that the open position is maintained by the gas cylinders.




Fig. 498: Gas cylinder

- ▶ Open engine bonnet.
 - ▷ Engine bonnet is held in this position by the gas cylinders.

Troubleshooting

Engine bonnet is not held?

- ▶ Replace the faulty gas cylinders.



DANGER

Hot exhaust system!
Beware of burns.

- ▶ Let the exhaust system cool down.

5.7 Cooling system

5.7.1 Cooling system: checking the coolant level

Checking the coolant level

Expansion tank with filler pipe is located in the engine compartment.

Ensure that following requirements are met:

- Engine bonnet is open.
- Diesel engine has cooled down.



Fig. 510: Coolant container

When the coolant is below the mark **MIN**:

- ▶ Top up the coolant.

Topping up coolant

The coolant to be added must have the correct anti-freeze concentration.



Fig. 511: Risk of scalding



CAUTION

Hot, pressurised liquid!
Beware of burns.

- ▶ Let the engine cool down.

5.10 Hydraulic system

5.10.1 Checking the oil level in the hydraulic tank and topping up oil

Checking the hydraulic oil level

Ensure that following requirements are met:

- The hydraulic oil is cold.




Fig. 524: Sight gauge

- ▶ Check the oil level on the sight gauge.

If the hydraulic oil is not visible in the sight gauge:

- ▶ Top up hydraulic oil.

Topping up hydraulic oil



Fig. 525: Tank vent filter

- ▶ Unscrew the tank vent filter 1 on the hydraulic tank.

5.15 Axles, tires

5.15.1 Wheels: checking mounting tightness of wheel lugs

Make sure that a torque wrench for a measuring range in excess of 630 Nm is to hand.



Note

- ▶ Carry out one-off intervals at 50, 100 and 250 operating hours after every wheel change as well!



Fig. 537: Check the wheel lugs

Tightening torque of wheel lugs = 630 Nm.

- ▶ Check all wheel lugs of all four wheels for the required tightening torque.

5.15.2 Tyres: checking and adjusting air pressure in tyres

The tyre pressure has a considerable influence on the overall operation of machine.

The air pressure of the tyres is dependent on the tyres, on how the machine is used and on the working attachment that is attached.

Ensure that following requirements are met:

- Machine is parked on level and solid ground.
- The correct specified values for the tyre air pressure are available.
- The tyres are cold.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL