

MF 7700 - Maintenance

MF 7715
MF 7716
MF 7718



Dyna-VT

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

1.1 Introduction

1

1.1.1 Introduction - Safety instructions

T000967

Operator's Manual

NOTE: This Operator's Manual is widely published and distributed and the availability of the attachments indicated, whether fitted to the basic tractor or as an accessory, may vary depending on the country or region in which the tractor is used. To find out which attachments are available in a given region, contact a Massey Ferguson dealer.

The purpose of this manual is to enable the owner and the operator to operate the tractor appropriately under normal conditions of use. Providing they follow the instructions carefully, the tractor will give many years of service in the Massey Ferguson tradition.

Use for any other activity (particularly forestry work) is considered to be contrary to the intended use.

The commissioning of equipment by the Massey Ferguson dealer on the user's premises enables the dealer to ensure that these operating and service instructions are properly understood. Always consult the Massey Ferguson dealer if there is any part of this manual that you do not understand. It is important that these instructions are understood and followed.

This manual does not cover all operation and safety instructions relevant to the implements and accessories that may be fitted at the time of tractor delivery or later. It is essential that operators use and understand the Operator's Manuals relating to these implements and accessories.

IMPORTANT: This manual must always be kept with the tractor. For extra copies, contact your Massey Ferguson dealer.

This chapter in the Operator's Manual highlights certain basic safety-related situations that may be encountered during normal operation and servicing of the tractor and provides the information needed to handle these situations.

This chapter supplements any safety instructions given in other chapters of this manual.

It may be necessary to take additional precautions, depending on the implements and accessories used and the working conditions on-site or in the service area. Massey Ferguson can under no circumstances exercise direct control over the commissioning, operation, inspection, lubrication or servicing of the tractor. It is therefore YOUR responsibility to take suitable safety precautions in such areas.



WARNING:

It is your responsibility to read and understand the instructions that appear in this chapter before using the tractor. They must then be strictly adhered to throughout the working day.

Servicing, spare parts, accessories and conditions of use

Daily servicing should become a routine, and a logbook of operating hours should be kept.

When spare parts are required, it is important to use only genuine Massey Ferguson parts. Massey Ferguson dealers supply genuine parts and can offer advice concerning their fitting and use. The use of lower quality parts may cause serious damage. Customers are advised only to purchase their spare parts from an approved Massey Ferguson dealer. In the same way, you must only use accessories specifically adapted to your tractor.

Owing to the considerable variation in operating conditions, it is not possible for the manufacturer to formulate complete or absolute assertions in its publications concerning the performance or operating methods of its machines or to accept liability for any loss or damage which may result from such assertions or possible errors or omissions.


If the tractor is to be used in abnormal conditions which could cause damage (use in deep water or in paddy fields for instance), you should consult your Massey Ferguson dealer to obtain special instructions to prevent the warranty from becoming void.

These tractors are designed only for usual farming activities (intended use). Use for any other activity (particularly forestry work) is considered to be contrary to the intended use.

Strict compliance with the repairs, service and operating conditions as specified by Massey Ferguson is also an essential component of the intended use.

IMPORTANT: Massey Ferguson accepts no responsibility in the event of damage to equipment or personal injury resulting from improper use.

The tractor must only be used, serviced and repaired by personnel who have full knowledge of its specific features and who are aware of the applicable safety measures (prevention of accidents).

-  **WARNING:**
In poor conditions, slow down and be extra careful, and engage 4-wheel drive if fitted.

It is important to have good knowledge of the operation of the tractor as well as all of its accessories and attached implements.

Remember that rain, snow, ice, loose gravel or soft ground can change the performance of the tractor.

1.4.3 Filling the fuel tank

T001555

- Always switch off the engine before filling up.
- Do not smoke while refuelling the tractor. Keep away from naked flames *fig. 2*.
- Proceed with care to prevent any splashes.



Fig. 2.

I050353

Filling AdBlue™ or DEF

Avoid all contact with the eyes, skin and clothing.

- Proceed with care to prevent any splashes.
- If swallowed. If large quantities of this product are swallowed, seek medical advice immediately. Do NOT induce vomiting unless indicated to do so by medical staff. Do not administer liquid to a person who is unconscious.
- In case of contact with skin, rinse with plenty of water and remove contaminated clothing.
- In case of contact with the eyes, rinse immediately under running water. In the event of irritation, seek medical advice.
- If fumes are inhaled, breathe in fresh air and seek medical advice, if necessary.
- Avoid AdBlue™ or DEF coming into contact with other chemical products
- Urea spillages must not be discharged into the drains.



Fig. 3.

I050357

1.4.4 Mounting and dismounting the operator's seat

T000983

- Always use three-point contact with the tractor and face the tractor when mounting and dismounting. (Three-point contact means that both hands and one foot or one hand and both feet are in contact with the tractor at all times when getting on and off).
- Clean your shoes and wipe your hands before getting on the tractor.
- Use handrails, grab handles, ladders or steps (if fitted) when getting on and off.

Starting assistance


 **WARNING:**
Never use any starter fluid or aerosol sprays. This could cause an explosion and the risk of very serious injury.



Fig. 2.

I002864

1.7.3 Checks to be carried out after start-up

T000986

Controls and indicator lights

After having started the engine, check all the controls and all the indicator lights again. Ensure everything is functioning correctly.

 **WARNING:**
In case of malfunction of a control or an indicator light, resolve the problem before using the tractor.

Mastering of the tractor

Move slowly until you are sure that everything is operating correctly. Be certain that you have full control of the steering and brakes. If the differential is locked, unlock it before continuing your route.

Towing: permissible load and speed**WARNING:**

The stopping distance increases with the speed and weight of the trailed implements, and also on a slope. Whether they are fitted with a brake system or not, trailed implements that are too heavy for the tractor or that are towed at too high a speed may lead to a loss of control. Take account of the total weight of the trailed implement (including the load).

The maximum permitted trailed weights are indicated on the name plate. In particular, comply with the following loads:

- Trailled weight without brakes: 3000 kg
- Trailled weight with independent brake system: 6000 kg
- Inertia braked trailed weight: 16000 kg

Never tow an implement:

- at a speed exceeding the speed limit in force in the relevant country and
- if the true weight of the tractor/implement assembly is greater than the tractor total permissible loaded weight indicated on the name plate.

Towed equipment without brakes:

Do not tow equipment that does not have brakes:

- at speeds of more than 32 km/h; or
- at speeds above those recommended by the manufacturer; or
- with a mass (weight) that is over 1,5 t when fully loaded and is more than 1.5 times the mass (weight) of the tractor.

Towed equipment with brakes:

Do not tow equipment that has brakes:

- at speeds of more than 50 km/h; or
- at speeds above those recommended by the manufacturer; or
- with a mass (weight) more than 4.5 times the mass (weight) of the tractor when fully loaded;
- at speeds of more than 40 km/h if, when fully loaded, it has a mass (weight) more than 3.0 times the mass (weight) of the towing unit.

1.8.10 Front-end loader

T006905

**WARNING:**

The tractor must be fitted with a FOPS (Falling Object Protection Structure) roof if using a loader.

The programmable features of the joystick or other control MUST NOT be used to operate a loader. In order to prevent involuntary loader motion, the loader joystick controller must be a self neutralising type. When the operator releases his grip on the joystick, the joystick must return to a non-operational neutral position - except for float detent position in the loader lower direction.

Always read the implement instruction books fully for implements to be used with the tractor and comply with the safety instructions they contain.

For the attachment points, refer to the specifications chapter.

**DANGER:**

The use of front-end loaders involves the risk of falling objects; if used for forestry work there is a risk of objects penetrating into the passenger compartment.

This tractor is not designed for haulage applications; its use is prohibited unless you install a FORESTRY KIT; contact the dealer to find out if a forestry kit is available for this tractor model. Only a specific forestry kit can provide the necessary protection against falling trees and the penetration of objects.

2. Maintenance

2

2.1	Service guide	53
2.1.1	Service guide	53
2.2	Cab	56
2.2.1	Air conditioning system: condenser	56
2.2.2	Air conditioning system: checking the air conditioning system	56
2.2.3	Cab air filter	56
2.2.4	Cab attachment	58
2.2.5	Windscreen washer	58
2.3	Engine	59
2.3.1	Recommended products	59
2.3.2	Fuel	59
2.3.3	Biodiesel fuel	61
2.3.4	AdBlue™ or DEF	62
2.3.5	6-cylinder SisuDiesel engine	63
2.3.6	Engine oil level check	63
2.3.7	Draining the engine oil	64
2.3.8	Replacing the engine oil filter	65
2.3.9	Draining the AdBlue™ or DEF tank	65
2.3.10	Replacing the AdBlue™ or DEF filter	65
2.3.11	Fuel system: fuel prefilter	69
2.3.12	Fuel system: fuel filter	69
2.3.13	Checking and cleaning the fuel cooler	69
2.3.14	Fuel system: Water separator prefilter	70
2.3.15	Fuel system: bleeding	71
2.3.16	Fuel system: injection pump, regulator and injectors	71
2.3.17	Fuel system: T4F SCR engine injection	71
2.3.18	Air filter	71
2.3.19	Cooling system	72
2.3.20	Check and replace the main fan/alternator Poly-V belt	74
2.3.21	Check and replace the air conditioning/alternator Poly-V accessories belt	75
2.3.22	Check and replace the air compressor (pneumatic braking) Poly-V accessories belt	76
2.4	Transmission	78
2.4.1	Recommended products	78
2.4.2	Checking the transmission oil level	78
2.4.3	Draining the transmission oil	78
2.4.4	Filtering the transmission hydraulic system	79
2.4.5	Checking the level of the rear final drive units	80
2.4.6	Draining the rear final drives	81
2.4.7	Checking and cleaning the transmission oil cooler	81
2.4.8	Lubricating the rear PTO shaft	82
2.5	Brakes	83
2.5.1	Recommended products	83
2.5.2	Checking the regulator filter	83
2.5.3	Bleeding the brake system	83
2.5.4	Compressed air system protection	84
2.6	Front power take-off	85
2.6.1	Recommended products	85
2.6.2	Checking and cleaning the oil cooler of the front PTO	85
2.6.3	Draining oil	85
2.6.4	Lubricating the front PTO shaft	86
2.7	Rear power take-off (PTO)	87
2.7.1	Lubricating the rear PTO shaft	87

- Insulate all exposed pipework. Ensure that any pipework is short in length and designed to be disassembled if necessary.
- Only stock "winter" quality fuel during the cold weather season.
- Frequently clean the fuel filter bowl.
- Do not puncture the fuel filter.
- Ensure a spare filter is always available. If a blockage occurs, due to fuel waxing, changing the fuel filter will enable restarting.

2.3.3 Biodiesel fuel

T009064

Recommended fuel specification

IMPORTANT: *The use of EN 14214:2008 or ASTM D6751 biodiesel fuels is not authorised for T4F SCR engine engines.*

The chemical composition of biodiesel damages the depollution system.

Biodiesel fuel is authorised for AGCO Power Tier 3 engines, except for the T4F SCR engine engine.

It must comply with the EN 14214:2008 or ASTM D6751 standard.

Rape methyl esters (RME), vegetable oil methyl esters (VOME) and soy methyl esters, together known as fatty acid methyl esters (FAME) are all included in these standards.

EN 590:2009 diesel fuels can contain up to 7% of the biodiesel corresponding to standard EN 14214:2008. ASTM D975-09b diesel fuels can contain up to 5% of the FAE biodiesel corresponding to standard ASTM D6751-08.

For more information, contact your dealer

NOTE: *Unrefined, cold-pressed rapeseed oil, other unesterified vegetable oils or types of fuel such as ethyl alcohol and methanol MUST NOT BE USED in these products.*

This fuel requires a different type of engine design, with precombustion chambers or a specific type of injection system. Moreover, "domestic fuel" must not be used as its quality has been reduced by the refineries. It can no longer provide sufficient lubrication and the amount of heavy polycyclic aromatic hydrocarbons has been increased to a critical level.

Fuel storage

The biodiesel must be stored in compliance with the recommended standards to avoid any water absorption or deterioration.

Fuel must never be stored for more than 12 months. Under certain conditions, biodiesel deterioration may lead to corrosion of the metal components and cause the seals to split prematurely.

Never store fuel in a tank with a painted inner surface, as biodiesel dissolves many types of paint.

When you fill up the tractor, make sure that the fuel does not run down the side of the filler neck. If there is any spillage, wipe up any traces of fuel immediately.

Avoid splashing the hoses with fuel and wipe off any spillage as quickly as possible.

Engine servicing required

AGCO Power Tier 0, 1, 2 and 3 engines, except T4F SCR engine engines, can operate with 100% biodiesel. If a biodiesel fuel is used in these engines, the time between changes of oil, oil filters and fuel filters must be halved.

An additional water separator must also be installed.

Consult your dealer to obtain this additional equipment.

IMPORTANT: *The T4F SCR engine engine cannot operate with biodiesel fuel.*

General information

- If the oil level exceeds the "Max" mark on the dipstick, the engine oil must be replaced.
- If a fuel leak (oil increase/dilution) suddenly worsens, the cause must be identified and corrected.
- Biodiesel can be used at start-up temperatures down to approximately -16 °C.
- If the tractor needs to remain immobilised for at least 4 weeks, use pure diesel during the last hour of operation to avoid clogging various components and filters or damaging seals with a weaker resistance to biodiesel.
- As biodiesel is a very powerful solvent, any residue in the fuel system may become dislodged after using biodiesel. The fuel filters must therefore be replaced promptly after the first few times the tank is filled with biodiesel.

Replacing the filter element: Procedure

1. Drain the prefilter by opening the screw of the filter bowl (1).
2. Remove the bowl (2).
3. Unscrew the filter element (3) and discard it.
4. Refit a new element (lubricate the seal with fuel).
5. Refit the bowl (lubricate the seal with fuel).
6. Bleed the system ([see §2.3.15, page 71](#)).




Fig. 20.

I048867

2

2.3.15 Fuel system: bleeding

T023543

Procedure

To ensure correct operation of the engine, the fuel system must be in perfect condition and free of air.

1. Place a clean container under the prefilter to recover the fuel,
2. Undo the bleed screw (1) and fit a transparent pipe onto the port
3. Operate the pump (2) until the liquid flows through the bleed screw without any air
4. Retighten the bleed screw

5. Start the engine and allow it to run at idle for several minutes to completely bleed the system

NOTE: Never activate the starter for more than 30 seconds in one go to avoid overheating the starter and discharging the battery.

6. Check that there are no leaks
7. Repeat the operation if required.




Fig. 21.

I053408

2.3.16 Fuel system: injection pump, regulator and injectors

T001047

The injection pump, regulator and injectors must be checked and adjusted by the dealer or agent (in accordance with the service guide).

2.3.17 Fuel system: T4F SCR engine injection

T021254

The injection system must be checked and adjusted by the dealer or agent (in accordance with the service guide).

2.3.18 Air filter

T025661

Cleaning and replacement: Frequency

Main filter

- Only clean the main filter if the blockage indicator light comes on
- Replace the main filter (2) [fig. 22](#) after the blockage indicator light has lit up five times, or once a year

Procedure

NOTE: In order to access the plug, it may be necessary to remove the oil recovery unit.

1. Unscrew the plug (1); the oil level should be level with the filler plug.
2. Top up if necessary.




Fig. 5.

I055108

2

2.4.6 Draining the rear final drives

T021302

Frequency

Drain and replace the oil in the final drives every 2000 hours.

Procedure

1. Remove the drain plug (1) and the level plug for filling (see §2.4.5, page 80).
2. After completely draining the oil, refit the drain plug and then refill the rear final drives to the correct level with a recommended oil.

NOTE: Allow time for the oil to settle before re-checking the level.




Fig. 6.

I055106

2.4.7 Checking and cleaning the transmission oil cooler

T025679

Frequency

Check the cooler every day and, if necessary, clean using compressed air.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2.9 Rear linkage

2.9.1 Recommended products

T001063

IMPORTANT: The warranty remains valid only as long as the lubricants used comply with the following classifications, and no other products are used.

Grease: AGCO M.1105 or lithium multi-purpose grease in accordance with the N.L.G.I. indices:

- N.L.G.I. number 1: Temperature often drops below 7 °C
- N.L.G.I. number 2: Temperature often ranges from 7 °C to 27 °C
- N.L.G.I. number 3: Temperature often exceeds 27 °C

2

2.9.2 Lubricating the linkage shaft

T021261

Frequency

Lubricate the rear power lift shaft every 500 hours.

Procedure

1. Lubricate the rear linkage shaft ((1) grease nipple on each side of the shaft).




Fig. 1.

I055896

2.9.3 Three-point linkage: lubrication

T021332

Frequency

Check/lubricate the linkage mechanism once a week.

Lubrication points

IMPORTANT: The threaded parts and hitch pins must be correctly protected with grease.

- (1) Lift rams




Fig. 2.

I055996

Replacing the breather: Procedure

1. Pull to release the breather filter (3).
2. Replace the breather filter (3).





Fig. 8.


I055264





Number	Amperage	Size	Protected function
K15			Relay for reversing lights and reversing alarm
K16			Power supply relay in +BAT ³ of the right-hand console power socket
K17			Not used
K18			Power supply relay in +APC ² of the right-hand console power socket and the front right-hand fender arch power socket
K19			Low beam lamps relay
K20			Not used
K21			Relay for the hand rail work lights and the front implement accessories connector work light
K22			Relay for roof rotary beacon, front implement accessories connector rotary beacon
K23			Front roof work lights relay
K24			Brake lights relay
K25			Supply relay for fuse F3, fuse F4, fuse F5 and K27 relay control circuit
K26			Air conditioning compressor supply relay
K27			Supply relay for roof ventilation
K28			Isobus connectors +BAT ³ relay
K29			Supply relay for fuse F54
K30			Supply relay for fuse F36 and fuse F37
K31			Supply relay for fuse F26, fuse F27, fuse F28 and fuse F29
K32			Supply relay for fuse F30, fuse F31 and fuse F32
K33			Tractor relay +APC ²

1. + ACC = + 12 V accessory
2. + APC = + 12 V ignition on
3. + BAT = + 12 V batteries

 High-pressure transmission oil filter blockage indicator light	
Activating condition(s) – Indicator light permanently on = filter blocked, if transmission oil temperature is above 49 °C	
Cause(s)	Solution(s)
Filter blocked	Change the filter element.
Transmission oil polluted	Check the quality of the oil.
Faulty high-pressure transmission oil filter blockage switch	Check the blockage switch.

 Differential lock indicator light	
Activating condition(s) – Indicator light permanently on = differential lock engaged – Indicator light flashing quickly = differential lock error	
Cause(s)	Solution(s)
Error in one of the components	Contact the dealer.

 Rear PTO engaged indicator light	
Activating condition(s) – Indicator light flashing slowly = rear PTO pre-engaged – Indicator light permanently on = rear PTO engaged – Indicator light flashing quickly = rear PTO error	
Cause(s)	Solution(s)
Error in one of the components	Contact the dealer.

 Pressure light for brakes (ParkLock depending on model) and pneumatic brakes	
Activating condition(s) – Indicator light permanently on = pressure in pneumatic or hydraulic brake system too low	
Cause(s)	Solution(s)
Pressure in pneumatic brake system lower than 4 bar	Check the condition of the air connection couplers with the implement, the implement braking system and the pneumatic braking system.
Pressure in the ParkLock brake system (depending on model) is less than 70 bar; the ParkLock will not disengage	Check the hydraulic brake system, and disengage the ParkLock mechanically in order to move the tractor.
Braking pressure sensor faulty	Contact the dealer.

N o.	F MI	Components concerned	Causes	Standard modes	SCR Technology modes
65 1	13	Injector no. 1	Injector not calibrated	3	
65 1	14	Injector no. 1	Short circuit	3	
65 2	5	Injector no. 2	Current below normal: open circuit	3	
65 2	13	Injector no. 2	Injector not calibrated	3	
65 2	14	Injector no. 2	Short circuit	3	
65 3	5	Injector no. 3	Current below normal: open circuit	3	
65 3	13	Injector no. 3	Injector not calibrated	3	
65 3	14	Injector no. 3	Short circuit	3	
65 4	5	Injector no. 4	Current below normal: open circuit	3	
65 4	13	Injector no. 4	Injector not calibrated	3	
65 4	14	Injector no. 4	Short circuit	3	
65 5	5	Injector no. 5	Current below normal: open circuit	3	
65 5	13	Injector no. 5	Injector not calibrated	3	
65 5	14	Injector no. 5	Short circuit	3	
65 6	5	Injector no. 6	Current below normal: open circuit	3	
65 6	13	Injector no. 6	Injector not calibrated	3	
65 6	14	Injector no. 6	Short circuit	3	
67 7	3	Starter relay	Low voltage side above normal or short-circuited to +12 V		
67 7	5	Starter relay	Voltage below normal or open circuit		
67 7	6	Starter relay	Low voltage side above normal		
72 3	2	Camshaft speed sensor	Number and/or position of pulses unlikely	2	
72 3	8	Camshaft speed sensor	Deviation of the signal between the camshaft sensor and crankshaft sensor	2	
72 3	31	Camshaft speed sensor	No signal	2	
72 9	3	Grid Heater	Voltage above normal		

N o.	F MI	Components concerned	Causes	Standard modes	SCR Technology modes
520213	31	MOCSOP (redundant stop test)	Diagnostic error		
520214	31	MOCSOP (redundant stop test)	Diagnostic error		
520215	31	MOCSOP (redundant stop test)	Diagnostic error		
520216	31	MOCSOP (redundant stop test)	Diagnostic error		
520217	31	MOCSOP (redundant stop test)	Diagnostic error		
520218	31	MOCSOP (redundant stop test)	Loss of message synchronisation		
520219	31	MOCSOP (redundant stop test)	Error appeared when storing torque limitation in memory		
520220	31	MOCSOP (redundant stop test)	Incorrect response time		
520221	31	MOCSOP (redundant stop test)	Too many errors during execution		
520222	31	MOCSOP (redundant stop test)	Diagnostic error		
520223	31	MOCSOP (redundant stop test)	Diagnostic error		
520224	31	MOCSOP (redundant stop test)	Time exceeded		
520225	31	MOCSOP (redundant stop test)	Diagnostic error		
520226	31	MOCSOP (redundant stop test)	Diagnostic error		
520227	31	MOCSOP (redundant stop test)	Diagnostic error		
520228	12	CY320	Module multiple supply error		
520229	13	FADC	A/D fast converter calibration error	3	

No.	Components concerned	Causes
6.X.1B	X3 - Dyna-VT 540 rpm PTO speed solenoid valve	Control error
6.X.1C	X4 - 1000 rpm PTO speed solenoid valve	Control error
6.X.1D	X3 - Dyna-VT 540 rpm PTO speed solenoid valve	Control error
6.X.41	X128 - Rear PTO ON/OFF switch	Pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.42	X94 - PTO switch on left-hand fender	Pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.43	X94 - PTO switch on left-hand fender	Pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.45	X15 - PTO clutch speed sensor	NEUTRAL speed selection, PTO not activated, X15 displays a speed, the clutch disk does not separate, PTO brake does not engage selected speed, PTO clutch 100% engaged, over 20% difference between PTO clutch speed and engine speed. PTO clutch disk slips: Clutch slippage PTO clutch speed is lower than output shaft speed, X15 sensor supply voltage error.
6.X.50	X16 - PTO output shaft speed sensor	The PTO shaft speed is higher than 1300 rpm, signal error (X16 or X15). The selected speed is lower than the PTO output shaft speed, X16 sensor supply voltage error, speed solenoid valve (X4, X3) locked in "deactivated" position.
6.X.55	X717 - Linkage and power-take off keypad on pillar	Neutral switch pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.56	X717 - Linkage and power-take off keypad on pillar	540 rpm switch pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.57	X717 - Linkage and power-take off keypad on pillar	540E rpm switch pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.58	X717 - Linkage and power-take off keypad on pillar	1000 rpm switch pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.59	X717 - Linkage and power-take off keypad on pillar	1000E rpm switch pressed down for over 30 seconds, mechanical or electrical error on switch
6.X.60	X15 - PTO clutch speed sensor	Difference of at least 12% between the output shaft speed and PTO clutch speed, speed solenoid valve (X4, X3) incorrectly connected or seized up. Mechanical fault with speed selection. Signal error to sensors (X15, X16)
	X16 - PTO output shaft speed sensor	
6.X.A1	X128 - Rear PTO ON/OFF switch	Communication error
6.X.B0	X128 - Rear PTO ON/OFF switch	Initialisation error
6.X.B5	X717 - Linkage and power-take off keypad on pillar	Communication error with neutral switch
6.X.B6	X717 - Linkage and power-take off keypad on pillar	Communication error with 540 rpm switch
6.X.B7	X717 - Linkage and power-take off keypad on pillar	Communication error with 540E rpm switch

3. Technical specifications

3

3.1	General specifications	163
3.1.1	Model MF 7715 Dyna-VT	163
3.1.2	Model MF 7716 Dyna-VT	163
3.1.3	Model MF 7718 Dyna-VT	164
3.2	Cab	166
3.2.1	Noise levels (dB(A)) at operator's ears	166
3.2.2	Level of vibration felt through the seat	166
3.3	Engine	167
3.3.1	Engine specifications	167
3.3.2	Fuel system and air filter	167
3.3.3	Cooling	167
3.3.4	Tightening torques	168
3.4	Transmission	169
3.4.1	Forward speed for all models with transmission in Dyna-VT mode	169
3.4.2	Gearbox	169
3.4.3	Final drives	169
3.4.4	Rear differential lock	169
3.5	Brakes	170
3.5.1	Brake system technical specifications	170
3.5.2	Regulatory data on maximum permitted trailed weights	170
3.6	Front axle and steering	172
3.6.1	Four-wheel drive front axle	172
3.6.2	Steering	172
3.7	Power take-off	173
3.7.1	Specifications	173
3.7.2	Tightening torques	173
3.8	Linkage	174
3.8.1	Rear linkage	174
3.9	Auxiliary hydraulics	175
3.9.1	Hydraulic system	175
3.10	Electrical equipment	176
3.10.1	Electrical equipment technical specifications	176
3.11	Wheels and tires	177
3.11.1	Rim	177
3.11.2	Tyres	177
3.11.3	Tightening torques	177
3.12	Capacities and dimensions	178
3.12.1	Capacities	178
3.12.2	Dimensions and weights	178
3.12.3	Attachment points: Dyna-VT models without front linkage	180
3.12.4	Attachment points: Dyna-VT models with front linkage	182

For towed equipment:

Do not tow equipment:

- Without brakes and that, when fully loaded weighs over 3000 kg
- With independent brakes and that, when fully loaded weighs over 6000 kg
- With overrun brakes and that, when fully loaded weighs over 16000 kg
- With assisted brakes (hydraulic or air) that, when fully loaded weighs over 32000 kg

Total permitted weight of tractor-implement combination

	Weight technically permissible for the tractor/trailer assembly
	MF 7715 MF 7716 MF 7718
With trailer without brakes	15500 kg
With trailer equipped with independent brake	18500 kg
With trailer equipped with overrun brake	28500 kg
With trailer with hydraulic braking	44000 kg

Load and ballast distribution per axle

Axle load distribution

		4-wheel drive	
		MF 7715/MF 7716/MF 7718	
Weights of unladen vehicle based on optional equipment		min.	max.
		6400 kg	8000 kg
Total weight distribution	Front axle	2600 kg	3600 kg
	Rear axle	3900 kg	5200 kg

Ballast distribution per axle

		4-wheel drive	
		MF 7715/MF 7716/MF 7718	
Maximum technically permissible loaded weights of the vehicle		12500 kg	
Maximum distribution of weight per axle	Front axle	5900 kg	
	Rear axle	10500 kg	
Minimum percentage of maximum permissible distribution of weight between axles	Front axle	47%	
	Rear axle	84%	

When ballasting the tractor, observe the following conditions:

- The minimum load on the front axle must be more than 20% of the tractor weight at no load.
- The load capacity of the rear tires must be taken into account. Do not overload the rear axle. (Refer to the load capacity table).

Reference	X	Y	Z
1 ⁽¹⁾	M20 -1862 mm	-315 mm	-45 mm
2 ⁽¹⁾	M20 -1862 mm	-315 mm	-125 mm
3 ⁽¹⁾	M20 -947 mm	-280 mm	27,5 mm
4 ⁽¹⁾	M20 -947 mm	-280 mm	-37,5 mm
5	M20 -947 mm	-280 mm	-102,5 mm
6 ⁽¹⁾	M20 51 mm	-270 mm	30 mm
7 ⁽¹⁾	M20 51 mm	-270 mm	35 mm
8 ⁽¹⁾	M20 27 mm	-270 mm	-146,5 mm
9	M16 300 mm	-	-
10	M16 841 mm	-	-
11	M16 675 mm	-	-
12	M16 81 mm	-	-
13	M16 922 mm	-	-
14	M16 332 mm	-	-
15	M16 827 mm (no front-end weight)		
16	M16 1522 mm	576 mm	-240 mm
17	M16 1522 mm	705 mm	-240 mm
18	M16 1672 mm	576 mm	-240 mm
19	M16 1672 mm	705 mm	-240 mm
20	- 125 mm	-	-
21	- 283 mm	-	-
22	- 276 mm	-	-

1. Front-end loader attachment points

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL