



70Z6

SHOP MANUAL

Operational Performance Test
Troubleshooting

93208-00821



93208-00821
October 2018

SHOP MANUAL

WHEEL LOADER

70Z6

*Operational Performance Test
Troubleshooting*

Powered by CUMMINS QSB6.7 Engine
Serial No. 70C7-0101 and up

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 1 Introduction

Preparation for Performance Tests

Observe the following rules in order to carry out performance tests accurately and safely.

THE MACHINE


1. Repair any defects and damage found, such as oil or water leaks, loose bolts, cracks and so on, before starting to test.

TEST AREA and TOOL

1. Select a hard and flat surface.
2. Secure enough space to allow the machine to run straight more than 200 m (656 ft 2 in), and to make the steering operate.
3. If required, rope off the test area and provide signboards to keep unauthorized personnel away.
4. Prepare the measuring instruments and tools. Use MPDr. if possible.

PRECAUTIONS

1. Before starting to test, agree upon the signals to be employed for communication among coworkers. Once the test is started, be sure to communicate with each other using these signals, and to follow them without fail.
2. Operate the machine carefully and always give first priority to safety.
3. While testing, always take care to avoid accidents due to landslides or contact with high-voltage power lines. Always confirm that there is sufficient space for full swings.
4. Avoid polluting the machine and the ground with leaking oil. Use oil pans to catch escaping oil. Pay special attention to this when removing hydraulic pipings.



T105-06-01-003

MAKE PRECISE MEASUREMENT

1. Accurately calibrate test instruments in advance to obtain correct data.
2. Carry out tests under the exact test conditions prescribed for each test item.
3. Repeat the same test and confirm that the test data obtained can be produced repeatedly. Use mean values of measurements if necessary.

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 2 Standard


Main Pump P-Q Diagram

- P-Q Control (Torque Control)
(Reference: Measured at Test Stand)
 - Rated Pump Speed: 2200 min⁻¹ (rpm)
 - Hydraulic Oil Temperature: 50±5 °C (122±9 °F)

 NOTE: Refer to T4-5-16.

Points on P-Q Line

	Delivery Pressure MPa (kgf/cm ²)	Flow Rate L/min
A	4.9 (50)	210±3
B	15.7 (160)	210±5
C	23.5 (240)	185±6
D	27.4 (280)	158±6



T4GB-04-02-001

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 4 Machine Performance Test


Service Brake Function Check

Summary:

1. Check the performance of the service brake.
2. The braking capability of the brake is an item of safety control. Be sure to conduct the performance test.

Preparation:

1. Adjust air pressure of the tires evenly in advance.
 - Bias Tire: 325 kPa (3.3 kgf/cm²) (47 PSI)
 - Radial Tire: 375 kPa (3.8 kgf/cm²) (54 PSI)
2. On a paved dry road, prepare a 150 m (492 ft) straight travel course (a 100 m (328 ft) of acceleration zone and a 50 m (164 ft) of test track) and set the brake starting point.
3. Empty the bucket and hold the lift arm with it floated 0.4 to 0.5 m (1 ft 4 in to 1 ft 8 in) above the ground.
4. Maintain the hydraulic oil temperature at 50±5 °C (122±9 °F). Warm the axle oil satisfactorily by repeating travel operation and brake operation. Make a warm up operation so that the indicators of the coolant temperature monitor and the torque converter oil temperature monitor should rise above the horizontal position.



- | | | | |
|----|---------------------------------------|----|----------------------|
| a- | 0.4 to 0.5 m (1 ft 4 in to 1 ft 8 in) | c- | Stopping Point |
| b- | Stopping Distance | d- | Brake Starting Point |

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 4 Machine Performance Test

Control Lever Operating Force


Summary:

1. Measure a play and operating condition of each control lever, pedal, and steering wheel, and measure operating force of them.
2. Measure maximum operating force of each control lever, pedal, and steering wheel.
3. Measure the lever stroke along the control lever operation from the grip center of each control lever. Measure at 150 mm (6 in) from the pedal support of each pedal.

Preparation:

1. Empty the bucket and hold the lift arm being floated 0.4 to 0.5 m (1 ft 4 in to 1 ft 8 in) above the ground.
2. Maintain the hydraulic oil temperature at 50 ± 5 °C (122 ± 9 °F).

Travel Position



M4GB-04-001

- a- 0.4 to 0.5 m (1 ft 4 in to 1 ft 8 in)

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 5 Component Test

Loading Circuit Main Relief Set Pressure


Summary:

Measure the main relief valve set pressure at the delivery port in main pump while operating the lift arm/bucket control lever.


 **NOTE:** Measure the pressure by using the MPDr.

Preparation:

1. Stop the engine.
2. Push the air bleed valve on top of the hydraulic oil tank and bleed air.
3. Remove the plug (G1/4) from delivery pressure check port (1) on the main pump. Install the adapter, the hose, and the pressure gauge.

 : 6 mm (0.24 in)


4. Start the engine. Confirm that no oil leakage is observed at the pressure gauge connection.
5. Maintain the hydraulic oil temperature at 50±5 °C (122±9 °F).



TNDB-04-05-008

1- Pump Delivery Pressure Check Port

2- Pump Delivery Pressure Sensor

 **NOTE:** Available Tool No.
 Pressure gauge: ST 6941
 Adapter: ST 6069
 Hose: ST 6943

Measurement:

1. Select the following conditions:

Accelerator Pedal	Power Mode Switch	Parking Brake Switch	Forward/Reverse Lever
Full stroke	ON	ON	N

2. Operate the bucket or lift arm control levers slowly, operate each cylinder to the stroke end, and relieve each function.
3. Repeat the measurement three times and calculate the mean values.

Evaluation:

Standard (lift arm/bucket relief operation):
 27.4 ~ 29.3 MPa (3974 ~4250 PSI)

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 5 Component Test








- Pilot Characteristics

Summary:

Main pump performance is checked by measuring the pump flow rate by using hydraulic tester (5) installed at the main pump delivery port to be measured. Use MPDr. and pressure gauge (18) at the same time.

IMPORTANT: This measurement procedure is a simple method. In order to measure accurately, disconnect the return circuit from the manifold valve and connect it to the hydraulic oil tank.

Preparation:

1. While referring to steps 1 to step 3 on T4-5-16, install hydraulic tester (5) to the main pump to be measured.
2. Disconnect the hose from regulator port Pi1 (21). Install the plug (G1/4) to the removed hose.
 : 19 mm (0.75 in)
3. Connect regulator port Pi2 (8) to the hydraulic oil tank.
 : 19 mm (0.75 in)
4. Install adapters (15) (3 used) to pressure reducing valve (16). Remove plug (23) from manifold valve (1). Install adapter (13) and hose (14). Connect hose (14) to port P1 of pressure reducing valve (16).
 : 8 mm (0.3 in)
 : 19 mm (0.75 in)
5. Install tee (17) to port P2 of pressure reducing valve (16). Connect pressure gauge (18) and hose (9) to tee (17). Connect hose (9) to the regulator (c).
 : 19 mm (0.75 in)
6. Connect hose (19) and tee (20) to port T of pressure reducing valve (16). Disconnect hose (10) from manifold valve port DR4 (22). Install tee (20) to manifold valve port DR4 (22). Connect hoses (10, 19) to tee (20).
 : 22, 27 mm (0.87, 1.06 in)
7. Remove the vacuum pump. Loosen plug (12) on top of the pump casing. Bleed air from the casing until oil only comes out.
 : 41 mm (1.61 in)
8. Fully open the loading valve of hydraulic tester (5).
9. Start the engine. Confirm that no oil leakage is observed at the pressure gauge connection.

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 5 Component Test

Brake Accumulator Pressure


CAUTION: If air is mixed in the brake system, the brake function is reduced and serious hazard may occur. Bleed air from the brake system after removing and installing the pipe lines and replacing hydraulic oil. (Refer to Troubleshooting B.)

Summary:

Measure the accumulated brake pressure at the accumulator output port. The accumulated brake pressure varies according to operation of the brake. Record the maximum value.

Preparation:


CAUTION: Set blocks (1) onto the front and rear tires in order not to move the machine. Keep away from the machine.



1. Stop the engine.
2. Push the air bleed valve on top of the hydraulic oil tank and bleed air.
3. Depress the brake pedal at least 50 strokes in order to decrease the accumulated pressure left in accumulator (5) of the brake circuit.
4. Disconnect hoses (3, 4) from brake charge valve (2). Install the tee (7/16-20UNF) and a pressure gauge between brake charge valve (2) and hoses (3, 4).

 : 19 mm (0.75 in)

5. Start the engine. Confirm that no oil leakage is observed at the pressure gauge connection.
6. Maintain the hydraulic oil temperature at 50 ± 5 °C (122 ± 9 °F).



- | | |
|--|------------------------------|
| 2- Brake Charge Valve (Unloader Valve) | 5- Service Brake Accumulator |
| 3- Hose | 6- Brake Valve |
| 4- Hose | 7- Parking Brake Accumulator |

SECTION 4 OPERATIONAL PERFORMANCE TEST
Group 5 Component Test

(Blank)

Air Conditioner Controller Fault Code List.....	T5-5-24
ECM Fault Code List.....	T5-5-25
TCU Fault Code List	T5-5-41
MC Fault Codes 111000 to 111002.....	T5-5-61
MC Fault Code 111003.....	T5-5-62
MC Fault Codes 111006, 111007, 111011	T5-5-65
CAN1 Harness Check	T5-5-66
MC Fault Codes 111014, 111025	T5-5-70
MC Fault Code 111100.....	T5-5-71
MC Fault Code 111103, 111106, 111107	T5-5-72
MC Fault Codes 111205.....	T5-5-73
MC Fault Codes 111200, 111203	T5-5-74
MC Fault Codes 111217, 111312	T5-5-75
MC Fault Codes 111204, 111206	T5-5-76
MC Fault Code 111208.....	T5-5-77
MC Fault Codes 111311, 111313	T5-5-78
MC Fault Code 111411	T5-5-79
MC Fault Code 111412.....	T5-5-80
MC Fault Code 111413.....	T5-5-81
MC Fault Code 111422.....	T5-5-82
MC Fault Code 111901	T5-5-83
Specification of Hydraulic Oil Temperature	
Sensor.....	T5-5-83
Hydraulic Oil Temperature Sensor.....	T5-5-83
MC Fault Codes 120003, 120004	T5-5-84
MC Fault Codes 120014	T5-5-85
Column Display Controller Fault Code 115001	T5-5-87
Column Display Controller Fault Code 115011	T5-5-88
Column Display Controller (Information)	
Fault Codes 120500 to 120503, 120505	T5-5-89
Column Display Controller Fault Codes	
120506, 120507, 120510 to 120512, 120515,	
120516, 120518.....	T5-5-90

Group 6 Troubleshooting B

Troubleshooting B (Machine Diagnosis by Using	
Troubleshooting Symptom) Procedure.....	T5-6-1
Relationship between Machine Trouble Symptoms	
and Related Parts.....	T5-6-3
Correlation between Trouble Symptoms and	
Part Failures	T5-6-24
Engine System Troubleshooting.....	T5-6-25
All Actuator System Troubleshooting	T5-6-27
Front Attachment System Troubleshooting	T5-6-31
Steering System Troubleshooting.....	T5-6-35
Travel System Troubleshooting	T5-6-37
Brake System Troubleshooting.....	T5-6-41
Other System Troubleshooting	T5-6-43
Engine System Troubleshooting	T5-6-47
All Actuator System Troubleshooting.....	T5-6-53
Front Attachment System Troubleshooting.....	T5-6-59
Steering System Troubleshooting	T5-6-69
Travel System Troubleshooting	T5-6-73
Brake System Troubleshooting	T5-6-83
Other System Troubleshooting.....	T5-6-87
Exchange Inspection	T5-6-101
Air Bleeding Procedures for Brake (Axle).....	T5-6-103

Group 7 Air Conditioner

Outline	T5-7-1
Component Layout.....	T5-7-2
Functions of Main Parts	T5-7-6
Troubleshooting.....	T5-7-11
How to Display and Delete Air Conditioner	
Controller Fault Code.....	T5-7-11
Air Conditioner Controller Fault Code List.....	T5-7-12
Air Conditioner Controller Fault Codes	
E11 to E22.....	T5-7-13
Air Conditioner Controller Fault Codes	
E43 to E92.....	T5-7-14
Faulty cooling (1)	T5-7-16
Faulty cooling (2)	T5-7-17
Faulty cooling (3)	T5-7-18
Faulty cooling (4)	T5-7-20
Faulty cooling (5)	T5-7-22
Faulty heating (1).....	T5-7-24
Faulty heating (2).....	T5-7-26
Others.....	T5-7-27
Blower motor does not operate.....	T5-7-30
Compressor clutch does not operate.....	T5-7-31
Cooling circuit check by using	
manifold gauge.....	T5-7-32
Work after Replacing Components	T5-7-34
Refill Compressor Oil	T5-7-35
Charge Air Conditioner with Refrigerant	T5-7-36
Hose and Pipe Tightening Torque.....	T5-7-44


SECTION 5 TROUBLESHOOTING


Group 1 Diagnosing Procedure

Fuse Inspection

Cracks in a fuse are so fine that it is very difficult or impossible to find by visual inspection. Use a circuit tester in order to correctly inspect fuse continuity. Use a circuit tester in order to correctly inspect fuse continuity by following the instructions described below.


1. Set the key switch to the ON position. When the key switch is in the ON position, current from key switch terminal M turns the battery relay ON so that electric power is supplied to all circuits except the glow plug relay circuit. (Refer to the circuit diagram.)
2. Remove the fuse box cover. Set a circuit tester. (Measurement Range: 0 to 30 V)
3. Ground the negative probe of circuit tester to the body. Touch the terminals located (e) of fuse box one-by-one with the positive probe of circuit tester. When normal continuity of a fuse is intact, the circuit tester will indicate 20 to 25 V (battery voltage).

 **NOTE:** Check the glow plug relay circuit fuse with the key switch set in the ON position and follow the procedure in step 3.




M178-07-034

- d- Terminals connected to the power source
- e- Terminals connected to loads (accessories)



MNEC-01-047

- a- Fuse Box A
- b- Fuse Box B
- c- Relay Box



M178-07-034

SECTION 5 TROUBLESHOOTING

Group 1 Diagnosing Procedure


Engine	Key Switch	Location to be Measured	Specification
Accessory Circuit			
Stopped	ON	Between (12) and Ground: Key Switch (ACC)	20 to 25 V
Stopped	ON	Between (13) and Ground: Radio	20 to 25 V
Stopped	ON	Between (5) and Ground: Fusible Link A (65A)	20 to 25 V

SECTION 5 TROUBLESHOOTING

Group 2 Monitor

Monitor Display


- 1- Monitor Display
- 2- Monitor Display Mode Switch
- 3- Monitor Display Selection Switch (Up)
- 4- Monitor Display Selection Switch (Down)
- 5- Speedometer
- 6- Machine Information Display
- 7- Hold Indicator
- 8- Forward/Reverse and Shift Position Indicator
- 9- Ride Control Indicator (Option)
- 10- ECO Indicator




MNDB-01-008

Vehicle Information Display (6)

- 12- Engine Speed Display
- 13- Coolant Temperature Display
- 14- Transmission Oil Temperature Display
- 15- Hydraulic Oil Temperature Display
- 16- Fuel Consumption Display
- 17- (Unused)
- 18- Hour Meter Display
- 19- Average Fuel Consumption Display
- 20- Odometer Display
- 21- Fault Code Display
- 22- (Unused)



MNDB-01-033



MNDB-01-033

SECTION 5 TROUBLESHOOTING


Group 3 e-Service

List of Frequency Distribution Data	
Item	Details
Pump Load	Frequency distribution of main pump delivery pressure
Radiator Coolant Temperature (79 °C or less)	Total hours when coolant temperature is less than 80 °C during a day.
Radiator Coolant Temperature (80 to 93 °C)	Total hours when coolant temperature is 80 °C or more and less than 94 °C during a day.
Radiator Coolant Temperature (94 to 104 °C)	Total hours when coolant temperature is 94 °C or more and less than 105 °C during a day.
Radiator Coolant Temperature (105 °C or more)	Total hours when coolant temperature is 105 °C or more during a day.
Hydraulic Oil Temperature (49 °C or less)	Total hours when hydraulic oil temperature is less than 50 °C during a day.
Hydraulic Oil Temperature (50 to 89 °C)	Total hours when hydraulic oil temperature is 50 °C or more and less than 90 °C during a day.
Hydraulic Oil Temperature (90 to 99 °C)	Total hours when hydraulic oil temperature is 90 °C or more and less than 100 °C during a day.
Hydraulic Oil Temperature (100 °C or more)	Total hours when hydraulic oil temperature is 100 °C or more during a day.
Torque Converter Oil Temperature (49 °C or less)	Total hours when torque converter oil temperature is less than 50 °C during a day.
Torque Converter Oil Temperature (50 to 89 °C)	Total hours when torque converter oil temperature is 50 °C or more and less than 90 °C during a day.
Torque Converter Oil Temperature (90 to 109 °C)	Total hours when torque converter oil temperature is 90 °C or more and less than 110 °C during a day.
Torque Converter Oil Temperature (110 °C or more)	Total hours when torque converter oil temperature is 110 °C or more during a day.

SECTION 5 TROUBLESHOOTING

Group 4 Component Layout

Electrical System (Cab)



TNED-01-02-029


TNEJ-01-02-013

- | | | |
|---|--|---|
| 1- Radio | 6- Components Related with Controllers and Relays (Refer to T5-4-7.) | 11- Front Wiper Motor |
| 2- Upper Switch Panel (Option) | 7- Accelerator Pedal Sensor (Accelerator Pedal) | 12- Components Related with Monitor and Switches (Refer to T5-4-9.) |
| 3- Speaker | 8- Brake Light Switch | 13- GPS Antenna (Option) |
| 4- Rear Wiper Motor | 9- Brake Pedal | 14- Communication Antenna (Option) |
| 5- Components Related with Right Console (Refer to T5-4-8.) | 10- Brake Pedal (Option) | |

SECTION 5 TROUBLESHOOTING

Group 4 Component Layout


Fan Valve (Option)



TNEE-01-02-031

- | | |
|--|--------------------------------------|
| 1- Fan Speed Control Solenoid Valve | 3- Fan Control Valve |
| 2- Fan Reverse Rotation Control Solenoid Valve | 4- Fan Reverse Rotation Spool |
| | 5- Fan Pump Delivery Pressure Sensor |

Priority Valve



TNDB-01-02-033

- | |
|---------------------------------|
| 6- Main Relief Valve (Steering) |
|---------------------------------|

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

MPDr. Fault Code Reference Table (Continued)

Fault Code	MPDr. Message	Category	Reference 1	Reference 2
114100-2	Communication Terminal: Abnormal EEPROM	Communication Terminal	T5-5-24	-
114101-2	Communication Terminal: Abnormal IB/OB Queue	Communication Terminal	T5-5-24	-
114102-2	Communication Terminal: Abnormal Local Loop Back	Communication Terminal	T5-5-24	-
114103-2	Communication Terminal: No Satellite Found	Communication Terminal	T5-5-24	-
114104-2	Communication Terminal: Remote Loop Back Error 1	Communication Terminal	T5-5-24	-
114105-2	Communication Terminal: Remote Loop Back Error 2	Communication Terminal	T5-5-24	-
114106-2	Communication Terminal: Transmission/Receiving Data Unmatched	Communication Terminal	T5-5-24	-

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

Proportional Solenoid Valve Failure

Fault Code	Trouble or MPDr. Message	Cause	Symptoms in Machine Operation When Trouble Occurs	Remedy
111411-2	Hydraulic Fan Reverse Rotation P/S Valve Abnormal FB	Solenoid valve output: 140 mA or more, feedback current: More than 920 mA or less than 70 mA; both are detected.	The fan reverse rotation control becomes ineffective. Fan rotation direction (in normal / reverse) cannot change manually and automatically.	Check the wire harness.
111411-3	Hydraulic Fan Reverse Rotation P/S Valve FB High Current	Current: more than 920 mA	Fan rotation direction is fixed in reverse.	Check the wire harness.
111411-4	Fan Reverse Rotation P/S Valve FB Low Current	Current: less than 70 mA	Fan rotation direction (in normal / reverse) cannot change manually and automatically.	Check the wire harness.

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

Fault Code (MP.Dr.)	Trouble (Cause)	Fault Code (INSITE)	Lighting Indicator
97-3	Water in Fuel Indicator Sensor Circuit-Voltage Above Normal, or Shorted to High Source. High voltage detected at the water in fuel circuit.	428	Service Indicator
97-4	Water in Fuel Indicator Sensor Circuit-Voltage Below Normal, or Shorted to Low Source. Low voltage detected at the water in fuel circuit.	429	Service Indicator
97-15	Water in Fuel Indicator-Data Valid but Above Normal Operational Range-Least Severe Level. Water has been detected in the fuel filter.	418	Service Indicator (Blinking)
100-1	Engine Oil Rifle Pressure-Data Valid but Below Normal Operational Range-Most Severe Level. Oil pressure signal indicates oil pressure below the engine protection critical limit.	415	Engine Warning Indicator
100-2	Engine Oil Rifle Pressure-Data Erratic, Intermittent, or Incorrect. An error in the engine oil pressure switch signal was detected by the ECM.	435	Service Indicator
100-3	Engine Oil Rifle Pressure 1 Sensor Circuit-Voltage Above Normal, or Shorted to High Source. High signal voltage detected at the engine oil pressure circuit.	135	Service Indicator
100-4	Engine Oil Rifle Pressure 1 Sensor Circuit-Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at engine oil pressure circuit.	141	Service Indicator

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

Fault Code (MP.Dr.)	Trouble (Cause)	Fault Code (INSITE)	Lighting Indicator
656-5	Injector Solenoid Driver Cylinder 6 Circuit-Current Below Normal, or Open Circuit. High resistance detected on injector Number 6 circuit or no current detected at Number 6 injector driver or return pin when the voltage supply at the harness is on.	325	Service Indicator
677-3	Starter Relay Driver Circuit-Voltage Above Normal, or Shorted to High Source. Open circuit or high voltage detected at starter lockout circuit.	584	Service Indicator
677-4	Starter Relay Driver Circuit-Voltage Below Normal, or Shorted to Low Source. Low voltage detected at starter lockout circuit.	585	Service Indicator
697-3	Auxiliary PWM Driver 1 Circuit-Voltage Above Normal, or Shorted to High Source. High signal voltage detected at the analog torque circuit.	2557	Service Indicator
697-4	Auxiliary PWM Driver 1 Circuit-Voltage Below Normal, or Shorted to Low Source. Low signal voltage detected at the analog torque circuit.	2558	Service Indicator
702-3	Auxiliary Input/Output 2 Circuit-Voltage Above Normal, or Shorted to High Source. High signal voltage or open circuit has been detected at the auxiliary input/output 2 circuit.	527	Service Indicator
703-3	Auxiliary Input/Output 3 Circuit-Voltage Above Normal, or Shorted to High Source. Low signal voltage has been detected at the auxiliary input/output 2 circuit.	529	Service Indicator
723-2	Engine Camshaft Speed / Position Sensor-Data Erratic, Intermittent, or Incorrect. The ECM has detected an error in the camshaft position sensor signal.	778	Service Indicator

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

TCU Fault Code	Trouble	Cause	Behavior of TCU	Repair Procedure
5480-3	Abnormal First Speed Clutch Proportional Solenoid Valve High Voltage	Shorted circuit in power circuit because of faulty wire harness or faulty connector. Faulty proportional solenoid valve.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel only at first or second speed. If other proportional solenoid valve is abnormal, TCU is fixed to neutral.	Check the wire harness between TCU and transmission control valve. Check the connector between TCU and transmission control valve. Check resistance in the proportional solenoid valve. (19 Ω at 20 °C (68 °F)) Check the internal wire harness in transmission control valve.
5480-4	Abnormal First Speed Clutch Proportional Solenoid Valve Low Voltage	Grounding to body because of faulty wire harness or faulty connector. Faulty shorted circuit to other proportional solenoid valve output circuit in TCU because of faulty wire harness or faulty connector. Faulty proportional solenoid valve.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel only at first or second speed. If other proportional solenoid valve is abnormal, TCU is fixed to neutral.	Check the wire harness between TCU and transmission control valve. Check the connector between TCU and transmission control valve. Check resistance in the proportional solenoid valve. (19 Ω at 20 °C (68 °F)) Check the internal wire harness in transmission control valve.
5480-5	Open Circuit in First Speed Clutch Proportional Solenoid Valve	Faulty contact of wire harness, connector, and TCU. Faulty proportional solenoid valve.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel only at first or second speed. If other proportional solenoid valve is abnormal, TCU is fixed to neutral.	Check the wire harness between TCU and transmission control valve. Check the connector between TCU and transmission control valve. Check resistance in the proportional solenoid valve. (19 Ω at 20 °C (68 °F)) Check the internal wire harness in transmission control valve.

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

TCU Fault Code	Trouble	Cause	Behavior of TCU	Repair Procedure
5675-2	High-Speed Forward Clutch Slipping. When operating the high-speed forward clutch, if the value calculated by the signal of transmission intermediate shaft speed sensor is different from the actual value of torque converter output speed sensor, TCU determines that the clutch slipping occurs.	High-speed forward clutch pressure is low. Main clutch pressure is low. Faulty transmission intermediate shaft speed sensor. Faulty torque converter output speed sensor. Faulty clutch.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel at first or second speed. If other clutch is abnormal, TCU is fixed to neutral.	Check the high-speed forward clutch pressure. Check the main clutch pressure. Check the signal of transmission intermediate shaft speed sensor. Check the signal of torque converter output speed sensor. Replace the clutch.
5680-2	Low-Speed Forward Clutch Slipping. When operating the low-speed forward clutch, if the value calculated by the signal of transmission intermediate shaft speed sensor is different from the actual value of torque converter output speed sensor, TCU determines that the clutch slipping occurs.	Low-speed forward clutch pressure is low. Main clutch pressure is low. Faulty transmission intermediate shaft speed sensor. Faulty torque converter output speed sensor. Faulty clutch.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel at first or second speed. If other clutch is abnormal, TCU is fixed to neutral.	Check the low-speed forward clutch pressure. Check the main clutch pressure. Check the signal of transmission intermediate shaft speed sensor. Check the signal of torque converter output speed sensor. Replace the clutch.
5685-2	Reverse Clutch Slipping. When operating the reverse clutch, if the value calculated by the signal of transmission intermediate shaft speed sensor is different from the actual value of torque converter output speed sensor, TCU determines that the clutch slipping occurs.	Reverse clutch pressure is low. Main clutch pressure is low. Faulty transmission intermediate shaft speed sensor. Faulty torque converter output speed sensor. Faulty clutch.	Turn TCU to neutral. After returning the forward/reverse lever to neutral, operate it again. Then, machine can travel at first or second speed. If other clutch is abnormal, TCU is fixed to neutral.	Check the reverse clutch pressure. Check the main clutch pressure. Check the signal of transmission intermediate shaft speed sensor. Check the signal of torque converter output speed sensor. Replace the clutch.

SECTION 5 TROUBLESHOOTING

Group 5 Troubleshooting A

CAN1 Harness Check

Preparation

- Before continuity check, set the key switch to the OFF position.

Evaluation

	Continuity (0 Ω)	Discontinuity (∞ Ω)
Continuity check (open circuit)	Correct	Discontinuity
Discontinuity check (shorted circuit)	Shorted circuit	Correct

Inspection	CAN Harness	MC	ECM	TCU	Information Controller	Column Display Controller	A/C
Continuity check between MC and each controller	High side	#A28	#B46	#25	#C5	#2-B30	#8
	Low side	#A29	#B47	#26	#C11	#2-B29	#9
Discontinuity check between CAN circuit and ground circuit in each controller	High side	#A28-#D1	#B46-#A1	#25-#1	#C5-#C14	#2-B30-#1-B28	#8-#26
		#A28-#E1	#B46-#A2	#25-#2	#C5-#C15	-	-
		#A28-#E2	-	-	-	-	-
		#A28-#E5	-	-	-	-	-
		#A28-#E6	-	-	-	-	-
	Low side	#A29-#D1	#B47-#A1	#26-#1	#C5-#C14	#2-B29-#1-B28	#9-#26
		#A29-#E1	#B47-#A2	#26-#2	#C5-#C15	-	-
		#A29-#E2	-	-	-	-	-
		#A29-#E5	-	-	-	-	-
		#A29-#E6	-	-	-	-	-

SECTION 5 TROUBLESHOOTING


Group 5 Troubleshooting A


MC Fault Codes 111204, 111206

Preparation

- Check the wiring connections first.
- Connect the test harness (Tool No. ST 6701) and dummy sensor equivalent to #4436271.
- Before inspection, set the key switch to the ON position.

Fault Code	Trouble or MPDr. Message	Inspection Method	Evaluation	Cause
111204-3	Pump Delivery Pressure Sensor Circuit High Input	Retry by using MPDr.	Un-displayed fault code	Faulty sensor.
		Measure voltage between B and body.	Voltage: 4.75 V or more	Shorted circuit in wire harness #1 and #2.
111204-4	Pump Delivery Pressure Sensor Circuit Low Input	Retry by using MPDr.	Un-displayed fault code	Faulty sensor.
		Measure voltage between A and body.	Voltage: less than 0.25 V	Open circuit in wire harness #1.
		Measure voltage between A and C (GND).	Voltage: less than 0.25 V	Open circuit in wire harness #3.
		-	Normal in above check.	Open circuit in wire harness #2.
111206-3	Hyd. Fan Circuit Pressure Sensor Circuit High Input	Retry by using MPDr.	Un-displayed fault code	Faulty sensor.
		Measure voltage between B and body.	Voltage: 4.75 V or more	Shorted circuit in wire harness #1 and #2.
111206-4	Hyd. Fan Circuit Pressure Sensor Circuit Low Input	Retry by using MPDr.	Un-displayed fault code	Faulty sensor.
		Measure voltage between A and body.	Voltage: less than 0.25 V	Open circuit in wire harness #1.
		Measure voltage between A and C (GND).	Voltage: less than 0.25 V	Open circuit in wire harness #3.
		-	Normal in above check.	Open circuit in wire harness #2.

 **NOTE:** The pump delivery pressure sensor is installed to the hydraulic pump. (See p. T5-4-15.)
The fan circuit pressure (fan pump delivery pressure) sensor is located above the fuel tank. (See p. T5-4-13.)



TDA-05-06-003

SECTION 5 TROUBLESHOOTING
Group 5 Troubleshooting A

(Blank)

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

Parts Item	Forward/Reverse Selector Switch (Option)	Forward/Reverse Switch (Option)
Function	Shifts forward/reverse lever and forward/reverse switch operations.	Shifts forward clutch solenoid valve, and reverse clutch solenoid valve of transmission.
Symptoms in control system when trouble occurs	TCU makes forward/reverse lever operation effective.	TCU makes forward/reverse lever operation effective.
Symptoms in machine operation when trouble occurs	Functions of forward/reverse lever become effective.	Functions of forward/reverse lever become effective.
Evaluation by Fault Code	-	TCU: 5040
Evaluation by Monitoring	TCU: Forward/Reverse Selector Switch	TCU: Option Forward/Reverse Switch (N)/(F)/(R)
Evaluation by using Test Harness	-	-
Note	The operation is effective with forward/reverse lever and forward/reverse switch set in the neutral position.	When forward/reverse lever is operated, forward/reverse selector switch operation becomes ineffective. (forward/reverse lever priority)
Descriptions of Control (Refer to F&S S/M)	T2-2, T2-5	T2-2, T2-5

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

Parts	Machine Speed Sensor
Item	
Function	Detects transmission output shaft speed.
Symptoms in control system when trouble occurs	When abnormality is detected, the following symptoms occur.
Symptoms in machine operation when trouble occurs	The speed meter continues to display 0 km/h. The overrun alarm control is not effective. The ride control (option) is not effective.
Evaluation by Fault Code	TCU: 5170
Evaluation by Monitoring	MC: Machine Speed Pulse
Evaluation by using Test Harness	-
Note	Refer to p. 5-4-17 for the sensor location. Possible to judge if speed sensor is faulty by switching pressure sensor with other speed sensor.
Descriptions of Control (Refer to F&S S/M)	T2-2

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

Trouble Symptom	E-4	E-5
Parts	Power mode is not shifted when pushing power mode switch.	Even if key switch is turned OFF, engine does not stop.
MC	○	○
ECM		●
TCU		
Information Controller	○	
Monitor	○	
Column Display Controller		
MPDr.	○	
Key Switch		●
Accelerator Pedal Sensor		
Power Mode Switch	●	
Forward/Reverse Lever		
Forward/Reverse Selector Switch (Option)		
Forward/Reverse Switch (Option)		
Battery		
Battery Relay		○
Fuse Box A		
Fuse Box B		
Neutral Relay		
Load Dump 2 Relay		○
Starter Relay 1		
ECM Main Relay		○
Fuel Pump Relay		
Starter		
Engine Unit		
Coolant Temperature Sensor		
Glow Plug Relay		
Glow Plug		
Pump Delivery Pressure Sensor		
Remark		

●: Check required ○: Related

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

Trouble Symptom	S-4
Parts	Secondary steering (option) is not operated. (Check automatic operation when the engine starts)
MC	●
TCU	
Information Controller	
Monitor	
MPDr.	● (Setting: ON)
Battery	
Fuse Box A	○ (#20)
Secondary Steering Relay (Option)	●
Machine Speed Sensor	○
Pilot Pump	
Brake Charge Valve	
Manifold Valve	
Steering Pressure Switch (Option)	●
Secondary Steering Pump Delivery Pressure Sensor (Option)	○
Steering Cylinder (Left, Right)	
Steering Accumulator	
Main Pump	
Secondary Steering Motor (Option)	○
Secondary Steering Pump (Option)	○
Remark	

●: Check required ○: Related

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

Trouble Symptom	O-10 Wiper is not operated.	O-11 Washer is not operated.	O-12 Cab light is not ON.
Parts			
MC			
Information Controller			
Column Display Controller	●		
Key Switch	○ (ON)	○ (ON)	
Battery			○
Fuse Box A			
Fuse Box B	● (#3, #5)*1	● (#3, #5)*1	● (#11)
Front Wiper/ Washer Switch	●	●	
Rear Wiper/ Washer Switch	●	●	
Cab Light Switch			●
Rear Cab Light Switch			●
Door Open/Close Switch (Cab)			●
Front Wiper Relay 1	●		
Front Wiper Relay 2	● (Fast Speed)		
Rear Wiper Relay	●		
Front Washer Relay		●	
Rear Washer Relay		●	
Front Wiper Motor	●		
Rear Wiper Motor	●		
Front Washer Motor		●	
Rear Washer Motor		●	
Remark			

●: Check required ○: Related

 NOTE: *1) Fuse #3: Front Wiper, Fuse #5: Rear Wiper

SECTION 5 TROUBLESHOOTING


Group 6 Troubleshooting B

A-5 Fan speed does not change.

Preparation

- The sensors detect the conditions necessary to operate fan speed control. Therefore, if these sensors fails, fan speed control becomes ineffective.
- Accelerator pedal sensor, coolant temperature sensor, boost temperature sensor, hydraulic oil temperature sensor, torque converter oil temperature sensor, and pressure sensor (refrigerant pressure) are also engaged in the fan speed control. However, if these sensors fail, other operating functions will be also affected.
- Refer to SYSTEM/Control System/Fan Reverse Rotation Control.

Procedure	Inspection Method	Condition	Evaluation	Cause
1	Monitor Target Hydraulic Fan Speed	Engine: Running	Fan speed does not change according to accelerator pedal depressing amount	Faulty ECM, TCU, or MC
2	Monitor Hydraulic Fan Circuit Pressure	Engine: Running	Fan pump delivery pressure does not change according to accelerator pedal depressing amount	Faulty fan pump
3	Disassemble and inspect the fan speed control solenoid valve	-	There is abnormality	Faulty fan speed control solenoid valve
4	Disassemble and inspect the fan control valve	-	There is abnormality	Faulty fan control valve
5	-	-	The check mentioned above is normal	Faulty fan motor

 **NOTE:** The fan pump is mounted to the engine (see p.T5-4-14). Refer to p.T5-4-13 and T5-4-16 for the fan system components.

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

F-8 Lift arm auto leveler lower kickout control (Optional) is not activated.


Preparation

- Refer to SYSTEM/Control System/Lift Arm Auto Leveler Lower Kickout Control.
- Check the wiring connections first.
- Check #16 fuse in fuse box A.


Procedure	Inspection Method	Condition	Evaluation	Cause
1	Measure voltage between pilot valve lift arm lower side coil harness end #081D and body	Key switch: ON	0 V	Open circuit in wire harness between #16 fuse in fuse box A and pilot valve lift arm lower side coil
2	Check continuity between pilot valve lift arm lower side coil harness end #536 and body	Lift arm lower, detent control lever operation	0 Ω	Faulty ground in pilot valve lift arm lower side coil
3	Monitor Lift Arm Auto Leveler Switch (lower)	Lift arm auto leveler switch (lower): ON	OFF is displayed	Faulty lift arm auto leveler switch (lower)
4	-	-	The check mentioned above is normal	Faulty pilot valve lift arm lower side coil

Connector (Wire harness end)

- Pilot Valve (Fingertip Control Lever Type) Dual Auto Leveler (Optional)
- Pilot Valve (Multi-Function Joystick Lever Type) Dual Auto Leveler (Optional)



TNDJ-05-06-003



T8UC-05-04-004

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

T-4 Travel mode can not be shifted.

Preparation

- Check the wiring connections first.

Procedure	Inspection Method	Condition	Evaluation	Cause
1	Monitor Travel Mode Selector Switch	Travel mode selector switch: AUTO 1/AUTO 2 mode	Manual mode is always displayed (0 is displayed on the monitor)	Faulty travel mode selector switch, or open circuit in wire harness between travel mode selector switch and MC
2	-	-	The check mentioned above is normal	Faulty MC

SECTION 5 TROUBLESHOOTING
Group 6 Troubleshooting B

(Blank)

SECTION 5 TROUBLESHOOTING

Group 6 Troubleshooting B

O-10 Wiper is not operated.

Preparation

- The wiper is driven by electric power routed via the relay circuit. The relay circuit of front wiper is controlled by the column display controller.
- In case the front washer is also not operated, check #3 fuse in fuse box B. In case the rear washer is also not operated, check #5 fuse in fuse box B.
- In case the wiper is not operated, first check if the wiper relay is activated. Next, check if electric power is routed to the wiper motor.
- Refer to SYSTEM/Electrical System.
- Check the wiring connections first.

• Front Wiper

Procedure	Inspection Method	Condition	Evaluation	Cause
1	Monitor Front Wiper Relay 1 Output	Key switch: ON Front wiper/ washer switch: LOW	OFF is displayed	Faulty column display controller
2	Monitor Front Wiper Relay 2 Output	Key switch: ON Front wiper/ washer switch: HIGH	OFF is displayed	Faulty column display controller
3	Monitor Front Wiper Switch	Key switch: ON Front wiper/ washer switch: LOW/HIGH	The position of front wiper/washer switch is not identical to the display of monitoring	Faulty front wiper/washer switch, or open circuit in wire harness between front wiper/washer switch and column display controller, or open circuit in harness between front wiper relay 1/2 and column display controller
4	Switch front wiper relay 1/2 with other general relay	Key switch: ON Front wiper/ washer switch: LOW/HIGH	Wiper is operated	Faulty front wiper relay 1/2
5	-	-	The check mentioned above is normal	Faulty front wiper motor

Connector (Wire harness end)

- Front Wiper Relay 1
- Front Wiper Relay 2




T183-05-04-003


SECTION 5 TROUBLESHOOTING

Group 7 Air Conditioner

Component Layout



TNDF-05-07-001



TNEJ-05-07-001

- | | | | |
|---------------------------|---|--|-------------------|
| a- Engine | b- To Radiator (Lower) | | |
| 1- Solar Radiation Sensor | 9- Fresh Air Filter | 11- Outdoor Ambient Temperature Sensor | 14- Receiver Tank |
| 5- Accelerator Pedal | 10- Air Conditioner Controller (Switch Panel) | 12- High/Low Pressure Switch | 27- Compressor |
| 6- Key Switch | | 13- Air Conditioner Condenser | 28- V Belt (A/C) |
| 8- Air Conditioner Unit | | | 29- Pulley (A/C) |

SECTION 5 TROUBLESHOOTING

Group 7 Air Conditioner

Air Conditioner Controller Fault Code List

Fault Code	Trouble	Cause	Symptoms in Machine Operation When Trouble Occurs.	Remedy
E11	Open circuit in re-circulated air sensor	Voltage: more than 4.95 V	Operation is controlled under such circumstance as no re-circulated air sensor is provided.	Check the harness. Replace the re-circulated air sensor.
E12	Shorted circuit in re-circulated air sensor	Voltage: less than 0.3 V	Operation is controlled under such circumstance as no re-circulated air sensor is provided.	Check the harness. Replace the re-circulated air sensor.
E13	Open circuit in outdoor ambient temperature sensor	Voltage: more than 4.88 V	Operation is controlled under such circumstance as no outdoor ambient temperature sensor is provided.	Check the harness. Replace the outdoor ambient temperature sensor.
E14	Shorted circuit in outdoor ambient temperature sensor	Voltage: less than 0.096 V	Operation is controlled under such circumstance as no outdoor ambient temperature sensor is provided.	Check the harness. Replace the outdoor ambient temperature sensor.
E18	Shorted circuit in solar radiation sensor	Voltage: more than 5.04 V	Operation is controlled under such circumstance as no solar radiation sensor is provided.	Check the harness. Replace the solar radiation sensor.
E21	Open circuit in frost sensor	Voltage: more than 4.79 V	The compressor clutch is disengaged. (The compressor stops.)	Check the harness. Replace the frost sensor.
E22	Shorted circuit in frost sensor	Voltage: less than 0.096 V	The compressor clutch is disengaged. (The compressor stops.)	Check the harness. Replace the frost sensor.
E43	Abnormal air vent damper servo motor	Shorted circuit: Voltage: 0 V Open circuit: Voltage: more than 5 V	Air vent damper servo motor becomes inoperable.	Check the harness. Replace the air vent damper servo motor.
E44	Abnormal air mix damper servo motor	Shorted circuit: Voltage: less than 0.2 V Open circuit: Voltage: more than 4.8 V	Air mix damper servo motor becomes inoperable.	Check the harness. Replace the air vent damper servo motor.
E51	Abnormal high/low refrigerant pressure	Voltage: 0 V	The compressor clutch is disengaged. (The compressor stops.)	Check the harness. Replace the high/low pressure switch.
E91	CAN communication error	Faulty CAN1 harness between monitor controller and air conditioner controller	Air conditioner stops.	Check the CAN1 harness. Replace air conditioner controller.
E92	CAN bus off error	Faulty air conditioner controller Faulty CAN1 harness	Air conditioner stops.	Check the CAN1 harness. Replace air conditioner controller.

SECTION 5 TROUBLESHOOTING

Group 7 Air Conditioner

Faulty cooling (5)

Condition:

- Fault Code: 44 (Abnormal air mix damper servo motor)

Faulty wiring, open circuit, disconnection of connector	Wirings inspection
Faulty servo motor	Replace
Clogged foreign matter	Remove foreign matter

Condition:

- Fault Code: 51 (Abnormal high/low refrigerant pressure)

High pressure cut is operated	Abnormally high ambient temperature		
	Lack of condenser cooling	Clogged fin with dirt or mud	Cleaning of fin (washing)
	Overcharge air conditioner with refrigerant	Remove refrigerant thoroughly and recharge refrigerant to proper level after purging	
	Air incorporation in refrigeration cycle	Remove refrigerant thoroughly and recharge refrigerant to proper level after purging	
Low pressure cut is operated	Abnormally low ambient temperature		
	Low refrigerant	Low refrigerant quantity	Charge refrigerant to proper level
		Gas leak	Check leak and charge with refrigerant after repairing faulty
	Faulty compressor	Swash plate shoe is locked	Replace compressor
		Piston is locked	Replace compressor
		Faulty suction discharge valve	Replace compressor
	Faulty expansion valve	Clogged valve (foreign matter)	Replace valve
		Temporary clogged due to freezing valve (water intrusion)	Thoroughly perform purging after replacing valve and receiver

SECTION 5 TROUBLESHOOTING

Group 7 Air Conditioner


Cooling circuit check by using manifold gauge


Condition:

- Engine Speed: 1500 min⁻¹
- Cab Window: Fully Open
- Air Conditioner: ON
- Airflow volume: Maximum
- Temperature Control Switch: Maximum cool
- Fresh / re-circulated air selection: Re-circulated Air
- Air conditioner inlet temperature: 30 to 35 °C

1. In normal

- Low-pressure side pressure: 0.15 to 0.25 MPa
- High-pressure side pressure: 1.37 to 1.57 MPa


 **NOTE:** The reading of manifold gauge may depend on conditions.



TDAA-05-07-018

2. Lack of refrigerant quantity


Trouble	Pressure is low on both sides of high-pressure and low-pressure. Cooling performance is low.
Cause	Refrigerant quantity is low. Gas leak.
Remedy	Check and repair of gas leak. Charge air conditioner with refrigerant.



TDAA-05-07-019

3. Excessive refrigerant, lack of condenser cooling


Trouble	Pressure is high on both sides of high-pressure and low-pressure. Cooling performance is low.
Cause	Overcharge air conditioner with refrigerant. Faulty condenser cooling.
Remedy	Adjust refrigerant quantity. Clean condenser. Check for machine cooling system.



TDAA-05-07-020

4. Water incorporation in circuit.

Trouble	After using a certain period of time, low-pressure side gradually indicates negative pressure.
Cause	Water is mixed in circuit.
Remedy	Replace receiver tank. Thoroughly perform purging before charging refrigerant to remove water.



TDAA-05-07-021

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL