



Technical Manual

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TRAINING

Qualified maintenance personnel using a scheduled maintenance program are the best way to minimize machine downtime and maximize productivity of equipment.

Marion offers factory and mine site maintenance seminars and special familiarization programs for mechanics, oilers, electricians and operators on a fee basis.

These programs are presented by qualified factory specialists and service technicians. Special customized training programs can also be developed to meet specific mine requirements.

Objectives of training and training materials are to provide the means for developing and maintaining on-site service repair capability.

For further information about Marion service training capabilities and programs contact:

Training Supervisor
Marion Division of INDRESCO Inc.
617 West Center St.
P.O.Box 505
Marion, OH 43302



PROTOCOL:

1. Turn the CPU selector switches to the STOP and WRITE positions. Put the Workmaster (W/M) in the OFF LINE MODE.
2. Clear the Workmaster (W/M) memory. The surest way to do this is to turn the W/M off and reboot the Logicmaster system. Another way is to select the F6 L/S/V Function Key from the Supervisor Menu and use the F5 CLEAR Function Key.
3. From the Supervisor Menu, select the SCRATCH PAD display and set the correct parameters to match the CPU ID number, installed memory size and Register memory size. (Use the SELECT key to get to the numeric or bottom field in the lower right of the display screen.) See example below.
4. Use 01 for CPU ID default, if not otherwise identified. Logic and register memory size must be correct, else the installation of the "blank" program may clear only part of the memory.
5. Select the F6 L/S/V Function Key from the Supervisor Menu and implement the standard STORE procedure.
7. Return to the Supervisor Menu, select F6 L/S/V Function Key from the Supervisor Menu and implement the standard STORE procedure for the desired real program.
8. Following storage of the operating program, return to the SCRATCH PAD display. Turn the CPU switches to RUN and PROTECT. Depress the ENABLE function key when prepared to power up the operating system.

SCRATCH PAD DISPLAY EXAMPLE:

CPU ID NUMBER:	1	WORDS USED:	18
MEMORY SIZE:	16K	WORDS AVAILABLE:	16,366
SUBROUTINES USED:	00	REGISTERS:	8,192
FUNCTIONS:	XPANDED		

NOVA COAL DRAG TEM LAYOUT

LEGEND

NORMALLY OFF, ON = FAULT

NORMALLY ON, OFF = FAULT

UNUSED, MAY BE ON OR OFF

NORMALLY ON, INDICATOR


NORMALLY OFF, INDICATOR

TEST POINT

POTENTIOMETER

SWITCH

NOTES:
-SHADED AREA REPRESENTS DAUGHTER BOARD
-FOR UNLABELED LIGHTS, CONSULT ELEMENTARY



JE
10

JD
10

JC
26

JB
26

JF
26

JK
34

JJ
34

JH
20

JG
20

JA
PWR SPY.

ROW
1

	F	E	D	C	B	A
LOOP1 O/C				TP1	TP1	TP1
LOOP2 O/C		RH1	3RD LP2 ARM O/C TRIP (-)	TP2 GFEX SCRDR	TP2 FWD CUR LIM	TP2 LP1 GND DET VOLT
GEN FLD O/C		RH2	3RC LP2 ARM O/C TRIP (+)	TP3	TP3	TP3
MTR FLD FLT			3RB ARM CUR UNBAL (-)	TP4	TP4 REV CUR LIM	TP4 LP1 VFB
		RH3	3RA ARM CUR UNBAL (+)	TP5	TP5	TP5
TIMED LOOP UNBAL			2RD REG PROV LEV DETECT	TP6	TP6	TP6 LP2 GND DET VOLT
ARM 1 ISO FLT		RH4	2RC REG PROV LEV DETECT	TP7	TP7	TP7
ARM 2 ISO FLT		RH5	2RB LP1 ARM O/C TRIP (-)	TP8 TOTAL GND VOLTS	TP8	TP8 LP2 VFB
HORN			2RA LP1 ARM O/C TRIP (+)	TP9	TP9	TP9
TP1		RH6	1RD FCL LOSS DETECT	TP10 ARM UNBAL CUR	TP10 X BUFFER OUT	TP10
TP2 LOOP UNBAL			1RC RCL LOSS DETECT	TP11	TP11	TP11
TP3 ARM1 ISO FLT			1RB	TP12 Y BUFFER OUT	TP12	TP12
TP4 ARM2 ISO FLT		RH7	1RA LOOP GND CALIB	TP13	TP13	TP13
TP5 LOOP1 O/C				RH1	RH1	RH1
TP6				RH2	RH2	RH2
TP7 MTR FLD FLT				RH3	RH3	RH3 LP1 VFB SCALING
TP8 GEN FLD O/C		RH8		RH4	RH4	RH4 LP2 VFB SCALING
TP9 LOOP2 O/C				RH5	RH5 CUR REG GAIN	RH5 VOLT REG GAIN
TP10				RH6	RH6	RH6
TP11 OPBSIL				IMOK	IMOK	IMOK
TP12 OPBACK						
TP13 OPBCR						
TP14 PBLT						
TP15 OPBLT						
NFMD	NCBA	NSWA	NOAA	NOAA	NOAA	NOAA

EVENT CODE TABLE

<u>EVENT CODE #</u>	<u>DESCRIPTION</u>
95	SYNC. MOTOR STATOR OVERTEMPERATURE
96	DRAGLINE CENTER JOURNAL OVERTEMPERATURE
97	HOUSE AMBIENT OVERTEMPERATURE
98	POWER CONTROL ROOM OVERTEMPERATURE
99	PROPEL LEFT OUTBOARD BEARING O'TEMP.
100	PROPEL LEFT INBOARD BEARING O'TEMP.
101	SWING LOWER BEARING #1 OVERTEMPERATURE
102	HOIST DRUM SHAFT LEFT OVERTEMPERATURE
103	DRAG DRUM SHAFT LEFT OVERTEMPERATURE
104	-RTD SPARE-

PAGE NUMBER : 11

ACTIVE EVENTS	ENABLE EVENT	DISABLE EVENT			GOTO PAGE #	PREV. PAGE	NEXT PAGE	HELP	MAIN MENU
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

1. Screen Description: Page 11 of the Event Code Table.
2. Screen accessed by F6, F7 or F8 Key of Event Code Table.
3. Function Keys Description:
 - F1 Returns to Active Events Screen.
 - F2 Enables a specified Event.
 - F3 Disables a specified Event
 - F6 Displays a specified Page of the Event Code Table.
 - F7 Displays Previous Page of the Event Code Table.
 - F8 Displays Next Page of the Event Code Table.
 - F9 Displays Event Code Table Help Screens.
 - F10 Returns to Main Screen.

PROPEL DRIVE SETUP

DESCRIPTION (UNITS)		CURRENT SETPOINT	TYPICAL SETTING	ALLOWABLE	
				MIN.SETPT	MAX.SETPT
1 AMPS AT PEAK POWER	(AMPS)	2088	2088	0	2480
2 AMPS AT FORWARD STALL	(AMPS)	3960	3960	SP#1	4000
3 AMPS AT REVERSE STALL	(AMPS)	-3960	-3960	-4000	-SP#1
4 MAX FORWARD REFERENCE (Q1)	(VOLTS)	8.00	8.00	1.00	8.00
5 MAX REVERSE REFERENCE (Q3)	(VOLTS)	-7.25	-7.27	-1.00	-7.27
6 ANGLE FOR TUB LOWERING	(DEGREES)	210	210	180	250
7 ANGLE FOR SHOE LOWERING	(DEGREES)	80	80	60	120
8 ANGLE FOR SHOE RAISING	(DEGREES)	270	270	250	310

SETUP MENU	SELECT SETPT.								MAIN MENU
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

1. Screen Description: Propel Drive Setup - view and change setpoints for Propel Drive.
2. Screen accessed from Parameter Setup menu by F4 Key.
3. Function Key Description:
 - F1 Returns to Parameter Setup Menu.
 - F2 Selects a parameter to change and then enter a new setpoint for that parameter.
 - F10 Returns to Main Menu.

SWING DRIVE MONITOR

<u>DESCRIPTION (UNITS)</u>	<u>CURRENT VALUE</u>	<u>ANALOG CARD #</u>	<u>CHANNEL#</u>	<u>SCALED VALUES</u>
SWING MASTERSWITCH	(VOLTS) 0.00	GENIUS	R-7027	8V = 1638CNT
SWING VOLTAGE FEEDBACK	(VOLTS) 0.7	I-801	8	8V = 600V
SWING CURRENT FEEDBACK	(AMPS) 1	I-833	4	8V = 2130A
SWING CURRENT REFERENCE	(AMPS) 0	0-897	3	8V = 2130A
SWING VOLTAGE REFERENCE	(VOLTS) 600.0	0-929	3	8V = 600A

MONIT. MENU									MAIN MENU
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

1. Screen Description: Swing Drive Monitor.
2. Screen accessed from Analog Monitor Menu.
3. Function Key Description:
 - F1 Returns to Analog Monitor Menu.
 - F10 Returns to Main Menu.

SWING GEN. FLD. DB CONTACT 0-004

SWING BRAKE RELEASE SEL.SW.	I-134	SOFTWARE LINE EXCITATION	O3-049
DRIVE RESET P.B.	I-005	SWING AC CONT INTERLOCK	I-164
SWING MASTERSW. NEUTRAL	O2-889	BOOM RAISE/LOWER MODE	AO-911
SWING GEN. FLD. CONTACTOR	I-047	SWING GEN. FLD FUSE LOSS	I-031
SWING AC CONTACTOR AUX.	O0-653	SWING FAULT TIMER	O0-664
SOFT START SALE AUX.	O0-322	M/G SET RUNNING	O3-055

SBREL	DRSETPB	SNEUTRL	LEX	SGFCX	SFTMR	SALEAUX	BRLMODE	SDB
I-134	I-005	O2-889	O3-049	I-047	O0-664	O0-653	AO-911	O-004
-] [---] / [-----] [---] [---] [---] / [-----] [---] [---] / [-----] ()								
SALEX	SGFFLSS							
I-164	I-031							
-] [---] [-----]								
SALE2	MGRUN							
O0-322	O3-055							
-] [---] / [-----]								

LE/DB MENU							NEXT SCREEN		MAIN MENU
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

1. Screen Description: Monitor Swing Generator Field DB Contact.
2. Screen accessed from LE/DB Directory by F4 Key or from 2nd Swing DB Diagnostics Screen by F8 key.
3. Function Key Description:
 - F1 Returns to LE/DB Menu.
 - F8 Display Next Screen of Swing DB Diagnostics.
 - F10 Returns to Main menu.

EVENT CODE TABLE

EVENT CODE #	DESCRIPTION	PAGES
001-038	MECHANICAL/STRUCTURAL MONITORS	2-5
045-104	TEMPERATURE MONITORS	6-11
120-136	AC POWER DISTRIBUTION SYSTEM	12-13
140-146	AC POWER UTILIZATION APPARATUS	14
170-246	DC POWER SYSTEMS	15-22
250-252	ANTI-TIGHTLINE AND PROPEL SYNCHRONIZATION	23
260-291	LOGIC AND CONTROL SYSTEMS	24-27
295-302	SOFT START MONITORS	28

ALL EVENTS THAT ARE HIGHLIGHTED IN YELLOW ARE DISABLED AT THE PRESENT TIME

PAGE NUMBER : 1

ACTIVE EVENTS	ENABLE EVENT	DISABLE EVENT			GOTO PAGE#	PREV. PAGE	NEXT PAGE	HELP	MAIN MENU
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10

1. Screen Description: Event Code Table (Table of Contents) - List all possible Events that can be logged.
2. Screen accessed from Active Events Screen by F2 Key.
3. Function Key Description:
 - F1 Returns to Active Events Screen.
 - F2 Enables a specified Event.
 - F3 Disables a specified Event
 - F6 Displays a specified Page of the Event Code Table.
 - F7 Displays Previous Page of the Event Code Table.
 - F8 Displays Next Page of the Event Code Table.
 - F9 Displays Event Code Table Help Screens.
 - F10 Returns to Main Screen.

<< RUNG 32 >>

Drag
DB Cont
Int'lck
DDBX
10040

Drag Cross reference for 00798
Suicide
Relay
DRGSUI
00798

+--]/[+-----

MG Set
Start
Latch
MGSLAT
03-0050

+--] [---+

<< RUNG 33 >>

Swing
Gen.Fld
DB Cont
SDB
00004

Swing Cross reference for 00799
Suicide
Relay
SWGSUI
00799

+--]/[-----

<< RUNG 58 >>

```

.....
.
.   The next four rungs control the operator's Limit Bypass light and
.   Limit buzzer.
.
.....

```

First	Limit	Cross reference for 02- 0901
Hoist	Buzzer	
Limit	Moment.	
HL 1	LIMBUZ1	
00-0747	02-0901	
---] [---	()	

```

314
Lower
Ref'nce
Zeroed
LLZREF
00-0745

```

```

---] [---
311
First
Drag In
Limit
DL 1
00-0754

```

```

---] [---
344
Pay Out
Ref'nce
Zeroed
POZREF
00-0765

```

```

---] [---
341
Static
Tight-
lineTrp
STLT
00-0759

```

```

---] [---
363

```

<< RUNG 94 >>

.....
. The next 2 rungs are used to load the present state of the discrete
. I/O into Registers R2372 - R2374.
.....

HstLoop	DISC'TE		DISC'TE	
Inst.	I/O		I/O	
OvrCurr	737-752		753-768	
HLPIOC	DISC#1		DISC#2	
10737	R02372	I0753	R02373	
+ [A	MOVE	B] - [A	MOVE	B] - ()

<< RUNG 95 >>

Disc'te	DISC'TE	Hoist	DISC'TE	
I/O	I/O	Mot.Fld	I/O	
785	785-800	Bit 1	49 - 64	
DISC1/O	DISC#3	HMFBIT1	DISC#4	
00785	R02374	00049	R02375	
+ [A	MOVE	B] - [A	MOVE	B] - ()
		513		

<< RUNG 96 >>

Hoist	Hoist	Drag	Drag	
Encoder	Encoder	Encoder	Encoder	
Reading	Reading	Reading	Reading	
HENC	HENC X	DENC	DENC X	
R00951	R02362	R00952	R02363	
+ [A	MOVE	B] - [A	MOVE	B] - ()

<< RUNG 97 >>

.....
. The next rung performs the actual movement of data.
.....

```
GLOBAL
COMMAND
BLOCK
GLBL1-2
R0832
+ [DPREQ]- ( )
```

<< RUNG 98 >>

```
*****
*
*           END SUBROUTINE NUMBER 1
*
*****
```

+ [Return]-

```

<< RUNG 153 >>
*****
*
*           BEGIN SUBROUTINE NUMBER 3
*
*           Analog Input
*
*
*   Each of the three Analog Input Modules provide 8 inputs. The inputs are
*   multiplexed and thus only one input from each Module would normally be
*   read in each scan. In order to obtain more frequent updates, this Sub-
*   routine is repeated 8 times in each scan.
*
*   In the first of the following rungs, the Do I/O function is used to
*   read the inputs to Module No. 1 immediately. The first 8 bits of the
*   input, which contain the channel number, are separated from the second 8
*   bits, which contain the status code, and moved to R2876 to serve as the
*   pointer to the table of analog inputs, R2877-R2900.
*
*   If the status bits indicate that there are no faults the input value is
*   moved to the table.
*
*   The Analog Input Modules are analog to digital converters; the scaling
*   is from plus or minus 10 volts to plus or minus 2048 "counts". The next
*   Subroutine is used to convert from "counts" to engineering units.
*
*****

+ [NO OP]- ( )

<< RUNG 154 >>
                An. In      Analog
                Mod. 1      Input
                Chan.No     Pointer
                ANIN1CH     ANINPTR
                Const      Const  I0801      R02876
+ [ DO I/O START END ]-[ MOVE RIGHT 8 BITS ]- ( )
                00801      00832

<< RUNG 155 >>
An.In 1 An.In 1 An. In  Analog
Data   Board Mod. 1  Input
Valid  OK      Data  Pointer
ANIN1DV ANIN1BK ANIN1D ANINPTR
I0809   I0813   I0817 R02876 Const
+---] [-----] [---[ SRC-TO-TABLE  LEN]- ( )
                        024

<< RUNG 156 >>
                An. In      Analog
                Mod. 2      Input
                Chan.No     Pointer
                ANIN2CH     ANINPTR
                Const      Const  I0833      R02876
+ [ DO I/O START END ]-[ MOVE RIGHT 8 BITS ]- ( )
                00833      00864
    
```

```

<< RUNG 207 >>

Analog          Analog
Output3         Output
Chnn101        Mod. 3
ANO3CH1        ANOUT3
R02839         00929
+[ A MOVE B ]-      ( )

<< RUNG 208 >>

Never          Analog      Cross reference for 00909
Ener-         Output1
gized         Bit 1      ] [ 210, 212, 219, 221, 228, 23
EVEROFF      ANO1B1    ( ) 217, 226, 235
00-0254     00909

+ ] [----- ( )
19

<< RUNG 209 >>

Never          Analog      Cross reference for 00910
Ener-         Output1
gized         Bit 2      ] [ 211, 213, 220, 222, 229, 23
EVEROFF      ANO1B2    ( ) 218, 227, 236
00-0254     00910

+ ] [----- ( )
19

<< RUNG 210 >>

Analog          Analog      Cross reference for 00925
Output1        Output2
Bit 1         Bit 1      ( ) 219, 228, 237
ANO1B1        ANO2B1
00909        00925

+ ] [----- ( )
208

<< RUNG 211 >>

Analog          Analog      Cross reference for 00926
Output1        Output2
Bit 2         Bit 2      ( ) 220, 229, 238
ANO1B2        ANO2B2
00910        00926

+ ] [----- ( )
209

<< RUNG 212 >>

Analog          Analog      Cross reference for 00941
Output1        Output3
Bit 1         Bit 1      ( ) 221, 230, 239
ANO1B1        ANO3B1
00909        00941

+ ] [----- ( )
208

<< RUNG 213 >>

Analog          Analog      Cross reference for 00942
Output1        Output3
Bit 2         Bit 2      ( ) 222, 231, 240
ANO1B2        ANO3B2
00910        00942

+ ] [----- ( )
209
    
```

```

<< RUNG 256 >>

Drag Calib. Permit          Calib. Cross reference for 02- 0900
Encoder Flasher Rope       Signal
Zero PB No. 1 Calib.       Control
DRZPB CALFL1 CALPER       CALSIG
10142 00-0231 00-0230     02-0900
+--] [---] [---] [---] [---] ( )
      247      246
Hoist Rope
Encoder Calib.
Zero PB Timer
HRZPB CALTMR
10141 00-0233
+--] [---] [---] [---]
      249

<< RUNG 257 >>

*****
*
*
*           END SUBROUTINE NUMBER 6
*
*
*****

+[ Return ]-

```

```

<< RUNG 293 >>
                                                                    Fifty Cross reference for 00- 0742
                                                                    Scan
                                                                    Timer
                                                                    TIMER
                                                                    Const 00-0742
-----[PRESC]---(TH)
                                                                    999 ( )
Fifty Scan 50 Scan ( )
Counter Timer ( )
SCNCNT Accum ( )
01021 TIME 50 ( )
                                                                    R01092 ( )
-----[ACCRG]---( R)
  291

<< RUNG 294 >>
Hoist          Hoist
Length         Length
M *100         Stk Ptr
HLEN*C        HLENPTR
R02376        R02751 Const
+[ SRC ADD-TO-TOP LIST LEN]- ( )
                                020

<< RUNG 295 >>
                                                                    Hoist
                                                                    Length
                                                                    Stk Ptr
                                                                    HLENPTR
Const          R02751
+[ A MOVE B ]- ( )
+00019

<< RUNG 296 >>
Hoist Prev SglPrec
Length Hoist Working
M *100 Length Reg'ter
HLEN*C PHLEN SPWR 1
R02376 R02771 R01036
+[ A SUBX B = C ]- ( )

<< RUNG 297 >>
SglPrec Average SglPrec
Working Hoist Working
Reg'ter Change Reg'ter
SPWR 1 AVHSTCH SPWR 1
R01036 R01107 R01036
+[ A ADDX B = C ]- ( )

<< RUNG 298 >>
SglPrec          DblPrec          DblPrec          Average SglPrec
Working          Working          Working          Hoist Working
Reg'ter          Reg'ter          Reg'ter          Change Reg'ter
SPWR 1          DPWR 1L          DPWR 1L          AVHSTCH SPWR 3
R01036 Const R01038          R01038          Const R01107 R01075
+[ A MPY B = C ]-[ A DVD B QUO REM ]- ( )
                                +00002
  +00001

```

```

*
* << RUNG 344 >>
*
* .....
* . This rung checks if the drag-in zero reference point has been reached. .
* .
* .....
*
* Drag   First SglPrec General      Limited RopeLim Limit      First Cross reference for 00- 0754
*Length DragLim Working Purpose    Drag Bypass Overrde    Drag In
*M *100 Set Pt. Reg'ter Reg'ter    Ref'nce PB Lat Relay   Limit ] [ 58, 587
*DLEN*C SP 802 SPWR 2 CONST=0      LIMDREF RLBPLAT LIMO'RD DL 1
* R02378 R03662 R01037 R00900      R00865 00-0735 00-0733 00-0754
+[ A SUBX B = C ]-[ A MOVE B ]---]/[-----]/[-----] ( )
*                                     54 7
*
* << RUNG 345 >>
*
* .....
* . This section checks if the drag-in trip limit has been exceeded for .
* . more than 0.05 seconds and shuts down the drive accordingly. .
* .
* .....
*
* Drag   Final SglPrec              DrgTrip Cross reference for 00- 0755
*Length DragLim Working            Limit
*M *100 Set Pt. Reg'ter            Aux'ary ] [ 346
*DLEN*C SP 803 SPWR 2              DLX 2 ]/[ 346
* R02378 R03663 R01037              00-0755
+[ A SUBX B = C ]-----] ( )
*
* << RUNG 346 >>
*
* DrgTrip Final Cross reference for 00- 0756
* Limit Drag
*Aux'ary Limit ] [ 54, 59, 61, 348
* DLX 2 DL 2 ]/[ 50
*00-0755 Const 00-0756
+--] [-----] [PRESC]---(TH)
* 345 005 ( )
*DrgTrip Drag ( )
* Limit Limit 2 ( )
*Aux'ary AccTime ( )
* DLX 2 DL2TIME ( )
*00-0755 R01096 ( )
+--]/[-----] [ACCRG]---( R)
* 345
|
| << RUNG 347 >>
|
|
|
+ [NO OP]- ( )
|

```

<< RUNG 391 >>

```

*****
*
*                               SUBROUTINE NUMBER 9
*
*                               DRIVE CONTROL
*
*
*
*****

```

+ [NO OP] -

()

<< RUNG 392 >>

```

.....
.
.   The next 19 rungs are used to sense the quadrant in which each of the
.   drives (hoist, drag, swing and flywheel) is operating. Voltage and current
.   polarities are detected. Both are positive for quadrant 1 and both are
.   negative for quadrant 3. Voltage is positive and current is negative in
.   quadrant 2 while the opposites exist in quadrant 4.
.
.....

```

+ [NO OP] -

()

<< RUNG 393 >>

Hoist	Value	Hoist	Cross reference for 00- 0115
Arm.	Not	Gen.Vlt	
V. x 10	Req'd	Positiv] [395, 396
HVFBVLT	NOTREQD	HVFBPOS] / [397, 398
Const R02341	R00769	00-0115	

+ [A SUBX B = C] ----- ()

+00000

<< RUNG 394 >>

Hoist	Value	Hoist	Cross reference for 00- 0116
Arm.	Not	Arm.Cur	
Amps.	Req'd	Positiv] [395, 398
HCFBAMP	NOTREQD	HCFBPOS] / [396, 397
Const R02344	R00769	00-0116	

+ [A SUBX B = C] ----- ()

+00000

<< RUNG 395 >>

Hoist	Hoist	Hoist	Cross reference for 00- 0111
Gen.Vlt	Arm.Cur	Quad-	
Positiv	Positiv	rant 1] [499, 510
HVFBPOS	HCFBPOS	H QUAD1	
00-0115	00-0116	00-0111	

+ -] [- - -] [- - -] ----- ()

| 393 394

```

*
* << RUNG 441 >>
*
* .....
* . The next 4 rungs limit the reference to the values preset through the .
* . OIT. .
* . .
* .....
*

```

```

* Hoist      SglPrec
* Max.      Working
*Ref'nce    Reg'ter
*HMXREF     SPWR
* R03532    R00799
+[ A MOVE B ]- ( )
*

```

```

* << RUNG 442 >>
*
* Hoist SglPrec DblPrec      DblPrec      Hoist Value
*Mast.Sw Working Working      Working      Mast.Sw Not
*Shaped Reg'ter Reg'ter      Reg'ter      Shaped Req'd
*HMSSHPD SPWR DPWR1          DPWR1          HMSSHPD NOTREQD
* R00802 R00799 R00800      R00800          Const R00802 R00769
+[ A MPY B = C ]-[ A DVD B QUO REM ]- ( )
*                                +00800
*

```

```

* << RUNG 443 >>
*
*SglPrec Hoist Value SglPrec      Hoist      Skip      Cross reference for 00- 0751
*Working Mast.Sw Not Working      Mast.Sw      Delim-
*Reg'ter Shaped Req'd Reg'ter      Shaped      iter      ( ) 83, 322, 352, 379, 447, 474
* SPWR HMSSHPD NOTREQD SPWR          HMSSHPD      ENDSKIP      555, 582, 586, 591, 608, 71
* R00799 R00802 R00769 R00799      R00802      00-0751
+[ A SUBX B = C ]-[ A MOVE B ]----- ( )
*

```

```

* << RUNG 444 >>
*
*Multi-
*Purpose
* Relay
* MPR1
*00-0100 Const
+--]/[---[SKIP ]- ( )
* 439 001
*

```

```

* << RUNG 445 >>
*
* Lower      SglPrec
* Max.      Working
*Ref'nce    Reg'ter
*LMXREF     SPWR
* R03533    R00799
+[ A MOVE B ]- ( )
*

```

```

* << RUNG 446 >>
*
* Hoist SglPrec DblPrec      DblPrec      Hoist Value
*Mast.Sw Working Working      Working      Mast.Sw Not
*Shaped Reg'ter Reg'ter      Reg'ter      Shaped Req'd
*HMSSHPD SPWR DPWR1          DPWR1          HMSSHPD NOTREQD
* R00802 R00799 R00800      R00800          Const R00802 R00769
+[ A MPY B = C ]-[ A DVD B QUO REM ]- ( )
*                                -00800
*

```

```

<< RUNG 482 >>
.....
.
.   This rung establishes the reference decrease ramp for normal hoist
.   conditions while the following rung applies when selecting the spreader
.   bar tension mode.
.
.....

Not In  Hoist Ref'nce Hoist  Hoist  Hoist
Hoist  Ref'nce Counter Old/New Ref'nce Old/New
Tension Decreas 1/Scan Ref'nce Adder Ref'nce
NOTTENS HREFDEC RC1/SC HO/NREF HREFADD HO/NREF
03-0061 00-0151 01005 R00805 R00806 R00805
+--][-----][-----][---[ A ADDX B = C ]- ( )
      476    413

<< RUNG 483 >>

Not In  Hoist Ref'nce Hoist  Hoist  Hoist
Hoist  Ref'nce Counter Old/New Ref'nce Old/New
Tension Decreas 1/2Scan Ref'nce Adder Ref'nce
NOTTENS HREFDEC RC1/2SC HO/NREF HREFADD HO/NREF
03-0061 00-0151 01006 R00805 R00806 R00805
+--][-----][-----][---[ A ADDX B = C ]- ( )
      476    414
|
*
* << RUNG 484 >>
*
* Hoist          Value
*Old/New        Not
*Ref'nce        Req'd
*HO/NREF        NOTREQD
* R00805 Const R00769 Const
+[ A SUBX B = C ]-[SKIP]- ( )
*      +00000          001
*
* << RUNG 485 >>
*
*Sft'wre
*LineExc
*Aux'ary
* LEX
*03-0049 Const
+--][---[SKIP]- ( )
*      001
*
* << RUNG 486 >>
*
* Hoist          DblPrec          DblPrec          SglPrec Value
* Arm.          Working          Working          Working Not
*V. x 10        Reg'ter          Reg'ter          Reg'ter Req'd
*HVFBVLT        DPWR1          DPWR1          SPWR NOTREQD
* R02341 Const R00800          R00800          Const R00799 R00769
+[ A MPY B = C ]-[ A DVD          B QUO REM ]- ( )
*      +00800          +06000
*
* << RUNG 487 >>
*
*SglPrec          SglPrec
*Working          Working
*Reg'ter          Reg'ter
* SPWR          SPWR
* R00799 Const R00799
+[ A ADDX B = C ]- ( )
*      +00100
    
```

<< RUNG 519 >>

The following rung calculates the multiplier which will be used to alter the swing master switch signal, depending upon the quadrant and armature voltage.

SglPrec Swing Swing Swing Value
Working Voltage Current Current SubTemp Not
Reg'ter Mult'er Sub'end Sub'end Reg'ter Req'd
SPWR SVLTMUL SCURSUB SCURSUB SSUBREG NOTREQD
R00799 R00943 R02907 R02907 Const R02929 R00769
+[A MPY B = C]-[A DVD B QUO REM]- ()
+01000

<< RUNG 520 >>

* SWING MASTER SWITCH SHAPING *
* The following 9 rungs create a low gain region around the master switch *
* neutral position. As for the hoist master switch, the signal is reduced to *
* one-fourth for the first one-fourth of handle travel. Refer to the hoist *
* explanation for more details.) *

Swing DblPrec DblPrec Swing Value
Mast.Sw Working Working Mast.Sw Not
V. x100 Reg'ter Reg'ter Shaped Req'd
SMSVIN DPWR1 DPWR1 SMSSHPD NOTREQD
R02340 Const R00800 R00800 Const R00807 R00769
+[A MPY B = C]-[A DVD B QUO REM]- ()
+00001 +00004

<< RUNG 521 >>

Swing SglPrec Multi- Cross reference for 00- 0100
Mast.Sw Working Purpose Relay] [119, 383, 384, 385, 387, 38
V. x100 Reg'ter MPR1 433, 435, 436, 437, 440, 49
SMSVIN SPWR MPR1 524, 526, 527, 528, 532, 53
Const R02340 R00799 00-0100 575, 576, 577, 579, 622, 62
+[A SUBX B = C]----- ()]/[444, 497, 583, 623, 627
+00200 () 118, 382, 386, 430, 434, 43
570, 574, 578, 620, 624, 69

<< RUNG 522 >>

Multi- SglPrec DblPrec
Purpose Working Working
Relay Reg'ter Reg'ter
MPR1 SPWR DPWR1
00-0100 R00799 Const R00800
+--] [---[A MPY B = C]- ()
521 +00005

<< RUNG 523 >>

Multi- DblPrec SglPrec Value
Purpose Working Working Not
Relay Reg'ter Reg'ter Req'd
MPR1 DPWR1 SPWR NOTREQD
00-0100 R00800 Const R00799 R00769
+--] [---[A DVD B QUO REM]- ()
| 521 -00004

<< RUNG 561 >>

```

.....
.
.   This rung provides for obtaining a low value of motor field current
.   when the master switch is in neutral and the armature voltage is low for
.   the prescribed period of time.
.
.....

```

Swing Mast.Sw	Swing Arm.	Value Not	Swing Arm.	Value Not	Swing MS Neut	Cross reference for 00- 0128
Neutral	V. x 10	Req'd	V. x 10	Req'd	Timer] [564
SNEUTRL	SVFBVLT	NOTREQD	SVFBVLT	NOTREQD	SNEUTMR	
02-0889	R02343	Const R00769	Const R02343	R00769	Const 00-0128	
+--] [---[A SUBX B = C]-[A SUBX B = C]-----[PRESC]---(TT)						
425	+00500	-00500			020 ()	
Swing					Swing ()	
Mast.Sw					Neutral ()	
Neutral					Time ()	
SNEUTRL					SNEUTRG ()	
02-0889					R02248 ()	
+--]/[-----[ACCRG]---(R)						
425						

<< RUNG 562 >>

```

.....
.
.   The following rungs provide control of the swing motor field exciter
.   similar to that described previously for the hoist motion.
.
.....

```

					Swing	Cross reference for 00- 0267
					Mot.Fld	
					Strong] [565, 566
					SMFST	
					00-0267	
+ [NO OP]----- ()						

<< RUNG 598 >>

.....
.
.
This voltage relay is used to change the reference ramp to prevent
excessive current excursions when plugging from high speed payout.
.
.
.....

Drag	Value	Payout	Cross reference for 00- 0168
Arm.	Not	Voltage	
V. x 10	Req'd	Relay] [599, 601
DVFBVLT	NOTREQD	PAYVLTG	1/[599, 601
R02342	Const R00769	00-0168	

+ [A SUBX B = C]----- ()
-05500

<< RUNG 599 >>

.....
.
.
This rung selects the reference ramp to be used for increasing the
reference according to the quadrant and voltage level.
.
.
.....

Dig	Drag	Drag	Drg Q12 Ref'nce	Drag	Drag	Drag
Mode	Ref'nce	Quad-	Voltage Counter	Old/New Ref'nce	Adder	Old/New Ref'nce
Status	Increas	rant II	Relay 1/2Scan	ref'nce	DREFADD	DO/NREF
DIGMODE	DREFINC	D QUAD2	DRGVLTG RC1/SC	DO/NREF	R00971	R00926 R00971
03-0059	00-0165	00-0132	00-0167 01005	R00971	R00926	R00971

+--] [-----] [---+] [---+]/[-----] [---+ [A SUBX B = C]- ()
592 408 595 413
Drg Q12 Ref'nce
Voltage Counter
Relay 1/2Scan
DRGVLTG RC1/2SC
00-0167 01006
+--] [-----] [---+
595 414
Drag Payout Ref'nce
Quad- Voltage Counter
rant IV Relay 1/Scan
D QUAD4 PAYVLTG RC1/SC
00-0134 00-0168 01005
+--] [---+]/[-----] [---+
410 598 413
Payout Ref'nce
Voltage Counter
Relay 1/2Scan
PAYVLTG RC1/2SC
00-0168 01006
+--] [-----] [---+
598 414
Drag Drag Ref'nce
Quad- Quad- Counter
rant II rant IV 1/Scan
D QUAD2 D QUAD4 RC1/SC
00-0132 00-0134 01005
+--]/[-----]/[-----] [---+
408 410 413

```

<< RUNG 636 >>

Drag      Drag      Dig      Drag      Cross reference for 00051
Mot.Fld  Mot.Fld  Mode    Mot.Fld
Strong   Weak    Status  Bit 1
DMFST    DMFWK   DIGMODE DMFBIT1
00-0264  00-0266 03-0059 00051
+---] [---] / [---] / [---] ( )

```

```

632      635
Drag
Mot.Fld
Medium
DMFMED
00-0265
+---] [---]

```

```

633
Propel   Propel
Mot.Fld  Mode
Bit 1    Status
PMFBIT1  PRPMODE
00057    03-0060
+---] [---] / [---] / [---]

```

```

643

```

```

<< RUNG 637 >>

Drag      Drag      Drag      Dig      Drag      Cross reference for 00052
Mot.Fld  Mot.Fld  Mot.Fld  Mode    Mot.Fld
Strong   Medium   Weak    Status  Bit 2
DMFST    DMFMED   DMFWK   DIGMODE DMFBIT2
00-0264  00-0265 00-0266 03-0059 00052
+---] [---] / [---] / [---] / [---] ( )

```

```

632      633      635
Propel   Propel
Mot.Fld  Mode
Bit 2    Status
PMFBIT2  PRPMODE
00058    03-0060
+---] [---] / [---] / [---]

```

```

644

```

```

<< RUNG 638 >>

*****
*
*                               PROPEL MOTOR FIELD CONTROL
*
*
*****

```

```

Propel      Propel      Propel      Cross reference for 00- 0273
Mast.Sw     Mode
Neutral     Status
LPNEUT      PRPMODE
02-0892     03-0060
+---] [---] / [---] / [---] ( )

```

```

426
Hoist      Drag
DB Cont    DB Cont
Int'lck   Int'lck
HDBX      DDBX
10039     10040
+---] [---] / [---] / [---]

```

```

Propel
Brake
PressSw
PBRKPS
10194
+---] [---]

```

<< RUNG 674 >>

```

*****
*
*           SUBROUTINE NUMBER 11
*
*           SOFT START CONTROL
*
*   The drag generator is used as a motor when Soft Starting the Motor-
*   Generator Set. Its shunt field current is supplied by its normal exciter
*   and its armature current is supplied by the Power Conversion Module (PCM).
*   Synchronous motor field current is supplied by the swing generator field
*   exciter while synchronizing and by the PCM in normal operation.
*   The same Subroutine is used for the three Regulators used during Soft
*   Starting. The next 4 rungs provide the constants required by these Reg-
*   ulators. The first block is for the drag generator field current regula-
*   tor, the second is for the PCM speed regulator and the third is for the
*   synchronous motor voltage regulator. The constants provided are, in order,
*   input resistance, feedback resistance, lead circuit resistance, lag cir-
*   cuit resistance, lead circuit capacitor function, lag circuit capacitor
*   function, and maximum value for the output. The capacitor function is
*   equal to the scan time divided by the capacitance.
*
*****

```

+ [NO OP] - ()

<< RUNG 675 >>

```

MG Set           SftStrt  Cross reference for 01020
Start           Start
Latch          1-Shot    ] [ 676, 677, 679, 680, 681
MGSTLAT        SSOS     ]/[ 678
03-0050        01020
+--] [-----] (OS)

```

<< RUNG 676 >>

```

SftStrt
Start
1-Shot
SSOS RES1D
01020 R01502
+--] [---[          BLOCK MOVE          ]- ( )
| 675          +30000 +30000 +20000 +00000 +00168 +00000 +00800

```

<< RUNG 677 >>

```

SftStrt
Start
1-Shot
SSOS RES1S
01020 R01522
+--] [---[          BLOCK MOVE          ]- ( )
| 675          +01000 +01000 +10000 +00000 +00000 +00000 +01000

```

<< RUNG 729 >>

Sync. Card ON SYNCHON A00300		Synchro Permiss -ive SASCON 00794	Cross reference for 00794
] / [-----] ()			
728			

<< RUNG 730 >>

```

.....
.
.   When the frequency (speed) and phase relationship are correct, the
.   synchronizing card provides the Synchronize signal, which is used by CPU
.   No. 2 to energise the closing coil for the vacuum circuit breaker. When
.   the VCB closes, CPU No. 2 provides the VCB Closed signal.
.   After the VCB closes, the calculated average swing reference is used to
.   hold the synchronous motor excitation at the level used in matching the
.   motor voltage to the machine voltage.
.
.....

```

SftStrt VCB Closed VCBCLSD 03-0053	SftStrt SYMFCM To PCM SYMFCM 03-0054	Average Voltage Ref'nce AVVREF R01300	SftStrt Voltage Reg.Ref SSVREF R01558	
+--] [-----] / [---[A MOVE B]-				()

<< RUNG 731 >>

SftStrt VCB Closed VCBCLSD 03-0053	SftStrt SYMFCM To PCM SYMFCM 03-0054	General Purpose Reg'ter CONST=0 R00900	SftStrt Speed Reg.Ref SSSPREF R01538	
+--] [-----] / [---[A MOVE B]-				()

<< RUNG 732 >>

SftStrt VCB Closed VCBCLSD 03-0053	SftStrt SYMFCM To PCM SYMFCM 03-0054	SftStrt Voltage Reg.Ref SSVREF R01558	SftStrt Voltage Reg.Ref SSVREF R01558	
+--] [-----] [---[A ADDX B = C]-				()
				+00001

<< RUNG 733 >>

SftStrt VCB Closed VCBCLSD 03-0053	SftStrt SYMFCM To PCM SYMFCM 03-0054	Average Voltage Ref'nce AVVREF R01300	SftStrt Working Reg. 1 SSWR1 R01197	
+--] [-----] [---[A MPY B = C]-				()
				+00001

***** UNREFERENCED RUNG EXPLANATION LIST *****

NO UNREFERENCED RUNG NUMBERS FOUND

***** AUX INPUT STATUS TABLE *****

AUX INPUT	NAME/ NICKNAME	CROSS REFERENCE
		() = implicit references MNE = mnemonic references

***** INTERNAL OUTPUT STATUS TABLE *****

INT OUTPUT	NAME/ NICKNAME	CROSS REFERENCE
0231	Calib. : Flasher No. 1 CALFL1] [248, 256 (TT) 247
0232	Calib. : Flasher No. 2 CALFL2] [247, 248 (TT) 248
0233	Rope : Calib. Timer CALTMR] [49, 50, 250, 252, 253, 255, 256, 262, 268 (TT) 249
0238	Hoist : Enc BCD Fault HBCDFLT] [261 () 260
0239	Drag : Enc BCD Fault DBCDFLT] [267 () 259
0240	Hoist : Encoder Check 1 HENCOK1] [266 () 264
0241	Hoist : Encoder Check 2 HENCOK2] [266 () 265
0242	Hoist : Encoder Check 3 HENCOK3] [273, 277, 278] / [39, 273, 283 () 266
0243	Drag : Encoder Check 1 DENCOK1] [272 () 270
0244	Drag : Encoder Check 2 DENCOK2] [272 () 271
0245	Drag : Encoder Check 3 DENCOK3] [274, 279, 280] / [39, 274, 283 () 272
0246	H. Enc. : Check Timer HENCTD] [275, 277] / [273, 281 (TH) 273
0247	D. Enc. : Check Timer DENCTD] [276, 279] / [274, 282 (TH) 274

***** INTERNAL OUTPUT STATUS TABLE *****

CHANNEL NUMBER 2-

INT OUTPUT	NAME/ NICKNAME	CROSS REFERENCE
0894	Reg'tor : Proving Relay RPRX	() 9
0895	Hoist : Shut- down HSCR	() 49
0896	Drag : Shut- down DSCR	() 50
0897	Hoist :]/[43 Encoder Enabled HENCOK	() 281
0898	Drag :]/[43 Encoder Enabled DENCOK	() 282
0899	Tight- line Limit TLLIM	() 371
0900	Calib. : Signal Control CALSIG	() 256
0901	Limit : Buzzer Moment. LIMBUZ1	() 58
0902	Limit : Buzzer On LIMBUZ2	() 59
0903	GenVltg :] [9 Proving Relay VPRAUX	() 13
0904	Sft'wre :] [9 Proving Relay SPRAUX	() 17
0905	Limit : Light Flash LIMIL1	() 60

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R00949 [00582]	Swing : Quad.4 Max Ref SMXREF4	147, 149, 537, 540, 540
R00950 [64737]	Swing : Quad.3 Max Ref SMXREF3	148, 537, 539, 539
R00951 [06401]	Hoist : Encoder Reading HENC	96, 250, 252, 260, 262, 263, 264, 265, 277
R00952 [03708]	Drag : Encoder Reading DENC	96, 253, 255, 259, 268, 269, 270, 271, 279
R00955 [00000]	Drag Q1 : Current Sub'end D1CUSUB	614, 614
R00957 [00270]	Drag : Voltage Mult'er DVLMUL	611, 613, 614
R00961 [00000]	Drag : Mast.Sw Shaped DMSSHPD	569, 573, 577, 578, 581, 581, 582, 582, 585, 585, 586, 586, 587, 589, 590, 590, 591, 591, 5
R00971 [00000]	Drag : Old/New ref'nce DO/NREF	592, 593, 599, 599, 600, 600, 601, 601, 602, 602, 603, 604, 608, 608, 609
R00983 [64724]	Propel : Current Sub'end PCURSUB	621, 621, 625, 625
R00985 [00130]	Propel : Ampere Sub'end PAMPSUB	621, 622, 625, 626
R01009 [06597]	Sync. : Voltage Ref'nce SYNVREF	709, 712, 712, 713, 713, 714
R01010 [00000]	M/G Set : Spd Ref In RPM MGSPDRF	691, 693, 694, 694, 696, 696, 700, 700, 701, 701, 702

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R02342 [65526]	Drag : Arm. V. x 10 DVFBVLT	12, 12, 169, 405, 595, 595, 597, 597, 598, 606, 610, 612, 620, 624, 629, 629, 630, 630
R02343 [65471]	Swing : Arm. V. x 10 SVFBVLT	11, 11, 170, 399, 516, 517, 558, 558, 559, 559, 561, 561
R02344 [00015]	Hoist : Arm. Amps. HCFBAMP	171, 394, 449, 511
R02345 [00074]	Drag : Lp1Arm. Amps. DCFABAMP	172, 406, 634
R02346 [65486]	Drag : Lp2Arm. Amps. D2CFBA	173
R02347 [00001]	Swing : Armatur Amps SCFBAMP	174, 546, 547, 551
R02348 [63578]	Hst.Mtr : Fld.Amp x 100 HMFAMP	175, 449
R02349 [65521]	Drg.Gen : Fld.Amp x 100 DGFAMP	176, 687, 687, 689, 703
R02351 [00012]	Machine : AC Current IMACH	177
R02352 [00064]	AC Gen. : Kilo- watts ACKW	178
R02353 [65527]	AC Gen. : Kilo- vars ACKVAR	179
R02354 [00905]	Air : Press. PSI X10 AIRPSI	182

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R03532 [00800]	Hoist : Max. Ref'nce HMXREF	121, 322, 323, 372, 378, 382, 441, 645
R03533 [64736]	Lower : Max. Ref'nce LMXREF	313, 384, 445, 645
R03534 [05500]	HstRlay : Pickup Q1 & Q2 HVRELAY	150, 505
R03535 [00100]	Tension : Current Level H SBTRI	124, 499, 502
R03551 [02088]	Drag Q1 : PeakPwr Amperes D1PKAMP	129
R03552 [63448]	Drag Q3 : PeakPwr Amperes D3PKAMP	133
R03553 [03600]	Drag : Stall Current D STALL	129, 133, 137, 615
R03554 [00800]	Drag : Forward Max.Ref DFMXREF	130, 352, 353, 386, 580, 646
R03555 [64736]	Drag : Reverse Max.Ref DRMXREF	134, 343, 388, 584, 586, 586, 646
R03556 [05700]	DrgRlay : Pickup Q1 & Q2 DVRPKUP	151, 595, 596
R03576 [02088]	Propel : PeakPwr Amperes P PKAMP	138, 142
R03577 [03960]	Propel : Forward Stall A PFSTALL	138, 622, 623

<< RUNG 4 >>

```

*****
*
*           BEGIN GENERAL DRIVE MANAGEMENT
*
*****

```

+ [NO OP] -

()

<< RUNG 5 >>

```

Never                                     Propel   Cross reference for 03- 0069
Ener-                                     LimitSw
gized                                     Mode     ] [ 96, 97
EVEROFF                                  PRPLSMO  ]/[ 96, 97
00-0254                                  03-0069
+---] [---] [---] [---] [---] [---] ( )

```

178

<< RUNG 6 >>

```

.....
.
.   Next few rungs check for Critical Blocks at power-up to determine if
.   they are "alive". This is done by putting an incorrect value on a block
.   point, if it doesn't change then the block is "dead". The blocks are
.   grouped and determined if they will effect the LE Chain or M/G Set logic.
.
.....

```

```

CntlBus      Hoist
Cntrlr       Joystck
OK Timr      Input
CBOKOS       HMSIN
A00703      Const  R07026
+---] [---] [ A MOVE B ]- ( )
      18 +10000

```

<< RUNG 7 >>

```

SensBus      Propel      MG Set1
Cntrlr       Right      Bearing
OK Timr      Outer      #1 Temp
SBOKTMR      PROUTER    MGBR10T
A00704      Const  R07001  Const  R07008
+---] [---] [ A MOVE B ]-[ A MOVE B ]- ( )
      23 +10000          +10000

```

<< RUNG 8 >>

```

SensBus      MG Set1      Propel
Cntrlr       Bearing      Left
OK Timr      #8 Temp      Outer
SBOKTMR      MGBR80T     PLOUTER
A00704      Const  R07014  Const  R07020
+---] [---] [ A MOVE B ]-[ A MOVE B ]- ( )
      23 +10000          +10000

```

```

<< RUNG 42 >>
Power          General
Up            Purpose
Scan         Reg'ter
PUPSCAN      CONST=4
00950        Const   R00904
+--]/[---[  A   MOVE   B ]-      ( )
      282  +00004

```

<< RUNG 43 >>

```

.....
.
.   Blowers, Oil Pumps, Filter Fans, Bleed Duct Fans, and Anti-Condensation .
. Heaters Control. .
.
.....

```

+ [NO OP] - ()

<< RUNG 44 >>

```

DC Motr DC Motr          DC Motr Cross reference for 00361
Blowers Blowers          Blower
StartPB Stop PB          Starter
STRIBLW STOPBLW         BLWSTTR
10069 10070             00361
+--] [---] [-----] ( )

```

```

Blowers
Running
Relay
BLOWERS
10168
+--] [---]

```

<< RUNG 45 >>

```

Blowers          Blowers Cross reference for 00340
Running          Running
Relay            Ind.Lt.
BLOWERS         BLWRSIL
10168           00340
+--] [---] ( )

```

```

M/G Set
Start
CyclePB
STRTCYC
10068
+--] [---]

```

```

<< RUNG 81 >>

      Drag SglPrec          Drag
      Ref'nce Working      Ref'nce
      I.Buff1 Reg'ter      I.Buff1
      DREFIB1 SPWR 1      DREFIB1
Const R02845 R01036 Const R02845
+[ A SUBX B = C ]-[ A MOVE B ]- ( )
+01638 +01638

<< RUNG 82 >>

      Drag Drag Drag Drag
      Joystck Joystck MastrSw MastrSw
      Payout Input LoDeadB O.Delta
      PAYOUTM DMSIN DMSLODB DMSODEL
      03-0904 R07028 R02821 R02829
+--] [---[ A SUBX B = C ]- ( )
      77

<< RUNG 83 >>

      Drag          Drg Pay          Drag          Drag Ref'nce
      MastrSw          Temp          Temp          Mast.SW Ref'nce Working
      O.Delta          DBPrec          DBPrec          I.Span I.Buff1 Reg'ter
      DMSODEL          DMSWR2          DMSWR2          DMSOSPN DREFOB1 REFWR
      R02829 Const R02847          R02847          R02818 R02849 R02833
+[ A MPY B = C ]-[ A DVD B QUO REM ]- ( )
+01638

<< RUNG 84 >>

      Drag          SglPrec          Drag
      Ref'nce          Working          Ref'nce
      I.Buff1          Reg'ter          I.Buff1
      DREFOB1          SPWR 1          DREFOB1
      R02849 Const R01036 Const R02849
+[ A SUBX B = C ]-[ A MOVE B ]- ( )
-01638 -01638


<< RUNG 85 >>

      Drag Drag          Drag
      Joystck Ref'nce          Refrnce
      Drag I.Buff1          Counts
      DRAGMS DREFIB1          DREFCNT
      03-0903 R02845          R02473
+--] [---[ A MOVE B ]- ( )
      76

<< RUNG 86 >>

      Drag Drag          Drag
      Joystck Ref'nce          Refrnce
      Payout I.Buff1          Counts
      PAYOUTM DREFOB1          DREFCNT
      03-0904 R02849          R02473
+--] [---[ A MOVE B ]- ( )
      77

```



```

<< RUNG 140 >>

Swing      M/G   Swg.Brk           Swing      Cross reference for 00124
Brake#1    Set   Alarm              Brake
PressSw    Running Timer          Set Lt.
SBRKPS1    MGRUN SBRKTMR          SBIL
10226      03-0055 00-0182          00124
+---] / [---] [---] / [---] -----( )
                240      149
Swing      Light
Brake#2    On
PressSw    Flasher
SBRKPS2    FLASH1
10195      00-0740
+---] / [---] +---] [---]
                179

LampTst
w/Alarm
ClearPB
LMPTEST
A00909
+---] [---]
                357

<< RUNG 141 >>

.....
.
.   Operation of the drag brake magnet valve is subject to logic similar to
.   that of the hoist drive. Special brake control is available in the
.   Boom Raise/Lower Mode.
.
.....

Drag      Drag      Drag      Drag      Drag      Drag      Drag      Cross reference for 00012
Gen.Fld  Clutch  DB Cont  Gen.Fld  Gen.Fld  Brake
DB Cont  PressSw  Int'lck  AC Cont  FuseLss  Release  Mag.Vlv  ] [ 150, 515
DDB      DCLTPS  DDBX     DALEX    DGFFLSS  DBR
00003    10199   10040    10163    10030    00-0212  DBMV
+---] [---] [---] [---] [---] [---] [---] [---] -----( )
                136                        113

<< RUNG 142 >>

.....
.
.   Next two rungs are used for OIT purposes; the Boom Raise/Lower Screen.
.   R-941 and R-942 are transferred to the OIT for display.
.
.....

Hoist      Hoist      Cross reference for A00305
Brake      BrkeSet
Mag.Vlv    1-Shot    ] [ 143
HBMV      HBSET1S
00011     A00305
+---] / [---] -----(OS)
                137

<< RUNG 143 >>

Hoist      Boom      Hoist      Hoist
BrkeSet    Rse/Lwr  Arm.        Current
1-Shot     Mode     Amps.       Feedback
HBSET1S    BRLMODE  HCFBAMP    HCFBLP
A00305     A00911   R02344     R00941
+---] [---] [---] [ A   MOVE   B ]-
                142      197

```

<< RUNG 175 >>

```

*****
*
*           BEGIN PROGRAM HOUSEKEEPING LOGIC
*
*****

```

+ [NO OP]-

()

<< RUNG 176 >>

Sft'wre	Reset	LE On	Cross reference for 00- 0351
LineExc	LE On	One	
Aux'ary	1-Shot	Shot] [360
LEX	LEOSRST	LEONOS	
03-0049	00-0352	00-0351	

+--] [-----]/[-----] ()

32 177

<< RUNG 177 >>

Sft'wre	Reset	Cross reference for 00- 0352
LineExc	LE On	
Aux'ary	1-Shot] [176
LEX	LEOSRST	
03-0049	00-0352	

+--] [-----] ()

32

<< RUNG 178 >>

```

.....
.
.   At times, the software logic may require use of an interlock which is
.   never subjected to a change of state. This rung provides such a function
.   for general purpose use by the programmer.
.
.....

```

Never	Never	Never	Cross reference for 00- 0254
Ener-	Ener-	Ener-	
gized	gized	gized] [5, 178, 268, 276, 279, 444,
EVEROFF	EVEROFF	EVEROFF	460, 512, 536, 538, 539, 54
00-0254	00-0254	00-0254	639, 640, 642, 646

+--] [-----]/[-----] ()]/[28, 178, 225, 250, 252, 264

178 178

<< RUNG 179 >>

Reset	Light	Cross reference for 00- 0740
Light	On	
Flasher	Flasher] [138, 140, 144, 147, 180, 35
FLASH2	FLASH1	
00-0741	Const 00-0740	

+--] [-----] [PRESC] --- (TT)

180 004 ()

Reset	LightOn	()
Light	Flasher	()
Flasher	AccTime	()
FLASH2	ONFLSHT	()
00-0741	R01084	()

+--] [-----] [ACCRG] --- (R)

180

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

```

<< RUNG 214 >>
  DOL   SyncMtr Field#1           M/G Set Cross reference for 00347
Select Contctr Contctr           Startng
Latch #1Closd ClsdRly           Ind.Lt.
DOL SEL SYM1CC FLD1CCR           STRTING
03-0076 I0098 I0100             00347
+--] [----] [----]/[-----] ( )
  208
  MG Set
  Start
  Latch
  MGSTLAT
  03-0050
+--] [----]
  228
  M/G Set
  Start
  CyclePB
  STRTCYC
  I0068
+--] [----]

<< RUNG 215 >>
  SyncMtr SyncMtr M/G           M/G Set Cross reference for 00348
Contctr Field Set               Started
#1Closd AppldIL Running        Ind.Lt.
SYM1CC SYMFALT MGRUN           STARTED
I0098 00346 03-0055           00348
+--] [----] [----] [----] ( )
  217 240
  M/G Set
  Start
  CyclePB
  STRTCYC
  I0068
+--] [----]

<< RUNG 216 >>
  SyncMtr                       VacBrkr Cross reference for 00345
Contctr                         Closed
#1Closd                         Ind.Lt.
SYM1CC                           VCBLT
I0098                             00345
+--] [----] ( )
  M/G Set
  Start
  CyclePB
  STRTCYC
  I0068
+--] [----]

```

<< RUNG 248 >>

Synchro
Card
"ON"
SYCHRON
00794

Synchro Cross reference for A00333
Card ON
OIT Aux
CARDONX
A00333

+---] [------()

<< RUNG 249 >>

SS/Sync
Motor
PCM Flt
PCMFLT
I0761

SS/Sync Cross reference for A00334
MotrPCM
Flt Aux
PCMTRIP
A00334

+---] [------()

```

<< RUNG 275 >>
.....
.
.   Next few rungs determine that the CPU is in a power up situation. This
.   signal will activate an OIT Reset and automatic update of the CPU date
.   and time.
.
.....

Power          OIT
Up             Transfr
Scan          Reg. 2
PUPSCAN      OITREG2
00950 Const   R00997
+--]/[---[ A MOVE B ]- ( )
  282 +00000

<< RUNG 276 >>

Never          OIT          OIT          Cross reference for A00910
Ener-         Transfr      PowerUp
gized        Reg. 2        Acknowl   ] [ 278
EVEROFF      OITREG2      POWERUP  ]/[ 277
00-0254 Const   R00997 Const
+--] [---[ BIT SET MATRIX LEN]----- ( )
  178 00002          001

<< RUNG 277 >>

Power          OIT          OIT
Up            PowerUp      Transfr
Scan        Acknowl      Reg. 1
PUPSCAN    POWERUP      OITREG1
00950 A00910 Const       R00999 Const
+--] [-----]/[---[ BIT SET MATRIX LEN]- ( )
  282 276 00002          001

<< RUNG 278 >>

OIT          OIT
PowerUp      Transfr
Acknowl     Reg. 1
POWERUP     OITREG1
A00910 Const R00999 Const
+--] [---[ BIT CLEAR MATRIX LEN]- ( )
  276 00002          001

<< RUNG 279 >>

Never      All      Disabl
Ener-     Zero's  Events
gized    Matrix  Matrix
EVEROFF  0-MATRX OITSSDB
00-0254 R01700 R00701 Const
+--] [---[ A INV B LEN ]- ( )
  178          019
    
```

```

<< RUNG 312 >>

OpnGear      LubeSys      LubeSys      Open  LubeSys
Propel       Utility       Utility       Gear B Utility
Int'val      Reg. 1          Reg. 1       Int'val Reg. 3
OGPINT      LSREG1        LSREG1       OGINTB LSREG3
R03677      Const R01247    R01247      Const R01204 R01249
+[  A MPY  B =  C      ]-[  A  DVD      B  QUO  REM ]- ( )
      +00060                                +00001

<< RUNG 313 >>

FrntEnd      LubeSys      LubeSys      FrntEnd LubeSys
Dig          Utility       Utility       Int. A Utility
Int'val      Reg. 1          Reg. 1       Aux'ary Reg. 3
LFDINT      LSREG1        LSREG1       FEINTA LSREG3
R03680      Const R01247    R01247      Const R01205 R01249
+[  A MPY  B =  C      ]-[  A  DVD      B  QUO  REM ]- ( )
      +00060                                +00001

<< RUNG 314 >>

Rotatng      LubeSys      LubeSys      Rotatng LubeSys
Frame        Utility       Utility       Frame Utility
Int'val      Reg. 1          Reg. 1       Int'val Reg. 3
RFINT       LSREG1        LSREG1       RFINT  LSREG3
R01202      Const R01247    R01247      Const R01202 R01249
+[  A MPY  B =  C      ]-[  A  DVD      B  QUO  REM ]- ( )
      +00060                                +00001

<< RUNG 315 >>

Low.Frm      Grease
Grs.Gun      Gun
Manual       Time
LFGGMAN      GUNTIME
R03681      R01206
+[  A  MOVE  B ]- ( )

<< RUNG 316 >>

Grease       LubeSys      LubeSys      Grease  LubeSys
Gun          Utility       Utility       Gun  Utility
Time        Reg. 1          Reg. 1       Time Reg. 3
GUNTIME     LSREG1        LSREG1       GUNTIME LSREG3
R01206      Const R01247    R01247      Const R01206 R01249
+[  A MPY  B =  C      ]-[  A  DVD      B  QUO  REM ]- ( )
      +00060                                +00001
    
```

```

<< RUNG 346 >>

Front      FrntEnd  Cross reference for 00- 0376
End        1-Shot
Valve A    Reset      ]/[ 345
FEVALVA    LFOSR
00514      00-0376
+---] [-----] ( )
349

<< RUNG 347 >>

Front      FrntEnd FrntEnd  Cross reference for 00- 0377
End        Fault   Fault
AirPump    Time   Timer   ] [ 347, 353
FE PUMP    FEFLTM LFFTMR ]/[ 347, 349
00513      R03683 00-0377
+---] [-----] [PRERG]---(TS)
350      ( )
Front      FrntEnd      FrntEnd      ( )
End        Fault        Fault        ( )
P.S. A     Timer          Time 1      ( )
FEPSA     LFFTMR        LFFTM       ( )
10483     00-0377          R01220     ( )
+---] [-----] [ACCRG]---( R)
347

Lube      FrntEnd
Fault     Fault
ResetPB   Timer
LFLTRST  LFFTMR
10488    00-0377
+---] [-----] [-----] [-----]
347

<< RUNG 348 >>

FrntEnd  Cross reference for 00- 0378
PSFault  Timer    ] [ 348, 353
LFPSFLT  ]/[ 348, 349
Const    00-0378
+---] [-----] [PRESC]---(TS)
060      ( )
Front      FrntEnd      FrntEnd      ( )
End        PSFault     Fault        ( )
P.S. A     Timer          Time 2      ( )
FEPSA     LFPSFLT     FEF2TM      ( )
10483     00-0378          R01221     ( )
+---] [-----] [ACCRG]---( R)
348

Lube      FrntEnd
Fault     PSFault
ResetPB   Timer
LFLTRST  LFPSFLT
10488    00-0378
+---] [-----] [-----]
348
    
```

```

<< RUNG 375 >>

Set Pt. Multi-      Set Pt. Value      Set Pt.
Trn'fer purpose    Table Not          Table
Latch Relay        Pointer Req'd      Pointer
SPLAT MPR2         SPPTR NOTREQD     SPPTR
03-0064 00-0101    Const R02450 R00769 Const    R02450
+--] [-----] [---[ A SUBX B = C ]-[ A MOVE B ]- ( )
    370   371 +03750                      +03451

<< RUNG 376 >>

*****
*
*                               END SUBROUTINE NUMBER 5
*
*****

+[ Return ]-

```

<< RUNG 423 >>

Aux'ary	SglPrec		Aux'ary	Aux'ary	
Month	Working		Day of	Day of	
of Year	Reg'ter		Year	Year	
AUXMNTH	SPWREG		AUXDOY	AUXDOY	
Const R00916	R00915	Const R00918	R00918		

+ [A SUBX B = C] - [A ADDX B = C] - ()
+00012 +00030

<< RUNG 424 >>

.....
. The following rung produces a number equal to the current hundreds of
. days.
.

Aux'ary	DblPrec		DblPrec		Hund-	DblPrec
Day of	Working		Working		reds	Working
Year	Reg'ter		Reg'ter		of Days	Reg'ter
AUXDOY	DPWREG		DPWREG		DAY/100	DPWREG
R00918	Const R00914		R00914	Const	R00919	R00914

+ [A MPY B = C] - [A DVD B QUO REM] - ()
+00001 +00100

<< RUNG 425 >>

.....
. The following rung produces a number equal to the current day of the year
. minus the hundreds of days.
.

Hund-	DblPrec		Aux'ary	DblPrec	Single
reds	Working		Day of	Working	Days
of Days	Reg'ter		Year	Reg'ter	Reg'ter
DAY/100	DPWREG		AUXDOY	DPWREG	SGLDAYS
R00919	Const R00914		R00918	R00914	R00920

+ [A MPY B = C] - [A SUBX B = C] - ()
+00100

<< RUNG 426 >>

.....
. The next rung converts decimal Single Days to BCD for compatibility with
. the CPU clock.
.

Single	General
Days	Working
Reg'ter	I/O
SGLDAYS	GENWI/O
R0920	O0897

+ [BIN TO BCD] - ()


```

<< RUNG 581 >>

SensBus          Drag
Cntrlr           Brake
OK Timr          PressSw
SBOKTMR          DBRKPS
A00704           Const I0193 Const
+--] [---[ BIT CLEAR MATRIX LEN]- ( )
    23 00016          001

<< RUNG 582 >>

SensBus SensBus          SensBus Cross reference for A00739
Cntrlr Drop#3            Drop #3
OK Timr Input16          BlckFlt ] [ 225
SBOKTMR SB3IN16          SNSDR03
A00704 10224             A00739
+--] [-----]/[-----]-( )
    23

<< RUNG 583 >>

SensBus          Drag
Cntrlr           Motor#1
OK Timr          Klixon
SBOKTMR          DM10TX
A00704           Const I0209 Const
+--] [---[ BIT CLEAR MATRIX LEN]- ( )
    23 00016          001

<< RUNG 584 >>

SensBus SensBus          SensBus Cross reference for A00740
Genius Block            Drop #4
Fault Address          BlckFlt
SBGBFLT SNSBLCK        SNSDR04
A00859 R00935 Const    A00740
+--] [---[ A EQUAL B ]-----[LATCH]---( L )
    578          +00393          ( )
Drive          ( )
Reset          ( )
P.B.          ( )
DRRSTPB       ( )
I0005         ( )
+--] [-----]-(UL)

<< RUNG 585 >>

M/G Set          SensBus Cross reference for A00741
TachLss         Drop #5
Trip            BlckFlt ] [ 225
TACHLSS        SNSDR05
A00240         A00741
+--] [-----]-( )
    537

<< RUNG 586 >>

Propel          SensBus Cross reference for A00742
Right          Drop #6
Outer          BlckFlt
PROUTER        SNSDR06
R07001 Const   A00742
+[ A EQUAL B ]-----]-( )
    +10000
    
```

```

<< RUNG 628 >>

CntlBus CntlBus          CntlBus Cross reference for A00794
Genius  Block           Drop#26
Fault  Address         BlckFlt
CBGFLT CNTBLCK        CNTDR26
A00863 R00937 Const   A00794
+--] [---[ A EQUAL B ]-----[LATCH]---( L)
    594          +00529      ( )
Drive          ( )
Reset         ( )
P.B.         ( )
DRRSTPB      ( )
I0005       ( )
+--] [-----[UL]-----

<< RUNG 629 >>

*****
*
*                      END OF SUBROUTINE NUMBER 8
*
*****

+ [ Return ] -

```

```

*
* << RUNG 666 >>
*
*
* 2048 = 8 in the upper byte of R4116.
*
*
*      Aux'ary SglPrec      Month Aux'ary      Day
*      Day of Working      and Day of      of
*      Year Reg'ter        Day Year        Month
*      AUXDOY SPWREG       DATE AUXDOY      DAYMNTH
* Const R00918 R00915 Const R04116 R00918 Const R00924
+[ A SUBX B = C ]-[ A MOVE B ]-[ A SUBX B = C ]- ( )
* +00213          +02048          +00212
*
* << RUNG 667 >>
*
*
* 2304 = 9 in the upper byte of R4116.
*
*
*      Aux'ary SglPrec      Month Aux'ary      Day
*      Day of Working      and Day of      of
*      Year Reg'ter        Day Year        Month
*      AUXDOY SPWREG       DATE AUXDOY      DAYMNTH
* Const R00918 R00915 Const R04116 R00918 Const R00924
+[ A SUBX B = C ]-[ A MOVE B ]-[ A SUBX B = C ]- ( )
* +00244          +02304          +00243
*
* << RUNG 668 >>
*
*
* 2560 = 10 in the upper byte of R4116.
*
*
*      Aux'ary SglPrec      Month Aux'ary      Day
*      Day of Working      and Day of      of
*      Year Reg'ter        Day Year        Month
*      AUXDOY SPWREG       DATE AUXDOY      DAYMNTH
* Const R00918 R00915 Const R04116 R00918 Const R00924
+[ A SUBX B = C ]-[ A MOVE B ]-[ A SUBX B = C ]- ( )
* +00274          +02560          +00273
*
* << RUNG 669 >>
*
*
* 2816 = 11 in the upper byte of R4116.
*
*
*      Aux'ary SglPrec      Month Aux'ary      Day
*      Day of Working      and Day of      of
*      Year Reg'ter        Day Year        Month
*      AUXDOY SPWREG       DATE AUXDOY      DAYMNTH
* Const R00918 R00915 Const R04116 R00918 Const R00924
+[ A SUBX B = C ]-[ A MOVE B ]-[ A SUBX B = C ]- ( )
* +00305          +02816          +00304

```

<< RUNG 700 >>

```

.....
.
.   The input at the neutral position is determined.
.
.....
    
```

Mast.SW	Hoist		Hoist		
Calib.	Joystck		Mast.Sw		
ZeroSet	Input		Zero Pt		
MSCALZS	HMSIN		HMSZERO		
A00563	R07026		R02802		
+	---	[A	MOVE	B]-	()
	697				

<< RUNG 701 >>

```

.....
.
.   The maximum and minimum input values are determined.
.
.....
    
```

Mast.SW	Hoist	Hoist	SglPrec	Hoist		Hoist
Calib.	Mast.Sw	Joystck	Working	Joystck		Mast.Sw
Max/Min	Max.Ref	Input	Reg'ter	Input		Max.Ref
MSCALMM	HMSMAX	HMSIN	SPWR 1	HMSIN		HMSMAX
A00564	R02800	R07026	R01036	R07026		R02800
+	---	[A SUBX	B =	C]-[A	MOVE	B]-
	698					()

<< RUNG 702 >>

Mast.SW	Hoist	Hoist	SglPrec	Hoist		Hoist
Calib.	Joystck	MastrSw	Working	Joystck		MastrSw
Max/Min	Input	Min.Ref	Reg'ter	Input		Min.Ref
MSCALMM	HMSIN	HMSMIN	SPWR 1	HMSIN		HMSMIN
A00564	R07026	R02801	R01036	R07026		R02801
+	---	[A SUBX	B =	C]-[A	MOVE	B]-
	698					()

<< RUNG 703 >>

```

.....
.
.   The dead band around neutral is established.
.
.....
    
```

Mast.SW	Hoist		Hoist		
Calib.	Mast.Sw		MastrSw		
Max/Min	Zero Pt		HiDeadB		
MSCALMM	HMSZERO		HMSHIDB		
A00564	R02802	Const	R02809		
+	---	[A ADDX	B =	C]-	()
	698		+00061		

<< RUNG 704 >>

Mast.SW	Hoist		Hoist		
Calib.	Mast.Sw		Mast.Sw		
Max/Min	Zero Pt		LoDeadB		
MSCALMM	HMSZERO		HMSLODB		
A00564	R02802	Const	R02810		
+	---	[A SUBX	B =	C]-	()
	698		+00061		

***** INPUT STATUS TABLE *****

INPUT/ (OVR)	NAME/ NICKNAME	CROSS REFERENCE
I0065	MG Set1 : Start P.B. STRTMG1] [228, 234 MNE 602
I0066	MG Set1 : Stop P.B. STOPMG1] [235]/[235
I0067	DOL/ SftStrt KeySw. DOL/SS] [208]/[232
I0068	M/G Set : Start CyclePB STRTCYC] [45, 47, 49, 51, 55, 59, 60, 213, 214, 215, 216, 217
I0069	DC Motr : Blowers StartPB STRTBLW] [44
I0070	DC Motr : Blowers Stop PB STOPBLW] [44
I0071	Oil Pump StartPB STRTPMP] [46, 48
I0072	Oil Pump Stop PB STOPPMP] [46, 48
I0073	Filter : Fan #1 StartPB STRTFF1] [50
I0074	Filter : Fan #1 Stop PB STOPFF1] [50, 53
I0075	Filter : Fan #2 StartPB STRTFF2] [54
I0076	Filter : Fan #2 Stop PB STOPFF2] [54, 57
I0077	AntiCnd : Heaters OFF/AUT ACHSSW] [58

***** INPUT STATUS TABLE *****

INPUT/ (OVR)	NAME/ NICKNAME	CROSS REFERENCE
10251	Altern. : Earth Fault ALT.E/F] [495
10252	Lgt/Pwr : Board B AV3.E/F L/PBBEF] [498
10481	Open : Gear P.S. A OGPSA] [324 1/[325, 326
10482	Open : Gear P.S. B OGPSB] [324 1/[325, 327
10483	Front : End P.S. A FEPSA] [347 1/[348, 349
10484	Rotatng : Frame P.S. A RFPSA] [332 1/[333, 334
10485	Rotatng : Frame P.S. B RFPSB] [332 1/[333, 335
10486	Rotatng : Frame P.S.A/B RFPSA/B] [332 1/[333, 334, 335
10487	HIBS : Pressur Switch HIBS PS	1/[458
10488	Lube : Fault ResetPB LFLTRST] [307, 308, 324, 325, 332, 333, 347, 348, 351, 352, 353, 354 1/[439, 440, 441, 442
10489	Manual : Propel Mode PB MANPROP] [306, 308, 327, 335 1/[326, 334
10490	OpnGear : Manual StartPB OGSTART] [326, 327
10491	FrntEnd : Manual StartPB FESTART] [349

***** OUTPUT STATUS TABLE *****

OUTPUT/ (OVR)	NAME/ NICKNAME	CROSS REFERENCE
00515	FrntEnd : /GrsGun Valve B FEVALVB] [343, 344, 350] [344, 349 () 343
00517	Rotatng : Frame AirPump RF PUMP] [332 () 336
00518	Rotatng : Frame Valve A RFVALVA] [330, 331, 334, 336] [335 () 334
00519	Rotatng : Frame Valve B RFVALVB] [330, 331, 335, 336, 338] [334 () 335
00529	Machine : Operat- ing IL MOPERIL	() 307
00530	Propel : Mode Ind.Lt. PRPMDIL	() 308
00531	Front : End FaultIL FEFLTIL] [439 () 353
00532	Rotatng : Frame FaultIL RFFLTIL] [440 () 352
00533	Propel : Fault Ind.Lt. PRFLTIL] [441 () 354
00534	Open : Gear FaultIL OGFLTIL] [442 () 351
00578	Clear : Sensor BusFlts SENSBUS	() 281
00642	Clear : Control BusFlts CNTLBUS	() 280
00785	Disc'te : I/O 785 DIO-785	MNE 303

***** A U X O U T P U T S T A T U S T A B L E *****

AUX OUTPUT	NAME/ NICKNAME	CROSS REFERENCE
A00211	Hoist : Current LmtLoss HCLL	() 523
A00214	Drag : LoopGnd Fault DLGNDF	() 524
A00216	Drag : Current LmtLoss DCLL	() 525
A00217	Swing : LoopGnd Fault SLGNDF	() 526
A00225	Swing : Voltage LmtLoss SVLL	() 527
A00227	Hoist : Loop O'Crnt HLO'C	(L) 528
A00228	Hoist : CurrIso Loss HCIL	(L) 529
A00231	Swing : Loop O'Crnt SLO'C	(L) 530
A00232	Swing : CurrIso Loss SCIL	(L) 531
A00235	Drag : Loop #1 O'Crnt DL10'C	(L) 532
A00236	Drag : CurrIso Loss DCIL	(L) 533
A00237	Drag Lp : Unbalnc Inst.Oc DLU10'C	(L) 534

***** AUX OUTPUT STATUS TABLE *****

AUX OUTPUT	NAME/ NICKNAME	CROSS REFERENCE
A00902	Sample :] [399 Temp at (OS) 393 06:00 TMP0600	
A00903	Sample :] [400 Temp at (OS) 394 10:00 TMP1000	
A00904	Sample :] [401 Temp at (OS) 395 14:00 TMP1400	
A00905	Sample :] [402 Temp at (OS) 396 18:00 TMP1800	
A00906	Sample :] [403 Temp at (OS) 397 22:00 TMP2200	
A00907	Clear :]/[634 Event () 632 Logger CLRFLTS	
A00908	Fresh : (CU) 646 Event Counter FLTCNTR	
A00909	LampTst :] [138, 140, 144, 147, 358, 361, 362, 363, 364 w/Alarm (TS) 357 ClearPB LMPTEST	
A00910	OIT :] [278 PowerUp]/[277 Acknowl () 276 POWERUP	
A00911	Boom :] [73, 74, 118, 122, 143, 198 Rse/Lwr]/[75, 129, 136, 137, 160, 204 Mode (L) 197 BRLMODE	
A00912	Boom :] [197, 197 Rse/Lwr () 196 Permiss BRLMAUX	
A00913	Drg/Prp : () 36 Trn'fer Aux'ary DPTR	

() = implicit references
MNE = mnemonic references

***** INTERNAL OUTPUT STATUS TABLE *****

CHANNEL NUMBER 0-

INT OUTPUT	NAME/ NICKNAME	CROSS REFERENCE
0404	HstDrum : Shaft Right 2074B04] [471
0405	DrgDrum : Shaft Right 2074B05] [472
0408	MG Set1 : Bearing #10TBit 2074B08] [473
0409	MG Set1 : Bearing #20TBit 2074B09] [474
0410	MG Set1 : Bearing #30TBit 2074B10] [475
0411	MG Set1 : Bearing #40TBit 2074B11] [476
0412	MG Set1 : Bearing #50TBit 2074B12] [477
0413	MG Set1 : Bearing #60TBit 2074B13] [478
0414	MG Set1 : Bearing #70TBit 2074B14] [479
0415	MG Set1 : Bearing #80TBit 2074B15] [480
0416	SyncMtr : Stator OT Bit 2074B16] [481
0417	Center : Journal OT Bit 2075B01] [482
0418	House : Ambient OT Bit 2075B02] [483

***** INTERNAL INPUT STATUS TABLE *****

CHANNEL NUMBER 2-

INT INPUT	NAME/ NICKNAME	CROSS REFERENCE
-----------	-------------------	-----------------

() = implicit references
MNE = mnemonic references

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R00001 [00832]	Event : Matrix (S6+A0) FLTMATX	639, 643, 643, 644
R00047 [00000]	SensBus : BadBlck Matrix SBMATRX	578
R00049 [00000]	CntlBus : BadBlck Matrix1 CBMTRX1	594
R00050 [00000]	CntlBus : BadBlck Matrix2 CBMTRX2	594
R00084 [00000]	Aux.Inp : Status Reg'ter AISTAT1	158
R00604 [00000]	Drg/Ppl : DB/LE AccTime FALTOFF	552
R00605 [00000]	Hoist : DB/LE AccTime RTDFALT	553
R00606 [00000]	Main LE : Permiss Time LEPERTM	554
R00607 [00000]	Swing : DB/LE AccTime VCFLTR1	556
R00650 [00000]	AlrmClr : /LmpTst AccTime TESTIME	357
R00701 [65535]	Disabld : Events Matrix OITSSDB	279, 643
R00730 [01577]		: 17, 20
R00740 [01641]		: 22, 25

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R02342 [-00010]	Drag : Arm. V. x 10 DVFBVLT	169, 170
R02343 [65471]	Swing : Arm. V. x 10 SVFBVLT	172, 173
R02344 [00015]	Hoist : Arm. Amps. HCFBAMP	143, 202, 203
R02349 [-00015]	DragGen : Fld.Amp x 100 DMFAMP	693, 693
R02354 [00905]	Air : Press. PSI x10 AIRPSI	250, 250
R02357 [00000]	PCM : Output Current PCMCFB	230
R02358 [06521]	Machine : AC Voltage VMACH	221, 223, 252, 252
R02364 [03590]	Propel : Encoder Degrees PENCDEG	89, 89, 93, 93, 95
R02372 [26624]	Disc'te : I/O 737-752 DISC#1	302
R02373 [61680]	Disc'te : I/O 753-768 DISC#2	302
R02374 [29264]	Disc'te : I/O 785-800 DISC#3	303
R02375 [00000]	DISC'TE : I/O 49 - 64 DISC#4	303
R02391 [08617]	Calibr. : Lower Limit CAL LL	11

***** REGISTER STATUS TABLE *****

REGISTER/ VALUE	NAME/ NICKNAME	CROSS REFERENCE
R07028 [03103]	Drag : Joystick Input DMSIN	76, 77, 79, 82, 708, 709, 709, 710, 710
R07029 [03083]	Swing : MastrSw Input SMSIN	99, 100, 102, 105, 716, 717, 717, 718, 718
R07033 [00499]	M/G Set : Speed Input SPEEDIN	379, 379, 537


() = implicit references

SERIES SIX OIT SETPOINT CONVERSION SHEET

The Boom Protection System has codes that are relative to all Draglines using Thumbwheels to display and change setpoints. The Draglines equipped with OIT's (Operator Interface Terminal's) use Parameter Numbers as their codes. This sheet helps convert the OIT codes into the more conventional Boom Protection codes.


Setpoint	OIT Parameter #	PLC Register	Description
108	1	R-3651	Static Tightline Trip
140	2	R-3652	Static TL Zero Reference
141	3	R-3653	Width of TL Slowdown Zone
142	4	R-3654	Gain for TL Slowdown Zone
304	5	R-3655	Gain for Lower/Payout Limit Trip
601	6	R-3656	Lower Limit
602	7	R-3657	Hoist Limit Zero Reference
603	8	R-3658	Hoist Limit Trip
605	10	R-3660	Width of Hoist Limit Slowdown Zone
677	15	R-3665	Hoist Drum Diameter
N/A	9	R-3659	Width of Lower/Payout Slowdown Zones
801	11	R-3661	Drag Payout Limit
802	12	R-3662	Drag Limit Zero Reference
803	13	R-3663	Drag Limit Trip
804	14	R-3664	Width of Drag Limit Slowdown Zone
877	16	R-3666	Drag Drum Diameter

EFFECT OF ADJUSTMENTS ON SERIES SIX BOOM PROTECTION ACTION




EFFECT OF ADJUSTMENTS ON SERIES SIX BOOM PROTECTION ACTION

CPU POWER SUPPLY TROUBLESHOOTING




GENIUS I/O TROUBLESHOOTING



STEP 3. INSERT THE BUS CONTROLLER

After setting board options, install the Bus Controller in the rack by following these steps:

1. Position the Bus Controller to the left of the Reference Selection DIP switches you set. Using the board remover/installer, press the board carefully into the connector until it is securely lodged.




2. Position the faceplate over the Bus Controller and tighten the screws.


STEP 4. WIRE THE SERIAL BUS

Using shielded, twisted pair cable, create a serial bus connecting the Bus Controller, I/O blocks, and other permanently-installed devices.

Cable used for one serial bus must all be the same, or the bus will not work. Other busses connected to the same CPU may use different types of cable (unless joined by a Bus Switching Module, as described on the next page). Cable specifications are listed below. For applications using Belden 9182 type cable, prefabricated cables are available in 15-inch and 3-foot lengths. See the Ordering Information on page 8.



Connect the Serial 1 terminals of adjacent devices together and the Serial 2 terminals of adjacent devices together. Connect each Shield In terminal to the Shield Out terminal of the previous device.



Cable # & Make	Outer Diameter	Terminating Resistor* -10%to+20% ½ Watt	Installation	Number of Conductors/AWG	Di-Electric Voltage Rating	Ambient Temp Rating	Maximum Length Cable Run, feet/meters at baud rate			
							153.6s	153.6e	76.8	38.4
(B)9182 (A)9823 (C)4596	.350in 8.89mm	150 ohms	In conduit	2 / #22	30v	60°C	2000ft 606m	3500ft 1061m	4500ft 1364m	7500ft 2283m●
(B)89128	.322in 8.18mm	150 ohms	In plenum No conduit	2 / #22	150v	200°C	2000ft 606m	3500ft 1061m	4500ft 1364m	7500ft 2283m●
(B)9841	.270in 6.86mm	120 ohms*	Double Shields	2 / #24	30v	80°C	1000ft 303m	1500ft 455m	2500ft 758m	3500ft 1061m●
(B)9207	.330in 8.38mm	100 ohms	In Conduit	2 / #20	300v	80°C	1500ft 455m	2500ft 758m	3500ft 1061m	6000ft 1818m●
(B)89207 (A)4794	.282in 7.16mm	100 ohms	In plenum No conduit	2 / #20	150v	200°C	1500ft 455m	2500ft 758m	3500ft 1061m	6000ft 1818m●
(B)9815	.330in 8.38mm	100 ohms	Direct Burial	2 / #20			1500ft 455m	2500ft 758m	3500ft 1061m	6000ft 1818m●
(B)9855	.315in 8.00mm	100 ohms	In Conduit	4 (two pair) #22	150v	60°C	1200ft 364m	1700ft 516m	3000ft 909m	4500ft 1364m●
(B)89696 (B)89855	.274in 6.96mm	100 ohms	In plenum No Conduit fire resist	4 (two pair) #22	150v	200°C	1200ft 364m	1700ft 516m	3000ft 909m	4500ft 1364m●
(B)9463 (A)9814	.243in 6.17mm	75 ohms	In Conduit	2 / #20	150v	60°C	800ft 242m	1500ft 455m	2500ft 758m	3500ft 1061m
(B)9302	.244in 6.20mm	75 ohms	In Conduit	4 (two pair) #22	300v	80°C	200ft 30m	500ft 152m	1200ft 333m	2500ft 758m

Notes: A = Alpha, B = Belden, C = Consolidated
 ● Limited to 16 taps at maximum length and 38.4 K baud.
 * For the Bus Controller, use on-board jumper to select 150 ohms.

BLOCK SPECIFICATIONS

Block type:	8 circuit combination input and output
Standby power (all inputs and outputs off):	IC660BBD100: 12 Watts IC660BBD101: 8.5 Watts
LED's (I/O Block):	Unit OK, I/O Enabled
LED's (each circuit):	On logic side of switch
Block to Block Isolation:	1500 V
Terminal Wiring:	One AWG 12 or two AWG 14
Weight:	4 lbs. (1.8 kg)
Heat Dissipation:	14.8W minimum with 8 inputs. 43.5W maximum with 8 outputs on at 2 amps.
Operating voltage (single source):	93-132 VAC
Frequency:	47-63 Hz
Power supply dropout time:	1 cycle (16.7mS at 60Hz, 20mS at 50Hz)

Input Characteristics:

	IC660BBD100	IC660BBD101
Non-tristate input, OFF state:		
Minimum voltage across input device (IN to H)	60 VRMS	60 VRMS
Maximum leakage through input device	1 mA	1 mA
Non-tristate input, ON state:		
Maximum voltage across input device (IN to H)	20 VRMS	20 VRMS
Maximum switch current threshold	6 mA RMS	6 mA RMS
Tristate input, OFF state:		
Acceptable voltage across input device (IN to H)	16 VRMS-40 VRMS	16 VRMS-40 VRMS
Tristate input, ON state:		
Maximum voltage across input device (IN to H)	4 VRMS	4 VRMS
Input load network:		
Resistor to "N"	13K ohms	13K ohms
Capacitor to "H"	.22 mfd	.10 mfd
Input processing time (typical)	2 ms + filter	
Selectable input filter times	10 to 100 ms in 10 ms increments	
Input diagnostics	Open Wire, Overtemperature	

Output Characteristics:

	IC660BBD100	IC660BBD101
Circuit output current (steady state)	2 amps RMS	2 amps RMS
Maximum inrush current up to 2 cycles	30 amps peak	30 amps peak
Maximum inrush current 2-6 cycles	20 amps peak	20 amps peak
Maximum block output current	15 amps maximum per block at 35° C	7.5 amps maximum per block at 60° C
Output Leakage @ 115 VAC:		
Current at 0 volt output (OUT to N)	<13mA	<7mA
Voltage at open output (OUT to N)	95 volts	65 volts
Output switch (OFF to ON/ON to OFF)	Zero crossing	Zero crossing
Maximum switching frequency	Once per second (high inrush currents)	Once per second (high inrush currents)
Turn-on delay (maximum)	0.5 Hz + 1 ms	0.5 Hz + 1 ms
Voltage drop (at 2 amps)	2.5 volts	2.5 volts
Voltage drop (at 30 amps inrush)	10 volts	10 volts
Recommended minimum load, resistive:	30mA	25mA
Recommended minimum load, inductive:	100mA	40mA
Fusing	Internal electronic short circuit trip. 100ms long time trip	
Output diagnostics	Short Circuit, Overload, No Load, Failed Switch, Overtemperature	

Environmental:

Operating Temperature	-0° to +60° C (32° to +140° F)
Storage Temperature	-40° to +100° C (-40° to +212° F)
Humidity	5% to 95% (non-condensing)
Vibration	5-10 Hz 0.2" displacement
10-200 Hz at 1G	

ORDERING INFORMATION

Description	Catalog Number <u>115 VAC Low-leakage</u> <u>I/O Block</u>	
115 VAC I/O Block	IC660BBD100	IC660BBD101
Terminal Assembly Only	IC660TSD100	IC660TSD100
Electronics Assembly Only	IC660EBD100	IC660EBD101

CONTENT OF THIS DATA SHEET

This data sheet describes installation and features of 115VAC/125VDC Isolated blocks.

Block Description	2
Compatibility	2
Bus Scan Times	2
Installation	3
Wiring	3
Block LEDs	5
Removing/Inserting the Electronics Assembly	5
Configuration	6
Block Specifications	8

COMPATIBILITY

This block can be used with any bus interface module or Hand-held Monitor. Hand-held Monitor version HHM501 is required to use all the features described in this data sheet.

Both versions of the Isolated block are backward compatible with previous Isolated blocks and may be used to replace them.

Both Isolated block versions have the same Terminal Assembly (IC660TSS100). Electronics Assembly (IC660EBS100) may be used to replace any version Electronics Assembly IC660ELS100.

BUS SCAN TIMES


The scan time contribution for an Isolated I/O block depends on the baud rate, the block's I/O configuration, and the type and number of controllers on the bus. In the table below, use the appropriate A column if the interface module is a Series Six Bus Controller version IC660CBB900 or 901. For any other type of interface module, use the B column. If there is another bus interface module on the bus sending outputs to the block at the same time, use the C column. All times shown are in milliseconds.

BAUD RATE	INPUTS ONLY BLOCK			OUTPUTS/COMBINATION		
	Bus Controller Type			Bus Controller Type		
	A	B	C	A	B	C
153.6 Kb s	.30	.51	.73	.58	.58	.87
153.6 Kb e	n/a	.59	.81	n/a	.66	.95
76.8 Kb	n/a	1.18	1.61	n/a	1.32	1.89
38.4 Kb	n/a	2.37	3.13	n/a	2.65	3.79

BLOCK DESCRIPTION

A 115 VAC/125 VDC Isolated Input/Output Block provides eight circuits rated to operate at a nominal 115 volts AC or 125 volts DC.

a40653



Note: The 13KL internal preload resistor remains connected when the Electronics Assembly is removed from the Terminal Assembly.


GFK-0044

Serial Bus Wiring

a43020

Wire the serial bus by connecting the Serial 1 terminals of adjacent devices together and the Serial 2 terminals of adjacent devices together. Connect Shield In to the Shield Out terminal of the previous device.

a42196



For the last block (electrically) on the bus, connect a terminating plug across the Serial 1 and Serial 2 terminals.

Field Wiring

Any circuit can be an input or output. Connect one terminal of a field device to DC power and the other to the block (terminals 10-41). All I/O devices must return to the same power circuit.

For block power, connect a DC source to the DC+ terminals (5-9) and the return to the DC- terminals (42-46). Depending on layout and current loads, positive and negative connections can be bussed and made by single wires to the block or power source.


To disable the block without removing power from input devices, use a Block Puller to unplug the Electronics Assembly. Do not disconnect H or N to remove power.

For a Sink block, connect outputs to the positive side of the power supply and inputs to the negative side.

For 5 volt Sink applications *only*, jumper the +5V terminal to any DC+ terminal.

CAUTION

Do not jumper the +5V terminal to DC+ for 12 or 24 volt sink applications. Do not apply more than 5.25 volts to the +5V terminal. Damage to the block may result.



GFK-0048

CONFIGURATION

Each block must be configured with the Hand-held Monitor to:

- Enter its Block Number (serial bus device number).
- Enter its Reference Number (required for Series Five and Series Six PLCs only).

Additional features, described below, can be changed by configuration from the Hand-held Monitor or the application program. Configuration for all blocks should be planned according to information supplied in the *Genius I/O System User's Manual*.

Configuration Protection: Prevents accidental or unauthorized changes to the block's configuration.

Current/Voltage Range: The voltage range of the circuit:

- 0-10 volts DC
- 10 volts DC to +10 volts DC
- 5 volts DC to +5 volts DC
- 0-5 volts DC
- 4-20 mA/1-5 volts DC.

The range selection is a setup parameter; it should NOT be changed while the block is operating.

Fault Reporting: Selects whether faults will be reported to the CPU for each circuit individually.

Input Filter Time: a filter time from 8 ms to 1024 ms can be independently selected for each input on the block. 4 ms unfiltered sampling is also available.

Filter time is a setup parameter; it should NOT be changed while the block is operating.

Alarm Input Mode: Selects whether an input will send its current value to the CPU, or only a normal/high alarm/low alarm indication.

Low/High Alarms: Scaled values between +32,767 for each input, representing a low or high alarm. These limits may be used for either Normal-mode or Alarm-mode inputs (see above).

Scaling Points: Used to convert the raw analog signal to/from engineering units.

Hold Last State: Each output can be configured to maintain its last value if CPU communications are lost and Output Default Value is not selected.

Output Default Value: Each output can be configured to default to a preselected value at powerup, or if CPU communication is lost.

Redundancy Mode: Selects no redundancy or "Hot Standby" mode.

BSM Present: Selected if the block is wired to dual serial bus via a Bus Switching Module.

Outputs Timeout Select: If BSM Present has been selected, this feature selects either 2.5 or 10 seconds as the delay for output defaults.

Baud Rate: May be 153.6 Kbaud standard, 153.6 Kbaud extended, 76.8 Kbaud, or 38.4 Kbaud. *All devices on the bus must use the same baud rate.*

Default Configuration

The following table lists factory default settings for the block's configurable features.

RTD INPUT BLOCKS: SPECIFICATIONS

Block Type:	Six RTD-compatible inputs, three isolated groups of two	
LED's (I/O Block):	Unit OK, I/O Enabled	
Block to Block Isolation:	1500 V	
Group to Group Isolation:	300 V	
Terminal Wiring:	Terminals 1-4: one AWG # 12 or two AWG #14 Terminals 5-22: AWG #22 to AWG #14	
Weight:	4 lbs. (1.8 kg)	
Heat Dissipation:	7W maximum	
115VAC/125 VDC block power:	115 VAC	125 VDC
Power supply voltage:	93-132 VAC @ 7W 47-63 Hz	105-145 VDC @ 7W 10% max. ripple
Power supply dropout time:	1 cycle	10 mS
24/48 VDC block power:	18-56 VDC @ 7W, 10% max. ripple	
Power supply voltage:	10 mS	
Power supply dropout time:		
Input Characteristics:		
Input resolution	±0.1 degree C	
Absolute accuracy (at 25° C)		
Platinum or Nickel:	±0.5 degree C typical, +1.0 degree C maximum	
10Ω Copper:	±5 degree C typical, +10 degree C maximum	
Input update frequency	Once every 400 mS, 800 mS, or 1600 mS	
Input filter ranges (per block)	400 mS, 800 mS, 1600 mS	
RTD linearization	Platinum (DIN 43760), Nickel (DIN 43760), Copper, Linear	
Resistance range	0 to 5000Ω	
Diagnostics	Input shorted, Internal fault, Wiring error, Open Wire, Overrange, Underrange, High Alarm, Low Alarm	
Environmental:		
Operating Temperature	0°C to +60° C (32°F to +140°F)	
Storage Temperature	-40°C to +100° C (-40°F to +212°F)	
Humidity	5% to 95% (non-condensing)	

ORDERING INFORMATION

Description	Catalog Number
115 VAC/125 VDC RTD Input Block	IC660BBA101
Terminal Assembly Only	IC660TBA101
Electronics Assembly Only	IC660EBA101
24/48 VDC RTD Input Block	IC660BBA021
Terminal Assembly Only	IC660TBA021
Electronics Assembly Only	IC660EBA021

To Select the Host CPU. A new Hand-held Monitor is set up to operate with a Series Six PLC. Alternate selections are SERIES FIVE or SERIES 90/PCIM. To change the current selection, press the F2 (TGL) key, then press F3 (Enter).

Press F4 (Next). The screen shows whether automatic shutoff is selected:

```
AUTO OFF = 10 min
ENABLED
```

To Enable/Disable Automatic Shutoff: this feature conserves battery power by shutting off the Hand-held Monitor 10 minutes after the last key entry. To change the current selection, press F2 (Toggle), then F3 (Enter).

Press F4 (Next). The display shows whether the Hand-held Monitor can be used to configure the Block Number (serial bus address) of I/O blocks, as well as the I/O circuit mix of some types of blocks. For the Series Six and the Series Five PLC, this selection also determines whether the HHM can be used to assign the Reference Address of I/O blocks.

```
CHNG BLK ID
ENABLED
```

To Enable/Disable Changing Block ID Parameters, press F2 TGL, then press F3 (Enter).

Press F4 (Next). The configuration screen shows whether the HHM can be used to change the baud rate of I/O blocks:

```
CHNG BLK BAUD
ENABLED
```

To Enable/Disable Changing I/O Block Baud Rate, press F2 (TGL) then press F3 (Enter).

Press F4 (Next). The display shows whether the HHM can be used to configure the features of I/O blocks:

```
CHNG BLK . CONFIG
ENABLED
```

To Enable/Disable I/O Block Configuration, press F2 (Toggle), then F3 (Enter).

Press F4 (Next). The display shows whether the HHM can be used to force I/O circuits:

```
CIRCUIT FORCING
ENABLED
```

To Enable/Disable I/O Circuit Forcing: press F2 (Toggle) then F3 (Enter).

Press F4 (Next). The display shows whether this HHM can clear faults:

```
CLEAR BLK FAULTS
ENABLED
```

To Enable/Disable Fault Clearing, press F2 (Toggle) then F3 (Enter).

Press F4 (Next). The display shows whether the HHM can display memory content from other devices:

```
EXAM DEV MEMORY
DISABLED
```

To Enable/Disable Reading Device Memory, press F2 (Toggle) then F3 (Enter).

PULSE TESTING OUTPUTS

Pulse Testing verifies the ability of outputs on a discrete block to change state. Pulse Testing also indicates whether output circuits (wires, power sources, loads) will start or stop current flow. Pulse testing is recommended for blocks controlling outputs that seldom change state. It provides assurance that when needed, an output will operate correctly. Blocks that control outputs which frequently change state do not need to use the Pulse Test feature. Pulse Testing does not provide enough energy to activate mechanical devices such as motor starters, relays, or solenoid valves, but may change the state of a very small load.

Executing a Pulse Test

The block being Pulse Tested must be the active block.

1. Press F2 from the Home menu to display the Analyze functions menu:

```

F1 : MONITOR BLOCK
F2 : MNTR / CTRL REF
F3 : BLOCK / BUS STS
F4 : PULSE TEST
  
```

2. Press F4 (Pulse Test) from the Analyze menu. The display shows:

```

PULSE TEST
REFS      33 - 48 01
NO FAULTS
exec
  
```

Line 2 shows the block's reference numbers and I/O configuration. Line 3 shows whether faults are associated with any I/O references.

3. Press F1 (Execute) to pulse all outputs on the block once. If the word **FAULTS** appears, it means that one or more diagnostic errors have occurred. Go to the Monitor/Control menu to display the specific type of fault that has occurred. It will be one of the following, *depending on the block type*:

```

  FAILED SWITCH
  SHORT CIRCUIT
  NO LOAD
  LOSS OF I / O POWER
  
```

For more information, refer to the fault definitions on the previous page. The fault message must be cleared.

Clearing Faults on the Active Block

If you press the CLEAR key from the Pulse Test screen, *all faults on the block* will be cleared.

If you press the Clear key from the Monitor/Control screen (after displaying a specific circuit fault), only that fault will be cleared.

Pulse Test Error Messages

If the Pulse Test cannot be performed or if the block fails to respond, an error message appears. Press the Clear key to remove the message.

E : PUL TST DISABLE

A Pulse Test cannot be performed unless the block's configuration is changed.

E : INVLD BLK TYPE

The block does not support Pulse Tests.

E : INVLD BLK CONFIG

The active block is an inputs-only block.

E : PULSE TEST FAIL

The HHM has not received an acknowledgement from the block within the predetermined amount of time. Retry the test. If it continues to fail, check the serial bus cable and active block.




Figure 1. USER ITEMS

1. BATTERY Light

Steady On: Battery Normal

Flashing: Battery Low: The CPU continues running. No. 2 (advisory) alarm is activated. To protect the memory contents, replace the battery before it fails. When the light begins to flash, battery failure will occur in approximately 30 days.

Steady Off: Battery Failed: CPU continues running, but will not restart if stopped. No. 2 alarm remains activated. Memory contents will be lost when power is switched off or lost.

2. PARITY Light

On: Internal Memory, Register Memory and Logic Memory Parity are OK.


Off: Internal Memory and/or Register Memory or Logic Memory parity error occurred when reading memory. An error message appears on the Workmaster® Computer display or in the work area of the Program Development Terminal display. Causes CPU to stop.

3. Lithium-Manganese Dioxide Battery**4. Battery Connectors****5. External Auxiliary Battery Select****NOTE**


For battery replacement information, consult the Series Six Plus Installation and Maintenance Manual, GEK-96602.

a43011

WALL OR PANEL MOUNTING DIMENSIONS




CPU, 1/0 13" RACK OUTLINE




a43011

WALL OR PANEL MOUNTING DIMENSIONS



CPU, 1/0 13" RACK OUTLINE
2 OF 2



MODULE INSTALLATION

Prior to installing the CCM2 or CCM3 module into the Series Six Plus PLC rack, set the backplane DIP switch package to all positions OPEN for the module installation location. (slot 5 or 6)

PRODUCT ENHANCEMENTS

Several new features and enhancements are available to the user with this release. A brief description of the Series Six Communication Control Module (CCM2, CCM3) features and enhancements are as follows:

Expanded I/O Reference: A new method of addressing the I/O points within the Expanded Instruction Set has been devised to allow access of additional I/O points. This feature allows addressing of channelized I/O points available with the Series Six expanded instruction set. The I/O points can be accessed by both the CCM protocol and Remote Terminal Unit (RTU) protocol for CCM3, and the CCM protocol only for CCM2. CCM also supports addressing of the Auxiliary I/O Override table. Refer to the attached documentation, Table 1, which shows the I/O addressing for CCM and RTU protocols.

Expanded User Memory Reference: The expanded II instruction set allows memory addressing up to 64K of the user logic memory. The expanded user logic memory is supported by the CCM protocol.

Single Bit Write: The CCM2 and CCM3 offer a single bit write feature that may be used on the input, output, auxiliary input, auxiliary output and auxiliary override tables in the Series Six PLC. This feature has been added to the CCM protocol, and will permit the user to set, clear, or toggle a bit. Refer to Table 2, which lists the new memory types allocated for the single bit write feature.

Programmable Timeouts and Retrys: This feature allows timeout and retry value programming for the CCM protocol. Four SCREQs have been defined to allow timeouts and retrys to be programmed for both ports. Refer to Table 6, which shows the format of the new SCREQs allocated for this feature.

DOCUMENTATION

Addendum pages for GEK-25364 Series Six Data Communication Manual explain the enhancements for Communication Control Module (CCM2, CCM3).

Pages 1 and 2: Shows mapping between Series Six channeled I/O and CCM and RTU points. Contains examples to show how to map Series Six I/O points to CCM and RTU points.


Pages 3 and 4: Lists the new memory types which define the target table and the bit write operation. Defines the bit write function invoked by the new SCREQ command in the ladder logic program. Shows the CCM protocol processing the bit write function.

Page 5: Lists the New SCREQs and default values for programmable retry and timeout values for the CCM protocol.

Affix the addendum documentation in your GEK-25364 manual for future reference.

Block Type B

If the block should operate as two 24-bit counters, "Type B" is selected during block configuration.



Each Type B counter has six inputs and two outputs, and may be separately configured for Up/Down, Pulse/Direction, or A Quad B operation.

Details of each Type B counter are shown at right. Each counter has two completely independent sets of Strobe inputs with storage registers and on/off Presets for each output. The Disable input, which is not available in the Type A configuration, can be used to inhibit counting.

The Disable input is level sensitive, and active high. All other inputs are edge-sensitive. Each Strobe input can be configured to be active on either the rising or the falling edge.


The Strobe inputs always use the 0.0025mS

high-frequency filter. A high-frequency filter or a 12.5mS low-frequency filter can be independently selected for each of the following signals:

1. Preload input
2. "Disable" input
3. Both count inputs

The low-frequency filter reduces the effect of signal noise. Maximum count rates are 200 KHz with the high-frequency filter and 40 Hz with the low-frequency filter.

Elements of a Type B Counter (2 per block)



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL