

A1 INJECTION SHEET CHECKING PROCEDURE



A2 DE 10 INJECTION



A3 DPS ENGINE

Technical support

Ares 507-607

Chapter A

60 05 031 190 – 06.2005 publication

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



Measurement and checking points

This sheet is intended to be duplicated and completed for each operation on the tractor. If you have to send it to the manufacturer's after sales service, it is essential to indicate:

Tractor type:

Serial n°:

Engine serial n°:

Total operating hours:

Date of operation:

Transmission type:

Checking operations

Concerns operations 2, 3, 4, 6, 7.


	Checking operation	Check
Engine	Oil level	
	Air filter	
	Diesel filter	
	Battery (volt)	
Transmission	Oil level	

Record of inspection results

	Start of test	End of test	Reference values (bar)
Hydraulic pressure 1			See appendix
Hydraulic pressure 2			
Hydraulic pressure 3			
Outside temperature			—
Transmission temperature			60°C → 65°C
Engine temperature			> 87°C
Diesel temperature			



Ares 657 – H 8262
 DPS 6068 TRT 71 engine
 Nominal speed 2 200 rpm



- Supply system Suction
- Supply system Supply pump pressure
- Discharge line
- Return line

162msm01r

FUEL SUPPLY LINE DATA

1 Main fuel tank:	250 litres	6 Stanadyne rotary injection pump type DE 10. Electronically controlled.
2 Filter:	149 microns	
3 Mechanical supply pumps.		7 Stanadyne staggered injection injectors 9.5 mm holder body (type 35107) Set pressure on injector: 250 bar.
4 Fuel pre-filter:	10 microns	
5 Filter:	2 microns	

DYNAMIC TIMING


Electronic management.

TEST CONDITIONS

- Refer to inspection procedure.
- Measure to be taken with visco-coupler **blocked**.


NOTE

– Reference values: measurements made on a tractor, closed central system with 100 l/min, fitted with pneumatic brakes and air conditioning, at an ambient temperature of 25 C with the viscous clutch **blocked**.




Description

Engine computer inputs and outputs




161msm24

Fig. 14



Additional technical details

Fuel booster system




161msm41

Fig. 32

Nomenclature

- 1 Fuel supply.
- 2 Transfer pressure regulator.
- 3 Charge accumulator.




Crankshaft position sensor

Measurement and checking points

Checking with Win Métadiag[®]

See chapter "G6".



582msm06

Fig. 54

Nomenclature

B2 Crankshaft position input.
D2 Sensor return.


1 Engine control unit.
2 Crankshaft position sensor.

Checking the resistance with a multimeter

Remove the engine control unit connector then measure the resistance between points "B2" and "D2" using multimeter n° 60 05 005 744.


Resistance: $3 \pm 0,3 \text{ k}\Omega$.

The shim wheel is composed of 46 teeth uniformly spaced and of 2 missing teeth which determine the high neutral position.



Technology of moving parts

Rings




121msm04


Fig. 10

The top compression ring is as close as possible to the top of the piston to reduce waste space. This has necessitated the use of an insert that has better temperature resistance. An accumulation groove between the top compression ring and the compression ring gives the gases a greater expansion volume. The top compression ring thus remains in contact with its bearing surface, reducing the passage of gas to the lower part of the engine.

1. The top compression ring is trapezoid shaped with a contact face of the barrel type. It is marked with a dot (A).
2. The compression ring has a trapezoid cross-section, with a skewed contact face. It is marked with 2 points (B).
3. The oil control ring has a classical shape.




Tightening torques



101msm24


Fig. 29



Check

Oil consumption

Table of acceptable oil consumption




Nomenclature

- 1 Excessive oil consumption.
- 2 Oil consumption remaining acceptable.
- 3 Oil consumption acceptable.

Complaints about oil consumption are usually expressed in the number of liters used daily. This information is not very specific. The following questions must be asked:

- How many hours in a day ?
- On the day in question, what was the engine operating load ?

A more satisfactory method for assessing oil consumption requires comparing the quantity of oil used and quantity of fuel burnt (see table). Long-term consumption (3 oil changes after engine running-in) must not exceed 0,95 l oil for 379 l fuel burnt.



Removal/refitting

Separate engine/gearbox

N.B.: Bleeding the air conditioning and coolant circuit is not required for engine/gearbox separation.

- Untighten the 10 screws (1) and disconnect the two connectors behind the instrument panel upholstery, as well as the grounding wire (refer to chapter "H2"), (the air conditioning/heating block follows the engine upon separation).

Elements to remove to allow separation:

- Remove the left-hand side step and tank.
- Disconnect the harnesses and piping embarrassing decoupling.
- Fit the decoupling trolley.

N.B.: Adjust the various stops of the uncoupling assembly to separate properly the engine to facilitate the assembly recoupling.

- Untighten the screws (2) and (3).
- Separate the engine/gearbox assembly.

Removing the engine

- Perform preliminary operations and "engine/front axle separation".
- Remove all elements preventing engine removal.

N.B.: Bleed the air conditioning.

- Position a prop under the transmission.

Note: To ensure safety, use a hoist adapted to the engine's weight: 600 kg.

- Unscrew screws (2) and (3) and pull the engine out.

For refitting, perform the reverse sequence of operations while tightening screws (2) and (3) to their proper torque. Refer to the chapter "Tightening torques".




101msm02r

Fig. 73




641msm19

Fig. 74



101msm25

Fig. 75



Removal/refitting

Reassembling pistons and connecting rods

N.B.: The pistons must be reassembled in the liners they were extracted from.

1. Smear the pistons and rings with clean engine oil. Fit the pistons into the liners using the ring compressor No. 77 01 388 111 (1).

N.B.: Check for each piston that the mark "FRONT" (A) on the upper face of the piston is turned towards the front of the cylinder block.

2. Push the piston into the liner until the upper ring is fully inside it.

Assembling the cap onto the connecting rod

1. Smear the half-bearings with clean engine oil, then assemble the cap onto the connecting rod with the pins (A) on the same side.

Important: Ensure that the cap is correctly aligned on the connecting rod with the junction surfaces perfectly coupled.

2. Dip the connecting rod bolts in clean engine oil and fit them.


Important: Never use the connecting rod bolts more than once for the final assembly of the engine. When connecting rod bolts have been tightened at final torque, do not reuse them.

3. Tighten the bolts alternately at 5,8 daN.m, then turn each bolt at a 90-100 degree angle. Refer to the chapter "Tightening torques".

Tightening method


1. Position the wrench in parallel the engine axis (A).

2. Tighten the bolt until the wrench is perpendicular to the engine axis (B).




121hsm12

Fig. 115




121hsm11

Fig. 116



121hsm13

Fig. 117



Removal/refitting


Reassembly of the balancer shafts

– Smear with clean engine oil the balancer shaft bushes in the cylinder block, as well as the shaft journals.

Important: Do not swap the shafts if the pinions are removed from the shafts on removal, and if they are swapped over, fit new bushes.


– Fit the balancer shafts and the stop plates, and tighten the bolts (B) to 4 daN.m (Fig. 159).

– Fit the counterweights (A) onto the balancer shafts on the bladed side (C). The counterweights must be opposed to the keys (D) (Fig. 160 and 161).




111hsm15

Fig. 159




111hsm14

Fig. 160



111hsm25


Fig. 161




Diagnostic Sheets

"Excessive oil consumption" sheet


Prior to this procedure, check the sealing on the outside pipes and the cap seals.





"Hexashift" module

Description



326msm90


Fig. 4

The "Hexashift" module is composed of:

- Speed increaser gearing (1a)
- Module 4 PS (1b).

The multiplier (1a) is mainly composed of an epicyclic gear train (3) and a brake clutch (F/E).


The module 4 PS is mainly composed of 2 epicyclic trains 1 primary train (1), 1 secondary train (2) and 2 brake clutches (respectively (B/A) and (D/C)).



Robot-driven ranges module


Kinematics range "A"

The reduction ratio is 0,1.



326msm1n

Fig. 28




326msm1o

Fig. 29




Characteristics GBA 25

Transmission type	GTA 2522		GTA 2523
Speed increaser gearing			
Number of clutch discs "B"			4
Number of brake discs "A"			3
Number of satellites			3
Module 4 PS			
Number of clutch discs "D"			3
Number of brake discs "C"			3
Number of satellites 1st epicyclic train gear			4
Number of clutch discs "F"			3
Number of brake discs "E"			3
Number of satellites 2nd epicyclic train gear			4
Shuttle reverser			
Number of rear clutch discs, diameter 172,5 mm			6
Number of front clutch discs, diameter 172,5 mm			6
Robot-driven ranges module			
Upper line			
Synchronizer			Single cone
Ram control			Staged jack without spring device
Lower line			
Synchronizer			Double cone
Ram control device			Staged jack with spring device
Range train "D"	40 km/h	46/38	47/37
	50 km/h	50/35	51/24
Crawler ranges module			
Number of satellites for slow			3
Number of satellites for extra slow			5 + 3




"Hexashift" module



326msm14


Fig. 79

- Turn over the multiplier housing (66).
- Remove the cover (94) marking its position.
- Recover the friction washer (91).
- Pull on the shaft (79) to remove the clutch "E" and brake "F" assembly.
- Loosen the screws (77) of the cover (78) in order to completely remove the clutch "E" and the brake "F".
- Recover the final brake disc (85).
- Remove the piston (81) using a jet of compressed air.
- Remove the planet-carrier (73).
- Recover the bush (71).
- Remove the ring gear (70).



326msm15

Fig. 80



326msm16


Fig. 81



Robot-driven ranges module

Nomenclature


- | | | |
|-------------------------|--|--|
| 1 Cover. | 32 Range "C" driving pinion and range "A" driven pinion. | 61 Spring. |
| 2 Range "D" stop nut. | 33 Locking ring. | 62 Bearing cup. |
| 3 Range "C" stop nut. | 34 Washers. | 63 Bearing cone. |
| 4 Range "B" stop nut. | 35 Roller bearings. | 64 Retaining ring. |
| 5 Range "A" stop nut. | 36 Retaining ring. | 65 Washer. |
| 6 Stop covers. | 37 Range "C" and "D" single cone synchroniser. | 66 Shims. |
| 7 Stop screw. | 38 Bush. | 67 Shouldered bushing. |
| 8 Screws. | 39 Range "D" driving pinion. | 68 Bearing cup. |
| 9 Prevention lock. | 40 Bearing cone. | 69 Bearing cone. |
| 10 Cam followers. | 41 Bearing cup. | 70 Bearing cone. |
| 11 Locating pin. | 42 Locking ring. | 71 Bearing cup. |
| 12 Locating pin. | 43 Sealing ring. | 72 Range "A" and "B" driven pinion. |
| 13 Shims. | 44 Retaining ring. | 73 Range "A" driving pinion. |
| 14 Bearing cup. | 45 O-rings. | 74 Needle bearing. |
| 15 Bearing cone. | 46 Cover. | 75 Lower shaft. |
| 16 Reverse gear pinion. | 47 O-ring. | 76 Range "A" and "B" double cone synchroniser. |
| 17 Bearing cone. | 48 Piston. | 77 Locking ring. |
| 18 Bearing cup. | 49 Retaining ring. | 78 Range "A" and "C" driven pinion. |
| 19 Shims. | 50 Guide rod. | 79 Spacer. |
| 20 Bearing cup. | 51 O-ring. | 80 Range "D" driven pinion. |
| 21 Bearing cone. | 52 Piston. | 81 Bearing cone. |
| 22 Upper shaft. | 53 O-ring. | 82 Bearing cup. |
| 23 Retaining ring. | 54 O-ring. | 83 Guide rod. |
| 24 Washer. | 55 Fork for ranges "C" and "D". | 84 Fork for ranges "A" and "B". |
| 25 Shims. | 56 Pin. | 85 Locking ring. |
| 26 Bearing cup. | 57 Plug. | 86 Inner piston. |
| 27 Bearing cone. | 58 Shims. | 87 O-rings. |
| 28 Bearing cone. | 59 Lubrication tube. | 88 Retaining ring. |
| 29 Bearing cup. | 60 O-ring. | 89 Spring. |



Robot-driven ranges module


Adjusting the prevention lock

- Place the gearbox in neutral.
- Fully tension the lock (9).
- Apply Frenetanch (242) to the threaded section.
- Slacken the lock to allow the selection of only one gear.
- Leave the other control rod in neutral.
- Tension the lock with a functional minimum play.
- Tighten the lock-nut.
- Using a 22 long socket machined to an outside diameter of 28 mm:
- Fit the sensors and their plungers.
- Using the sensor control LEDs of control unit No. 60 05 006 155, check that 2 ranges cannot be selected at the same time.




326msm84

Fig. 152



Low pressure circuit 20 bar

Description



394msm03

Fig. 1

The low pressure circuit maintains a pressure of 20 bar. It allows notably to supply the:

- 3 "Hexashift" solenoid valves: PSV1, PSV2, PSV3* or SV1, SV2, SV3
- 2 proportional forward solenoid valves: PSVF, PSVR
- 4 "on/off" solenoid valves of robot-driven ranges: SVA, SVB, SVC, SVD.


The flow supply of the low pressure circuit depends on the high pressure hydraulic circuit fitted on the tractor.

A 60 micron filter protects the solenoid valves.

The accumulator fills the low pressure circuit upon major flow requirements at low engine speed.


Low pressure is monitored electronically by a 9 bar pressure contact.


* The proportional solenoid valves of the "Hexashift" PSV1, PSV2, PSV3 are now all or nothing solenoid valves from the Ares serial number A0301184 for Ares 607 and A0500884 for the Ares 507.



Open center 60 l/min

Hydraulic diagram






Control unit GBA 25 measuring and checking points

Test conditions:

- Engine at nominal speed.
- Oil temperature 60 °C.

Checking the “Hexashift” module feed pressures

- Connect the tester n° 60 0570 507 6 to the pressure connection “PSV1/SV1”, “PSV3/SV3” and “PSV2/SV2”.
- Engage the 6 gears in turn.
- The pressure should be 18,5 bar on the corresponding solenoid valves.



394msm15

Fig. 40

Test conditions Transmission oil temperature: 60 °C Engine running at 2 000 rpm	PSV1/SV1		PSV3/SV3		PSV2/SV2	
	Pressure in bar	Solenoid valve supply	Pressure in bar	Solenoid valve supply	Pressure in bar	Solenoid valve supply
First speed	18,5	0,8 A	0	0	18,5	0,9 A
Second speed	0	0	0	0	18,5	0,9 A
Third speed	18,5	0,8 A	0	0	0	0
Fourth speed	0	0	0	0	0	0
Fifth speed	18,5	0,8 A	18,5	0,8 A	0	0
Sixth speed	0	0	18,5	0,8 A	0	0




"Load sensing" 110 l/min measuring and checking points

Test conditions:

- Engine at nominal speed.
- Oil temperature 60°C.


Lubrication / boost pressure check

- Connect tester n° 60 05 705 076 to the pressure coupling (7) of the right-hand cover or to the coupling (10) of the lubrication tank.
- The pressure should be $6,3 \pm 1$ bar ($5,5 \pm 1$ bar at 1 000 rpm) (Fig. 57).
- The pressure should be 3,5 bar (Fig. 58).




391hsm55

Fig. 57




395msm09

Fig. 58




Electronic transmission control

Communication network



60cmsm00

Fig. 3



Gearbox electronic control

The management of the reverser under torque obligatorily requires the following functions:


- Power supply
- Gears and safety.

Pin	Function	State	Condition
Auto 5.53			
41	Temperature probe supply	0 V	Master switch on
21	Transmission temperature	0 V to 5 V	Master switch on
23	Driver seat contact	12 V	Driver sitting on the seat
27	Temperature indicator On	12 V	Temperature too high
Auto 5.52			
21	Transmission oil pressure	0 V	Pressure OK
13	Pressure indicator On	12 V	Pressure too low
Auto 5.51			
2	Sensor supply	10 V	Master switch on
41	Sensor supply	0 V	Master switch on
1	Power supply of forward proportional solenoid valves	12 V	Contact On, reverter in neutral, pedal not fully declutched
30	Pedal fully declutched	12 V	Contact On, reverter in neutral, pedal not fully declutched
20	Lever in reverse	12 V	Lever in reverse
16	Lever in forward	12 V	Lever in forward
19	Lever neutral	12 V	Lever neutral
35	Lever raised	12 V	Lever raised
37	Theoretical forward speed	Hz	Tractor in motion
38	Speed reverter output under torque	Hz	Tractor in motion
34	Clutch pedal position	0,5 V to 4,5 V	According to pedal position
26	Diagnostic indicator On	12 V	Gearbox fault
12	Horn On	12 V	Gearbox fault
3	Feedback from rear proportional solenoid valve	$0 < \dots < 0,8 \text{ A}$	Tractor in reverse
6	Supply of rear proportional solenoid valve	$0 < \dots < 0,8 \text{ A}$	Tractor in reverse
4	Feedback from forward proportional valve	$0 < \dots < 0,8 \text{ A}$	Tractor in forward
5	Supply of forward proportional solenoid valve	$0 < \dots < 0,8 \text{ A}$	Tractor in forward
Full Auto 5			
39	CAN communication	—	
40	CAN communication	—	



Gearbox electronic control

"Overdrive"




60csm19

Fig. 20

Nomenclature

- 24** Engine electronic central unit DE 10.
- 170** "Auto 5" electronic central unit.
- 197** Accelerator pedal sensor.



Electrical tests

"Auto-5" electronic unit

Voltage test (on connection concerned)

Test conditions:

- Power on.
- Energise the input or output to be checked.
- Check the unit's input and output voltage depending on the relevant operating state.
- Connect a multimeter n° 60 05 006 744 (voltmeter function) in parallel.
- Use tool n° 60 05 033 250 to connect to the connection concerned.

Frequency test (on connection concerned)


Test conditions:

- Power on.
- Activate the input to be checked.
- Check the unit's input voltage against the relevant sensor state.
- Connect a multimeter n° 60 05 006 744 (frequency meter function) in parallel.
- Use tool n° 60 05 033 250 to connect to the connection concerned.

Current test (on connection concerned)


Test conditions:

- Power on.
- Activate the output to be checked.
- Check the increase in the current supplied at the output from the unit.
- Connect a multimeter n° 60 05 006 744 (ammeter function) in series.
- Use tool n° 60 05 033 250 to connect to the connection concerned.




601msm09

Fig. 39




601msm10

Fig. 40



601msm11

Fig. 41




"Shuttle reverser" measurement and checking points

Checking the reverser selector (188)

See electrical tests, controller for details of the checking procedure.

- Two magnets (x) and (y) are located on the reverser selector on either side of the hinge with contacts on an electronic testing board.
- Voltages checked according to the following control logic.



601msm18

Fig. 58

Position	Ignition		B4 (solenoid valves)	A4 (rear)	A2 (front)	B2 (neutral)	A5 (rise)
	x	y					
Forwards	2	—	12 V	0 V	12 V	0 V	0 V
Neutral	3	1	0 V	0 V	0 V	12 V	0 V
Reverse	4	—	12 V	12 V	0 V	0 V	0 V
Rise	—	1 or—	12 V	0 V	0 V	12 V	12 V

Checking the "BOC" low clutch pedal switch

See electrical tests, supply circuit switch for details of test procedure.

- Pedal in high position, contact closed.
- Pedal in low position, contact open.
- Switch supplied at 12 volts by the controller.

Checking the theoretical speed and reverser output speed sensors (37) (27)

See electrical tests, variable reluctance induction sensors for details of test procedure.

Refer to "speed and security" function for test values.

"4-WHEEL DRIVE UNIT" MEASUREMENT AND CHECKING POINTS

CHECKING THE FRONT AXLE ENGAGEMENT SWITCH (234).....	C3.26
CHECKING THE FRONT AXLE ENGAGEMENT SOLENOID VALVE (101).....	C3.26

"DIFFERENTIAL LOCK" MEASUREMENT AND CHECKING POINTS

CHECKING THE FRONT AND REAR DIFFERENTIAL LOCK SWITCH (232).....	C3.27
CHECKING THE FRONA AND REAR DIFFERENTIAL LOCKING SOLENOID VALVES (102).....	C3.27

"POWER TAKE-OFF" MEASUREMENT AND CHECKING POINTS

CHECKING THE 3-POSITION REAR PTO SWITCH (53)	C3.28
CHECKING THE PTO SELECTOR SWITCH (54)	C3.28
REAR PTO EXTERNAL SWITCH (44).....	C3.28
CHECKING THE ECONOMICAL PTO SELECTOR SWITCH (42)	C3.29
CHECKING THE GROUND SPEED PROPORTIONAL PTO SELECTOR SWITCH (41)	C3.29
CHECKING THE REAR PTO SOLENOID VALVE (103).....	C3.29
CHECKING THE PTO BRAKE SOLENOID VALVE (104)	C3.30
CHECKING THE PTO SPEED SENSOR (39)	C3.31

"BRAKING" MEASUREMENT AND CHECKING POINTS

CHECKING THE SERVICE BRAKE SWITCHES (203)	C3.32
CHECKING THE PARKING BRAKE SWITCH (204) (TRANSMISSION 40 AND 50 KM/H)	C3.32
CHECKING THE BRAKE FLUID LEVEL SWITCH (214) (TRANSMISSION 40 KM/H)	C3.33
CHECKING THE CUT-OUT RELAY PRESSURE SENSOR (127) (TRANSMISSION 50 KM/H).....	C3.33
CHECKING THE VOLTAGE ADAPTER PLATE (128) (POWER SUPPLY OF THE CUT-OUT RELAY SENSOR)	C3.35
CHECKING THE CUT-OUT RELAY SOLENOID VALVE (126) (TRANSMISSION 50 KM/H)	C3.36



Presentation of the rear axle

Foot brake

For transmissions GTA 2522 and GTA 2523 the surface of brake filling increases by 56%.


Brake discs	40 km/h	50 km/h
Internal diameter (mm)	274	243
External diameter (mm)	343	355
Surface area (cm ²)	334	526

The tightness between the axle and the axle housing is now ensured by a shoulder and an o-ring.



343msg1

Fig. 21



"HD" axle tube

Refitting the roller bearings and seals

- Clean the seal bearing faces. The seal bearing faces, the cups and cones should be free from burrs and impacts.
- Coat the outside diameter of the seal (9) with Loctite Oléoétanche (542).


N.B.: Fit the seals the right way round.

Without replacing the shaft (2)

Important: So that the seal lip does not contact on the same position of the shaft, fit the seal at 5 mm from the cup shoulder (Fig. 40).


When replacing the shaft (2)

- Position the seal at 4 mm from the cup shoulder (Fig. 40).
- Lubricate and fit the bearing cups.
- Fit the bush (5) on the face of the axle tube, set back 2,9 mm (Fig. 39).
- Using a suitable jig, fit the 3-lip seal (3) into the wheel shaft.
- Lubricate the shaft (2) and fit the wheel-side cone (4).
- Grease the cone and lips of the seal moderately.
- Protect the splines of the shaft (2) and insert it in the axle tube.
- Shim as described in the procedure below.
- Grease via the plug or the grease nipple (12).
- Refit the axle tube (see relevant paragraph).




343msmc8

Fig. 39




343msmc9


Fig. 40



Crown wheel and pinion and differential

Sectional view





Crown wheel and pinion and differential

- Refit the spool valve support after having coated the sealing surface with Loctite Formajoint (510).
- Coat the threads of the 4 support attachment screws with Loctite Frenetanch (242).
- Tighten the support attachment screws to 5 to 7 daN.m.
- Refit the hydraulic covers previously removed (see chapter "E").
- Reconnect the PTO brake and lubrication supply hoses.
- Adjust the handbrake.
- Refit the cab (see chapter "H").
- Refit the hitch ladder.
- Adjust the power take-off controls (see relevant paragraph).
- Put the gear fork back in place.
- Glue with Loctite Frenbloc (270) and tighten screw (49).
- Set the crawler speed control (see chapter "B").
- Bleed the brake circuit (see relevant paragraph).
- Tighten the wheel nuts to 42 ± 2 daNm.
- Check the oil level of the casing.
- Test the tractor.




343msm57

Fig. 102




343msme4

Fig. 103



Rear power take-off upper shaft

Sectional view (540 and 1 000 rpm economy)




343msm78

Fig. 129

Nomenclature

- | | | |
|---------------------------|---------------------------|------------------------|
| 1 Power take-off clutch. | 19 Screws. | 37 O-ring. |
| 2 Screws. | 20 Cover. | 38 Lock screw. |
| 3 Power take-off shaft. | 21 Washer. | 39 Fork. |
| 4 Circlip. | 22 Needle bearing. | 40 Deflector. |
| 5 Sliding sleeve. | 23 21 sprocket pinion. | 41 Bearing. |
| 6 Bush. | 24 Fork. | 42 Bush. |
| 7 Shaft. | 25 Nut. | 43 66 sprocket pinion. |
| 8 Circlip. | 26 Screws. | 44 Pad. |
| 9 Bearing cup. | 27 Lock screw. | 45 Sliding gear hub. |
| 10 Bearing cone. | 28 Shaft. | 46 Operating sleeve. |
| 11 18/28 sprocket pinion. | 29 Washer. | 47 56 sprocket pinion. |
| 12 Deflector. | 30 Washer. | 48 Circlip. |
| 13 Bearing cone. | 31 Needle bearing. | 49 Locking ring. |
| 14 Bearing cup. | 32 28/31 sprocket pinion. | 50 Bearing. |
| 15 Piston. | 33 Spacer. | 51 Seal. |
| 16 O-ring. | 34 Needle bearing. | 52 Shaft. |
| 17 Shim(s). | 35 Plug. | 53 Stub shaft. |
| 18 Washer. | 36 Pin. | |



Proportional PTO

- Unscrew the nut (33).
- Remove the shaft (27) and the pinion (29).

Fitting shims to the shaft (27)

- Put the pinion (29) and the shaft (27) in place in the box.
- Assemble without shim (30) in order to obtain some play (Fig. 163).
- Tighten nut (33) to 20 daN.m.
- Measure the backlash.
- Shim in order to obtain preload of 0,05 and a play of 0,10 mm.




343msmf2

Fig. 161




343msmf4

Fig. 162



343msmf3

Fig. 163



Transmission service brake 50 km/h


– Coat the brake discs with a suitable oil.

Note: Check that the disc slides freely on the planetary.

- Carry out the tightness test (see relevant paragraph).
- Refit the axle tubes (see relevant paragraph).
- Purge the main brake circuit and the trailer brake circuit (if assembled) (see relevant paragraph).
- Perform the hydraulic and braking road tests.
- Check the seals on the dismantled elements.


Sealing test

Important: When intervening on the brake piston and O-rings, it is highly recommended to check the sealing.




The elbow couplers (5) on the transmissions 50 km/h have throats. In the event of exchange of these elbow couplers, they must be replaced by couplers of the same diameter.

- Keep the piston in place with the locally made tool (Fig. 190 and 191).
- Fit an air inflation nozzle (C) to a JIC (1/2-100) coupling (A) to be screwed onto the bend (5). Connect to a conventional inflation handle fitted with its pressure gauge and place a pressure release valve n° 60 05 005 310 upstream.
- Supply the circuit with 5-bar compressed air to ensure the proper operation of the piston.
- Reduce the pressure to 0,3 bar.
- Close the pressure regulator valve. For 1 minute, no pressure reduction should be noticed on the pressure gauge.
- Remove the pressure gauge. Remove the restraining tool.
- Connect the brake hose.




362msm07

Fig. 191



362msm02

Fig. 192



362msm08

Fig. 193



Transmission hand brake 50 km/h


Technical specifications

GTA transmission	2522	2523
Brake types	Oil immersed disk brakes	
Diameter of friction discs	165 mm	
Number of discs	5	
Control	Mechanical	

Exploded view


Nomenclature

- | | | |
|-----------------------|-------------------|-------------|
| 1 Circlip. | 14 Seal. | 27 Plate. |
| 2 Pinion. | 15 Washer. | 28 Nut. |
| 3 Screws. | 16 Circlip. | 29 Nut. |
| 4 Locating pin. | 17 Screws. | 30 Plate. |
| 5 Blanking plate. | 18 Support plate. | 31 Spring. |
| 6 Disc. | 19 Drive pinion. | 32 Link. |
| 7 Backplate. | 20 Crown wheel. | 33 Screws. |
| 8 Mechanism assembly. | 21 Pin. | 34 Ball. |
| 9 Disc. | 22 Pin. | 35 Circlip. |
| 10 Washer. | 23 Fork end. | 36 Cam. |
| 11 Circlip. | 24 Stud. | 37 Finger. |
| 12 Spring. | 25 Pin. | |
| 13 Pin. | 26 Link. | |



Braking 40 km/h

Brake valve "Iruna" plus "Booster"



362msm66

Fig. 7


Nomenclature

- | | |
|------------------------|---------------------------------|
| 1 Brake valve control. | 5 20 bar supply. |
| 2 Jar supply. | 6 Return. |
| 3 Brake controls. | A Brake valve. |
| 4 Balancing pipe. | B Power brake system "booster". |


When the brake pedals are operated, the 20 bar pressure is added to the force applied by the foot to help move the master cylinder.


Open center 60 l/min

Lubrication of the power take-off, the gearbox lower line and the bevel gear



Brake lubrication






60 l/min open centre measurement and checking points

Test conditions:

- Engine at nominal speed.
- Oil temperature 60°C.
- Without using actuators (steering, transmission, etc.).

Checking the flow coming from the steering box

- Connect tester n° 60 05 005 736 upstream of the distribution valve.
- Check the flow rate which should be 46 ± 5 l/min.




394msm16

Fig. 48

Checking the control pressure

- Connect tester 60 05 705 076 to the left-hand cover as illustrated below.
- The pressure should be 20 bar.



394msm17

Fig. 49



"Load sensing" 100 l/min "inspection results" sheet

This sheet may be copied and should be completed for each operation on the tractor. If it has to be returned to the manufacturer's after sales department; the following must be included:

Tractor type:

Serial n°:

Total operating hours:

Date of operation:

Checking the flow coming from the steering box

Test conditions Oil temperature 60°C	Flow in l/min	Measured value
Engine running at 2 200 rpm	46 ± 5	

Checking the control pressure

Test conditions Oil temperature 60°C	Pressure in bar	Measured value
Engine running at 2 200 rpm	20	

Cooler inlet flow rate check

Test conditions Oil temperature 80°C	Flow in l/min	Measured value
Engine running at 2 000 rpm	24 ± 2	

Cooler inlet pressure check

Test conditions Oil temperature 80°C	Pressure in bar	Measured value
Engine running at 2 000 rpm	6	

Checking the lubrication flow rate from the spool valves and the 10 cm³ pump


Test conditions Oil temperature 60°C	Flow in l/min	Measured value
Engine running at 2 000 rpm	30 ± 5	

Checking the rear axle lubrication pressure and flow rate

Test conditions Oil temperature 75°C	Pressure in bar	Measured value
Engine running at 2 200 rpm	3 to 4	
	Flow in l/min	Measured value
	35	

Transmission braking circuit (50 km/h version)

Purging the circuit




395msm75

Fig. 85

- Start the engine.
- Press on both brake pedals at the same time with moderate strength (30 daN).
- Unscrew the right brake purge screw (D), left brake purge screw (G), and the braking valve (I).

- Let the oil flow through a transparent tube until the air bubbles have disappeared.
- Close the purge valves and release the brake pedals.
- Check the firmness of the pedals.



Electronic rear axle control

Braking circuit solenoid valve control logic

Engine ignition phase


Pressure	Electrical state	Hydraulic state
All pressures	12 V	No inflation

Inflation phase after engine ignition

Pressure	Electrical state	Hydraulic state
< 90 bar	0 V	Inflation up to 105 bar
> 90 bar	12 V	No inflation

Engine running after inflation phase

Pressure	Electrical state	Hydraulic state
< 75 bar	0 V	Inflation up to 90 bar
> 90 bar	12 V	No inflation



"Power take-off" measurement and checking points

Checking the economical PTO selector switch (42)

See electrical tests, reed switch for details of checking procedure.

- Switch neutral, contact open between terminals "1" and "2".
- Switch actuated in the presence of a magnet on the economical speed selection lever, contact closed.
- Switch supplied at 12 V.

Checking the ground speed proportional PTO selector switch (41)


See electrical tests, supply circuit switch for details of test procedure.

- Switch at rest, proportional PTO disengaged:
 - Contact open between terminals "a" and "a+".
 - Contact closed between terminals "b" and "b+".
- Switch actuated, proportional PTO engaged:
 - Contact closed between terminals "a" and "a+".
 - Contact open between terminals "b" and "b+".
- Switch supplied at 12 V.

Checking the rear PTO solenoid valve (103)


See electrical tests, on/off solenoid valve for details of test procedure.

- Solenoid valve at rest (PTO disengaged).
- Solenoid valve powered (PTO engaged).
- Solenoid valve supplied at 12 V.




601msm29

Fig. 25



601msm30

Fig. 26




601msm33


Fig. 27



Main torques

Tightening torques and sealants





Bevel gear and differential

Removing the bevel gear and differential


- Immobilise the tractor (see "Preliminary operations prior to working on the front axle").
- Remove the front axle.

N.B.: To remove the drive pinion and differential lock assembly, the universal shafts must be removed beforehand.

- Drain the differential by unscrewing the plug (19) (Fig. 42).
- Remove the bearing (12) by unscrewing the screw (13).
- Extract the bushes (9), (10), (7).
- Remove the sealing bush (1).
- Loosen the bevel pinion nut (2) using tool n° 60 05 006 536.
- Support then remove the cover (16) containing the drive pinion and differential.
- Remove the screws (34) and locking tabs (35) and (57).
- Mark the differential bearing flanges (22) in relation to the cover (16) to avoid reversing them on refitting.
- Unscrew the slotted nuts (36) with tool n° 60 05 006 534 and nut (56) with tool n° 60 05 006 581 (axle 20.29-4).
- Remove the screws (23).


Note: Do not reverse the bearings of the differential bearing blocks if they are not replaced.

- Put the cover fitted with the bevel pinion in a vice.
- Hold the drive pinion.
- Unscrew the nut (2) from the bevel pinion and extract it.
- Extract the inner bush from the bearing with an extractor.
- Extract the outer rings from the bevel pinion bearings (4) and (18).



451hsm36

Fig. 40



451hsm34

Fig. 41



4 wheel drive unit

- Remove the cover (35), the discs (33) and the backplates (34).

N.B.: According to the tractor reference, the hub (30), the cover (35), the Belleville washers (31), the discs (33) and the backplates (34) may differ.

- Separate the hub (30) from the housing (32).
- Remove the O-ring from the hub (30).
- Remove the Belleville washers.
- Remove the two rings (12) (Fig. 66).
- Extract the cone (19) using a press and an appropriate installation.

Refitting the clutch

N.B.: All seals must be changed and lubricated on refitting.

N.B.: If the proportional power take-off gear (41) has been removed, tighten the screws to 11 daN.m with Loctite Frenetanch (242) (Fig. 59).

- Ensure that the duct of hub (30) is not blocked.
- Refit the Belleville washers (31) the the right direction (Fig. 67).
- Position the hub (30) in the clutch housing (32).
- Align the holes in the discs (33), the backplates (34) and the cover (35).


N.B.: To assist final fitting of the clutch, align the clutch housing on the disc, backplate, cover assembly (35) using 2 guide rods (A), without refitting the circlip (37) or the shims (36) and (9) (Fig. 68).

- Remove the bell pinion.



474msm07

Fig. 66




474msm08

Fig. 67




474msm09

Fig. 68



Epicyclic reduction gear and wheel hub

Exploded view



452msm09

Fig. 14

Nomenclature

- | | | |
|-------------------------------------|------------------|----------------------------|
| 1 Reduction gear cover. | 10 Circlip. | 20 Tapered roller bearing. |
| 2 Filling, dipstick and drain plug. | 11 Spacer. | 21 Washer. |
| 3 Wheel nut. | 12 Crown wheel. | 22 Stud. |
| 4 Screws. | 13 Screws. | 23 Half-hub. |
| 5 Universal shaft. | 14 Screws. | 24 Tapered roller bearing. |
| 6 Planet gear pins. | 15 Bush. | 25 Seal. |
| 7 Washer. | 16 Washer. | 26 Washer*. |
| 8 Needles. | 17 Sprocket. | 27 Locating pin*. |
| 9 Planet gear pinion. | 18 Locking ring. | |
| | 19 O-ring. | |

* Version 40 km/h only.



Suspension cylinder and lower arm

Refitting the torsion bar

- Using a jack, lift the lower arm as high as possible (tractor in low position) (Fig. 50).
- Lubricate the splines of the front flange (108).
- Before refitting the torsion bar (118), check the stamp on the end (Fig. 51).

SX : Left-hand torsion bar.

DX : Right-hand torsion bar.

The arrow indicates the direction of torsion bar rotation on preloading.

N.B.: The stamp should be located on the rear flange side (115).

- On the front flange side (108), introduce the torsion bar fitted with the circlip so that it is fully inserted in the flanges and flush up against the circlip.


N.B.: Observe the marks made earlier.

- Position the rear flange (115) and insert the screws, without tightening, so that they are at the base of the slot on the left-hand side (looking at the flange face-on).




452hsm35

Fig. 50



452hsm36

Fig. 51



452hsm37

Fig. 52

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



Bevel gear and differential

Adjusting the pinion gear pre-load


- Replace the washer (5) and the spacer (17).

N.B.: All preloads must be measured without the seal (1).

N.B.: This adjustment is only required on the pinion after fitting the 2 tapered bearings.

IMPORTANT: Do not tighten the nut in one go. Tap the ends of the pinion lightly with a hammer to seat the bearings correctly. A new spacer (17) must be fitted.

- The nut must be tightened gradually, without overtightening, using tool n° 60 05 006 536.
- Wrap the cord around the splined part of the gear (Fig. 75).
- Using spring balance n° 77 01 388 008, measure the force (P) required to drive the bevel pinion. It should be between 9,2 and 13,7 daN.
- Lock the nut by bending the lock washer.



451hsm39


Fig. 75

Adjusting backlash

- Refit the differential housing.
- Refit the flanges (22).

N.B.: Change the O-ring (55) on the differential lock aperture of axle (20.29 – SI12/SI14).

- Check the meshing backlash which should be between 0,18 and 0,23 mm.
- Repeat several times by checking a number of teeth. If the values differ, place the probe on the tooth where the lowest value was recorded.
- Apply the same torque to the differential bearing nuts. Use tools n° 60 05 006 534 and n° 60 05 006 581 (axle 20.29 SI12/SI14).
- Place the dial gauge probe at 90° with the surface of a pinion tooth.



451hsm40

Fig. 76



Measurement and checking points


Test conditions.

- Transmission oil temperature: 60°C.
- Engine running at nominal speed.

Checking the differential lock circuit pressure (axle 20.29-4)

In case of a front differential lock malfunction, check the following items:

- The front differential control circuit pressure.
- Correct solenoid valve operation.
- Check that the engine control unit is working correctly with Win Métadiag[®]. If the ECU sends information but the solenoid valve is not powered, check the continuity of the solenoid valve supply circuit (see chapter "F").
- Set up pressure gauge n° 60 05 705 076 and adapter n° 60 05 005 718.
- Measure the pressure by activating the differential lock button. The pressure should be 20 bar. If it is not equal to 20 bar, check on the right-hand cover whether the supply to the other 20 bar circuits is correct.
- If hydraulic oil leaks from the front differential locking system it will flow directly into the differential housing. A leak on the circuit can only be detected therefore by checking that the differential housing level is not above the maximum level.



453hsm68

Fig. 2



Measurement and checking points

Test conditions.

- Engine idling.
- Transmission oil temperature: 60°C.

Checking the front axle engagement pressure

- Remove the 4-wheel drive housing supply pipe and fit a hydraulic hose in its place.
- Connect pressure gauge n° 60 05 705 076 to the hose.
- Measure the pressure which should be 0 bar when the front axle is engaged.
- Measure the pressure which should be 20 bar when the front axle is disengaged.

A Open centre hydraulic circuit.


B Hydraulic circuit LS 100 l/min

C Hydraulic circuit LS 110 l/min




474msm16

Fig. 19



474msm17

Fig. 20



474msm18

Fig. 21



D3

ELECTRONIC COMPONENTS

RH COVER

EXTERNAL VIEW.....	E3.18
GEOGRAPHICAL LOCATION OF THE HYDRAULIC COMPONENTS ON THE PRIORITY UNIT.....	E3.19
PRESSURE LIMITER "DBV1" (210 BAR).....	E3.20
PRESSURE LIMITER "DBV2" (175 BAR).....	E3.20
NON-RETURN VALVE "RV2".....	E3.20
REMOVAL.....	E3.21
REMOVAL/REFITTING THE MAIN PUMP.....	E3.21
REPLACING THE RH COVER.....	E3.22

LH COVER

REMOVAL.....	E3.23
REMOVAL/REFITTING THE STEERING PUMP.....	E3.23
REFITTING.....	E3.23

CIRCUIT SELECTOR

DESCRIPTION ("LOAD SENSING" SIGNAL).....	E3.24
--	-------

HYDRAULIC MEASUREMENT AND CHECKING POINTS

PRESSURE CHECK FOR A FLOW RATE OF LESS THAN 40-L/MIN AND A FLOW RATE OF 60 L/MIN.....	E3.25
STANDBY PRESSURE CHECK.....	E3.25
TEST AT 20 L/MIN.....	E3.27
TEST AT 60 L/MIN.....	E3.27
MINIMUM/MAXIMUM FLOW RATE CHECK ON THE AUXILIARY SPOOL VALVES.....	E3.28
BRAKE VALVE CHECK.....	E3.28

"HYDRAULIC INSPECTION RESULTS" SHEET


CHECKING THE STANDBY PRESSURE OF THE 14 CM ³ PUMP.....	E3.29
CHECK THE PRESSURE FOR A REQUIRED FLOW LESS THAN 40 L/MIN AND A FLOW OF 60 L/MIN.....	E3.29
MINIMUM/MAXIMUM FLOW RATE CHECK ON THE AUXILIARY SPOOL VALVES.....	E3.29

HYDRAULIC MEASUREMENT AND CHECKING POINTS

MAXIMUM STEERING CYLINDER PRESSURE CHECK.....	E3.31
SHOCKPROOF VALVE OPENING PRESSURE CHECK.....	E3.33


"HYDRAULIC INSPECTION RESULTS" SHEET

STEERING PUMP CHECK.....	E3.34
MAXIMUM STEERING CYLINDER PRESSURE CHECK.....	E3.34
SHOCKPROOF VALVE OPENING PRESSURE CHECK.....	E3.34




Steering unit

"OSPF 160 ON" unit (100 l/min "Load Sensing" circuit and centre open 60 l/min)




364msm07

Fig. 13



Description

Operation



394msm70

Fig. 1

Nomenclature


- | | | | |
|---|--------------------------|----|---------------------------|
| 1 | 150 micron filter. | 7 | Steering unit. |
| 2 | 15 cm ³ Pump. | 8 | Oil cooler. |
| 3 | 19 cm ³ Pump. | 9 | Transmission lubrication. |
| 4 | 10 cm ³ Pump. | 10 | Spool valve unit. |
| 5 | 15 micron filter. | 11 | Trailer brake valve. |
| 6 | 15 micron filter. | | |

This 60 l/min centre open circuit is characterised by 3 hydraulic pumps.

A 19 cm³ pump supplies the braking valve followed by the auxiliary and linkage spool valves.

A 15 cm³ pump supplies first the steering unit, then the 20 bar services.

A 10 cm³ pump that continually lubricates the different transmission components.




Hydraulic measurement and checking points

Test conditions:

- Engine at nominal speed.
- Oil temperature at 60°C.


Steering pump check

- Connect the tester n° 60 05 005 736 to the steering filter outlet.
- Turn the wheels in one direction then in the other and measure the pressure when the wheels are at the end stops.
- The flow should be 45,8 l/min
- The pressure should be 175 bar when the wheels are at the end stops.



394msm02r

Fig. 15



Description


Engine running, flow demand above the capacity of the low rate pump

In this case, equality cannot be achieved between the low flow pump pressure and the LS pressure added to the stand-by pressure. The force of the spring pushes the balance, the slide moves into a position interrupting the backflow from the pumps to pump intake. The flow from the high flow pump will rejoin the operating system via non-return valve RV 2.

Low flow pump pressure = LS pressure + stand-by pressure.


High rate pressure = LS pressure + stand-by pressure + RV 2 check valve ΔP .

RV 2 = approximately 5 barars.




396msm69

Fig. 6




Hydraulic measurement and checking points



394msm04r


Fig. 27



Operation

Pressure/flow regulation


With the engine stopped



395msm58


Fig. 6

The pump, at rest, is at maximum displacement because of the action of the return spring.
 The 2 valves, 200 and 22 bar, are also held at rest by springs.




395msm59

Fig. 7



RH cover

Identification of ports and lines




395msm26

Fig. 25

Nomenclature (Fig. 25)

- A** Adjustment screw, 22 bar.
- B** Adjustment screw, 200 bar.
- C** Main filter, 15 micron.
- D** Boost.
- E** Rear axle lubrication only.
- F** High pressure from variable displacement pump.
- G** High pressure outlet of variable displacement pump.
- H** To variable displacement pump control piston.
- I** Regulator return.
- J** Return from priority unit(s) (depending on version).
- XLS** LS signal (Load Sensing).

N.B.: Screws (A) and (B) are factory set. Do not change these settings.



Hydraulic measurement and checking points


- Connect tester n° 60 05 705 076 to each diagnostic socket located:
 - On the pump regulator: Pressure XIs = P2
 - On the right-hand cover: Pump pressure = P3.

Regulator position	Engine speed (rpm)	Q2 (l/min)	P2 (bar)	P3 (bar)
Maximum	2 200	100 ± 10	P2 =-P3 22 ± 1	130
Minimum		5 ± 1		

- Turn the control of the regulator concerned slowly to the minimum limit; (Q2) should gradually fall to a minimum flow rate of 5 ± 1 l/min

Trigger pressure check on the (KO) spool valve

- Connect tester n° 60 05 005 736 to a spool valve.
- Connect tester n° 60 05 705 076 to the pump regulator to read: Pressure XIs = P2.
- Run the engine at 1 000 rpm. Actuate the spool valve in the kick-out position, release the lever and gradually close the flowmeter valve until the lever returns to neutral. Read the trigger pressure: P2 = 160 to 185 bar.








Conductor allocations

	Blue
1	+ AVC signalling control
2	D+ alternator
3	D+ instrument panel
4	Reverser engaged not in neutral
5	+APC transmission
6	Light relays controls
7	Start
8	Stop light output
9	Start-up controls
10	Stop light input
11	+ APC control panel
12	Hydraulic pressure warning light

	Grey
1	Parking position
2	+ AVC hazard warning light control
3	Front screen washer
4	+ AVC control panel
5	Windschr. wiper ctrl park. pos.
6	Flashing unit
7	+ P radio/cigar lighter
8	Power supply to indicator unit
9	+ APC rotating beacon control
10	Intermittent
11	+ APC hazard warning lights controls
12	+APC implement socket

	Brown
1	+ AVC engine calculator
2	+AVC REH
3	+ AVC socket 25 A
4	D+ REH
5	+ AVC socket 25 A
6	+ AVC suspended front axle
7	+ APC transmission controls
8	+ AVC transmission calculator
9	+ APC front PTO controls
10	+APC REH
11	+ APC engine calculator
12	+ APC transmission controls

	Red
1	Air conditioning relay controls (thermostat)
2	Air conditioning compressor (+)
3	Pressure switch
4	Not neutral
5	Non-neutral controls
6	—
7	+ APC reverser control ISC
8	+ AVC not switched
9	Recirculation (+)
10	Recirculation (-)
11	Recirculating controls
12	+ APC recirculation controls




605msm90

	White
1	Cuna braking solenoid valve
2	Hydraulic pressure
3	Cuna braking relay control
4	+AVC (constant source)
5	Outside rear work lights power supply
6	Safety solenoid valve
7	Outer work light relay control
8	+ AVC switched inside rear work lights
9	Outside rear work lights relay controls
10	Outside rear work lights power supply
11	+APC
12	Outside rear work lights relay controls


	Black
1	+ AVC ceiling light/radio/clock
2	+ P radio/clock/cigar-lighter
3	+ APC On-board computer
4	+ AVC accessories
5	Safety solenoid valve
6	Cab top mudguard lights
7	D+ on-board computer
8	+ AVC front work light
9	+ APC Electrohydraulic spool valve (DEH)
10	Outside front work light power supply
11	+ APC rear windscreen wiper control
12	Outside front work light relay control

	Green
1	+ P cigar-lighter
2	Earth
3	Left-hand lights
4	Left-hand lights
5	—
6	Right-hand lights
7	+ APC front windscreen wiper park position
8	Ventilation 3rd speed relay control
9	+ APC seat
10	Ventilation 3rd speed controls
11	+ APC windscreen wiper/washer control
12	+ APC ventilation

	P288
1	+ Interior front working lights
2	+ Side work lights



Instrument panel ventilation and climate control



605msm62




Electropilot - Front linkage

Ref	Item
110	Fuse box
141	Hydraulic spool valve control plate
142	RH electrohydraulic spool valve
143	LH electrohydraulic spool valve
144	Safety solenoid valve
168	External front linkage lift switch
169	External front linkage lower switch
255	Joystick - Solenoid pilot



Wire markers	2	J69	Ending
27	952	0,6 CAN-Low	J252 2
28	956	0,6 CAN-High	J252 5
29	981	0,6 +APC RH and LH DEH	P42 12
31	980	0,6 Safety solenoid valve ctrl	P42 2
32	951	0,6 CAN-Low	J251 2
33	955	0,6 CAN-High	J251 5
37	M9U	0,6 DEH earth	E6A
37	M9U*	1 DEH earth	E9A

* TCE 15/25 control




604msmY0


Wire markers	2	J199	Ending
1	9006	0,6 Potentiometer X	J198 9
2	9007	0,6 Potentiometer Y	J198 10
3	9002	0,6 +APC joystick	J198 3
5	9017	0,6 Safety solenoid valve (on)	J198 11
6	9005	0,6 CAN-High	P190 4
7	9010	0,6 Hydraul. motor ctrl (on)	J198 7
8	9011	0,6 Joystick on/off control	J198 5
9	9012	0,6 LED output on / off	J198 6
10	9004	0,6 CAN-Low	P190 1
11	9013	0,6 Raise extension command	J198 13
12	9014	0,6 Raise extension command	J198 16
13	M9X	0,6 Joystick earth	J198 19
14	9015	0,6 Relay output 1	J197 A1
15	9016	0,6 Relay output 2	J197 A5
16	9018	0,6 Hydraul. motor ctrl (off)	J198 8




604msmAj




606msmJ2




606msmH8



606msmJ3




606msmH7



606msmH9



Suspended front axle




605msm85

Ref	Item
110	Fuse box
170	"Auto 5" electronic central unit
295	Control solenoid valve
296	RH cylinder solenoid valve
297	LH cylinder solenoid valve
303	Suspended front axle central electronic unit
304	Automatic/locking switch
305	Rise/lower switch
403	LH suspension sensor
404	RH suspension sensor


Wire markers	2	J182	Ending
2	482	1	Front axle lower ctrl
3	483	1	Front axle rise ctrl
4	484	1	Lock ctrl
5	485	1	Automatic ctrl
6	486	1	+ AVC suspended front axle
8	488	1	+ APC suspended front axle
9	M4E	1	Front axle controller earth
10	M4F	1	Front axle controller earth
11	491	1	Front axle indicator light
12	489	1	Speed information (14 km/h threshold)

1	2	3	4	5	6
	482	483	484	485	486
12	11	10	9	8	7




604msmM5


Wire markers	403/404
A	+APC
B	Signal
C	Earth



606msmM7



606msmM8




606msmM9






Cigarette lighter - Clock - Radio - Antenna - Cab light and spot



Ref	Item
13	Roof lamp
14	Lighting spot
60	Key ignition switch
79	Car-radio
80	Clock
83	LH loudspeaker
84	RH loudspeaker
86	Cigarette lighter
87	Radio antenna
110	Fuse box
111	Cab top fuse box
208	RH door light switch
209	LH door light switch

Wire markers	Wire	Wire	Wire	Ending
1	230	0,5	+ AVC ceiling light and spot	J286 1
2	231	1	+ P cab top	J286 2
6	223	1	Side light indicator	J286 5


Wire	Wire	Wire	Wire	Wire	Wire
11	9	7	5	3	1
228	218	224	222	232	230
229	227	225	223		231
12	10	8	6	4	2




604msmC7

Wire markers	Wire	Wire	Wire	Ending
1	M5E	0,5	Ceiling light earth	J64 3
2	M5N	0,5	LH door switch earth	209
3	M5O	0,5	RH door switch earth	208
4	M5X	0,5	Spotlight earth	J289 3


Wire	Wire	Wire	Wire	Wire	Wire
1	M5E	M5X	M5L	517	545
2	M5N		M5D	M5H	20
3	M5O	M5R		544	
				6	9
				12	15
				18	21



60bmsm19



* Version with manual air conditioning and without air conditioning with electric rearview mirror




60ems28

60csm47
* Version with manual air conditioning and without air conditioning with electric rearview mirror




25 A power socket

Ref	Item
82	25A power socket
110	Fuse box







Transmission calculator supply



Ref	Item
110	Fuse box
170	"Auto 5" electronic central unit





CONTENTS

1a - Instrument panel harness F2.4
 1b - Instrument panel adaptation harness F2.4
 1c - Climate control harness F2.4
 1d - Manual air conditioning or ventilation harness (without air conditioning) F2.4
 2 - Preheating control harness F2.18
 3/1a - 4 cylinder engine front harness F2.18
 3/1b - 4 cylinder radiator cowling harness F2.18
 3/2a - 6 cylinder engine front harness F2.18
 3/2b - 6 cylinder radiator cowling harness F2.18
 4 - Suspended front axle control harness F2.26
 5a - Cab top harness F2.28
 5b - Rotating beacon harness F2.28
 5c - Police plate lighting harness F2.28
 5d - Work light power supply harness F2.28
 7/1 - Closed centre circuit transmission harness - 110 litres - Pneumatic brake -
 Hydraulic brake - Italy (Cuna) F2.38
 7/2 - Closed centre circuit transmission harness - 110 litres or open centre - Pneumatic brake -
 Hydraulic brake - Italy (Cuna) F2.42
 8a - Pneumatic brake transmission control harness - Hydraulic brake - Italy (Cuna) F2.46
 8b - Proportional PTO control harness F2.46
 8c - ECO/POWER Hexactiv harness F2.46
 8d - ISO socket harness F2.46
 9/1a - TCE 15T Control harness F2.54
 9/1b - TCE 15T Harness F2.58
 9/2a - TCE 15/25 Control harness F2.60
 9/2b - TCE 15/25 Harness F2.64
 9/3 - Front lift control harness F2.66
 9/4 - Electrohydraulic spool valve control harness F2.68
 10 - On-board computer harness F2.70
 Shunt base

Abbreviations


+APC + After contact
 +AVC (constant source)+ Before contact
 + P + Parking
 4 WD 4 wheel drive
 AR Reverse
 AV Forwards
 CDE Control
 RH Right
 ECO Economy
 EV Windscreen wiper
 EXT Exterior
 LH Left
 GND Ground
 LS Loudspeaker
 INT interior
 SR Shuttle reverser
 LCD liquid crystal display
 LED Indicator light
 LV Windscreen washer
 ODB On board computer
 IP Instrument panel
 PTO Power take-off (PTO)
 POT Potentiometer
 REH Electro-hydraulic lift
 REF Reference
 TCE Electronic Tracto-Control
 IP Instrument panel
 TRANS Transmission
 ECU Central electronic unit
 W Engine speed information



1c - Climate control harness

Wire markers	2	P282	Ending
1	WH/BK	0,5	Recirculation control
2	WH/RD	0,5	Recirculation control
3	BK	0,5	Antifrost thermostat earth
4	RD/GN	0,5	Defrosting thermostat
5	RD/BK	0,5	+ APC recirculation controls
6	GN/BK	0,5	Power unit
7	AZ	0,5	Ventilation speed 1
8	BK	0,5	Control system earth
▼	—	—	—
11	GR/RD	0,5	Engine control
12	GR/BK	0,5	Engine control
13	VI	0,5	By-pass valve
14	BL	0,5	Valve setpoint
15	RD	0,5	Sensor REF
▼	—	—	—


18	8
	NO
	AZ
	VE/NO
	RG/NO
5	
RO	
	RG/NO
4	
BU	
	RG/VE
VI	
	BC/NO
GR/NO	
	BC/NO
9	1



604msmAW

Wire markers	2	P283	Ending
1	RD	4	Ventilation control
2	BK	4	Earth

1	RG
2	NO



604msmAX

Wire markers	Colour
AZ	Azure
WH	White
BL	Blue
GR	Grey
BK	Black
RD	Red
RO	Pink
GN	Green
VI	Purple

1d - Manual air conditioning or ventilation harness


Connectors	Designation
J112**	Air conditioning recirculation control
J287**	Recycling actuator
P17***	Instrument panel harness connection
P113**	Instrument panel harness connection

* Version without air conditioning ** Manual air conditioning version

Wire markers	2	J112	Ending
1	M1W	0,6	Recirculation LED earth
2	140	1	+ APC recirculation controls
3	141	1	Recirculation control
4	M1V	0,6	Air conditioning LED earth
5	138	0,6	+ APC air conditioning control
6	139	0,6	Air conditioning control
▼	—	—	—

With manual air conditioning option only

9	139	141	3
8	138	140	2
7	M1V	M1W	1
	4		




604msmD3

Wire markers	2	J287	Ending
1	WH	0,5	Recirculation control
2	WH	0,5	Recirculation control

With manual air conditioning option only

1	2
BC/NO	BC/RG




604hsmAT

Wire markers	2	P17	Ending
1	BK	3	Ventilation
2	YL	1	Ventilation speed 1
3	BR	2	Ventilation speed 2
4	WH	3	Ventilation speed 3

manual air conditioning

4	BC	MA	3
2	JA	NO	1




604msmBA

Wire markers	2	P113	Ending
1	GN	0,6	Air conditioning pressure relay control
2	VE/JA	0,6	Air conditioning control
3	RD	1	Recirculation +
4	BK	1	Recirculation -

With manual air conditioning option only

4	NO	VE/JA	2
3	RG	VE/NO	1



604msmBB



Wire markers	Colour
WH	White
YL	Yellow
BR	Brown
BK	Black
RD	Red
GN	Green



5a - Cab top harness



Wire markers	2	J169	Ending		
1	539	0,5	Side light relay controls (on standby)	J291	B7
2	M5V	0,5	Side work light relay earth (on standby)	J60	A2
3	557	3	+ Side work lights (on standby)	P286	21
4	—	—	—	—	—
5	558	3	+ Side work lights (on standby)	J292	2

manual air conditioning - Without air conditioning





604msmP8

Wire markers	2	J191	Ending		
1	536	1	Safety solenoid valve	P286	4
2	512	1	+ APC Electrohydraulic spool valve (DEH)	P286	8
3	M5T	1	DEH earth	J60	B5



604msmP9

Wire markers	2	J275	Ending		
1	571	0,6	CAN-Low	P137	6
2	569	0,5*	CAN-Low	J150A	5
3	—	—	—	—	—
4	572	0,6	CAN-High	P137	3
5	568	0,6	CAN-High	J150A	4
6	—	—	—	—	—




604msmR1

* Section = 0,6 for climate control version

Wire markers	2	J278	Ending		
1	573	0,6	Ventilation speed 1	P279	1
2	574	0,6	Earth	P279	2
3	575	0,6	+APC	P279	3
4	576	0,6	Sensor REF	P279	4
5	—	—	—	—	—
6	577	0,6	Pressure switch	P279	6
7	578	0,6	Ventilation setpoint	P279	7
8	579	0,6	Power unit	P279	8
9	580	0,6	Defrosting thermostat	P279	9
10	581	0,6	Hood grille temperature sensor	P279	10
11	582	0,6	LH cover sensor	P279	11
12	583	0,6	By-pass valve	P279	12
13	584	0,6	Air-conditioning unit outlet temperature sensor	P279	13
14	585	0,6	Overhead instrument panel temperature sensor	P279	14
15	—	—	—	—	—
16	586	0,6	Engine control	P279	16
17	587	0,6	Engine control	P279	17
18	588	0,6	Recirculation control	P279	18
19	589	0,6	Recirculation control	P279	19
20	590	0,6	Air conditioning compressor	P279	20
21	591	0,6	Line K	P279	5
22	—	—	Pilot	P279	21

With climate control option only



1	573	585	14
2	574		15
3	575	586	16
4	576	587	17
5			18
6	577		19
7	578		20
8	579		21
9	580	588	22
10	581	589	23
11	582	590	24
12	342C	595	25
13	583	591	26



604msmR2

Wire markers	2	J289	Ending		
1	—	—	—	—	—
2	546	0,6	+ AVC spotlight	P61	5
3	M5X	0,5*	Spotlight earth	E5A	

* Section = 0,6 for climate control version





604msmR3





8a - Pneumatic brake transmission control harness - Hydraulic brake - Italy (Cuna)

Wire markers	2	J1	Ending	
1	879	1	+APC solenoid valve supply	P119 12
2	891	0,6	Sensor voltage+	P119 6
3	874	0,75	Reverse drive solenoid valve return (PSVR)	P80 30
4	832	0,6	Forward drive solenoid valve return (PSVF)	J80 10
5	867	0,75	Forward drive solenoid valve (PSVF)	J80 26
6	868	0,75	Reverse solenoid valve (PSVR)	J80 27
7	823	0,75	Range solenoid valve A (SVA)	J80 5
8	875	0,75	Range solenoid valve B (SVB)	J80 23
9	828	0,6	PTO driver power supply	53
10	886	0,75	Range solenoid valve D (SVD)	E8B
11	—	—	—	—
12	862	0,6	Buzzer	P20 21
13	808	0,6	Tractor speed	J300 1
14	838	1	+APC auto 5	J136 B6
15	M8G	1	"Auto 5"	J68 B1
16	869	0,75	Forward motion control	P20 8
17	845	0,6	Switch S1 end-of-travel	J80 2
18	866	0,75	Switch S3 end-of-travel	J80 16
19	876	0,6	Neutral control	P20 1
20	870	0,75	Reversing control	P20 7
21	897	0,6	Solenoid valve monitoring range D (SVD)	E8B
22	857	0,75	Range solenoid valve C (SVC)	J80 24
23	824	0,75	Rear PTO solenoid valve	J80 8
26	852	0,6	Diagnostic indicator	P20 18
27	—	—	—	—
28	M8D	1	"Auto 5" (1)	J68 B6
29	871	1	+AVC auto 5	J136 A2
30	878	0,6	+APC solenoid valve supply	P119 12
31	892	0,6	Accelerator POT	P20 17
32	863	0,75	Switch S2 end-of-travel	J80 13
33	882	0,75	Switch S4 end-of-travel	J80 17
34	865	0,75	Clutch cursor sensor	P20 10
35	801	0,6	Lever raised	P119 4
36	827	0,6	+ Rear PTO speed sensor	J80 14
37	830	0,6	+ Tractor speed sensor	J80 12
38	889	0,75	+ Module speed ISC	J80 29
39	881	0,6	CAN-Low (diagnostic)	J233 2
40	880	0,6	CAN-High (diagnostic)	J233 5
41	893	0,6	Sensor voltage-	P119 5
42	837	1	+APC auto 5	J136 B7





604msmX6

Wire markers	2	J2	Ending	
1	8162	0,6	+APC	J67 B7
2	—	—	—	—
3	890	0,75	Solenoid valve feedback (PSV1)	Diode
4	826	0,75	Solenoid valve feedback (PSV2/3)	J80 22
5	822	0,75	(PSV3) solenoid valve	J80 21
6	884	0,75	(PSV2) solenoid valve	J80 37
7	883	0,6	Furrow control	J49 B4
8	814	0,6	4-wheel drive control	J45 1
9	829	1	+ APC driver	J67 A2
10	860	0,6	Crawler speed light	J150 12
11	821	0,75	Differential solenoid valve	J80 7
12	873	0,6	Rear PTO light	P20 15
13	834	0,6	Hydraulic pressure	P20 16
14	887	1	+APC auto 5 (2)	J136 A6
15	M8H	1	"Auto 5" (2)	J68 B2
16	817	0,6	Rear PTO stop (wing)	P20 6
17	896	0,6	PDF 1 000 rpm	54
18	812	0,6	Range - control	J49 A4
19	810	0,6	LH stop	P20 13
20	841	0,6	Range change	J49 B2
21	833	0,6	Pressure switch (20 bar)	J80 3
22	861	0,6	Crawler speed	47
23	877	0,75	(PSV1) solenoid valve	Diode
24	8001	0,6	Differential indicator	J150 13
25	825	0,75	4-wheel drive solenoid valve	J80 6
26	8000	0,6	4 wheel drive light	J150 10
27	—	—	—	—
28	M8F	1	"Auto 5" (2)	J68 A7
29	850	1	+AVC auto 5 (2)	J136 B3
30	818	0,6	Rear PTO clutch control	53
31	885	0,6	Up position TCE	P20 4
32	811	0,6	Range + control	J49 A2
33	819	0,6	PTO Eco	42
34	816	0,6	RH brake light	P20 12
35	815	0,6	Differential control	J46 1
36	898	0,75	Gearbox input speed sensor	J80 33
37	894	0,75	Pressure switch (5 bar)	J80 25
38	831	0,6	Engine speed	J80 11
39	803	0,6	CAN-Low	J307 2
40	802	0,6	CAN-High	J307 5
41	—	—	—	—
42	888	1	+APC auto 5 (2)	J136 A5



604msmX7

Wire markers	2	J45	Ending	
1	814	0,6	4-wheel drive control	J2 8
5	846	0,6	+APC 4-wheel drive control	J67 A3



604msmX8




9/2a - TCE 15/25 Control harness

Wire markers	2	J71	Ending
1	—	—	—
2	914	0,75	Down valve voltage+
3	M9E	1*	TCE
4	M9F	1*	TCE
5	913	0,75	Up valve voltage-
6	912	0,75	Down valve voltage-
7	905	0,6	+ APC backligh
▼	—	—	—
12	921	0,6	CAN-High return
13	922	0,6	CAN-Low return
14	—	—	—
15	906	0,6	Rear position voltage+
16	908	0,6	LH draft voltage+
17	910	0,6	RH draft voltage+
18	—	—	—
19	933	0,6	Rear position voltage-
20	934	0,6	LH rear draft voltage-
21	935	0,6	RH rear draft voltage-
22	—	—	—
23	907	0,6	Rear position signal
24	911	0,6	RH draft signal
▼	—	—	—
29	915	0,75	Up valve voltage+
30	904	1,4	+AVC REH
31	932	1,4	+AVC REH
▼	—	—	—
34	923	0,6	+APC REH
▼	—	—	—
37	901	0,6	Rear lowering ext ctrl
38	900	0,6	Rear raising ext ctrl
39	—	—	—
40	918	0,6	CAN-High network
41	919	0,6	CAN-Low network
42	920	0,6	REH up position
▼	—	—	—
47	902	1	+ APC (D+) alternator charge
▼	—	—	—
51	909	0,6	LH draft signal
▼	—	—	—

* Section = 1,4 for version with electrohydraulic spool valve (DEH)

27		55
26		54
25		53
24	911	52
23	907 909	51
22		50
21	935	49
20	934	48
19	933 902	47
18		46
17	910	45
16	908	44
15	906	43
14		42
13	922 919	41
12	921 918	40
11		39
10		38
9	901	37
8		36
7	905	35
6	912 923	34
5	913	33
4	M9F	32
3	M9E 932	31
2	914 904	30
1		29
	915	28




604msmAA

Wire markers	2	J189	Ending
1	950	0,6	CAN-Low
2	9030	0,6	CAN-Low
3	9032	0,6	CAN-Low
4	948	0,6	CAN-High
5	9031	0,6	CAN-High
6	9033	0,6	CAN-High

With electrohydraulic spool valves only

1	4
950	948
2	9030 9031
9032	9033
3	6




604msmF0

Wire markers	2	J190	Ending
1	953	0,6	CAN-Low
▼	—	—	—
4	957	0,6	CAN-High
▼	—	—	—


With electrohydraulic spool valves only

1	4
953	957
2	
3	6




604msmG0

Wire markers	2	J248	Ending
A1	946	0,6	REH raise control
A2	944	0,6	REH raise control
A3	903	0,6	+APC REH
A4	—	—	—
A5	941	0,6	+ REH raise control
A6	943	0,6	REH lower control
A7	947	0,6	REH lower control
B1	900	0,6	Rear raising ext ctrl
B2	—	—	—
B3	942	0,6	+ REH lower control
B4	939	0,6	+ REH lower control
B5	940	0,6	+ REH raise control
B6	901	0,6	Rear lowering ext ctrl
B7	—	—	—



1	2	3	4	5	6	7
A	946	944	903	941	943	947
B	900		942	939	940	901




604msmAB

Wire markers	2	J251	Ending
1	954	0,6	CAN-Low
2	951	0,6	CAN-Low
3	9036	0,6	CAN-Low
4	949	0,6	CAN-High
5	955	0,6	CAN-High
6	9037	0,6	CAN-High

With electrohydraulic spool valves only

1	4
954	949
2	951 955
9036	9037
3	6






604msmJ0





1a - Instrument panel harness



Wire markers	2	J10	Ending
A1	031	1,5	Flashing unit
A2	032	1,5	Flashing light supply
A5	036	1	Front LH indicator
A6	038	1,5	RH flashing lights
A7	039	1,5	RH flashing lights
B1	033	1,5	Flashing light supply
B2	—	—	—
B3	035	1,5	LH flashing lights
B4	034	1,5	LH flashing lights
B5	037	1,5	LH rear flashing light
B6	041	1,5	RH rear flashing light
B7	040	1	Front RH indicator



Wire markers	2	J13	Ending
1	220	0,5	Braking solenoid valve - Italy
2	125	0,5	Hydraulic pressure
3	059	0,5	Handbrake
3	219	0,5	Handbrake
4	—	—	—
5	178	3	Outside rear work lights power supply
6	106	1	Safety solenoid valve
7	175	0,5	Outside RR work light ctrl
8	176	3	+ AVC Rear work lights
9	179	0,5	Rear work light ctrl
10	094	1	Feu de travail aile arriere G
10	095	1	Feu de travail aile arriere D
11	196	0,75	+ APC LH PTO button
12	177	0,5	Rear wing light control





Wire markers	2	J14	Ending
5	MOD	1	Diagnostic plug
6	189	1	CAN-High
7	084	1	Line K
14	188	1	CAN-Low
15	085	1	Line L
16	076	1	+ AVC diagnostic socket





Wire markers	2	J15	Ending
4	157	1,5	Not neutral
5	156	1,5	Reverser relay ctrl engaged
6	174	0,5	Inside rear work light control
7	150	1,5	+APC neutral relay contact

Without air conditioning





Wire markers	2	J15	Ending
1	142	0,5	Air conditioning pressure relay control
2	145	1	Air conditioning compressor
3	146	1	Pressure switch
4	157	1,5	Not neutral
5	156	1,5	Reverser relay ctrl engaged
6	174	0,5	Inside rear work light control
7	150	1,5	+APC neutral relay contact
8	—	—	—
9	143	1	Recycling-
10	144	1	Recycling+
11	141	1	Recirculation control
12	140	1	+ APC recirculation controls

manual air conditioning



Wire markers	2	J15	Ending
2	194	3	Long range light power supply
3	192	0,5	Long-range light control
4	157	1,5	Not neutral
5	156	1,5	Reverser relay ctrl engaged
6	174	0,5	Inside rear work light control
7	150	1,5	+APC neutral relay contact
12	087	2	+ APC ventilation

Climate control





3/1b - 4 cylinder radiator cowling harness


3/2a - 6 cylinder engine front harness

Connectors	Designation
J273	RH work light
J274	LH work light
J280*	Hood temperature sensor
P265	Engine front harness connection

* Climate control version

Wire markers	2	J273	Ending
1	342B	1	RH work light
2	M3RB	1	RH work light earth
			E3G
			E3H


1	2
342B	M3RB



604msmJ7

Wire markers	2	J274	Ending
1	342C	1	LH work light
2	M3RC	1	LH work light earth
			E3G
			E3H

1	2
342C	M3RC




604msmJ8

Wire markers	2	J280	Ending
A	347A	1	Hood temperature sensor
B	348A	1	Hood temperature sensor
			P265
			P265

With climate control option only

B	A
348A	347A



604msmJ9


Wire markers	2	P265	Ending
1	310A	2	Headlights
2	347A*	1	Hood temperature sensor
3	342A	2	Working lights
4	M3CC	2	Work light earth
7	311A	2	Dipped headlights
8	348A*	1	Hood temperature sensor
9	M3RA	2	Work light earth
			E3A
			J280
			E3G
			E3C
			E3B
			J280
			E3H

manual air conditioning - Without air conditioning

7	311A	M3CC	310A	1
8				2
9	M3RA		342A	3
				4
				6

Climate control

7	311A	M3CC	310A	1
8	348A		347A	2
9	M3RA		342A	3
				4
				6





604msmK1

* Climate control version

Connectors	Designation
J01	Instrument panel harness connection
J16	Preheating harness connection
J22	Windscreen washer pump
J31	Engine water temperature
J34	Compressor
J51	Front power take-off
J200	Rear windscreen washer pump
J209	Air temperature
J210	Engine water temperature
J212	Engine speed
J213	Injection pump
J218	Injection pump
J226	Fuel temperature
J243	Controller Area Network (CAN)
J244	Controller Area Network (CAN)
J265	Radiator cowling harness connection
P02	Instrument panel harness connection


Wire markers	2	J01	Ending
R	322	10	+ AVC general
S	300	7	+ AVC general
T	—	—	—
U	301	7	+ AVC general
V	304	3	Starter solenoid
W	310	2	Dipped headlights
X	311	2	Headlights
Y	342	2	Grille work lights control
Z	—	—	—
			E3D
			E3D
			E3D
			32
			J265
			J265
			J265



604msmK2

Wire markers	2	J16	Ending
A	316	1	Preheating ctrl
			J218
			K3


A
316



604msmK3

Wire markers	2	J22	Ending
1	M3K	1	Windscreen washer pump
1	M3P	1	Rear screen washer
2	—	—	—
3	320	1	Windscreen washer pump
			E0B
			J200
			P02
			H

3	2	1
320		M3K
		M3P




604msmK4



7/1 - Closed centre circuit transmission harness - 110 litres - Pneumatic brake - Hydraulic brake - Italy (Cuna)

Wire markers		2		J82		Ending	
1	712	0,75	+	Tractor speed	P80	E7C	12
2	M7N	0,75					


1	2
712	M7N



604msmU3

Wire markers		2		J83		Ending	
1	711	0,75	+	Engine speed sensor	P80	E7C	11
2	M7O	0,75					


1	2
711	M7O



604msmU4

Wire markers		2		J84		Ending	
1	714	0,75	+	Rear PTO speed	P80	E7C	14
2	M7P	0,75					


1	2
714	M7P



604msmU5

Wire markers		2		J85		Ending	
1	709	0,75		Solenoid valve brake PdF rear	P80	E7A	9
2	M7C	0,75					


1	2
709	M7C



604msmU6

Wire markers		2		J86		Ending	
1	708	0,75		Rear PTO solenoid valve	P80	E7A	8
2	M7J	0,75					


1	2
708	M7J



604msmU7

Wire markers		2		J87		Ending	
1	704	0,75		Oil filter blocked	P80	E7A	4
2	M7F	0,75					


1	2
704	M7F



604msmU8

Wire markers		2		J88		Ending	
1	707	0,75		Differential solenoid valve	P80	E7A	7
2	M7G	0,75					


1	2
707	M7G



604msmU9

Wire markers		2		J89		Ending	
1	706	0,75		4 WD solenoid valve	P80	E7A	6
2	M7H	0,75					


1	2
706	M7H



604msmV1

Wire markers		2		J90		Ending	
1	705	0,75		Range solenoid valve A (SVA)	P80	E7A	5
2	M7I	0,75					


1	2
705	M7I



604msmV2

Wire markers		2		J91		Ending	
1	719	0,75		- Transmission temperature	P80	P80	19
2	720	0,75					


1	2
719	720



604msmV3

Wire markers		2		J92		Ending	
1	721	0,75		(PSV3) solenoid valve	P80	E7E	21
2	717	0,75					


1	2
721	717



604msmV4

Wire markers		2		J116		Ending	
1	726	0,75		Forward drive solenoid valve (PSVF)	P80	P80	26
2	710	0,75					

1	3
726	710





604msmV5




8a - Pneumatic brake transmission control harness - Hydraulic brake - Italy (Cuna) - 50 km/h

Wire markers	2	J46	Ending
1	815	0,6	Differential control
5	847	0,6	+APC differential control
			J2 35
			E8G





604hsmX9

Wire markers	2	J47	Ending
1	848	1	+APC clutch control
2			
			J2
			E8G



604msmY1


Wire markers	2	J49	Ending
A1			
A2	811	0,6	Range + control
A2	8003	0,6	Range + control
A3			
A4	812	0,6	Range - control
A4	8004	0,6	Range - control
A5			
B1			
B2	841	0,6	Range change
B3	853	0,6	+APC +/- range control
B4	8006	0,6	Furrow control
B4	883	0,6	Furrow control
B5			
			J2 32
			220A
			J2 18
			220B
			J2 20
			E8G
			220C
			J2 7



604msmY2


Wire markers	2	J68	Ending
A1	M8A	2	Transmission control earth
A2	M8B	0,6	Indicator light display earth
A3	M8Q**	1	Air brake solenoid valve
A3	M8R*	0,6	ISO unit
A4			
A5	M8C	0,6	LCD display
A6	M8E***	1,4	Solenoid valve earth
A7	M8F	1	Earth "Auto 5"
A7	M8T	0,6	Resistance earth
B1	M8G	1	Earth "Auto 5"
B2	M8H	1	Earth "Auto 5" (2)
B3	M8J	1	Earth "Auto 5" (1/2)
B4	M8K	1	Earth "Auto 5" (3)
B5	M8M	1	Earth "Auto 5" (3)
B6	M8D	1	Earth "Auto 5" (1)
B7	M8L	0,75	GND frequency earth
			E6A
			J195 9
			J80 35
			J207 2
			J137 1
			J80 31
			J2 28
			J300 3
			J1 15
			J2 15
			184
			J237 15
			J237 28
			J1 28
			J80 15

* Version with ISO socket
 ** Version with pneumatic braking and 50 km/h
 *** Section = 1,5 for hydraulic version Italy




604msmBK

Without ISO socket





With ISO socket - Hydraulic brake (Italy)



Without ISO socket - Pneumatic brake - 50 km/h



With ISO socket - Pneumatic brake - 50 km/h



604msmY4




9/2a - TCE 15/25 control harness



Wire markers	2	J69	Ending		
1	906	0,6	Rear position voltage+	J71	15
2	907	0,6	Rear position signal	J71	23
3	933	0,6	Rear position voltage-	J71	19
4	912	0,75	Down valve voltage-	J71	6
5	908	0,6	LH draft voltage+	J71	16
6	909	0,6	LH draft signal	J71	51
7	934	0,6	LH rear draft voltage-	J71	20
8	914	0,75	Down valve voltage+	J71	2
9	913	0,75	Up valve voltage-	J71	5
10	910	0,6	RH draft voltage+	J71	17
11	911	0,6	RH draft signal	J71	24
12	935	0,6	RH rear draft voltage-	J71	21
13	—	—	—	—	—
14	915	0,75	Up valve voltage+	J71	29
15	—	—	—	—	—
16	925	0,6	+APC radar (RH+ relayed)	J70	A5
17	924	0,6	Radar signal	P42	6
18	M9G	0,6	Radar	E9A	—
▼	—	—	—	—	—
23	984	0,75	Fuel level	P42	10
24	—	—	—	—	—
25	M9S	0,75	Fuel gauge	P42	11
26	—	—	—	—	—
27	952*	0,6	CAN-Low	J252	2
28	956*	0,6	CAN-High	J252	5
29	981*	1	+ APC Electrohydraulic spool valve (DEH)	P42	12
30	—	—	—	—	—
31	980*	1	Safety solenoid valve	P42	2
32	951*	0,6	CAN-Low	J251	2
33	955*	0,6	CAN-High	J251	5
▼	—	—	—	—	—
37	M9U*	1	DEH earth	E9A	—

* Version with DEH

Without electrohydraulic spool valve




With electrohydraulic spool valve





604msmY0

Wire markers	2	J70	Ending		
A1	904	1,4	+AVC REH	J71	30
A2	—	—	—	—	—
A3	905	0,6	+ APC backligh	J71	7
A4	—	—	—	—	—
A5	925	0,6	+APC radar (RH+ relayed)	J69	16
▼	—	—	—	—	—
B1	917	2	+AVC REH	P42	9
B2	932	1,4	+AVC REH	J71	31
B3	903	0,6	+APC REH	J248	A3
B4	916	0,6	+APC REH	P42	3
B5	923	0,6	+APC REH	J71	34
▼	—	—	—	—	—



604msmBJ



604msmZ0

CHECKS AND ADJUSTMENTS

CONNECTIONS TO TCE 15 T UNITS	G2.8
POSITION SENSOR ON GPA 20 AXLE	G2.10
FORCE SENSOR ON GPA 20 AXLE	G2.11
THEORETICAL FORWARD SPEED SENSOR ON GPA 20 AXLE	G2.12
LIFT SPOOL VALVE SOLENOID VALVES	G2.12

G3 – TCE 15/25 ELECTRONIC LIFT

DESCRIPTION

TCE 15/TCE 25	G3.2
ACCESS TO THE INSTALLED SOFTWARE VERSION (TCE 15, TCE 25)	G3.3
LIFT OPERATING CONDITIONS	G3.3
ERROR CODES	G3.3
ELECTRICAL ARCHITECTURE	G3.4
ECU INPUTS AND OUTPUTS	G3.5

CHECKS AND ADJUSTMENTS

CONNECTIONS TO TCE 15/TCE 25 UNITS	G3.6
POSITION SENSOR	G3.7
LOAD SENSOR	G3.8
THEORETICAL FORWARD SPEED SENSOR	G3.9
TCE 25 RADAR	G3.10
LIFT SPOOL VALVE SOLENOID VALVES	G3.10

G4 – INFOTRAC AND ISO SOCKET


PRESENTATION OF THE "INFOTRAC"

FUNCTIONS	G4.2
GENERAL DESCRIPTION	G4.2
OPERATION	G4.3
OPERATING SEQUENCE	G4.5
SCHEMATIC DIAGRAM	G4.6
FUNCTIONS OF CONNECTOR WIRES	G4.7
OUTSIDE AIR TEMPERATURE SENSOR	G4.8

Characteristics

Input/output by function

Input/output by function (rev counter, various speeds and hour counter)



584msm08

Fig. 17

Nomenclature

- | | |
|--------------------------------------|-------------------------------|
| 1 Rear power take-off speed. | 5 Actual speed radar signal*. |
| 2 Alternator signal (engine speed). | 6 Speed calibration control. |
| 3 Dashboard electronic control unit. | 7 Front PTO signal*. |
| 4 Theoretical speed sensor signal. | 8 Display selection control. |


Nature of signal or electrical level

- 1, 2, 4, 5*: AC signal measured on frequency indicator.
- 6, 8: Earth contact.
- 7*: 12 V DC voltage if front PTO control engaged.

* Option depending on model.

Description

TCE 15 T



382hsn19a

Fig. 1

Nomenclature

1 5-position mode switch (transport, high position, stop, working position and dropping).

2 Position adjustment control (work depth adjustment).

3 Lift movement indicator lights (up/down).

4 Transport lock button.

5 Button to adjust rate of descent.

6 Safety warning light. This light will be lit or start flashing if the safety function or alarm is activated on the TCE unit. It can be activated in three different ways.

– Light flashing slowly or quickly: Operating fault. The flashing rate defines the nature of the fault. The lift can still be used (Win Métadiag[®] is required to determine the origin of the fault).


– Light on steady: System in safety mode. To reset the unit, carry out the lift setup procedure.

7 Button to adjust top limit.

8 Keys to adjust sensitivity of draft/position control.


9 Damping mode key for transport.

10 Mechanical stop identifying the "low limit" position.



Description

ECU inputs and outputs



382msm10

Fig. 4

Nomenclature

- 1 Battery.
- 2 Signal.
- 3 Black light.

Presentation of the ISO socket

ISO unit

Its purpose is to make the signals received for an implement usable.

– Change the unit in the event of a fault.

The ISO unit (1) is located on the rear panel.


A single connector receives the inputs and outputs (Fig. 9). For more information, refer to the connector channel table (see chapter "G5").



581msm05

Fig. 8

Harness schematic




581msm12

Fig. 9

Nomenclature

1 ISO unit.

E Inputs.



Description

The Electropilot system operates via a CAN bus.

Note: a CAN bus consists of 2 wires that carry information in binary form .

The information does not have a precise destination but is preceded by an identifier. Information is made available to all units present on the bus. From the moment that an identifier is relevant to a unit, the latter will process the message that accompanies this identifier .


These 2 wires are twisted ("twisted pair") to improve interference resistance.

The CAN bus links the joystick, the two electrohydraulic spool valves, as well as the "Auto 5" transmission unit. Électropilot can only be activated with the engine running. This "engine running" signal is provided by the transmission unit (Auto 5).

When the system is active, the safety spool valve is powered. Control of this solenoid is provided by the joystick and amplified within the settings console.

If the joystick is moved forwards, this sends a certain identifier onto the bus accompanied by a flow order (this will depend on the position of the joystick and the setting of potentiometer "A" on the console).

This identifier will only be of interest to spool valve "A" which will position the spool to obtain the required flow.



"Inspection results" sheet

This sheet is intended to be duplicated and completed for each operation on the tractor. If you have to send it to the manufacturer's after sales service, it is essential to indicate:

Tractor type.....

The serial number.....

Total operating hours.....


Date of operation

Checking the safety solenoid valve

Test conditions with power on	Nominal voltage (volt)	Measured voltage
Control in neutral	0	
Control activated	12	
Test condition with power off	Nominal resistance (Ohm)	Measured resistance
Control activated	5,3	


Checking the control pressure

Test conditions Oil temperature at 60°C Engine at nominal speed	Nominal pressure (bar)	Recorded pressure
Control activated	22,5 ± 1,5	



Engine application

Engine overview



586hsm60

Fig. 21


Nomenclature

- 1 Percentage of engine charge at a given speed.
- 2 Indicates an error on the fuel temperature function.
- 3 Error code relating to point (2). Double-click it to access the corresponding sheet.



Engine application

Anomaly code SPN 190 FMI 16 Moderate engine overspeed



582msm06

Fig. 33

Nomenclature

B2 Crankshaft position sensor input.

D2 Crankshaft position sensor return.

1 Engine control unit.

2 Fuel temperature sensor.

Code SPN 190 FMI 16 is declared if

The engine control unit detects that the engine speed exceeds 3 000 rpm


This is what happens if the SPN 190 FMI 16 code is in force

The engine control unit cuts off the fuel feed until the engine runs at less than 2 800 rpm

1. The electronic management system may be affected

Using Win Métadiag[®], watch whether other codes appear and look at their diagnostic procedure.


2. In the absence of other memorised or active codes, clear the SPN 190 FMI 16 code and monitor the codes to see if they are repeated.



Engine application

Anomaly code SPN 1076 FMI 10

Pump solenoid valve circuit intermittently short-circuited



582msm20

Fig. 11

Nomenclature

- 1 Engine control unit.
- 2 Pump solenoid valve.

- A3 Pump solenoid valve return.
- K2 Pump solenoid valve feed.


Code SPN 1076 FMI 10 is declared if

The pump solenoid valve circuit is short-circuited at the supply.

This is what happens if the SPN 1076 FMI 10 code is in force

The control unit immediately reduces the engine power to 50 % of its maximum power.

<p>1. Check the connection Carry out a preliminary inspection of the UCE unit connector, the pump connector and any other connector. Find any dirty, worn or badly positioned terminals.</p>	<p>No defective connection Go to 2. Defective connection(s) Repair the defective connection(s).</p>
<p>2. Check the engine control unit 1 Master switch off. 2 Disconnect the pump solenoid valve and engine control unit connectors. 3 Measure with the multimeter the resistance between the terminal K2 of the front wiring assembly: – A good earth. – All the other terminals of the control unit connector.</p>	<p>Record of less than 20 000 ohms Go to 3. Record of less than 20 000 ohms Pump solenoid valve feed wire short-circuited.</p>
<p>3. Check the pump solenoid valve return circuit 1 Master switch off. 2 Disconnect the pump solenoid valve and engine control unit connectors. 3 Measure with the multimeter the resistance between the terminal A3 on the front wire assembly side and: – A good earth. – All the other terminals of the control unit connector.</p>	<p>Record of less than 20 000 ohms Go to 4. Record of less than 20 000 ohms Pump solenoid valve return wire short-circuited.</p>



Engine application

– Check the unit and click OK.


If the unit does not match, connect the required unit and click "Retry".



586msm31


Fig. 52

– Otherwise click "Cancel" and repeat the Internet downloading procedure, checking the information entered on the site.



Service brake cut-out relay solenoid valve (centre open at rest)


Error codes	Object	Cause	Audio warning:	"ISC" reset requested
337	Inconsistency between the selected gear and the measured ratio.	Check: Engine speed data. The shuttle reverser output speed sensor. For a possible seizure of the forward/reverse or "Hexashift solenoid valves (PSV1, PSV2, PSV3). For a possible mechanical problem on the forward/reverse or "Hexashift" clutches (slippage).	Yes	Yes
341	Short circuit at 12 volts of the power take-off solenoid valve.	Check: For a possible 12 V short circuit on the solenoid valve power supply harness. The "Auto 5" unit with tool n° 60 05 033 249 and replace if necessary.	No	No
342	Short circuit on power take-off solenoid valve earth.	Check: For a possible open circuit in the solenoid valve supply harness. For a possible short circuit to earth on the solenoid valve. The "Auto 5" unit with tool n° 60 05 033 249 and replace if necessary.		
343	Power take-off solenoid valve circuit open.	Check: For a possible open circuit in the solenoid valve supply harness. The resistance of the solenoid valve winding. The "Auto 5" unit with tool n° 60 05 033 249 and replace if necessary.		
344	Drop in engine speed (during power take-off start-up).	Check: Possible mechanical problem with the power take-off. Possible problem with the tool driven by the power take-off.		
345	Button active but power take-off off (e.g.: after engine stall).	Check: The harnesses and their connections. Power take-off solenoid valve. Power take-off engine speed sensors. Possible mechanical problem with the power take-off. The "Auto 5" unit with tool n° 60 05 033 249 and replace if necessary.		



Service brake cut-out relay solenoid valve (centre open at rest)

After programming each function in its slot, run the programming procedure again.


- Answer "Yes" to the question "Have you exchanged one or more units?".
- Check that the functions and versions are correct.
- Exit the application by clicking the icon (3).



586msm45

Fig. 75

N.B.: During the programming procedure, code 400 (see list of error codes) is displayed on the screen.



Dashboard application

Overview



586hsm50

Fig. 98

Nomenclature

- 1 Built-in test. Illustrated indicator lamps lit simultaneously or successively.
- 2 Software version.



H1 CAB LIFTING AND GLASS BONDING

H2 MANUAL HEATING/AIR CONDITIONING


H3 REGULATED HEATING AND A/C

Technical support

Ares 507-607

Chapter H

60 05 031 190 – 06.2005 publication




Removing the cab

Operation n° 12

- Identify and disconnect the spool valve control junctions.
- Open junction (K) (Fig. 16).
- Unscrew locknuts (L) (Fig. 17).
- Unscrew nut (M) towards the control lever (Fig. 17).


Operation n° 13

- Disconnect the handbrake cable (N) (Fig. 18). Refer to chapter "C4" for the setting procedure.
- Disconnect the crawler range control cable.




841hsm18

Fig. 16




841hsm19

Fig. 17



841msm30

Fig. 18



Removal/refitting of glazing

– As soon as the perimeter of the windscreen frame is covered: With the help of another person and observing rules of safety (gloves, goggles and stepladder on each side of the engine), bond the windscreen to the cab starting at the top

Take care on passing the worklight protectors.

- Align the windscreen vertically and horizontally with the lower windows.
- Apply the necessary pressure to flatten the seal around the entire perimeter.
- Strap the windscreen against the cab.

N.B.: Do not fasten too tightly.

- Stick masking tape at the lower window joints.
- Coat the joint grooves with sealant and smooth off the excess with a spreader.
- Refit the removed components.

Tractor standing time after bonding:

30 minutes at an outdoor temperature of 20°C.


If the temperature is very low:

- Start the engine and set the cab heating to the deicing position.
- If necessary, heat the perimeter of the windscreen with a hot air blower.
- In all cases, refer to the drying indicator which must not be tacky.




841hsm54

Fig. 62



841msm34

Fig. 63



841hsm56

Fig. 64

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL