

200CLC 230CLC and 270CLC Excavator Repair

TECHNICAL MANUAL 200CLC, 230CLC, and 270CLC Excavator Repair

TM1931 09JAN04 (ENGLISH)

For complete service information also see:

200CLC, 230CLC, and 270CLC Excavator Operation and Tests	TM1930
POWERTECH® 4.5 L & 6.8 L (4045 and 6068) Diesel Engines, Base Engine	CTM104
POWERTECH® 4.5 L & 6.8 L (4045 and 6068) Diesel Engines, Level 4 Electronic Fuel Systems with Bosch VP44 Pump	CTM170
Alternators and Starting Motors	CTM77
Undercarriage Appraisal Manual	SP326

**Worldwide Construction
And Forestry Division**

LITHO IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T133555 -JUN-28AUG00

T133588 -19-28AUG00

TX03679,00016CC -19-21AUG00-1/1

Follow Safety Instructions

Read the safety messages in this manual and on the machine. Follow these warnings and instructions carefully. Review them frequently.

Be sure all operators of this machine understand every safety message. Replace operator's manual and safety labels immediately if missing or damaged.



T133556 -JUN-24AUG00

TX03679,00016F9 -19-28AUG00-1/1

Operate Only If Qualified

Do not operate this machine unless you have read the operator's manual carefully and you have been qualified by supervised training and instruction.

Familiarize yourself with the job site and your surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to your work situation and your work site.

TX03679,00016FA -19-30OCT00-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



DX.RCAP -19-04JUN90-1/1

TS281 -UN-23AUG88

Remove Paint Before Welding or Heating

Hazardous fumes can be generated when paint is heated by welding or using a torch. Dust from sanding or grinding paint can also be hazardous.

Remove paint to at least 76 mm (3 in.) from area to be heated. Wear an approved respirator when sanding or grinding paint. If a solvent or paint stripper is used, wash area with soap and water. Remove solvent or paint stripper containers from work area and allow fumes to disperse at least 15 minutes before welding or heating.

Work outside or in a well-ventilated area. Dispose of waste, paint and solvents properly.



TX03679,0001732 -19-06SEP00-1/1

T133546 -UN-24AUG00

Make Welding Repairs Safely

NOTE: Disable electrical power before welding. Turn off main battery switch or disconnect positive battery cable. Separate harness connectors to engine and vehicle microprocessors.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines fail as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs. Make sure there is good ventilation. Wear eye protection and protective equipment when welding.



TX03679,00016D5 -19-02OCT00-1/1


T133547 -UN-31AUG00

Angle Fitting

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).

NOTE: Do not allow hoses to twist when tightening fittings.

4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.




T6520AB -UN-18OCT88

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART

Thread Size	N•m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

NOTE: Torque tolerance is ± 10%.

04T,90,K66 -19-29SEP99-2/2



A—Plug (2 used)
B—Bracket (2 used)

C—Pin (2 used)
D—O-Ring (2 used)

E—Metal Face Seal (2 used)
F—Bushing (2 used)

G—Roller
H—Axle

Disassemble and Assemble Track Roller

1. Remove plug (A) and drain oil.
2. Remove pin (C).
3. Remove bracket (B) using a bearing puller attachment and adapters from puller set.

IMPORTANT: Metal face seals can be reused if they are not worn or damaged. A used seal must be kept together as a set because of wear patterns on seal ring face.

4. Remove metal face seal (E) from roller and bracket. Keep seal rings together as a matched set with seal ring faces together to protect surfaces.
5. Inspect metal face seals. See Metal Face Seals Repair. (See procedure in this group.) For seals that will be reused, put a piece of cardboard between seal rings to protect seal face.
6. Remove axle (H) from roller.

NOTE: Only remove bushing if replacement is necessary.

7. Remove bushing (F) using a 2 jaw puller and adapters from puller set.
8. Replace parts as necessary.

Apply a thin film of oil to bushings (F) and install.

IMPORTANT: O-rings and seat surfaces for O-rings must be clean, dry, and oil free so O-rings do not slip when roller is turning.

9. Thoroughly clean O-rings and seat surfaces in brackets (B) and in seal rings using volatile, non-petroleum base solvent and lint-free tissues.
10. Install seals (E) in brackets (B) and in roller (G). Apply equal pressure with fingers at four equally spaced points on seal face. Seal must "pop" down into place so O-ring is tight against seal bore. A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.

Continued on next page

OUOE049.0000063 -19-19NOV01-4/6

Track System

NOTE: Wear on pins and bushings does not extend over the entire surface. Turning pins and bushing is determined by the amount of wear.

- Turn pins (C and K) and bushings (E and I) as required.
- Clean any dust or rust from the surfaces of track link pin bores and counterbores and the ends of bushings.
- Apply grease to the counterbore in track links, the seals, and the ends of bushings.
- For each joint, fill the clearance between the pin OD and bushing ID with grease.
- Install seal (H) so tapered side (L) is toward bushing.

OUOE049,0000065 -19-20JUN01-5/5

01
0130
13


Broken Track Chain Part Repair

Disassemble and Assemble Track Chain to Replace Broken Part

- Remove track shoes from each side of broken link assembly. See Track Shoe Repair. (See procedure in this group.)

IMPORTANT: When making cuts using cutting torch, be careful not to cut or gouge good parts.

- Cut links, bushing, and pin at points (A) to remove broken link (B).




A—Cut Locations
B—Broken Link

T5821AG -UN-26OCT88

OUOE003,0000008 -19-28OCT01-1/4

- Grind the ends of bushing (A) even with links to make it into a master bushing.

A—Bushing



Continued on next page

OUOE003,0000008 -19-28OCT01-2/4

T5821AH -UN-26OCT88


6. Install DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool (F). (Group 9900.)
7. Install plate top (A) and nuts (B) with smallest opening to allow access to nut (D).
8. Extend jack ram to provide enough travel to release spring to the approximate free length.

Track Adjuster and Recoil Spring—Specification

Recoil Spring (200CLC and 230CLC)—Free Length	626 mm (24.64 in.) approximate
Recoil Spring (270CLC)—Free Length.....	679 mm (26.73 in.) approximate

9. Tighten nuts (B) so plate is tight against retainer plate.
10. Remove valve (C) and special plug (E).

- A—Top Plate
- B—Nut (8 used)
- C—Valve
- D—Nut
- E—Special Plug
- F—DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool



01
0130
23

T7720AG -UN-28APR92

Continued on next page

OUOE003,000000A -19-09NOV01-5/6

- | | | | |
|-------------------------------|---------------------------|-------------------------------|----------------------------|
| 1—Third Planet Carrier | 9—Spacer (2 used) | 18—Spring Pin (3 used) | 26—Needle Bearing (6 used) |
| 2—Third Planet Sun Gear | 10—Second Planet Sun Gear | 19—Pin (3 used) | 27—Third Planet Gear |
| 3—Thrust Plate (6 used) | 11—First Planet Carrier | 20—Thrust Plate (6 used) | 28—Propel Motor |
| 4—Second Planet Gear (3 used) | 12—Shaft | 21—Needle Bearing (3 used) | 29—Metal Face Seal |
| 5—Needle Bearing (3 used) | 13—Ring Gear | 22—First Planet Gear (3 used) | 30—Bearing (2 used) |
| 6—Pin (3 used) | 14—Thrust Pad | 23—Spring Pin (3 used) | 31—Drum |
| 7—Spring Pin (3 used) | 15—Cap Screw (12 used) | 24—Pin (3 used) | 32—Bearing Nut |
| 8—Second Planet Carrier | 16—Cover | 25—Thrust Plate (6 used) | 33—Dowel Pin |
| | 17—Cap Screw (24 used) | | |

Disassemble and Assemble Propel Gearbox—200CLC and 230CLC

1. Remove cap screws (15) and cover (16).
2. Remove shaft (12) and first planet carrier (11).
3. Remove second planet sun gear (10) and second planet carrier (8).

CAUTION: Heavy component; use a hoist.

Propel Gearbox—Specification

Ring Gear (200CLC and 230CLC)—Weight..... 41 kg (90 lb) approximate

4. Install JT01748 Lifting Brackets to ring gear (13). Remove cap screws (17) and ring gear.

CAUTION: Heavy component; use a hoist.

Propel Gearbox—Specification

Third Planet Carrier (200CLC and 230CLC)—Weight..... 39 kg (85 lb) approximate

5. Remove third planet sun gear (2) and third planet carrier (1).

NOTE: Disassembly of first, second, and third planet carriers are similar. Repeat procedure as required.

6. Remove spring pins, pins, thrust plates, needle bearings, and planetary gears.

Clean and inspect parts, replace as necessary. Oil parts with gear oil prior to assembly.

OUOE049,0001000 -19-19NOV01-4/14

7. Install spring pins with slit (1) toward end of pin.
8. Install third planet gear (27) in third planet carrier (1) with marked side towards hole for spring.

1—Slit



T142429 -JUN-22JUN01

Continued on next page

OUOE049,0001000 -19-19NOV01-5/14


Propel Motor Repair

Remove and Install Propel Motor—200CLC and 230CLC


NOTE: Propel motor is an integral part of propel gearbox.

If removal is required. See Propel Gearbox Repair. (Group 0250.)

Remove and Install Propel Motor—270CLC

 **CAUTION: Prevent possible injury from unexpected machine movement. Block both tracks when removing propel motors. When propel motors are removed, machine has no brakes and can move. The machine will roll free on a slope or while being towed.**

1. Block tracks.
2. Drain oil from propel gearbox. Approximate capacity is 6.0 L (6.5 qt).

 **CAUTION: The hydraulic oil tank is pressurized. High pressure release of oil can cause serious burns or penetrating injury.**

3. Do Hydraulic Oil Tank Vent Procedure. (Group 3360.)
4. Pull a vacuum in hydraulic oil tank using a vacuum pump or drain hydraulic oil tank. See 270CLC Drain and Refill Capacities. (Operator's Manual.)

Continued on next page

ouoe049,0001010 -19-19NOV01-1/26

23. Install shoulder bolt (C) through link assembly (D) at end of servo piston. Install plug and O-Ring . Tighten shoulder bolt (C) and plug (B).

Propel Motor—Specification


Shoulder Bolt (270CLC)—Torque 49 N•m (36 lb-ft)

24. Install O-ring and cover (A). Tighten cover cap screws.

Propel Motor—Specification

Servo Piston Cover Cap Screw (270CLC)—Torque 88 N•m (65 lb-ft)

- A—Cover
- B—Plug and O-Ring
- C—Shoulder Bolt
- D—Valve Plate and Link Assembly



02
0260
11

T8321AF -JUN-20SEP94

Continued on next page

ouoe049,0001010 -19-19NOV01-15/26

NOTE: Valves can be removed with propel motor on machine.

5. Check Valves (M)

Install parts and tighten plug.

Propel Motor—Specification

Check Valve Plug (270CLC)—
Torque 235 N•m (173 lb-ft)

NOTE: Valve can be removed with propel motor on machine.

6. Brake Pressure Reducing Valve (U)


Install parts and tighten plug.

Propel Motor—Specification

Brake Pressure Reducing Valve
Plug (270CLC)—Torque..... 69 N•m (51 lb-ft)

ouoe049,0001010 -19-19NOV01-26/26

02
0260
21



04
0400
3

T143012 -JN-19NOV01

T143012

- 1—Bracket, Right Front
- 2—Bracket, Left Front
- 3—Bracket, Rear (2 used)
- 4—Cap Screw (14 used)
- 5—Washer (14 used)

16. Remove cap screws (4) and washers (5) from engine mounts.
17. Raise engine slightly. Move engine away from hydraulic pump and drive gearbox. Lift and remove engine when disengaged from hydraulic pump drive coupling.
18. Repair or replace parts as necessary. If disassembly is necessary, see Engine Disassembly Sequence. (CTM104.)

CAUTION: Heavy component; lift engine using JDG23 Lifting Sling. Lifting force must be 90° to engine lift points.

Engine—Specification

Engine—Weight..... 954 kg (2100 lb) approximate

19. Use JDG23 Lifting Sling to install engine. Install engine mount cap screws (5) and washers (4).

Tighten cap screws.

Engine—Specification

Engine Mount Cap Screw—
Torque..... 350 N•m (260 lb-ft)

20. Align hydraulic pump and drive gearbox to engine and tighten cap screws.

Engine—Specification

Drive Gearbox-to-Flywheel
Housing Cap Screw—Torque..... 50 N•m (37 lb-ft)

21. Connect engine wiring. See Machine Harness (W2) Component Location Diagram. (Group 9015-10.)
22. Fill radiator and reservoir with coolant. See Cooling System Fill and Deaeration Procedure. (Operator's Manual.)
23. Bleed Fuel System. (Operator's Manual.)

Air Intake System Leakage Test

1. Remove air cleaner cover. Remove primary filter element.
2. Put a large plastic bag inside and over end of element as shown. Install element and cover.
3. Remove fitting for start aid nozzle from intake manifold.
4. Install the JDG51 Inlet Air Adapter (A).
5. Connect air pressure regulator to adapter using hose and fitting.

IMPORTANT: Plastic bag could be drawn into the engine causing damage if engine starts. Do not start the engine when turning the engine crankshaft to close valves.

6. Pressurize air intake system to 14—21 kPa (0.14—0.21 bar) (2—3 psi). If intake system cannot be pressurized, turn engine crankshaft slightly to close valves.


Air Intake System—Specification

Leakage Test—Pressure..... 14—21 kPa (0.14—0.21 bar)
(2—3 psi)

7. Spray a soap solution over all connections from the air cleaner to turbocharger and intake manifold. Check for leaks. Correct all leaks
8. When installing start aid nozzle, be certain arrow on nozzle is pointing against intake air flow.



T5906AP -JUN-23FEB89



T6089AR -JUN-25OCT88

A—JDG51 Inlet Air Adapter

05
0520
1

TX,05,GG2309 -19-19NOV01-1/1

Section 17 Frame or Supporting Structure

Contents

Page

Group 1740—Frame Installation

Welding On Machine17-1740-1

Welding Repair of Major Structure17-1740-2

Group 1749—Chassis Weights

Counterweight17-1749-1

6. Remove lock nuts (4) securing cab to rubber mounts at all four corners. Discard lock nuts.

7. Remove cap screws (1 and 3).

SMCLEAN,000000B -19-19NOV01-3/4



CAUTION: Heavy component; use a hoist.

Cab—Specification

Cab—Weight 290 kg (640 lb) approximate

8. Use lifting straps and connect cab to hoist.

NOTE: Move cab forward slightly to clear propel pedals during removal.

9. Remove cab.

10. Repair or replace parts as necessary.

NOTE: Check that all lines and cables are out of the way before installing cab.

11. Install cab.

12. Install cap screws (1 and 3).

Cab—Specification

Cab-to-Platform Cap Screw—
Torque 50 N•m (37 lb-ft)


13. Install washers (5) and new lock nuts (4).

Cab—Specification

Cab Mount Lock Nut—Torque 205 N•m (152 lb-ft)

14. Connect electrical connectors. See Monitor Harness (W3) Component Location and See Cab Harness (W1) Component Location Diagram. (Group 9015-05.)

15. Install monitor controller. See Remove and Install Monitor Controller and Display (A5). (Group 9015-20.)



T106453

T106453 -UN-15JAN97

18
1800
3

SMCLEAN,000000B -19-19NOV01-4/4

Flush and Purge Air Conditioner System



CAUTION: Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.

See Refrigerant Cautions and Proper Handling. (See procedure in this group.)

NOTE: Flushing can be performed on machine.

1. Recover R134a Refrigerant. (See procedure in this group.)

Add flushing solvent to system with JT02075 Flusher and JT02098 Flusher Fitting Kit.

2. Remove and discard receiver/dryer.
3. Connect flusher outlet hose to inlet end of compressor discharge line using JT02102 Adapter.
4. Fill flusher tank with solvent and fasten all connections. Dispose of solvent properly.

Flush and Purge Air Conditioner System—Specification

Flusher Tank—Capacity 4 L (1 gal)

NOTE: Air pressure must be at least at specification for flushing and purging.

Flush and Purge Air Conditioner System—Specification

Air Pressure—Pressure 620 kPa (90 psi) (6.2 bar)
minimum for flushing and purging

5. Connect a supply line of moisture-free compressed air or dry nitrogen to flusher air valve.
6. Open air valve to force flushing solvent into condenser circuit. Flusher tank is empty when hose pulsing stops. Additional flushing cycles are required if system is heavily contaminated with burned oil or metal particles.

7. Clean compressor as follows:

- a. Remove compressor and measure oil drained from both manifold ports.

- b. Connect flusher outlet hose to inlet end of compressor discharge line using JT02102 Adapter.
- c. Pour flushing solvent into suction port and discharge port. Plug both ports in compressor manifold, using JT02099 and JT03194 Caps.

Flush and Purge Air Conditioner System—Specification

Flushing Solvent in Suction

Port—Volume..... 240 mL (8 fl oz)

Flushing Solvent in Discharge

Port—Volume..... 120 mL (4 fl oz)

- d. Turn compressor end for end and roll it side to side.
- e. Remove both plugs from manifold ports and drain solvent from compressor.
- f. Connect battery power to compressor clutch coil. Rotate pulley at least five revolutions to move solvent out of cylinders.
- g. Invert compressor. Roll end for end and side to side. Drain thoroughly.
- h. Repeat previous two steps at least three times.

8. Divide system into two circuits:


- Condenser circuit, including inlet and outlet hoses.
- Evaporator circuit, including inlet and outlet hoses.

9. Condenser:

IMPORTANT: DO NOT attempt to flush through compressor or receiver/dryer. Flushing through expansion valve is acceptable if refrigerant oil has a normal odor and appearance.

- a. Flush/Purge Condenser:

Bucket Links Repair



T142977

T142977 -UN-24JUL01

- | | | | |
|-------------------------|-------------------------|----------------|--------------------|
| 1—Nut (4 used) | 4—Dust Seal (2 used) | 7—Cylinder Pin | 10—Right Side Link |
| 2—Cap Screw (2 used) | 5—Bushing (2 used) | 8—Wooden Block | 11—Left Side Link |
| 3—Thrust Plate (2 used) | 6—Thrust Plate (4 used) | 9—Center Link | 12—Pin |

Remove and Install Bucket Links

NOTE: Removal of bucket is not necessary for removal of just bucket links.

1. Connect hoist to center link (9) using lifting strap. Put wooden block (8) between bucket cylinder and

arm to hold cylinder up when cylinder pin (7) is removed.


2. Remove parts (1—5).

As cylinder pin (7) is removed, lower links (10 and 11) to ground.

Continued on next page

TX,33,GG2406 -19-19NOV01-1/2

Inspect Boom, Arm, and Bucket Pins, Bushings and Bosses



T7779AC (CY)

T7779AC -UN-11JUN92

A—Boom Cylinder Head
End-to-Frame Joint
B—Boom Cylinder Rod
End-to-Boom Joint
C—Boom-to-Frame Joint

D—Boom-to-Arm Joint
E—Arm Cylinder Head
End-to-Boom Joint
F—Arm Cylinder Rod
End-to-Arm Joint

G—Bucket Cylinder Head
End-to-Arm Joint
H—Bucket Cylinder Rod
End-to-Side and Center
Links Joint

I—Side Links-to-Arm Joint
J—Center Link-to-Bucket Joint
K—Bucket-to-Arm Joint

Boom (200CLC)—Specification

Boom Cylinder Head End-to-Frame Joint Pin (200CLC)—OD	80.0 mm (3.15 in.) nominal OD.....
79.0 mm (3.11 in.) limit of use	
Boom Cylinder Head End-to-Frame Joint Bushing (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	
Boom Cylinder Head End-to-Frame Joint Boss (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	
Boom Cylinder Rod End-to-Boom Joint Pin (200CLC)—OD	90.0 mm (3.54 in.) nominal OD.....
89.0 mm (3.50 in.) limit of use	
Boom Cylinder Rod End-to-Boom Joint Bushing (200CLC)—ID	90.0 mm (3.54 in.) nominal ID
91.5 mm (3.60 in.) limit of use	
Boom Cylinder Rod End-to-Boom Joint Boss (200CLC)—ID	90.0 mm (3.54 in.) nominal ID
91.5 mm (3.60 in.) limit of use	
Boom-to-Frame Joint Pin (200CLC)—OD	90.0 mm (3.45 in.) nominal OD.....
89.0 mm (3.50 in.) limit of use	
Boom-to-Frame Joint Bushing (200CLC)—ID	90.0 mm (3.45 in.) nominal ID
91.5 mm (3.60 in.) limit of use	
Boom-to-Arm Joint Pin (200CLC)—OD	90.0 mm (3.54 in.) nominal OD.....
89.0 mm (3.50 in.) limit of use	

Boom-to-Arm Joint Bushing (200CLC)—ID	90.0 mm (3.54 in.) nominal ID
91.5 mm (3.60 in.) limit of use	

Arm (200CLC)—Specification

Arm Cylinder Head End-to-Boom Joint Pin (200CLC)—OD	80.0 mm (3.15 in.) nominal OD.....
79.0 mm (3.11 in.) limit of use	
Arm Cylinder Head End-to-Boom Joint Bushing (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	
Arm Cylinder Head End-to-Boom Joint Boss (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	
Arm Cylinder Rod End-to-Arm Joint Pin (200CLC)—OD	80.0 mm (3.15 in.) nominal OD.....
79.0 mm (3.11 in.) limit of use	
Arm Cylinder Rod End-to-Arm Joint Bushing (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	
Arm Cylinder Rod End-to-Arm Joint Boss (200CLC)—ID	80.0 mm (3.15 in.) nominal ID
81.5 mm (3.21 in.) limit of use	

Bucket (200CLC)—Specification

Bucket Cylinder Head End-to-Arm Joint Pin (200CLC)—OD	71.0 mm (2.80 in.) nominal OD.....
70.0 mm (2.76 in.) limit of use	

Continued on next page

CED, TX08227, 3206 -19-19NOV01-1/4

Hydraulic System

1—Pump Housing	15—Bearing Nut (2 used)	28—Plug (2 used)	43—Drain Plug
2—Lock Washer (6 used)	16—Roller Bearing (2 used)	29—O-Ring	44—O-Ring
3—Cap Screw (6 used)	17—Ring (2 used)	30—Special Fitting	45—Cap Screw (2 used)
4—Spring Pin (4 used)	18—Roller Bearing (2 used)	31—Spring Pin (2 used)	46—Lock Washer (2 used)
5—O-Ring (10 used)	19—Pump 1 (Front) Drive Shaft	32—Oil Seal (2 used)	47—Washer (2 used)
6—O-Ring (2 used)	20—Pin (2 used)	33—Snap Ring (2 used)	48—Pilot Pump
7—Cap Screw (4 used)	21—Center Shaft (2 used)	34—Fill Plug	49—Snap Ring
8—Right Regulator Pump 1 (Front)	22—Spring (2 used)	35—Snap Ring (2 used)	50—Snap Ring
9—Cap Screw (2 used)	23—Piston (14 used)	36—Pump 1 (Front) Driven Gear	51—Ball Bearing
10—Cap Screw (2 used)	24—Cylinder Block (Rotor) (2 used)	37—Gasket	52—Pilot Pump Drive Gear
11—Cap Screw (2 used)	25—Pump 2 (Rear) Drive Shaft	38—Cap Screw (2 used)	53—Pilot Pump Drive Shaft
12—Left Regulator Pump 2 (Rear)	26—Spacer Ring (Pump 2 [Rear] Drive Shaft only)	39—Pump 2 (Rear) Drive Gear	54—Snap Ring
13—O-Ring (4 used)	27—O-Ring (2 used)	40—Dipstick	55—Oil Seal
14—O-Ring (6 used)		41—Dipstick Tube	56—Pump Drive Gearbox
		42—Gasket	57—Set Screw (2 used)
			58—Dampener Drive Coupling

Continued on next page

OJ0E027,0000017 -19-19NOV01-5/21

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

29. For original parts, install drive (E) and driven (F) gears on shafts so timing marks (A, B, and C) are aligned.

For new parts, install the JDG1054 Aligning Bar on the socket (I and J) end of drive shafts.

Install aligning bar so end marked "Long Shaft Side" is to pump 2 (rear) drive shaft (H). Turn shafts so socket alignment dowels (L and M) engage a socket in drive shafts. The socket for pump 1 (front) drive shaft is slightly below the centerline of socket for pump 2 (rear) drive shaft when shafts are timed correctly.

Install cap screws (N) to hold bar in position.


30. From the splined end of shafts, turn shafts to the left to remove any play between socket alignment dowels and sockets.
31. Install gear on pump 2 (rear) drive shaft. Install the snap ring.

Install gear on pump 1 (front) drive shaft. As necessary, turn shaft slightly or turn gear to another position so teeth on gears engage. Install snap ring.


32. Apply oil to center shaft (21), pistons (23) and cylinder blocks (24). Use petroleum jelly to hold pin (20) in hole in center shaft.
33. Install cylinder block so pin engages slot in cylinder block.
34. Apply thread lock and sealer (medium strength) to threads of dowel pins (63). Tighten dowel pins into pump 1 (front) (64) and pump 2 (rear) (65) valve plates.

Hydraulic Pump and Drive Gearbox—Specification

Dowel Pin-to-Pump 1 (Front) and Pump 2 (Rear) Valve Plate—
Torque 9.8 N•m (86 lb-in.)



T105624 -UN-11DEC96



T8323AQ -UN-04OCT94

- A—Pump 1 (Front) Drive Shaft-to-Driven Gear Timing Mark
- B—Driven Gear-to-Drive Gear Timing Mark
- C—Pump 2 (Rear) Drive Shaft-to-Drive Gear Timing Mark
- D—Snap Ring (2 used)
- E—Drive Gear
- F—Driven Gear
- G—JDG1054 Aligning Bar (Pump Timing Tool)
- H—Pump 2 (Rear) Drive Shaft
- I—Socket
- J—Socket
- K—Pump 1 (Front) Drive Shaft
- L—Socket Alignment Dowel
- M—Socket Alignment Dowel
- N—M8-1.25 Cap Screw (2 used)

Pilot Pump Repair

Remove and Install Pilot Pump


CAUTION: The hydraulic oil tank is pressurized. High pressure release of oil can cause serious burns or penetrating injury.

1. Do Hydraulic Oil Tank Vent Procedure. (See procedure in this group.)
2. Drain pump drive gearbox. Approximate oil capacity is 1.0 L (1.1 qt).
3. Pull a vacuum in hydraulic oil tank using a vacuum pump or drain hydraulic oil tank. See 200CLC Drain and Refill Capacities, 230CLC Drain and Refill Capacities, or 270CLC Drain and Refill Capacities. (Operator's Manual.)
4. Disconnect lines.
5. Remove adapter (1).
6. Remove cap screws (2) and pilot pump (3).
7. Repair or replace parts as necessary.
8. Apply Rigid Form-In-Place Gasket to mounting surface for pilot pump.
9. Tighten cap screw (2).

Pilot Pump—Specification

Pump-to-Drive Gearbox Cap
Screw—Torque..... 49 N•m (36 lb-ft)

10. Install adapter (1) and O-ring.
11. Connect lines. See Main Hydraulic System Component Location. (Group 9025-15.)
12. Fill pump drive gearbox so level is above "H" mark on dipstick. See Change Pump Drive Gearbox Oil. (Operator's Manual.)



1—Adapter
2—Cap Screw (2 used)
3—Pilot Pump

T142279B -UN-20JUL01

33
3360
27

Pilot Controller Repair

Remove and Install Pilot Controller



CAUTION: The hydraulic oil tank is pressurized. High pressure release of oil can cause serious burns or penetrating injury.

1. Do Hydraulic Oil Tank Vent Procedure. (See procedure in this group.)
2. Remove covers.
3. Disconnect wiring harness and remove lever.
4. Remove cap screws and remove pilot controller from console.
5. Disconnect lines.
6. Repair or replace parts as necessary.
7. Connect lines. See Main Hydraulic System Component Location. (Group 9025-15.)

NOTE: Position cap screw with spring pin, in lower right hole of controller.

8. Install pilot controller and tighten cap screws.

Pilot Controller—Specification

Pilot Controller-to-Console Cap
Screw—Torque..... 10 N•m (7.2 lb-ft)

9. After pilot controller is installed, check operation of all functions to be sure they operate as shown on decal mounted on console.

Continued on next page

OUE027,000020 -19-19NOV01-1/3

33
3360
37


Hydraulic System

1—Cap Screw (10 used)	9—Gasket	16—O-Ring (7 used)	23—Valve
2—Body	10—Body	17—Spring (4 used)	24—O-Ring
3—Gasket	11—Name Plate	18—Spring	25—Spring
4—Body	12—Screw (4 used)	19—Spring Seat (7 used)	26—Spool
5—Gasket	13—Plate	20—Spool (6 used)	27—Spring
6—Body	14—Cap Screw (11 used)	21—Plate	28—Spring
7—Gasket	15—Plug (7 used)	22—O-Ring	29—Plate
8—Body			

Disassemble and Assemble Pilot Signal Manifold

Continued on next page

OJ0E027.0000027 -19-19NOV01-4/6



T143189

Control Valve—4-Spool

Disassemble and Assemble Control Valve 4-Spool

Continued on next page

TX.33.UU4002 -19-19NOV01-10/18

T143189 -UN-19NOV01

33
3360
57

- Remove cap screws (1), lock washers (2) and washers (3).

CAUTION: Heavy component; use a hoist.

Hydraulic Oil Tank—Specification

Hydraulic Oil Tank—Weight 150 kg (330 lb) approximate

- Remove hydraulic oil tank using a hoist and lifting straps.
- Repair or replace parts as necessary.
- Install hydraulic oil tank (4).
- Tighten cap screws (1).

Hydraulic Oil Tank—Specification

Oil Tank-to-Frame Cap Screw—
Torque 205 N•m (152 lb-ft)

- Connect lines. See Main Hydraulic System Component Location. (Group 9025-15.)


Hydraulic Oil Tank—Specification

T-Bolt Type Clamp—Torque 4.4 N•m (40 lb-in.)
Worm Gear Type Clamp—Torque 5.9—6.9 N•m (52—61 lb-in.)

- Connect electrical connector on bottom of tank.
- Fill hydraulic oil tank. See 200CLC Drain and Refill Capacities, 230CLC Drain and Refill Capacities , 270CLC Drain and Refill Capacities, and Hydraulic Oil. (Operator’s Manual.)

IMPORTANT: Hydraulic pump will be damaged if not filled with oil before starting. Procedure must be performed to fill pump housing whenever oil has been drained from the pump or hydraulic oil tank.

- Do Hydraulic Pump and Drive Gearbox Start-Up Procedure. (See procedure in this group.)



- 1—Cap Screw (4 used)
- 2—Lock Washer (4 used)
- 3—Washer (4 used)
- 4—Hydraulic Oil Tank


T143359 -UN-20JUL01

Continued on next page

OUE027,000022 -19-19NOV01-2/4

33
3360
67

10. Disconnect hydraulic lines (7) from head end of boom cylinder (6).
11. Mark location of shims (8) to aid in assembly.
12. Remove parts (8—11) and remove boom cylinder (6).
13. Repair or replace parts as necessary.
14. Install shims equally on each side of cylinder head end to get the minimum amount of clearance in joint.
15. Align pin bores so Shims are not damaged as pin (10) is installed.
16. Connect boom cylinder head end to frame.
17. Tighten nuts (11) against each other allowing cap screws (9) to be free to turn in hole.



T143048 -UN-02AUG01

- 6—Boom Cylinder
- 7—Rod End-to-Boom Section Bottom Port Line
—Head End-to-Boom Section Top Port Line
- 8—Shim (as required)
- 9—Cap Screw (2 used)
- 10—Boom Cylinder-to-Frame Pin (2 used)
- 11—Nut (4 used)

Specification

Boom Cylinder-to-Frame Pin
 Retainer Nut—200CLC—Torque..... 271 N•m (tighten nut against nut)
 200 lb-ft (tighten nut against nut)

Specification

Boom Cylinder-to-Frame Pin
 Retainer Nut—230CLC,
 270CLC—Torque..... 549 N•m (tighten nut against nut)
 405 lb-ft (tighten nut against nut)

18. Connect lines. See Main Hydraulic System Component Location. (Group 9025-15.)

Tighten boom cylinder hoses.

Specification


Boom Cylinder Hose—200CLC—
 Torque 175 N•m
 130 lb-ft

Specification

Boom Cylinder Hose—230CLC,
 270CLC—Torque..... 206 N•m
 152 lb-ft

Continued on next page

FR91424,0000002 -19-04NOV03-4/6



T106211

Boom Cylinder—200CLC, 270CLC

- | | | | |
|--------------------------------|--------------------------|-----------------------|-------------------------|
| 1—Cylinder Barrel and Bushings | 11—Back-Up Ring | 21—Nut | 32—O-Ring |
| 2—Rod and Bushings | 12—Cap Screw (12 used) | 22—Set Screw | 33—Cap Screw (4 used) |
| 3—Rod Guide | 13—Cushion | 23—Steel Ball | 34—Band |
| 4—Wear Ring | 14—Cushion Seal | 25—Seal (2 used) | 35—Clamp |
| 5—Snap Ring | 15—Piston | 26—Retainer Ring | 36—Cap Screw (2 used) |
| 6—Buffer Ring Seal | 16—Cap Seal and O-Ring | 27—Seal (2 used) | 37—Lock Washer (2 used) |
| 7—U-Cup Seal | 17—Back-Up Ring (2 used) | 28—Hydraulic Line | 38—Half Clamp (2 used) |
| 8—Back-Up Ring | 18—Buffer Seal (2 used) | 29—Hydraulic Line | 39—Cap Screw |
| 9—Wiper Seal | 19—Wear Ring (2 used) | 30—O-Ring | 40—Lock Washer |
| 10—O-Ring | 20—Shim | 31—Cap Screw (4 used) | 41—Lubrication Fitting |

Install boom cylinder barrel and rod bushings to a depth equal to the thickness of seals (25 and 27).

NOTE: The left and right boom cylinders are the same except for the head (28) and rod (29) end lines, and clamps (34 and 35).

NOTE: Use a cylinder repair kit when assembling a cylinder.

20. Install seals (25 and 27) tight against bushing with seal lip outward.

Continued on next page

FR91424,0000003 -19-05NOV03-10/20

T106211 -UN-16JAN97

13. Check for rod curvature on V-blocks using dial indicator.

Specification

Boom Rod—Curvature 0.5 mm per 1 m
0.020 in. per 3.25 ft


14. Inspect rod surface for scratches or wear.

Boom Cylinder—Specification

Boom Rod Allowable Scratch—

Depth 0.1 mm (enough to detect by a
fingernail)
0.004 in. (enough to detect by a
fingernail)

Boom Rod—230CLC—OD..... 89.910—90.0 mm
3.536— 3.540 in.



T6585XG -JUN-27OCT88

15. Repair or replace parts as necessary.


Continued on next page

FR91424,000006 -19-11NOV03-5/8


13. Remove parts (A—D and G).

NOTE: Note direction of flat face (E) on cushion and notches (F) in cushion seal and cushion for assembly.

- A—Nut
- B—Shim
- C—Piston
- D—Cushion
- E—Flat Face
- F—Notch
- G—Cushion Seal



T6585XK -UN-27OCT88



T8286BL -UN-16JUL94

FR91424,000005 -19-11NOV03-7/22

14. Remove ring (A).

Push cushion (C) against shoulder.


Remove retainer ring (B) and remove cushion.

NOTE: Note direction of flat face on cushion and notches in cushion seal for assembly.

Remove cushion seal (D).

15. Remove parts from rod guide and piston.

NOTE: Inspect the piston, inside the rod guide and barrel for wear, scratches and nicks that may cut or damage a seal or wear ring.



T7778AU -UN-10JUN92

Arm Cylinder Rod End Cushion

- A—Ring
- B—Retainer Ring
- C—Cushion Seal
- D—Cushion Seal

33
3360
,107

Continued on next page

FR91424,000005 -19-11NOV03-8/22

49. Apply clean oil to piston and seals. Attach a hoist to rod using a lifting strap. Carefully install piston, rod and rod guide into barrel.

50. Tighten cap screws (A).


Specification

Arm Cylinder Rod Guide-to-Barrel

Cap Screw—Torque 365 N•m
270 lb-ft

51. Install the lines (B).

A—Cap Screw
B—Lines



FR91424,000005 -19-11NOV03-22/22

- 19. Connect lines. See Main Hydraulic System Component Location. (Group 9025-15.)

Tighten bucket cylinder hoses.

Bucket Cylinder—Specification

Bucket Cylinder Hose—	
200CLC—Torque.....	175 N•m 130 lb-ft
Bucket Cylinder Hose—230CLC,	
270CLC—Torque.....	205 N•m 152 lb-ft

IMPORTANT: Trapped air suddenly compressed in a cylinder is heated and ignites the oil used for assembly causing cap seal and ring damage. Start with cylinder rod retraced and the rod end filled with clean oil. Connect the cylinder head end and lines. Operate function to slowly extend rod. Procedure will eliminate most of the air and reduce the possibility of damage.

- 20. Start engine.
- 21. Slowly extend bucket cylinder to align pin bores so shims are not damaged as pin is installed.
- 22. Install shims equally on each side of cylinder rod end and side links to get minimum amount of clearance in joint.
- 23. Connect bucket cylinder head end to arm.
- 24. Tighten nuts against each other allowing cap screw to be free to turn in hole.

Bucket Cylinder—Specification


Bucket Cylinder-to-Pin Retainer	
Nut—Torque	550 N•m (tighten nut against nut) 405 lb-ft (tighten nut against nut)

- 25. Lubricate all pivot joints. See Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease. (Operator’s Manual.)
- 26. Bleed air from cylinder. See Hydraulic Cylinder Bleed Procedure. (Group 3360.)

33
3360
,127

21. Push wear ring (C) to bottom of bore using a driver disk and a press.
22. Install the snap ring (B).
23. Install back-up ring (A) and O-ring (D).

A—Back-Up Ring
B—Snap Ring
C—Wear Ring
D—O-Ring



Continued on next page

FR91424,0000012 -19-21NOV03-11/20

T6585XN -UN-27OCT88

13. Check for rod curvature on V-blocks using dial indicator.

Specification

Bucket Rod—Curvature..... 0.5 mm per 1 m
0.020 in. per 3.25 ft


14. Inspect rod surface for scratches or wear.

Bucket Cylinder—Specification

Bucket Rod Allowable Scratch—

Depth 0.1 mm (enough to detect by a fingernail)
0.004 in. (enough to detect by a fingernail)

Bucket Rod—230CLC—OD 89.910—90.0 mm
3.536— 3.540 in.



T6585XG -JUN-27OCT88

15. Repair or replace parts as necessary.

Continued on next page

FR91424,000013 -19-21NOV03-5/9

Mechanical Drive Elements

14. Do Swing Gearbox Start-Up Procedure. (See procedure in this group.) See Swing Motor Start-Up Procedure . (Group 4360.)


Continued on next page

AGALLARDO,0000039 -19-19NOV01-3/14

43
4350
3

5. Put hardwood blocks (B), approximately 254 mm (10 in.) between lower track rollers (A) and track chain (C).
6. Turn upperstructure back to left side so it is 90° to track.

A—Track Rollers
 B—Hardwood Blocks
 C—Track Chain



T7720AM -UN-07MAY92

TX,43,SB524 -19-19NOV01-3/10

CAUTION: Heavy component; use a hoist.

Upperstructure—Specification


200CLC Machine—Without	
Tracks—Weight	17 330 kg (38,200 lb) approximate
230CLC Machine—Without	
Tracks—Weight	20 329 kg (44,818 lb) approximate
270CLC Machine—Without	
Tracks—Weight	22 453 kg (49,500 lb) approximate

7. Put two DFT1089 Barrel Support under counterweight (D). (Group 9900.)

To provide enough clearance, use bridge planks (E) and hardwood blocks (F) to raise height of supports and planks to 1.4 m (55 in.). Height is approximate clearance needed to clear bottom of rotary manifold. Do not put blocks under cap screw heads. Keep height below maximum.

Upperstructure—Specification

Floor-to-Bottom of Main Frame—	
Height	1.4 m (55 in.) minimum
Height	1.45 m (57 in.) maximum



T7720AS -UN-07MAY92


D—Counterweight
 E—Bridge Plank (As Required)
 F—Hardwood Block (As Required)
 G—DFT1089 Barrel Support (4 used)

Continued on next page

TX,43,SB524 -19-19NOV01-4/10

10. Install loading plug (C).
11. Install taper pin (B) even with top of swing bearing.
12. Tack weld pin (A) to swing bearing.
13. Add multi-purpose grease to swing bearing through lubrication fittings. See Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease. (Operator's Manual.)

A—Tack Weld
B—Taper Pin
C—Loading Plug



T6876FI -UN-07MAY92

Continued on next page

TX,43,SB526 -19-19NOV01-6/8

1—Bearing	13—O-Ring (2 used)	26—Spacer	38—Cap Screw (3 used)
2—Snap Ring	14—Plate	27—Spring	39—Brake Release Valve
3—Dowel Pin (2 used)	15—Cap Screw (4 used)	28—Washer	40—Housing
4—O-Ring	16—O-Ring (2 used)	29—Cylinder Block	41—Shaft
5—Crossover Relief Valve (2 used)	17—Plug (2 used)	30—Pin (12 used)	42—Snap Ring
6—Valve Housing	18—Valve Plate	31—Washer	43—Spacer (2 used)
7—Poppet (2 used)	19—Spring (22 used)	32—Ball Bushing	44—Bearing
8—Spring (2 used)	20—Brake Piston	33—Retainer	45—Snap Ring
9—O-Ring (2 used)	21—O-Ring	34—Piston (9 used)	46—O-Ring
10—Drain Plug (2 used)	22—O-Ring	35—Thrust Plate	47—Oil Seal
11—Cap Screw (4 used)	23—Friction Plate (3 used)	36—Plug	48—Cover
12—O-Ring (2 used)	24—Plate (4 used)	37—O-Ring	49—Snap Ring
	25—Snap Ring		

**Disassemble Swing Motor and Park Brake—
270CLC**

**dropped. Hold valve plate during
disassembly.**



CAUTION: Heavy Component; use a hoist.

Swing Motor and Park Brake—Specification

Swing Motor and Park Brake
(270CLC Machine)—Weight..... 66 kg (150 lb) approximate



CAUTION: Swing motor valve housing and cover is under spring pressure. Remove cap screws evenly to release spring force.

1. Mark alignment of swing motor housing and valve housing assembly. Loosen cap screws (11).

IMPORTANT: Valve plate has a polished surface. Valve plate may remain on valve housing or stay with cylinder block. Valve plate may be damaged if

2. Remove valve plate (18) and springs (19).
3. Remove brake piston (20).
4. Remove parts (29—34) from shaft (41).
5. Remove snap ring (49) from housing (40) to remove cover (48) and O-ring (46).
6. Install cover (48) in vise and remove oil seal (47).
7. Tap shaft (41) assembly lightly and remove from housing (40). Bearing (44), snap rings (42 and 45), and spacers (43) are removed with shaft.
8. Replace parts as necessary.

Continued on next page

TX,4360,DV1356 -19-19NOV01-6/10


DF1063 Lift Bracket

Tool is the same as used on other machines. Only the lift bracket of the tool is used for this machine with adapter DFT1130.

Lift Bracket is used to remove and install propel motor.

Material required:

- 38.1 mm x 76.2 mm x .48 mm (1-1/2 in. x 3 in. x 3/16 in.) Square Tube
- 1.3 mm (1/2 in.) 1020 Steel Plate
- 1 mm x 38.1 mm (3/8 in. x 1-1/2 in.) Cap Screw with Nut (4 used)




99
9900
1

T8318AC -UN-20SEP94

Continued on next page

CED,OUTX818,81 -19-11MAY00-1/2

DF1038 Torque Adapter



T6557CH (CV)

T6557CH -UN-25OCT95

Torque Adapter is used to check rolling drag torque on rotor drive shaft.

- 17 mm (0.125 in.) hex head driver

Material required:

CED,OUTX818,83 -19-11MAY00-1/1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL