



647865EN (14/01/2021)

MHT 10180 MINING 129M ST4 S1

MHT 10230 MINING 129M ST4 S1

MHT- X 10180 MINING 129M ST3A S1

MHT- X 10230 MINING 129M ST3A S1

REPAIR MANUAL

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




Never step on a part of the machine that has not been designed for it.



Never wear clothes, jewelry or objects that could get caught during work and cause accidents.


Always wear protection glasses, gloves, safety shoes as well as any other protection required for the work to be carried out.



When carrying out maintenance operations near a mobile object, make sure it is securitized.



When changing, or draining oils or fuel, or any other operation with liquids, solids, gases that are harmful to the environment, make sure the necessary precautions are taken to avoid contaminating the environment.




GENERAL CONTROL AND ADJUSTMENT





| | pages |
|--|----------|
| STANDARD TIGHTENING TORQUES | 2 |
| LUBRICANTS AND FUEL | 3 |

NETWORKING – SYSTEM OVERVIEW

A4 Motor control module (MCM)
A60 Aftertreatment control module (ACM)



Key

-  Cooled air circuit
-  Intake air circuit
-  Exhaust gas circuit
-  Interaction between components

ENGINE GENERAL INFORMATION

The engine is a water-cooled four-stroke diesel engine with direct injection.

The cylinders are arranged in a row. Each cylinder has two inlet valves and one outlet valve.

Each cylinder has its own fuel injection pump (unit pump) with a short high-pressure fuel injection line to the multi-hole nozzle at the centre of the combustion chamber.

The unit pumps sit directly in the crankcase and are driven by the camshaft.

The engine is equipped with exhaust gas turbocharger and intercooler as standard. The engine can be equipped with optional engine brakes (brake valve and constant throttle valves).

It is a low-emission engine.

Start of injection, injection duration and injection quantity are controlled entirely electronically.


ELECTRONIC ENGINE CONTROL UNIT

The engine has a fully electronic management system which, along with the engine and its associated sensors, consists of the following components:

- engine control unit (MR)
- drive control unit (FR) and/or other vehiclespecific control units, e.g. adaptation module (ADM)
- exhaust gas aftertreatment control unit (only for engines with BlueTec® exhaust gas aftertreatment)

The control units are interconnected by a CAN line (Controller Area Network line), which facilitates the exchange of all necessary data.


FUEL COOLING CIRCUIT



MHT 10180 / MHT 10230 - TIGHTENING TORQUE

ENGINE SUSPENSION ASSEMBLY

When not specified tighten as indicated in the general table



DIAGNOSTIC SOFTWARE PROCEDURES



Fig. J

Start the control panel of the machine. Place the cursor on the icon underlined in the photo and click double to open the program (Fig. J).

10






Fig. K

Click on "MERCEDES BENZ" (Fig. K).




Wait on the display is visualized **"ADM OK"** Ref.1 and push the button **"OK"** Ref.2 (Fig. S).

Fig. S




Turn the starting key of the machine and bring it to position **"0"** Ref.1. Wait that the data progression bar arrives to the end and turn the starting key of the machine and bring it on position **"1"** Ref. 2 (Fig. T).

Fig. T



Push the control button **"<<"** Ref. 1 on the Minidiag2, go on **"01-DIAGNOS."** Ref. 2 and push the button **"OK"** Ref. 3 (Fig. U).

Fig. U






Then go on **"02-MOSTRA MEMORIA ERRORI"** Ref. 1 and push the button **"OK"** Ref.2 (Fig. V).


Fig. V

MHT 10180 / 10230 - REMOVING ENGINE AND RADIATOR

DISASSEMBLY ORDER

10


Step 1**REMOVING THE RADIATOR****Step 2****REMOVING THE RADIATOR HYDRAULIC MOTOR****Step 3****REMOVING THE I.C. ENGINE**



D - REMOVING THE OIL FILTER


Carry out operation B.

Slacken the screw (Ref. 1) and remove the belt tensioner (Ref. 2).



Disconnect the oil inlet pipe (Ref. 1) .

Fix the pipe using a clamp so that it does not slip in the bottom part of the engine housing and oil does not leak out.



Slacken the screw (Ref. 1) to free the alternator (Ref. 2) and rotate it downwards.


Slacken the screws (Ref. 3) which block the oil filter (Ref. 4) on the engine supports and remove the filter from the engine.




E - REMOVING THE FUEL OIL FILTER AND PUMP

Carry out operation A.


Disconnect the fuel incoming and outgoing tubes (Ref. 1) from the filter, taking care to keep these facing upwards to avoid draining the tank.




Disconnect the plug from the engine control unit ECU (Ref. 1).
Disconnect all electrical connections.



Disconnect the exhaust pipe (Ref. 1).



Place an hydraulic jack under the hydrostatic pump and slacken the screws (Ref. 1) which block the engine.



Secure the engine to the overhead crane and slacken the screws (Ref. 1) which fix the engine to the chassis.

| SPN | FMI | DTC | Fault description | Recommended Action | CEL | SEL | MIL | Fault location |
|-----|-----|--------|---|---|-----|-----|-----|----------------|
| 701 | 3 | BD0203 | Digital Output 3/07 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 35/06 (Selection), 35/25 (Fault Detection) and 35/42 (Configuration) for correct configuration of output pin 3/07 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 9" | ON | OFF | OFF | Pin 3/07 |
| 701 | 4 | BD0204 | Digital Output 3/07 Circuit shorted to GND | "Check wiring of associated pin Check parameters 35/06 (Selection), 35/25 (Fault Detection) and 35/42 (Configuration) for correct configuration of output pin 3/07 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 9" | ON | OFF | OFF | Pin 3/07 |
| 701 | 5 | BD0205 | Digital Output 3/07 Open Circuit (broken wire, terminal floating) | "Check wiring of associated pin Check parameters 35/06 (Selection), 35/25 (Fault Detection) and 35/42 (Configuration) for correct configuration of output pin 3/07 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 9" | ON | OFF | OFF | Pin 3/07 |
| 702 | 3 | BE0203 | Digital Output 3/08 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 35/07 (Selection), 35/26 (Fault Detection) and 35/43 (Configuration) for correct configuration of output pin 3/08 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 10" | ON | OFF | OFF | Pin 3/08 |
| 702 | 4 | BE0204 | Digital Output 3/08 Circuit shorted to GND | "Check wiring of associated pin Check parameters 35/07 (Selection), 35/26 (Fault Detection) and 35/43 (Configuration) for correct configuration of output pin 3/08 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 10" | ON | OFF | OFF | Pin 3/08 |
| 702 | 5 | BE0205 | Digital Output 3/08 Open Circuit (broken wire, terminal floating) | "Check wiring of associated pin Check parameters 35/07 (Selection), 35/26 (Fault Detection) and 35/43 (Configuration) for correct configuration of output pin 3/08 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 10" | ON | OFF | OFF | Pin 3/08 |
| 703 | 3 | BF0203 | Digital Output 3/09 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 35/08 (Selection), 35/27 (Fault Detection) and 35/44 (Configuration) for correct configuration of output pin 3/09 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 14" | ON | OFF | OFF | Pin 3/09 |
| 703 | 4 | BF0204 | Digital Output 3/09 Circuit shorted to GND | "Check wiring of associated pin Check parameters 35/08 (Selection), 35/27 (Fault Detection) and 35/44 (Configuration) for correct configuration of output pin 3/09 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 14" | ON | OFF | OFF | Pin 3/09 |
| 703 | 5 | BF0205 | Digital Output 3/09 Open Circuit (broken wire, terminal floating) | "Check wiring of associated pin Check parameters 35/08 (Selection), 35/27 (Fault Detection) and 35/44 (Configuration) for correct configuration of output pin 3/09 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 14" | ON | OFF | OFF | Pin 3/09 |
| 704 | 3 | C00203 | Digital Output 4/07 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 35/16 (Selection), 35/35 (Fault Detection) and 35/52 (Configuration) for correct configuration of output pin 4/07 Run Service Routine (chapter 6.4, routines 15 to 17): – Digital Output Pin Under Software Control: Start Response with Signal Parameter 15" | ON | OFF | OFF | Pin 4/07 |

| SPN | FMI | DTC | Fault description | Recommended Action | CEL | SEL | MIL | Fault location |
|------|-----|--------|--|--|-----|-----|-----|----------------|
| 3842 | 5 | 020F05 | Analog Ground 3/02 Open Circuit (broken wire, terminal floating) | "Check wiring of associated pin Check Parameters 35/05 (Selection) and 35/24 (Fault Detection) for correct configuration." | ON | OFF | OFF | Pin 3/02 |
| 3843 | 3 | 030F03 | Digital Input 1/01 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 13/01 (Selection), 13/35 (Fault Detect Ena) for correct configuration of input pin 1/01" | ON | OFF | OFF | Pin 1/01 |
| 3843 | 4 | 030F04 | Digital Input 1/01 Circuit shorted to GND | "Check wiring of associated pin Check parameters 13/01 (Selection), 13/35 (Fault Detect Ena) for correct configuration of input pin 1/01" | ON | OFF | OFF | Pin 1/01 |
| 3844 | 3 | 040F03 | Digital Input 1/02 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 13/01 (Selection), 13/35 (Fault Detect Ena) for correct configuration of input pin 1/02" | ON | OFF | OFF | Pin 1/02 |
| 3844 | 4 | 040F04 | Digital Input 1/02 Circuit shorted to GND | "Check wiring of associated pin Check parameters 13/02 (Selection), 13/36 (Fault Detect Ena) for correct configuration of input pin 1/02" | ON | OFF | OFF | Pin 1/02 |
| 3845 | 3 | 050F03 | Digital Input 1/12 Circuit shorted to Ubat | "Check wiring of associated pin Check parameter 13/39 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/12" | ON | OFF | OFF | Pin 1/12 |
| 3845 | 4 | 050F04 | Digital Input 1/12 Circuit shorted to GND | "Check wiring of associated pin Check parameter 13/39 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/12" | ON | OFF | OFF | Pin 1/12 |
| 3846 | 3 | 060F03 | Digital Input 1/14 Circuit shorted to Ubat | "Check wiring of associated pin Check parameter 13/40 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/12" | ON | OFF | OFF | Pin 1/14 |
| 3846 | 4 | 060F04 | Digital Input 1/14 Circuit shorted to GND | "Check wiring of associated pin Check parameter 13/40 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/12" | ON | OFF | OFF | Pin 1/14 |
| 3847 | 3 | 070F03 | Digital Input 1/15 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 13/04 (Selection), 13/41 (Fault Detect Ena) for correct configuration of input pin 1/15" | ON | OFF | OFF | Pin 1/15 |
| 3847 | 4 | 070F04 | Digital Input 1/15 Circuit shorted to GND | "Check wiring of associated pin Check parameters 13/04 (Selection), 13/41 (Fault Detect Ena) for correct configuration of input pin 1/15" | ON | OFF | OFF | Pin 1/15 |
| 3848 | 3 | 080F03 | Digital Input 1/16 Circuit shorted to Ubat | "Check wiring of associated pin Check parameter 13/42 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/16" | ON | OFF | OFF | Pin 1/16 |
| 3848 | 4 | 080F04 | Digital Input 1/16 Circuit shorted to GND | "Check wiring of associated pin Check parameter 13/42 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/16" | ON | OFF | OFF | Pin 1/16 |
| 3849 | 3 | 090F03 | Digital Input 1/17 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 13/05 (Selection), 13/43 (Fault Detect Ena) for correct configuration of input pin 1/17" | ON | OFF | OFF | Pin 1/17 |
| 3849 | 4 | 090F04 | Digital Input 1/17 Circuit shorted to GND | "Check wiring of associated pin Check parameters 13/05 (Selection), 13/43 (Fault Detect Ena) for correct configuration of input pin 1/17" | ON | OFF | OFF | Pin 1/17 |
| 3850 | 3 | 0A0F03 | Digital Input 1/11 Circuit shorted to Ubat | "Check wiring of associated pin Check parameter 13/38 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/11" | ON | OFF | OFF | Pin 1/11 |
| 3850 | 4 | 0A0F04 | Digital Input 1/11 Circuit shorted to GND | "Check wiring of associated pin Check parameter 13/38 (Fault Detect Ena) for correct configuration of Fault Detection of pin 1/11" | ON | OFF | OFF | Pin 1/11 |
| 3851 | 3 | 0B0F03 | Digital Input 2/09 Circuit shorted to Ubat | "Check wiring of associated pin Check parameters 13/07 (Selection), 13/46 (Fault Detect Ena) for correct configuration of input pin 2/09" | ON | OFF | OFF | Pin 2/09 |

MHT 10180 / MHT 10230

| SPN | FMI | Fault_name | Fault Description |
|-----|-----|---|---|
| 636 | 10 | Crankshaft Position Sensor Signal Erratic | t.b.d. |
| 636 | 11 | Crankshaft Position Sensor Failure | t.b.d. |
| 636 | 14 | Crankshaft Position Sensor Pins Sw apped | Pins Sw apped |
| 636 | 15 | Phase Shift of CRK Tooth 97 to CAM Tooth 10 is too High (Crankshaft Position - Camshaft Position Correlation) | Phase Shift of CRK tooth 97 to CAM tooth 10 is too high |
| 639 | 14 | J1939 Data Link Failure | CPC 2 Fault |
| 641 | 3 | Turbo Control Circuit Failed High | Short Cut to Battery |
| 641 | 4 | Turbo Control Circuit Failed Low | Short Cut to Ground |
| 641 | 5 | Turbo Control Circuit Open | Open Load |
| 647 | 3 | Fan Stage 1 Circuit Failed High | Short Cut to Battery |
| 647 | 4 | Fan Stage 1 Circuit Failed Low | Short Cut to Ground |
| 647 | 5 | Fan Stage 1 Circuit Failed Open | Open Load |
| 651 | 3 | Injector Cylinder #1 Needle Control Valve, Abnormal Operation (MAX) | Injector Push Error |
| 651 | 4 | Injector Cylinder #1 Needle Control Valve, Abnormal Operation (MIN) | Injector Push Error |
| 651 | 5 | Injector Cylinder #1, Needle Control Valve Circuit Open | Injector Open Load Error |
| 651 | 6 | Injector Cylinder #1 Needle Control Valve, Valve Shorted Circuit | Valve short circuit of injector |
| 651 | 7 | Injector Cylinder #1 Needle Control Valve, Stucks Open | Injector from Cylinder 1 has a sticking needle |
| 651 | 10 | Injector Cylinder #1 Needle Control Valve, Abnormal Rate of Change | Pull-in detection failure |
| 652 | 3 | Injector Cylinder #2 Needle Control Valve, Abnormal Operation (MAX) | Injector Push Error |
| 652 | 4 | Injector Cylinder #2 Needle Control Valve, Abnormal Operation (MIN) | Injector Push Error |
| 652 | 5 | Injector Cylinder #2 Needle Control Valve, Circuit Open | Injector Open Load Error |
| 652 | 6 | Injector Cylinder #2 Needle Control Valve, Valve Shorted Circuit | Valve short circuit of injector |
| 652 | 7 | Injector Cylinder #2 Needle Control Valve, Stucks Open | Injector from Cylinder 2 has a sticking needle |
| 652 | 10 | Injector Cylinder #2 Needle Control Valve, Abnormal Rate of Change | Pull-in detection failure |
| 653 | 3 | Injector Cylinder #3 Needle Control Valve, Abnormal Operation (MAX) | Injector Push Error |
| 653 | 4 | Injector Cylinder #3 Needle Control Valve, Abnormal Operation (MIN) | Injector Push Error |
| 653 | 5 | Injector Cylinder #3 Needle Control Valve, Circuit Open | Injector Open Load Error |
| 653 | 6 | Injector Cylinder #3 Needle Control Valve, Valve Shorted Circuit | Valve short circuit of injector |
| 653 | 7 | Injector Cylinder #3 Needle Control Valve, Stucks Open | Injector from Cylinder 3 has a sticking needle |
| 653 | 10 | Injector Cylinder #3 Needle Control Valve, Abnormal Rate of Change | Pull-in detection failure |
| 654 | 3 | Injector Cylinder #4 Needle Control Valve, Abnormal Operation (MAX) | Injector Push Error |
| 654 | 4 | Injector Cylinder #4 Needle Control Valve, Abnormal Operation (MIN) | Injector Push Error |
| 654 | 5 | Injector Cylinder #4 Needle Control Valve, Circuit Open | Injector Open Load Error |
| 654 | 6 | Injector Cylinder #4 Needle Control Valve, Valve Shorted Circuit | Valve short circuit of injector |
| 654 | 7 | Injector Cylinder #4 Needle Control Valve, Stucks Open | Injector from Cylinder 4 has a sticking needle |
| 654 | 10 | Injector Cylinder #4 Needle Control Valve, Abnormal Rate of Change | Pull-in detection failure |
| 655 | 3 | Injector Cylinder #5 Needle Control Valve, Abnormal Operation (MAX) | Injector Push Error |
| 655 | 4 | Injector Cylinder #5 Needle Control Valve, Abnormal Operation (MIN) | Injector Push Error |
| 655 | 5 | Injector Cylinder #5 Needle Control Valve, Circuit Open | Injector Open Load Error |
| 655 | 6 | Injector Cylinder #5 Needle Control Valve, Valve Shorted Circuit | Valve short circuit of injector |





| SPN | FMI | Fault_name | Fault Description |
|--------|-----|---|--|
| 5588 | 19 | CAN3 Electrical Failure | Timeout of PBS messages |
| 5926 | 3 | Differential Pressure Icooler Out Sensor Circuit Failed High | Compressor Differential Pressure Inlet Failed High |
| 5926 | 4 | Differential Pressure Icooler Out Sensor Circuit Failed Low | Compressor Differential Pressure Inlet Failed Low |
| 5926 | 13 | Icooler Out Differential Pressure Sensor Out of Calibration Low | zero offset compensation too low |
| 5926 | 14 | Icooler Out Differential Pressure Sensor Out of Calibration High | zero offset compensation too high |
| 5926 | 20 | Icooler Out Differential Pressure Plausibility Fault, Pressure too High (Low Box) | Compressor Delta Pressure Failed High |
| 5926 | 21 | Icooler Out Differential Pressure Plausibility Fault, Pressure too Low (High Box) | Compressor Delta Pressure Failed Low |
| 5927 | 2 | Water Pump Limp Home Mode | MU is set if water pump is in limp home mode |
| 5927 | 7 | Water Pump Mechanical Defect Detected | MU is set if an error from PVH is indicated |
| 5928 | 3 | H Bridge 2 EGR Valve Circuit Shorted to Battery | H Bridge 2: Short Cut Battery |
| 5928 | 4 | H Bridge 2 EGR Valve Circuit Shorted to Ground | H Bridge 2: Short Cut to Ground |
| 5928 | 5 | H Bridge 2 EGR Valve Short Circuit/ Over Current | H Bridge 2: Short Cut Open Load |
| 5928 | 14 | H Bridge 2 EGR Valve Circuit Open Load | H Bridge 2 Open Load |
| 520192 | 18 | EGR Feedback on Lambda too Low | EGR Feedback on Lambda to low |
| 520193 | 16 | EGR Feedback on Lambda too High | EGR Feedback on Lambda to high |
| 520194 | 14 | MU_EGR_OBD_3 | spare MU needed for prototyping with V4.1 |
| 520195 | 14 | MU_EGR_OBD_4 | spare MU needed for prototyping with V4.1 |
| 520196 | 14 | MU_EGR_OBD_5 | spare MU needed for prototyping with V4.1 |
| 520197 | 14 | MU_OBD_PROTO_EV_1 | spare event MU needed for prototyping with V4.1 |
| 520198 | 14 | MU_OBD_PROTO_EV_2 | spare event MU needed for prototyping with V4.1 |
| 520199 | 14 | MU_OBD_PROTO_EV_3 | spare event MU needed for prototyping with V4.1 |
| 520200 | 14 | MU_OBD_PROTO_EV_4 | spare event MU needed for prototyping with V4.1 |
| 520201 | 14 | MU_OBD_PROTO_EV_5 | spare event MU needed for prototyping with V4.1 |
| 520204 | 3 | Reserved 2 | TBD4 Temperature Circuit Failed High |
| 520204 | 4 | Reserved 1 | TBD4 Temperature Circuit Failed Low |
| 520205 | 3 | Thermal Switch Circuit Failed High | |
| 520205 | 4 | Thermal Switch Circuit Failed Low | |
| 520206 | 3 | Reserved 4 | TBD3 Temperature Circuit Failed High |
| 520206 | 4 | Reserved 3 | TBD3 Temperature Circuit Failed Low |
| 520208 | 3 | Turbo Compound Valve Circuit Failed High | Short-circuit to battery |
| 520208 | 4 | Turbo Compound Valve Circuit Failed Low | Short-circuit to ground |
| 520208 | 5 | Turbo Compound Valve Circuit Failed Open | Open Load |
| 520210 | 3 | Function 19 Circuit Failed High | Function 19 (reserved) |
| 520210 | 4 | Function 19 Circuit Failed Low | Function 19 (reserved) |
| 520210 | 5 | Function 19 Circuit Failed Open | Function 19 (reserved) |
| 520211 | 3 | Service Push Button Circuit Failed High | |
| 520214 | 3 | Function 22 Circuit Failed High | Function 22 (reserved) |
| 520214 | 4 | Function 22 Circuit Failed Low | Function 22 (reserved) |
| 520214 | 5 | Function 22 Circuit Failed Open | Function 22 (reserved) |
| 520216 | 3 | Function 25 Circuit Failed High | Function 25 (reserved) |
| 520216 | 4 | Function 25 Circuit Failed Low | Function 25 (reserved) |
| 520216 | 5 | Function 25 Circuit Failed Open | Function 25 (reserved) |
| 520217 | 3 | RCP Test Function 1 Circuit Failed High | Short Cut to Battery |
| 520217 | 4 | RCP Test Function 1 Circuit Failed Low | Short Cut to Ground |
| 520217 | 5 | RCP Test Function 1 Circuit Failed Open | Open Load |
| 520218 | 3 | RCP Test Function 2 Circuit Failed High | Short Cut to Battery |

MHT 10180 / MHT 10230

| SPN | FMI | Fault_name | Fault Description | Pin No. | Failure cause |
|------|-----|--|--|----------|------------------------------|
| 3515 | 19 | MU_ISP_UQS_T_DEF_ERR | | | |
| 3516 | 1 | MU_SCR_DIA_UQS_PCT_DEF | | | |
| 3516 | 7 | MU_SCR_DIA_UQS_TMPR_DIAG | | | |
| 3516 | 9 | MU_ISP_UQS_SNA | | | |
| 3516 | 19 | MU_ISP_UQS_CONC_DEF_ERR | | | |
| 3516 | 20 | MU_ISP_UQS_CONC_DRIFT_HI | | | |
| 3516 | 21 | MU_ISP_UQS_CONC_DRIFT_LO | | | |
| 3517 | 1 | DEF Tank Level - Zone 4 | | | |
| 3517 | 9 | MU_ISP_CAN_L_DEF_TANK_SRH | | | |
| 3517 | 14 | DEF Tank Level - Zone 2 | | | |
| 3517 | 17 | DEF tank level check - Lim1 reserve | | | |
| 3517 | 18 | DEF Tank Level - Zone 3 | | | |
| 3517 | 19 | DEF Tank Signal Erratic via CAN | | | |
| 3517 | 31 | MU_TRC_L_DEF_TANK_LIM_5 | | | |
| 3521 | 31 | MU_SCR_DIA_UQS_IS_DIESEL | | | |
| 3523 | 8 | Regen Frequency Error | | | |
| 3556 | 0 | Regen Temperature - Out of Range High | | | |
| 3556 | 1 | Regen Temperature - Out of Range Low | | | |
| 3556 | 18 | DOC Outlet Temp Low (Low Temp Regen) | | | |
| 3597 | 3 | High Side Digital Output 1 Circuit Failed High | Short circuit to battery on HS1_SCR | 1,3,5 | output is shorted to battery |
| 3597 | 4 | High Side Digital Output 1 Circuit Failed Low | Short circuit to ground on HS1_SCR | 1,3,5 | output is shorted to ground |
| 3598 | 3 | High Side Digital Output 2 Circuit Failed High | Short circuit to battery on HS2 (HS_DPF) | 21,23,25 | output is shorted to battery |
| 3598 | 4 | High Side Digital Output 2 Circuit Failed Low | Short circuit to ground on HS2 (HS_DPF) | 21,23,25 | output is shorted to ground |
| 3599 | 3 | High Side Digital Output 3 Circuit Failed High | Short circuit to battery on HS3_SCR | 15,39,9 | output is shorted to battery |
| 3599 | 4 | High Side Digital Output 3 Circuit Failed Low | Short circuit to ground on HS3_SCR | 15,39,9 | output is shorted to ground |
| 3609 | 3 | DOC Inlet Pressure Circuit Failed High | | 87 | |
| 3609 | 4 | DOC Inlet Pressure Circuit Failed Low | | 87 | |
| 3609 | 8 | DOC Inlet Pressure Signal Spike | DPF In Pressure sensor sporadic def ect | 87 | |
| 3609 | 10 | DOC Inlet Pressure Sensor Stuck | | | |
| 3609 | 21 | DPF Inlet Pressure - Drift Low | | | |
| 3610 | 0 | DPF System Back Pressure Too High | | | |
| 3610 | 2 | DPF Outlet Pressure Sensor - Not Plausible | | | |
| 3610 | 3 | DPF Outlet Pressure Circuit Failed High | | 72 | |
| 3610 | 4 | DPF Outlet Pressure Circuit Failed Low | | 72 | |
| 3610 | 7 | DPF Outlet Pressure High | | | |
| 3610 | 8 | DPF Outlet Pressure Signal Spike | DPF Out Pressure sensor sporadic def ect | 72 | |
| 3610 | 10 | DPF Outlet Pressure Sensor Stuck | | | |

MHT-X 10180 / MHT-X 10230

FAULT CODES

The background colour  is used to indicate the newly supported or changed fault codes since diagnosis version 207. The background colour  is used to indicate the newly supported or changed fault codes since diagnosis version 210. The background colour  is used to indicate the newly supported or changed fault codes since diagnosis version 211. The background colour  indicates PLD/MR2 fault codes which are received from the PLD/MR2 control unit and are broadcasted by the ADM over J1939.

| ADM3 fault code (J1939) SPN / FMI | "ADM3 fault code (K-line)" | "MR2 fault code (K-line)" | Fault location | Fault description | Remedial action | Pin |
|-----------------------------------|----------------------------|---------------------------|-----------------------------------|--------------------------------|--|-----------|
| 51 / 0 | - | 12419 | Engine Throttle Position | Above Measuring Range | | LSCAN-MR |
| 51 / 1 | - | 12420 | Engine Throttle Position | Below Measuring Range | | LSCAN-MR |
| 51 / 2 | - | 12424 | Engine Throttle Position | Measuring Range Not Plausible | | LSCAN-MR |
| 51 / 2 | - | 14217 | Engine Throttle Position | Performance | | LSCAN-MR |
| 51 / 3 | - | 14205 | Engine Throttle Position Sensor | Circuit High | | LSCAN-MR |
| 51 / 4 | - | 14206 | Engine Throttle Position Sensor | Circuit Low | | LSCAN-MR |
| 51 / 7 | - | 12431 | Engine Throttle Position | Defective | | LSCAN-MR |
| 51 / 13 | - | 14218 | Engine Throttle Position | Position Not Learned | | LSCAN-MR |
| 69 / 9 | 17309 | - | Two Speed Axle Switch | Abnormal Update Rate | | CAN-J1939 |
| 69 / 19 | 17319 | - | Two Speed Axle Switch | Received Network Data in Error | | CAN-J1939 |
| 70 / 9 | 17409 | - | Parking Brake Switch | Abnormal Update Rate | | CAN-J1939 |
| 70 / 19 | 17419 | - | Parking Brake Switch | Received Network Data in Error | | CAN-J1939 |
| 84 / 3 | 10103 | - | Vehicle Speed (C3 or J1939) | Open Circuit | - Check wiring | 15/03 |
| 84 / 9 | 10109 | - | Vehicle Speed (C3 or J1939) | Abnormal Update Rate | | CAN-J1939 |
| 84 / 14 | 10114 | - | Vehicle Speed (C3 or J1939) | Signal Not Plausible | - Check wiring | 15/03 |
| 84 / 19 | 10119 | - | Vehicle Speed (C3 or J1939) | Received Network Data in Error | | CAN-J1939 |
| 91 / 0 | 10200 | - | Accelerator Pedal (AFPS or J1939) | Not Adjusted | "- Restart accelerator pedal adjustment routine - Check wiring - Limit value idle operation position: 5,0 V - Limit value kickdown position: 4,9 V" | 21/11 |
| 91 / 3 | 10203 | - | Accelerator Pedal (AFPS or J1939) | Voltage too High | "- Pedal unit exchange, if defective - check wiring - Limit value idle operation position: 5,0 V - Limit value kickdown position: 4,9 V" | 21/11 |
| 91 / 4 | 10204 | - | Accelerator Pedal (AFPS or J1939) | Voltage too Low | "- Pedal unit exchange, if defective - Check wiring - Limit value idle operation position: 5,0 V - Limit value kickdown position: 4,9 V" | 21/11 |

MHT-X 10180 / MHT-X 10230

| ADM3 fault code (J1939) SPN / FMI | "ADM3 fault code (K-line)" | "MR2 fault code (K-line)" | Fault location | Fault description | Remedial action | Pin |
|-----------------------------------|----------------------------|---------------------------|---|--|--|----------|
| 974 / 2 | 14202 | - | Remote Throttle Pedal (HFG) | Supply Voltage Out of Range (Pin HFG+) | - Limit values for the supply voltage of the HFG: Minimum value: 4,8 V and maximum value: 5,2 V. | 18/17 |
| 974 / 3 | 14203 | - | Remote Throttle Pedal (HFG) | Voltage too High | | 18/18 |
| 974 / 4 | 14204 | - | Remote Throttle Pedal (HFG) | Voltage too Low | | 18/18 |
| 986 / 1 | - | 10631 | Fan Speed | Speed Too Low | | LSCANMR |
| 986 / 9 | - | 10612 | Fan Speed | Time Out | | LSCANMR |
| 986 / 9 | - | 17112 | Fan Speed | Time Out | | LSCANMR |
| 1004 / 3 | 14403 | - | Output Relay 4 (REL 4) | Open Circuit | | 18/01 |
| 1004 / 4 | 14404 | - | Output Relay 4 (REL 4) | Short Circuit to Ground | | 18/01 |
| 1005 / 3 | 14503 | - | Output PWM Pedal Supply or Transmission (FP+) | Open Circuit | | 15/05 |
| 1005 / 4 | 14504 | - | Output PWM Pedal Supply or Transmission (FP+) | Short Circuit to Ground | | 15/05 |
| 1015 / 1 | 15001 | - | PWM Accelerator Pedal (PWM FFG) | No Supply Voltage at Pin FP+ | - Check wiring | 15/05 |
| 1015 / 3 | 15003 | - | PWM Accelerator Pedal (PWM FFG) | No Signal at Path 2 (GAS2) | "- Check wiring - Pins 21/13, 15/05 , 21/14." | |
| 1015 / 4 | 15004 | - | PWM Accelerator Pedal (PWM FFG) | No Signal at Path 1 (GAS1) | "- Check wiring - Pins 21/12, 15/05 , 21/14" | |
| 1015 / 5 | 15005 | - | PWM Accelerator Pedal (PWM FFG) | Not Adjusted | "- Restart accelerator pedal adjustment routine" | - |
| 1015 / 6 | 15006 | - | PWM Accelerator Pedal (PWM FFG) | Idle Position Out of Adjusted Range | "- Restart accelerator pedal adjustment routine" | - |
| 1015 / 7 | 15007 | - | PWM Accelerator Pedal (PWM FFG) | Out of Adjusted Range | "- Restart accelerator pedal adjustment routine" | - |
| 1072 / 3 | 10003 | - | Decompression Brake Valve (MBR_KD) | Open Circuit | "- Check wiring - Check solenoid valve" | 15/10 |
| 1072 / 4 | 10004 | - | Decompression Brake Valve (MBR_KD) | Short Circuit to Ground | "- Check wiring - Check solenoid valve" | 15/10 |
| 1074 / 3 | 14603 | - | Exhaust Brake Valve (MBR_BK) | Open Circuit | "- Check wiring - Check exhaust brake valve" | 15/06 |
| 1074 / 3 | - | 14256 | Exhaust Brake Valve (PLD/MR2) | Circuit High | | LSCAN-MR |
| 1074 / 4 | 14604 | - | Exhaust Brake Valve (MBR_BK) | Short Circuit to Ground | "- Check wiring - Check exhaust brake valve" | 15/06 |
| 1074 / 4 | - | 14255 | Exhaust Brake Valve (PLD/MR2) | Circuit Low | | LSCAN-MR |
| 1074 / 5 | - | 14257 | Exhaust Brake Valve (PLD/MR2) | Circuit Open | | LSCAN-MR |
| 1074 / 12 | - | 14254 | Exhaust Brake Valve (PLD/MR2) | Performance | | LSCAN-MR |
| 1127 / 1 | - | 14259 | Intake Throttle Turbocharger | Underboost | | LSCAN-MR |
| 1132 / 3 | - | 13115 | Intake Air Temperature Sensor 2 | Circuit High | | LSCAN-MR |
| 1132 / 4 | - | 13116 | Intake Air Temperature Sensor 2 | Circuit Low | | LSCAN-MR |
| 1136 / 0 | - | 14273 | Engine ECU Temperature | Temperature too High | | LSCAN-MR |

MINIDIAG 2 - RECOVERY RELEASE 2_5.02.69




N° 1 - Minidiag 2 - Powertrain Business Unit Engines

N° 1 - ODB cable

 **The Minidiag 2 has to be in version recovery release 2_5.02.69**


FORWARD GEAR SCHEMATIC DIAGRAM



PUMP / MOTOR CONTROL AND ADJUSTMENT


1 - TRANSMISSION ADJUSTMENT POINTS


A4VG 110 DA SERIES 40 PUMP




Key:

- 1 - HP (High Pressure) limiter
- 2 - Bypass function
- 3 - Circuit selector
- 4 - Pressure cut-off (DR)
- 5 - Boost relief valve
- 6 - Circuit selector stop screw







TRANSMISSION REFIT

| | pages |
|---|----------|
| REFITTING THE HYDROSTATIC TRANSMISSION | 2 |
| – GENERAL INFORMATION | 2 |
| – PREPARATION AND SAFETY INSTRUCTIONS | 2 |
| – REFITTING THE UNIVERSAL SHAFTS..... | 3 |
| – REFITTING THE HYDRAULIC MOTOR | 4 |
| – REFITTING THE GEAR | 5 |
| – REFITTING THE PUMPS..... | 6 |
| – REFITTING THE MOVEMENT PUMP | 6 |
| – REFITTING THE SERVICES PUMP | 6 |
| – REFITTING THE HYDROSTATIC PUMP..... | 7 |

DIGITAL GAUGE KIT



FUNCTIONS:


- **Gauge function:** the display allows the following combinations:
 - ⇒ The upstream pressure temperature at +/- 2°C
 - ⇒ The upstream temperature P1 with its mini and maxi (700 bar in class 0.1)
 - ⇒ Downstream pressure P2 with its min. and max. (700 bar in class 0.1)
 - ⇒ Differential pressure $\Delta P = P1 - P$
- **Hold function:** The user can freeze the screen display at any time to take notes
- **Unit function:** The user can change the unit of measurement at any time (bar, psi, kPa, mCe).
- **Function Tare:** Enables offset to zero
- **Leak test function:** Can measure a pressure variation over a specified time
- **Record function:** A maximum of 16000 readings can be recorded. The sampling period can be configured.
- **Reset function:** The 2 sensors are reset to zero

Digital Manometer kit.....662187

Consisting of:


- 1 - 1 digital gauge ΔP HP 700 bar
- 2 - 1 measurement hose DN2 1215/1620, L = 1,5m, 630 bar
- 3 - 2 measurement hoses DN2 1620/1620, L = 1,5m, 630 bar
- 4 - 2 gauge adaptors 1620

BRAKE CIRCUIT




DEACTIVATE THE NEGATIVE BRAKE (S.A.H.R - SPRING APPLIED HYDRAULIC RELEASE) TYPE 1

- 1 - Place stop blocks behind the wheels and secure the telescopic handler.
- 2 - Unscrew the cap's (2) on all four actuators(3) (a little bit of hydraulic oil may seep out of each actuator), always keep a suitable container underneath each actuator until the cap's have been replaced.
- 3 - Allen key size 17mm.
- 4 - Remove the retaining springs(4) on all four actuators(3).
- 5 - (In no particular order) starting with one actuator (3) at a time loosen the lock nut (5) , loosen the actuator shaft adjuster (6) / (7). Once the actuator shaft adjuster (6) / (7) turns freely then the brake mechanism pertaining the specific actuator is fully released.
- 6 - Socket sizes – 17 mm & 19 mm long type - or Special Tool.
- 7 - Repeat the procedure in step "5" for the remaining actuators until all four brake mechanisms is fully released.
- 8 - Replace all the retaining springs(4) and caps(2) on all the actuators(3); ensure the lock nuts(5) are lightly tightened.





Note: In the absence of hydraulic servo-assistance of the direction and at the brakes, act slowly and forcibly on these two commands. Avoid sudden movements and jerks if the telescopic handler needs to be towed.

TIGHTENING TORQUES





BRAKE REFIT

Install the master-cylinder (Ref. 2) and attach with the two fastening screws (Ref. 1), to be tightened to the standard torque.



Attach the master cylinder (Ref. 1) to the brake pedal (Ref. 2) ensuring that the friction washers (Ref. 3) are correctly positioned.


40






Install the lower dashboard casing (Ref. 1) and attach with two screws (Ref. 2).




Install the mat (Ref. 1).




CABLE REEL ADJUSTMENT






Slacken the screw (Ref. 1) and its nut to release the top pin (Ref. 2) of the slewing cylinder.



Remove the top pin (Ref. 1) which blocks the slewing cylinder on the boom head.




With the help of an overhead crane (Ref. 1), lower the cylinder until it comes out of the boom head.



Remove the slewing cylinder (Ref. 1) from the vehicle.

REASSEMBLING THE SLEWING CYLINDER


Insert the chain of the overhead crane (Ref. 1) in the slot on the top of the boom and fix the chain to the head of the slewing cylinder or to an eyebolt fitted on the cylinder.




With the help of an overhead crane lift the slewing cylinder (Ref. 1) at the top of the boom.




Insert the upper hinge pin (Ref. 3) to block the slewing cylinder to the boom.




Fit the screw (Ref. 4) and its nut to block the top pin (Ref. 3) of the slewing cylinder.






HYDRAULIC CHARACTERISTICS AND SPECIFICATIONS


| | pages |
|---------------------------------------|----------|
| PRESSURE TAKE-OFF POINTS | 2 |
| – A11VO DA SERIES 10 PUMP | 2 |





REMOVING THE DIRECTIONAL CONTROL VALVE

Removing carter rear upper(Ref. 1), carter rear lower (Ref. 2) and oil cooler (Ref. 3), as seen in the picture to access the directional control valve.




Place a container under the machine.


Mark all electrical connections, all tubes and attacks with a marker ,before disassembly to ensure proper repositioning when reassembling

Remove the tubes from the directional control valve and disconnect the electric connectors from the directional control valve.

⚠ Plug all the pipes and connectors to prevent impurities from contaminating the hydraulic circuit.



Slacken the screws (Ref. 1) secure the distributor to appropriate lifting means and unscrew the screws (Item 1) and washers.




Remove the directional control valve (Ref. 1) from the vehicle.




REFITTING THE DIRECTIONAL CONTROL VALVE


Reposition the directional control valve on the vehicle using the appropriate lift means.



Block the directional control valve (Ref. 1) on the truck frame by means of the screws (Ref. 2).



Reconnect all the electrical connections and hydraulic pipes on the directional control valve (Ref. 1), taking care to reposition them correctly, by following the markings made in the disassembly phase.




Refit the upper rear carter (Ref . 1) , the rear lower carter (Ref . 2) and radiator (Ref . 3) , as seen in the picture with appropriate screws.

ELECTRICITY

- **ELECTRICAL CHARACTERISTICS AND SPECIFICATIONS**
- **ELECTRICAL SCHEMATIC DIAGRAMS**
- **ELECTRICAL COMPONENTS LOCATION**
- **ELECTRICAL CONTROL AND ADJUSTMENT**
- **ELECTRICAL TROUBLESHOOTING**
- **ELECTRICAL SPECIFIC TOOLING**



647954
RADIOCONTROL ATEC
DYNAMIC
(Installation manual)



80



647955
RADIOCONTROL ATEC
DYNAMIC
(Service manual)



647805
RADIOCONTROL ATEC
SERIE DYNAMIC PLUS
(Repair manual)

| | | | | |
|---------------|---------------|---------------|----------------|--------------|
| X742 □ A108 | X837 □ A120 | X900.S □ A83 | X997.2 □ A114 | XB.P □ A132 |
| X743 □ A108 | X838.P □ A133 | X911 □ A112 | X998 □ A73 | XC.S □ A111 |
| X744 □ A109 | X838.S □ A118 | X911.P □ A16 | X998 □ A74 | XF56 □ A93 |
| X745 □ A109 | X850.1 □ A95 | X911.S □ A16 | X998 □ A75 | XF56 □ A94 |
| X746 □ A110 | X850.2 □ A95 | X911.S □ A135 | X998 □ A85 | XF59 □ A94 |
| X747 □ A110 | X851.1 □ A95 | X912 □ A112 | X998 □ A86 | XF60 □ A93 |
| X748 □ A110 | X851.2 □ A95 | X912.P □ A16 | X998 □ A87 | XF60 □ A94 |
| X748.S □ A142 | X870.1 □ A95 | X912.S □ A16 | X998.1 □ A114 | XFEM.P □ A96 |
| X750 □ A70 | X870.2 □ A95 | X912.S □ A17 | X998.2 □ A114 | XFEM.S □ A97 |
| X750 □ A82 | X870.S □ A52 | X913.P □ A17 | X999 □ A114 | XFM □ A134 |
| X757 □ A98 | X871 □ A52 | X913.S □ A17 | X1000 □ A53 | XGF □ A142 |
| X757.S □ A50 | X871.1 □ A95 | X918 □ A10 | X1000.P □ A104 | XL1 □ A142 |
| X761 □ A16 | X871.2 □ A95 | X927 □ A120 | X1000.P □ A139 | XL2 □ A142 |
| X762 □ A16 | X872 □ A52 | X936.P □ A17 | X1001 □ A54 | XL3 □ A142 |
| X765.S □ A16 | X875.1 □ A52 | X936.S □ A17 | X1001.P □ A96 | XL4 □ A142 |
| X771.S □ A119 | X875.S □ A52 | X936.S □ A120 | X1002 □ A75 | XOPT1 □ A112 |
| X777 □ A135 | X877.P □ A53 | X936.S □ A126 | X1002 □ A87 | XOPT2 □ A112 |
| X778 □ A135 | X877.P □ A120 | X936.S □ A132 | X1002.P □ A54 | XP □ A135 |
| X791 □ A116 | X877.S □ A53 | X977 □ A17 | X1002.P □ A75 | XP1 □ A99 |
| X791 □ A130 | X880 □ A53 | X978 □ A70 | X1002.P □ A87 | XP2 □ A99 |
| X792.S □ A117 | X881 □ A53 | X978 □ A83 | X1002.P □ A112 | XRE □ A135 |
| X793.S □ A131 | X888 □ A70 | X987 □ A128 | X1002.P □ A141 | |
| X793.S □ A133 | X888 □ A82 | X989 □ A128 | X1002.S □ A54 | |
| X794.P □ A117 | X888A □ A133 | X991 □ A71 | X1003 □ A75 | |
| X794.P □ A126 | X888A □ A134 | X991 □ A83 | X1003 □ A87 | |
| X794.P □ A131 | X889 □ A70 | X992 □ A71 | X1004 □ A75 | |
| X794.S □ A117 | X889 □ A82 | X992.1 □ A120 | X1004 □ A87 | |
| X794.S □ A131 | X889 □ A133 | X992.2 □ A120 | X1005 □ A54 | |
| X802 □ A50 | X889 □ A134 | X993.P □ A118 | X1005 □ A55 | |
| X804/A □ A122 | X889.S □ A112 | X993.P □ A131 | X1006 □ A55 | |
| X804/B □ A122 | X890 □ A82 | X993.S □ A71 | X1006 □ A56 | |
| X804.P □ A119 | X890 □ A134 | X993.S □ A83 | X1007 □ A56 | |
| X804.S □ A50 | X890.P □ A70 | X993.S □ A113 | X1008 □ A75 | |
| X806 □ A50 | X890.S □ A70 | X993.S □ A120 | X1008 □ A87 | |
| X807.P □ A51 | X891.P □ A70 | X995 □ A121 | X1009 □ A87 | |
| X807.P □ A101 | X891.S □ A70 | X995.S □ A71 | X1010 □ A56 | |
| X807.S □ A51 | X892.S □ A70 | X995.S □ A71 | X1011.P □ A57 | |
| X808.P □ A51 | X892.S □ A83 | X996 □ A113 | X1011.S □ A88 | |
| X808.P □ A113 | X894 □ A70 | X997 □ A72 | X1020 □ A57 | |
| X808.S □ A51 | X894 □ A83 | X997 □ A73 | X1021 □ A57 | |
| X812 □ A51 | X895 □ A53 | X997 □ A83 | X1022 □ A57 | |
| X817 □ A51 | X899.1 □ A113 | X997 □ A84 | XB □ A112 | |
| X819 □ A52 | X899.2 □ A113 | X997 □ A85 | XB.P □ A125 | |
| X821 □ A52 | X900 □ A135 | X997.1 □ A114 | XB.P □ A126 | |

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| X912.s | 1 | | | | |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | | | | |
| | 5 | | | | |
| | 6 | | | | |
| X913.p | 1 | C | 1 | X162.s/10 | 0F70 |
| | 2 | N | 1 | Gnd3.1 | |
| | 3 | B | 1 | X162.s/11 | 7368 |
| | 4 | V | 1 | X162.s/12 | 3058 |
| X913.s | 1 | | | | |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | | | | |
| X936.p | 1 | Z | 1 | X162.s/2 | F100 |
| | 2 | N | 1 | Gnd3.1 | |
| X936.s | 1 | | | | |
| | 2 | | | | |
| X977 | 1 | SCH | 0.32 | SA32 | |
| | 2 | R | 0.32 | SA30 | |
| | 3 | N | 0.32 | SA31 | |
| | 4 | B | 0.2 | SA34 | |
| | 5 | L | 0.2 | SA33 | |

CABIN LINE

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| A | 1 | SCH | | SA105 | |
| B | 1 | SCH | | SA122 | |
| C | 1 | SCH | | SA117 | |
| D | 1 | SCH | | SA114 | |
| E | 1 | SCH | | SA108 | |
| Gnd5.1 | - | N | 1 | X446/2 | |
| | | N | 1 | X452/24 | |
| | | N | 1 | X817/2 | |
| | | N | 1 | x1022/2 | |
| | | N | 1 | X444/8 | |
| | | N | 1 | X412/1 | |
| | | N | 0.5 | X625/1 | |
| | | N | 1 | X880/5 | |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|------------------|------------|---------------|----------------------|------------------|----------------|
| X103.p | 1 | M | 2.5 | SA73 | 0005 |
| | 2 | R | 4 | X807.s/1 | F206 |
| | 3 | R | 2.5 | X469/1 | 0F56 |
| | 4 | M | 2.5 | SA91 | 0013 |
| | 5 | H | 1 | X434/R37 | 1008 |
| | 6 | B | 1 | SA67 | 6527 |
| | 7 | | | | |
| | 8 | M | 1 | SA72 | |
| | 9 | L | 1 | X470/21 | |
| | 10 | G | 1 | X470/19 | |
| | 11 | B | 1 | X433/9 | 6905 |
| | 12 | B | 1 | X434/R36 | 7405 |
| | 13 | | | | |
| | 14 | H | 1 | SA74 | 1007 |
| | 15 | B | 1 | SA89 | 6353 |
| | 16 | | | | |
| | 17 | C | 1 | X436.2/6 | 0400 |
| | 18 | B | 1 | X434/L33 | 6021 |
| | 19 | B | 1 | X454/22 | 6744 |
| | 20 | C | 0.5 | SA59 | 00F2 |
| | 21 | | | | |
| | 22 | G | 1.5 | X407/R1_87 | 2010 |
| | 23 | G | 1.5 | X407/R2_87 | 2009 |
| | 24 | G | 1 | SA69 | 2001 |
| | 25 | G | 1 | X459/7 | 2003 |
| | 26 | | | | |
| | 27 | V | 1 | X433/19 | 3325 |
| | 28 | B | 1.5 | X404.s/6 | 6100 |
| | 29 | V | 1 | X433/20 | 3061 |
| X118.p | 1 | B | 1 | X118.p | |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | | | | |
| | 5 | | | | |
| | 6 | | | | |
| | 7 | B | 1 | X118.p/1 | |
| | 8 | | | | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|-------------|-----|--------|---------------|-----------|---------|
| X422 | 1 | | | | |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | N | 1 | Gnd6.2 | |
| | 5 | B | 0.5 | SA95 | 6162 |
| | 6 | G | 0.5 | SA55 | |
| | 7 | | | | |
| | 8 | C | 0.5 | X1007/F7b | F149 |
| | 9 | | | | |
| | 10 | | | | |
| | 11 | | | | |
| | 12 | | | | |
| | 13 | | | | |
| | 14 | V | 0.5 | SA61 | |
| | 15 | | | | |
| | 16 | R | 1 | X1007/F8b | F148 |
| | | R | 0.5 | X415/16 | F148 |
| X432 | 1 | C | 2.5 | SA64 | 0407 |
| | 2 | C | 2.5 | SA64 | 0407 |
| | 3 | C | 2.5 | SA64 | 0407 |
| | 4 | N | 2.5 | Gnd7 | |
| X433 | 1 | C | 1 | SA62 | |
| | 2 | V | 1 | X160.p/2 | 3323 |
| | 3 | B | 1 | X877.s/6 | 6561 |
| | 4 | V | 1 | X160.p/23 | 3057 |
| | 5 | A | 1 | X160.p/10 | 1391 |
| | 6 | A | 1 | X160.p/11 | 1390 |
| | 7 | G | 0.5 | SA129 | |
| | 8 | V | 1 | X162.p/4 | 3336 |
| | 9 | B | 1 | X103.p/11 | 6905 |
| | 10 | A | 1 | X160.p/30 | 1337 |
| | 11 | Z | 1 | X128.p/1 | 0600 |
| | 12 | B | 1 | X450/B | 6877 |
| | 13 | B | 1 | X466/2 | 6435 |
| | 14 | V | 1 | X162.p/12 | 3058 |
| | 15 | V | 1 | X128.p/7 | 3309 |
| | 16 | V | 1 | X128.p/14 | 3310 |
| | 17 | V | 1 | X160.p/7 | 3012 |
| | 18 | V | 1 | X160.p/1 | 3013 |
| | 19 | V | 1 | X103.p/27 | 3325 |
| | 20 | V | 1 | X103.p/29 | 3061 |
| | 21 | M | 1 | SA91 | 0013 |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|------------------|------------|---------------|----------------------|------------------|----------------|
| X468 | 1 | | | | |
| | 2 | | | | |
| | 3 | A | 0.5 | X449/4 | 1332 |
| | 4 | M | 1 | SA73 | 0005 |
| | 5 | | | | |
| | 6 | A | 0.5 | X449/3 | 1331 |
| | 7 | B | 0.5 | X449/1 | 6843 |
| | 8 | B | 0.5 | X449/5 | 6841 |
| | 9 | | | | |
| | 10 | | | | |
| | 11 | | | | |
| | 12 | | | | |
| | 13 | | | | |
| | 14 | | | | |
| | 15 | | | | |
| | 16 | | | | |
| | 17 | | | | |
| | 18 | H | 1 | X434/L10 | 1072 |
| | H | 1 | X1002.s/2 | 1072 | |
| X469 | 1 | R | 2.5 | X103.p/3 | 0F56 |
| | 2 | M | 1.5 | SA73 | 0005 |
| | 3 | B | 1.5 | SA67 | 6527 |
| | 4 | | | | |
| | 5 | | | | |
| | 6 | | | | |
| | 7 | | | | |
| | 8 | | | | |
| | 9 | | | | |
| | 10 | | | | |
| | 11 | | | | |
| | 12 | | | | |
| | 13 | | | | |
| | 14 | B | 1 | X118.s/2 | 7790 |
| | 15 | B | 1 | X118.s/3 | 7791 |
| | 16 | V | 0.5 | X472/A | |
| | | V | 0.5 | SA121 | |
| | 17 | B | 1 | SA7 | 6162 |
| 18 | G | 0.5 | X472/B | | |
| | G | 0.5 | SA120 | | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|----------------|-----|--------|---------------|-----------|---------|
| X1011.p | A | B | 0.5 | SA260 | 6358 |
| | B | | | | |
| | C | L | 0.5 | X806/F | |
| | D | | | | |
| | E | | | | |
| | F | B | 0.5 | X806/G | |
| | G | | | | |
| | H | B | 0.5 | SA261 | 6162 |
| | J | G | 0.5 | SA129 | |
| | K | V | 0.5 | SA130 | |
| | L | Z | 1 | X160.p/4 | 0609 |
| | M | B | 1 | X160.p/6 | 6054 |
| | N | C | 1 | X1020/2 | 0F80 |
| | P | R | 1 | X345.s/5 | F302 |
| | R | M | 1 | X345.s/6 | 0005 |
| | S | A | 1 | X160.p/12 | 1316 |
| | T | A | 1 | X160.p/14 | 1350 |
| | U | A | 1 | X345.s/7 | 1339 |
| | V | A | 1 | X345.s/8 | 1340 |
| | W | C | 1 | X1006/F2b | 0F18 |
| X | | | | | |
| X1020 | 1 | C | 1 | SA63 | 0400 |
| | 2 | C | 1 | X1011.p/N | 0F80 |
| X1021 | 1 | C | 1 | X1005/F5b | 00F5 |
| | 2 | B | 1 | X618/1 | 8012 |
| X1022 | 1 | 2 | X1007/F9b | F150 | |
| | 2 | 2 | Gnd5.1 | | |

ENGINE LINE MHT 10180 / 10230

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|-------------|-----|--------|---------------|-----------|---------|
| B | 1 | SCH | | SA20 | |
| D | 1 | SCH | | SA25 | |
| Gnd1 | - | N | 2 | X325/B | |
| | | N | 2 | X324/B | |
| | | N | 2 | X323/B | |
| | | N | 2 | X322/B | |
| | | N | 1 | X1002/4 | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|-------------|-----|--------|---------------|------------|---------|
| X314 | 15 | R | 2.5 | SA9 | F230 |
| | 16 | M-H | 1 | SA205 | |
| | 17 | | | | |
| | 18 | | | | |
| | 19 | G | 1 | SA204 | |
| | 20 | B | 1 | X103.s/15 | 6307 |
| | 21 | B | 1 | X1002/2 | 1072 |
| X315 | 1 | C | 1.5 | X319/6 | 0F52 |
| | 2 | N | 1.5 | Gnd2.2 | |
| X316 | 1 | H | 1 | X103.s/16 | 1036 |
| | 2 | H | 1 | X103.s/14 | 1007 |
| | 3 | C | 1 | X319/4 | 0F50 |
| | 4 | R | 1 | X319/5 | 0F51 |
| | 5 | | | | |
| X317 | - | H | 4 | X321/R1-87 | 1001 |
| X318 | F1 | R | 4 | X320/R1-30 | F255 |
| | F2 | R | 4 | X320/R2-30 | F256 |
| | F3 | R | 4 | X321/R2-30 | F258 |
| | | R | 1 | X319/2 | F258 |
| | F4 | R | 4 | X103.s/2 | F260 |
| | F5 | | | | |
| | F6 | R | 4 | X321/R1-30 | F259 |
| | COM | R | 35 | X326 | |
| X319 | 1 | B | 1.5 | X321/R2-87 | 6907 |
| | 2 | R | 1 | X318/F3 | F258 |
| | 3 | B | 1.5 | X321/R2-87 | 6907 |
| | 4 | C | 1 | X316/3 | 0F50 |
| | 5 | R | 1 | X316/4 | 0F51 |
| | 6 | C | 1.5 | X315/1 | 0F52 |
| | 7 | R | 1.5 | SA13 | 0201 |
| | 8 | R | 4 | SA14 | |
| | 9 | R | 4 | SA14 | |
| | 10 | R | 2.5 | X103.s/3 | 0F56 |
| | 11 | R | 4 | SA23 | F301 |
| | 12 | R | 1 | SA22 | F300 |
| | | R | 1 | X750/1 | F300 |
| | 13 | R | 10 | SA13 | 0201 |
| | 14 | R | 10 | SA5 | F230 |
| | 15 | | | | |
| | 16 | | | | |
| | 17 | R | 4 | SA14 | |
| 18 | R | 2.5 | X892.s/1 | F231 | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|------------------|------------|---------------|----------------------|------------------|----------------|
| SA9 | - | R | 6 | X319/14 | F230 |
| | | R | 2.5 | X314/5 | F230 |
| | | R | 2.5 | X314/6 | F230 |
| SA16 | - | G | 0.5 | X1011.s/J | |
| | | G | 0.5 | X991/A | |
| | | G | 0.5 | SA118 | |
| SA19 | - | V | 0.5 | SA119 | |
| | | V | 0.5 | X991/B | |
| | | V | 0.5 | X1011.s/K | |
| SA24 | - | M | 2.5 | X997/2 | 0005 |
| | | M | 0.75 | X998/23 | 0005 |
| | | M | 1.5 | X997/7 | 0005 |
| | | M | 4 | X1009 | 0005 |
| | | M | 0.75 | X998/22 | 0005 |
| | | M | 1.5 | X998/24 | 0005 |
| | | M | 1.5 | X997/33 | 0005 |
| | | M | 1.5 | X997/46 | 0005 |
| SA25 | - | SCH | | D/1 | |
| | | B | 0.5 | X1011.s/A | 6358 |
| SA26 | - | SCH | | SA27 | |
| | | SCH | | SA99 | |
| | | SCH | | B/1 | |
| SA27 | - | SCH | | SA26 | |
| | | B | 1 | X1011.s/H | 6162 |
| SA28 | - | R | 0.5 | X997/58 | F300 |
| | | R | 0.5 | X997/45 | F300 |
| | | R | 1 | X319/12 | F300 |
| SA29 | - | R | 2.5 | X997/3 | F301 |
| | | R | 2.5 | X997/5 | F301 |
| | | R | 2.5 | X997/1 | F301 |
| | | R | 2.5 | X997/4 | F301 |
| | | R | 4 | X319/11 | F301 |
| | | R | 2.5 | X997/6 | F301 |
| SA98 | - | B | 0.5 | X993.s/2 | 6054 |
| | | B | 0.5 | X1011.s/M | 6054 |
| | | B | 0.75 | X998/46 | 6054 |
| SA99 | - | N | 0.5 | Gnd2.1 | |
| | | SCH | | SA26 | |
| | | N | 0.5 | X991/C | |
| SA118 | - | G | 0.5 | X997/53 | |
| | | G | 0.5 | SA16 | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|----------------|-----|--------|---------------|------------|---------|
| X998 | 78 | A | 0.75 | X993.s/5 | 1441 |
| | 79 | A | 0.75 | X341/2 | 1476 |
| | 80 | | | | |
| | 81 | | | | |
| | 82 | | | | |
| | 83 | A | 0.75 | X313/2 | 1341 |
| | 84 | A | 0.75 | X312/2 | 1342 |
| | 85 | A | 0.75 | X993.s/6 | 1415 |
| | 86 | A | 0.75 | X978/2 | 1414 |
| | 87 | | | | |
| | 88 | | | | |
| | 89 | | | | |
| | 90 | | | | |
| | 91 | | | | |
| | 92 | | | | |
| | 93 | | | | |
| | 94 | | | | |
| | 95 | | | | |
| 96 | | | | | |
| X1002 | 1 | B | 1 | X321/R1-86 | 1072 |
| | 2 | B | 1 | X314/12 | 1072 |
| | 3 | A | 1 | X1011.s/W | 0F18 |
| | 4 | N | 1 | Gnd9 | |
| X1002.p | 1 | H | 1 | X1002.p/2 | 1072 |
| | 2 | H | 1 | X1002.p/1 | 1072 |
| | 3 | | | | |
| | 4 | | | | |
| X1003 | - | R | 16 | X1008 | 0201 |
| X1004 | - | R | 16 | X413.s/1 | |
| X1008 | - | R | 16 | X1003 | 0201 |
| X1009 | - | M | 4 | X103.s/4 | 005 |
| | | M | 4 | SA24 | 005 |
| | | M | 1.5 | X1011.s/R | 005 |

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| XFEM.s | 1 | CB | 1.5 | X04.p/1 | |
| | 2 | CV | 1.5 | X03/2 | |
| | 3 | RB | 1 | X1001.p/1 | |
| | 4 | N | 1 | SA01 | |

PRE-START ALLARM LINE

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| +30 | - | N | 70 | TL.30 | |
| TL.30 | - | N | 70 | +30 | |

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| TL.87 | - | N | 70 | Pump+ | |
| Pump+ | - | N | 70 | TL.87 | |

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| Gnd | - | N | 70 | Pump- | |
| Pump- | - | N | 70 | Gnd | |

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| TL.85 | - | N | 1 | X627.p/B | |
| TL.86 | - | G | 1 | X627.p/A | |
| X627.p | A | G | 1 | TL.86 | |
| | B | N | 1 | TL.85 | |
| | C | | | | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|------------------|------------|---------------|----------------------|------------------|----------------|
| X737 | 1 | N | 1.5 | SA39 | |
| | 2 | G-V | 1.5 | SA40 | |
| | 3 | H | 1.5 | SA41 | |
| | 4 | M | 1.5 | SA43 | |
| X738.1 | - | M | 1.5 | SA42 | |
| X738.2 | - | L | 1.5 | SA44 | |
| X739 | 1 | B | 1 | X746/5 | 6551 |
| | 2 | B | 1 | X746/7 | 6562 |
| | 3 | N | 1 | SA38 | |
| | 4 | C | 1 | SA35 | 00F3 |
| X740 | 1 | B | 1 | X745/5 | 7510 |
| | 2 | B | 1 | X745/7 | 7511 |
| | 3 | N | 1 | SA38 | |
| | 4 | C | 1 | SA35 | 00F3 |
| X741 | 1 | B | 1 | X741/B | 7509 |
| | | B | 1.5 | X733/1 | 7509 |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | | | | |
| | 5 | C | 1.5 | X404.p/10 | 00F8 |
| | | C | 1 | X741/10 | 00F8 |
| | 6 | | | | |
| | 7 | | | | |
| | 8 | | | | |
| | 9 | N | 1 | X745/9 | |
| | | N | 1 | X742/9 | |
| | 10 | C | 1 | X741/5 | 00F8 |
| | A | | | | |
| B | B | 1 | X741/1 | 7509 | |

| Reference | Pin | Colour | Cross-section | Direction | Wire N° |
|------------------|------------|---------------|----------------------|------------------|----------------|
| X792.s | 1 | Z | 1.5 | SA5 | |
| | 2 | B | 1 | X791/26 | 7685 |
| | 3 | B | 1 | X791/27 | 7686 |
| | 4 | B | 1 | X791/34 | 7682 |
| | 5 | B | 1 | X791/24 | 7684 |
| | 6 | B | 1 | X791/25 | 7690 |
| | 7 | | | | |
| | 8 | B | 1 | X791/28 | 7683 |
| | 9 | H | 0.5 | X993.p/9 | |
| | 10 | G | 0.5 | X993.p/7 | |
| | 11 | S | 0.5 | X993.p/8 | |
| | 12 | B | 0.5 | X993.p/5 | |
| | 13 | V | 0.5 | X993.p/6 | |
| | 14 | B | 1 | X791/32 | 7687 |
| | 15 | V | 1 | X791/12 | 3571 |
| | 16 | B | 1 | X791/33 | 7688 |
| | 17 | B | 1 | X993.p/10 | 6173 |
| | 18 | B | 1 | X993.p/11 | 6983 |
| | 19 | B | 1 | X993.p/12 | 7367 |
| | 20 | L | 0.5 | SA7 | |
| | 21 | V | 1 | X791/11 | 3075 |
| | 22 | V | 1 | X791/10 | 3297 |
| | 23 | V | 1 | X791/9 | 3264 |
| | 24 | B | 0.5 | SA6 | |
| T1 | N | 1.5 | SA1 | | |
| T2 | | | | | |
| X794.p | 1 | | | | |
| | 2 | | | | |
| | 3 | | | | |
| | 4 | | | | |
| | 5 | | | | |
| | 6 | | | | |
| X794.s | 1 | Z | 1 | SA5 | |
| | 2 | N | 1 | SA1 | |
| | 3 | B | 0.5 | SA6 | |
| | 4 | L | 0.5 | SA7 | |
| | 5 | | | | |
| | 6 | | | | |

CLAMP CONTROL CABIN LINE

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| A | - | SCH | | SA3 | |
| SA1 | - | G | 0.5 | X989/C6 | |
| | | G | 0.5 | X120.p/A | |
| | | G | 0.5 | X120.s/A | |
| SA2 | - | V | 0.5 | X989/B7 | |
| | | V | 0.5 | X120.s/A | |
| | | V | 0.5 | X120.p/A | |
| SA3 | - | SCH | | A/- | |
| | | SCH | | SA5 | |
| | | SCH | | SA4 | |
| SA4 | - | B | 0.5 | X120.s/C | 6162 |
| | | SCH | | SA3 | |
| SA5 | - | B | 0.5 | X120.s/C | 6162 |
| | | SCH | | SA3 | |
| SA6 | - | C | 1 | X479.s/8 | 0F63 |
| | | C | 1 | X479.p/8 | 0F63 |
| | | C | 1 | X989/C1 | 0F63 |
| | | C | 1 | X989/A8 | 0F63 |
| | | C | 1 | X987/1 | 0F63 |
| SA7 | - | N | 1 | X479.p/2 | |
| | | N | 1 | X479.s/2 | |
| | | N | 1 | X989/B1 | |
| X120.p | A | G | 0.5 | SA1 | |
| | B | V | 0.5 | SA2 | |
| | C | B | 0.5 | SA5 | 6162 |
| X120.s | A | G | 0.5 | SA1 | |
| | B | V | 0.5 | SA2 | |
| | C | B | 0.5 | SA5 | 6162 |
| X479.p | 1 | R | 1 | X479.s/1 | 0F57 |
| | 2 | N | 1 | SA7 | |
| | 3 | B | 1.5 | X479.s/3 | 6308 |
| | 4 | B | 1 | X479.s/4 | 6307 |
| | 5 | B | 1 | X479.s/5 | 6353 |
| | 6 | B | 1.5 | X479.s/6 | 6983 |
| | 7 | H | 1 | X479.s/7 | 1007 |
| | 8 | C | 1 | SA6 | 0F63 |

GUARDIAN ANGEL LINE

| <i>Reference</i> | <i>Pin</i> | <i>Colour</i> | <i>Cross-section</i> | <i>Direction</i> | <i>Wire N°</i> |
|------------------|------------|---------------|----------------------|------------------|----------------|
| BZ01 | 1 | L | 1 | X019/A8 | |
| | 2 | N | 1 | SA3 | |
| SA01 | - | C | 1 | X026/1 | |
| | | C | 1 | X026/3 | |
| | | C | 1 | X479.p/8 | |
| | | C | 1 | X019/A1 | |
| | | C | 1 | X479.a/8 | |
| SA02 | - | H | 1 | X019/C3 | |
| | | H | 1 | X479.a/7 | |
| | | H | 1 | X479.p/7 | |
| SA03 | - | N | 1 | X479.P/2 | |
| | | N | 1 | BZ01/2 | |
| | | N | 1 | X025/1 | |
| | | N | 1 | X024/1 | |
| | | N | 1 | X479.A/2 | |
| | | N | 1 | X019/C8 | |
| SCH | - | SCH | | X120.p/C | |
| | | SCH | | X472A.s/C | |
| | | SCH | | X472.p/C | |
| | | SCH | | X120A.s/C | |
| X04.s | 1 | CV | 1.5 | X019/B8 | |
| X016.s | 1 | A | 1 | X026/4 | |

ECU INPUTS/OUTPUTS


pages

| | |
|---|-----------|
| CONTROL UNIT INPUTS/OUTPUT..... | C3 |
| TERA 9 INPUTS/OUTPUT..... | C3 |
| – MC2M INPUTS/OUTPUT | C4 |
| – MIDAC INPUTS/OUTPUT | C5 |
| – ACM2 INPUTS/OUTPUT MHT10180 / MHT 10230 | C6 |
| – ECU RC INPUTS/OUTPUT MHT 10180 / MHT 10230 | C7 |
| – CPC4 INPUTS/OUTPUT MHT 10180 / 10230..... | C8 |
| – ADM3 INPUTS/OUTPUT MHT - X 10180/ MHT - X 10230..... | C9 |
| – MCM2 INPUTS/OUTPUT MHT 10180 / MHT 10230 | C10 |
| – MR2 INPUTS/OUTPUT MHT - X 10180 / MHT - X 10230 | C10 |

TECHNICAL SHEETS FOR ELECTRICAL COMPONENTS


| | pages |
|--|-------|
| – A870 24V DC - DC CONVERTER..... | D3 |
| – B400 CAB LIGHT DOOR SWITCH | D3 |
| – B401 DOOR SECURITY MICROSWITCH | D4 |
| – B618 STOP LIGHT PRESSURE SWITCH | D4 |
| – B645 BOOM ANGLE ANGULAR SENSOR..... | D5 |
| – B761 BOTTOM-TILTING CILINDER PRESSUR SENSOR | D6 |
| – B762 STEM-TILTING CILINDER PRESSUR SENSOR..... | D6 |
| – B765 BOOM ANGLE/RETRACT SENSOR..... | D7 |
| – B802 STOP PEDAL PRESSURE SWICH..... | D7 |
| – B821 STEERING PRESSURE SWITCH | D8 |
| – B977 PLANAR SENSOR..... | D8 |
| – Q312 REVERSE SPEED SOLENOID VALVE | D9 |
| – Q313 FORWARD SPEED SOLENOID VALVE | D9 |
| – Q341 HYDRAULIC PUMP SOLENOID VALVE | D10 |
| – Q600 CRAB STEERING SOLENOID VALVE | D10 |
| – Q604 LEFT LEVEL SOLENOID VALVE..... | D11 |
| – Q608 SLOW SPEED SOLENOID VALVE..... | D11 |
| – Q610 FAST SPEED SOLENOID VALVE..... | D12 |
| – Q619 DIFFERENTIAL LOCK SOLENOID VALVE | D12 |
| – Q621 PARKING BRAKE SOLENOID VALVE | D13 |
| – Q622 CONCENTRIC STEERING SOLENOID VALVE..... | D13 |
| – Q623 STEERING MODE SOLENOID VALVE | D14 |
| – Q624 RIGHT LEVEL SOLENOID VALVE | D14 |
| – Q630 EV SOLENOID VALVE | D15 |
| – Q632 EV OPTIONAL 1 SOLENOID VALVE | D16 |
| – Q633 EV OPTIONAL 2 SOLENOID VALVE | D17 |
| – Q634 EV RETRACT SOLENOID VALVE..... | D18 |
| – Q635 EV TELESCOPE EXTENSION SOLENOID VALVE..... | D19 |
| – Q636 EV LOAD TILTING SOLENOID VALVE | D20 |
| – Q637 EV DOWNLOAD TILTING SOLENOID VALVE | D21 |
| – Q638 EV BOOM UP SOLENOID VALVE..... | D22 |
| – Q639 EV BOOM DOWN SOLENOID VALVE..... | D23 |
| – Q978 2 HYDROSTATIC ENGINE VALVE | D24 |
| – S412 JSM JOYSTICK..... | D25 |
| – S436 IGNITION SWITCH..... | D26 |
| – S438 WINDSHIELD MOTOR STEERING COLUMN SWITCH | D26 |
| – S440 LIGHT STEERING COLUMN SWITCH..... | D27 |
| – S451 EXTERNAL TEMPERATURE SENSOR..... | D27 |

Q604 LEFT LEVEL SOLENOID VALVE



| PIN | Function |
|-----|-------------|
| 1 | EV Level LH |
| 2 | GND |

Corresponding connector




Diagram

| | Typical |
|----------------|---------|
| Supply voltage | 24 V |
| Consumption | 0.8 A |


Notes: _____

Q608 SLOW SPEED SOLENOID VALVE



| PIN | Function |
|-----|---------------|
| 1 | EV Slow speed |
| 2 | GND |

Corresponding connector




Diagram

| | Typical |
|----------------|---------|
| Supply voltage | 24 V |
| Consumption | 0.8 A |


Notes: _____

Q637 EV DOWNLOAD TILTING SOLENOID VALVE



| | PIN | Function |
|---|-----|------------------------------------|
| 1 | 1 | EV Download tilting solenoid valve |
| 2 | 2 | GND |

Corresponding connector




Diagram

| | Typical |
|----------------|------------|
| Supply voltage | 24 V |
| Consumption | 0.18÷0.8 A |

Notes: _____

Pressure reducing valve
 P/I charateristic/control pressure 30 bar



Representation of a track.


- ⇒ Flows are referred to 16 bar LS-DELTA P.
- ⇒ Unloading 30 bar ± 2 whit 15 LPM.
- ⇒ Port relief valves setting flow 10 LPM.
- ⇒ LS relief valve/LS.

It is detailed in the following chapter:

◀ Group 80 - Electrical control and adjustment

Notes: _____

EXAMPLE OF CODES ON ELECTRICAL DIAGRAMS




Example of marking on cables and components on an electrical diagram


Key:


- | | |
|---------------------------------|--------------------------------|
| 1 - Marking grid | 10 - Electrical component name |
| 2 - + Permanent | 11 - Splice |
| 3 - + After ignition | 12 - Version choice |
| 4 - Grounds | 13 - Other diagram reference |
| 5 - Wire N° | 14 - CAN |
| 6 - Electrical connector | 15 - CAN Shielding |
| 7 - Electrical connector name | 16 - Option |
| 8 - Electrical connector PIN N° | |
| 9 - Electrical component | |

(14/01/2021)

80-02-EN










DIAGRAM 29 (LED bars)







DIAGRAM 34 (Radio-clamp boom head)






| Item | Designation | Position on harness layout | | | | | | | | | | | | | | | | | | | | | |
|---------|---|----------------------------|-----------|------|-----------|------------|-------------|----------------|-------------------|----------------|-----------|-----------------|-------------|-------------|---------------------|------------------------|---|---------------------|----------------------|--------------------------|------------|-------------------|-----------------------------|
| | | CHASSIS 1 | CHASSIS 2 | BOOM | CABIN | ENGINE ST4 | ENGINE ST3A | Downgrade ST3A | MAIN POWER CABLES | Emergency stop | Brake | Security device | Optionals 1 | Optionals 2 | Radio control-cabin | Radio-basket boom head | Radio-basket chassis / radio control signal | Clamp control cabin | Radioclamp boom head | Boom clamp (with basket) | Cabin roof | ROOF AMBER LIGHTS | Red/ Green indicator lights |
| X453 | I/o core unit | | | | Q38 | | | | | | | | | | | | | | | | | | |
| X454 | I/o core unit | | | | Q38 | | | | | | | | | | | | | | | | | | |
| X455 | Encoder can open | | | | C32 | | | | | | | | | | | | | | | | | | |
| X456 | Can control pannel | | | | E33 / E34 | | | | | | | | | | | | | | | | | | |
| X457 | Service relay | | | | E4 / E5 | | | | | | | | | | | | | | | | | | |
| X458 | Flasher unit | | | | G12 / G13 | | | | | | | | | | | | | | | | | | |
| X459 | Warning switch | | | | O20 | | | | | | | | | | | | | | | | | | |
| X460 | Midac unit | | | | I25 / I26 | | | | | | | | | | | | | | | | | | |
| X461.1 | Front windshield diode | | | | Q27 / Q28 | | | | | | | | | | | | | | | | | | |
| X461.2 | Diode reset windshield wiper | | | | Q28 | | | | | | | | | | | | | | | | | | |
| X462 | Dptidnal jdystick | | | | G38 | | | | | | | | | | | | | | | | | | |
| X463 | Cardan speed sensdr | | I24 | | | | | | | | | | | | | | | | | | | | |
| X467 | Reverse speed alarm | | | | Q33 / Q34 | | | | | | | | | | | | | | | | | | |
| X468 | Mercedes unit | | | | Q38 | | | | | | | | | | | | | | | | | | |
| X468.p | Driver's seat line cpc4-1 | | | | | | | G12 / G13 | | | | | | | | | | | | | | | |
| X468.s | X1 cpc4 connector | | | | | | | K26 | | | | | | | | | | | | | | | |
| X469 | Mercedes unit | | | | S38 | | | | | | | | | | | | | | | | | | |
| X469.p | Driver's seat line cpc4-2 | | | | | | | G18 / G19 | | | | | | | | | | | | | | | |
| X469.s | X2 cpc4 connector | | | | | | | K20 / K21 | | | | | | | | | | | | | | | |
| X470 | Mercedes unit | | | | S38 | | | | | | | | | | | | | | | | | | |
| X470.p | Driver's seat line cpc4-3 | | | | | | | G24 | | | | | | | | | | | | | | | |
| X470.s | Cpc4-ecan 3 | | | | | | | K31 / K32 | | | | | | | | | | | | | | | |
| X471 | Mercedes unit | | | | S38 | | | | | | | | | | | | | | | | | | |
| X471.p | Driver's seat line cpc4-4 | | | | | | | G28 / G29 | | | | | | | | | | | | | | | |
| X471.s | X4 cpc4 connector | | | | | | | K14 / K15 | | | | | | | | | | | | | | | |
| X472 | End j1939 can line resistor | | | | Q15 | | | | | | | | | | | | | | | | | | |
| X472.p | Power / Signals | | | | | | | | | | E23 | | | | | | | | | | | | |
| X472A.s | Can J1939 | | | | | | | | | | E20 / E21 | | | | | | | | | | | | |
| X473.s | Maneuvers restoration connector | | | | G25 / G26 | | | | | | | | | | | | | | | | | | |
| X474 | Generatdr and engine service relay fuse | | | | G12 | | | | | | | | | | | | | | | | | | |
| X476 | Levelling switch | | | | K33 | | | | | | | | | | | | | | | | | | |
| X477.p | Clima grdup interf ace | | | | I16 / I17 | | | | | | | | | | | | | | | | | | |
| X478.p | Optional | S8 / S9 | | | | | | | | | | | | | | | | | | | | | |
| X478.s | Optional | S14 / S15 | | | | | | | | | | | | | | | | | | | | | |
| X479.a | Power / Signals | | | | | | | | | | O22 / O23 | | | | | | | | | | | | |
| X479.p | Anti-theft system mating part connector | | | | O14 / O15 | | | | | | O19 | | | | | | | G31 / G32 | | | | | |
| X479.s | Anti-theft system connector | | | | O16 | | | | | | | | | | | | | I34 | | | | | |
| X481.s | Rpm signal pull up resistence | | | | A21 / A22 | | | | | | | | | | | | | | | | | | |
| X555.s | Chains extension | | | | | | | | | | | | | | | | | | | | | | |
| X600 | 1steering solenoid valve | | C9 | | | | | | | | | | | | | | | | | | | | |
| X601 | Urea pipe preheating 1 | | | | | C15 | | | | | | | | | | | | | | | | | |
| X602 | Urea pipe preheating 2 | | | | | C16 | | | | | | | | | | | | | | | | | |
| X603 | Urea pipe preheating 3 | | | | | C17 / C18 | | | | | | | | | | | | | | | | | |
| X604 | Left level solenoid valve | | E16 | | | | | | | | | | | | | | | | | | | | |

BOOM HARNESS



OPTIONALS 2




(only MHT-X 10180/10230)

ENGINE SLOW WIRING

2nd BOOM-HEAD WIRING OR
2nd BOOM-HEAD + BLOCK ACCESSORIES WIRING

BLOCK ACCESSORIES + 3rd BOOM-HEAD WIRING



OPERATOR PANEL

INSTRUMENT CONTROL PANEL

The control panel (Ref.1) with 9" colour screen display shows and informs the operator of all the steps of the operation of the telehandler.

Six control modes are saved in the memory of the "HMI" panel (Ref.1) and can be selected by means of the human-machine interface keypad (Ref.2) on the armrest (Ref.3) in the cabin.



KEYPAD WITH CONTROL KNOB

This tool provides the operator with an excellent touch feedback and the greatest benefit of the keypad with knob is increasing the functions in a single control.

Put display functions within reach

- 5 hot keys for rapid navigation
- scroll with rotary knob
- Select with pushbutton

Functions:

- Rotary knob with select pushbutton (Ref. 1): turn the knob to scroll the pages and to navigate between pages (if possible) after pressing it to select or confirm the choice.
- LOAD CHART key (Ref. 2) press it to enter in "F2 - Load limiter page",
- HOME key (Ref. 3): push it to enter in "Machine diagnostic mode control",
- BACK key (Ref. 4): press it to back in the choice,
- MENU key (Ref. 5): press it to enter in "Menu screen",
- OPTIONAL key (Ref. 6): from "F1 - Driving page" press it to enter in the "Driving setup page".



CONNECTION AND DIAGNOSTICS OF 3B6 CONTROL UNITS

EQUIPMENT REQUIRED

- 1 CAN PEAK
- 1 cable

Ref. 729458
Ref. 887194

PROCEDURE



Fig. A

For carrying out diagnostics on 3B6 control units use the “3B6 WinScope” program present on the Pad.

Connect the PC or the PAD to the machine using the CAN PEAK cable and the OBD cable in the socket marked “M” (Fig. A).




Fig. B

Switch on the machine panel.

Open the “3B6 WinScope” program.

Select “Utils” (Fig. B).




Fig. C

Select “Hardware Configuration” and check to make sure the display (Fig. C) shows the following parameters selected and highlighted:

- | | |
|--------------------------|----------|
| Hardware Type: | USBCAN |
| Port: | COM 1 |
| Modem Init String: | AT&FEO |
| CAN Message Type: | Standard |
| Baudrate (Kb/s): | 250 |
| Parallel Port Address: | 378 |
| Parallel Port Interrupt: | 7 |
| ID Msg Order: | 40 |
| ID Msg Reply: | 41 |

Press “Ok” to confirm.





| SPN / FMI | SPN / FMI | DTC | Fault / Description | Possible Cause | Reaction | Remedy |
|--|-----------|-------|---|---|-----------------------------------|--|
| "FMI = 2, DATA ERRATIC, INTERMITTENT OR INCORRECT" | 2 | 2 | j1939_registerRxDataboxes() <> J1939_BOXSTATUS_VALID_DU16 | | | |
| 8011 | | | res_17 | | | |
| 8012 | 32786 | 7F012 | CAN CVC2TCU_1 | Timeout data received | Ramp down --> Machine stops | "Check the wiring CAN2 pin: 253 (CAN H2) 254 (CAN L2) Check the vehicle controller operation." |
| "FMI = 2, DATA ERRATIC, INTERMITTENT OR INCORRECT" | 2 | 2 | j1939_registerRxDataboxes() <> J1939_BOXSTATUS_VALID_DU16 | | | |
| 8013 | 32787 | 7F013 | CAN CVC2TCU_2 | Timeout data received | Ramp down --> Machine stops | "Check the wiring CAN2 pin: 253 (CAN H2) 254 (CAN L2) Check the vehicle controller operation." |
| "FMI = 2, DATA ERRATIC, INTERMITTENT OR INCORRECT" | 2 | 2 | j1939_registerRxDataboxes() <> J1939_BOXSTATUS_VALID_DU16 | | | |
| 8014 | 32788 | 7F014 | HW Monitor Ignore | HW errors: inputs, outputs, can bus module. Error occurs during initialization. | No reaction | Check the hw inputs, outputs, can bus |
| FMI = 31, CONDITION EXISTS | 31 | 1F | | Some output solenoids faulty | | |
| 8015 | 32789 | 7F015 | HW Monitor LimpHome | HW errors: inputs, outputs, can bus module. Error occurs during initialization. | Machine moves at limited velocity | Check the hw inputs, outputs, can bus |
| FMI = 31, CONDITION EXISTS | 31 | 1F | | Some output solenoids faulty | | |
| 8016 | 32790 | 7F016 | HW Monitor Stop | HW errors: inputs, outputs, can bus module. Error occurs during initialization. | Machine doesn't move | Check the hw inputs, outputs, can bus |
| FMI = 31, CONDITION EXISTS | 31 | 1F | | | | |
| 8017 | 32791 | 7F017 | HW Monitor Switch | HW errors: inputs, outputs, can bus module. Error occurs during initialization. | Machine doesn't move | Check the hw inputs, outputs, can bus |
| FMI = 31, CONDITION EXISTS | 31 | 1F | | | | |
| 8018 | | | res_24 | | | |
| 8019 | | | res_25 | | | |
| 801A | | | res_26 | | | |
| 801B | | | res_27 | | | |
| 801C | | | res_28 | | | |
| 801D | | | res_29 | | | |

| SPN / FMI | SPN / FMI | DTC | Fault / Description | Possible Cause | Reaction | Remedy |
|--|-----------|-------|---|---|---|--------|
| 805B | 32859 | 7F05B | Scicos Active | Simulation flag active | Vehicle doesn't move | |
| FMI=14, SPECIAL INSTRUCTIONS | 14 | E | SCICOS_ACTIVE: Simulation active | | | |
| 805C | | | res_92 | | | |
| 805D | | | res_93 | | | |
| 805E | | | res_94 | | | |
| 805F | | | res_95 | | | |
| 8060 | | | res_96 | | | |
| 8061 | | | res_97 | | | |
| 8062 | | | res_98 | | | |
| 8063 | | | res_99 | | | |
| 8064 | 32868 | 7F064 | Wrong Machine Configuration | Machine configuration from master controller is wrong. Drive controller is not initialized. | Vehicle doesn't move | |
| FMI=14, SPECIAL INSTRUCTIONS | 14 | E | set_Machine.WrgMchCfg_b8 PLC_PRG.StSysInIt_u16 <> 16#0000 | | | |
| 8065 | 32869 | 7F065 | ECU Temperature above normal operation limit | The traction controller temperature above normal operation limit | "Ramp down to velocity limited --> Machine moves at limited velocity in both direction. Gearbox is locked." | |
| "FMI = 12 BAD INTELLIGENT DEVICE OR COMPONENT" | 12 | C | sys_getHwTemp() > 85°C | | | |
| 8066 | 32870 | 7F066 | ECU Maximum continuous operating time reached | The traction controller runs for more of 24h | No reaction | |
| "FMI = 12 BAD INTELLIGENT DEVICE OR COMPONENT" | 12 | C | sys_getTime() > 24h | | | |
| 8067 | 32871 | 7F067 | ECU Maximum operating lifetime reached | The traction controller operating lifetime above maximum value limit | No reaction | |
| "FMI = 12 BAD INTELLIGENT DEVICE OR COMPONENT" | 12 | C | sys_getAge() > 10000h | | | |
| 8067 | | | res_103 | | | |
| 8068 | | | res_104 | | | |
| 8069 | | | res_105 | | | |
| 806A | | | res_106 | | | |
| 806B | | | res_107 | | | |
| 806C | | | res_108 | | | |
| 806D | | | res_109 | | | |
| 806E | | | res_110 | | | |
| 806F | | | res_111 | | | |
| 8070 | | | res_112 | | | |
| 8071 | | | res_113 | | | |
| 8072 | | | res_114 | | | |


ANNEX A

CALIBRATION PROCEDURES WITH TEXT DISPLAY



Insert the first level password to carry out the following calibrations.

| | | Description |
|---|-------------------------|---|
|  | CODE | Main page. Enter the password and press "+" to access the programming mode. |
|  | CONFIGURATION Config | Vehicle configuration (no password needed). The following parameters are available. <ul style="list-style-type: none"> • language • brightness • unit |
|  | OPTIONS | The following parameters are available. <ul style="list-style-type: none"> • Partial Hours • Time Setting • Machine Type • Event Long |
|  | OPTIONS Time setting | The following parameters are available. <ul style="list-style-type: none"> • Day • Month • Year • Hour • Minute |

CONNECTIONS TO FORKLIFT TRUCK




Note: The cable Ref. 947201 can diagnose the entire machine.



REMOVING THE CAB HOUSING

Remove the 4 screws (Ref. 1) from the cab's front fairing (Ref. 2).


Open the inspection case (Ref. 3) with the ignition key.




Remove the antenna cable from the casing (Ref. 1).




Remove the windscreen washer hoses (Ref. 2) from the fairing (Ref. 1).






Secure the heater (Ref. 1) to an overhead crane with ropes and chains.




Unscrew the screws (Ref. 1) in the cabin front and remove the heater.




Pay attention at the seal (Ref. 1) between the heater and the cabin.

A - ELECTRIC WINDOW AND MOTOR REFIT




Slide the whole rack and pinion motor (Ref. 1) into the door (Ref. 2).



Connect the connector (Ref. 1).


Insert the roller (Ref. 2) in the rail (Ref. 3)

Pivot the motor in the door.



Press the electric window motor against the bracket (Ref. 1) and mount it using the four screws (Ref. 2).

Re-stick the plastic film (Ref. 3) or change it, depending on its condition.




Check the condition of the door's interior trim clips (Ref. 1) before refitting it

MHT 10180 / MHT 102030


- Remove the screws on DEF tank support (Ref 6) to remove it

 **Pay attention to the weight of the tank.**

- Pull-down the DEF tank (Ref 5)

**REFITTING PROCEDURE**

Proceed in reverse order to refit the DEF tank.



OPTIONS - ATTACHMENTS COMPONENTS LOCATION

| | pages |
|--|----------|
| POSITION OF AIR CONDITIONING COMPONENTS | 3 |
| POSITION OF AIR CONDITIONING CONNECTORS..... | 4 |
| – POSITION OF AIR CONDITIONING CONNECTORS ON DIAGRAM | 5 |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL