





**REPAIR MANUAL
MANUEL DE RÉPARATION
REPARATURANLEITUNG
MANUAL DE REPARACIÓN
MANUALE RIPARAZIONE**

This document has been printed from  **mye doc**



MANITOU BF

Head office: 430, Rue de l'Aubinière
44150 Ancenis - FRANCE
Share capital: 39,548,949 euros
857 802 508 RCS Nantes
Tel: +33 (0)2 40 09 10 11
www.manitou.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

FRONT AND REAR TYRES

DIMENSIONS	PRESSURE	TYRE LOAD		PRESSURE ON THE CONTACT SURFACE		AREA OF THE CONTACT SURFACE	
				HARD GROUND	LIGHT GROUND	HARD GROUND	LIGHT GROUND
440/80-24 T37 158B TUBELESS	4,1 BAR	FRONT UNLADEN	2000 KG	7,69 KG/CM2	2,15 KG/CM2	260 CM2	930 CM2
		FRONT LADEN	5850 KG	12,15 KG/CM2	3,36 KG/CM2	482 CM2	1743 CM2
		REAR UNLADEN	2450 KG	8,24 KG/CM2	2,29 KG/CM2	297 CM2	1070 CM2
		REAR LADEN	850 KG	5,99 KG/CM2	1,66 KG/CM2	138 CM2	500 CM2
445/70R24 IT510 151G TUBELESS	4,1 BAR	FRONT UNLADEN	2000 KG	8,79 KG/CM2	2,9 KG/CM2	228 CM2	690 CM2
		FRONT LADEN	5850 KG	10,3 KG/CM2	3,4 KG/CM2	568 CM2	1721 CM2
		REAR UNLADEN	2450 KG	9,07 KG/CM2	3,02 KG/CM2	270 CM2	810 CM2
		REAR LADEN	850 KG	7,24 KG/CM2	2,38 KG/CM2	115 CM2	349 CM2
15,5-25 12PR SGL DL 2A	4,5 BAR	FRONT UNLADEN	2000 KG	6,96 KG/CM2	3,76 KG/CM2	288 CM2	533 CM2
		FRONT LADEN	5850 KG	8,42 KG/CM2	4,55 KG/CM2	695 CM2	1286 CM2
		REAR UNLADEN	2450 KG	6,81 KG/CM2	3,71 KG/CM2	360 CM2	660 CM2
		REAR LADEN	850 KG	6,07 KG/CM2	3,27 KG/CM2	140 CM2	260 CM2
15,5/80-24 SGI 16PR TUBELESS	4,5 BAR	FRONT UNLADEN	2000 KG	9,09 KG/CM2	2,47 KG/CM2	220 CM2	810 CM2
		FRONT LADEN	5850 KG	13,84 KG/CM2	3,75 KG/CM2	423 CM2	1560 CM2
		REAR UNLADEN	2450 KG	10,21 KG/CM2	2,71 KG/CM2	240 CM2	903 CM2
		REAR LADEN	850 KG	7,88 KG/CM2	2,15 KG/CM2	110 CM2	402 CM2
445/70R24 XM47 TL 151G TUBELESS	4,1 BAR	FRONT UNLADEN	2000 KG	1,9 KG/CM2	KG/CM2	1050 CM2	CM2
		FRONT LADEN	5850 KG	3,33 KG/CM2	KG/CM2	1754 CM2	CM2
		REAR UNLADEN	2450 KG	2,16 KG/CM2	KG/CM2	1133 CM2	CM2
		REAR LADEN	850 KG	1,07 KG/CM2	KG/CM2	794 CM2	CM2
1200R24 X MINE D2	6 BAR	FRONT UNLADEN	2000 KG	4,15 KG/CM2	KG/CM2	482 CM2	CM2
		FRONT LADEN	5850 KG	6,69 KG/CM2	KG/CM2	874 CM2	CM2
		REAR UNLADEN	2450 KG	4,64 KG/CM2	KG/CM2	528 CM2	CM2
		REAR LADEN	850 KG	2,33 KG/CM2	KG/CM2	365 CM2	CM2
15,5R25 XHA	4 BAR	FRONT UNLADEN	2000 KG	2,82 KG/CM2	1,32 KG/CM2	685 CM2	1466 CM2
		FRONT LADEN	5850 KG	3,63 KG/CM2	1,64 KG/CM2	1612 CM2	3567 CM2
		REAR UNLADEN	2450 KG	3,09 KG/CM2	1,44 KG/CM2	793 CM2	1699 CM2
		REAR LADEN	850 KG	1,72 KG/CM2	0,8 KG/CM2	473 CM2	1010 CM2
445/65R22,5 XZY TL 169K TUBELESS	4,5 BAR	FRONT UNLADEN	2000 KG	3,43 KG/CM2	KG/CM2	583 CM2	CM2
		FRONT LADEN	5850 KG	4,84 KG/CM2	KG/CM2	1208 CM2	CM2
		REAR UNLADEN	2450 KG	3,66 KG/CM2	KG/CM2	669 CM2	CM2
		REAR LADEN	850 KG	2,59 KG/CM2	KG/CM2	326 CM2	CM2
18R19,5 XF TL TUBELESS	6,5 BAR	FRONT UNLADEN	2000 KG	3,39 KG/CM2	1,57 KG/CM2	579 CM2	1249 CM2
		FRONT LADEN	5850 KG	4,23 KG/CM2	1,96 KG/CM2	1381 CM2	2980 CM2
		REAR UNLADEN	2450 KG	3,51 KG/CM2	1,63 KG/CM2	674 CM2	1454 CM2
		REAR LADEN	850 KG	3,47 KG/CM2	1,61 KG/CM2	244 CM2	526 CM2
480/65R24 TL 146D SF TUBELESS	3,8 BAR	FRONT UNLADEN	2000 KG	3,18 KG/CM2	0,97 KG/CM2	627 CM2	2047 CM2
		FRONT LADEN	5850 KG	3,32 KG/CM2	1,99 KG/CM2	1761 CM2	2943 CM2
		REAR UNLADEN	2450 KG	3,25 KG/CM2	1,13 KG/CM2	754 CM2	2167 CM2
		REAR LADEN	850 KG	2,94 KG/CM2	0,48 KG/CM2	283 CM2	1695 CM2

HYDRAULIC CIRCUIT

- Type of pump	Variable displacement piston pump
. Capacity	63 cm3
. Flow rate at full speed	148 L/mn
. Flow rate at 2300 rpm	145 L/mn
. Flow rate at 1600 rpm	101 L/mn
- Pressure	
. Lifting, tilting, telescoping, attachment circuit	270 Bar
. Steering circuit	140 Bar
- Filtration	
. Return	10 µ
. Suction	125 µ

CHARACTERISTICS (WITH FLOATING FORK CARRIAGE)

MT 1335 HSL Turbo MONO-ULTRA NACELLE ORH Série 2-E2

FRONT AND REAR TYRES

DIMENSIONS	PRESSURE	TYRE LOAD		PRESSURE ON THE CONTACT SURFACE		AREA OF THE CONTACT SURFACE	
				HARD GROUND	LIGHT GROUND	HARD GROUND	LIGHT GROUND
400/80-24 156A8 PIA TUBELESS BF GOODRICH	4,1 BAR	FRONT UNLADEN	2650 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	6150 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2400 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	650 KG	KG/CM2	KG/CM2	CM2	CM2
440/80-24 T37 158B TUBELESS DUNLOP	4,5 BAR	FRONT UNLADEN	2650 KG	8,69 KG/CM2	2,40 KG/CM2	305 CM2	1105 CM2
		FRONT LADEN	6150 KG	12,75 KG/CM2	3,50 KG/CM2	483 CM2	1758 CM2
		REAR UNLADEN	2400 KG	8,42 KG/CM2	2,34 KG/CM2	285 CM2	1025 CM2
		REAR LADEN	650 KG	5,72 KG/CM2	1,59 KG/CM2	113 CM2	407 CM2
15,5-25 12PR SGL DL 2A GOODYEAR	4,5 BAR	FRONT UNLADEN	2650 KG	6,95 KG/CM2	3,77 KG/CM2	381 CM2	703 CM2
		FRONT LADEN	6150 KG	8,48 KG/CM2	4,59 KG/CM2	725 CM2	1339 CM2
		REAR UNLADEN	2400 KG	6,81 KG/CM2	3,71 KG/CM2	353 CM2	648 CM2
		REAR LADEN	650 KG	4,64 KG/CM2	2,50 KG/CM2	140 CM2	260 CM2
15,5/80-24 SGI 16PR TUBELESS GOODYEAR	4,5 BAR	FRONT UNLADEN	2650 KG	10,49 KG/CM2	2,82 KG/CM2	253 CM2	939 CM2
		FRONT LADEN	6150 KG	14,06 KG/CM2	3,80 KG/CM2	438 CM2	1618 CM2
		REAR UNLADEN	2400 KG	10,00 KG/CM2	2,69 KG/CM2	240 CM2	892 CM2
		REAR LADEN	650 KG	8,77 KG/CM2	2,35 KG/CM2	74 CM2	277 CM2
1200R24 X MINE D2 MICHELIN	6,5 BAR	FRONT UNLADEN	2650 KG	4,90 KG/CM2		541 CM2	
		FRONT LADEN	6150 KG	6,96 KG/CM2		884 CM2	
		REAR UNLADEN	2400 KG	4,65 KG/CM2		516 CM2	
		REAR LADEN	650 KG	1,88 KG/CM2		345 CM2	
15,5R25 XHA TUBELESS MICHELIN	4 BAR	FRONT UNLADEN	2650 KG	3,09 KG/CM2	1,44 KG/CM2	857 CM2	1839 CM2
		FRONT LADEN	6150 KG	3,68 KG/CM2	1,66 KG/CM2	1683 CM2	3729 CM2
		REAR UNLADEN	2400 KG	3,10 KG/CM2	1,45 KG/CM2	775 CM2	1661 CM2
		REAR LADEN	650 KG	1,53 KG/CM2	0,71 KG/CM2	436 CM2	931 CM2
18R19,5 XF TUBELESS MICHELIN	6,5 BAR	FRONT UNLADEN	2650 KG	3,56 KG/CM2	1,65 KG/CM2	716 CM2	1546 CM2
		FRONT LADEN	6150 KG	4,32 KG/CM2	2,00 KG/CM2	1419 CM2	3061 CM2
		REAR UNLADEN	2400 KG	3,49 KG/CM2	1,62 KG/CM2	663 CM2	1432 CM2
		REAR LADEN	650 KG	3,04 KG/CM2	1,41 KG/CM2	213 CM2	460 CM2

HYDRAULIC CIRCUIT

- Type of pump	Double gear pump with flow divider on the 2nd chamber	
	1st chamber	2nd chamber
. Capacity	43,8 cm ³	27,8 cm ³
. Max. rating capacity unladen	103 L/min	65 L/min
. Flow rate at 2300 rpm	101 L/min	64 L/min
. Flow rate at 1600 rpm	70 L/min	44 L/min
- Pressure		
. Telescoping circuit	260 Bar	160 Bar
. Lifting, tilting, stabilizer, tilting corrector, attachment circuit	260 Bar	
. Steering circuit		140 Bar
- Filtration		
. Return	10 µ	10 µ
. Suction		125 µ

CHARACTERISTICS (WITH EXTENSIBLE PLATFORM 2M25/4M) MT 1435 HSL Turbo MONO-ULTRA NACELLE ORH Série 2-E2


FRONT AND REAR TYRES

DIMENSIONS	PRESSURE	TYRE LOAD		PRESSURE ON THE CONTACT SURFACE		AREA OF THE CONTACT SURFACE	
				HARD GROUND	LIGHT GROUND	HARD GROUND	LIGHT GROUND
440/80-24 T37 158B TUBELESS DUNLOP	4,5 BAR	FRONT UNLADEN	3350 KG	9,42 KG/CM2	2,60 KG/CM2	352 CM2	1275 CM2
		FRONT LADEN	3800 KG	9,96 KG/CM2	2,75 KG/CM2	374 CM2	1356 CM2
		REAR UNLADEN	2100 KG	8,03 KG/CM2	2,23 KG/CM2	261 CM2	939 CM2
		REAR LADEN	1850 KG	7,73 KG/CM2	2,14 KG/CM2	239 CM2	861 CM2
15,5/80-24 SGI 16PR TUBELESS GOODYEAR	5,5 BAR	FRONT UNLADEN	3350 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	3800 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2100 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	1850 KG	KG/CM2	KG/CM2	CM2	CM2
1200R24 X MINE D2 MICHELIN	7,5 BAR	FRONT UNLADEN	3350 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	3800 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2100 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	1850 KG	KG/CM2	KG/CM2	CM2	CM2
15,5R25 XHA TUBELESS MICHELIN	4,75 BAR	FRONT UNLADEN	3350 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	3800 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2100 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	1850 KG	KG/CM2	KG/CM2	CM2	CM2
18R19,5 XF TUBELESS MICHELIN	8 BAR	FRONT UNLADEN	3350 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	3800 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2100 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	1850 KG	KG/CM2	KG/CM2	CM2	CM2
15,5/80-24 163A8 TR-01 TUBELESS MITAS	4,9 BAR	FRONT UNLADEN	3350 KG	KG/CM2	KG/CM2	CM2	CM2
		FRONT LADEN	3800 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR UNLADEN	2100 KG	KG/CM2	KG/CM2	CM2	CM2
		REAR LADEN	1850 KG	KG/CM2	KG/CM2	CM2	CM2

HYDRAULIC CIRCUIT


- Type of pump	Double gear pump with flow divider on the 2nd chamber	
	1st chamber	2nd chamber
. Capacity	43,8 cm ³	27,8 cm ³
. Max. rating capacity unladen	103 L/min	65 L/min
. Flow rate at 2300 rpm	101 L/min	64 L/min
. Flow rate at 1600 rpm	70 L/min	44 L/min
- Pressure		
. Telescoping circuit	260 Bar	160 Bar
. Lifting, tilting, stabilizer, tilting corrector, attachment circuit	260 Bar	
. Steering circuit		140 Bar
- Filtration		
. Return	10 μ	10 μ
. Suction		125 μ

DIMENSIONS AND LOAD CHART (WITH FLOATING FORK CARRIAGE) MT 1335 HSL Turbo MONO-ULTRA NACELLE ORH Série 2-E2



A	1200 mm
B	2770 mm
C	2119 mm
C1	2198 mm
D	5939 mm
D1	6018 mm
D2	4405 mm
E	7139 mm
F	1900 mm
F1	1900 mm
G	450 mm
G1	445 mm
G2	450 mm
G3	275 mm
H	7 °
H1	7 °
I	1050 mm
J	950 mm
K	1040 mm
L	45 mm
N	1860/1910 mm
O	125 mm
P2	43,5 °
P3	40 °
R	3905 mm
S	8817 mm
T	4205 mm
U1	2575 mm
U2	2755 mm
V	5675 mm
V1	1470 mm
V2	4113 mm
W	2315 mm
W1	2320 mm
W2	1125 mm
W3	2035 mm
Y	12 °
Z	112 °

DIMENSIONS AND LOAD CHART (WITH EXTENSIBLE PLATFORM 2M25/4M)
MT 1435 HSL Turbo MONO-ULTRA NACELLE ORH Série 2-E2



A	1200 mm
B	2770 mm
C	4270 mm
C1	2348 mm
C2	887 mm
D1	6168 mm
D2	4405 mm
E	8090 mm
F	1916 mm
F1	1916 mm
G	450 mm
G1	445 mm
G2	450 mm
G3	275 mm
H	7 °
H1	7 °
I	1050 mm
J	950 mm
K	2250/4000 mm
L	1250 mm
N	1860/1910 mm
P2	43,5 °
P3	40 °
R	3905 mm
S	9767 mm
T	5916 mm
U1	2575 mm
U2	2755 mm
V	7386 mm
V1	1470 mm
V2	4112 mm
W	2330 mm
W1	2320 mm
W2	1125 mm
W3	2035 mm
Y	90 °
Z	90 °

LUBRICANTS AND FUEL



USE THE RECOMMENDED LUBRICANTS AND FUEL:

- For topping up, oils may not be miscible.
- For oil changes, MANITOU oils are perfectly appropriate.

DIAGNOSTIC ANALYSIS OF OILS

If a service or maintenance contract has been organized with the dealer, a diagnostic analysis of engine, transmission and axle oils may be requested depending on the rate of use.

(*) FUEL CHARACTERISTICS

Use a high-quality fuel to obtain optimal performance of the I.C. engine.

CHARACTERISTICS OF RECOMMENDED FUEL:

- DERV à EN590
- BS2869 Class A2
- ASTM D975 - 91 Class 2D
- JIS K2204 (1992) Grades 1, 2, 3 and Special Grade 3.

I.C. ENGINE				
ORGANS TO BE LUBRICATED	CAPACITY	RECOMMENDATION	PACKAGING	PART NUMBER
I.C. ENGINE	11 Liters	MANITOU Oil API CH4	5 L.	661706
			20 L.	582357
			55 L.	582358
			209 L.	582359
COOLING CIRCUIT	21,5 Liters	Cooling liquid (protection - 30°)	2 L.	473076
			5 L.	470077
			20 L.	470078
		Cooling liquid (protection - 25°)	2 L.	554002
			5 L.	554003
			20 L.	554004
FUEL TANK	135 Liters	Diesel fuel (*)		

TRANSMISSION				
ORGANS TO BE LUBRICATED	CAPACITY	RECOMMENDATION	PACKAGING	PART NUMBER
GEAR BOX	2 Liters	MANITOU Oil SAE80W90 Mechanical transmission	2 L.	499237
			20 L.	546330
			55 L.	546221
			209 L.	546220
TRANSMISSION UNIVERSAL JOINT		MANITOU Grease Multipurpose HD NLGI 2	400 g.	161589
			1 Kg.	554973
			5 Kg.	554974
			20 Kg.	499233
			50 Kg.	489670

JIB			
ORGANS TO BE LUBRICATED	RECOMMENDATION	PACKAGING	PART NUMBER
JIB PADS	MANITOU Grease Multipurpose NLGI 2	400 g.	545996
		1 Kg.	161590
		50 Kg.	499235
GREASING OF THE JIB	MANITOU Grease Multipurpose HD NLGI 2	400 g.	161589
		1 Kg.	554973
		5 Kg.	554974
		20 Kg.	499233
		50 Kg.	489670
OPTION GREASING THE SINGLE SIDE-SHIFT CARRIAGE	MANITOU Grease Multipurpose HD NLGI 2	400 g.	161589
		1 Kg.	554973
		5 Kg.	554974
		20 Kg.	499233
		50 Kg.	489670

Vietata la riproduzione anche parziale di testo ed illustrazioni

Impaginazione: TEMAS s.r.l. - Gallarate (Va)
Stampa: Gennaio 1998 (N.L. 7309)

Data subject to change without notice. We decline all responsibility for the use of non-original components, or accessories which have not been tested and submitted for approval.


Dati soggetti a modifiche senza impegno di preavviso. Si declina ogni responsabilità per l'utilizzo di componenti non originali o accessori non collaudati e approvati.

Änderungen ohne vorherige Ankündigung vorbehalten. Es wird jede Verantwortung für die Verwendung von Nichtoriginalteilen oder nicht abgenommenem und genehmigtem Zubehör abgelehnt.

Los datos pueden ser modificados sin aviso previo. Se declina toda responsabilidad en el caso de uso de componentes no originales o bien de accesorios no ensayados y aprobados.

Le constructeur se réserve le droit d'apporter des modifications à sa production, sans pour cela être tenu d'en donner préavis. Nous déclinons toute responsabilité pour l'utilisation de pièces non originales ou d'accessoires non testés et homologués.

DISASSEMBLY OF DIRECTLY FLANGED REDUCTION GEAR 357 - SMONTAGGIO GRUPPO RIDUTTORE 357 AFFLANGIATO - DIREKT GEFLANSCHTER REDUZIERER 357 ZERLEGEN - DESMONTAJE GRUPO REDUCTOR 357 CON BRIDA - DEMONTAGE DU GROUPE REDUCTEUR BRIDE 357



GB

a


Reduction gear directly flanged on the axle with mechanic gear control.



GB

b

Reduction gear directly flanged on the axle with hydraulic gear control.




GB

c

Reduction gear directly flanged on the axle with or without revolution indicator.


DISASSEMBLY OF DIRECTLY FLANGED REDUCTION GEAR 357- SMONTAGGIO GRUPPO RIDUTTORE 357 AFFLANGIATO - DIREKT GEFLANSCHTER REDUZIERER 357 ZERLEGEN - DESMONTAJE GRUPO REDUCTOR 357 CON BRIDA - DEMONTAGE DU GROUPE REDUCTEUR BRIDE 357



F1240094




Pull out gear, needle bearings and distance piece form the box.



F1240095




Remove the bearing if it needs replacing.



F1240096



Re-introduce the bearing into the box.



F1240097



Remove the oil shield plate only if necessary. Caution: the oil inlet must face upwards.



F1240098



Re-introduce the oil shield plate with oil inlet facing upwards. Apply LOCTITE 510 on the outside.




F1240099



Fit the oil shield plate into position 5-5.5 mm from box plane.

ASSEMBLY OF DIRECTLY FLANGED REDUCTION GEAR 357 - ASSEMBLAGGIO GRUPPO RIDUTTORE 357 AFFLANGIATO - DIREKT GEFLANSCHTER REDUZIERER 357 MONTIEREN - MONTAJE GRUPO REDUCTOR 357 CON BRIDA - ASSEMBLAGE DU GROUPE REDUCTEUR BRIDE 357



F1240120



GB

a

Re-assemble the motion upper shaft.




F1240104



GB

b

Re-assemble the full lower shaft and the flow regulator plate.



F1240121



GB

c

Position the shaft so that the bearing juts out approximately 5 mm from the cover of the reduction unit.



F1240122



GB

d

Temporarily re-assemble the cover with screws. (Be sure that the niche faces upwards).




F1240101



GB

e

Simultaneously insert: fork and sliding blocks, coupling and flow regulator plate.



F1240100




GB

f

Re-insert screws and tighten.


ASSEMBLY OF DIRECTLY FLANGED REDUCTION GEAR 357 - ASSEMBLAGGIO GRUPPO RIDUTTORE 357 AFFLANGIATO - DIREKT GEFLANSCHTER REDUZIERER 357 MONTIEREN - MONTAJE GRUPO REDUCTOR 357 CON BRIDA - ASSEMBLAGE DU GROUPE REDUCTEUR BRIDE 357



F1240140




Tighten screws using a torque wrench setting of 49–51 Nm.



F1240141




Assemble flange, O-ring and nut using LOCTITE 242.



F1240142




Screw down the nut of the flange.



F1240143




Tighten the nut using a torque wrench setting of 260–280 Nm.



F1240144



Re-fix the protection plate after applying LOCTITE 510.




F1240069



Complete flanged reduction gear 357 with mechanical gear control.


- Connect six hoses 11 (Fig. BB).

Fig. BB



- Refit two guide support mounting bolts 12 (Fig. BC).
- Insert hoses of lower layer into arm.

Fig. BC



- Check alignment of pipes under arm and replace their seal (Fig. BD).
- Reconnect connectors 13 (Fig. BE) to hoses tilting them slightly outwards.
- Refit brackets Item 14 (Fig. BE).

Fig. BD





Fig. BE




- Start fork lift truck.
- Operate all hydraulic circuits.
- Check oil level in tank and top up if necessary.
- Switch off engine.
- Decompress all hydraulic circuits.
- Restart.
- Lower stabilisers.
- Perform several complete telescope movements checking hoses unwind correctly inside arm.
- Refit housings 15 (Fig. BF) to rear of chassis.

Fig. BF



- Lower arm so that pin 5 (Fig. E) is opposite hole 6 in chassis.

Fig. E




- Remove hose guide 7 (Fig. F) see pages 6 - 7 (Fig. B - I).

Fig. F



- Remove two mounting bolts 8 (Fig. G) from hydraulic valve block support 9.
- Position wooden block 10 (Fig. G) (approx. 100 mm tall and 300 mm long) under telescopic cylinder.
- Drive out telescopic cylinder pin 5 (Fig. E).

Fig. G



TILT CYLINDER REMOVAL

Operation requires two people

- Remove circlip 1 (Fig. A) from lower pin.
- Drive out pin 2 (Fig. B).



Warning: carriage may tilt.

Fig. A





Fig. B




- Extend cylinder rod fully.

- Relieve pressure from hydraulic circuit by operating control valve levers.


- Disconnect hoses 3 (Fig. C).

Fig. C




- Blank cylinder ports 4 (Fig. D).

Fig. D



- Support cylinder under rod by lowering arm (Fig. E).

Fig. E



MT 835 MU + T.
MT 845 + T.
MT 940 L + T.

MT 845 T. MU
MT 940 L T. MU

PROCEDURE

- Place the truck on a flat surface, position the jib horizontally.

NOTE : Ensure there is sufficient room to extract the telescope.

- Extract the telescope over 450 mm or so.
- Stop the engine.
- Decompress the attachment and tilt circuits.

REMOVAL OF THE LIFT BRACKET

- Procure a suitable device (Pallet stacker, chain block, etc.) to remove the lift bracket.
- Remove head pin item 1 (Fig. A) on the tilt cylinder.
- Remove pin item 2 (Fig. A) on the connecting rod (Ensuring that the articulated parts do not fall down).
- Remove slewing pin item 3 (Fig. A) on the lift bracket.
- Remove the lift bracket (Fig. B).

REMOVAL OF THE TILT CYLINDER

- Position a pan under the tilt cylinder.
- Disconnect both hoses item 1 (Fig. C) on the tilt cylinder (30 mm wrench).

NOTE : Oth elbows item 2 (Fig. C) must stay on the cylinder valve.

- Place caps on the hoses.
- Place a wedge under the tilt cylinder.
- Remove pin item 1 (Fig. D) from the base of the tilt cylinder.
- Remove the tilt cylinder.

Fig. A




Fig. B




Fig. C





Fig. D



REPLACING HOSES OF THE ATTACHMENTS

- Hoses are positioned on the left hand side of the boom.
- Remove pressure in the hydraulic circuit using the distributor lever.
- Remove the circlips from the lower axis of the incline cylinder (Fig. 1).
- Push the axis back (Fig. 2).
- Disconnect the hoses on the end of the boom (Fig. 3), being careful to mark at least one hose, e.g. :
 - A white mark on the lower hose.
- Remove the upper nozzle (Fig. 4) in order to disconnect the lower hose.
- Cut the assembling collars (Fig. 5).
- Unscrew the hose guide (Fig. 6), then remove it (Fig. 7).

Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6





Fig. 7



REMOVAL OF THE INNER TELESCOPE

Remove the incline and attachment hoses as well as the inner telescope cylinder (See “removing the inner telescope cylinder”).

- Replace the lower runners on the inner telescope base (Fig. 1).
- Pull on the end of the boom (Fig. 2) (Pull the telescope out by about 2 m).
- Using a lifting system (Forklift truck, Maniscopic, etc) sling load the telescope at 350 mm from the inner telescope head axis (Fig. 3), if the incline cylinder remains mounted on the boom.
- If this is not the case, sling load the boom at 550 mm from the axis.

IMPORTANT : Mark all runners and shims before removing them.

- Remove the lower runners on the intermediate boom (Fig. 4 -5).

Fig. 1



Fig. 2



Fig. 3




Fig. 4





Fig. 5



REPLACEMENT OF THE INTERMEDIARY HOSES (SUPPLY, ATTACHMENT, AND TILT CYLINDER)

DISASSEMBLY

- Refer to the section "Lower hose disassembly" up to the disassembly of the hose guide (Item 1, Fig. A).

- Remove the cover plate (Item 1, Fig. B).

- Position a wooden block (Item 1, Fig. C) under the cylinder (av. 100 mm high and 300 mm long).

- Remove the circlip and extract the pin at the base of the inside telescope cylinder (Fig. D).

- Remove both fixing screws (Item 1, Fig. E) on the hydraulic flange bracket.

NOTE : A hydraulic supply is needed to extract the telescope cylinder from the jib. There are two options :

- Ⓐ You have another fork lift truck and you supply the cylinder from that truck's attachment circuit.
- Ⓑ Placing the hose guide along the truck, connect the two supply hoses on the inside telescope cylinder (Item 1, Fig. F) on the supply circuit of the tilt cylinder (Item 2, Fig. F).

Fig. A




Fig. B




Fig. C




Fig. D




Fig. E






Fig. F



- Disassemble the relevant hydraulic block inside the jib (Item 1, Fig. K).

- Pull on the hydraulic block (Item 1, Fig. L) so as to be able to disconnect the attachment or tilt supply hoses.

 Check that the pieces of strings follow after the hoses.

NOTE : In order to make it easier to loosen and to tighten the hoses, place a block (Item 2, Fig. L) between the hydraulic block and the hose guide, and hold the assembly with a clamp (Item 3, Fig. L).

- Mark the position of the hoses.

- Disconnect the hoses to be replaced, and remove them, checking that the piece of string does follow after the hose.

REASSEMBLY

- Prepare the new hoses.

Transfer the markings, and pair them using new plastic collars (Item 1, Fig. M) replace the pieces of string.

- Start returning them into place.

- Thread the hoses into the sleeve (Item 1, Fig. N) in the lower telescope, making use of the strings and guiding them from the rear of the jib.

NOTE : Check that the plastic collars are not getting caught into the edge of the sleeve.

- Connect the hoses (Item 1, Fig. O) to the hydraulic block, remove the clamp (Item 2) and the bracket (Item 3, Fig. O).


 The hoses must not get twisted while being tightened on the fittings.

Fig. K




Fig. L




Fig. L1




Fig. M




Fig. N





Fig. O



MOUNTING INSIDE THE JIB

- Present the assembly at the back of the jib.
- Insert the hoses of the accessory circuit and pitch actuator circuit into duct 1 (Fig. X) of the inside telescope.
- Insert the telescoping actuator about 1 metre into the jib (Fig. Y).
- Secure the hydraulic blocks 2 (Fig. Z) onto the pins provided for this purpose.
- Insert the telescoping actuator 3 (Fig. A1) fully.
- Mount the axle of the telescoping actuator.
- Secure clamp support 4 (Fig. B1).
- Check that the six hoses 5 (Fig. C1) are in the same plane.
- If necessary, undo the 6 clamps (Fig. B1), and withdraw the twinned hoses in order to achieve correct alignment.

IMPORTANT : If you have to adjust these twinned hoses, then it is essential that you adjust the four clamps 4 to the positions indicated in (Fig. L), adhering to the mounting instructions.

Fig. X




Fig. Y




Fig. Z




Fig. A1




Fig. B1






Fig. C1




- Thread hose guide 1 (Fig. F1) under the cylinder.
- Thread lower hoses 2 (Fig. F1) under the large telescope.

Fig. F1



- Centre guide 3 (Fig. G1) in relation to the guide block.
- Fix the guide using both screws 4 (Fig. G1) and standard thread locking product.

Fig. G1



- Fit the RH hose guide 1 (Fig. H1) and LH hose guide 2 (Fig. I1) to the rear of the telescope cylinder using fixing screws and washers. See below for the dimensions.

NOTE : The screws to be fitted with standard thread locking compound.

Fig. H1







Fig. I1



DISASSEMBLY OF THE OUTSIDE TELESCOPE CYLINDER

- Stop the truck with the jib in the horizontal position.
- Decompress the supply circuit to the telescope cylinder by operating on the corresponding lever.
- Remove the balancing valve (Item 1, Fig. A) at the base of the cylinder.

 Take care not to damage the seals between the valve and its bracket and to place caps on the supply openings of both the valve and the cylinder.

- Place a sling under cylinder head, using a lifting gear (Fig. B).

- Remove the circlip and extract the pin from the cylinder head (Fig. C).

- Remove the circlips (Fig. D) from the intermediary joints.

- Remove the pins (Item 1, Fig. E) using M12 screws (Item 2, Fig. E).

- Remove the driving squares (Item 1, Fig. F).

Fig. A




Fig. B




Fig. C




Fig. D




Fig. E





Fig. F



5 - SX 14 BLOCK REPAIR PROCEDURES

5.1 CHANGING THE LS LIMITER

NB : This operation does not require removal of the distribution block from the machine.


Machine switched off :

- Place all machine receivers connected to the distribution block in the idle position.
- Work the distribution slide valves to release the pressure build-up.

NB : Collect any leaking oil in an appropriate receptacle.

- On the inlet member, unscrew the LS limiter (17 mm wrench).

Remounting : tightening torque (cf. § 6)



5.2 CHANGING THE FLOW RATE GOVERNOR

NB : This operation does not require removal of the distribution block from the machine.


Machine switched off :

- Place all machine receivers connected to the distribution block in the idle position.
- Work the distribution slide valves to release the pressure build-up.

NB : Collect any leaking oil in an appropriate receptacle.

- On the inlet member, unscrew the flow rate governor (22 mm wrench)


Remounting : tightening torque (cf. § 6)



REMOVING AND REPLACING THE STRAINER

- Using flat nose pliers, extract the strainer from the governor.

Warning: do not damage the O-ring on the end of the governor.



**A29**

Serrer le bouchon à l'aide d'une clé dynamométrique au couple de serrage de 5 (daNm)

**A30**

Placer la pompe verticalement avec l'arbre d'entraînement tourné vers le bas, puis serrer l'étau. Veiller à ne pas abîmer des parties usinées pendant le serrage.

Assembler en vissant l'ensemble à la main.

Le repère fait précédemment (sur le corps de pompe et le couvercle) évitera toute possibilité d'erreur au remontage.

**A31**

Serrer les vis à l'aide d'une clé dynamométrique au couple de serrage de 7 (daNm) en faisant des déplacements diagonalement opposés.

**A32**

Pour contrôler le couple en rotation bouger l'arbre menant pour vérifier qu'il soit libre de tourner et qu'on n'a pas fait d'erreurs pendant le montage.

- Remove the control cylinder stop.



- Extract the piston from the control cylinder.
- Swivel the pump plate to release the piston more easily.



- Remove the control cylinder rod.


NOTE : The head of the rod has a particular shape, so you might need to move the plate in order to remove it.



- Remove the tilting plate.




4 - Mounting of the head and the spacer on the Ø 105 element.

 Check visually the cleanliness level of the element, which must not have scratches, burrs and oxydation traces.


The chamfers for seals passing must be perfectly clean.

Assemble the head on the element after having correctly sprayed the head inside with vaseline oil or hydraulic oil.

Mount the spacer and place its hole facing to the element hole.



5 - Mounting of piston Ø 125 on the element Ø 105

 Check visually the cleanliness level of the rod Ø 25, which must not have scratches, burrs and oxydation traces.



Place the element Ø 105 with its head in one or two vices equipped with smooth jaws and block the element head.

Apply some vaseline oil or hydraulic oil in the mouth of the element.

Assemble the piston Ø 125 and maintain the rod Ø 25 in the center of the element Ø 125, by means of the Ø 25 centering sleeve (Tooling code Y0004094).

Screw and block the piston with the adjustable hook-wrench.

Put some glue (Loctite 243) on the screw and tighten at a torque of 20 N.m. with the dynamometric key.



B - REMOVAL AND REASSEMBLY OF THE PISTON AND LOCKING RING

REMOVAL

- Place the stem in a vice fitted with false jaws.
- Tighten so as to stop it turning.
- Loosen nut 5 (Fig. B1) and unscrew it completely using a box wrench. Or depending on the version, remove locking screw 6 (Fig. 1) using a hexagonal wrench.

NOTE : Locking ring 6 (Fig. B1) is fitted using Loctite, then blocked by striking it with a chisel

- Remove piston 4 (Fig. B2) by pulling it out manually or, depending on the version, by unscrewing piston 7 (Fig. B1) using a hook wrench.
- Remove locking ring 2 (Fig. B3) by sliding it along the stem.

INSPECTION


- Check that the stem is straight over its whole length, using a comparator (Fig. B4).
- Check that the stem is not scaling, corroded or scratched.

REASSEMBLY


- Reassemble locking ring 2 (Fig. B5) on stem 1 (Fig. B5).
- Reassemble piston 4 (Fig. B1) on the stem.
- Screw and lock nut 5 (Fig. B1) using a box wrench and a torque wrench. See the table for the tightening torque (Fig. B6). Or, depending on the version, screw piston 7 (Fig. B1) using a spanner wrench (see tightening torque Fig. B6) and block it with locking screw 6 (Fig. B1).

- NOTE :
- The locking screw should be fitted using Loctite 243, see section E.
 - Tightening torque for the screw = 20 Nm.
 - Strike with a chisel to drive the screw into the metal.


B1




B2




B3



B4




B5




COMPENSATION CYLINDER

MT 1335 H SLT ...



COMPENSATION CYLINDER

MT 1745 H SLT Ultra ...



**HYDRAULIC DIAGRAM MT 1745 HSL TURBO MONO-ULTRA
NACELLE ORH SÉRIE 2-E2**

AC	Accumulator	3	Lowering
		4	Telescope 1/2 sortie
BF	FORE block		
BS3	Selector block 3 elements	MC	Master cylinder
BS4	Selector block 4 elements	MH	Hydrostatic motor
BT	Transfer box		
		N	Level
CA	Suction strainer	P	Hydraulic pump
CAR	Back pressure valve	PAAV	Front attachment fitting (option)
CPD	Double piloted valve	PAAR(O)	Rear attachment fitting (Option)
CSD	Double safety valve	PD	Steering pump
CSP	Piloted safety valve	PH	Hydrostatic pump
		PP	Pressure point
D	Valve bank (9) sections	PRES	Pressure sensitive switch
	EA Attachment section	PRF(O)	Drain-back fitting (option)
	ECD Levelling section	PS	Emergency pump
	EE1 Main inlet section		
	EE2 Secondary inlet section		
	EI Tilting section	R	Hydraulic tank
	EL Lifting section	RF	Cooler
	ES Outlet section	RLF	Réservoir liquide de frein
	ESD R.H. stabilizer section	R3V(O)	Tap 3 ways (option)
	ESG L.H. stabilizer section	R3VD(O)	Tap double 3 ways (Option)
	ET1 Telescope 1 section		
	ET2 Telescope 2 section	TH7	Joystick TH7
	ET3 Telescope 3 section		
D3	Driving valve bank 3 positions	VAP	Control valve
	Position 1 : Steering short	VARM	Manual control valve
	Position 2 : Steering front wheel	VBE	Blocking rear axle cylinder DE
	Position 3 : Crab position	VC	Compensation cylinder DE
DSL	Lifting emergency control valve	VCD	Levelling cylinder DE
DST1/2	Telescope 1/2 emergency control valve	VDAR	Rear steering cylinder
DST3	Telescope 3 emergency control valve	VDAV	Front steering cylinder
		VI	Tilting cylinder DE
		VL	Lifting cylinder DE
ESAR	Rear axle	VN	Cockpit orientation cylinder DE
ESAV	Front axle	VPV	Gear change cylinder
EVPV	Gear change electrovalve	VSD	R.H. stabilizer cylinder DE
EVBE	Rear axle lock electrovalve	VSG	L.H. stabilizer cylinder DE
EVR	Retracting telescope 3 electrovalve	VT1&2	Telescope 1 & 2 cylinder DE
EVS	Extending telescope 3 electrovalve	VT3	Telescope 3 cylinder DE
EVT(F)(O)	Jib head electrovalve (Option)	VTSDL(O)	Translation cylinder TSDL (Option)
		VVT(O)	Locking carriage cylinder (option) DE
F	Filter		
FDAV	Front disk brake		
FR	Return filter		
M	i.C. Engine Type 1104C-44T (TURBO)		
	- Rating slow unladen 850 tr/min		
	- Nominal rating load 2200 tr/min		
	- Max. rating unladen 2350 tr/min		
MA	Joystick		
	M1 Telescope / Attachment		
	M2 Lifting / Tilting		
	M3 R.H. stabilizer		
	M4 L.H. stabilizer		
	M5 Jib head electrovalve (Option)		
	M6 Levelling system		
	1 Lifting		
	2 Telescope 1/2 suppressed		

- NOTA :**
- 1 - The main relief valve's pressure, on inlet sections are given at engine's maximum rating.
 - 2 - The secondary valve's pressure, are given at 1000 rpm of the engine.
 - 3 - Pressure relief valve's control must be done at an oil temperature of 50°C.

HYDRAULIC DIAGRAM**MT 1335 HSL TURBO ULTRA****NACELLE ORH RC SÉRIE 2-E2**

AC	Accumulator	PAAV(O)	Front attachment fitting (option)
AD	Depressurization accumulator	PD	Steering pump
		PH	Hydrostatic pump
BT	Transfer box	PP	Pressure point
		PRF(O)	Drain-back fitting (option)
CA	Suction strainer	PS	Emergency pump
CAR	Back pressure valve		
CPD	Double piloted valve	R	Hydraulic tank
CSD	Double safety valve	RLF	Braking oil tank
CSP	Piloted safety valve	RF	Cooler
D1	Valve bank 3 sections	TH7	Joystick TH7
	EA Attachment section		
	ECD Levelling section		
	EE Inlet section	VBE	Blocking rear axle cylinder DE
	ET2 Telescope 2 section	VC	Compensation cylinder DE
		VCD	Levelling cylinder DE
D2	Valve bank 5 sections	VDAR	Rear steering cylinder
	EE Inlet section	VDAV	Front steering cylinder
	EI Tilting section	VI	Tilting cylinder DE
	EL Lifting section	VL	Lifting cylinder DE
	ESD R.H. stabilizer section	VN	Cockpit orientation cylinder DE
	ESG L.H. stabilizer section	VPV	Gear change cylinder
	ET1 Telescope 1 section	VSD	R.H. stabilizer cylinder DE
		VSG	L.H. stabilizer cylinder DE
D3	Steering valve bank 3 positions	VT1	Telescope 1 cylinder DE
	Position 1 : Steering short	VT2	Telescope 2 cylinder DE
	Position 2 : Steering front wheels	VVT(O)	Locking carriage cylinder (option) DE
	Position 3 : Crab position		
ESAR	Rear axle		
ESAV	Front axle		
EVBE	Rear axle lock electrovalve		
EVPV	Gear change electrovalve		
FDAV	Front disk brake		
FHP	High pressure filter		
FR	Return filter		
M	I.C. Engine Type 1104C-44T (TURBO)		
	- Rating slow unladen	850 tr/min	
	- Nominal rating load	2200 tr/min	
	- Max rating unladen	2350 tr/min	
MA	Joystick		
	C1 Extending telescope 1 & 2		
	C2 Retracting telescope 1 & 2		
	C3 Extending telescope 3		
	C4 Retracting telescope 3		
	BP1 Tap : Stabilizer / Levelling		
	BP2 Tap : Attachment		
	1 Lifting		
	2 Reverse tilt		
	3 Lowering		
	4 Forward tilt		
MC	Master cylinder		
MH	Hydrostatic motor		
N	Level		
P	Hydraulic pump		

- NOTA :**
- 1 - The main relief valve's pressure, on inlet sections are given at engine's maximum rating.
 - 2 - The secondary valve's pressure, are given at 1000 rpm of the engine.
 - 3 - Pressure relief valve's control must be done at an oil temperature of 50°C.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

HYDRAULIC DIAGRAM**MT 1435 HSL TURBO ULTRA SÉRIE 2-E2**

AC	Accumulator	PD	Steering pump
AD	Depressurization accumulator	PH	Hydrostatic pump
		PP	Pressure point
BT	Transfer box	PRF(O)	Drain-back fitting (option)
CA	Suction strainer	R	Hydraulic tank
CAR	Back pressure valve	RLF	Braking oil tank
CPD	Double piloted valve	RF	Cooler
CSD	Double safety valve		
CSP	Piloted safety valve		
D1	Valve bank 3 sections	TH7	Joystick TH7
	EA Attachment section		
	ECD Levelling section	VC	Compensation cylinder DE
	EE Inlet section	VCD	Levelling cylinder DE
	ET2 Telescope 2 section	VDAR	Rear steering cylinder
		VDAV	Front steering cylinder
		VI	Tilting cylinder DE
D2	Valve bank 5 sections	VL	Lifting cylinder DE
	EE Inlet section	VSD	R.H. stabilizer cylinder DE
	EI Tilting section	VSG	L.H. stabilizer cylinder DE
	EL Lifting section	VT1	Telescope 1 cylinder DE
	ESD R.H. stabilizer section	VT2	Telescope 2 cylinder DE
	ESG L.H. stabilizer section	VVT(O)	Locking carriage cylinder (option) DE
	ET1 Telescope 1 section		
D3	Steering valve bank 3 positions		
	Position 1 : Steering short		
	Position 2 : Steering front wheels		
	Position 3 : Crab position		
ESAR	Rear axle		
ESAV	Front axle		
EVPV	Gear change electrovalve		
FDAV	Front disk brake		
FHP	High pressure filter		
FR	Return filter		
M	I.C. engine Type 1104C-44T (TURBO)		
	- Rating slow unladen 850 tr/min		
	- Nominal rating load 2200 tr/min		
	- Max rating unladen 2350 tr/min		
MA	Joystick		
	C1 Extending telescope 1 & 2		
	C2 Retracting telescope 1 & 2		
	C3 Extending telescope 3		
	C4 Retracting telescope 3		
	BP1 Tap : Stabilizer / Levelling		
	BP2 Tap : Attachment		
	1 Lifting		
	2 Reverse tilt		
	3 Lowering		
	4 Forward tilt		
MC	Master cylinder		
MH	Hydrostatic motor		
N	Level		
P	Hydraulic pump		
PAAV(O)	Front attachment fitting (option)		

- NOTA :**
- 1 - The main relief valve's pressure, on inlet sections are given at engine's maximum rating.
 - 2 - The secondary valve's pressure, are given at 1000 rpm of the engine.
 - 3 - Pressure relief valve's control must be done at an oil temperature of 50°C.



REPAIR INSTRUCTIONS

CONTENTS

- General repair instructions	5
- Seal kits and sub assembly groups	6
- Sub assemblies groups	7 à 8
- Sealing of the drive shaft	9
- Sealing of the boost pump	10
- Sealing of the control piston cover	11
- Sealing of the control piston cover	12
- Sealing of the boost pressure valve	13
- Sealing of the pressure relief valve HD	14
- Sealing of the pressure cut-off valve	15
- Sealing of the control device.....	16
- Control device DA	18
- Sealing of the regulator valve.....	19
- Pump disassembly	20 à 22
- Disassembly of the positioning piston	23 à 24
- Dismantling of the cylinder	25
- Inspection notes.....	26 à 27
- Positioning piston, rotary group assembly	28
- Installation of rotary group	29 à 30
-Assembly of the pump	31 à 33

REPAIR INSTRUCTIONS


Sealing of the pressure relief valve HD




Remove valve completely.
Control : O-ring, housing.
Replacement of the tightening nut, record measure (*).
Attention !
After assembly check "valve setting".

REPAIR INSTRUCTIONS



Dismantling of the control




Mark position of the cover.
Loosen locking screw, remove cover.



Remove positioning ring.



Fit tool device and preload spring.
Remove take-off ring.



Remove rings.
Remove safety ring.
Attention : parts are under spring load.

**Tightening torques for shaft bolts
(Metric ISO Standard Thread)**

The values for tightening torques shown in the table are valid only for shaft bolts with metric ISO- standard threads and head support surface dimensions in accordance with DIN 912, DIN 931 and DIN 933. These values are also valid only for light or uncoiled, untreated surface as well as for use only with torque-indicating wrenches and force limiting tools.	Thread size	Strength Classes		
		8.8	10.9	12.9
		Tightening Torque (lb.ft)		
	M 3	0,8	1,2	1,4
	M 4	2,1	3,0	3,6
	M 5	4,4	6,3	7,4
	M 6	7,4	10,3	12,5
	M 8	18,4	25,8	30,2
	M10	36,1	50,9	61,2
	M12	63,4	88,4	106,9
M14	99,5	140,0	169,5	
M16	154,8	217,4	261,6	
M18	213,7	298,5	357,4	
M 20	302,2	427,5	508,5	
M 22	405,4	574,9	685,4	
M 24	523,5	737,0	884,4	
M 27	773,9	1105,5	1326,6	
M 30	1068,7	1474,0	1768,8	

**Tightening torques for locking screws VSTI
(Metric ISO fine thread)**


Thread size	Designation	Tightening torques (lb.ft)
M 8 x 1	VSTI 8 x 1 -ED/SA	= 4
M 10 x 1	VSTI 10 x1 -ED	= 7
M 12 x 1,5	VSTI 12 x 1,5 -ED	= 15
M 14 x 1,5	VSTI 14 x 1,5 -ED	= 22
M 16 x 1,5	VSTI 16 x 1,5 -ED/SA	= 22
M 18 x 1,5	VSTI 18 x 1,5 -ED/SA	= 29
M 20 x 1,5	VSTI 20 x 1,5 -ED/SA	= 37
M 22 x 1,5	VSTI 22 x 1,5 -ED	= 44
M 26 x 1,5	VSTI 16 x 1,5 -ED/SA	= 51
M 27 x 2	VSTI 27 x 2 -ED	= 66
M 30 x 1,5	VSTI 30 x 1,5 -ED/SA	= 74
M 33 x 2	VSTI 33 x 2 -ED/SA	= 88
M 42 x 2	VSTI 42 x 2 -ED/SA	= 147
M 48 x 2	VSTI 48 x 2 -ED	= 220



**Tightening torques for seal-lock nuts
(Metric ISO-Standard Thread)**

The values for tightening torques shown in the table are valid only for seal-lock nuts of the strength class 8.8 and with metric ISO-standard thread.	Thread size	Strength classes		
		8.8	10.9	12.9
		Tightening torque (lb.ft)		
	M 6	7,4		
	M 8	16,2		
	M 10	29,5		
	M 12	50,9		
	M 14	81,1		
	M 16	125,3		


**Tightening torques for cross-slotted lens head screws
DIN 7985
(Metric ISO- Standard Thread)**

The values for tightening torques shown in the table are valid only for cross-slotted lens head screws DIN 7985 of the strength class 8.8 and with metric ISO-standard thread.	Thread size	Strength classes		
		8.8	10.9	12.9
		Tightening torques (lb.ft)		
	M 3	0,8		
	M 4	2,1		
	M 5	4,4		
	M 6	7,4		
	M 8	18,4		
	M10	36,1		







32 Loosen fixing screw.
Use only socket wrench.




52




53 Insert retaining plate with piston and center pin. Use screw with Precote-coating.



54 Make sure all parts are fitted in correctly.




55 Swivel cylinder block to max. and fix the cylinder.



PUMP A 4 VG 71 DA PRESSURE MEASURING POINTS

For the kits of pressure port hoses and couplings, please refer to the catalogue "pressure gauge box" Ref. 547037.


PUMP A 4 VG 71 - 90 DA



5. ADJUSTING MOTOR A 6VM DISPLACEMENT CHANGEOVER

A) CHECK MINIMUM DISPLACEMENT (MAX. SPEED) :

- The check is made driving the truck on level ground with the engine a full speed in forward drive.



- Connect two 600 bar pressure gauges as shown above. At maximum drive speed the two gauges should read the same. This signifies that both sides of the Servo piston are subject to the same pressure and the motor is at its minimum displacement.
- The actual speed can be verified (see the speed scale and technical data for the machine).

B) CHECK START OF REGULATION :

- With the wheels raised from the ground and the truck supported on blocks gradually apply the brake pedal to raise the pressure in the HP circuits (inching valve by-passed).
- Watch the two gauges. When the HP gauge shows 200/250 bar the changeover pressure will drop then the HP will continue to rise until it reaches the setting of the DR valve. (Changeover pressure : See specification for different trucks).
- The changeover point can be adjusted by the screw.

ELECTRIC DIAGRAM

MT 1745 H SL TURBO ULTRA SÉRIE 2-E2

↳ N°: 222099

ELECTRIC PRINCIPLE CIRCUIT

- 1 - Preheating
- 2 - Battery
- 3 - Starter
- 4 - Preheating relay
- 5 - Cold start
- 6 - Engine stop electrovalve
- 7 - Alternator
- 8 - Fuel level
- 9 - Machine fault sound alarm
- 10 - Hourmeter
- 11 - Load indicator
- 12 - Engine oil pressure
- 13 - Brake fluid
- 14 - Air filter clogging
- 15 - Engine water temperature
- 16 - Filter clogging indicator light
- 17 - Free
- 18 - Hand brake
- 20 - Front wheels alignment detector
- 21 - Front wheels alignment indicator light
- 22 - Rear wheels alignment detector
- 23 - Rear wheels alignment indicator light
- 24 - Sound alarm
- 25 - L.H. stoplight
- 26 - R.H. stoplight
- 27 - Free
- 30 - L.H. working head light
- 31 - R.H. working head light
- 32 - Control panel lighting
- 33 - R.H. rear position light
- 34 - R.H. front position light
- 35 - L.H. rear position light
- 36 - L.H. front position light
- 37 - L.H. front low beam
- 38 - R.H. front low beam
- 39 - L.H. front main beam
- 40 - R.H. front main beam
- 41 - Main beam indicator light
- 42 - Revolving light
- 43 - R.H. working tail light
- 44 - L.H. working tail light
- 45 - Free
- 46 - Hydraulic motor rotation electrovalve
- 47 - L.H. rear reverse light
- 48 - R.H. rear reverse light
- 49 - Reverse gear sound alarm
- 50 - Moving speed limitation electrovalve
- 51 - Forward electrovalve
- 52 - Reverse electrovalve
- 53 - Low speed indicator light
- 54 - High speed indicator light
- 55 - High speed electrovalve
- 56 - High speed control relay
- 57 - Low speed control relay
- 58 - Start safety relay
- 59 - Forward relay
- 60 - Reverse relay
- 61 - Rear reverse light relay
- 63 - Safety system
- 64 - Movements cut-off
- 67 - Front windscreen washer
- 68 - Front windscreen wiper
- 69 - Flasher unit / warning unit
- 70 - Flasher unit / warning unit indicator light
- 71 - R.H. rear indicator
- 72 - R.H. front indicator
- 73 - L.H. rear indicator
- 74 - L.H. front indicator
- 75 - Warning unit / indicator light switch
- 76 - Roof light
- 77 - Cabin rear windscreen wiper
- 78 - Cabin roof windscreen wiper
- 79 - Ventilation
- 80 - Free
- 81 - Transmission cut-off relay
- 82 - Lifting proportional electrovalve
- 83 - Tilting proportional electrovalve
- 84 - Telescope 1 & 2 proportional electrovalve
- 85 - Telescope 3 proportional electrovalve
- 86 - Attachment proportional electrovalve
- 87 - Levelling proportional electrovalve
- 88 - R.H. stabilizer proportional electrovalve
- 89 - L.H. stabilizer proportional electrovalve
- 90 - Movements cut-off (safety module)
- 91 - Stabilizers pressostat
- 92 - Joystick
- 93 - E18/S6 module
- 94 - Movements cut-off switch
- 95 - Levelling movement safety
- 96 - Safety : block axle/jib lifting 67°
- 97 - Safety : speed jib lifting 67°
- 98 - Reduction : speed jib lifting

COLOUR CODING

- | | | |
|------------|--------------------|------------|
| bc : White | bl : Blue | g : Grey |
| j : Yellow | jvt : Yellow/Green | m : Brown |
| n : Black | o : Orange | r : Red |
| ro : Pink | vt : Green | v : Purple |

CONNECTOR

- A - Fuse box/relay (4 pin connection + 1 pin connection)
- B - Indicator light module
- C - Cabin
- D - Front windscreen wiper
- E - Fuse box/relay (13 pin connection)
- F - Fuse box/relay (7 pin connection)
- G - Fuse box/relay (11 pin connection)
- H - Fuse box/relay (21 pin connection)
- I - Lighting switch
- J - Engine box
- K - Engine harness (4 pin connection)
- R - Valve bank (6 pin connection)
- S - Joystick (6 pin connection)
- T - Load safety module (3 pin connection)
- U - Load safety module (6 pin connection)
- V - Principle beam (2 pin connection)

ELECTRIC DIAGRAM

→ N°: 236905

MT 1335 H SL TURBO MONO ULTRA ORH SÉRIE 2-E2**MT 1435 H SL TURBO MONO ULTRA ORH SÉRIE 2-E2**

S33 - Transmission cut-off switch to accelerator pedal
S34 - Seat switch

V1 - Fault test diode
V2 - Diode (TUV version)

Y1 - Engine stop electrovalve
Y2 - Forward electrovalve
Y3 - Reverse electrovalve
Y4 - Hydraulic engine rotation electrovalve
Y5 - Free
Y6 - High speed electrovalve
Y7 - Cold start electrovalve
Y8 - Moving speed limitation electrovalve

ELECTRIC DIAGRAM

↳ N°: 236906

MT 1335 H SL TURBO ULTRA ORH RC SÉRIE 2-E2**MT 1435 H SL TURBO ULTRA ORH RC SÉRIE 2-E2**

- S33 - Transmission cut-off switch to accelerator pedal
- S34 - HP filter clogging pressure switch
- S35 - Seat switch

- V1 - Fault test diode
- V2 - Diode (TUV version)

- Y1 - Engine stop electrovalve
- Y2 - Forward electrovalve
- Y3 - Reverse electrovalve
- Y4 - Hydraulic motor rotation electrovalve
- Y6 - High speed electrovalve
- Y7 - Cold start electrovalve
- Y8 - Moving speed limitation electrovalve

ELECTRIC DIAGRAM

MT 1745 H SL TURBO ULTRA ORH RC SÉRIE 2-E2

↳ N°: 236906

ELECTRIC PRINCIPLE CIRCUIT

- 1 - Preheating
- 2 - Battery
- 3 - Starter
- 4 - Preheating relay
- 5 - Cold start
- 6 - Engine stop electrovalve
- 7 - Alternator
- 8 - Fuel level
- 9 - Machine fault sound alarm
- 10 - Hourmeter
- 11 - Load indicator
- 12 - Engine oil pressure
- 13 - Brake fluid
- 14 - Air filter clogging
- 15 - Engine water temperature
- 16 - Hydraulic return filter clogging
- 17 - Free
- 18 - Hand brake
- 19 - Free
- 20 - Front wheels alignment detector
- 21 - Front wheels alignment indicator light
- 22 - Rear wheels alignment detector
- 23 - Rear wheels alignment indicator light
- 24 - L.H. stoplight
- 25 - R.H. stoplight
- 26 - Sound alarm
- 27 - Free
- 28 - L.H. working head light
- 29 - R.H. working head light
- 30 - Control panel lighting
- 31 - R.H. rear position light
- 32 - R.H. front position light
- 33 - L.H. rear position light
- 34 - L.H. front position light
- 35 - L.H. front low beam
- 36 - R.H. front low beam
- 37 - L.H. front main beam
- 38 - R.H. front main beam
- 39 - Main beam indicator light
- 40 - Revolving light
- 41 - R.H. working tail light
- 42 - L.H. working tail light
- 43 - Free
- 44 - Free
- 46 - Hydraulic motor rotation electrovalve
- 47 - L.H. rear reverse light
- 48 - R.H. rear reverse light
- 49 - Reverse gear sound alarm
- 50 - Moving speed limitation electrovalve
- 51 - Forward electrovalve
- 52 - Reverse electrovalve
- 53 - Low speed indicator light
- 54 - High speed indicator light
- 55 - High speed electrovalve
- 56 - High speed control relay
- 57 - Low speed control relay
- 58 - Start safety relay
- 59 - Forwrd relay
- 60 - Reverse relay
- 61 - Rear reverse light relay
- 62 - Transmission cut-off relay

- 65 - Front windscreen washer
- 66 - Front windscreen wiper
- 67 - Blinker centre / warning
- 68 - Blinker centre / warning indicator light
- 69 - R.H. rear blinker
- 70 - R.H. front blinker
- 71 - L.H. rear blinker
- 72 - L.H. front blinker
- 73 - Warning switch / indicator light
- 74 - Roof light
- 75 - Cabin rear windscreen wiper
- 76 - Cabin roof windscreen wiper
- 79 - Ventilation
- 80 - Platform start relay
- 81 - HP filter clogging

COLOUR CODING

- | | | |
|------------|--------------------|------------|
| bc : White | bl : Blue | g : Grey |
| j : Yellow | jvt : Yellow/Green | m : Brown |
| n : Black | o : Orange | r : Red |
| ro : Pink | vt : Green | v : Purple |

CONNECTEUR

- A - Fuses box / relay (4 pin connection + 1 pin connection)
- B - Indicator light module
- C - Cabin
- D - Front windscreen wiper
- E - Fuses box / relay (13 pin connection)
- F - Fuses box / relay (7 pin connection)
- G - Fuses box / relay (11 pin connection)
- H - Fuses box / relay (21 pin connection)
- I - Light switch
- J - Engine box
- K - Box connection ORH (11+1+1 ways)
- L - Box connection ORH (4 ways)
- M - Box connection (2 ways)

ELECTRIC COMPONENTS

- E1 - R.H. rear blinker
- E2 - R.H. front blinker
- E3 - L.H. rear blinker
- E4 - L.H. front blinker
- E5 - L.H. stoplight
- E6 - R.H. stoplight
- E7 - R.H. rear position light
- E8 - R.H. front position light
- E9 - L.H. rear position light
- E10 - L.H. front position light
- E11 - L.H. front low beam
- E12 - R.H. front low beam
- E13 - L.H. front main beam
- E14 - R.H. front main beam
- E15 - R.H. working tail light
- E16 - L.H. working tail light
- E17 - L.H. working head light
- E18 - R.H. working head light
- E19 - Revolving light
- E20 - L.H. rear reverse light

→ N°: 222098

ELECTRIC PRINCIPLE DIAGRAM

1	- Preheating	62	- Transmission cut-off relay
2	- Battery	63	- Safety system
3	- Starter	64	- Movements cut-off
4	- Preheating relay	65	- Movements cut-off suppression switch
5	- Cold start	66	- Movements cut-off electrovalve
6	- Engine stop electrovalve	67	- Stabilizer control switch
7	- Alternator	68	- Arm lifting angular sensor
8	- Fuel level	69	- Free
9	- Machine fault sound alarm	70	- Arm angular safety electrovalve
10	- Hourmeter	71	- Free
11	- Load indicator	72	- Front windscreen washer
12	- Engine oil pressure	73	- Front windscreen wiper
13	- Brake fluid	74	- Levelling movement safety
14	- Air filter clogging	75	- Angular speed safety
15	- Engine water temperature	76	- Movements safety (stabilizer)
16	- Hydraulic return filter clogging	77	- Retracted telescope safety
17	- Free	78	- Blinking centre / warning
18	- Hand brake	79	- Blinking centre / warning indicator light
19	- Free	80	- R.H. rear blinker
20	- Front wheels alignment detector	81	- R.H. front blinker
21	- Front wheels alignment indicator light	82	- L.H. rear blinker
22	- Rear wheels alignment detector	83	- L.H. front blinker
23	- Rear wheels alignment indicator light	84	- Warning switch / indicator light
24	- Sound alarm	85	- Roof light
25	- L.H. stoplight	86	- Cabin rear windscreen wiper
26	- R.H. stoplight	87	- Cabin roof windscreen wiper
27	- Free	88	- Ventilation
28	- Free	89	- Free
29	- Free		
30	- L.H. working head light		
31	- R.H. working head light		
32	- Control panel lighting		
33	- R.H. rear position light		
34	- R.H. front position light		
35	- L.H. rear position light		
36	- L.H. front position light		
37	- L.H. front low beam		
38	- R.H. front low beam		
39	- L.H. front main beam		
40	- R.H. front main beam		
41	- Main beam indicator light		
42	- Revolving light		
43	- R.H. working tail light		
44	- L.H. working tail light		
45	- Free		
46	- Hydraulic motor rotation electrovalve		
47	- L.H. rear reverse light		
48	- R.H. rear reverse light		
49	- Reverse gear sound alarm		
50	- Moving speed limitation electrovalve		
51	- Forward electrovalve		
52	- Reverse electrovalve		
53	- Low speed indicator light		
54	- High speed indicator light		
55	- High speed electrovalve		
56	- High speed control relay		
57	- Low speed control relay		
58	- Start safety relay		
59	- Forward relay		
60	- Reverse relay		
61	- Rear reverse light relay		

COLOUR CODING

bc : White	bl : Blue	g : Grey
j : Yellow	jvt : Yellow/Green	m : Brown
n : Black	o : Orange	r : Red
ro : Pink	vt : Green	v : Purple

CONNECTEUR

A	- Fuses box / relay (4 pin connection + 1 pin connection)
B	- Indicator light module
C	- Cabin
D	- Front windscreen wiper
E	- Fuses box / relay (13 pin connection)
F	- Fuses box / relay (7 pin connection)
G	- Fuses box / relay (11 pin connection)
H	- Fuses box / relay (21 pin connection)
I	- Light switch
J	- Engine box
K	- Control case (ORH)

ELECTRIC COMPONENTS

E1	- R.H. rear blinker
E2	- R.H. front blinker
E3	- L.H. rear blinker
E4	- L.H. front blinker
E5	- L.H. stoplight
E6	- R.H. stoplight
E7	- R.H. rear position light
E8	- R.H. front position light
E9	- L.H. rear position light

↳ N°: 222099

ELECTRIC PRINCIPLE CIRCUIT

1	- Preheating	67	- Front windscreen washer
2	- Battery	68	- Front windscreen wiper
3	- Starter	69	- Blinking centre / warning
4	- Preheating relay	70	- Blinking centre / warning indicator light
5	- Cold start	71	- R.H. rear blinker
6	- Engine stop electrovalve	72	- R.H. front blinker
7	- Alternator	73	- L.H. rear blinker
8	- Fuel level	74	- L.H. front blinker
9	- Machine fault sound alarm	75	- Warning switch / indicator light
10	- Hourmeter	76	- Roof light
11	- Load indicator	77	- Cabin rear windscreen wiper
12	- Engine oil pressure	78	- Cabin roof windscreen wiper
13	- Brake fluid	79	- Ventilation
14	- Air filter clogging	80	- Free
15	- Engine agua temperature	81	- Free
16	- Hydraulic return filter clogging	82	- Lifting proportional electrovalve
17	- Free	83	- Tilting proportional electrovalve
18	- Hand brake	84	- Telescope 1 & 2 proportional electrovalve
20	- Front wheels alignment detector	86	- Attachment proportional electrovalve
21	- Front wheels alignment indicator light	87	- Levelling proportional electrovalve
22	- Rear wheels alignment detector	88	- R.H. stabilizer proportional electrovalve
23	- Rear wheels alignment indicator light	89	- L.H. stabilizer proportional electrovalve
24	- Sound alarm	90	- Rear axle lock electrovalve
25	- L.H. stoplight	91	- E18/S6 module
26	- R.H. stoplight	92	- Joystick
27	- Free	93	- Stabilizer control switch
30	- L.H. working head light	94	- Movements safety (stabilizer)
31	- R.H. working head light	95	- Levelling movement safety
32	- Control panel lighting	96	- Arm lifting angular sensor
33	- R.H. rear position light	97	- Movements cut-off switch
34	- R.H. front position light	98	- Movements cut-off (safety module)
35	- L.H. rear position light		
36	- L.H. front position light		
37	- L.H. front low beam		
38	- R.H. front low beam		
39	- L.H. front main beam		
40	- R.H. front main beam		
41	- Main beam indicator light		
42	- Revolving light		
43	- R.H. working tail light		
44	- L.H. working tail light		
45	- Free		
46	- Hydraulic motor rotation electrovalve		
47	- L.H. rear reverse light		
48	- R.H. rear reverse light		
49	- Reverse gear sound alarm		
50	- Moving speed limitation electrovalve		
51	- Forward electrovalve		
52	- Reverse electrovalve		
53	- Low speed indicator light		
54	- High speed indicator light		
55	- High speed electrovalve		
56	- High speed control relay		
57	- Low speed control relay		
58	- Start safety relay		
59	- Forward relay		
60	- Reverse relay		
61	- Rear reverse light relay		
62	- Transmission cut-off relay		
63	- Safety system		
64	- Movements cut-off		

COLOUR CODING

bc : White	bl : Blue	g : Grey
j : Yellow	jvt : Yellow/Green	m : Brown
n : Black	o : Orange	r : Red
ro : Pink	vt : Green	v : Purple

CONNECTEUR


A	- Fuses box / relay (4 pin connection + 1 pin connection)
B	- Indicator light module
C	- Cabin
D	- Front windscreen wiper
E	- Fuses box / relay (13 pin connection)
F	- Fuses box / relay (7 pin connection)
G	- Fuses box / relay (11 pin connection)
H	- Fuses box / relay (21 pin connection)
I	- Light switch
J	- Engine box
K	- Principle beam (4 way case)
L	-
M	-
N	-
O	-
R	- Valve bank (6 pin connection)
S	- Joystick (6 pin connection)
T	- Load safety module (3 pin connection)
U	- Load safety module (6 pin connection)
V	- Principle beam (2 pin connection)

BB-3 CALIBRATOR

MLT ... LSU
MLA ... LSU

Parts required

1 BB3 calibrator	Ref.662 070	Item 1
1 connecting lead	Ref.662 071	Item 2



Procedure

⚠ Never connect or disconnect the BB3 calibrator while the machine is switched on.

- Switch off the machine.
- Open the lid of the document holder 3 (Fig. A or B) situated behind the driver's seat.

Fig. A MLT ... LSU




Fig. B MLA ... LSU




Fig. C MLT ... LSU




Fig. D MLA ... LSU



- Connect the BB3 calibrator to the micro-controller's diagnostic socket 4 (Fig. C or D).

N°	DESCRIPTION OF ACTION	KEY	CALIBRATOR SCREEN DISPLAY	COMMENTS
7 Procedure to be followed if the engine stalls				
7,1	- Press →	F1	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GEN settings 2 _____ GLR settings 3 _____ Param1 GLR 4 _____ Param2 GLR </div>	
7,2	- Press →	4	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GLR Min 2 _____ measure time 3 _____ 4 _____ </div>	
7,3	- Press →	1	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 60 </div>	
7,4	- Press twice →	CLEAR	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 </div>	To clear the parameter.
7,5	- Press → then - Press →	5 5	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 55 </div>	To enter the new parameter. Lower in steps of 5%. NOTE : Do not go below 40%.
7,6	- Press →	ENTER	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GLR Min 2 _____ measure time 3 _____ 4 _____ </div>	To confirm the new parameter.
7,7	- Press →	MENU	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GEN settings 2 _____ GLR settings 3 _____ Param1 GLR 4 _____ Param2 GLR </div>	Return to the previous menu.
7,8	- Press →	MENU	<div style="border: 1px solid black; padding: 5px;"> F1 _____ Config/Cal F2 _____ Diagnostic PROC _____ Status TEACH _____ Storage </div>	Return to the initial menu.
7,9	- Save the parameters			See steps 4.1 to 4.5.

5 - RC2-1 MICROCONTROLLER SETTINGS : F1 MENU (Adjustment and parameter setting)
(Ref : 236673 - 246556 - 249920)

1 gen settings				2 GLR settings			
1 - poti nominal min.position max position	/	/		1 - diesel charac adjustment range min 0 max 1 increment +/- 1			0
Not used				Creation of the learning curve			
2 - poti diesel Idling speed min position upper than 0,6 Maxi speed max position lower than 4,4	0,8 V 4,3 V			2 - GLR on / off value 1 GLR off value 2 GLR on			GLR on
Record of te potentiometer Thermal motor system	Example			Activation power regulation			
3 - I min pump adjustment range min 200 mA max 600 mA increment +/- 10 mA	0,8 V 4,3 V 400 mA			3 - R diesel adjustment range min 500 ms max 3000 ms increment +/- 22 ms			1800 ms
Minimum current proportional solenoid				Times ramp of teh reaction of teh regulation			
4 - I max pump adjustment range min 1000 mA max 1600 mA increment +/- 10 mA	1200 mA			4 - teeth diesel adjustment range min 1 max 300 increment +/- 1			MLT A15 MLA 17 MLT B 17
Maximum current proportional solenoid				Number of flying teeth motor or coefficient reading motor system			
5 - dither - freq value 1 100 Hz value 2 200 Hz	100 Hz			5 - fixed eng spd adjustment range min 0 rpm max 3000 rpm increment +/- 10 rpm			0 rpm
Frequency adjustment Dither							
6 - supply voltage value 1 12 V value 2 24 V	12 V			6 - dump idle spee adjustment range min 50 rpm max 300 rpm increment +/- 5 rpm			50 rpm
Supply voltage				Load tolerance motor idle			
7 - displacem swi value 1 setting poti value 2 setting BB3	setting BB3			7 - dump half spee adjustment range min 50 rpm max 500 rpm increment +/- 5 rpm			200 rpm
Max displacement : pump controlled by potentiometer or BB3				Load tolerance motor semi-mode			
8 - nom displacem adjustment range min 0 % max 100 % increment +/- 1 %	100 %			8 - dump full spee adjustment range min 50 rpm max 500 rpm increment +/- 5 rpm			300 rpm
Max displacement pumps authorised in %				Load tolerance motor at maximum			


BB-3 CALIBRATOR

MLT ... LSU
MLA ... LSU

Parts required

1 BB3 calibrator
1 connecting lead

Ref.662 070 Item 1
Ref.662 071 Item 2



Procedure

⚠ Never connect or disconnect the BB3 calibrator while the machine is switched on.

- Switch off the machine.
- Open the lid of the document holder 3 (Fig. A or B) situated behind the driver's seat.

Fig. A MLT ... LSU




Fig. B MLA ... LSU




Fig. C MLT ... LSU





Fig. D MLA ... LSU



- Connect the BB3 calibrator to the micro-controller's diagnostic socket 4 (Fig. C or D).

N°	DESCRIPTION OF ACTION	KEY	CALIBRATOR SCREEN DISPLAY	COMMENTS
7 Procedure to be followed if the engine stalls idling				
7,1	- Press →	F1	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GEN settings 2 _____ GLR settings 3 _____ Param1 GLR 4 _____ Param2 GLR </div>	
7,2	- Press →	4	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GLR Min 2 _____ measure time 3 _____ 4 _____ </div>	
7,3	- Press →	1	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 60 </div>	
7,4	- Press twice →	CLEAR	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 </div>	To clear the parameter.
7,5	- Press → then - Press →	5 5	<div style="border: 1px solid black; padding: 5px;"> 1 GLR Min 0 - 80 +/- 1 55 </div>	To enter the new parameter. Lower in steps of 5%. NOTE : Do not go below 40%.
7,6	- Press →	ENTER	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GLR Min 2 _____ measure time 3 _____ 4 _____ </div>	To confirm the new parameter.
7,7	- Press →	MENU	<div style="border: 1px solid black; padding: 5px;"> 1 _____ GEN settings 2 _____ GLR settings 3 _____ Param1 GLR 4 _____ Param2 GLR </div>	Return to the previous menu.
7,8	- Press →	MENU	<div style="border: 1px solid black; padding: 5px;"> F1 _____ Config/Cal F2 _____ Diagnostic PROC _____ Status TEACH _____ Storage </div>	Return to the initial menu.
7,9	- Save the parameters			See steps 4.1 to 4.5.

5 - RC2-2 MICROCONTROLLER SETTINGS : F1 MENU (Adjustment and parameter setting)

(Ref : 253157)

Blue: Adjustment of the theoretical engine speed sensor.

Yellow: Adjustment points adaptable by the customer.


1 gen settings				2 GLR settings				3 Param 1 GLR			
1 - poti nominal min.position max position		/ /		1 - diesel charac adjustment range min 0 max 1 increment +/- 1		0		1 - P1 (nA > nN) adjustment range min 1 max 2000 increment +/- 10		400	
Not used				Creation of the learning curve							
2 - poti diesel Idling speed min position upper than 0,6 Maxi speed max position lower than 4,4		Example		2 - GLR on / off value 1 GLR off value 2 GLR on		GLR on		2 - P2 (nA < nN) adjustment range min 1 max 2000 increment +/- 10		400	
Record of te potentiometer Thermal motor system				Activation power regulation							
3 - I min pump adjustment range min 200 mA max 600 mA increment +/- 10 mA		0,8 V 4,3 V 400 mA		3 -				3 - I1 (nA > nN n' > 0) adjustment range min 0 max 1000 increment +/- 10		100	
Minimum current proportional solenoid											
4 - I max pump adjustment range min 1000 mA max 1600 mA increment +/- 10 mA		1200 mA		4 - teeth diesel adjustment range min 1 max 300 increment +/- 1		MLA 17 MLT B 17		4 - I2 (nA > nN n' < 0) adjustment range min 0 max 1000 increment +/- 10		100	
Maximum current proportional solenoid				Number of flying teeth motor or coefficient reading motor system							
5 - dither - freq value 1 100 Hz value 2 200 Hz		100 Hz		5 - fixed eng spd adjustment range min 0 rpm max 3000 rpm increment +/- 10 rpm		0 rpm		5 - I3 (nA < nN n' < 0) adjustment range min 0 max 1000 increment +/- 10		400	
Frequency adjustment Dither											
6 - CAN-service value 1 on value 2 off		off		6 - diesel-up adjustment range min 500 ms max 3000 ms increment +/- 22 ms		3000 ms		6 - I4 (nA < nN n' > 0) adjustment range min 0 max 1000 increment +/- 10		240	
Not used				Ramp inertia acceleration fuel injection pump							
7 - displacem swi value 1 setting poti value 2 setting BB3		setting BB3		7 - diesel down adjustment range min 500 ms max 3000 ms increment +/- 22 ms		500 ms		7 - D factor adjustment range min 0 max 1000 increment +/- 10		50	
Max displacement : pump controlled by potentiometer or BB3				Ramp inertia deceleration fuel injection pump							
8 - nom displacem adjustment range min 0 % max 100 % increment +/- 1 %		100 %		8 -				8 - d call rate adjustment range min 3 max 6 increment +/- 3		3	
Max displacement pumps authorised in %											

INSPECTION PROCEDURE FOR THE LONGITUDINAL STABILITY ALARM STRAIN GAUGE

Connector engineering :

+ power supply	red wire / contact	N° 1
- power supply and PT 100	brown wire / contact	N° 2
+ measurement	yellow wire / contact	N° 3
- measurement	green wire / contact	N° 4
PT 100	blue wire / contact	N° 5
Shielding	white / contact	N° 6


Description of the connectors of strain gauge.



Prior to any electrical inspection, carry out a visual check on the state of the gauge and its connections.



Electric skeleton diagram



TC	Control panel	CONNECTORS	
BP	Bouton poussoir	C1	5-way, black AMP MIC IV-TV - Ref. 144 518-2
L	Tongue	C2	6.35 x 0.8 mm female connector
S	Blower	C3	90" 6.35 x 0.8 mm female connector
T	Thermostat	C4	Deutsch Ref. HD10-6-12P
P1	Low pressure gauge	C5	1-way RKG female connector Ref. 920 510
P2	High pressure gauge	C6	Deutsch Ref. HD16-6-12S-B010
R	Relay	C7	2-way female DT - Ref. 552 459
EC	Compressor clutch	C8	2-way male DT - Ref. 552 457
F1	7.5 A fuse	C9	2-way male DT - Ref. 552 457
F2	30 A fuse	C10	2-way female DT - Ref. 552 459

2 INSTRUCTIONS FOR STARTING UP THE MANITOU PRODUCTION UNIT

2.1- CHECK BEFORE LOADING

Tightening the coolant connections according to the torque table.

CONNECTION	MODULE	TORQUE Nm
COMPRESSOR DISCHARGE	8 ‘’	15.4 Nm
COMPRESSOR SUCTION	10 7/8 ‘’	24.4 Nm
CONDENSER INPUT	8 ‘’	15.4 Nm
DEHYDRATOR OUTPUT	6 5/8 ‘’	15.4 Nm
EVAPORATOR INPUT	6 5/8 ‘’	15.4 Nm
EVAPORATOR OUTPUT	10 7/8 ‘’	24.4 Nm

2.2- CHARACTERISTICS OF COOLANT R134a

WARNING : *The MANITOU air-conditioning system uses coolant R134a only (Ref. MANITOU 4500421 – 14.5 Kg bottle) and PAG SP20 oil code : 430A08 only.*

Characteristics of coolant R134a

* Trade name	: Fluorocarbon 134a
* Use	: Coolant
* Chemical characteristics	: Tetrafluoroethane 134a
* Chemical formula	: CH ₂ FCF ₃
* Physical state	: Liquefied gas
* Colour	: Colourless
* Odour	: Slightly of ether
* Boiling point (s/1bar)	: -26.5 °C
* Melting point	: -101°C
* Density at 25°C	: 1.21kg/l
* Critical pressure	: 40.56 bar
* Critical temperature	: +100.6 °C
* Weight as gas	: 5 times heavier than air
* 1 kg in liquid state at 1 bar	: 200 l in gaseous state
* Thermal decomposition	: from 110°C
* Hazardous decomposition products	: hydrogen halides and traces of carbonyl halides
* Dangerous reactions	: With alkaline metals and alkaline-earths of powdered metal salts : Al-Zn-Be...
* Flash point	: No flash point
* Self-ignition temperature	: Over 750°C
* Limit of explosivity	: Below none, above none
* Ozone destruction potential	: Zero (none).

5.2- PRECAUTIONS (GB)



5.2.1- Once the A/C system is slowing down, it is losing its efficiency. Contact an approved MANITOU dealer if this is the case with your air conditioner.

CAUTION : Never repair your air conditioner by yourself. An approved MANITOU dealer will have the technical know-how, all the necessary tools and the spare parts.

5.2.2- Do not open the A/C system, as it will cause loss of refrigerant. The refrigerant in the A/C system can carry some risks. The R-134a refrigerant is colourless, odourless and denser than the air.

5.2.3- Never loosen the compressor-draining plug, as it will cause loss of the refrigerant. Always check the oil level in the compressor when the A/C system is empty

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL