




**REPAIR MANUAL
MANUEL DE RÉPARATION
REPARATURANLEITUNG
MANUAL DE REPARACIÓN
MANUALE RIPARAZIONE**

This document has been printed from  **mye doc**



MANITOU BF

Head office: 430, Rue de l'Aubinière
44150 Ancenis - FRANCE
Share capital: 39,548,949 euros
857 802 508 RCS Nantes
Tel: +33 (0)2 40 09 10 11
www.manitou.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

PREAMBLE

This chapter deals with the general instructions and safety notice during inspection and maintenance work. Other instructions and warnings are indicated in each chapter concerned.

In order to reduce accident risks, make sure to:

- Follow the instructions in the truck operating and maintenance manual.
 - ⇒ This manual should be found in all trucks.
- Please follow all safety instructions.
- Use the appropriate tools for any work to be performed.
- Use original Manitou spare parts.

Any non-compliance increases the risk of accidents occurring which may lead to causing grievous bodily harm and even death.

An efficient, dependable and profitable combination will be formed if the operator follows the safety manual correctly and the machine is serviced properly.

When you see this symbol:



It means: Warning! Be careful! Your safety, somebody else's or the safety of the lift truck itself is at risk.


The manufacturer cannot predict all possible risky situations. Consequently, the safety instructions given in the safety manual are not exhaustive.

At any time, as an operator, you must envisage, within reason, the possible risk to yourself, to others or to the lift truck itself when you repair, service or drive it.

Manitou cannot be held responsible for the use of any lifting devices, tools or operating methods other than those specified.

FUEL CIRCUITS LOCATION


LOW PRESSURE



Key:



- 1 - Primary fuel filter
- 2 - Water separator
- 3 - Fuel pump
- 4 - Fuel cooler (option)
- 5 - ECM
- 6 - Secondary fuel filter
- 7 - Injection pump
- A - High pressure fuel output to high pressure fuel manifold
- B - Relief valve (PRV) return to high pressure fuel manifold
- C - Return to fuel tank
- D - Electronic injector return
- E - Fuel feed from fuel tank

HIGH PRESSURE



Key:

- 1 - Electronic injectors
- 2 - High pressure fuel collector
- 3 - Fuel pressure sensor
- 4 - Fuel relief valve
- 5 - Fuel pump
- 6 - Injection pump solenoid
- 7 - Injection pump
- 8 - Injection pump speed




I.C. ENGINE REMOVAL


Remove the draining hatch (Item 1) situated under the engine housing. To do so, remove the 4 screws.

Place a hydraulic tank under the cooler and then drain the cooling liquid by opening its drain plug.

⇒ Quantity of cooling liquid = 18L




Open the drain plug (Item 2) to release the flow.



Loosen the 2 clamps (Items 3 and 4) of the "calorstat-cooler" hose (Item 5).

Remove the hose (Item 5).

	<i>Manitou code</i>	<i>FMI</i>	<i>Perkins</i>	<i>Components</i>	<i>Description</i>	<i>Engine shutdown from the ECM</i>	<i>Reduced power</i>	<i>Reduced engine speed</i>
CODES	1347	6	1779	Fuel Rail Pressure Valve Solenoid	Short Circuit			
	2882	2	1743	Engine operation Selector Mode Switch	Data Erratic, Intermittent, or Incorrect			
	-	-	-	All Good			YES	
EVENTS	100-01	3	E360	Engine Oil Pressure	Low Oil Pressure (2 sec.)			
	100-17	1	E360	Engine Oil Pressure	Low Oil Pressure (8 sec.)			
	105-15	1	E539	Inlet Manifold Air Temperature	Above Normal = Lamp			
	105-16	2	E539	Inlet Manifold Air Temperature	Above Normal = DERATE		1%/s	
	107-15	1	E172	Air Filter	Clog Filter			
	110-00	3	E361	Engine Coolant Temperature.	Engine Shutdown = Level 3 (118°)			
	110-15	1	E361	Engine Coolant Temperature.	Lamp = Level 1 (113°)			
	110-16	2	E361	Engine Coolant Temperature.	Derate = Level 2 (114°)		1%/s	
	111-01	3	E2143	Engine Coolant Level	Low Low Level	Possible		
	157-00	1	E396	Fuel Rail	Too High Pressure	YES	YES	YES
	157-01	1	E398	Fuel Rail	Too Low Pressure		YES	
	190-15	1	E362	Engine Overspeed	Overspeed			
	97-15	1	E232	Fuel Water Separator	Water Level Too High			




BASIC MANOMETER KIT

20



This box contains all the components required for measuring pressure on all Manitou products.



Basic Manometer kit..... 549671

Consisting of:

- 1. 1 Manometer 1/9 bar 549882
- 2. 1 Manometer 0/40 bar 549883
- 3. 2 Manometers 0/60 bar 549884
- 4. 1 Manometer 0/400 bar 549885
- 5. 2 Manometers 0/600 bar 549886
- 6. 4 Standard hoses 549887
- 7. 2 Hoses for Maniscopic 549888
- 8. 7 Manometer tap connectors 549889



FREEWHEEL AND TOWING

⚠ This maneuver is dangerous. Put the lift truck carefully into neutral before towing, because the parking brake system is out of service.


Towing can be carried out at very low speed and over short distances. How to intervene:

- Put the forward-reverse gear switch into neutral (N).
- Wedge the truck in place
- Loosen/deactivate the parking brake.
- Switch on the hazard warning lights.

MECHANICAL UNLOCKING OF THE NEGATIVE BRAKE ON FRONT AND REAR AXLE




- Loosen the locknuts (Item 1) of the manual mechanical unlocking screws (Item 2) by bringing the locknuts back by 8 mm approx.



- Tighten the screws (Item 1) until they stop on the pressure plate (Item 3).
- With a wrench, alternately tighten the screws (Item 1) by one 1/4 turn at a time to restrain the Belleville springs and release the disc brakes.


Note: The travel required for unlocking is 1 turn.


⚠ It is important that the opposing screws are screwed by the same number of turns.




- Put the towing device into place.
- Remove the chocks.

⚠ Do not tow truck at a speed greater than 6 km/h. Maximum towing distance: 5 km.


This procedure is also available in the AXLE MR  647142FR



Unscrew the screws (Item 2) and remove the rear casing (Item 3) from the turret.




Disconnect the pipes (Item 4) from the valve (Item 5) of the 1st extension ram (Item 6).



Secure the upper cylinder to the overhead crane by tying it with a with a noose; slightly raise the ram (Item 6) until the load on the pins is removed.




Remove the seeger clip. (Item 7) and withdraw the rear hinge pin (Item 1) of the ram (Item 6).




REMOVING THE IIIrd AND IVTH BOOMS FROM THE IIND EXTENSION BOOM

With the help of the overhead crane, keep the framework of the IIIrd extension boom raised and remove the lower foot-carrier plates by unscrewing the lower lateral grub screws (Item 1).




Remove the upper foot-carrier plates of the IInd extension (Item 2) using the grub screws and upper lateral grub screws (Item 3).




⚠ Ensure that the chains attached to the upper part of the 1st extension are not under tension.

Withdraw the pins (Item 4) that attach the chains (Item 5) to the tie rods (Item 6).




Remove the pulley (Item 7).
Withdraw the chains towards the front of the boom, stretching them at the upper part of the framework of the IIIrd extension boom.

⚠ Warning: secure the chains to the top of the boom so that when extracting the framework they are under tension and therefore cannot slide laterally.




For fitting the grub screws, check the measurement "X" from which 6 mm must be subtracted to obtain the exact measurement "Y" of insertion of the grub screw into the framework.


Warning : do not exceed the maximum height of the grub screw otherwise there would be a risk of interference with the framework.



Refit the five chain attachment points (Item 11) on the IInd, IIIrd and IVth extensions.



Refit the chain tie rods (Item 12) to the iron block (Item 13).




Lock the lower chain tie rods (Item 14) in the lower front part of the boom.




REFITTING THE TELESCOPIC BOOM TO THE TRUCK

With the help of an overhead crane or hoist, raise the boom and position it on the truck in its seating on the turret.


⚠ Take care when lifting. To prevent the boom becoming unbalanced and overturning, it must be guided by an operator.



Insert the boom/turret hinge pin (Item 1) into the appropriate hole.




Lock the pin (Item 1), with the screw (Item 2) and nut (Item 3).



Reconnect the basket electrical system connector (Item 4) and the safety system connector.

Values indicative only


The electronic system is always comparing the U_{sc} control signal with the U_{sp} position signal. This signal will be within: $0,25U$ and $0,75 U$. U is the electronic control unit's voltage.



Signal = $0,50 \times U$

Consequences:


- No excited electrovalve.
- No slide movement.
(No flowrate towards «A» and «B».)



Signal = $0,25 \times U$

Consequences:


- Electrovalves 1 and 2 excited.
- Max. movement of slide towards «A».
(Max flowrate towards «A».)



Signal = $0,75 \times U$


Consequences:

- Electrovalves 3 and 4 excited.
- Max. movement of slide towards «B».
(Max. flowrate towards «B».)




70

	Showing on machine	Pressure port	Line function	Control component		Theoretical value		Value measured on machine	
				Minimum value	Maximum value	Mini	Maxi	Mini	Maxi
P4	Yes	Stabiliser line	Stabiliser system power supply	Connection to the tank	LP stabiliser system	0b	220b	0b	235b
P5	No	Fan line	Fan motor power supply	Mini RPM resistance	Maxi RPM resistance	8b	175b	8b	95b
P6	Yes	Compensation cylinder	Compensating cylinder on pillar side	Connection to the tank	Secondary valve 300b	0b	300b	/	/




Remove the 2 screws (Item 7) of the cylinder guide (Item 8) and then remove it.




Remove the length sensor (Item 9) by unscrewing its 2 screws (Item 10). Position it on the outside of the stabiliser.


Note: Each length sensor is specific to its stabiliser and has a different reference.



Remove the protective casing (Item 11) under the stabiliser.



Using a slide caliper, take the dimension for the 4 chain tensioners. These measurements will be useful for reassembling the chains provided that they are not replaced by new ones.



Only loosen the telescope extension chains behind the stabiliser base. Next dislodge the 2 tensioners (Item 12).

OPERATING CONDITIONS

MACHINE WITH FORKS

MACHINE WITH FORKS ON WHEELS OR STABILISERS

MOVEMENTS AUTHORISED FROM THE CAB			
	TURRET UP TO +/-15°	TURRET MORE THAN +/-15°	COMMENTS
	BOOM UP TO 55°	BOOM MORE THAN 55°	
	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X		
STABILISER DESCENT	X	X	
TURRET ROTATION	X	X	
TOP TILT	X	X	
BOTTOM TILT	X	X	
BOOM ASCENT	X	X	
BOOM DESCENT	X	X	
BOOM RETRACTION	X	X	
BOOM EXTENSION	X	X	
OPTION 1	X	X	
OPTION 2	X	X	
LEVELLING CORRECTION	OPERATION ON FRONT SIDE, WITH BOOM < 3M		
AXLE LOCKING	LOCKED (INDICATOR LAMP FLASHING) WITH TURRET ROTATED OR BOOM > 55°		

WARNING: The rotation is cut-off if the boom is > 55°, rotation only authorised up to +/- 5°.

WARNING: The stabilisers may be raised if the turret is positioned up to +/-5°, the boom retracted and positioned at 55° maximum.

MOVEMENTS AUTHORISED FROM CAB WITH ANTI-TILT EXCLUSION BUTTON ACTIVATED			
	TURRET UP TO +/-15°	TURRET MORE THAN +/-15°	COMMENTS
	BOOM UP TO 55°	BOOM MORE THAN 55°	
	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X	X	
STABILISER DESCENT	X	X	
TURRET ROTATION	X	X	
TOP TILT	X	X	
BOTTOM TILT	X	X	
BOOM ASCENT	X	X	
BOOM DESCENT	X	X	
BOOM RETRACTION	X	X	
BOOM EXTENSION	X	X	
OPTION 1	X	X	
OPTION 2	X	X	

WARNING: the platform exclusion button has no effect on the operation mentioned above.

WARNING: the levelling correction is never made by the button.

MACHINE ON WHEELS WITH FIXED BASKET / ORH

MOVEMENTS AUTHORISED FROM THE CAB					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION	X	X			
TOP TILT	X	X			
BOTTOM TILT	X	X			
BOOM ASCENT	X (only up to H = 3 m)	X (only up to H = 3 m)			
BOOM DESCENT	X	X	X	X	
BOOM RETRACTION	X	X			
BOOM EXTENSION					
OPTION 1	X	X			
OPTION 2	X	X			

MOVEMENTS AUTHORISED FROM CAB WITH PLATFORM EXCLUSION BUTTON ACTIVATED					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION	X	X			
TOP TILT	X	X			
BOTTOM TILT	X	X			
BOOM ASCENT	X (only up to H = 3 m)	X (only up to H = 3 m)			
BOOM DESCENT	X	X	X	X	
BOOM RETRACTION	X	X			
BOOM EXTENSION					
OPTION 1	X	X			
OPTION 2	X	X			


MACHINE WITH RADIO CONTROL

MACHINE ON STABILISERS


MOVEMENTS AUTHORISED FROM THE CAB					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION					
TOP TILT					
BOTTOM TILT					
BOOM ASCENT					
BOOM DESCENT	X				As considered as platform
BOOM RETRACTION					
BOOM EXTENSION					
OPTION 1					
OPTION 2					

MOVEMENTS AUTHORISED FROM CAB WITH PLATFORM EXCLUSION BUTTON ACTIVATED					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION	X	X	X	X	
TOP TILT	X	X	X	X	
BOTTOM TILT	X	X	X	X	
BOOM ASCENT	X (ALSO MORE THAN 3 m)	X (ALSO MORE THAN 3 m)	X (ALSO MORE THAN 3 m)	X (ALSO MORE THAN 3 m)	
BOOM DESCENT	X	X	X	X	
BOOM RETRACTION	X	X	X	X	
BOOM EXTENSION	X	X	X	X	
OPTION 1	X	X	X	X	
OPTION 2	X	X	X	X	


<i>Electrical components and connectors</i>			
<i>Wiring harness type</i>	<i>Item</i>	<i>Designation</i>	<i>Diagram</i>
Dashboard	L104	Stabiliser extension/descent indicator lamp	20
Dashboard	L105	Stabiliser retraction/ascent indicator lamp	20
Dashboard	L112	Stabiliser indicator lamp selected	20
Dashboard	L113	Telescope indicator lamp selected	20
Cab	M40	Upper windscreen wiper motor	32
Cab	M40a	Upper windscreen wiper pump motor	32
Cab	M41	Rear screen wiper motor	33
Cab	M41a	Rear windscreen wiper pump motor	33
Cab	M44	Electric window motor	33
Cab	M122	Front windscreen wiper pump motor	19
Rear frame	MAIN FUSE	Main fuse	1
Frame fuse box and relay	Midac_C1	Midac_C1 control unit input/output	5
Turret	Midac_T1	Midac_T1 control unit input/output	27
	P.MIL.	Military plug	1
Turret	PH1	Lifting cylinder CEC pressure sensor on rod side	29
Turret	PH2	Compensating cylinder CEC pressure sensor on rod side	29
Turret	PL1	Lifting cylinder CEC pressure sensor on piston side	29
Turret	PL2	Compensating cylinder CEC pressure sensor on piston side	29
Frame fuse box and relay	PROGRAMMING	Connector for programming	7
	QS1	Short circuit	1
Cab	R	Rear defrosting resistance	33
Cab fuse box and relay	R1	Horn relay	18
Cab fuse box and relay	R2	Operator panel supply relay	17
Cab fuse box and relay	R3	Red rotating beacon light relay	18
Cab fuse box and relay	R4	"15" supply relay	17
Cab fuse box and relay	R5	Flashing unit	18
Cab fuse box and relay	R6	Arm_T1 relay Watchdog	27
Cab fuse box and relay	R7	Electronic control units supply relay	17
Cab fuse box and relay	R8	Seat tilt relay	17
Cab fuse box and relay	R9	Seat tilt relay	17
Cab fuse box and relay	R10	Arm_T1 control unit supply relay	27
Cab fuse box and relay	R11	Start-up validation relay	18
Cab fuse box and relay	R12	Cab user points fuse supply relay	32
Cab fuse box and relay	R13	Large mixing bucket relay	17
Frame fuse box and relay	R16	Engine starting relay	6
Frame fuse box and relay	R17	Arm_T1 control unit watchdog relay	5
Frame fuse box and relay	R18	Supply for fuses	6
Frame fuse box and relay	R19	Rear fog lights relay	2
Frame fuse box and relay	R20	Light position relay	2
Frame fuse box and relay	R21	Reverse gear relay	2
Frame fuse box and relay	R22	Low beam relay	2
Frame fuse box and relay	R23	Engine starting relay	4
Frame fuse box and relay	R24	Main beam relay	2
Frame fuse box and relay	R25	Stop light relay	2
Frame fuse box and relay	R26	Hydraulic cooling fan relay	4
Frame fuse box and relay	R27	Arm_C1 control unit supply relay	12
Frame fuse box and relay	R28	Arm_C2 control unit supply relay	14
Frame fuse box and relay	R29	Back-up pump relay	4
Frame fuse box and relay	R30	Truck control unit supply relay	5
Movement locking system	R99	Re-supply relay	25




80




80



80




80




80

KEY / POSITION OF CONNECTORS

<i>Electrical components and connectors</i>						
<i>Wiring harness type</i>	<i>Item</i>	<i>Designation</i>	<i>2D Location</i>			<i>Harness details</i>
			<i>A</i>	<i>B</i>	<i>C</i>	
Frame fuse box and relay	11 MIC	Connector for reservation				8
Front frame	Arm_C1	Arm_C1 control unit input/output		E32		1
Front frame	Arm_C2	Arm_C2 control unit input/output		E32		1
Turret	Arm_T1	Arm_T1 control unit input/output connector		M18		3
Turret/ movement locking system	Arm_T1a	Turret/movement locking system harness interface		M18		3 / 11
Cab	BS11	Right loudspeaker		M19		5
Cab	BS12	Left loudspeaker		M19		5
Frame fuse box and relay	CAN-J1939	BUS J1939 balancing resistance				8
Frame fuse box and relay	CAN-OPEN_1	OPEN CAN connector				8
Front frame	CAN-OPEN_2	CAN BUS balancing resistance		E33		1
Platform prewiring	CAN-OPEN_3	OPEN CAN balancing resistance		O37		
Cab	E12	Front right working light		K24		5
Cab	E13	Left front work light		K24		5
Cab	E16	Rear right working light		M17		5
Cab	E17	Rear left working light		K17		5
Rear frame	ENGINE	Engine connector		I19		2
Front frame	EV1	Turret locking shaft ascent electrovalve		E23		1
Front frame	EV2	Turret locking shaft descent electrovalve		E23		1
Front frame	EV3	Stabiliser descent/extension electrovalve		E24		1
Front frame	EV4	Stabiliser ascent/retraction electrovalve		E24		1
Front frame	EV5	Rear left stabiliser electrovalve		E24		1
Front frame	EV6	Rear left telescope electrovalve		E24		1
Front frame	EV7	Right rear stabiliser electrovalve		E25		1
Front frame	EV8	Rear right telescope electrovalve		E25		1
Front frame	EV9	Front right stabiliser electrovalve		E26		1
Front frame	EV10	Front right telescope electrovalve		E26		1
Front frame	EV11	Front left stabiliser electrovalve		E27		1
Front frame	EV12	Front left telescope electrovalve		E27		1
Front frame	EV13	Hydraulic oil cooling electrovalve		C15		1
Front frame	EV14	Engine oil temperature sensor		A14		1
Front frame	EV15	Parking brake electrovalve		E26		1
Front frame	EV16	Short steering electrovalve		E29		1
Front frame	EV17	Crab steering electrovalve		C29		1
Front frame	EV18	Air-conditioning electrovalve		C29		1
Movement locking system	EV138	LS cut-off electrovalve at start-up		M21		11
Turret	EV142	Air-conditioning electrovalve connector reservation				3
Movement locking system	EVD	Movement cut-off electrovalve				11
Cab fuse box and relay	F1	Platform fuse				9
Cab fuse box and relay	F2	Cab front working lights fuse				9
Cab fuse box and relay	F3	Cab rear working lights fuse				9
Cab fuse box and relay	F4	Working lights fuse on telescope/upper windscreen wiper				9
Cab fuse box and relay	F5	Rear windscreen wiper windscreen washer fuse				9
Cab fuse box and relay	F6	Rear windowdefrost power supply fuse				9
Cab fuse box and relay	F7	Electric window fuse				9
Cab fuse box and relay	F8	Dashboard switch power supply fuse				9
Cab fuse box and relay	F9	Seat equipment power supply fuse				9




80



80

RATED CAPACITY LIMITER PAGE (F2)



1	Percentage bar	LCD bar showing the load lifted as a percentage in relation to the maximum load authorised under this working condition. Green reference: Secure area Yellow reference: Warning area (load lifted greater than 90% of the maximum load authorised). Red reference: Cut-out area (load raised greater than 100% of the maximum load authorised).
2	Rated capacity limitation information	According to the icons on the screen: - Height - Telescope angle - Telescope length - Range - Actual load - Maximum load authorised in the current position - Turret angle
3	Stability area	See paragraph on Stability
4	Messages area	Area of generic text used for diagnostics and during calibration. Under normal conditions, it is possible for alerts or warning messages to appear.
5	Generic indicator lamps	In accordance with the icons on the screen - Extended stabiliser - Stabiliser on ground - Turret centred - Turret locked - Vertical control - Horizontal control
6	Truck configuration	Shows an icon with the attachment selected and the operating mode code according to the machine manual


CALIBRATION OF MACHINE SENSORS

The machine is calibrated directly from the cab display.

The calibration procedures can be accessed after having entered the first password

Procedure for entering the password

- Start the engine as soon as the screen below appears; press on the "ENTER" button



- The following screen appears.



- Using the button , move the asterisk above the figure that you wish to change.

2 - In the "ECU" dropdown list, it is possible to adjust the speed of the machine's movements.

- ⇒ Choose the speed of movements that you want to adapt for the cab, platform or radio.
- ⇒ In the table displayed, enter the value required (100% = max. speed).

ID	Npar	T1	Value	Um	Range	Cabin Speed Regulations
1	F-00		100	%	4	Boom Lift
2	F-01		100	%	4	Boom Down
3	F-02		100	%	4	Potation Cw
4	F-03		100	%	4	Potation Ccw
5	F-04		100	%	4	Forks Up
6	F-05		100	%	4	Forks Down
7	F-06		100	%	4	Boom extend
8	F-07		100	%	4	Boom retract
9	F-08		100	%	4	Option Direction 1
10	F-09		100	%	4	Option Direction 2
11	F-10		100	%	4	Winch Up
12	F-11		100	%	4	Winch Down

Figure 1: Cab

ID	Npar	T1	Value	Um	Range	Basket Speed Regulations
1	F-20		53	%	4	Boom Lift
2	F-21		72	%	4	Boom Down
3	F-22		49	%	4	Potation Cw
4	F-23		45	%	4	Potation Ccw
5	F-24		33	%	4	Forks Up
6	F-25		48	%	4	Forks Down
7	F-26		100	%	4	Boom extend
8	F-27		100	%	4	Boom retract
9	F-28		100	%	4	Option Direction 1
10	F-29		100	%	4	Option Direction 2

Figure 2: Platform

ID	Npar	T1	Value	Um	Radio Speed Regulations
1	F-30		1300	%	Boom Up [Fast]
2	F-31		790	%	Boom Down [Fast]
3	F-32		690	%	Boom Up [Slow]
4	F-33		550	%	Boom Down [Slow]
5	-		-	-	-
6	F-34		1300	%	Winch Up [Fast]
7	F-35		1300	%	Winch Down [Fast]
8	F-36		870	%	Winch Up [Slow]
9	F-37		480	%	Winch Down [Slow]
10	-		-	-	-
11	F-38		1000	%	Forks Up [Fast]
12	F-39		1300	%	Forks Down [Fast]
13	F-40		850	%	Forks Up [Slow]
14	F-41		550	%	Forks Down [Slow]
15	-		-	-	-
16	F-42		1300	%	Boom Extend [Fast]
17	F-43		1300	%	Boom Retract [Fast]
18	F-44		500	%	Boom Extend [Slow]

Figure 3: Radio

METERING PUMP ASSEMBLY POSITIONS

Always place the metering pump with the discharge side towards the top.


! *Observe the minimum tilt of 15°.*

It is possible to choose an assembly position with a tilt greater than 15°, but tilts between 15° and 35° are preferred.

! *The fuel pipes between the metering pump and the heating system must, if possible, be managed from bottom to top.*

Positions permitted

- a = Tilts permitted
- b = Preferable
- c = Not permitted
- d = Metering pump



Manometric heights permitted

Elevation difference between the vehicle tank and the metering pump:


a = 3 m max.

Elevation difference for unpressurised tanks:

b = 1 m max. – for suction pipe with internal Ø 2 mm

b = 1,5 m max. – for suction pipe with internal Ø 5 mm

! *Check that the tank vent is clear.*




Elevation difference in case of tank with low pressure at suction (valve of 0,03 bar on tank cap):


b = max. 0,4 m

Elevation difference between the metering pump and heating system:


c = max. 2 m



After unscrewing all the fixing screws, remove the housing (Item 10) protecting the distributor.




Unscrew the screws (Item 11), remove their washers and remove the front cover housing (Item 12).




Unscrew the screws (Item 13) remove their washers and remove the housing (Item 14) protecting the power steering.



Unscrew the screws (Item 15) with their washers and remove the housing (Item 16) protecting the space under the cab.



With the help of the overhead crane, remove the turret from the truck frame, resting it on a horizontal surface or safe supports that can bear the weight.



REMOVING THE TURRET ROTATION MOTOR


Disconnect all the hydraulic pipes of the turret rotation motor (Item 1).

Secure the motor (Item 1) with ropes and an overhead crane, unscrew all the screws (Item 2) remove the washers (Item 3) and lift the rotation motor (Item 1) until it is removed from the turret.




REFITTING THE LIFTING RAM TO THE TURRET


With the help of the overhead crane, place the lifting ram (Item 1) on the turret.



Insert the pin (Item 2) locking the ram (Item 1) on the base plate side through the appropriate hole in the turret.



Screw in the screw (Item 3) and nut (Item 4) to lock the pin (Item 2).



Reconnect the grease nipple (Item 5) to the ram (Item 1).

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below














- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

AIR-CONDITIONING COMPONENTS OVERVIEW




IDENTIFICATION PLATES


Descriptions	Plates
1 - Manufacturer's plate	
2 - Cab plate	
3 - Engine plate	
4 - Hydrostatic pump plate	
5 - Hydrostatic motor	
6 - Hydraulic pump plate	
7 - Rear axle plate	
8 - Front axle plate	
9 - Frame plate	
10 - Attachments pump	
11 - Gear box	

PERKINS ENGINE ELECTRICAL DIAGRAM

J2
(ECM connector)


10





Disconnect the electrical connectors on the hydrostatic pump.


- ⇒ X51 = Reverse gear electrovalve (port "a")
- ⇒ X53 = Forward gear electrovalve (port "b")
- ⇒ X52 = Hydrostatic pump DRE valve



Disconnect the following hoses:

- ⇒ Discharge hose in B
- ⇒ Drainage hose in T1
- ⇒ Cooling hose in T2
- ⇒ Discharge hose in A
- ⇒ Suction hose in S
- ⇒ Cooling hose (to CV, ECBR and RCFP) in G

If needed, mark the hoses to facilitate reassembly.



Disassemble the hydrostatic pump (Item 7) of the engine (Item 8). To do so, remove the 4 screws (Item 9).

Position a lifting system + strap above the hydrostatic pump. Raise it slightly in order to relieve its shaft.

Using a crowbar, disassemble the engine's hydrostatic pump.

Remove the "hydraulic pump + hydrostatic pump" assembly in the engine housing.

PERKINS 1106D EURO 3 ENGINE ERROR CODES LIST

The codes can be viewed on the PAD diagnostic tool.

<i>Manitou code</i>	<i>FMI</i>	<i>Perkins</i>	<i>Components</i>	<i>Description</i>	<i>Engine shutdown from the ECM</i>	<i>Reduced power</i>	<i>Reduced engine speed</i>
29	2	774	Secondary Throttle Position Sensor	Data Erratic, Intermittent, or Incorrect			YES
29	3	774	Secondary Throttle Position Sensor	Voltage Above Normal			YES
29	4	774	Secondary Throttle Position Sensor	Voltage Below Normal			YES
29	8	774	Secondary Throttle Position Sensor	Abnormal Frequency, Pulse Width, or Period			YES
29	12	774	Secondary Throttle Position Sensor	Wrong System or Conponant			YES
91	2	91	Primary Throttle Position Sensor	Data Erratic, Intermittent, or Incorrect			YES
91	3	91	Primary Throttle Position Sensor	Voltage Above Normal			YES
91	4	91	Primary Throttle Position Sensor	Voltage Below Normal			YES
91	8	91	Primary Throttle Position Sensor	Abnormal Frequency, Pulse Width, or Period			YES
91	12	91	Primary Throttle Position Sensor	Wrong System or Conponant			YES
100	3	100	Engine Oil Pressure Sensor	Voltage Above Normal			
100	4	100	Engine Oil Pressure Sensor	Voltage Below Normal			
100	10	100	Engine Oil Pressure Sensor	Sensor 5V Supply Connection Open Circuit			
105	3	172	Inlet Manifold Air Temperature Sensor	Voltage Above Normal			
105	4	172	Inlet Manifold Air Temperature Sensor	Voltage Below Normal			
102	3	1785	Inlet Manifold Air Pressure Sensor	Voltage Above Normal			
102	4	1785	Inlet Manifold Air Pressure Sensor	Voltage Below Normal			
102	10	1785	Inlet Manifold Air Pressure Sensor	Sensor 5V Supply Connection Open Circuit		YES	
110	3	110	Engine Coolant Temperature Sensor	Voltage Above Normal			
110	4	110	Engine Coolant Temperature Sensor	High Coolant Temperature SHUTDOWN			
157	3	1797	Fuel Rail Pressure Sensor	Voltage Above Normal		YES	
157	4	1797	Fuel Rail Pressure Sensor	Voltage Below Normal		YES	
158	2	1834	Keyswitch	Data Erratic, Intermittent, or Incorrect	YES		
168	0	168	ECM Battery Power	Excesive Battery Power	YES		
168	1	168	ECM Battery Power	Low Battery Power	YES		
168	2	168	ECM Battery Power	Intermittent	YES		
190	8	190	Speed/Timing Sensor	Abnormal Frequency, Pulse Width, or Period	With 261-11	YES	
630	2	268	Customer or System Parameters	Data Incorrect	YES	YES	

CODES



Figure 1: PAD screen shot

ERROR CODES

The codes can be viewed on the PAD diagnostic tool under the heading "RC2/2 ECU", as well as in Group 20: Section "Transmission troubleshooting".

PARKING BRAKE

CHARACTERISTICS

Type: Disk immersed in oil
 Pressure: 40 bar

A negative controlled electro-hydraulic system acts on the front and rear axle.

PURGING PROCEDURE

Tools required:

- ⇒ 1 transparent hose (Item 1)
- ⇒ 1 container
- ⇒ 1 10 mm wrench



Purging order:

- 1 - Rear right purge screw
- 2 - Rear left purge screw
- 3 - Front right purge screw
- 4 - Front left purge screw

⚠ Stabilise the machine on level ground. Wedge the machine in place to prevent any movement during the bleeding procedure.









Start machine.

Deactivate the parking brake using the switch (Item 2) inside the cab.

LIST OF COMPONENT PART NOS.

<i>Part no.</i>	<i>Description</i>	<i>Characteristics (Options)</i>
3B6	Roller	
CSD	Double lock valve	
CSP	Controlled safety valve	
MC1	Micro chain 1	
MC2	Micro chain 2	
TC	Remote camera	OPTION
VI	Traverse ram	
VTI1	First extension ram	
VTI2	Second extension ram	
X134	Roller connector	
X152	Connector provided for basket	




Pretension the internal chains by screwing down the nuts on the pull rods.

Use the values given in the table below:

- 2 internal chains, 1st extension, 80 mm (Item 4).
- 2 internal chains, 2nd extension, 85 mm (Item 5).
- 1 internal chain, 3rd extension, 85 mm (Item 6).


(Values measured from the outside of the pins of the chains to the outside of the chassis).




REMOVING THE RAMS FROM THE BOOM

REMOVING THE TRAVERSE RAM


Unscrew the bush (Item 1) locking the pin (Item 2).



Secure the rapid attachment (Item 3) to an overhead crane. Remove the pin (Item 2) from the quick connector (Item 3) and the traverse ram (Item 4).




Disconnect the hydraulic pipes (Item 5) from the ram lock valve.






Slacken the pull rods (Item 23) of the lower chains in the lower front part of the boom.




Completely remove the chain tie rod (Item 24) from the iron block (Item 25) so that the framework can then be removed from the IIIrd and IVth extension.




Warning: before carrying out this operation, check that the chains are not under tension.

Remove the five chain attachment points (Item 26) on the IInd, IIIrd and IVth extension.


Stretch the chains towards the rear of the truck so that they do not interfere with the removal operation.



Extract the IInd extension boom manually by about 20 cm to permit extraction of the upper rear feet.



Using the grub screws (Item 2) raise the lower foot-carrier plates until the framework is not in contact with the upper feet; adjust it so that there is 1,5/2 mm clearance between the feet and the framework (take care not to strain the frameworks excessively).




REFITTING THE IIND, IIIRD AND IVTH BOOMS INTO THE 1ST EXTENSION BOOM

Prepare the feet by fitting the threaded inserts (Item 1) to them. Taking great care, with the help of an overhead crane, insert the IInd, IIIRD and IVth extensions into the framework of the 1st extension boom by sliding it on the lower feet.


Before proceeding with the operation, spread a layer of grease on the sliding area of the feet.

Do not fully insert the frameworks, but leave them extended by about 50 cm to enable the front feet to be fitted.




Raise the framework of the IInd extension and fit the feet (Item 2) to the lower part.


Fix the feet using the grub screws (Item 3), washers (Item 4) and self-locking nuts (Item 5); use medium strength Loctite thread lock on the two central grub screws.




Refit the pulleys (Item 6) and insert the pins (Item 7), locking them with the associated screws (Item 8) and nuts (Item 9).




Reinsert the rear hinge pin (Item 3) of the ram (Item 1) and refit the seeger clip (Item 4).



Reconnect the pipes (Item 5) to the valve (Item 6) of the 1st extension ram (Item 1).




Refit the rear turret housing (Item 7) by screwing in the screws (Item 8).



REFITTING THE TRAVERSE RAM

With the help of ropes, an overhead crane and a jack, refit the traverse ram (Item 1) to the head of the boom.



Suspension electrovalve operating logic

	X5	X10	X11	X21	X22	X23	X24	X25	X26	X27	X28	X29	X30	X31	X47	X48	X63	X64
Left levelling	1	1	1	1	1			1			1			1	1	1	1	1
Right levelling	1	1	1	1	1		1					1	1		1	1	1	1
Rear / front levelling	1	1	1	1	1		1	1	1			1		1	1	1	1	1
Front / rear levelling	1	1	1	1	1					1	1		1		1	1	1	1
Suspension		1	1	1	1										1	1	1	1
Frame ascent	1	1	1	1	1									1	1	1	1	1
Frame descent	1	1	1	1	1	1	1	1	1	1	1		1		1	1	1	1

Stabiliser electrovalve operating logic



	X5	EV3	EV4	EV5	EV6	EV7	EV8	EV9	EV10	EV11	EV12
C1 stabiliser extension	1	1					1				
C1 stabiliser retraction	1		1				1				
C2 stabiliser extension	1	1				1					
C2 stabiliser retraction	1		1			1					
C3 stabiliser extension	1	1		1							
C3 stabiliser retraction	1		1	1							
C4 stabiliser extension	1	1			1						
C4 stabiliser retraction	1		1		1						
C5 stabiliser extension	1	1					1				
C5 stabiliser retraction	1		1				1				
C6 stabiliser extension	1	1						1			
C6 stabiliser retraction	1		1					1			
C7 stabiliser extension	1	1								1	
C7 stabiliser retraction	1		1							1	
C8 stabiliser extension	1	1									1
C8 stabiliser retraction	1		1								1

70

PRESSURE TEST PORTS


To view the pressure test port values of the hydrostatic transmission:

◀ Group 20 - "TRANSMISSION CONTROL AND ADJUSTMENT"

	Showing on machine	Pressure port	Line function	Control component		Theoretical value		Value measured on machine	
				Minimum value	Maximum value	Mini	Maxi	Mini	Maxi
P1	Yes	Distributor PP	Distributor power supply	Movement cut-off EV (EVX)	LP LS distributor + Δp distributor	0b	295b	0b	270b
									
P2	No	Distributor LS line	Load signal	Connection to the tank	Distributor LP LS	0b	270b	0b	245b
									

70

STABILISER HYDRAULIC CYLINDER + CHAINS




Key:

A - Front right stabiliser
B - Front left stabiliser

C - Rear right stabiliser
D - Rear left stabiliser

SCHEMATIC DIAGRAM OF OPERATION



PREPARATION AND SAFETY INSTRUCTIONS

- Deactivate battery power supply using a battery cut-off.
- Before any work, lower the stabiliser opposite to the one that has to be removed. This step will enable better access for the removal of the cylinder and the extraction of the chains.

Example: When stabiliser A is removed, lower stabiliser B.

MACHINE ON WHEELS WITH FIXED BASKET / ORH WHEN TILTING





MOVEMENTS AUTHORISED FROM THE CAB					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION	X	X			Only to return to the centre
TOP TILT					
BOTTOM TILT	X	X			
BOOM ASCENT	X (only up to H = 3 m)	X (only up to H = 3 m)			
BOOM DESCENT					
BOOM RETRACTION	X	X			
BOOM EXTENSION					
OPTION 1	X	X			
OPTION 2					

MOVEMENTS AUTHORISED FROM CAB WITH PLATFORM EXCLUSION BUTTON ACTIVATED					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				
STABILISER DESCENT	X	X			
TURRET ROTATION					
TOP TILT					
BOTTOM TILT	X	X	X	X	
BOOM ASCENT	X (only up to H = 3 m)	X (only up to H = 3 m)			
BOOM DESCENT					
BOOM RETRACTION	X	X	X	X	
BOOM EXTENSION					
OPTION 1	X	X	X	X	
OPTION 2					


MACHINE ON STABILISERS WITH PENDULAR PLATFORM

MOVEMENTS AUTHORISED FROM THE CAB					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				Only with detector on pendular reading
STABILISER DESCENT	X	X			
TURRET ROTATION					
TOP TILT					
BOTTOM TILT					
BOOM ASCENT					
BOOM DESCENT					
BOOM RETRACTION					
BOOM EXTENSION					
OPTION 1					
OPTION 2					


MOVEMENTS AUTHORISED FROM CAB WITH PLATFORM EXCLUSION BUTTON ACTIVATED					
	BOOM UP TO H=3 m	BOOM UP TO H=3 m	BOOM MORE THAN H=3 m	BOOM MORE THAN H=3 m	COMMENTS
	RETURN BOOM	BOOM EXTENDED	RETURN BOOM	BOOM EXTENDED	
STABILISER ASCENT	X				Only with detector on pendular reading
STABILISER DESCENT	X	X			
TURRET ROTATION	X	X	X	X	
TOP TILT	X	X	X	X	
BOTTOM TILT	X	X	X	X	
BOOM ASCENT	X (also more than 3 m)	X (also more than 3 m)	X	X	
BOOM DESCENT	X	X	X	X	
BOOM RETRACTION	X	X	X	X	
BOOM EXTENSION	X	X	X	X	
OPTION 1	X	X	X	X	
OPTION 2	X	X	X	X	


ECU	Type	PIN	value	Designation	Item	ECU location
Midac T1	Inlet	1c	3V / 6V / 9V	Winch cab analogue signal on-board	X2 / 5	
	Inlet	2a	3V / 6V / 9V	Turret rotation speed adjustment potentiometers	X6a	
	Inlet	2c	3V / 6V / 9V	TILTING cab analogue signal	X2 / 7	
	Inlet	3a	3V / 6V / 9V	TELESCOPE cab analogue signal	X1 / 8	
	Inlet	3c	3V / 6V / 9V	LIFTING cab analogue signal	X2 / 8	
	Inlet	4c	3V / 6V / 9V	ATTACHMENT cab analogue signal	X1 / 5	
	Inlet	8c	12V	Attachment control neutralization	I72	
	Inlet	26	12V	Left cab manipulator neutral contact	X1/1;2;14;	
	Inlet	26	12V	Right cab manipulator neutral contact	X2 / 1;2;14;	
	Inlet	30;31	12V	3D platform tilting/rotation switch	I25	
	Inlet	32	12V	Cab manipulator consent	X1 / 13	
RC 2-2	Inlet	33	Frequency	Speed sensor (gear box)	X60	
	Outlet	J1-30	Analogue	2nd gear electrovalve (gear box)	X62	
	Outlet	J1-31	Analogue	1st gear electrovalve (gear box)	X61	
RC4-4	Inlet	10	12V	Forward gear info from ARM_C1 terminal 52	ARM C1	
	Inlet	11	12V	Reverse gear info from ARM_C1 terminal 53	ARM C1	
	Inlet	12	0V	Hydrostatic pump oil filter clogging	X58	
	Inlet	20		Electronic brake pedal (Inching)	X71	
	Inlet	21	12V	Door info from ARM_C1 terminal 47	ARM C1	
	Inlet	23	0V	Hydrostatic transmission oil temperature sensor	X57	
	Inlet	44		Hydrostatic motor speed sensor	X56	
	Outlet	J2-15	12V	Reverse gear electrovalve	X51	
	Outlet	J2-29	12V	Forward gear electrovalve	X53	
	Outlet	J2-30	Analogue	Hydrostatic motor switch electrovalve	X55	
VIEW J5	Inlet	5	Analogue	Lifting cylinder CEC pressure sensor on rod side	PH1	
	Inlet	6	Analogue	Compensating cylinder CEC pressure sensor on rod side	PH2	
	Inlet	13	Analogue	Lifting cylinder CEC pressure sensor on piston side	PL1	
	Inlet	14	Analogue	Compensating cylinder CEC pressure sensor on piston side	PL2	
X151	Inlet	N/A	12V	Radio control switch	I115	< Group 80 - Electrical components location
X6 a	Inlet		3V / 6V / 9V	ROTATION cab analogue signal	X1 / 7	< Group 80 - Electrical components location
Plus start-up action	Outlet		12V	LS cut-off electrovalve at start-up	EV138	< Group 80 - Electrical components location

<i>Electrical components and connectors</i>			
<i>Wiring harness type</i>	<i>Item</i>	<i>Designation</i>	<i>Diagram</i>
Cab fuse box and relay	F8	Dashboard switch power supply fuse	19
Cab fuse box and relay	F9	Seat equipment power supply fuse	18
Cab fuse box and relay	F10	Switch lighting fuse	19
Cab fuse box and relay	F11	Dashboard switch power supply fuse	22
Cab fuse box and relay	F12	Security sensor power supply fuse	29
Cab fuse box and relay	F13	Dashboard switch power supply fuse	19
Cab fuse box and relay	F14	Red hazard warning light relay power supply fuse	18
Cab fuse box and relay	F15	Sensor power supply fuse under cab	29
Cab fuse box and relay	F16	Operator panel power supply fuse	17
Cab fuse box and relay	F17	Horn relay power supply fuse	18
Cab fuse box and relay	F18	Emergency stop palm button supply fuse	19
Cab fuse box and relay	F19	Seat tilt supply fuse	17
Cab fuse box and relay	F20	Seat supply fuse	30
Cab fuse box and relay	F21	Large mixing bucket fuse	22
Cab fuse box and relay	F22	CAN BUS supply fuse for radio control	26
Cab fuse box and relay	F23	Arm_T1 control unit relay supply fuse	27
Cab fuse box and relay	F24	Relay supply fuse for electronic control units	17
Cab fuse box and relay	F25	Heating timer reservation fuse	23
Cab fuse box and relay	F26	Emergency "30" fuse	18
Cab fuse box and relay	F27	Car radio "30" fuse	23
Cab fuse box and relay	F28	Cigarette lighter fuse	23
Cab fuse box and relay	F29	Reservation supply fuse	33
Cab fuse box and relay	F30	Cab interior lighting fuse	33
Frame fuse box and relay	F31	Front left, rear right positions fuse	3
Frame fuse box and relay	F32	Front right, rear left positions fuse	3
Frame fuse box and relay	F33	Contact and rear cable reel fuse	6
Frame fuse box and relay	F34	Oil radiator cooling fuse	4
Frame fuse box and relay	F35	Rotax preheating/sensor fuse	7
Frame fuse box and relay	F36	Left low beam fuse	3
Frame fuse box and relay	F37	Right low beam fuse	3
Frame fuse box and relay	F38	Arm_C1 supply fuse	12
Frame fuse box and relay	F39	Left main beam fuse	3
Frame fuse box and relay	F40	Right main beam fuse	3
Frame fuse box and relay	F41	"30" reservation fuse	4
Frame fuse box and relay	F42	Arm_C2 relay supply fuse	14
Frame fuse box and relay	F43	Rear fog light reservation fuse	2
Frame fuse box and relay	F44	Reverse functions fuse	2
Frame fuse box and relay	F45	Control units supply fuse	5
Frame fuse box and relay	F46	Rexroth resources supply fuse	8
Frame fuse box and relay	F47	Battery "30" reservation fuse	6
Frame fuse box and relay	F48	Brake light fuse	2
Frame fuse box and relay	F49	Connector fuse for programming	6
Frame fuse box and relay	F50	Alternator fuse	5
Frame fuse box and relay	F51	Back-up pump relay fuse	4
Frame fuse box and relay	F52	Battery "30" reservation fuse	6
Frame fuse box and relay	F53	Battery "30" reservation fuse	6
Frame fuse box and relay	F54	Start button "15" reservation fuse	6
Frame fuse box and relay	F55	Relay fuse supply R29, R19, R24, R20, R21, R22, R23, R26, R25	4
Frame fuse box and relay	F56	Rexroth resources supply fuse	8
Frame fuse box and relay	F57	Hydrostatic speed sensor fuse	11
Frame fuse box and relay	F58	Start button "15" reservation fuse	6




80







80


<i>Electrical components and connectors</i>			
<i>Wiring harness type</i>	<i>Item</i>	<i>Designation</i>	<i>Diagram</i>
	X143	Attachment electrovalve on DANFOSS distributor	30
Turret	X143A		
Distributor	X143B		
	X143C		
	X144	Tilting/compensation electrovalve on DANFOSS distributor	30
Turret	X144A		
Distributor	X144B		
	X144C		
	X145	Telescope extension electrovalve on DANFOSS distributor	30
Turret	X145A		
Distributor	X145B		
	X145C		
	X146	Boom lifting electrovalve on DANFOSS distributor	30
Turret	X146A		
Distributor	X146B		
	X146C		
	X147	Turret rotation electrovalve on DANFOSS distributor	30
Turret	X147A		
Distributor	X147B		
	X147C		
	X148	Winch electrovalve on DANFOSS distributor	30
Turret	X148A		
Distributor	X148B		
	X148C		
Turret/Seat	X149	Turret/seat harness interface	17, 27, 30, 31, 32
Turret/Cab	X150	Turret/cab harness interface	18, 19, 21, 23, 29, 32, 33
Turret	X151	Turret/radio control harness interface	26
Turret/Platform rewiring	X152	Turret/platform harness interface	26
Turret	X153	Option connector	28
	X154	Turret/movement locking system harness interface (Option)	25
Distributor	X154B		
	X154C		
Movement locking system	X154D		
Dashboard	X155	Radio control switch by-pass	19
Distributor	X155	Electronic module for EVD valve management	30
Dashboard/ Cab interior air-conditioning	X160	Dashboard/cab interior air conditioning harness interface	23
Dashboard	X161	Pressure sensitive switch	23
Turret	X200	Green indicator lamp rewiring	26
Platform rewiring	XA	Telescope head a platform rewiring connector	26
Platform rewiring	XB	Telescope head b platform rewiring connector	26
Rear frame	XC	Preheat rewiring option connector	9
Dashboard	XCD	Car radio connector with CD player	9
Frame fuse box and relay	XDG	OBD2 connector	7
Front frame	XDRC	Reservation connector XDRC	11
Movement locking system	XEVDA	Movement cut-off electrovalve	30
Distributor	XEVDB		
	XEVDC		
Rear frame	XR	BUS J1939 balancing resistance	9
Dashboard	XT	Video connector rewiring	19




80















<i>Ground</i>						
<i>Wiring harness type</i>	<i>Item</i>	<i>Designation</i>	<i>Location 2D</i>			<i>Harness details</i>
			<i>A</i>	<i>B</i>	<i>C</i>	
Front frame	GROUND	Front frame ground				1
Front frame	GROUND	Front left frame ground				1
Rear frame	GROUND-B	Rear frame ground				2
Turret	GROUND	Turret ground				3
Dashboard	GROUND	Dashboard ground			C27	4
Cabine	GROUND	Cabin ground				5




80

2	Calibration and maintenance button
	This button, used with the appropriate password, activates the calibration menu. Only accessible on the F2 page.
3	Operator configuration button
	This button activates (with or without password) the Operator parameter menu (Contrast, screen brightness, etc.). Accessible on the F2 page.
4	Attachment selection
	Press this button to change the attachment being used.
5	Horn button
	This button switches off the horn.
6	Hook button
	Not used.
7	Arrow and ENTER buttons
	These buttons are used to move around in the menu and confirm the selections.
8	Tare/Escape button
	To exit the command or page in progress.
9	Green/yellow/red indicator lamps
	Status of actual load Green = OK Yellow = warning: load between 90% and 100% Red = overload: the movement is not authorised


P14 : Au				Option movement												
Au	111	222	333	111: Control lever tester 0 +/- 1000 222: Percentage of speed introduced by the control lever 333: Danfoss control(0 – 256)												
				<table border="1"> <tr> <td></td> <td>MINI</td> <td>Neutral</td> <td>MAXI</td> </tr> <tr> <td>111</td> <td>-1000</td> <td>0</td> <td>1050</td> </tr> <tr> <td>333</td> <td>200</td> <td>512</td> <td>900</td> </tr> </table>		MINI	Neutral	MAXI	111	-1000	0	1050	333	200	512	900
	MINI	Neutral	MAXI													
111	-1000	0	1050													
333	200	512	900													
P15 : Ar				Winch movement												
Ar	111	222	333	111: Control lever tester 0 +/- 1000 222: Percentage of speed introduced by the control lever 333: Danfoss control(0 – 256)												
P16: trans pressures																
0 B111		2 B222		Values from pressure sensors in Bit (0-1024)												
1 B333		3 xxxx		0: Pillar side pressure sensor on lifting cylinder 1: Rod side pressure sensor on lifting cylinder 2: Pillar side pressure sensor on compensating cylinder 3: Rod side pressure sensor on compensating cylinder												
P17: Lmi status																
	*			View status (see below)												
	M IIII: VVVV															
P18: Mac.Status																
	*			View status (see below)												
	M IIII: VVVV															
P19: Not used																
P20 : Act1A				Main telescope reel: ACT 1A												
ACT1A		A:aaaa		Main telescope reel: left sensor												
ccc	Eee	L:ssss		A: aaaa Angle sensor value (boom value at 0° XXXX bits) C: cccc Message counter E: ee Sensor error L: ssss Length sensor value (value completion boom completion folded XXXXX bits)												
P21 : Act1B				Main telescope reel: ACT 1B												
ACT1B		A:aaaa		Main telescope reel: right sensor												
ccc	Eee	L:ssss		A: aaaa Angle sensor value (boom value at 0° XXXX bits) C: cccc Message counter E: ee Sensor error L: ssss Length sensor value (value completion boom completion folded XXXXX bits)												



3 - In the "Utils" dropdown menu, choose "Pri Selection".




4 - Click on "Browse"



5 - Search for the file that corresponds to the machine that you wish to carry out diagnostics on.

⇒ MRT 3050: "C/Program Files/Winscope/MCI/MRT3050/CFG_LIGHT.IT"



6 - Click on "Open".


CROSS-SECTION VIEW OF HEATING SYSTEM

LIST OF PARTS


- 1 - Hot air blower
- 2 - Electronic control box
- 3 - Combustion air blower
- 4 - Spark plug
- 5 - Cover
- 6 - Heat exchanger
- 7 - Flame/overheating sensor
- 8 - Timer with potentiometer
- 9 - "Heating/fan" switch
- 10 - Fuse box with main fuse and "control element" fuse
- 11 - Electric motor
- 12 - Fuel connector
- 13 - Flange seals
- 14 - Combustion chamber
- 15 - Heater vent
D2= Ø 60 mm
D4= Ø 75/90 mm
- 16 - Combustion air pipe
- 17 - Metering pump
- 18 - Fuel filter fitted in the metering pump
- 19 - Swivelling burner
- 20 - Exhaust pipe
- 21 - Exhaust

CIRCUITS

- F** - Fresh air
- W** - Hot air
- A** - Exhaust gas
- B** - Fuel
- V** - Combustion air



REMOVING THE CAB, TURRET AND THUST RING



GENERAL INFORMATION

To reach the various components, the order of removal must be observed. Mark all the hydraulic pipes and electrical connections with a felt tip pen before removing them to ensure correct repositioning during reassembly.


 **Plug all hydraulic orifices to prevent any impurities from contaminating the hydraulic system.**

PREPARATION AND SAFETY INSTRUCTIONS


Place the truck on a horizontal surface and extend the stabilisers to ensure the greatest stability and safety.

Special instruments:


- Lifting crane (5000 kg. minimum).
- Hydraulic power unit.



Unscrew the nuts (Item 6) and remove the tie rods (Item 7) to remove the heating fluid tank (Item 5).




Unscrew the screws (Item 8) and remove the collars (Item 9) to release the pipes from the turret.



Unscrew the screws (Item 10) to release the brackets (Item 11) from the turret that support the rotating manifold (Item 12).



Disconnect all the hydraulic pipes from the rotating manifold (Item 12).




Screw on the nuts (Item 4) and lock nuts (Item 5) using a tightening torque of 562 Nm.


Using the hydraulic power unit, pump oil into the oil system to cause rotation of the hub of the rotation motor (Item 1) and thus rotation of the thrust ring.

Through the appropriate holes (Item 3) under the frame, screw in the screws (Item 6) to attach the turret to the truck frame, using the hydraulic power unit, rotate the turret as much as necessary to screw in all the screws, two at a time.

Replace the plugs in the two holes (Item 7) in the turret.




Warning: the six lowest screws and their nuts are fitted to correspond with the holes (Item 8) in the frame plate.




Disconnect the power unit pipes (Item 2) and reconnect the hydraulic plant pipes to the turret rotation motor (Item 1).


Reconnect all the pipes to the rotating manifold (Item 9), attach the brackets (Item 10) to the turret by screwing in the screws (Item 11).




Lock the hydraulic pipes to the turret with the collars (Item 12) by screwing in the screws (Item 13).




Refit the rear housing (Item 20) of the cab by screwing in the screws (Item 21).



Replace the engine cover (Item 22) on the truck and fix it with the screws (Item 23) and washers (Item 24).



Refit the tie rods (Item 25) to the engine cover (Item 22) by screwing in the screws (Item 26), washers (Item 27) and nuts (Item 28).



Group 80 - ELECTRICAL SCHEMATIC DIAGRAMS - Sheet "26 - BASKET RADIO CONTROL CONNECTOR OPTION"

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL