



**CRAWLER EXCAVATOR**

**E80B  
TIER 4**

**REPAIR  
MANUAL**

87480998 NA

Issued 01July 08



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## SECTION 1 - SAFETY AND GENERAL INFORMATION

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer


Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-14960	

## INTERNATIONAL UNIT SYSTEM

### INTRODUCTION

Although this manual uses the SI units system. Outline of SI units system is described here. Given below are an excerpt of the units that are related to this manual :

1. Etymology of SI Units  
English : International System of units
2. Construction of SI Unit System



GRAPHIC\_ID Figure 2

#### 1. Basic Units

**Table1-1**

QUANTITIES	DESIGNATION	SIGN
Length	Meter	m
Mass	Kilogram	kg
Time	Second	s
Current	Ampere	A
Thermodynamic temperature	Kelvin	K
Gram molecule	Mol	mol
Luminous intensity	Candela	cd

#### 2. Supplementary Units

**Table1-2**

QUANTITIES	DESIGNATION	SIGN
Plain angle	Radian	rad
Solid angle	Steradian	sr

#### 3. Derived Units of Basic Units

**Table1-3**

QUANTITIES	DESIGNATION	SIGN
Area	Square meter	m <sup>2</sup>
Volume	Cubic meter	m <sup>3</sup>
Velocity	Meter per second	m/s
Acceleration	Meter per second / second	m/s <sup>2</sup>
Density	Kilogram per cubic meter	kg/m <sup>3</sup>

#### 4. Derived Units bearing Peculiar Designations

**Table1-4**

QUANTITY	UNIT	SYMBOL	FORMULA
Frequency	hertz	Hz	1Hz=1/s
Force	newton	N	kg • m/s <sup>2</sup>
Pressure and Stress	pascal	Pa	N/m <sup>2</sup>
Energy, Work and Quantity of heat	joule	J	N•m
Power	watt	W	J/s
Quantity of electricity	coulomb	C	A•s
Electric potential difference, Voltage, and Electromotive force	volt	V	W/A
Quantity of static electricity and Electric capacitance	farad	F	C/V
Electric resistance	ohm	Ω	V/A
Celcius temperature	celcius degree or degree	°C	(t+273.15)K
Illuminance	lux	lx	l m/m <sup>2</sup>

#### 5. Prefixes of SI

PREFIX		POWER
DESIGNATION	SIGN	
Giga	G	10 <sup>9</sup>
Mega	M	10 <sup>6</sup>
Kilo	k	10 <sup>3</sup>
Hecto	h	10 <sup>2</sup>
Deca	da	10
Deci	d	10 <sup>-1</sup>
Centi	c	10 <sup>-2</sup>
Milli	m	10 <sup>-3</sup>
Micro	μ	10 <sup>-6</sup>
Nano	n	10 <sup>-9</sup>
Pico	p	10 <sup>-12</sup>

SECTION 1 - SAFETY AND GENERAL INFORMATION  
CHAPTER 2 - SPECIFICATIONS

Unit: kg (lbs)

Item	Model	2.13 M (7 ft-0 in) Arm + 600 mm (23.6 in shoe)	
3.3.2 Arm cylinder		68	(150)
3.3.3 Pin (Mounting arm • Mounting arm cylinder)		13	(29)
4. Lubricant and water (including the following :)		211	(465)
4.1 Hydraulic oil		*103	(227)
4.2 Engine oil		5	(11)
4.3 Fuel		103	(227)
4.4 Water		5	(11)

**NOTE:** Numerical values marked \* indicate the dry weight.

SECTION 1 - SAFETY AND GENERAL INFORMATION  
CHAPTER 3 - ATTACHMENT DIMENSIONS

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.


All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-14990	

**BUCKET**

**BUCKET DIMENSIONAL DRAWING**

Hoe bucket



GRAPHIC\_1D

Figure 7

**BUCKET DIMENSIONAL TABLE**

Unit : mm (ft-in)

Type	Hoe Bucket	
Capacity	0.22 m <sup>3</sup> (0.29 cu/yd)	0.28 m <sup>3</sup> (0.37 cu/yd)
Part No.	YT61B00019F1	YT61B00042F1
A	290 (11.4in)	290 (11.4in)
B	R1,037 (3ft-5in)	R1,037 (3ft-5in)
C	550 (21.7in)	650 (25.6in)
D	238 (9.37in)	238 (9.37in)
E	182 (7.17in)	182 (7.17in)
F	650 (25.6in)	750 (29.5in)
G	450 (17.7in)	550 (21.7in)
H	466 (18.3in)	573 (22.6in)
I	166 (6.54in)	191 (7.52in)
lo	150 (5.91in)	191 (7.52in)
d1	Ø65 (2.56in)	Ø65 (2.56in)
d2	Ø50 (1.97in)	Ø50 (1.97in)

## SECTION 2 - MAINTENANCE

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.


All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15000	

**TIGHTENING TORQUE FOR HOSE AND FITTING**

**JOINT (O-RING TYPE)**


Size (PF)	Wrench (mm)	Tightening torque Nm (pound-ft)
1 / 8	14	17±2 (13±1.5)
1 / 4	19	36±2 (27±1.5)
3 / 8	22	74±5 (55±4)
1 / 2	27	108±9.8 (80.0±7)
3 / 4	36	162±9.8 (119±7)
1	41	255±9.8 (188±7)



GRAPHIC\_ID
Figure 4

**HYDRAULIC HOSE (30° FLARE TYPE)**


Size (PF)	Wrench(mm)	Tightening torque Nm (pound-ft)
1 / 8	17	15±2.0 (11±1.5)
1 / 4	19	29±4.9 (21±3.6)
3 / 8	22	49±4.9 (36±3.6)
1 / 2	27	78±4.9 (58±3.6)
3 / 4	36	118±9.8 (87±7.2)
1	41	137±15 (101±11)



GRAPHIC\_ID
Figure 5

**JOINT (ORS TYPE)**


Unified screw size	Opposing flats	Tightening Torque Nm (pound-ft)
1-14 UNS	30, 32	137±14 (101±10)
1 3 / 16-12 UN	36	177±18 (131±13)
	41	206±26 (152±15)
1 7 / 16-12 UN	41	206±26 (152±15)
	46	206±26 (152±15)



GRAPHIC\_ID
Figure 6

**SPLIT FLANGE**


Size	Tightening torque Nm (pound-ft)			
	Standard pressure series 20.6 MPa	Bolt size	Hi pressure series 41.2 MPa	Bolt size
3 / 4	33.9±5.6 (25±4)	M10	39.5±5.6 (29±4)	M10
1	42.4±5.6 (31±4)	M10	62.2±5.6 (46±4)	M12
1 1 / 4	55.1±7.1 (41±5)	M10	93.3±8.4 (69±6)	M14
1 1 / 2	70.6±8.4 (52±6)	M12	169±11 (125±8)	M16
2	81.9±8.4 (60±6)	M12	282±11 (208±8)	M20



GRAPHIC\_ID
Figure 7

### COUNTERWEIGHT LIFTING JIG

1. Two lifting jigs (YY60C01111P1, YY60C01112P1)



GRAPHIC\_1D

Figure 36

SECTION 2 - MAINTENANCE  
CHAPTER 2 - STANDARD MAINTENANCE TIME TABLE

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15020	

SECTION 2 - MAINTENANCE  
CHAPTER 2 - STANDARD MAINTENANCE TIME TABLE


GROUP No.	LOCATION	WORK TO BE DONE	UNIT	REMARK	UNIT: HOUR		
03 Swing frame	148	Engine	O/H	1 set	Reference for engine		
		Other necessary works	Detach/attach	1 set	Removing and installing guard	0.5	
			Detach/attach	1 set	Removing and installing counter weight	0.4	
			Detach/attach	1 set	Removing and installing pump	2.3	
			Detach/attach	1 set	Removing and installing air cleaner	0.4	
			Detach/attach	1 set	Removing and installing muffler	0.4	
			Detach/attach	1 set	Removing and installing radiator	3.5	
		150	Upper frame		See Upper Frame Removal		
		151	Upper frame ASSY	Detach/attach	1 pc.	After removing swivel joint	1.0
		152	•Mounting bolt	Detach/attach	1 set		0.3
		153	•Upper frame slinging	Detach/attach	1 pc.		0.3
		154	•Cleaning	Cleaning	1 pc.		0.2
		155	•Sealant	Apply	1 pc.		0.2
			Other necessary works	Detach/attach	1 set	Cab	1.5
				Detach/attach	1 set	Guard	0.3
			Detach/attach	1 set	Counter weight	0.4	
			Detach/attach	1 set	Boom	1.0	
04 Travel system	00	Travel relation			See Crawler Removal		
	01	Track link ASSY	Detach/attach	One side	Include adjustment of tension	1.0	
	02	•Track link attaching and detaching position	Preparation	One side		0.1	
	03	•Master pin	Detach/attach	One side		0.4	
	04	•Track link extending and winding	Detach/attach	One side		0.4	
	05	Shoe plate	Replace	1 pc.		0.4	
	10	Upper roller relation			See Upper Roller Removal		
	11	Upper roller ASSY	Detach/attach	1	After removing track link	0.2	
	12	Upper roller	O/H	1		1.0	
	20	Lower roller relation			See Lower Roller Removal		
	21	Lower roller ASSY	Detach/attach	1		0.2	
	22	Lower roller	O/H	1		1.0	
	30	Front idler relation			See Front Idler Removal		
	31	Front idler ASSY	Detach/attach	One side	After removing track link	0.5	
	32	Front idler ASSY slinging	Detach/attach	One side		0.2	
	33	Front idler ASSY	Disassemble	One side		0.2	
	34	Idler ASSY	O/H	One side		1.0	
	35	Idler adjuster ASSY	O/H	One side	Replace spring	2.0	
36	•Grease cylinder	O/H	One side		0.5		
40	Sprocket			See Sprocket Removal			
41	Sprocket	Replace	One side	After removing track link	0.5		
50	Travel motor relation			See Travel Motor Removal			

## NOTES

**MEASURING TRAVEL PERFORMANCES**


**Travel Speed**

1. Purposes  
Measure the travel sprocket revolution and confirm the performances between the hydraulic pump and the travel motor of the travel drive system.
2. Conditions  
Hydraulic oil temperature ;  
45~55°C (113~131°F)  
Crawler on the right and left sides are tensioned evenly.
3. Preparation  
Attach the reflection panel with a magnet to the travel motor cover.  
Swing the swing frame through 90° as shown and make the crawler on one side take off the ground, using the attachment.
4. Measurement  
Engine revolution; Hi idle  
2-speed travel switch; 1st speed and 2nd speed  
Measuring points ; Right and left  
Method, example 1 ;  
    Measure revolution with a stroboscope  
Method, example 2 ;  
    Measure the revolutions per minute visually.



GRAPHIC\_ID Figure 14

**ONE SIDE LIFTED POSITION**



GRAPHIC\_ID Figure 15


**ADHERING POSITION OF REFLECTION PANEL**

Sprocket revolution Unit: min<sup>-1</sup>

Measurement item		Standard value	Repairable level	Service limit
RH & LH	H mode 1st speed	31.1-27.9	24.3 -21.8	18.7 or less
	H mode 2nd speed	59.5-53.9	46.4 -42.0	36.1 or less
	S mode 2nd speed	59.5-53.9	46.4 -42.0	36.1 or less

**Deviation of Travel**

1. Purpose  
Measure the amount of deviation at 20m (66ft) travel and confirm the horizontal balance between the hydraulic pump and the travel motor of the travel drive system.
2. Condition  
Hydraulic oil temperature ;  
45~55°C (113~131°F)  
RH and LH crawler are tensioned evenly.  
Firm, level ground  
Engine revolution; Hi idle




GRAPHIC\_ID Figure 16

**TRAVEL POSITION**

**ENGINE CONTROL EQUIPMENT****Governor motor and Mechatro controller**

1. By operating accel dial, the input voltage change is sensed by CN102-8 pin of Mechatro controller.
2. The Mechatro controller computes the input voltage, and outputs command to governor motor, and incline governor lever of engine to the swing angle corresponding to accel dial set value..
3. The limit switch in the governor motor is the starting point of the governor motor.




GRAPHIC\_ID

Figure 39

**Speed sensor**

1. Installing place  
Engine flywheel housing
2. Sensor attaching procedure
  - A. Screw the sensor in until it contacts the ring gear. In this case, do not damage the top of the sensor.
  - B. Rotate the sensor one turn (360 degrees) reversely, and tighten with a lock nut (Opposing flats 22 mm).  
Tightening torque : 29.4±4.9Nm (21.7±3.6 pound-ft)
  - C. Check the output voltage at the maximum and minimum speed in no-load running.
  - D. If the above-mentioned output is beyond the range of table of table, loosen the nut again  
And adjust the between the sensor and ring gear to obtain the appropriate voltage



GRAPHIC\_ID

Figure 40

**The Voltage From Sensor**

Engine Speed	Output Voltage	
	Voltage Waveform	AC Current (Effective Value)
Maximum Speed At No-Load 2420 min <sup>-1</sup>	20V - 72V (Peak - Peak)	7.1V - 25.5V
Minimum Speed At No-Load 1050 min <sup>-1</sup>	9V - 40V (Peak - Peak)	3.2V - 14.2V

SECTION 3 - SYSTEMS  
CHAPTER 1 - MECHATRO CONTROL SYSTEM

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15050	

SECTION 3 - SYSTEMS  
CHAPTER 1 - MECHATRO CONTROL SYSTEM

No.	Displays	Contents	No.	Displays	Contents
19	NO.19 DIGITAL INPUT DI15 OFF DI16 OFF DI17 OFF DI18 OFF DI19 OFF DI20 OFF DI21 OFF DI22 OFF DI23 OFF DI24 OFF DI25 OFF DI26 OFF DI27 OFF DI28 OFF	ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication	23	NO.23 DIGITAL OUTPUT DO15 COMP. OFF MEAS. OFF DO16 COMP. OFF MEAS. OFF DO17 COMP. OFF MEAS. OFF DO18 COMP. OFF MEAS. OFF DO19 COMP. OFF MEAS. OFF DO20 COMP. OFF MEAS. OFF DO21 COMP. OFF MEAS. OFF	Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value
20	NO.20 DIGITAL INPUT DI29 OFF DI30 OFF DI31 OFF DI32 OFF DI33 OFF DI34 OFF DI35 OFF DI36 OFF DI37 OFF DI38 OFF DI39 OFF DI40 OFF DI41 OFF DI42 OFF	ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication ON/OFF indication	24	NO.24 DIGITAL OUTPUT DO22 COMP. OFF MEAS. OFF DO23 COMP. OFF MEAS. OFF DO24 COMP. OFF MEAS. OFF DO25 COMP. OFF MEAS. OFF DO26 COMP. OFF MEAS. OFF DO27 COMP. OFF MEAS. OFF DO28 COMP. OFF MEAS. OFF	Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value
21	NO.21 DIGITAL OUTPUT DO1 COMP. OFF MEAS. OFF DO2 COMP. OFF MEAS. OFF DO3 COMP. OFF MEAS. OFF DO4 COMP. OFF MEAS. OFF DO5 COMP. OFF MEAS. OFF DO6 COMP. OFF MEAS. OFF DO7 COMP. OFF MEAS. OFF	Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value	25	NO.25 WIPER SYSTEM WIPER SW OFF RISEUP SW OFF REVERSE SW OFF PREVENT ARC OFF CW MOTOR RLY OFF CCW MOTOR RLY OFF WASHER SW OFF MOTOR RELAY OFF	Wiper switch Wiper rise-up switch Wiper reverse rotation switch Wiper motor ark prevention relay Wiper normal rotation relay Wiper reverse rotation relay Washer switch Washer motor relay
22	NO.22 DIGITAL OUTPUT DO8 COMP. OFF MEAS. OFF DO9 COMP. OFF MEAS. OFF DO10 COMP. OFF MEAS. OFF DO11 COMP. OFF MEAS. OFF DO12 COMP. OFF MEAS. OFF DO13 COMP. OFF MEAS. OFF DO14 COMP. OFF MEAS. OFF	Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value Set value in computer Measured value	27	NO.27 MERIT SYSTEM  COMMUNICATION OFF 4  0412051200	Status of communication in MERIT controller

GRAPHIC\_1D

Figure 15

2) Service diagnosis mode No.2

No.	Displays	Contents	No.	Displays	Contents
1	NO.1 MAIN CONT. P/N YT22E00064F1 PROGRAM VERSION 1-VER 01.00 2-VER 00.00  SERVICE DIAG 2	P/No. indication  Program version indication MERIT controller program version  Service diagnosis mode	33	NO.33 BUCKET C-1 P1-PRES 0.0M C-2 P2-PRES 0.0M E-1 P1-PSV 0mA E-2 P2-PSV 0mA D-1 P1-JL(BPC) 0mA D-2 P2-JL(BPC) 0mA D-3 S-TRAVEL 0mA B-5 BUCKET DIG 0.0M B-6 BUCKET DUMP 0.0M G-3 ENG SPEED 1000 POWER SHIFT 0mA	Pump pressure sensor Pump pressure sensor Command current Command current Command current Command current Bucket digging pressure sensor Bucket dump pressure sensor Engine actual rpm Power shift current

GRAPHIC\_1D

Figure 16

SECTION 3 - SYSTEMS  
CHAPTER 1 - MECHATRO CONTROL SYSTEM

Connector No.	Pin No.	Port name	Function	Input/putput	Signal level
CN104	1	GA	Boom head	Input	0V
	2	A17			0.5~4.5V
	3	+5VA			Power output 5V
	4	+5VA	Boom rod	Input	Power output 5V
	5	A18			0.5~4.5V
	6	GA			0V
	7	GA	Spare	Input	0V
	8	A19			0.5~4.5V
	9	+5VA			Power output 5V
	10	+5VA	Spare	Input	Power output 5V
	11	A20			0.5~4.5V
	12	GA			0V
	13	A21	Spare	Input	0.5~4.5V
	14	GA			0V
	15	A22			Fuel level
	16	GP	Engine coolant temp.	Input	0V
	17	A23			0.5~4.5V
	18	GA			0V
	19	GA	Swing left	Input	0V
	20	A24			0.5~4.5V
	21	+5VA			Power output 5V
	22	+5VA	Bucket dump	Input	Power output 5V
	23	A25			0.5~4.5V
	24	GA			0V
	25	GA	Bucket digging	Input	0V
	26	A26			0.5~4.5V
	27	+5VA			Power output 5V
	28	DI 1	Starting point of accel motor	Input	GND / OPEN

Connector No.	Pin No.	Port name	Function	Input/putput	Signal level
CN105	1	+24V	Battery relay output side		20~32V
	2	+24V	Battery relay output side (sensor analog output)		20~32V
	3	+24V	Battery relay output side		20~32V
	4	DO 7	Travel 1,2 speed select valve	Output	24V/OPEN
	5	DO 8	Swing P/B select valve	Output	24V/OPEN
	6	DO 9	Pressure compensation valve	Output	24V/OPEN
	7	DO 11	Spare	Output	24V/OPEN
	8	GND	Battery (-)		0V
	9	GND	Battery (-)		0V
	10	D10+	Spare	Output	+0~800mA
	11	D1+	Spare	Output	+0~800mA
	12	D1-			-0~800mA
	13	D2+	Spare	Output	+0~800mA
	14	D2-			-0~800mA
	15	D3+	Spare	Output	+0~800mA
	16	D3-			-0~800mA
	17	D4+	Spare	Output	+0~800mA
	18	D4-			-0~800mA
	19	D5+	Spare	Output	+0~800mA
	20	D5-			-0~800mA
	21	GND	Battery (-)		0V
	22	D10-	Spare	Output	-0~800mA
	23	D6+	Spare	Output	+0~800mA
	24	D6-			-0~800mA
	25	D7+	Spare	Output	+0~800mA
	26	D7-			-0~800mA
	27	D8+	Spare	Output	+0~800mA
	28	D8-			-0~800mA
	29	D9+	Spare	Output	-0~800mA
	30	D9-			+0~800mA
	31	+24V	Battery direct connection		20~32V

SECTION 3 - SYSTEMS  
CHAPTER 2 - HYDRAULIC SYSTEM

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15060	

### Travel Circuit

#### TRAVEL MOTOR FUNCTIONS

##### (1) Functions

- 1)Prevention from overrun on a slope
- 2)Shockless relief valve prevents sudden stop by inertia
- 3)High/Low 2 speed switching mechanism
- 4)Travel parking brake
- 5)Travel speed automatic switching mechanism

#### TRAVEL FORWARD PILOT SIMULTANEOUS OPERATION CIRCUIT

##### (1)Operation

- 1)Start travel right and left at the same time with control lever, and the pilot proportional secondary pressure is delivered through P/V (11) 2, 4 ports, at the same time select higher pressure and the higher pressure is delivered through 5, 6 ports, then acts on low pressure sensors (SE9) (SE10).
- 2)Pilot proportional secondary pressure flows into a2, a3 ports of control valve (2), acts on travel spool, and switches main circuit.
- 3)The signal output by low pressure sensor is input to mechatro controller, and the output voltage of low pressure sensor is input to mechatro controller, and the engine speed is changed from 2200 rpm to 2400 rpm.

#### TRAVEL 2 SPEED SOLENOID COMMAND CIRCUIT

##### (1)Purpose

Change travel motor speed with switch.

##### (2)Operation

Press switches with rabbit and turtle marks on travel lever grips, and the solenoid (SV-3) of proportional valve block (13) is excited and is switched, and solenoid command is output by port A2 and sends to P port of travel motor (4), opens oil passage to high speed piston, the self-pressure is led to the swash plate and the swash plate is changed to high speed tilting angle (small tilting).

#### TRAVEL MAIN CIRCUIT (RIGHT OPERATION)

##### (1)Operation

With travel pilot operation, the travel speed is switched, and the oil delivered through D1 port of main pump passes through C/V P-A2, flows into P2 port of travel motor (4) through C port of swivel joint (9) allowing travel motor to perform the operation.

(Refer Components System: Travel Motor Function)

#### TRAVEL MAIN CIRCUIT (RIGHT AND LEFT SIMULTANEOUS OPERATION)

##### (1)Purpose

1. Control of travel deviation caused by different pressure loading

##### (2)Operation

As for the oil flow at simultaneous operation, the following explanation is based on the assumption, that the loaded pressure of right travel is higher than left. Before the oil flows through the right and left travel spools, and the oil flows into the travel motor (4) via A2, A3 ports, the oil from P port flows via the pressure compensation valve (A). In this case, the right higher loading pressure acts on the pressure compensation valve (A), and the pressure narrows the opening of compensation valve. Consequently, the travel deviation is controlled, because the left loading pressure increased, and the inflow rate is adjusted.

### Arm Circuit

#### ARM CONTROL PILOT CIRCUIT

##### (1)Operation

1)Start arm in operation, and pilot proportional secondary pressure is output through port (4) of left pilot valve (10), and acts on low pressure sensor (SE7), and at the same time the pressure branches into 2 circuits and acts on Pi2 and b7 ports of C/V (2).

2)Then, the secondary pressure acted on C/V (2) b7 port switches arm spool. And secondary pressure acted on Pi2 port of C/V (2) releases the arm lock valve.

#### RECIRCULATION FOR ARM-IN OPERATION AND MAIN CIRCUIT

##### (1)Purpose

Speed up of arm-in operation

##### (2)Principle

To have a part of return oil in arm-in operation conflues with feed oil

##### (3)Operation

1)Pump delivery oil flows into arm spool through P port of C/V (2). After passing through arm spool, flows through arm pressure compensation valve (G-1) and is fed to the rod side of arm cylinder (6) through B7 port of C/V (2). Simultaneously, the loading pressure for arm-in operation acts on flow control valve (G-3) provided in C/V (2) as the load sensing pressure. (See Components System: Control Valve.)

The flow is regulated in the pump delivery flow rate in accordance with the negative control pressure by keeping the differential pressure of pump delivery pressure and load sensing pressure constant.

2)On the other hand, the return oil from the head side of arm cylinder (6) flows through A7 port of C/V (2) and is led to arm spool through arm lock valve released by pilot proportional secondary pressure which acts on Pi2 port.

3)The return oil is branched into the 2 oil flows. One returns to the tank while being restricted by passing through orifice passage provided on arm spool. Another is recirculated in arm cylinder feed pressure by boost check valve (G-2) for recirculation.






---

**NOTES**




UPPER HARNESS ASSEMBLY (1/6)

ITEM	PART NAME	PART No.	Q'TY	REMARKS
2	CABLE	YT13E01145P2	1	STARTER
3	CABLE	YT13E01142P1	1	BATTERY-RELAY
4	CABLE	YT13E01143P1	1	BATTERY-GROUND
5	CABLE	YT13E01144P2	1	BATTERY-BATTERY
6	CABLE	LE13E01006P1	1	FLOOR GROUND
45	HARNESS	LF13E01043P1	1	UPPER HARNESS




- NOTES
1. TIGHTENING TORQUE OF BATTERY TERMINAL : 3.4N·m (2.5lbf·ft)
  2. TIGHTENING TORQUE AT EARTH : 10.7N·m (7.9lbf·ft)
  3. TIGHTENING TORQUE  
M6 : 9.6N·m (7.1lbf·ft)  
M8 : 23.5N·m (17.3lbf·ft)  
M10 : 46.1N·m (34.0lbf·ft)
  4. ATTACHMENT OF WELDING CLIP WITHOUT DIRECTIONS IS MADE INTO THE FOLLOWING.






**Boom Harness Assembly**




GRAPHIC\_1D Figure 42

**Boom Harness : YT15E01004P2**



GRAPHIC\_1D Figure 43


**Boom Light Install**



GRAPHIC\_1D Figure 44

SECTION 3 - SYSTEMS  
 CHAPTER 4 - COMPONENTS SYSTEM

Construction



GRAPHIC\_1D

Figure 2

CONSTRUCTION OF HYDRAULIC PUMP & REGULATOR

## Adjustment Of Piston Pump

(The names for each part are depending on Fig. 15)

Using adjusting screw, the maximum flow rate and power control characteristic of pump (1st turning point P1 and 2nd turning point) are adjustable.

### 1. Maximum flow rate adjusting

Loosen hexagon nut and turn the lock screw to adjust the flow rate.

Theoretical flow rate changes about  $6 \text{ cm}^3/\text{rev}$  per 1 turn of the lock screw.


### 2. Input power adjusting

#### a) 1st turning point adjusting

Loosen the nut with the hexagon nut locked, and turn the hexagon nut to turn the sleeve together, consequently pressure is adjustable. The pressure at 1st turning point is increased by turning the sleeve clockwise. In this time, the stopper turns together, turn the stopper reversely to return to the original position.

#### b) 2nd turning point adjusting

Loosen the hexagon nut with the nut locked, and turn the stopper to adjust the pressure. The pressure at 2nd turning point is decreased by turning the stopper clockwise.




GRAPHIC\_1D


Figure 15

## PUMP ADJUSTING


Control valve (5/5)



SECTION PP




MAIN PLUNGER (TRAVEL,DOZER,OPTION)



MAIN PLUNGER (SWING,BOOM,BUCKET,ARM)

SECTION 3 - SYSTEMS  
CHAPTER 4 - COMPONENTS SYSTEM



GRAPHIC\_1D

Figure 43


**NEUTRAL POSITION**



**Operation**

**1. Lever in neutral**

The action of spring (509) (for secondary pressure setting) that determines the output pressure of the pilot valve does not act upon spool (201). Therefore, spool (201) (for return) is pushed up by spring (221) [spring seat (216)]. The output ports (2,4) connect with the T port. The result is that the output pressure is equal to the tank pressure.




GRAPHIC\_ID

Figure 74

**2. When the pilot lever is tilted**

When the lever is tilted and the push rod (511) strokes, the spool (201) [spring seat (216)] moves downward to make the port P to connect with the port 2, 4, with the result that the oil of the pilot pump flows to the port 2, 4 to produce a pressure.




GRAPHIC\_ID

Figure 75

**3. Lever held**

When the pressure at ports (2,4) rises to a level equivalent to the action of spring (509) that is set by tilting the lever, the hydraulic pressure balances the spring action. When the pressure of ports (2,4) rises above a set value, ports (2,4) and the P port close while ports (2,4) and the T port open. When the pressure at ports (2,4) falls below a set value, ports (2,4) and the P port open while ports (2,4) and the T port close. Thus the secondary pressure is kept constant.



GRAPHIC\_ID


Figure 76

SECTION 3 - SYSTEMS  
CHAPTER 4 - COMPONENTS SYSTEM

Tightening torque Nm (pound-ft)	No.	Parts	Qty	Tightening torque Nm (pound-ft)	No.	Parts	Qty
	M-1	Taper Roller Bearing	1		M-22	Return Plate	1
	M-3	Friction Plate	2		M-23	Cam Plate	1
	M-4	Separator Plate	2		M-24	Level Gauge	1
	M-5	Snap Ring	1		M-25	O-ring	1
	M-6	Needle Bearing	1		M-26	Housing	1
	M-7	O-ring	1		M-27	Collar	1
	M-8	O-ring	1		M-28	Oil Seal	1
	M-9	O-ring	1		M-30	Backup Ring	2
	M-10	Balance Plate	1		M-31	O-ring : 1B P21	2
	M-11	Piston	2		M-33	Backup Ring	2
	M-12	Teflon Ring	2		M-34	O-ring : 1B P26	2
	M-13	Plug : PT 1/4	2		M-35	Parallel Pin	2
	M-14	Bushing	4		M-36	Plug : PF 3/8	1
	M-15	Scrowave	4		M-37	O-ring : 1B P14	1
	M-16	Teflon Ring	4		M-38	Socket Bolt : M12 × 30	4
	M-17	Spring	13		M-39	Cover	1
	M-18	Piston	1		M-40	Plug	1
	M-19	Cylinder	1		70	Relief Valve Assy	2
	M-20	Support Spring	1		100	Bypass Valve Assy	2
	M-21	Piston Assy	7				

**Construction**


1. Structure of travel unit



GRAPHIC\_1D

Figure 97

## Reduction Gear



GRAPHIC\_1D

Figure 107

The reduction unit has the following two functions.

### 1. Slow-down function


The reduction unit is transmitted the rotation from hydraulic motor and changes the rotation as shown below.

Rotation speed is reduced  
Torque is increased

### 2. Final power output function

The final rotation power output (torque) is transmitted to the machine sprocket.

5. Swing Cylinder



GRAPHIC\_1D

Figure 116


No.	NAME	QTY	No.	NAME	QTY	No.	NAME	QTY
1	Cylinder Tube Assy	1	11	O-ring	1	21	Set Screw	1
2	Piston Rod Assy	1	12	Holder	1	22	Steel Ball	1
3	Rod Cover	1	13	Cushion Seal	1	23	Cushion Bearing	1
4	Bushing	1	14	Collar	1	24	Cushion Seal	1
5	Snap Ring	1	15	Backup Ring	2	25	Snap Ring	1
6	Buffer Ring	1	16	Cushion Ring	1	26	Stopper	2
7	U-ring	1	17	Piston	1	27	Bushing	2
8	Wiper Ring	1	18	Seal Ring Assy	1	28	Wiper Ring	4
9	O-ring	1	19	Slide Ring	2	29	Grease Nipple	1
10	Backup Ring	1	20	Nut	1			

SECTION 3 - SYSTEMS  
CHAPTER 4 - COMPONENTS SYSTEM

Code No. Parts Name Parts No. Use Applicable Machine	Specifications	Description								
E - 22 Converter YN77S00005F1 DC24V → DC12V  YB05 - 03001 ~ LA05 - 02001 ~ YT05 - 15001 ~ LF05 - 04001 ~	<table border="1" data-bbox="435 336 901 493"> <tr> <td>Input voltage</td> <td>DC24V</td> </tr> <tr> <td>Output voltage</td> <td>DC12V</td> </tr> <tr> <td>Output current</td> <td>2.5A Max</td> </tr> <tr> <td>Ground</td> <td>Negative</td> </tr> </table> <div data-bbox="560 535 698 682" style="text-align: center;"> <p>VIEW A</p> </div> <div data-bbox="706 598 1015 651">           HOUSING YAZAKI 7122-2262            TERMINAL YAZAKI 7114-2020         </div> <div data-bbox="1063 325 1307 735" style="text-align: center;"> <p>Fix the wire with tape</p> <p>A</p> </div>	Input voltage	DC24V	Output voltage	DC12V	Output current	2.5A Max	Ground	Negative	<p style="text-align: right;">Figure 136</p>
Input voltage	DC24V									
Output voltage	DC12V									
Output current	2.5A Max									
Ground	Negative									
E - 23 Socket YN81S01002P1 Power Socket  YB05 - 03001 ~ LA05 - 02001 ~ YT05 - 15001 ~ LF05 - 04001 ~	<table border="1" data-bbox="435 808 901 892"> <tr> <td>Rated voltage</td> <td>DC12V</td> </tr> <tr> <td>Insulation</td> <td>More than 10MΩ at 500V megger</td> </tr> </table> <div data-bbox="633 903 1396 1197" style="text-align: center;"> <p>CHARACTER DESIGN PART (INCISED CHARACTER)</p> <p>TERMINAL, GND</p> <p>POSITIVE TERMINAL 980-10760</p> <p>OPEN OR CLOSE DIRECTION</p> </div>	Rated voltage	DC12V	Insulation	More than 10MΩ at 500V megger	<p style="text-align: right;">Figure 137</p>				
Rated voltage	DC12V									
Insulation	More than 10MΩ at 500V megger									
E - 35 Glow VI8970476041 Glow plug  YT05 - 15001 ~ LF05 - 04001 ~	<table border="1" data-bbox="435 1270 917 1428"> <tr> <td>Type</td> <td>QOS-III 24V</td> </tr> <tr> <td>Rated voltage</td> <td>23.0V</td> </tr> <tr> <td>Time to reach 800 °C※</td> <td>5sec</td> </tr> <tr> <td>Collor of finish</td> <td>Stem/Yellow, Insulator/Brack</td> </tr> </table> <p>※ When applying rated voltage at normal temperature</p> <div data-bbox="560 1491 1193 1638" style="text-align: center;"> <p>Insulator</p> </div>	Type	QOS-III 24V	Rated voltage	23.0V	Time to reach 800 °C※	5sec	Collor of finish	Stem/Yellow, Insulator/Brack	<p style="text-align: right;">Figure 138</p>
Type	QOS-III 24V									
Rated voltage	23.0V									
Time to reach 800 °C※	5sec									
Collor of finish	Stem/Yellow, Insulator/Brack									

SECTION 3 - SYSTEMS  
CHAPTER 4 - COMPONENTS SYSTEM

Code No. Parts Name Parts No. Use Applicable Machine	Specifications	Description
SE - 14		
Engine coolant thermo sensor		Mating connector YAZAKI No. 7323-2710
VI8970633010		
Engine coolant thermo sensor		
YT05 - 15001 ~ LF05 - 04001 ~		



Resistance

Temperature (°C)	-10	20	50
Resistance (kΩ)	10.0	2.5	0.785

GRAPHIC\_1D

Figure 157

SE - 15	Float operation													
Fuel sending unit														
YN52S00045F1														
Fuel level														
YN11 - 45001 ~ YQ11 - 06001 ~ YF05 - 02001 ~ YU05 - 02001 ~ YT05 - 15001 ~ LF05 - 04001 ~	<table border="1"> <thead> <tr> <th>Float</th> <th>Resistance Ω</th> </tr> </thead> <tbody> <tr> <td>FULL</td> <td>10<sup>+0.1</sup><sub>-0.6</sub></td> </tr> <tr> <td>3/4</td> <td>(19)</td> </tr> <tr> <td>1/2</td> <td>32±5</td> </tr> <tr> <td>1/4</td> <td>(49.5)</td> </tr> <tr> <td>EMPTY</td> <td>85<sup>+10</sup><sub>0</sub></td> </tr> </tbody> </table>	Float	Resistance Ω	FULL	10 <sup>+0.1</sup> <sub>-0.6</sub>	3/4	(19)	1/2	32±5	1/4	(49.5)	EMPTY	85 <sup>+10</sup> <sub>0</sub>	
Float	Resistance Ω													
FULL	10 <sup>+0.1</sup> <sub>-0.6</sub>													
3/4	(19)													
1/2	32±5													
1/4	(49.5)													
EMPTY	85 <sup>+10</sup> <sub>0</sub>													

GRAPHIC\_1D

Figure 158

SECTION 3 - SYSTEMS  
CHAPTER 5 - AIR CONDITIONING SYSTEM

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15090	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SECTION 3 - SYSTEMS  
CHAPTER 5 - AIR CONDITIONING SYSTEM



GRAPHIC\_1D

Figure 7

AIR CONDITIONER PIPING (2/2)

**DISASSEMBLY AND ASSEMBLY**

**Precautions To Be Exercised In Operation**

**1. Special Refrigerator Oil**

This air conditioner uses special refrigerator oil SP20 for use with new refrigerant R134a. Oils other than SP20 may not be used. Since SP20 tends to absorb moisture and may corrode paint and resin, the following points must be noted:

- A. Do not keep open all pipe connections on a new compressor and the component parts of the installed refrigeration circuit (Remove valves and caps at the pipe openings of the compressor, just before connecting pipes. If you have removed a pipe joint for repair, put a cap to both ports immediately.)
- B. Use care so SP20 does not adhere to the painted surface and resin parts. In case SP20 has adhered to such surfaces, wipe it off immediately.

2. The receiver dryer is filled with desiccant to absorb moisture in the circuit. Therefore, remove the valve at the pipe port immediately before connecting pipes.

**3. Tightening Torque**

**A. Pipe Joints**

When connecting pipe joints, coat the O-ring with special oil (SP20) and fasten to the tightening torque indicated in the table, using a double spanner.

**B. Screws and Bolts**

Fasten to the tightening torque indicated in the table

**4. Amount of Oil for Compressor**

The compressor SD7H (HD type) is filled with 135cc (8.2cu/in) of oil. If the oil volume is small, seizure at high revolution and shortening of service life will occur. If the oil volume is large, the cooling ability will be deteriorated.

Once the air conditioner is operated, part of the oil is dispersed in the refrigeration circuit. Therefore, when replacing the parts in right Table, adjust the oil level to that of table.

5. Before performing operation, stop the engine and turn off all power supplies to the equipment related to the air conditioner.

6. After the operation is over, confirm that all faults have been repaired completely, by operating the air conditioner.

Unit: Nm (pound-ft)	
Pipe Fastening Part	Tightening Torque
D hose and compressor (M8 bolt)	19.6-24.5 (14-18)
D hose and condenser	19.6-24.5 (14-18)
L hose and condenser	11.8-14.7 (8.7-11)
L hose and receiver dryer (M6 bolt)	7.8-11.8 (5.8-8.7)
L hose and air conditioner unit	11.8-14.7 (8.7-11)
S hose and air conditioner unit	29.4-34.3 (22-25)
Expansion valve	1.96-2.45 (1.4-1.8)

Unit: Nm (pound-ft)	
Screw Size	Tightening Torque
N4, T4 machine screw, M4	0.78-1.18 (0.58-0.87)
N5, T5 machine screw, M5	1.96-2.45 (1.4-1.8)
M6 (mounting part of L hose joint)	7.85-11.8 (5.8-8.7)
M6 (except mounting part of L hose joint)	9.8-11.8 (7.2-8.7)
M8 (mounting part of S,D hose joints)	19.6-24.5 (14-18)
M8 (mounting part of A/C unit)	9.8-11.8 (7.2-8.7)
M8 ( other than those mentioned above)	11.8-15.7 (8.7-12)
M10	39.2-53.9 (29-40)

Replaced Parts	Amount To Be Filled In
Evaporator	40 cc (2.4 cu/in)
Condenser	40 cc (2.4 cu/in)
Compressor	Drain out the volume of oil left in the compressor to be replaced, from the new compressor.
Receiver dryer	20 cc (1.2 cu/in)
Hoses	20 cc (1.2 cu/in)

(5) Removing Gauge Manifold


When the refrigerant level has been checked, disconnect the charging hoses from the compressor in the following manner :

1. Press the "L" shape metal fitting of the charging hose (blue) on the low pressure side against the service valve of the compressor so the refrigerant does not leak out and loosen the nut. As soon as the nut has been removed, disconnect the charging hose from the service valve.
2. Leave the high pressure side as it is till the high pressure gauge reading falls. [below 1MPa (140psi)].
3. Disconnect the charge hose (red) on the high pressure side the same way as on the low pressure side.


SECTION 3 - SYSTEMS  
CHAPTER 5 - AIR CONDITIONING SYSTEM

Blower motor speed does not change.

CASE (1)



CASE (2)



## SECTION 4 - DISASSEMBLY AND ASSEMBLY

---

---


CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15100	

1. Removing bucket drive pin (J)

Put bucket on the ground, position it so that the bucket drive pin (J) is not loaded, adjust bucket link, and pull out pin (J).



GRAPHIC\_ID

Figure 5

**Attaching Bucket**

1. Attaching bucket drive pin (J)

Attach bucket drive pin (J) first, then continue in the reverse procedure of the pulling out.




**WARNING**

**When aligning the pin holes, do not put your finger in the pin holes in any circumstances, but align them visually.**

**NOTE:** Check that the seals are not scored and replace a faulty one if necessary.

**NOTE:** When inserting the pin, coat the shaft with grease.



GRAPHIC\_ID

Figure 6

## SWING

### Removal of Swing Bracket and Cylinder

Preparation for removal


1. To make the removing work easy, swing by around 30° for leftward.
2. Remove cover (D1) then disconnect the hoses of bucket cylinder, arm cylinder and boom cylinder, and apply plugs to all the openings.

### Removal of Swing Bracket (A9)

1. Removing the capscrew (C5) that is preventing the rod pin (C1) of swing cylinder (C) from coming out, remove the pin (C1).
2. Install the boom foot pin (D) to the original position on swing bracket (A1), then temporarily lift it up.
3. Removing two capscrews (E3) those are preventing the pin (E1) (E2) from coming out, remove the pin (E1) (E2).
4. Remove the swing bracket (A1).  
Weight of swing bracket : 245kg (540 lb)

### Removal of Swing Cylinder (C)

1. Disconnect 2 connecting hoses for the swing cylinder.
2. Removing the capscrew (C5) that is preventing the head side pin (C2) of swing cylinder from coming out, remove the pin (C2).
3. Take out the swing cylinder (C) from the machine front side.  
Weight of swing cylinder : 70kg (154 lb)



GRAPHIC\_1D


Figure 33

### Removing Rod Cover Assembly

Remove rod cover assy from piston rod (2). If it is too difficult to remove, strike flange section of rod cover (3) with plastic hammer.

Hang the rod cover assy with crane and remove it straight horizontally.

**NOTE:** Care should be taken not to damage the bushing (4) lip section of link and seal with screw of piston rod (2) when pulling out rod cover (3).



GRAPHIC\_ID


Figure 52

### Disassembling Rod Cover Assembly

#### 1. Removing buffer ring

1) Buffer ring (6) (Teflon made seal) is fitted on the inside of rod cover (3). Pierce with pointed tool on the seal, raise it, insert spatula and take it out.

**IMPORTANT:** Do not reuse the removed seal.



GRAPHIC\_ID

Figure 53


#### 2. Removing U-ring (7) and wiper ring (8)

1) Remove U-ring (7) with driver, etc.

2) The wiper ring (8) is press-fitted.

Pierce with driver, etc. on rubber and strike and remove it with driver.

**IMPORTANT:** Do not reuse the removed seal.




GRAPHIC\_ID

Figure 54

**Tightening Torque**

(1)Piston nut

Cylinder name	Opposing flat A	Tightening torque Nm (pound-ft)
Boom	80 mm	3000 (2210)
Arm	75 mm	3000 (2210)
Bucket	60 mm	1420 (1050)
Dozer	80 mm	5100 (3360)
Swing	75 mm	2510 (1850)




GRAPHIC\_ID

Figure 75

(2)Setscrew

Cylinder name	Opposing flat	Tightening torque Nm (pound-ft)
Boom	6 mm	56.9 (42)
Arm	5 mm	31.5 ( 23)
Bucket	4 mm	16.2 (12)
Dozer	-	-
Swing	5 mm	31.5 (23)




GRAPHIC\_ID

Figure 76

(3)Rod cover

Cylinder name	Tightening torque Nm (pound-ft)
Boom	834 (615)
Arm	570 ( 420)
Bucket	450 (330)
Dozer	1360 (1003)
Swing	736 (540)




GRAPHIC\_ID

Figure 77

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 1 - ATTACHMENTS

Items	Phenomenon	Related parts	Abnormalities	Measures and corrective actions
4	The operation is unstable.	Air	Air is remained in cylinder.	1) Remove air. a) If cylinder is not equipped with air bleed port ; Release air by extending and retracting it at low speed several times. b) If cylinder is equipped with air bleed port ; Unload so that the internal pressure is not raised, loosen air breather and release air completely. (Reference) When cylinder has stopped in an emergency, cylinder may be extended and contracted slightly. This phenomenon is caused by the pressure of hydraulic oil, and easily occurs on the cylinder of which the stroke is longer.
	Great shock when changed from / to extension to / from retraction.	Pin bushing Pin	The space between fitting section and pin bushing is too large.	1) Measure dimension of pin and pin bushing, if it exceeds the specified dimension, replace it with new one.
	Noise when cylinder is worked.	Lubrication	Insufficient lubrication	1) Lubricate.
		Pin bushing Pin	Scuffing on engaged section	1) Replace it with new one, and lubricate.
	<b>Hydraulic oil is expanded and contracted with change of temperature and pressure. Consequently the cylinder is also extended and retracted, so care must be taken in order not to mistake this for internal leakage. Check it for internal oil leakage in the constant temperature and pressure conditions.</b>			



GRAPHIC\_ID

Figure 5

6. Remove cab attaching bolt

5 capscrews (A1) M12×65 (Mark ■) and 1 cap screw (A3) M12×30. (Mark ▲)

7. Slings cab


A. Remove two plastic plugs at the front of the ceiling of the cab. Then place a wire sling with eye rings and a hook around the cab, as shown in Fig 7.

B. Then lift up slowly avoiding interference with surroundings.

Wire with hook ;

Length 1.5m (4ft 11in)×Dia. 8mm (0.315in)×3pcs.

Weight of cab ; Approx. 250kg (550 lbs)




GRAPHIC\_ID

Figure 6

**Installation**

Install it in reverse order of removing according to the Tightening torque Table.

Tightening position	Allen wrench Hex (mm)	Tightening torque Nm (pound-ft)
Capscrew (A1)(A3)	19	80 (66)
Sems bolt M6 (A39)(A40)	Torx driver (T30)	8.5 (6.3)
Sems bolt M6 (A22)(A23)	Plus driver	5.0 (3.7)




GRAPHIC\_ID

Figure 7

## HYDRAULIC TANK

### Preparation for Removal

1. Swinging upper structure 45 degrees.  
Swing upper structure to make the removal of suction hose for pump installed under tank easier.
2. Necessary to remove the hydraulic oil tank.




GRAPHIC\_ID

Figure 26

3. Bleeding internal air of tank  
Press cap by finger to bleed internal air.


**IMPORTANT:** *Keep pressing until the hissing sound stops.*



GRAPHIC\_ID

Figure 27

4. Remove cover (B1)
  - A. Remove 6 sems bolts (B10) M10×25.
  - B. Remove cover (B1).
  - C. Remove suction strainer (B4).
5. Remove cover (B2)
  - A. Remove 6 sems bolts (B10) M10×25.
  - B. Remove cover (B2).
  - C. Remove filter element (B7).
6. Turn the handle of element assy (B7), and disassemble the removed filter element (B7).
7. Draining hydraulic oil  
Place pump in tank and draw up hydraulic oil.  
Capacity of tank : 72 L (19gal)




GRAPHIC\_ID

Figure 28

## COUNTERWEIGHT

### Preparation for Removal

1. Removing hood assy (3-2).  
Remove hood on engine.
2. Removing hood assy (3-1).
3. Preparing slinging jig  
Remove plug (A6), and attach weight slinging jig  
(See Chapter Tools.) to counterweight.




GRAPHIC\_ID

Figure 49

### Removal

1. Lifting up counterweight temporarily  
Hook wire rope to slinging jig, and lift it and stretch wire rope to the degree where it is providing no slack temporarily.  
Weight of counterweight : Approx. 840 kg (1850 lbs)  
Wire more than  $\varnothing 10$  (0.394 in) : 1.5 m (4 ft 11 in)  $\times$  2 pcs.
2. Removing counterweight
  - A. Remove 3 capscrews (A1) M20  $\times$  135.
  - B. Remove shim.



GRAPHIC\_ID

Figure 50

### Installation

1. Install counterweight in the reverse procedure of removing.
2. Install shim as it was
3. Slinging counterweight  
Check that 3 attaching bolts can be screwed in by hand.
4. Apply Loctite #262 on capscrews (A1), and tighten them with washers (A2).  
Tightening torque : 490 Nm (361 pound-ft)
5. Remove slinging tools, and attach plugs (A6).



GRAPHIC\_ID

Figure 51

**CONTROL VALVE**

**Preparation for Removing**

1. Remove panel assy (2-1) (See Fig. 12)
2. Remove cover assy (2-5) (See Fig. 13)
3. Release air in hydraulic oil tank, open cover of suction element of hydraulic oil, and lower the level. (See Fig. 35)


**Removal**

1. Removing hoses for each piping  
Attach tag on hose, and write port name on it, then remove hoses.

Ports	Functions	Ports on right sides (on machine)	Ports	Functions
A8	Option (Head)		B8	Option (Rod)
A7	Arm out		B7	Arm in
A6	Bucket dump		B6	Bucket digging
A5	Boom down		B5	Boom up
A4	Dozer down		B4	Dozer up
A3	Travel left (Forward)		B3	Travel left (Reverse)
A2	Travel right(Forward)		B2	Travel right (Reverse)
A1	Swing (Right)		B1	Swing (Left)
Ports	Functions	Ports on rear sides (on machine)	Ports	Functions
Pr	Back press. Compensaton		a8	Option (Head)
			a7	Arm out
			a6	Bucket dump
			a5	Boom down
			a4	Dozer down
			a3	Travel left
			a2	Travel right
		a1	Swing (Right)	
		Ps	LS press. detection	

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 2 - UPPER STRUCTURE

3. Removing upper frame attaching bolts  
Remove 23 capscrews (B31) M16×85 and a reamer bolt (B30) used to install swing bearing and upper frame.
4. Slings upper frame  
Sling according to Fig. 78, and remove upper frame and put it on a stand.  
Weight : Approx. 5 ton (11,000lbs)



GRAPHIC\_ID

Figure 80

**Installation**


1. Installing is done in the reverse order of removing.
2. Cleaning mating surfaces of upper frame and swing bearing.
3. Applying Loctite #515 on mating surface.
4. Slings upper frame  
Match marks and install it with three reamer bolts temporarily.

**NOTE:** Confirm the reamer bolt positions referring to Fig. 82.

24 mm; Apply Loctite #262  
Tightening torque : 157 Nm (120 pound-ft)


5. Install swing bearing  
Install 23 capscrews (B31) M16×85.  
24 mm; Apply Loctite #262  
Tightening torque : 157 Nm (116 pound-ft)

Install a reamer bolt (B30).  
24 mm,  
Tightening torque : 157 Nm (116 pound-ft)



GRAPHIC\_ID

Figure 81




GRAPHIC\_ID

Figure 82

C. Installing of piston assembly

Install return plate (9), which is installed spring (57), retainer SPH (17), and piston assembly (10), into cylinder (11).

**ATTENTION:** Refer to matchmark, which is put on the side faces of return plate (9) and cylinder (11) prior to disassemble it, install piston assembly (10) to the original hole.




GRAPHIC\_ID

Figure 101

D. Installing of cradles

Install cradles (7) (16) into housing (4), and tighten them to the specified torque 5.9 Nm (4.4 pound-ft) with socket head screw (6) (Opposing flats 3).

**NOTE:** Tighten socket head screw (6) temporarily to position cradles (7) and (16) in parallel. And apply hydraulic oil to cradles (7) and (16), place cam (8) on them, and get the smooth movement of cradles by tilting several times. Then remove cam (8) once and tighten socket head screw (6) to specified torque.



GRAPHIC\_ID


Figure 102

E. Installing shaft

Apply hydraulic oil to port plate (12) (sliding surface with cylinder (11)) which is installed by the procedure shown in Item (B). And place the port plate on cylinder (11) which is installed by the procedure shown in Item (C). Apply hydraulic oil to the shoe sliding surface of piston assembly (10) and place cam (8) on the shoe sliding surface.

Install shaft (1) so as to connect to the spline of cylinder (11).

Install power piston assembly (41) on cover (64) and install rod PW (35) on power piston assembly (41).



GRAPHIC\_ID

Figure 103

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 2 - UPPER STRUCTURE

**Maintenance Standard**


After disassembly of pump, if any remarkable damage was found on any part or the wear of each sliding part is more than the standard value, replace the parts with new ones.

Table 1				
Parts	Inspection and Measurement location	Standard (Service limit)	Measuring Instrument	Corrective action
Piston assembly (10)	Roughness of shoe sliding surface	0.8 S	Surface roughness meter	Correct by paper lapping
	Flaw depth of shoe sliding surface	0.4mm (0.016in) or less	Micrometer	Replace with a new one
	Looseness of connection part between caulked piston and shoe	0.4mm (0.016in) or less	Dial gauge	Replace with a new one
	Outer diameter of piston	Hardly worn out. In case of flaw or seize, replace it with new one.		
Cam (8)	Roughness of surface	0.8 S	Surface roughness meter	Lapping
Cylinder (11)	Roughness of end surface	0.4 S	Surface roughness meter	Lapping
	Piston bore	Hardly worn out. In case of flaw or seize, replace it with new one.		
Port plate (12)	Roughness of surface	0.8 S	Surface roughness meter	Lapping
Piston assembly (10) Cylinder (11)	Gap between piston outer diameter and piston bore	0.04mm (0.0016in) or less	Micrometer Pneumatic Micrometer	Replace with a new one

Table 2	
Parts	Inspection and Maintenance Standard
Taper roller bearing (5) Needle bearing (20)	If flaking on inner and outer race is found, replace the bearing with a new one. After disassembling replace the bearing with a new one, and reassemble it.
Oil seal (2)	If flaw on lip is found, replace the oil seal with a new one. After disassembling replace the oil seal with a new one, and reassemble it.
O-ring (18),(21),(26),(41),(43),(54),(64),(73)	If flaw on O-ring is found, replace the O-ring with a new one. After disassembling replace the O-ring with a new one, and reassemble it.

8. Disassembling of flow control valve

- A. Loosen cap (2) and remove it as an assembly.  
Tightening torque : 100 Nm (74 pound-ft)
- B. Remove cap (1), and remove spring retainer (3), spring (4), spring retainer (5) and spool (6).  
Tightening torque : 60 Nm (44 pound-ft)




GRAPHIC\_ID

Figure 144

**NOTE:** When the cap (1) is removed, spring reacts with the force of 90 N (20.2 lbs) to 100 N (22.5 lbs). Hold down the cap to prevent the parts jumping out, and remove every part.

Do not disassemble the cap (8) because it was caulked.




GRAPHIC\_ID

Figure 145

9. Disassembling of slow return check valve


- A. Loosen cap (1) and remove filter retainer (4) and filter (5).  
Tightening torque : 30 Nm (22 pound-ft)

**NOTE:** Direct the large rounded corner of the filter to the cap.



GRAPHIC\_ID


Figure 146



GRAPHIC\_ID

Figure 168

5. Install Jig A



GRAPHIC\_ID

Figure 169


Turn joint (301) in counterclockwise with Jig A to remove.

Jig A : See Jig in this section.

: 24mm

**WARNING:** When the force of return springs (221) is strong, never loosen joint (301). If loosened, it might result in jumping out of plate (151), plug (211) and push rod (212).

Remove joint (301) pressing plate (151) downward with two fingers.




GRAPHIC\_ID

Figure 170

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 2 - UPPER STRUCTURE

PILOT VALVE (TRAVEL)

Construction




GRAPHIC\_1D

Figure 189

Torque Nm (pound-ft)	No.	Name	Qty	Torque Nm (pound-ft)	No.	Name	Qty
	101	CASING	1	29.4 (22)	251	RO PLUG	3
	102	CASING (DAMPER)	1	6.9 (5.1)	252	PLUG	6
	191	SEAT 1	2		253	RO PLUG	2
	192	SEAT 2	2		261	O-RING	3
	193	BUSHING 2	2		263	O-RING	2
	194	STEEL BALL	2	8.8 (6.5)	271	SOCKET BOLT	4
	201	COVER	2		301	SPOOL	4
	202	PLUG	4		311	SPRING SEAT	4
	203	GREASE CUP	4		313	WASHER	4
	210	PACKING	4		324	SPRING	4
	211	O-RING	4		335	SPRING	4
	212	O-RING	4		336	SPRING	4
	213	O-RING	2		413	CAM SHAFT	2
	214	PUSH ROD	4		414	BUSHING	4
	217	SHIM	4		420	CAM	2
	218	SPRING SEAT	4	6.9 (5.1)	471	STEEL BALL	4
	224	PISTON	4		472	SET SCREW	2
	225	STEEL BALL	12		501	BELLOWS (BOOTS)	2

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 2 - UPPER STRUCTURE

5. Lift up and remove cover (39).




GRAPHIC\_ID

Figure 199

6. Remove snap ring (5) with plier.


7. Remove inner race of needle bearing (6).



GRAPHIC\_ID

Figure 200

8. Remove the O-ring (9).



GRAPHIC\_ID


Figure 201

6. Installing the ring gear (10).

Degrease the mating surface between the gear case (5) and the ring gear (10) and the pin (9).


Apply liquid packing (Three Bond #1215, gray) to the area of the gear case (5) inside the bolt circle, and install the ring gear (10) on the gear case (5).

Apply sealant equally so that the thickness projecting from nozzle is about 1.5 mm (0.06 in) in diameter.



GRAPHIC\_ID

Figure 225




GRAPHIC\_ID

Figure 226

7. Installing the holder 2 assy (15)

A. Install the needle bearing (16) in spur gear 5 (18). Install this assy together with the thrust plate 2 (19) into holder 2 (21), and insert the shaft 2 (17) into the spur gear.

Apply hydraulic oil to the inside diameter of spur gear 5 (18), needle bearing (16) and the outside diameter of the shaft 2 (17).




GRAPHIC\_ID


Figure 227

B. Drive the spring pin (20)

**NOTE:** Drive spring pin facing the split to gear side.



GRAPHIC\_ID



GRAPHIC\_ID

Figure 228


SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 2 - UPPER STRUCTURE

**Troubleshooting**

<b>Table 3</b>		
Trouble	Cause	Remedy
1. External leakage of hydraulic oil	Defective O-ring	Replace all seals.
2. Internal leakage of hydraulic oil	1) Defective slipper seal 2) Sliding face worn excessively	1) Replace all seals. 2) Replace assy.
3. Swivel joint seized	1) Stem and body seized  2) Setting failure of swivel stopper bracket	1) Grind and hone. Replace assy, if stem and body are too loose and causing oil leakage.  2) Reinstall Secure 2~3 mm (0.08~0.12 in) allowance for bolt stopper.
4. Loose swivel stem and cover	Socket bolt tightened insufficiently.	Retighten to specified torque.

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
CHAPTER 3 - TRAVEL SYSTEM

Maintenance Standard



GRAPHIC\_1D

Figure 11

Unit : mm (in)							
No.	ITEM	STANDARD VALUE		REPAIRABLE LEVEL	SERVICE LIMIT	REMEDY	
A	Link pitch	155.6±0.1(6.126±0.0039)		160 (6.30)	164 (6.46)	Replace the link assy if the service limit is exceeded.	
B	O.D. of bushing	Ø41 <sup>+0.214</sup> <sub>+0.174</sub> (1.6142 <sup>+0.0084</sup> <sub>+0.0069</sub> )		Ø37 (1.46)	Ø36 (1.42)		
C	Height of link	75±0.15 (2.9528±0.0059)		69 (2.72)	67 (2.64)		
D	Interference between bushing and link	Basic dimension	Tolerance		Fit	Fit	Replace
		Ø41 (1.6142)	Shaft	+0.214 (+0.0084) +0.174 (+0.0069)	Interference 0.05 (0.0020)	Interference 0	
E	Interference between track pin and link	Ø24 (0.9449)	Shaft	+0.15 (+0.008) 0 (0)	Interference 0.05 (0.0020)	Interference 0	
F	Interference between master pin and link	Ø24 (0.9449)	Shaft	-0.05 (-0.0020) -0.08 (-0.0032)	Interference 0.05 (0.0020)	Interference 0	Replace Link
G	Clearance between links (both sides)	1.6 (0.06)		8 (0.32)	10 (0.39)	Replace	
H	STD shoe plate	26 (1.02)		15 (0.59)	13 (0.51)	Replace	
I	Tightening torque of shoe bolt	294 Nm (220 pound-ft)				Retighten	

Tools and Jigs


No.	JIGS	SHAPE
a	Master pin fixing jig	

GRAPHIC\_ID

8. Removing bushing (3)

Since thickness of bushing (3) is thin, remove it through lathe or strip it with care not damage inner hole of roller. When the wear of bushing is not large, place upper roller (1) on jig (m) for repair stand and apply the end of push-out jig on the end face of bushing (3) end, and push it out striking it with mallet.

**NOTE:** Hammer the inside surface of roller lightly so as not to damage the surface. Put the extrusion jig (n) uniformly over the circumference of bushing (3) and extrude it little by little.




GRAPHIC\_ID

Figure 37

Installing

1. Attach O-ring (6) to one side  
 Install O-ring (6) to shaft groove.  
 Apply grease to O-ring.  
 Replace O-ring with new one.



GRAPHIC\_ID


Figure 38

2. Press fitting bushing (3)

Align inner hole of roller (1) and bushing (3) and press fit it vertically in capacity of press fit load, 3600kg (7940 lbs), in the condition that bushing push-in jig (g) is inserted into bushing (3).

Apply molybdenum disulfide grease on press-fit section of bushing, and press-fit it in ordinary temperature.

Bushing which fails to press-fit because of the one-side pressing should not be fitted.



GRAPHIC\_ID

Figure 39

SECTION 4 - DISASSEMBLY AND ASSEMBLY  
 CHAPTER 3 - TRAVEL SYSTEM


**Tools and Jigs**

Unit : mm (in)		
No.	JIGS	SHAPE
R	Pin striking jig	<p>Ø15 (0.591")              105 (4.13")              15 (0.591")              1.18"              Ø30</p> <p>GRAPHIC_ID</p>
S	Shaft push out jig	<p>250 (9.84")              1.81"              Ø46</p> <p>GRAPHIC_ID</p>
T	Bushing drawing rod	<p>200 (7.87")              0.630"              Ø16</p> <p>GRAPHIC_ID</p>
U	Repair stand	<p>About 400 (15.7")              About 80 (3.15")              About 250 (9.84")              2 pcs</p> <p>GRAPHIC_ID</p>
V	Bushing Press fitting jig	<p>Ø70 (2.76")              10 (0.394")              54 (2.13")              44 (1.73")              Ø49.6<sup>+0.1</sup><sub>0</sub>              (1.953<sup>+0.004</sup><sub>0</sub>)</p> <p>GRAPHIC_ID</p>

7. Slings travel motor assy

Sling travel motor with nylon sling applied on the the side close to sprocket installing section and remove the motor.

Weight of motor Approx. 90 kg (198 lbs)



GRAPHIC\_ID

Figure 80

**Installing**

Installing of the travel motor piping is performed in the reverse order of removal.

1. Cleaning  
Check that contact surface of travel motor and track frame is free from burr and stain.
2. Tightening torque  
Tighten capscrew and hydraulic pipes to the specified torque.
3. Fill inside from motor drain port to cashing with hydraulic oil before piping for drain. When starting operation, operate motor in low idling and at low speed for several minutes, and check it for possible oil leakage and noise.


Parts	Size	Tools	No.	Tightening Torque Nm(pound-ft)	Remarks
Capscrew	M14	22	3	181 (134)	Apply loctite #262
	M16	24	2	279 (210)	Apply loctite #262
Flareless nut for pipes, sleeve	Ø10 X 1.5	19	—	49 (36)	
	Ø15 X 2.0	27	—	118 (87)	
	Ø18 X 2.5	32	—	147 (110)	
Connector	PF1/4	19	PP	36.3 (27)	
	PF3/8	22	T1,T2	73.6 (54)	
	PF1/2	27	P1,P2	108 (80)	

### Disassembly

1. Clean the outside surface of travel unit prior to disassembly. Be sure to attach the parts to the original positions.

For this purpose, we strongly recommend to record the original positions of parts before and during disassembling.

2. Remove the drain plug and drain lubricating oil. The travel unit oil capacity is 1.35L. Place the travel unit on flat and clean ground.



GRAPHIC\_ID

Figure 95

3. Remove the relief valves (1) on both sides.


**NOTE:** Remove the relief valve (1) first, and the removal of 8 bolts (2) and the motor cover (3) becomes easier.



GRAPHIC\_ID

Figure 96


27. Remove the cam (43) from the body casing.



GRAPHIC\_ID

Figure 119

28. Remove the 2 steel balls (44) and piston (45) from the body casing. And remove the spring (46) which is located under the piston.



GRAPHIC\_ID

Figure 120

8. Using the "Jig for floating seal fitting", install the other floating seal (70) in the body casing. Apply SAE30 engine oil or gear oil 80W-90 to the contact surface (flat surface) of the seal ring (metal).

**IMPORTANT:** Clean and dry O-ring (rubber) and seal ring (metal) before attaching the floating seal. Apply SAE30 engine oil or gear oil 80W-90 to the contact surface of the seal ring.

When joining 2 parts, use caution to prevent damage like scratch and so on to the floating seal.



GRAPHIC\_ID

Figure 144

9. Lift the gear casing (50) on the body casing (73) by means of a crane as shown in the figure. Install the gear casing to the body casing (73).


**NOTE:** With the ring gear placed on the body casing, there is a space left between them. This space is not a problem because it is caused by the action of a floating seal. This space is eliminated by attaching ring nut (68).



GRAPHIC\_ID

Figure 145


37. Turn the motor cover over. Install the valve plate (22) in the original position.  
Apply the appropriate amount of hydraulic oil to the surface of the valve.



GRAPHIC\_ID

Figure 173


38. Apply grease to the 10 holes of the motor cover.  
Install the springs (76) into the holes.  
To prevent the springs (76) from falling from holes, the grease was applied.



GRAPHIC\_ID

Figure 174

39. Place the motor cover (3) on the body casing.  
Check if the springs (76) are not fallen.  
Tighten 8 bolts (2) to install the motor cover.  
Tighten the bolts (2) to the specified torque 129.4Nm (95.4 pound-ft).



GRAPHIC\_ID

Figure 175

SECTION 5 - TROUBLESHOOTING  
CHAPTER 1 - TROUBLESHOOTING BY ERROR CODES

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15150	

SECTION 5 - TROUBLESHOOTING  
CHAPTER 1 - TROUBLESHOOTING BY ERROR CODES

**Table 7**

Error code	B012		
Trouble	Boom up pressure sensor outputs error		
Judging condition	After starter switch ON and engine does not start yet. And the input voltage from the sensor after starter switch ON is in the range of 1.4V or more to less than 4.7V.		
Symptom	In case that auto acceleration is turned ON, even when control lever was shifted to neutral, engine speed does not slow down.		
Control in the event of failure	Normal control		
Returned in normal condition	Not returned automatically under normal condition. Switch the power OFF once and turns on it again.		
Service diagnosis checking screen	Screen No.	5	B-1 BOOM RAISE
	Screen No.		
	Screen No.		
Checking object	Checking contents and remedy		
1	• Boom up pressure sensor SE-3	When B012 is cancelled and other error occurs by turning starter switch on after exchanging the connector with other sensor. Check sensor unit for possible failure. If failure found, replace it.	
2	• Wiring between boom up pressure sensor and controller CN-126F CN-101F	When B012 is displayed after turning the starter switch on after the connector is exchanged with other sensor. Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	• Mechatro controller	Check that the error is corrected after replacement of controller.	

**Table 8**

Error code	B013		
Trouble	Boom up pressure sensor's wiring disconnects.		
Judging condition	The input voltage from boom up pressure sensor is less than 0.1V.		
Symptom	In case that auto acceleration is turned ON, even when control lever was shifted, engine speed does not rise.		
Control in the event of failure	Normal control		
Returned in normal condition	It returns automatically in normal condition.		
Service diagnosis checking screen	Screen No.	5	B-1 BOOM RAISE
	Screen No.		
	Screen No.		
Checking object	Checking contents and remedy		
1	• Boom up pressure sensor SE-3	When B013 is cancelled and other error occurs after exchanging the connector with other sensor. Check sensor unit for possible failure. If failure found, replace it.	
2	• Wiring between boom up pressure sensor and controller CN-126F CN-101F	When B013 is displayed after the connector is exchanged with other sensor. Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	• Mechatro controller	Check that the error is corrected after replacement of controller.	

SECTION 5 - TROUBLESHOOTING  
CHAPTER 1 - TROUBLESHOOTING BY ERROR CODES

**Table 27**

Error code	B074		
Trouble	Swing pressure sensor's power source is shortcut.		
Judging condition	The input voltage from swing pressure sensor is 4.7V or more.		
Symptom	All operation speed slows down.		
Control in the event of failure	Set proportional valve output rate of P1 and P2 pumps to constant current. (Current value in all operation is neutral.) Set output of P1 unload proportional valve to 0mA. (Valve emergency mode)		
Returned in normal condition	It returns automatically in normal condition.		
Service diagnosis checking screen	Screen No.	6	B-7 SWING
	Screen No.		
	Screen No.		
Checking object	Checking contents and remedy		
1	Swing pressure sensor SE-5	When B074 is cancelled and other error occurs by turning starter switch on after exchanging the connector with other sensor. Check sensor unit for possible failure. If failure found, replace it.	
2	Wiring between swing pressure sensor and controller CN-126F CN-103F	When B074 is displayed after turning the starter switch on after the connector is exchanged with other sensor. Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	Mechatro controller	Check that the error is corrected after replacement of controller.	

**Table 28**

Error code	B082		
Trouble	Swing left pressure sensor outputs error		
Judging condition	After starter switch ON and engine does not start yet. And the input voltage from the swing left pressure sensor after starter switch ON is in the range of 1.4V or more to less than 4.7V.		
Symptom	Swing parking brake does not work.		
Control in the event of failure	Swing parking solenoid valve is changed to non-excitation.		
Returned in normal condition	Not returned automatically under normal condition. Switch the power OFF once and turns on it again.		
Service diagnosis checking screen	Screen No.	6	B-7 SWING (Higher Pressure is selected between swing left and right, and the higher one is indicated.)
	Screen No.		
	Screen No.		
Checking object	Checking contents and remedy		
1	Swing left pressure sensor SE-41	When B082 is cancelled and other error occurs by turning starter switch on after exchanging the connector with other sensor. Check sensor unit for possible failure. If failure found, replace it.	
2	Wiring between swing left pressure sensor and controller CN-127F CN-101F	When B082 is displayed after turning the starter switch on after the connector is exchanged with other sensor.  Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	Mechatro controller	Check that the error is corrected after replacement of controller.	

SECTION 5 - TROUBLESHOOTING  
CHAPTER 1 - TROUBLESHOOTING BY ERROR CODES

**Table 47**

Error code	H081		
Trouble	Grounding of coolant temperature sensor is short-circuited.		
Judging condition	The input voltage from coolant temperature sensor is 0.1V or less.		
Symptom	The water temperature is fixed to 20 °C.		
Control in the event of failure	Normal control		
Returned in normal condition	It returns automatically in normal condition.		
Service diagnosis checking screen	Screen No.	2	G-5 The lower side of water temperature meter on gauge cluster is fixed.
	Screen No.		
	Screen No.		
Checking object		Checking contents and remedy	
1	• Coolant temperature sensor SE-14	Measure the resistance between terminals. 20 °C 10 Ω~ 878 Ω	
2	• Wiring between coolant temperature sensor and controller F-4 CN-104	Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	• Mechatro controller	Check that the error is corrected after replacement of controller.	

**Table 48**

Error code	H091		
Trouble	Fuel sensor grounding is short-circuited.		
Judging condition	The input voltage from fuel sensor is 0.1V or less.		
Symptom	Warning for low fuel level is indicated.		
Control in the event of failure	Fuel level becomes 0%.		
Returned in normal condition	It returns automatically in normal condition.		
Service diagnosis checking screen	Screen No.	10	H-9 FUEL LEVEL
	Screen No.		
	Screen No.		
Checking object		Checking contents and remedy	
1	• Fuel sensor potentiometer SE-15	Move fuel sensor and measure the resistance between terminals of fuel sensor. EMPTY 95Ω ~ FULL 5Ω	
2	• Wiring between fuel sensor and controller CN-152F CN-104F	Check wiring for possible failure according to the wiring checking procedure and repair it if necessary.	
3	• Mechatro controller	Check that the error is corrected after replacement of controller.	

SECTION 5 - TROUBLESHOOTING  
CHAPTER 2 - TROUBLESHOOTING BY TROUBLE

---

---

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History				
Issue	Issue Date	Applicable Machines	Form Number	Remarks
First Edition	07-2008	E80B	5-15160	

SECTION 5 - TROUBLESHOOTING  
CHAPTER 2 - TROUBLESHOOTING BY TROUBLE

10. Bucket digging is slow

No.	Sections	Contents/normal value		Corrective action, others
1	Bucket digging pressure sensor	Carry out service diagnosis	•See Service Diagnosis Data List Operation No.12 bucket digging full lever and relief	Check and replace pressure sensor Check remote control valve
2	Pilot proportional secondary pressure	Measure directly remote control pressure of bucket digging (b port)	Check that pressure is 3.0MPa or more in bucket digging full lever and high idling operation	Check remote control valve When equipped with multi control valve, check it while changing lever pattern
3	Remote control valve	Check targeted remote control valve	Check that spool is free from abnormal damage and Spring is free from breakage.	Replace
4	Main relief valve <Trouble> Relief pressure is low.	Check set pressure of pump from Pd1 port	Operation : Boom up full lever and relief 26MPa or more	Replace
5	Bucket spool <Trouble> Pump pressure is high.	Visual check	When removing, free from abnormal resistance against sliding. Free from abnormal damage on outside of spool Spring is free from breakage.	Replace (Check on the casing for damage)
6	Over load relief valve	Check targeted spool visually	Free from dust entered in over load relief valve. Seat is free from abnormality.	Replace
7	Check valve for bucket recirculation	Visual check	Free from abnormal resistance against sliding. Spring is free from breakage.	Replace
8	Pressure compensation valve for bucket	Visual check	Free from abnormal resistance against sliding. Spring is free from breakage.	Replace (Check on the casing for damage)

11. Bucket dump is slow

No.	Sections	Contents/normal value		Corrective action, others
1	Bucket dump pressure sensor	Carry out service diagnosis	•See Service Diagnosis Data List Operation No.14 bucket dump full lever and relief	Check and replace pressure sensor Check remote control valve
2	Pilot proportional secondary pressure	Measure directly remote control pressure of bucket dump	Check that pressure is 3.0 MPa or more in bucket dump full lever and high idling operation	Check remote control valve When equipped with multi control valve, check it while changing lever pattern
3	Remote control valve	Check targeted remote control valve	Check that spool is free from abnormal damage and Spring is free from breakage.	Replace
4	Main relief valve <Trouble> Relief pressure is low.	Check set pressure of pump from Pd1 port	Operation : Boom up full lever and relief 26MPa or more	Replace
5	Bucket spool <Trouble> Both P1, P2 pressures are high.	Visual check	When removing, free from abnormal resistance against sliding. Free from abnormal damage on outside of spool Spring is free from breakage.	Replace (Check on the casing for damage)
6	Over load relief valve	Check targeted spool visually	Free from dust entered in over load relief valve. Seat is free from abnormality.	Replace

SECTION 5 - TROUBLESHOOTING  
CHAPTER 2 - TROUBLESHOOTING BY TROUBLE

27. Slow boom swing left

No.	Sections	Contents/normal value		Corrective action, others
1	Boom swing left pressure sensor	Carry out service diagnosis	•See Service Diagnosis Data List Operation No.16 boom swing left full lever and relief	Check and replace pressure sensor Check remote control valve
2	Pilot proportional secondary pressure	Measure directly pilot proportional secondary pressure of boom swing left (a9 port)	Check that pressure is 3.0 MPa or more in boom swing left full lever and high idling operation.	Check remote control valve.
3	Remote control valve	Check targeted remote control valve	Check that spool is free from abnormal damage and spring is free from breakage.	Replace
4	Lock valve poppet <Trouble> Pump pressure is high	Visual check	When removing, free from abnormal resistance against sliding. Free from abnormal damage on outside of poppet.	Replace (Check on the casing for damage)
5	Relief pressure	Check set pressure	Operation : Relief pressure is 26.0 MPa or more at boom swing left full lever	Reset or replace
6	Boom swing spool <Trouble> Pump pressure is high	Visual check	When removing, free from abnormal resistance against sliding. Free from abnormal damage on outside of spool. Spring is free from breakage.	Replace (Check on the casing for damage)
7	Over load relief valve	Check targeted spool visually (ROD side)	Free from dust entered in port relief valve. Seat is free from abnormality	Replace
8	Pressure compensation valve for boom swing	Visual check	When removing, free from abnormal resistance against sliding. Free from abnormal damage on outside of spool. Spring is free from breakage.	Replace (Check on the casing for damage)

**NOTES**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL