

Impreza P1 1999-2000



Exit

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

4) How to measure the outer diameter of each piston

Measure the outer diameter of each piston at the height shown in figure. (Thrust direction)

CAUTION:

Measurement should be performed at a temperature of 20°C (68°F).

Piston grade point H:

40.0mm (1.575 in)

Piston outer diameter:

Standard

A: 91.985 — 91.995 mm (3.6214 — 3.6218 in)


B: 91.975 — 91.985 mm (3.6211 — 3.6214 in)

0.25 mm (0.0098 in) *oversize*

92.225 — 92.235 mm (3.6309 — 3.6313 in)

0.50 mm (0.0197 in) *oversize*

92.475 — 92.485 mm (3.6407 — 3.6411 in)



5) Calculate the clearance between cylinder and piston.

CAUTION:

Measurement should be performed at a temperature of 20°C (68°F).

Cylinder to piston clearance at 20°C (68°F):

Standard

0.010 — 0.030 mm (0.0004 — 0.0012 in)

Limit

0.050 mm (0.0020 in)

6) Boring and honing

(1) If the value of taper, out-of-roundness, or cylinder-to-piston clearance measured exceeds the specified limit or if there is any damage on the cylinder wall, rebore it to use an oversize piston.

CAUTION:

When any of the cylinders needs reboring, all other cylinders must be bored at the same time, and use oversize pistons. Do not perform boring on one cylinder only, nor use an oversize piston for one cylinder only.

(2) If the cylinder inner diameter exceeds the limit after boring and honing, replace the crankcase.

CAUTION:

Immediately after reboring, the cylinder diameter may differ from its real diameter due to temperature rise. Thus, pay attention to this when measuring the cylinder diameter.

Limit of cylinder enlarging (boring):

0.5 mm (0.020 in)

9. PISTON AND PISTON PIN

1) Check pistons and piston pins for damage, cracks, and wear and the piston ring grooves for wear and damage. Replace if defective.

2) Measure the piston-to-cylinder clearance at each cylinder.

If any of the clearances is not to specification, replace the piston or bore the cylinder to use an oversize piston.

3) Make sure that piston pin can be inserted into the piston pin hole with a thumb at 20°C (68°F). Replace if defective.



Standard clearance between piston pin and hole in piston:

Standard

0.004 — 0.010 mm (0.0002 — 0.0004 in)

Limit


0.020 mm (0.0008 in)



Control Module I/O Signal

Content	Connector No.	Terminal No.	Signal (V)		Note	
			Ignition SW	Engine ON (Idling)		
			ON (Engine OFF)			
Crankshaft position sensor	Signal (+)	B136	6	0	±6	Sensor output waveform
	Signal (-)	B136	23	0	0	—
	Shield	B136	30	0	0	—
Camshaft position sensor	Signal (+)	B136	5	0	±6	Sensor output waveform
	Signal (-)	B136	23	0	0	—
	Shield	B136	30	0	0	—
Mass air flow sensor	Signal	B136	1	1	1.0 — 1.7	—
	Shield	B136	30	0	0	—
	GND	B136	31	0	0	—
Throttle position sensor	Signal	B136	20	Fully closed: 0.5±0.3 Fully opened: 4.3±0.3		—
	Power supply	B136	12	5	5	—
	GND	B136	24	0	0	—
Oxygen sensor	Signal	B136	21	0		Rich mixture: 0.7 Lean mixture: 0
	Shield	B136	30	0	0	—
Engine coolant temperature sensor	Signal	B136	28	0.6 — 1.0	0.6 — 1.0	After warm-up
	GND	B136	24	0	0	—
Intake air temperature sensor	B136	19		2.5 — 2.3	1.4 — 1.6	After warm-up
Vehicle speed sensor	B135	26		0 or 5	0 or 5	"5" and "0" are repeatedly displayed when vehicle is driven.
Starter switch	B135	2		0	0	Cranking: 10 to 14
A/C switch	B135	11		ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—
Ignition switch	B136	25		10 — 13	13 — 14	—
Neutral position switch (MT)	B135	29		ON: 5 OFF: 0		Switch is ON when gear is in neutral position.
Test mode connector	B135	22		5	5	When connected: 0
Read memory connector	B135	13		5	5	When connected: 0
Back-up power supply	B135	17		10 — 13	13 — 14	—
Control unit power supply	B136	9		10 — 13	13 — 14	—
		8				
Ignition control	# 1, # 2	B134	7	0	3.4, max.	—
	# 3, # 4	B134	16	0	3.4, max.	—
Fuel injector	# 1	B134	31	10 — 13	13 — 14	Waveform
	# 2	B134	32	10 — 13	13 — 14	Waveform
	# 3	B134	25	10 — 13	13 — 14	Waveform
	# 4	B134	18	10 — 13	13 — 14	Waveform

TURBOCHARGER SYSTEM




Construction and Function

Knock sensor

This sensor is mounted on the cylinder block and detects knocking vibrations of the engine. It consists of a piezo-element, weight and case.

The piezo-element inside of the sensor converts vibration into voltage signal that is output to the ECM. ECM controls ignition timing based on the knock sensor signal.

As sensor signal is detected, ECM retards the ignition timing. When the knocking stops, the ignition timing is advanced again.




TIGHTENING TORQUE: 21 to 27 N-m (2.1 to 2.7 Kg-m) (15.2 to 19.6 ft-lb)

Construction and Function

Fuel System

The fuel system delivers the fuel required for combustion. Fuel sent to the injector from the fuel tank by the fuel pump is maintained at a specified pressure that is always greater than the intake manifold internal pressure by constant value. Fuel is injected into the intake manifold by the injector in accordance with injection signals from the ECM.

Today, the most common fuel system uses multi-point Fuel injection (MPI), which equips an injector at the intake port of each cylinder. The MPI system allows a high level of intake air system design, high-precision air-fuel ratio control, along with exceptional output, fuel economy, and exhaust gas characteristics.



CO2	% VOL	13% OR HIGHER
HC	ppmVOL	200ppm MAX
O2	% VOL	3% MAX
CO	% VOL	0.2% MAX
LAMBDA		0.97 to 1.03
OIL TEMP		MIN 80° C
ENGINE SPEED	IDLE	700 to 900 rpm
	FAST IDLE	2,400 to 2,700 rpm

CO2	% vol	13.73
HC	ppm vol	15
O2	% vol	0.31
CO	% vol	0.004
COcor	% vol	0.00
Lambda		1.015
Engine speed	1/min	726
Oil temperature	°C	88

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL