

130G Excavator Repair

(PIN: 1FF130GX__F040608—)

**REPAIR TECHNICAL MANUAL
130G Excavator (PIN: 1FF130GX_
_ F040608—)**

TM13348X19 23APR18 (ENGLISH)

**Worldwide Construction
And Forestry Division**
PRINTED IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ —UN—15APR13


TX,INSPECT -19-08SEP10-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting, or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592 —UN—15APR13

TX,MOVING,PARTS -19-20JAN11-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 —UN—23AUG88

DX,FLUID -19-06OCT16-1/1

Travel Safely

When working on steep slopes, travel as straight up and down as possible to prevent roll-over.


DO NOT PARK ON A HILLSIDE OR AN INCLINE.

Always park the machine on level ground.

Know the location of bystanders before moving the machine.

Always keep the reverse warning alarm in working condition. The alarm warns bystanders when the machine starts to move in reverse.

Use a signal person when moving the machine in congested areas. Coordinate hand signals before starting the machine.



Travel Safely

T6964AD —UN—20DEC88

CN93077,00000B3 -19-01JUL15-1/1

Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 —UN—23AUG88

DX,POISON -19-21APR93-1/1

Add and Operate Attachments Safely

Always verify compatibility of attachments by contacting your authorized dealer. Adding unapproved attachments could affect machine stability or reliability and could create a hazard for others near the machine.

Ensure that a qualified person is involved in attachment installation. Add guards to machine if operator protection

is required or recommended. Verify that all connections are secure and attachment responds properly to controls.

Carefully read attachment manual and follow all instructions and warnings. In an area free of bystanders and obstructions, carefully operate attachment to learn its characteristics and range of motion.

TX,ATTACH -19-20JAN11-1/1

Torque Values

Service Recommendations for Flat Face O-Ring Seal Fittings

1. Inspect the fitting sealing surfaces and O-ring. They must be free of dirt or defects.
2. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
3. Index angle fittings and tighten by hand pressing joint together to ensure O-ring remains in place.

4. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening fittings, use backup wrench on straight hose couplings.

IMPORTANT: Tighten fittings to 150% of listed torque value if indexing is necessary or if fitting is attached to an actuating device.

Tighten fittings to 50% of listed torque value if used in aluminum housing.

FLAT FACE O-RING SEAL FITTING TORQUE*						
Nominal Tube OD		Thread Size	Swivel Nut		Bulkhead Nut	
mm	in	in	N·m	lb·ft	N·m	lb·ft
6.35	0.250	9/16-18	16	12	12	9
9.52	0.375	11/16-16	24	18	24	18
12.70	0.500	13/16-16	50	37	46	34
15.88	0.625	1-14	69	51	62	46
19.05	0.750	1-3/16-12	102	75	102	75
22.22	0.875	1-3/16-12	102	75	102	75
25.40	1.000	1-7/16-12	142	105	142	105
31.75	1.250	1-11/16-12	190	140	190	140
38.10	1.500	2-12	217	160	217	160


*Torque tolerance is +15 -20% unless otherwise specified.

Stud End O-ring Seal Torque for Straight and Adjustable Fittings*				
Thread Size	Straight Hex Size	Locknut Hex Size	Straight Fitting or Locknut Toque	
in	in	in	N·m	lb·ft
3/8-24	5/8	9/16	12	9
7/16-20	5/8	5/8	21	15
1/2-20	3/4	11/16	26	19
9/16-18	3/4	3/4	34	25
3/4-16	7/8	15/16	73	55
7/8-14	1-1/16	1-1/16	104	76
1-1/16-12	1-1/4	1-3/8	176	130
1-3/16-12	1-3/8	1-1/2	230	170
1-5/16-12	1-1/2	1-5/8	285	210

*Torque tolerance is +15 -20% unless otherwise specified.

OUO6092,00010A4 -19-04MAR16-1/1

Service Recommendations For Inch Series Four Bolt Flange Fittings



Flange Fittings

A—Sealing Surface
B—Split Flange

C—Pinched O-Ring
D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.
5. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART					
Nominal Flange Size	Cap Screw Size	N·m		lb·ft	
		Min	Max	Min	Max
1/2	5/16-18 UNC	20	31	15	23
3/4	3/8-16 UNC	28	54	21	40
1	3/8-16 UNC	37	54	27	40
1-1/4	7/16-14 UNC	47	85	35	63
1-1/2	1/2-13 UNC	62	131	46	97
2	1/2-13 UNC	73	131	54	97
2-1/2	1/2-13 UNC	107	131	79	97
3	5/8-11 UNC	158	264	117	195
3-1/2	5/8-11 UNC	158	264	117	195
4	5/8-11 UNC	158	264	117	195
5	5/8-11 UNC	158	264	117	195


04T,90,K174 -19-01AUG94-1/1

T6890BB —UN—15APR13

Track Roller Disassemble and Assemble

SPECIFICATIONS	
Lower Track Roller Capacity	200 mL 6.8 fl oz
Fill Plug Torque	30 N·m 22 lb·ft

OTHER MATERIAL
NEVER-SEEZ® Anti-Seize Lubricant
Loctite® Klean 'N Prime™ Primer
Loctite® 592™ PST® Thread Sealant (slow cure)



TX1091562

Track Roller Components

1— Bushing (2 used)
2— Roller
3— Bracket (2 used)

4— Metal Face Seal (2 used)
5— Pin (2 used)

6— O-Ring (2 used)
7— Plug (2 used)

8— Axle

1. Remove plugs (7) and drain oil.
2. Remove pins (5).
3. Remove brackets (3).

NOTE: Metal face seals can be reused if they are not worn or damaged. A used seal must be kept together as a set because of wear patterns on seal ring face.

4. Remove metal face seals (4) from roller and bracket. Keep seal rings together as a matched set with seal ring faces together to protect surfaces.

NOTE: For seals that are reused, insert a piece of cardboard between seal rings to protect seal face.

5. Inspect metal face seals. See Metal Face Seals Repair. (Group 0130.)
6. Remove axle (8) and O-rings (6).

NOTE: Bushings should only be removed if replacement is necessary.

7. If necessary, remove bushings (1) using a press.
8. Inspect and replace parts as necessary. See 130G Track Roller Tread Diameter. (SP326VOL1 Undercarriage Appraisal Manual.)
9. Apply a thin film of oil to new bushings. Install bushings so flange is tight against shoulder of idler.

IMPORTANT: Avoid damage to metal face seals. Metal face seals and seat surfaces must be clean, dry, and oil free so they do not slip when roller is turning.

NOTE: A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.


10. Thoroughly clean seat surfaces in idler, brackets, and metal face seals using volatile, non-petroleum base solvent and lint-free tissues.

Continued on next page

MM16284,0001E79 -19-09DEC15-1/2

14. Remove master pin (1) using 50-ton track press.

1— Master Pin




Master Pin Removal Using Track Press

Continued on next page

JB51320,0000A3 -19-19OCT15-7/8

TX1098806A —UN—27SEP11

Track System



TX1098003

Track Link Assembly

- | | | |
|---------------------------|-------------------------------------|---------------------|
| 1— Replacement Track Pin | 11— Replacement Track Link Assembly | 12— Collar (4 used) |
| 10— Replacement Track Pin | | |

- | | |
|--|--|
| <p>8. Install replacement track link assembly (11) and collars (12).</p> <p>9. Install replacement track pin (10).</p> <p>10. Install replacement track pin (1).</p> | <p>11. Install three track shoes surrounding damaged area. See <u>Track Shoe Remove and Install</u>. (Group 0130.)</p> |
|--|--|

BG71631,0000252 -19-12JUL12-6/6

TX1098003 —UN—16SEP11

16. Raise upper half of DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool and tighten T-handles (16).
17. Extend 20-ton hydraulic jack ram to release pressure on nut (13).
18. Remove nut (13).
19. Lower 20-ton hydraulic jack ram to release recoil spring tension.
20. Remove nuts (7), top plate, and DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool.


7— Nut (8 used)

8— Top Plate

12— DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool

13— Nut

16— T-Handles



DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool

Continued on next page

MM16284,0001E75 -19-30NOV15-5/7

TX1123092 —UN—25SEP12

1. Remove travel gear case. See Travel Gear Case Remove and Install. (Group 0250.)

Specification

Travel Gear Case Assembly—Weight (approximate).....	230 kg 507 lb
---	------------------

2. Drain gear oil. See Drain and Refill Travel Gear Case Oil. (Operator's Manual.)
3. Place travel gear case assembly on workbench with travel motor (20) side facing down.
4. Apply alignment marks at mating positions of cover (17), ring gear (15), and drum (24).
5. Remove cap screws (18) and cover.
6. Apply alignment marks at mating positions and remove shaft (14), spacer (13), and first stage planetary carrier (12) from ring gear (15).
7. Apply alignment marks at mating positions and remove spring pins (9), pin fasteners (8), thrust plates (29), needle bearings (7), and planetary gears (6) from first stage planetary carrier (12).
8. Apply alignment marks at mating positions and remove second stage sun gear (11) from second stage planetary carrier (10).

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

9. Install JT01748 Lifting Brackets to ring gear. Apply alignment marks at mating positions. Remove cap screws (23) and ring gear.

Specification

Ring Gear—Weight (approximate).....	34 kg 75 lb
-------------------------------------	----------------

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

10. Using ST0916 Lifting Tool, remove second stage planetary carrier (10) from drum (24).

Specification

Second Stage Planetary Carrier—Weight (approximate).....	30 kg 66 lb
--	----------------

Loctite and its related brand marks are trademarks of Henkel Corporation

11. Apply alignment marks at mating positions and remove spring pins (5), pin fasteners (4), thrust plates (1), needle bearings (2), and planetary gears (3) from second stage planetary carrier (10).

12. Remove bearing nut (27) using DFT1036A Travel Gear Case Nut Wrench and DFT1109 Holding Bar. See DFT1036A Travel Gear Case Nut Wrench and see DFT1109 Holding Bar. (Group 9900.)

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

13. Remove drum and sprocket assembly using JT01748 Lifting Brackets.

Specification

Drum and Sprocket Assembly—Weight (approximate).....	63 kg 139 lb
Drum—Weight (approximate).....	25 kg 55 lb

IMPORTANT: Avoid damage to metal face seal. Seal must be kept together as a set because of wear patterns. Metal face seal can be reused if seal is not worn or damaged.

14. Remove and inspect metal face seal (21).

NOTE: Further disassembly is not necessary unless bearing replacement is required. Bearing will be destroyed during removal and must be replaced with a new bearing.

15. Inspect tapered roller bearings (22) and races inside drum (24).

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

16. Using appropriate lifting device, remove cap screws (26) and sprocket (25).

Specification

Sprocket—Weight (approximate).....	38 kg 84 lb
------------------------------------	----------------

17. Clean, inspect, and replace parts as necessary.

Continued on next page

JB51320,00000AC -19-04DEC17-3/7

CAUTION: Prevent possible injury from components under pressure. Park brake piston (6) may come out quickly with considerable force. Use only regulated air pressure and stand clear of brake piston when removing.

- Carefully apply specified air pressure to brake release passage (29) to remove park brake piston (6).

Specification

Specified Air—Pressure.....	100—300 kPa
	1—3 bar
	15—44 psi

IMPORTANT: Prevent possible damage due to improper handling. Position piston with seating surface facing up.

- Remove O-rings (5 and 7) from brake piston.
- Remove plates (8) and friction plates (9) from park brake housing (28).

IMPORTANT: Pistons (15) must be installed into the same bores because of wear patterns. Mark location of pistons with respect to bores for proper assembly.

- Remove rotor (19), springs (18), bushing (17), retainer (16), and pistons (15).
- Inspect parts for wear or damage. Compare to specification.

Specification

Disc Spring—Height.....	6.40—6.50 mm
	0.252—0.256 in
Friction Plate—Height.....	2.35—2.40 mm
	0.093—0.094 in
Plate—Height.....	1.35—1.40 mm
	0.053—0.055 in

CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.


IMPORTANT: Prevent possible damage due to improper handling. Prevent swash plate (14) from falling out while park brake housing is positioned horizontally.

- Using appropriate lifting device, position housing with brake release oil passage facing downward.

Specification

Park Brake Housing—Weight (approximate).....	38 kg
	84 lb

- Remove swash plate (14). If swash plate can not be easily removed, apply air pressure to piston oil passage (31). Cover pistons (13) with cloth to prevent ejection.



Travel Motor and Park Brake Housing

- 28— Park Brake Housing
- 29— Brake Release Passage
- 31— Piston Oil Passage

Specification

Specified Air—Pressure.....	100—300 kPa
	1—3 bar
	15—44 psi

- Remove pistons (13) and balls (12) using a magnet.
- Remove retaining ring (23).
- Remove shaft and roller bearing (24) from housing.
- Remove and discard oil seal (25).
- Remove retaining ring (30) and roller bearing from shaft.
- Repair or replace parts as necessary.
- Using appropriate lifting device, position park brake housing (28) with park brake valve (2) mounting surface facing up.
- Apply multipurpose grease to lip of oil seal and apply Loctite® 277™ Threadlocker (high strength) to outer surface of oil seal.
- Install oil seal using D01044AA Bushing, Bearing, and Seal Driver Set.
- Install roller bearing to shaft using D01044AA Bushing, Bearing, and Seal Driver Set. Install retaining rings (23 and 30).
- Apply multipurpose grease to balls (12). Install balls into housing.
- Install pistons (13) to housing with stepped side facing inside.
- IMPORTANT:** Prevent damage to surface of shaft during installation. Surface damage of shaft may cause damage to needle bearing inner race. Wrap tape around shaft during installation of components.
- Install shaft and roller bearing assembly into housing.


Continued on next page

MM16284,0001E7C -19-11DEC15-4/5

TX1205243 —UN—09NOV15

NOTE: It is not necessary to evacuate air conditioning system during engine removal.

16. Install identification tags and disconnect air conditioner compressor clutch (Y11) connector. See Machine Harness (W2) Component Location. (Group 9015-10.)
17. Remove serpentine belt (22). See Inspect Serpentine Belt. (Operator's Manual.)
18. Remove cap screws (23) and set air conditioner compressor aside.
19. Remove dosing injector. See Diesel Exhaust Fluid (DEF) Dosing Injector Remove and Install. (Group 0530.)
20. Remove decomposition tube. See Diesel Exhaust Fluid (DEF) Decomposition Tube Remove and Install. (Group 0530.)
21. Remove exhaust tube. See Exhaust Tube Remove and Install. (Group 0530.)
22. Remove diesel particulate filter (DPF). See Diesel Particulate Filter (DPF) Remove and Install. (Group 0530.)
23. Remove selective catalyst reduction (SCR). See Selective Catalyst Reduction (SCR) Remove and Install. (Group 0530.)



Air Conditioner Compressor

22— Serpentine Belt
23— Cap Screw (4 used)

Y11— Air Conditioner
Compressor Clutch


JB51320,0000B1 -19-15JAN18-4/11

TX1115636A —UN—13JUN12

IMPORTANT: Prevent possible fuel spill. On machines without a fuel shutoff valve, install clamp on fuel hose to prevent the release of fuel.

24. Install clamp on fuel supply hose (17). Install identification tags and disconnect fuel supply hose. Close all openings using caps and plugs.

17— Fuel Supply Hose



Fuel Supply Hose

Continued on next page

JB51320,0000B1 -19-15JAN18-5/11

TX1115621A —UN—13JUN12

10. Remove cap screws (18 and 19) and radiator (20).


11. Repair or replace parts as necessary.

INSTALLATION


Installation is reverse of removal procedure.

18— Cap Screw (2 used)
19— Cap Screw (2 used)


20— Radiator



Cooling Package



Radiator (top view)



Radiator (bottom view)

TX1205763A —UN—19NOV15

TX1205764A —UN—19NOV15

TX1205765A —UN—19NOV15

JB51320,00000B3 -19-10DEC15-4/4

Exhaust Tube Remove and Install

SPECIFICATIONS	
Exhaust Tube Clamp Torque	20 N·m 177 lb·in

1. Park and prepare machine for service safely. [See Park and Prepare for Service Safely.](#) (Group 0001.)

IMPORTANT: Avoid machine damage. After turning key switch to OFF position, only turn battery disconnect switch to OFF position when indicator light no longer illuminates.


2. Turn battery disconnect switch to OFF position. [See Battery Disconnect Switch.](#) (Operator's Manual.)
3. Remove clamps (1) and exhaust tube (2).
4. Inspect and replace parts as necessary.
5. Install exhaust tube and clamps.

IMPORTANT: The life of the exhaust bellows is dependant on being properly aligned. If not aligned correctly, the life of the exhaust bellows will significantly decrease and may risk unfiltered exhaust into the atmosphere.

6. Perform exhaust bellows alignment procedure. [See Exhaust Bellows Alignment Procedure.](#) (Group 0530.)
7. Tighten exhaust tube clamps to specification.

Specification

Exhaust Tube	
Clamp—Torque.....	20 N·m 177 lb·in



Exhaust Tube

1— Clamp (2 used)

2— Exhaust Tube

8. Turn battery disconnect switch to ON position. [See Battery Disconnect Switch.](#) (Operator's Manual.)
9. Operate machine and check for leaks.

TX1203954A —UN—27OCT15

DB95148,00023E7 -19-23NOV15-1/1

Diesel Exhaust Fluid (DEF) Tank Remove and Install


SPECIFICATIONS	
Diesel Exhaust Fluid (DEF) Tank Capacity (S.N. —041330)	26.7 L 7.1 gal
Diesel Exhaust Fluid (DEF) Tank Capacity (S.N. 041331—)	24.6 L 6.5 gal
Toolbox Weight (approximate)	32 kg 71 lb
Diesel Exhaust Fluid (DEF) Tank Cover Weight (approximate)	34 kg 75 lb

1. Park and prepare machine for service safely. See [Park and Prepare for Service Safely](#). (Group 0001.)
2. Drain or pump diesel exhaust fluid (DEF) from DEF tank into approved container.

Specification

Diesel Exhaust Fluid (DEF) Tank—Capacity (S.N. —041330).....	26.7 L 7.1 gal
Diesel Exhaust Fluid (DEF) Tank—Capacity (S.N. 041331—).....	24.6 L 6.5 gal

3. Remove cap screws (1) and top cover (2).



Top Cover

1— Cap Screw (4 used)

2— Top Cover


TX1165844A —UN—22JUL14

TW62213,0000483 -19-19OCT17-1/9

4. Remove cap screws (3) and side cover (4).

3— Cap Screw (4 used)

4— Side Cover



Side Cover

Continued on next page


TW62213,0000483 -19-19OCT17-2/9

TX1165845A —UN—18AUG14

External Exhaust Systems

12. Remove cap screws (14) and bracket (13).
13. Install identification tags and disconnect heater connectors (E5601—E5603).
14. Remove cap screws (15) and electrical connectors.
15. Remove cap screws (16) and set coolant lines (17 and 18) aside.

- | | |
|---|--|
| <ul style="list-style-type: none"> 13— Bracket 14— Cap Screw (6 used) 15— Cap Screw (3 used) 16— Cap Screw (2 used) 17— Coolant Line | <ul style="list-style-type: none"> 18— Coolant Line E5601—Diesel Exhaust Fluid (DEF) Unit Pressure Line Heater E5602—Diesel Exhaust Fluid (DEF) Unit Supply Line Heater E5603—Diesel Exhaust Fluid (DEF) Unit Return Line Heater |
|---|--|




Diesel Exhaust Fluid (DEF) Dosing Unit

DB95148.00023F1 -19-30NOV15-6/10

TX1197481A —UN—15JUL15

16. Disconnect electrical connector (19).

- 19— Electrical Connector




Electrical Connector (bottom)

DB95148.00023F1 -19-30NOV15-7/10

TX1166569A —UN—29JUL14

17. Install identification tags and disconnect DEF lines (20—22) from DEF dosing unit (B5501). Close all openings using caps and plugs.

- | | |
|--|---|
| <ul style="list-style-type: none"> 20— Diesel Exhaust Fluid (DEF) Line 21— Diesel Exhaust Fluid (DEF) Line | <ul style="list-style-type: none"> 22— Diesel Exhaust Fluid (DEF) Line B5501—Diesel Exhaust Fluid (DEF) Dosing Unit |
|--|---|



Diesel Exhaust Fluid (DEF) Lines

Continued on next page

DB95148.00023F1 -19-30NOV15-8/10


TX1166570A —UN—29JUL14

Damper Drive (Flex Coupling) Remove and Install

OTHER MATERIAL
Loctite® 242® Threadlocker (medium strength)

SPECIFICATIONS	
Coupling-to-Flywheel Cap Screw Torque	220 N·m 162 lb·ft
Spline Hub-to-Pump Shaft Set Screw Torque	50 N·m 37 lb·ft
Coupling-to-Spline Hub Cap Screw Torque	220 N·m 162 lb·ft

1. Park and prepare machine for service safely. See Park and Prepare for Service Safely. (Group 0001.)



TX1167328

Damper Drive (flex coupling)

- 1— Spline Hub
- 2— Set Screw (2 used)
- 3— Coupling
- 4— Cap Screw (4 used)
- 5— Flywheel Insert (4 used)

- 6— Flywheel Guide Pin (4 used)
- 7— Cap Screw (4 used)
- 8— Hub Insert (4 used)

- 9— Groove Mark
- 10— Hydraulic Pump
- 11— Flywheel Housing
- 12— Hub Guide Pin (8 used)

A—Damper Drive (flex coupling)

NOTE: Coupling (3) may come off with pump or stay on flywheel.

2. Remove hydraulic pump (10). See Pump 1 and 2 Remove and Install. (Group 3360.)

Loctite and its related brand marks are trademarks of Henkel Corporation

Continued on next page

JL58967,0000144 -19-27JUL15-1/2

TX1167328—UN—31JUL14

Cab Remove and Install

SPECIFICATIONS	
Cooling System Capacity	23.5 L 6.2 gal
Hydraulic Oil Tank Capacity	69 L 18.2 gal
Cab Weight (approximate)	658 kg 1451 lb
Cab Mount Cap Screw Torque	550 N·m 406 lb-ft
Cab Isolator Lock Nut Torque	206 N·m 152 lb-ft
100-Pin Connector (X3) Cap Screw Torque	10 N·m 89 lb-in

1. Park and prepare machine for service safely. [See Park and Prepare for Service Safely.](#) (Group 0001.)

IMPORTANT: Avoid machine damage. After turning key switch to OFF position, only turn battery disconnect switch to OFF position when indicator light no longer illuminates.

2. Turn battery disconnect switch to OFF position. [See Battery Disconnect Switch.](#) (Operator's Manual.)


⚠ CAUTION: Prevent possible injury. Explosive release of fluids from pressurized cooling system can cause serious burns. Shut off engine. Remove filler cap when cool to touch. Slowly loosen filler cap to relieve the pressure, then remove.

3. Drain cooling system. [See Drain Cooling System.](#) (Operator's Manual.)

Specification	
Cooling System—Capacity.....	23.5 L 6.2 gal

⚠ CAUTION: Avoid personal injury from high-pressure fluid. High-pressure release of hydraulic oil from pressurized system can cause serious burns or penetrating injury. Relieve pressure from hydraulic system before servicing.

4. Release hydraulic oil tank pressure by pressing pressure release button at top of hydraulic oil tank. [See Hydraulic Oil Tank Pressure Release Procedure.](#) (Group 9025-25.)
5. Apply vacuum or drain hydraulic oil tank. [See Apply Vacuum to Hydraulic Oil Tank.](#) (Group 3360.) [See Drain and Refill Hydraulic Tank Oil.](#) (Operator's Manual.)



Electrical Connectors

5— Cap Screw (4 used)

6— Electrical Connector (4 used)

Specification

Hydraulic Oil Tank—Capacity.....	69 L 18.2 gal
----------------------------------	------------------

6. Remove cap screws (5) and disconnect electrical connectors (6).
7. Recover refrigerant from air conditioning system. [See Recover R134a Refrigerant.](#) (Group 1830.)

Continued on next page


SA65494,0000099 -19-04DEC15-1/13

Operator Enclosure

3. Remove cap screws (5) and windshield wiper motor (M5).

5— Cap Screw (2 used)

M5—Windshield Wiper Motor



TX1097953 —UN—16SEP11


JS20420,0001353 -19-21AUG15-3/9

IMPORTANT: Avoid windshield damage. Isolator (7) is attached to windshield with adhesive. Avoid too much pressure to windshield when removing isolator from windshield.

4. Remove cap screws (6) and isolator (7).

6— Cap Screw (4 used)

7— Isolator




TX1097954 —UN—16SEP11

Continued on next page

JS20420,0001353 -19-21AUG15-4/9

Operator Enclosure



TX1199359

6—Rear Left Side Glass
a—Black Ceramic Painted Surface

b—Black Ceramic Painted Range
c—Chamfer Here
d—Shaded Paint Along Periphery

Rear Left Side Glass

Continued on next page

DS35042,0000522 -19-10AUG15-7/9

Seat and Seat Belt

- | | | | |
|---------------------------|-------------------------------------|-------------------------------|---------------------------|
| 1— T4 Upper Seat Assembly | 7— Seat Spring (4 used) | 12— 51 Suspension Kit | 18— Tether Strap (2 used) |
| 2— Back Rest Cover | 8— Seat Directional Handle (2 used) | 13— Fore and Aft Adjuster Kit | 19— Headrest |
| 3— Back Rest Foam | 9— Seat Height Riser | 14— Damper Kit | 20— Adjustment Cable |
| 4— Bottom Seat Cover | 10— Air Lumber Support | 15— Weight Adjuster Kit | 21— Bearing Kit |
| 5— Bottom Seat Foam | 11— Up Stop Bump Stop Kit | 16— Suspension Cover | |
| 6— Seat Frame | | 17— Lever and Center Pivot | |

MD03584,000006A -19-04SEP12-2/2

Group 1830 Heating and Air Conditioning

R134a Refrigerant Cautions and Proper Handling

SERVICE EQUIPMENT AND TOOLS

Refrigerant Identifier

⚠ CAUTION: DO NOT allow liquid refrigerant to contact eyes or skin. Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves, and protective clothing.

If liquid refrigerant contacts eyes or skin, **DO NOT** rub the area. Splash large amounts of **COOL** water on affected area. Go to a physician or hospital immediately for treatment.

DO NOT allow refrigerant to contact open flames or very hot surfaces such as electric welding arc, electric heating element, and lighted smoking materials.

DO NOT heat refrigerant over 52°C (125°F) in a closed container. Heated refrigerant will develop high pressure which can burst the container.

Keep refrigerant containers away from heat sources. Store refrigerant in a cool place.

DO NOT handle damp refrigerant container with bare hands. Skin may freeze to container. Wear gloves.

If skin freezes to container, pour **COOL** water over container to free the skin. Go to a physician or hospital immediately for treatment.

IMPORTANT: To meet government standards relating to the use of refrigerants, R134a is used in the air conditioning system. Because it does not contain chlorine, R134a is not detrimental to the ozone in the atmosphere. However, it is illegal to discharge any refrigerant into the atmosphere. It must be recovered using the appropriate recovery stations.

Use correct refrigerant recovery, recycling, and charging stations. Do not mix refrigerants, hoses, fittings, components, or refrigerant oils.

Use only John Deere approved R134a refrigerant products. Mixing of products not compatible will cause system damage and contaminate recovery, recycling, and charging station equipment. Care must be taken to identify and use equipment, refrigerant oil, and refrigerant designed only for R134a refrigerant systems. Refrigerant should be tested for type and purity before recovery, recycling, or charging of system. Refrigerant identifier should be used before any testing or repair to system is performed.

AS79221,00005A0 -19-03MAR16-1/2

Refrigerant Identifier

Used to safely and correctly identify type and check purity of refrigerant prior to recovery, recycling, and charging of air conditioning systems.

AS79221,00005A0 -19-03MAR16-2/2

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Heating and Air Conditioning

10. Remove cap screws (12) and set 12-volt power converter (A8) aside.

11. Remove cap screws (15 and 17).


12— Cap Screw (2 used)

15— Cap Screw (4 used)

16— Relay Block

17— Cap Screw (3 used)

A8—12-Volt Power Converter



Heater and Air Conditioner Connections

TX1125662A —UN—09NOV12

JB51320,00000E0 -19-12OCT15-3/6

12. Remove cap screws (18) and set air conditioner controller (ACF) (A7) aside. See Cab Harness (W1) Component Location. (Group 9015-10.)

13. Install identification tags and disconnect air conditioner 4-pin connector (X51) and air conditioner 10-pin connector (X52). See Heater and Air Conditioner Harness (W41) Component Location. (Group 9015-10.)

14. Remove cap screws (21), cover (22), and panel (23).

18— Cap Screw (4 used)

21— Cap Screw (7 used)


22— Cover

23— Panel

A7—Air Conditioner Controller (ACF)

X51— Air Conditioner 4-Pin Connector

X52— Air Conditioner 10-Pin Connector



Heater and Air Conditioner Panel

TX1126671A —UN—27NOV12

Continued on next page

JB51320,00000E0 -19-12OCT15-4/6

Bucket Remove and Install

For additional information, see [Bucket Remove and Install](#). (Operator's Manual.)

BE78919,000073D -19-01FEB18-1/1

Adjust Bucket Pivot End Play

SPECIFICATIONS	
Bucket Pivot Bushing-to-Arm Clearance (as close to but not less than)	0.5 mm 0.020 in

1. Park and prepare machine for service safely. See [Park and Prepare for Service Safely](#). (Group 0001.)
2. Remove nuts (2) and cap screw (1).
3. Measure clearance between bushing and arm. Adjust clearance to specification.

Specification


Bucket Pivot Bushing-to-Arm—Clearance (as close to but not less than)..... 0.5 mm
0.020 in

NOTE: Alternate buckets may have different adjustment procedures.

4. Slide pin (5) out of bucket to edge of seal (4).
5. Inspect bushings and seals. See [Inspect Pins, Bushings, and Bosses—Front Attachment](#) and see [Bushings and Seal Remove and Install](#). (Group 3340.)
6. Remove or add shims (3) on each side of joint to get a minimal amount of clearance. There must be some clearance in the joint.
7. Push pin back into place. Align pin bores and install cap screw.

IMPORTANT: Avoid possible damage to pins. Cap screws must be free to turn in hole to allow movement of pins. Tighten nuts against each other, not against retainer.

8. Install cap screw and tighten nuts against each other.



Bucket Pivot Shims




Measuring Bushing to Arm Clearance

- | | |
|---------------------|---------|
| 1— Cap Screw | 4— Seal |
| 2— Nut (2 used) | 5— Pin |
| 3— Shim (as needed) | |

TX1113143A—UN—27APR12

TX1113142A—UN—27APR12

DB95148,0002327 -19-01DEC15-1/1



TX1115305 —UN—07JUN12

TX1115305

Boom Foot Pin

- 13— Cap Screw
- 14— Washer
- 15— Retaining Plate

- 16— Boom Foot Pin
- 17— Thrust Plate

- 18— Thrust Plate
- 19— Shim (2 used)

16. Remove cap screw (13), washer (14), and retaining plate (15).

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

NOTE: Location of shims (19) should be recorded to aid in assembly procedure.

17. Support boom with appropriate lifting device and remove boom foot pin (16), thrust plates (17 and 18), and shims (19).

Specification

Boom With Arm	
Cylinder—Weight	
(approximate).....	1172 kg
	2584 lb
Boom Foot Pin—Weight	
(approximate).....	23 kg
	51 lb

18. Remove boom.

19. Inspect pins and bushings for wear. See Inspect Pins, Bushings, and Bosses—Front Attachment. (Group 3340.)

20. Repair or replace parts as necessary.

21. Clean pins and bores.

22. Apply grease to pins and bores.

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

23. Support boom with appropriate lifting device. Install boom foot pin and thrust plates equally on each side. Add shims to attain specified boom thrust plate clearance.

Specification

Boom Thrust	
Plate—Clearance.....	0—1.5 mm
	0—0.06 in
Boom Foot Pin—Weight	
(approximate).....	23 kg
	51 lb

24. Install retaining plate, washer, and cap screw (13). Tighten cap screw to specification.

Specification

Boom Foot Pin Cap	
Screw—Torque.....	400 N·m
	295 lb·ft

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

Continued on next page

JB51320,00000E9 -19-09DEC15-6/7

25. Connect hoses. See Pump 1, Pump 2, and Pilot Pump Line Identification. (Group 9025-15.)

26. Connect solenoids. See Pump Harness (W8) Component Location. (Group 9015-10.)

27. Connect sensors. See Pump Harness (W8) Component Location. (Group 9015-10.)

28. Install suction hose and clamps.

29. Fill hydraulic oil tank. See Drain and Refill Hydraulic Tank Oil. (Operator's Manual.)

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

30. Install SCR. See Selective Catalyst Reduction (SCR) Remove and Install. (Group 0530.)

31. Install hood. See Hood Remove and Install. (Group 1910.)

32. Turn battery disconnect switch to ON position. See Battery Disconnect Switch. (Operator's Manual.)

IMPORTANT: Hydraulic pump will be damaged if not filled with oil before starting. Procedure must be

performed to fill pump housing whenever oil has been drained from the pump or hydraulic oil tank.

33. Perform pump 1 and 2 start-up procedure. See Pump 1 and 2 Start-Up Procedure. (Group 3360.)

⚠ CAUTION: Prevent possible injury from unexpected machine movement. Clear all personnel from area before operating machine.

34. Operate machine and check for leaks. Verify all machine functions operate correctly. See Operational Checkout. (Group 9005-10.)

35. Check pump regulator adjustments.

For minimum flow:


- See Pump Regulator Test and Adjustment—Minimum Flow. (Group 9025-25.)

For maximum flow:

- See Pump Regulator Test and Adjustment—Maximum Flow. (Group 9025-25.)

62. Install disc springs (44) onto pump 1 cylinder block (43) as shown. Install bushing (45), retainer (46), and pistons (69).

43— Pump 1 Cylinder Block 45— Bushing
44— Disc Spring (2 used)



Disc Spring and Bushing Installation

Continued on next page

MM16284,0001E7A -19-10DEC15-13/15

TX1207047 —UN—08DEC15

Hydraulic System

- 1— Housing
- 2— Sleeve B
- 3— Spool B
- 5— Cylinder B
- 6— Load Piston
- 7— O-Ring
- 8— Backup Ring
- 9— O-Ring
- 10— Stop B
- 12— Stop (2 used)
- 14— O-Ring

- 15— Stop O-Ring (2 used)
- 16— Nut (2 used)
- 17— Nut (2 used)
- 20— Piston A
- 22— Cylinder A
- 24— Stop A
- 27— Sleeve A
- 28— Spool A
- 29— Set Screw

- 34— Nut
- 35— Cover
- 36— Piston B
- 37— Cap Screw (8 used)
- 38— Cover
- 39— Pipe Plug
- 41— O-Ring
- 43— Screw (4 used)
- 47— Outer Compression Spring

- 48— Inner Compression Spring
- 49— Compression Spring
- 52— O-Ring
- 58— Pipe Plug
- 59— O-Ring
- B36— Pump 1 Control Pressure Sensor

SPECIFICATIONS	
Pump 1 and Pump 2 Cover-to-Housing Cap Screw Torque	20 N·m 177 lb·in

IMPORTANT: Avoid possible regulator damage. Apply clean hydraulic oil to parts prior to installation.

NOTE: Note direction of piston, sleeve, and spool A.

NOTE: Pump 1 and pump 2 regulators are similar. Pump 1 regulator is used in this procedure.

1. Remove pump 1 and 2 regulator. See Pump 1 and 2 Regulator Remove and Install. (Group 3360.)

IMPORTANT: Avoid possible housing damage. Some parts from housing port A are different from port B. Parts for each port must be kept together and installed into the same port from which they were removed.

NOTE: Removal of stops (10, 12, and 24) and set screw (29) from covers (35 and 38) will require the adjustment of pump regulators. Only remove parts from covers if replacement is necessary.

2. Remove cap screws (37) and covers (35 and 38) with set screw (29) and stops (10, 12, and 24) attached.
3. Remove stop O-rings (15) and compression springs (47—49).

NOTE: Note direction of sleeve B (2) and spool B (3).

4. Remove cylinder B (5), load piston (6), sleeve B, and spool B from housing (1).
5. Remove load piston, O-rings (7 and 9), and backup ring (8) from cylinder B.

NOTE: Note direction of piston A (20), sleeve A (27), and spool A (28).

6. Remove cylinder A (22), piston A, sleeve A, and spool A from housing.
7. Remove piston A and O-ring (14) from cylinder.
8. Remove pump 1 control pressure sensor (B36) and O-ring (52).
9. Remove pipe plug (39) and O-ring (41).
10. Repair or replace parts as necessary.
11. Install pipe plug (39) and O-ring (41).
12. Install pump 1 control pressure sensor (B36) and O-ring (52).

13. Insert spool A into sleeve A and install into center of housing.

14. Install O-ring (14) and insert piston A into cylinder A.

15. Install cylinder A into housing.

NOTE: Note direction of sleeve B (2) and spool B (3).

16. Insert spool B into sleeve B and install into center of housing.

17. Install O-rings (7 and 9), backup ring (8), and load piston and insert piston B into cylinder B.

18. Install cylinder B into housing.

19. Install O-rings (15) and compression springs (47—49).

20. Install covers with set screw and stops attached.

21. Install cap screws (37) and tighten to specification.

Specification

Pump 1 and Pump 2 Cover-to-Housing Cap Screw—Torque.....	20 N·m 177 lb·in
--	---------------------

22. Install pump 1 and 2 regulator. See Pump 1 and 2 Regulator Remove and Install. (Group 3360.)

IMPORTANT: Prevent possible pump 1 and 2 damage. Fill hydraulic pumps with oil before starting engine.

23. After installing regulator, perform pump 1 and pump 2 start-up procedure. See Pump 1 and 2 Start-Up Procedure. (Group 3360.)

24. Operate machine and check for leaks. Check pump regulator for adjustments.

For minimum flow:

- See Pump Regulator Test and Adjustment—Minimum Flow. (Group 9025-25.)

For maximum flow:

- See Pump Regulator Test and Adjustment—Maximum Flow. (Group 9025-25.)

JJ03229,0001184 -19-23NOV15-2/2

Hydraulic System

1. Apply alignment marks on pilot shutoff solenoid valve (3) and solenoid (6) to aid in assembly.
2. Clamp pilot shutoff solenoid valve in vise.
3. Remove cap screws (9), solenoid, and O-ring (11).
4. Remove plugs (8), O-rings (12), spring (1), and spool (4).
5. Remove screen (5).
6. Clean and inspect all parts. Replace worn or damaged parts as necessary. Use new O-rings when assembling.

IMPORTANT: To prevent seizing, apply clean hydraulic oil to parts before assembling.

7. Install screen.

8. Install spool, spring, O-rings, and plugs. Tighten plug to specification.

Specification

Plug—Torque.....28 N·m
21 lb·ft

9. Install O-ring and solenoid.
10. Align marks made during disassembly. Install cap screws and tighten to specification.

Specification

Solenoid-to-Pilot
Shutoff Valve Cap
Screw—Torque.....4 N·m
35 lb·in

JJ03229,000118B -19-02DEC15-3/2

31. Install snap rings (11) to ST4144 Snap Ring Holder (26).

32. Install snap rings (11) into groove on head of spools remaining out of spring compressor.

IMPORTANT: Avoid possible component damage. Ports 1 and 3 use pushers with one outer groove. Ports 2 and 4 use pushers with two outer grooves.

33. Install pushers into housing by hand.

34. Verify snap rings (11) and balance springs are installed correctly.

35. Install pushers to housing.

36. Apply TY6341 Multipurpose SD Polyurea Grease to ball at ends of pushers.

37. Apply TY6341 Multipurpose SD Polyurea Grease to joint of universal joint and to inner surface of sleeve seals.

38. Apply TY6341 Multipurpose SD Polyurea Grease to inner surface of oil seals.

39. Install O-rings (6) and sleeves.


40. Apply Loctite® 271™ Threadlocker (high strength) to the threads of universal joint.

41. Secure plate by aligning cap screw holes in plate with cap screw holes in housing and install universal joint. Tighten universal joint to specification.

	Specification
Universal Joint—Torque.....	25 N·m 221 lb·in

42. Install cam onto universal joint. Check clearance between cam and pushers.

Loctite and its related brand marks are trademarks of Henkel Corporation



Snap Ring Installation Tool

- | | |
|-------------------------|------------------------------|
| 1— Housing | 25— ST4146 Spring Compressor |
| 24— ST4145 Spool Holder | 26— ST4144 Snap Ring Holder |

Specification

Cam-to-Pusher—Clearance.....	0—0.2 mm 0—0.008 in
------------------------------	------------------------

43. Hold cam and tighten coupling to specification.


Specification

Coupling-to-Cam and Universal Joint—Torque.....	70 N·m 52 lb·ft
---	--------------------

44. Install pilot valve (left and right). See Pilot Valve (Left and Right) Remove and Install. (Group 3360.)

TX1096326 —UN—24AUG11

Pilot Signal Manifold Disassemble and Assemble



T143485

Pilot Signal Manifold (1 of 2)

Continued on next page

JJ03229,0001195 -19-10NOV15-1/3

T143485 - UN - 17JUL01

Hydraulic System

- | | | | |
|---|--|---|---|
| <ul style="list-style-type: none"> 1— Control Valve 2— Pilot Housing 3— Pilot Housing Cap Screw (4 used) 4— Plug 5— O-Ring 6— Plug (3 used) 7— Plug 9— Plug 10— O-Ring 11— Spring 12— Boom Lower Meter-In Cut Valve 13— Boom 1 Spool Bolt (upper) 14— Spring Seat (2 used) 15— Spring 16— Boom 1 Spool | <ul style="list-style-type: none"> 17— Valve 18— Spring 19— O-Ring 20— Boom 1 Spool Bolt (lower) 21— O-Ring (2 used) 22— Boom 2 Spool Bolt 23— Spring Seat (2 used) 24— Spring 25— Boom 2 Spool 26— Backup Ring 27— O-Ring 28— Piston 29— Boom Anti-Drift Valve (selector valve) 30— Boom Anti-Drift Valve (check valve) | <ul style="list-style-type: none"> 31— Valve 32— Plug 33— Overload Relief Valve (Boom Bottom Side) 34— O-Ring 35— Backup Ring 36— O-Ring 37— Backup Ring (2 used) 38— O-Ring (3 used) 39— Orifice 164— Boom Lower Meter-In Cut Valve Assemble 165— Boom 2 Spool Assemble 166— Boom 1 Spool Assemble | <ul style="list-style-type: none"> 167— Boom Anti-Drift Valve (selector valve) 168— Boom Anti-Drift Valve (check valve) 182— Backup Ring (2 used) 183— O-Ring (2 used) 184— Washer 185— Spring 186— Plug 187— O-Ring 188— Plug |
|---|--|---|---|

Control Valve Remove

NOTE: Not all parts are serviceable. Disassembly is for inspection only.

1. Remove control valve. See Control Valve Remove and Install. (Group 3360.)

IMPORTANT: Prevent control valve damage from contamination. Clean dirt and debris from control valve before disassembly.

2. Clean control valve of any dirt or debris before disassembly.

JJ03229,0001197 -19-09DEC15-3/33

Boom Lower Meter-In Cut Valve Assembly (164) Disassemble and Assemble


1. Remove pilot housing cap screws (3) and pilot housing (2).

NOTE: Pilot housing should be installed last if inspection of other parts in this section are needed. If no other parts in this section are being inspected, install pilot housing.

2. Remove plugs (4, 6, 7, and 9) and O-ring (5).
3. Remove O-ring (10), spring (11), and boom lower meter-in cut valve (12).

NOTE: O-rings (21 and 38), backup ring (37), and orifice (39) are shown on main control valve (top front) graphic.

4. Remove O-rings (21 and 38), backup ring (37), and orifice (39).
5. Inspect parts and replace as necessary.
6. Install orifice (39), backup ring (37), and O-rings (21 and 38).
7. Install boom lower meter-in cut valve, spring, and O-ring (10).
8. Install O-ring (5) and plugs into housing.
9. Install pilot housing and pilot housing cap screws. Tighten to specification.



Boom Lower Meter-In Cut Valve

- | | |
|--|---|
| <ul style="list-style-type: none"> 2— Pilot Housing 3— Pilot Housing Cap Screw (4 used) 4— Plug 5— O-Ring 6— Plug (3 used) 7— Plug | <ul style="list-style-type: none"> 9— Plug 10— O-Ring 11— Spring 12— Boom Lower Meter-In Valve 164— Boom Lower Meter-In Cut Valve Assembly |
|--|---|

Specification

Pilot Housing Cap Screw—Torque.....	50 N·m 37 lb·ft
-------------------------------------	--------------------

Continued on next page

JJ03229,0001197 -19-09DEC15-4/33


TX1121769—UN—04SEP12

Digging Regenerative Valve Assembly (169) Disassemble

NOTE: Not all parts are serviceable. Disassembly is for inspection only.

1. Remove cover cap screws (83) and cover (82).
2. Remove digging regenerative valve assembly (169) from pilot plate.
3. Secure digging regenerative valve (88) in a vise using wood blocks. Remove digging regenerative valve bolt (85), spring (86), and washer (87).
4. Inspect for wear and damage.

82— Cover	86— Spring
83— Cover Cap Screw (2 used)	87— Washer
84— O-Ring	88— Digging Regenerative Valve
85— Digging Regenerative Valve Bolt	169— Digging Regenerative Valve Assembly



Digging Regenerative Valve

JJ03229,0001197 -19-09DEC15-21/33


TX1121775—UN—06SEP12

Bypass Shut-Out Valve Assembly (172) Disassemble

NOTE: Not all parts are serviceable. Disassembly is for inspection only.

1. Remove bypass shut-out valve assembly (172).
2. Secure bypass shut-out valve (98) in a vise using wood blocks. Remove bypass shut-out valve bolt (95), spring (96), and washer (97).
3. Inspect for wear and damage.

95— Bypass Shut-Out Valve Bolt	98— Bypass Shut-Out Valve
96— Spring	172— Bypass Shut-Out Valve Assembly
97— Washer	




Bypass Shut-Out Valve

Continued on next page

JJ03229,0001197 -19-09DEC15-22/33

TX1121776—UN—06SEP12



TX1120885

Control Valve (housing-B) (top side)

Continued on next page

JJ03229,0001198 -19-09DEC15-2/26


TX1120885 — UN — 06SEP12

Load Check Valve Assembly (Travel Left Parallel Circuit and Travel Left Tandem Circuit) (122 and 123) Disassemble and Assemble


1. Remove O-rings (67) and backup rings (68).
2. Remove springs (69 and 70) and load check valves (71 and 72).
3. Inspect parts and replace as necessary.
4. Install load check valves, springs, backup rings, and O-rings.

67— O-Ring (2 used)
 68— Backup Ring (2 used)
 69— Spring
 70— Spring

71— Load Check Valve (travel left tandem circuit)
 72— Load Check Valve (travel left parallel circuit)
 122— Load Check Valve Assembly (travel left parallel circuit)
 123— Load Check Valve Assembly (travel left tandem circuit)



Load Check Valve (travel left parallel circuit)



Load Check Valve (travel left tandem circuit)

JJ03229,0001198 -19-09DEC15-19/26

TX1121677 —UN—31AUG12


TX1121678 —UN—31AUG12

Check Valve Assembly (Auxiliary Flow Combiner Circuit) (124) Disassemble and Assemble

1. Remove plug (64).
2. Remove spring (65) and check valve (66).
3. Inspect parts and replace as necessary.
4. Install check valve, spring, and plug.

64— Plug
 65— Spring

66— Check Valve (auxiliary flow combiner circuit)
 124— Check Valve Assembly (auxiliary flow combiner circuit)




Check Valve (auxiliary flow combiner circuit)

Continued on next page

JJ03229,0001198 -19-09DEC15-20/26

TX1121679 —UN—31AUG12



TX1020509

Restriction Valve

TX1020509 —UN—30MAR07

JJ03229,000119A -19-10DEC15-2/2


Arm Cylinder Remove and Install

SPECIFICATIONS	
Arm Cylinder Weight (approximate)	160 kg 353 lb

1. Park and prepare machine for service safely. [See Park and Prepare for Service Safely.](#) (Group 0001.)
2. Position machine as shown. Fully retract bucket cylinder (1) and arm cylinder (2). Lower bucket to ground.

⚠ CAUTION: Avoid personal injury from high-pressure fluid. High-pressure release of oil from pressurized system can cause serious burns or penetrating injury. Relieve pressure from hydraulic system before servicing.

3. Release hydraulic oil tank pressure by pressing the button on top of hydraulic oil tank. [See Hydraulic Oil Tank Pressure Release Procedure.](#) (Group 9025-25.)
4. Apply vacuum to hydraulic oil tank to minimize hydraulic oil loss. [See Apply Vacuum to Hydraulic Oil Tank.](#) (Group 3360.)



Machine Position

1— Bucket Cylinder
2— Arm Cylinder

3— Boom Cylinder

CK90142,0000073 -19-03DEC15-1/3

5. Install identification tags and disconnect hydraulic lines (4 and 5) and lubrication line (6) from arm cylinder. Close all openings using caps and plugs.

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

6. Support arm cylinder using appropriate lifting device.


Specification

Arm Cylinder—Weight (approximate).....	160 kg 353 lb
--	------------------

NOTE: Location of shims (11) should be recorded to aid in assembly.

7. Remove nuts (7), cap screw (8), pin (9), and shims (11) from head end of arm cylinder.


- | | |
|---------------------------------|----------------------|
| 2— Arm Cylinder | 8— Cap Screw |
| 4— Hydraulic Line (to head end) | 9— Pin (head end) |
| 5— Hydraulic Line (to rod end) | 10— Boom |
| 6— Lubrication Line | 11— Shim (as needed) |
| 7— Nut (2 used) | |



Arm Cylinder (head end)

Continued on next page

CK90142,0000073 -19-03DEC15-2/3



TX1134169 —UN—04APR13

TX1134169

Bucket Cylinder Seal Identification

- | | | | |
|-------------------|-----------------|--------------------------|-------------------------------------|
| 1— Barrel | 10— Backup Ring | 18— Wear Ring (2 used) | 23— Set Screw (2 used) |
| 3— Rod | 11— Dust Seal | 19— Wear Ring (2 used) | 24— Socket Head Cap Screw (10 used) |
| 5— Cylinder Head | 12— O-Ring | 20— O-Ring | |
| 6— Bushing | 13— Backup Ring | 21— Backup Ring (2 used) | |
| 7— Retaining Ring | 14— O-Ring | 22— Piston Nut | |
| 8— Seal | 16— Piston | | |
| 9— U-Ring | 17— Seal Ring | | |

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

1. Attach appropriate lifting device and secure cylinder to a work bench. Drain hydraulic oil from cylinder.

Specification

Bucket Cylinder—Weight
(approximate)..... 94 kg
207 lb

2. Pull rod (3) out so piston (16) is against cylinder head (5).

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

3. Connect rod to appropriate lifting device using a lifting strap.

Specification

Bucket Cylinder
Rod—Weight
(approximate)..... 55 kg
121 lb

4. Remove socket head cap screws (24) from cylinder head.

IMPORTANT: Prevent damage to sliding surface of rod. Be sure to pull rod and piston assembly straight out of barrel (1).

5. Remove rod, cylinder head, piston, and piston nut (22) from barrel (1).
6. Secure rod in ST5908 Hydraulic Cylinder Disassembly/Assembly Device.
7. Apply alignment mark on piston nut and rod.
8. Remove staked material from set screw (23) holes using a small air grinder or a drill and bit.
9. Remove set screws.
10. Remove piston nut using ST3262 Piston Nut Tool.
11. Remove piston using ST3370 Piston Tool.
12. Remove seal ring (17), wear rings (18 and 19), O-ring (20), and backup rings (21) from piston.
13. Remove cylinder head from rod.

Mechanical Drive Elements

- | | | | |
|--|--|-----------------------------------|--------------------------|
| 1— Swing Motor | 9— Pin (3 used) | 16— Lock Plate | 25— Ring Gear |
| 2— First Stage Sun Gear | 10— Spring Pin (3 used) | 17— Cap Screw (2 used) | 26— Housing |
| 3— Thrust Plate | 11— Needle Bearing (6 used) | 18— Second Stage Carrier | 27— Lower Roller Bearing |
| 4— Pin (3 used) | 12— Second Stage Planetary Gear (3 used) | 19— Thrust Plate | 28— Seal |
| 5— Spring Pin (3 used) | 13— Thrust Plate (3 used) | 20— Second Stage Sun Gear | 29— Sleeve |
| 6— Needle Bearing (3 used) | 14— Upper Roller Bearing | 21— First Stage Carrier | 30— O-Ring |
| 7— First Stage Planetary Gear (3 used) | 15— Bearing Nut | 23— Cap Screw (8 used) | 31— Shaft |
| 8— Thrust Plate (3 used) | | 24— Ring Gear Cap Screw (12 used) | 32— Drain Plug |
| | | | 33— Drain Line |

- Remove drain plug (32). Drain oil from swing gear case. See Drain and Refill Swing Gear Case Oil. (Operator's Manual.)
- Disconnect drain line (33) from housing (26).
- Install alignment marks between swing motor (1), ring gear (25), housing (26), and upperstructure to aid in assembly.
- Remove swing motor and park brake. See Swing Motor and Park Brake Remove and Install. (Group 4360.)
- Remove first stage carrier (21) and disassemble parts (4—8).
- Remove ring gear cap screws (24) and ring gear (25).
- Remove second stage sun gear (20) and thrust plate (19) from second stage carrier (18). Disassemble parts (9—13) from second stage carrier.

NOTE: Second stage sun gear (20) may be removed separately or with carrier.

NOTE: First stage sun gear (2) and thrust plate (3) can be removed with the swing motor.

Loctite and its related brand marks are trademarks of Henkel Corporation

CK90142,0000066 -19-04DEC17-3/7

- Remove bearing nut (15) from shaft (31) using DFT1237 Swing Gear Case Nut Spanner Wrench. See DFT1237 Swing Gear Case Nut Spanner Wrench. (Group 9900.)

NOTE: Bearing and sleeve are pressed onto shaft.

- Remove upper roller bearing (14).


CAUTION: Avoid possible crushing injury from heavy component. Use appropriate lifting device.

- Remove housing (26) using appropriate lifting device.

Specification

Housing Assembly—Weight (approximate)..... 59 kg
130 lb

15— Bearing Nut



Bearing Nut

Continued on next page

CK90142,0000066 -19-04DEC17-4/7

TX1110936—UN—26MAR12

Mechanical Drive Elements

- 1— Outer Race
- 2— Inner Race
- 3— Steel Ball (99 used)

- 4— Lubrication Fitting (2 used)
- 5— Lower Seal

- 6— Upper Seal
- 7— Spacer (99 used)

1. Park and prepare machine for service safely. See Park and Prepare for Service Safely. (Group 0001.)
2. Inspect swing bearing upper seal (6) and lower seal (5). Replace if damaged. See Swing Bearing Upper


Seal Install or see Swing Bearing Lower Seal Install. (Group 4350.)

CK90142,000006A -19-17NOV15-2/4

3. Grind tack weld (9) off top of taper pin (11).
4. Drive taper pin out from bottom side of bearing.
5. Remove loading plug (10) using an M10-1.5 cap screw.

- 9— Tack Weld
- 10— Loading Plug

- 11— Taper Pin



Swing Bearing Cross Section

CK90142,000006A -19-17NOV15-3/4


TX1092921 —UN—06JUN11

6. Remove steel balls (12) and spacers (13).
7. Turn inner race to remove remaining steel balls and spacers.
8. Lift outer race off inner race.
9. Replace parts as necessary.
10. Install spacers and steel balls. Turn inner race as needed to install spacers and steel balls.
11. Install loading plug.


12. Install taper pin even with top of swing bearing.
13. Tack weld pin to swing bearing. See Welding On Machine. (Group 1740.)
14. Add multipurpose grease to swing bearing through lubrication fittings. See Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease. (Operator's Manual.)
15. If upper or lower seals are damaged, replace seals. See Swing Bearing Upper Seal Install and see Swing Bearing Lower Seal Install. (Group 4350.)

- 12— Steel Ball (99 used)

- 13— Spacer (99 used)



Swing Bearing Cross Section




Swing Bearing Cross Section

CK90142,000006A -19-17NOV15-4/4

TX1092922 —UN—06JUN11

TX1092924 —UN—06JUN11



TX1204442A —UN—270CT15

Swing Gear Case Assembly

- | | | | |
|----------------------------------|--|----------------------------------|--------------------------------------|
| 1—Hydraulic Oil Tank Return Line | 3—Pilot Signal Manifold Hydraulic Line | 6—Swing Motor Cap Screw (7 used) | B32—Front Attachment Pressure Sensor |
| 2—Control Valve Hydraulic Line | 4—Swing Damper Valve Hydraulic Line (2 used) | 7—Swing Motor and Park Brake | |

6. Install identification tags and disconnect hydraulic lines (1—4). Close all openings using caps and plugs.
7. Install identification tag and disconnect front attachment pressure sensor (B32).

⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

8. Support swing motor and park brake (7) using appropriate lifting device.

Specification

Swing Motor and Park Brake—Weight (approximate).....	34 kg 75 lb
--	----------------

9. Remove swing motor cap screws (6). Remove swing motor and park brake.
10. Inspect and repair or replace parts as necessary. See Swing Motor and Park Brake Disassemble. (Group 4360.)
11. Install swing motor and park brake. Install swing motor cap screws. Tighten to specification.

Specification

Swing Motor Cap Screw—Torque.....	64 N·m 47 lb·ft
-----------------------------------	--------------------

12. Connect front attachment pressure sensor (B32).
13. Connect hydraulic lines (1—4). See Hydraulic System Line Connections. (Group 9025-15.)
14. Perform swing motor and park brake start-up procedure. See Swing Motor and Park Brake Start-Up Procedure. (Group 4360.)
15. Remove vacuum or fill hydraulic oil tank. See Apply Vacuum to Hydraulic Oil Tank. (Group 3360.) See Drain and Refill Hydraulic Tank Oil. (Operator's Manual.)

Specification

Hydraulic Oil Tank—Capacity.....	69 L 18.2 gal
----------------------------------	------------------

16. If hydraulic oil tank was drained, perform pump start-up procedure. See Pump 1 and 2 Start-Up Procedure. (Group 3360.)
17. Check hydraulic oil level. See Check Hydraulic Tank Oil Level. (Operator's Manual.)

Continued on next page

JB51320,000011F -19-09NOV15-2/3

Hydraulic System

- 1— Swing Motor Gear Case
- 2— Oil Seal
- 3— Roller Bearing
- 4— Shaft
- 5— Shoe Plate
- 6— Plunger (9 used)
- 7— Plate
- 8— Snap Ring
- 9— Rotor
- 10— Plate (4 used)
- 11— Friction Plate (4 used)
- 12— Cap Screw (4 used)

- 13— O-Ring (2 used)
- 14— Plug (2 used)
- 15— Make-Up Check Valve Plug (2 used)
- 16— O-Ring (2 used)
- 17— Spring (2 used)
- 18— Poppet (2 used)
- 19— Park Brake Valve Casing
- 20— Crossover Relief Valve (2 used)

- 21— O-Ring
- 22— Roller Bearing
- 23— Valve Plate
- 24— Spring Plate
- 25— Brake Piston
- 26— O-Ring
- 27— O-Ring
- 28— O-Ring (3 used)
- 29— Piston
- 30— Spring
- 31— Ball
- 32— Plug (3 used)
- 33— Snap Ring
- 34— O-Ring

- 35— Bushing
- 36— O-Ring (2 used)
- 37— O-Ring (2 used)
- 38— Backup Ring (2 used)
- 39— Backup Ring (2 used)
- 40— O-Ring (2 used)
- 41— O-Ring
- 42— Plug
- 43— Pin (2 used)
- 45— Poppet
- 46— Spring

SPECIFICATIONS	
Park Brake Valve Casing Cap Screw Torque	265 N·m 195 lb
Poppet Plug Torque	235 N·m 173 lb-ft
Swing Motor Crossover Relief Valve Torque	235 N·m 173 lb-ft

1. Install inner race of roller bearings (3 and 22) to shaft (4) using press.
 2. Install oil seal (2) to swing motor gear case (1).
 3. Install outer race of roller bearing (3) to swing motor gear case.
- IMPORTANT: Prevent possible oil seal damage. Wrap tape around shaft splines during installation.**
4. Install shaft (4) and snap rings (33 and 8) to swing motor gear case.
 5. Install shoe plate (5) to case with chamfered side toward swing motor gear case.
 6. Install plate (7) to plungers (6) with notch on retainer facing the shoe plate (5) side.
 7. Align notch and install plate.
 8. Install plungers to rotor (9).
 9. Install rotor to shaft (4).
 10. Starting with a plate (10), alternately install plates and friction plates (11) to swing motor gear case and rotor, aligning the four notches on the outer side of friction plates and on the spline side of plates respectively.
 11. Install O-rings (26 and 27) to case.
 12. Align matching mark and install brake piston (25) into case.
 13. Install spring plate (24) to brake piston.

14. Install ball (31), spring (30), and piston (29) to case.
15. Install outer race of roller bearing (22) to park brake valve casing (19).
16. Install O-ring (21) to park brake valve casing. Apply grease to valve plate (23). Install plate and guide pins (43) to park brake valve casing with notch on port facing toward the rotor (9).
17. Apply grease to needle part of roller bearing (22).
18. Install O-rings (28 and 41).
19. Install poppet (45) and spring (46) into case. Install plugs (32).
20. Install O-ring (41) and plug (42) into swing motor gear case.
21. Install park brake valve casing to swing motor gear case. Tighten cap screws (12) to specification.

Specification

Park Brake Valve Casing Cap Screw—Torque.....	265 N·m 195 lb
---	-------------------

22. Install poppets (18), springs (17), O-rings (16), and make-up check valve plugs (15). Tighten to specification.

Specification

Poppet Plug—Torque.....	235 N·m 173 lb-ft
-------------------------	----------------------

23. Install crossover relief valves (20) to park brake valve casing. Tighten to specification.

Specification

Swing Motor Crossover Relief Valve—Torque.....	235 N·m 173 lb-ft
--	----------------------

JB51320,0000122 -19-29JUN16-2/2

ST4920 Track Recoil Spring Disassembly and Assembly Tool

NOTE: It is recommended that DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool be used with track recoil spring disassembly and assembly tool. See DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool. (Group 9900.)

Dimensions given are metric.

Tool is the same as used on other machines except the holder (C). For each track adjuster use the holder with the correct size hole for the nut on that track adjuster.


Track Recoil Spring Disassembly and Assembly Tool (compression tool) is used with hydraulic jack to compress recoil spring in track adjuster repair.

Material required:

- 1020 HR Steel for Holder (C), Supporting Plate (E), Base Plate (F), and Base (G).
- "D" Grade (SAE Grade 5) for Eyebolts (D), Nuts (A), and Cap Screws (H).
- "F" Grade (SAE Grade 8) for Studs (B).

Print Numbers:

- A-ST4050 Nut
- B-ST4045 Bolt
- C-ST4035 Holder (Plate)
- C-ST4036 Holder (Plate)
- C-ST4037 Holder (Plate)
- D-ST4047 Eyebolt
- E-ST4040 Supporting Base
- F-ST4042 Base Plate
- G-ST4041 Base
- H-ST4046 Cap Screw
- I-ST4049 Lock Washer




- | | |
|--------------------|------------------------|
| A—Nut (12 used) | F—Base Plate |
| B—Stud (4 used) | G—Base (4 used) |
| C—Holder | H—Cap Screw (4 used) |
| D—Eyebolt (2 used) | I—Lock Washer (8 used) |
| E—Supporting Plate | |

Continued on next page

DV53278.0000362 -19-08OCT12-1/4

T6585UY—UN—24MAR98

DFT1119 Pump Support



TX1022920

Pump support is used with a hand hoist to support a pump(s) when an engine is removed.

Two end stands are needed.

Drill the holes through the square steel tubing so they are centered.

Material required:

- C3 x 5 Steel Channel
- 88.9 x 88.9 x 6.35 mm (3.5 x 3.5 x 0.250 in.) Square Steel Tubing

- 76.2 x 76.2 x 6.35 mm (3 x 3 x 0.250 in.) Square Steel Tubing
- 63.5 x 63.5 x 6.35 mm (2.5 x 2.5 x 0.250 in.) Square Steel Tubing
- 19 mm (3/4 in.) Flat Bar Stock
- M10 x 89 mm or 3/8 x 3-1/2 in. D Grade (SAE Grade 5) Cap Screw (2 used)
- M10 or 3/8 in. D Grade (SAE Grade 5) Nut (2 used)

DV53278,0000369 -19-08OCT12-1/1

TX1022920—UN—11JAN08

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL