

444K Loader Repair

TECHNICAL MANUAL

444K Loader Repair

TM10685 03MAR11 (ENGLISH)

For complete service information also see:

444K Loader Test Manual	TM10684
444K Loader Operator's Manual	OMT227993
PowerTech™ 4.5 L and 6.8 L Diesel Engines—Base Engine	CTM104
PowerTech E™ 4.5 L and 6.8 L Diesel Engines—Level 16 Electronic Fuel System with Denso HPCR	CTM502
120 Series Hydraulic Cylinders	CTM114319
125 Series Hydraulic Cylinders	CTM109319
Super Caddy Oil Cleanup Procedure.....	CTM310
JDLink™ / ZXLink™ Machine Monitoring System.....	CTM10006
Specifications Manual.....	SP458
JDLink / ZXLink (MTG) Diagnosis and Tests Manual	TM114519

**Worldwide Construction
And Forestry Division**
LITHO IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Prevent Fires

Handle Fuel Safely: Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep trash, debris, grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines, exhaust components, and electrical wiring. Never store oily rags or flammable materials inside a machine compartment.

Maintain Hoses and Wiring: Replace hydraulic hoses immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Keep A Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use extinguisher properly.



T133553 —UN—07SEP00



T133554 —UN—07SEP00



TX03679,00016F5 -19-03NOV08-1/1

T133552 —UN—14SEP00


Clean Debris from Machine

Keep engine compartment, radiator, batteries, hydraulic lines, exhaust components, fuel tank, and operator's station clean and free of debris.

Clean any oil spills or fuel spills on machine surfaces.

Temperature in engine compartment may go up immediately after engine is stopped. **BE ON GUARD FOR FIRES DURING THIS PERIOD.**

Open access door(s) to cool the engine faster, and clean engine compartment.



OUT4001,00000E3 -19-20AUG09-1/1

T6669AG —UN—18OCT88

**Section 01
Wheels**

Contents

Page

Group 0110—Powered Wheels and Fasteners
Wheel Remove and Install..... 01-0110-1
Tire Remove and Install..... 01-0110-2

CAUTION: Prevent crushing injury from heavy component. Use appropriate lifting device when lifting component.

Specification

Machine—Weight
(approximate).....11 786 kg
25 983 lb.

8. Raise rear of machine using floor jack. Install floor stands under frame on each side and under rear corners of frame.

CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device when lifting component.

9. Remove rear wheels. See Wheel Remove and Install. (Group 0110.)

IMPORTANT: Do not reuse drive shaft universal joint cap screws. Replace cap screws to avoid machine damage.

10. Remove cap screws to disconnect drive shaft.


CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device when lifting component.

Specification

Axle and Differential
with Oscillating
Supports—Weight
(approximate)..... 980 kg
2161 lb.


11. Install low-lift jack under axle and differential.

1— Floor Stand (4 used)



TX1005981A —UN—04APR06

Floor Stand Under Frame




TX1005982A —UN—04APR06

Positioning Floor Stands

Continued on next page

AA95137,0001B43 -19-14AUG08-2/6

Axle Planetary Pinion/Service Brake Housing Disassemble and Assemble



TX1002890

Axle Planetary Pinion/Service Brake Housing

- | | | | |
|--|------------------------------------|-------------------------------|---|
| 1— Axle Planetary Pinion/Service Brake Housing | 6— Inner Bearing Cone | 11— O-Ring | 16— Cylindrical Roller Bearing (3 used) |
| 2— Plug (2 used) | 7— Spindle | 12— Sun Gear | 17— Snap Ring (3 used) |
| 3— Brake Bleeder | 8— Pinion Carrier End Plate | 13— Planetary Pinion (3 used) | 18— Service Brake Disk |
| 4— Outer Housing Seal | 9— Self-Locking Cap Screw (4 used) | 14— Planetary Pinion Carrier | 19— O-Ring |
| 5— Bearing Cone | 10— End Cover | 15— Pin | |


Continued on next page

MH66088,0000996 -19-05SEP08-1/44


TX1002890—UN—10MAY06

30. Clean O-rings (37) using a volatile, non-petroleum base solvent and lint-free tissues. Apply a thin film of oil to O-rings and install.
31. Clean oil from guide ring (36) and guide ring groove using a volatile, non-petroleum base solvent and lint-free tissues.
32. Align end points of guide ring in the 12 o'clock position (as viewed when housing is installed on axle tube).
33. Apply a small amount of Quick Gel Super Glue at both end points of guide ring to maintain its position.

- | | |
|--|---------------------------|
| 1— Axle Planetary
Pinion/Service Brake
Housing | 37— O-Ring (2 used) |
| 36— Guide Ring | 38— Support Ring (2 used) |



TX1006515A —UN—17APR06



TX1006523

Cross-Sectional View


TX1006523 —UN—17APR06

MH66088,0000996 -19-05SEP08-22/44

NOTE: The Illustration shows pins in correct position for piston installation.

34. Orient piston as shown, shoulder side up.
35. Drive service brake piston pins (43) flush with mounting surface (44).

- | | |
|--------------------------|----------------------|
| 35— Service Brake Piston | 44— Mounting Surface |
| 43— Pin (6 used) | |



Service Brake Piston and Pins

TX1006683A —UN—19APR06

Continued on next page


MH66088,0000996 -19-05SEP08-23/44

Axle Shaft, Bearings, Reduction Gears

21. For rear axle, remove cap screws (72) and oscillating support housing (73).

72— Cap Screw (4 used)

73— Oscillating Support Housing



TX1007256A —UN—03MAY06


Oscillating Support Housing (Rear Axle Only)

MM16633,00024F3 -19-13AUG08-17/22

22. Remove yoke nut (43) and washer. Remove yoke (41).

41— Yoke

43— Yoke Nut



TX1006524A —UN—17MAY06

Pinion Nut and Yoke

MM16633,00024F3 -19-13AUG08-18/22

23. Remove pinion seal (39) from differential housing.


NOTE: Outer pinion bearing (38) will come out as pinion is being removed.

24. Using a soft faced mallet, remove pinion (34) and outer pinion bearing (38).

34— Pinion

39— Pinion Seal

38— Outer Pinion Bearing



TX1007322A —UN—17MAY06

Pinion Seal

Continued on next page

MM16633,00024F3 -19-13AUG08-19/22


NOTE: Attempt to obtain highest value within specification.

- Using a torque wrench, check rolling torque of the pinion bearings. If rolling torque is not within specifications, correct with appropriate size spacer ring.

Specification

Pinion Bearing—Torque..... 1.1—2.3 N·m
9.7—20.4 lb-in.

- When correct rolling torque has been obtained, remove yoke.
- Install yoke seal and repeat step 8.



Rolling Torque Check

TX1007328A —UN—04MAY06

MM16633,00024F4 -19-13AUG08-11/34

NOTE: Make sure thrust washers (4) and (2) are installed correctly within tabs of carrier (1).

- Install spacer (3) and thrust washers (2) and (4) into carrier (1).
- Install side gear (5).
- Install pinion gears (6) and beveled thrust washers (7).

NOTE: Access holes (46) are identified by holes that go all the way through carrier.


- Install pinion shaft (8) into bore in side of carrier, opposite access holes (46).
- Install pinion gears (6), thrust washers (7), and split pinion shafts (9) into carrier. Rotate split pinion shafts so holes in end of shafts are seen in access holes (46).

- | | |
|-------------------------|-----------------------------------|
| 1— Carrier | 7— Beveled Thrust Washer (4 used) |
| 2— Thrust Washer | 8— Pinion Shaft |
| 3— Spacer | 9— Split Pinion Shaft (2 used) |
| 4— Thrust Washer | 15— Pin (2 used) |
| 5— Side Gear | 16— Spring Pin (2 used) |
| 6— Pinion Gear (4 used) | 46— Access Holes |



Differential Components

TX1006502A —UN—17MAY06



Pinion Shaft, Gears, and Carrier


TX1007353A —UN—17MAY06

Continued on next page

MM16633,00024F4 -19-13AUG08-12/34

49. If contact pattern differs considerably, correct with appropriate size shim (51). See step 1.

51— Shim



Shim

TX1006642A —UN—18APR06


MM16633,00024F4 -19-13AUG08-31/34

50. Insert shim (57) and axle shaft (58) into sun gear shaft (56).

51. Install shaft assembly into axle tube (68) from differential side.

56— Sun Gear Shaft
57— Shim

58— Axle Shaft



Axle

TX1006678A —UN—19APR06

MM16633,00024F4 -19-13AUG08-32/34

CAUTION: Prevent possible injury from crushing. Heavy component, use appropriate lifting device when lifting component.


52. Install preassembled differential carrier assembly (70) using DFT1273 Lifting Device (64).

Specification

Differential Assembly
—Weight (approximate)..... 45 kg
100 lb

64— DFT1273 Lifting Device
67— Differential Housing

70— Differential Carrier Assembly



Installing Differential

TX1007049A —UN—03MAY06

Continued on next page

MM16633,00024F4 -19-13AUG08-33/34

Torque Converter and Housing Remove

1. Remove transmission. See Transmission Remove and Install. (Group 0350.)

CAUTION: Prevent possible injury from crushing. Heavy component, use appropriate lifting device.


Specification

Transmission—Weight	
(approximate).....	504 kg
	1110 lb


NOTE: Earlier JDG1129 Transmission Mounting Brackets require that the right side bracket be revised. Note bracket sketch showing revised mounting hole (A). Revise hole by elongating the existing hole as required.

2. Install transmission in repair stand using JDG1129 Transmission Mounting Brackets (1).

A—Mounting Hole **1— JDG1129 Transmission Mounting Bracket (2 used)**




Bracket Sketch Showing Revised Mounting Hole (A)



JDG1129 Transmission Mounting Brackets

SW03989,0000422 -19-25FEB08-1/10

3. Remove lock plate and cap screws from input flange washer.
4. Remove washer and input flange from the shaft.




Lock Plate and Cap Screws

Continued on next page

SW03989,0000422 -19-25FEB08-2/10

12. Remove transmission housing from repair stand. Install transmission cover with clutch packs into repair stand using JDG1129A Mounting Brackets. Fasten transmission cover to mounting brackets using cap screws, washers, and nuts as shown.




Mounting Bracket Positions

TX1028696A —UN—29AUG07

MH66O88,0000723 -19-10OCT08-10/19

13. Rotate the repair stand so clutch packs are facing up. This will allow them to be removed from the cover.
14. Remove washers and nuts retaining clutch packs.




TX1049945A —UN—09OCT08

MH66O88,0000723 -19-10OCT08-11/19

15. Clutch pack layout viewed from torque converter side of transmission.

- | | |
|-----------------------------|------------------------------------|
| 6— First Speed Clutch (K1) | 9— Forth Speed Forward Clutch (K4) |
| 7— Second Speed Clutch (K2) | 10— Reverse Clutch (KR) |
| 8— Third Speed Clutch (K3) | 11— Forward Clutch (KV) |



View from Torque Converter Side


TX1028698A —UN—29AUG07

Continued on next page

MH66O88,0000723 -19-10OCT08-12/19

23. Install dowel pins (2).

14— Dowel Pin (2 used)



Dowel Pin Installation

TX1049939 —UN—09OCT08


AA95137,0001B50 -19-10OCT08-21/28

NOTE: Locate hanger in same position as it was removed from.

24. Install housing cover cap screws and tighten to specification.

Specification

Housing Cover Cap	
Screw—Torque.....	46 N·m 34 lb·ft



Torque Cap Screw

T109078 —UN—15APR97

AA95137,0001B50 -19-10OCT08-22/28

NOTE: Grease sealing lip of shaft seal.

25. Using JDG10837 Output Shaft Seal Installer, install shaft seal with the lip facing inward.



Shaft Seal Installation

T109079 —UN—15APR97

Continued on next page

AA95137,0001B50 -19-10OCT08-23/28

NOTE: Push against cone of bearing.

On clutch KR, there is no recess in the shaft. Installation of snap ring will be in contact of bearing cone.

16. Press idler gear against shoulder.




Press Idler Gear Against Shoulder

T108673 —UN—10APR97

MH66O88,00006EC -19-14AUG08-13/18

17. Retain idler gear by means of snap ring.




Retain Idler Gear

T108674 —UN—10APR97

MH66O88,00006EC -19-14AUG08-14/18

18. Assemble pre-assembled plate carrier until all plates are engaged.



Assemble Plate Carrier

T108675 —UN—10APR97

Continued on next page

MH66O88,00006EC -19-14AUG08-15/18

18. Install end shim and snap ring.



End Shim and Snap Ring Installation

T1108738 —UN—10APR97

MH66O88,0000980 -19-20AUG08-14/23

NOTE: For the adjustment of the plate clearance there are snap rings of different thicknesses available that can be used if proper clearance cannot be obtained. To ensure proper measuring result, install plates temporarily without oil.


19. Adjust plate clearance to specification.

Specification

K2 and K3 Clutch Pack

Plate—Clearance..... 1.8—2.0 mm (0.071—0.079 in.)

- a. Press end shim and measure the dimension from the end face/plate carrier to the end shim with depth gauge. Record dimension (No. 1).



End Shim Press

T1108739 —UN—10APR97

MH66O88,0000980 -19-20AUG08-15/23


- b. Press end shim against snap ring (upward) until contact and measure with gauge. Record dimension (No. 2).

Example for Clutch Pack Clearance Check	
Dimension No. 1	8.00 mm (0.315 in.)
Dimension No. 2	6.00 mm (0.236 in.)
Difference = Plate Clearance	2.0 mm (0.079 in.)
Specification = Pack Clearance	1.8—2.0 mm (0.071—0.079 in.)

- c. If a clutch pack clearance is not to specification, correct by using the proper corresponding snap ring from service parts to increase or decrease clearance. Snap rings come in various sizes.

- d. After proper clearance is obtained, remove disks and plates from assembly.

20. Add oil to plates and disks.



Clutch Pack Clearance Check


T1108740 —UN—09MAY97

21. Reassemble clutch pack assembly.

Continued on next page

MH66O88,0000980 -19-20AUG08-16/23

19. Assemble idler gear.



T108991 —UN—14APR97


MH66O88,0000982 -19-15AUG08-15/20

NOTE: Install thrust disk (1) with chamfer facing thrust washer.

20. Install thrust washer (3), bearing (2), and disk (1).

1— Disc
2— Bearing


3— Thrust Washer



T108992 —UN—29APR97

MH66O88,0000982 -19-15AUG08-16/20

21. Assemble K4 carrier assembly onto shaft until seated and all plates are engaged.



T108993 —UN—14APR97

Continued on next page

MH66O88,0000982 -19-15AUG08-17/20

17. Install new O-rings (12) to output shaft and apply light coat of oil to O-rings.

12— O-Ring (2 used)



O-Ring Installation


TX1047532A —UN—20AUG08

MH66088,000099F -19-06OCT08-12/18

18. Install engagement sleeve (11), compression spring (10), retainer (9), and snap ring (8) using a press.

8— Snap Ring
9— Retainer

10— Compression Spring
11— Engagement Sleeve




Engagement Sleeve Installation

TX1047531A —UN—20AUG08

Continued on next page

MH66088,000099F -19-06OCT08-13/18

Transmission Hydraulic Control Valve Remove and Install



TX1048258

Transmission Hydraulic Control Valve Assembly

1— Stud (14 used)
2— Gasket
3— Manifold Plate

4— Nut (14 used)
5— Plate
6— Cap Screw (23 used)

7— Plug
8— O-Ring (8 used)
9— Cap Screw (36 used)


10— Spring
11— Valve Spool
12— Pressure Switch

TW73308,000037C -19-10OCT08-1/6

TX1048258 —UN—09SEP08

1. Replace two cap screws (6) with alignment studs.
2. Remove the remaining cap screws (6) and remove control valve from manifold plate (3).
3. Remove plate (5).

6— Cap Screw (23 used)



TX1048486A —UN—10SEP08

Continued on next page

TW73308,000037C -19-10OCT08-2/6


Hydraulic System

29. Install two alignment studs into housing. Install gasket (5)

Install cover (2), cap screws (1), and remove alignment studs. Tighten to specification.

Specification

Solenoid Cover-to-Housing Cap	5 N·m
Screw—Torque.....	44 lb-in.




Solenoid Cover Installation

T1108692—UN—16APR97

TW73308,000037D -19-12SEP08-14/24

30. Install wiring harness connector (4) with clamp (3) to cover (2).

NOTE: Ensure that the clamp snaps in.



Wiring Harness Connector Installation


T1108693—UN—16APR97

TW73308,000037D -19-12SEP08-15/24

31. Install three compression springs (15) and pressure control valve pistons (14).

32. Install three compression springs (20) and dampening valve pistons (21).

33. Install compression spring (18) and system pressure regulating valve (19).



Valves Installed into Control Valve Block

T1135928—UN—12JAN01

Continued on next page

TW73308,000037D -19-12SEP08-16/24

Section 04 Engine

Contents

Page

Group 0400—Removal and Installation

PowerTech E™ 4.5 L John Deere

Engine 04-0400-1

Engine Remove and Install..... 04-0400-1

Serpentine Belt Remove and
Install 04-0400-6

Start Aid Nozzle Remove and Install


1. Open left engine access door.
2. Disconnect start aid tube (2) from start aid nozzle (1).
3. Loosen start aid nozzle jam nut (4) from start aid nozzle (1).
4. Remove start aid nozzle (1) from air inlet.
5. Clean or replace as necessary. Inspect start aid nozzle O-ring (5) and replace if necessary.

NOTE: Red paint dot indexing mark (3) on nozzle indicates direction of nozzle opening.


6. Apply PM37421 High Strength Thread Lock and Sealer to nozzle before installing into air inlet with red paint dot indexing mark (3) pointing upward and tighten jam nut.
7. Connect start aid tube (2) to start aid nozzle (1).
8. Close left engine access door.

1— Start Aid Nozzle
2— Start Aid Tube
3— Red Paint Dot Indexing
Mark

4— Start Aid Nozzle Jam Nut
5— Start Aid Nozzle O-Ring



Start Aid Nozzle Location



Start Aid Nozzle

TX1021161A —UN—27MAR07

T196125 —UN—10NOV03


MM16633.0002507 -19-22AUG08-1/1

Cooling Package Plenum Remove and Install

⚠ CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

1. Park machine and lower attachment to ground. Allow engine to cool.
2. Turn battery disconnect switch to the OFF position.



⚠ CAUTION: Prevent injury from pressurized coolant. Explosive release of fluids from cooling system can cause serious burns.

Shut off engine. Remove filler cap when cool to touch. Slowly loosen filler cap to relieve the pressure, then remove.

3. Release any pressure from radiator surge tank.

Continued on next page

SW03989,000045A -19-29JUN09-1/4

X9811 —UN—23AUG88

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Fuel Tank Remove and Install

1. Turn battery disconnect switch to the OFF position.

2. Remove counterweights. See Counterweights Remove and Install. (Group 1749.)



TX1046662

TX1046662—UN—08AUG08

Continued on next page

MH66O88.00008EA -19-22AUG08-1/3

**Section 09
Steering System**

Contents

	Page
Group 0960—Hydraulic System	
NeverGrease™ Pin Joints	09-0960-1
Orbital Steering Valve Remove and Install	09-0960-3
Steering Column Remove and Install	09-0960-5
Steering Column Disassemble and Assemble	09-0960-6
Steering Cylinders Remove and Install	09-0960-7
Steering Cylinder Bushings Remove and Install	09-0960-9
Secondary Steering Pump Remove and Install—If Equipped	09-0960-9
Secondary Steering Valve Remove and Install—If Equipped	09-0960-11
Loader Start-Up Procedure (Steering Cylinder)	09-0960-12

Steering Cylinder Bushings Remove and Install

IMPORTANT: Only use a hydraulic puller for removal and installing NeverGrease™ Pin Joint type bushings. Never use slide hammer or impact type puller.

Shimming is required where specified. Some joints are more critical and will be specified


NeverGrease is a trademark of Deere & Company

when required. Alignment in the joint is important to prevent premature wear.

Remove and install bushings in steering cylinder using Hydraulic Puller Set D01047AA. See NeverGrease™ Pin Joints. (Group 3140.)

SW03989,00004B4 -19-19MAR08-1/1

Secondary Steering Pump Remove and Install—If Equipped



TX1035011

Secondary Steering Pump

1— Hydraulic Lines

2— Cap Screw (4 used)

3— Wiring Harness

4— Secondary Steering Pump

CAUTION: Prevent possible injury from unexpected machine movement. Install articulation lock bar before working in frame hinge area.

1. Install articulation lock bar. Stop engine.

Continued on next page

MH66O88.00008F5 -19-23SEP08-1/2


TX1035011 —UN—16JAN08

Active Elements

13. Remove snap ring (25). Remove planetary pinion (27).

25— Snap Ring (3 used)

27— Planetary Pinion (3 used)



Planetary Pinion Removal


TX1007399A —UN—05MAY06

MH66088,0000999 -19-05SEP08-11/30

NOTE: To aid in installation, note order of service brake clutch disks during removal.

14. Remove service brake clutch pack (44). Inspect and replace as necessary.

44— Service Brake Clutch Pack



Service Brake Clutch Pack

TX1007400A —UN—05MAY06


MH66088,0000999 -19-05SEP08-12/30

15. Remove cap screws from spring cover.

16. Remove parts (20—22).

20— Spring Cover
21— Spring Disk

22— Disk Washer



Service Brake Spring

TX1007402A —UN—05MAY06

Continued on next page

MH66088,0000999 -19-05SEP08-13/30

Service Brake Bleeding Procedure


Each axle is equipped with two brake bleed screws, one for each wheel. Brakes must be bled whenever there is a potential for air entering the system.

NOTE: Two people are required to bleed brake system, one to operate brake valve and other to open and close bleed screws.

1. Engage park brake.
2. Put a clear plastic tube on bleed screw (1) and route to hydraulic oil tank or other suitable container.
3. Start engine and run at slow idle.
4. Push and hold brake pedal down until brake bleeding procedure is complete.

IMPORTANT: Stop bleeding procedure if bubbles continue for more than 3 minutes. Check and correct problem, then continue.

5. Open bleed screw until hydraulic oil starts to flow. Close bleed screw when bubbles disappear. Release brake pedal.
6. Repeat procedure for remaining bleed screws.



Service Brake Bleed Procedure

1— Bleed Screw

7. Check hydraulic reservoir oil level. See Check Hydraulic Oil Level. (Operator's Manual.)

TX1005964A —UN—04APR06

MH66088,000099B -19-15AUG08-1/1

Active Elements

1— Drive Shaft Nut	10— Dowel Pin (2 used)	19— O-Ring	28— Inner Seal
2— Washer	11— Spacer	20— Separator Plate (7 used)	29— Plug and O-Ring
3— Cotter Pin	12— Inner Seal	21— Friction Disk (7 used)	30— Plug and O-Ring
4— O-Ring (6 used)	13— Snap Ring	22— Backing Plate	31— Housing
5— Yoke	14— Bearing Cone Assembly	23— Spring (36 used)	32— Outer Seal
6— Outer Seal	15— O-Ring	24— Spring Retainer	33— Yoke
7— Cap Screw (6 used)	16— Shims	25— Drive Shaft	
8— Housing Cover	17— O-Ring	26— Bearing Cone Assembly	
9— Fitting	18— Piston	27— Seal Retainer Snap Ring (2 used)	

NOTE: Yoke (33) is on the splined end of drive shaft (25).

1. Remove yoke (33) from drive shaft (25).
2. Remove cotter pin (3), drive shaft nut (1), washer (2), and yoke (5).
3. Remove seal retainer snap rings (27) and outer seals (6 and 32) from both ends of park brake assembly.
4. Remove spacer (11) and snap ring (13) through the bore of housing cover (8) off of drive shaft (25).

⚠ CAUTION: Prevent possible injury from flying objects. Cover plate under spring pressure. Remove cap screws evenly to avoid possible injury.

5. Remove cap screws (7) evenly.


SW03989,0000394 -19-25MAY10-2/5

NOTE: Remove housing cover and piston as one assembly.

6. Remove housing cover (8) from housing (31).
7. Separate piston (18) with O-rings (15 and 19) and shims (16) from housing cover (8).
8. Remove inner seal (12) from bore of housing cover (8).
9. Remove drive shaft (25), friction disks (21), separator plates (20), bearing cone assemblies (14 and 26) from housing (31).
10. Remove bearing cone assembly (14), separator plates (20), and friction disks (21) from drive shaft (25).
11. Remove bearing cone assembly (26) from drive shaft (25).

NOTE: Bearing cups will be in the housing cover and housing.

12. Remove bearing cups from housing cover (8) and housing (31).




14— Bearing Cone Assembly	21— Friction Disk (7 used)
15— O-Ring	25— Drive Shaft
18— Piston	26— Bearing Cone Assembly
20— Separator Plate (7 used)	

Continued on next page

SW03989,0000394 -19-25MAY10-3/5

TX1029130 —UN—10SEP07

Frame Installation



TX1028964

Center Articulating Point

1— Upper Pivot Pin

3— Lower Pivot Pin

5— Bushing

7— Cap Screw (6 used)

2— Steering Cylinder Pin (2 used)

4— Cap Screw

6— Engine Frame

10. Remove steering cylinder pins (2).

11. Remove cap screw (4).

12. Remove cap screws (7) holding bushing (5) to the frame.

13. Remove lower pivot pin (3). See Lower Pivot Bearing and Seals Remove and Install. (Group 1740.)

14. Remove upper pivot pin (1). See Upper Pivot Bearing and Seals Remove and Install. (Group 1740.)

Continued on next page

SW03989.0000426 -19-13AUG08-2/3

TX1028964 —UN—05SEP07

Section 18 Operator's Station

Contents

	Page		Page
Group 1800—Removal and Installation			
Cab Remove and Install	18-1800-1	Receiver-Dryer Remove and Install	18-1830-14
Group 1810—Operator Enclosure			
Windowpanes Remove and Install	18-1810-1	Condenser Remove and Install	18-1830-15
Cab Door Hold-Open Release Adjust.....	18-1810-1	Air Conditioning High-Low Pressure Switch Remove and Install	18-1830-15
Cab Door Hold-Open Latch Pin Adjust.....	18-1810-1	Fresh Air Filter Remove and Install	18-1830-16
Front and Rear Windshield Wiper Motor Remove and Install.....	18-1810-2	Recirculating Air Filter Remove and Install	18-1830-17
Group 1821—Seat and Seat Belt			
Seat Remove and Install	18-1821-1	Compressor Remove and Install	18-1830-18
Seat Belt Remove and Install	18-1821-1	Compressor Clutch—R134a Disassemble and Assemble	18-1830-19
Group 1830—Heating and Air Conditioning			
Proper Refrigerant Handling.....	18-1830-1	Clutch Hub Clearance—R134a Check	18-1830-20
R134a Refrigerant Cautions.....	18-1830-1		
R134a Compressor Oil Charge Check	18-1830-1		
R134a Compressor Oil Removal.....	18-1830-1		
R134a Component Oil Charge	18-1830-2		
Refrigerant Leak Testing.....	18-1830-2		
Refrigerant Hoses and Tubing Inspection	18-1830-3		
R134a Refrigerant Recovery/Recycling and Charging Station Installation Procedure	18-1830-3		
R134a System Recover.....	18-1830-4		
R134a System Evacuate.....	18-1830-5		
R134a System Charge	18-1830-6		
Air Conditioner System Cleaning Procedures	18-1830-7		
Air Conditioner System Purge	18-1830-7		
Air Conditioner System Flush.....	18-1830-8		
Air Conditioning Module With Heater/Evaporator Coil	18-1830-10		
Heater/Evaporator Coil Remove and Install	18-1830-11		
Expansion Valve Remove and Install	18-1830-12		
Freeze Control Switch Remove and Install	18-1830-12		
Freeze Control Switch Bench Test.....	18-1830-13		
Heater Control Valve Remove and Install	18-1830-13		
Heater Control Valve Leak Check.....	18-1830-13		
Blower Motor Assembly Remove and Install	18-1830-14		


Operator Enclosure

- | | | | |
|------------------------------|---------------------------------------|-------------------------------|---------------------|
| 1— Washer Hose Clip (2 used) | 5— Pivot Retaining Hardware Kit | 9— Rear Wiper Motor | 13— Washer Hose |
| 2— Grommet | 6— Washer Hose Elbow Bulkhead Fitting | 10— Rear Wiper Motor Assembly | 14— Washer Arm Hose |
| 3— Wiper Blade | 7— Pivot Retaining Nut | 11— Rear Wiper Assembly | |
| 4— Wiper Arm | 8— Pivot Washer | 12— Washer Hose Coupler | |

4. Disconnect washer hose (13) at coupler (12).

MH66O88,000072D -19-29JUL08-5/6

5. Remove rear wiper motor mounting plate (16).
6. Lower rear wiper motor (9), mounting plate (16), and wiper arm (4).
7. Remove rear wiper motor from mounting plate.
8. Disassemble parts as shown and replace as necessary.
9. Install rear wiper motor to mounting plate.
10. Install wiper motor and mounting plate with mounting hardware.
11. Connect electrical harness to wiper motor.
12. Connect windshield washer hose to coupler.
13. Install roof.



Rear Windshield Wiper

15— Rear Wiper Motor
Mounting Plate Screws

16— Rear Wiper Motor
Mounting Plate

T196711A—UN—18DEC03

MH66O88,000072D -19-29JUL08-6/6

Air Conditioner System Cleaning Procedures

Flushing: Flushing the system or component is a cleaning process using a liquid solvent to remove oil and debris. Purging is always necessary after flushing to remove solvent from the system or component.

Following is a list of situations that require a flushing procedure be done:

- The compressor has an internal failure.
- No oil remains in used compressor.
- Oil drained from compressor appears or smells overheated.
- System was contaminated with a mixture of refrigerant oils.
- System was left open to the atmosphere long enough for dirt, moisture, or debris to enter the tubing or components.
- System has an internal blockage.

The following solvent is recommended for flushing air conditioner systems. Use only solvents with an equivalent MSDS.

- TY16134 John Deere Air Conditioning System Flushing Solvent

Purging: Purging the system or a component is a cleaning process using a gas to force liquid from the system. Purging alone will not remove refrigerant oil from the system.

Following is a list of situations that require a purging procedure be done:

- After flushing system with solvent, to prevent oil dilution
- System was contaminated with nitrogen or two refrigerants.
- System was left open to the atmosphere and flushing could not be performed.
- Installation of new lines, condenser, or evaporator was required.

Evacuating: Evacuating the system is a process to remove air and moisture from the system, creating a vacuum.

MH66O88,000091C -19-18FEB08-1/1

Air Conditioner System Purge

IMPORTANT: Air compressors used for purging systems require a water separator. Purging without a separator adds moisture, creating hydrofluoric acid when combined with refrigerant oil. Acid is corrosive to metal tubing.

1. Connect dry nitrogen hose to gauge manifold center hose.
2. Connect gauge manifold suction hose to compressor suction port, and open valves.
3. Connect gauge manifold discharge hose to compressor discharge post, and open valve.

Disconnect discharge hose from gauge manifold to allow purging nitrogen to atmosphere.

4. Open nitrogen tank valve and adjust regulator to 275 kPa (40 psi) (2.75 bar). Purge system for two minutes. Disconnect nitrogen supply.

Specification

Nitrogen Tank Valve	
Regulator—Pressure.....	275 kPa
	2.75 bar
	40 psi

5. Evacuate system. See R134a System Evacuate. (Group 1830.)

MH66O88,000091D -19-21FEB08-1/1

Recirculating Air Filter Remove and Install


NOTE: The recirculating air filter is located inside left console.

1. Remove knob (1).
2. Remove console tray (2).
3. Remove recirculating air filter retainer (3).
4. Remove recirculating air filter (4).

⚠ CAUTION: Prevent possible injury from flying debris. Reduce compressed air to less than 210 kPa (2 bar) (30 psi) when using for cleaning purposes. Clear area of bystanders, guard against flying chips, and wear personal protection equipment, including eye protection.


5. Clean filter in one of these ways:
 - Tap filter on a flat surface with the dirty side facing down.
 - Use compressed air opposite to the normal air flow.
 - Wash the filter in warm, soapy water. Flush the filter and let it dry before using the air conditioner.
6. Install recirculating air filter.
7. Install retainer.
8. Install console tray and secure with knob.

- | | |
|--------------------------------------|------------------------------|
| 1— Knob | 4— Recirculating Air Filter |
| 2— Console Tray | 5— Fresh Air Filter Retainer |
| 3— Recirculating Air Filter Retainer | 6— Fresh Air Filter |



Console Tray

TX1037230A —UN—25FEB08



Air Filters

TX1037231A —UN—25FEB08


MH66O88,000092B -19-21FEB08-1/1

Section 31 Loader

Contents

	Page		Page
Group 3102—Bucket			
Bucket Remove and Install	31-3102-1	Main Relief Valve Disassemble and Assemble	31-3160-15
Powerllec Pin-On Bucket Remove and Install	31-3102-2	Load Sense Relief Valve Disassemble and Assemble	31-3160-15
Welded Bucket Cutting Edges Remove and Install	31-3102-3	Circuit Relief With Anticavitation Valve Disassemble and Assemble	31-3160-16
Bolt-On Cutting Edges Remove and Install	31-3102-4	Anticavitation Valve Disassemble and Assemble	31-3160-17
Cracked Cutting Edge Repair	31-3102-4	Boom Cylinder Remove and Install	31-3160-18
Group 3140—Frames			
Loader Bucket Tilt Linkage Remove and Install	31-3140-1	Bucket Cylinder Remove and Install	31-3160-20
Bucket Linkage Seals and Bushings Remove and Install	31-3140-2	Boom and Bucket Cylinder Disassemble and Assemble	31-3160-21
Loader Boom Bushings and Seals Remove and Install	31-3140-3	Boom or Bucket Cylinder Bushings and Seals Remove and Install	31-3160-21
Boom Remove and Install	31-3140-4	Loader Start-Up Procedure	31-3160-22
Powerllec™ Leveling Link Disassemble and Assemble	31-3140-6	Hydraulic Reservoir Remove and Install	31-3160-22
Powerllec™ Bellcrank Remove and Install	31-3140-10	Pilot Control Valve Remove and Install	31-3160-24
Powerllec™ Bucket Cylinder Remove and Install	31-3140-14	Pilot Control Valve Disassemble and Assemble	31-3160-26
Powerllec™ Bucket Link Disassemble and Assemble	31-3140-20	Auxiliary Function Pilot Control Valve Remove and Install	31-3160-28
Powerllec™ Guide Links Remove and Install	31-3140-24	Auxiliary Function Pilot Control Valve Disassemble and Assemble	31-3160-31
Powerllec™ Coupler Disassemble and Assemble	31-3140-28	Pilot Accumulator Remove and Install	31-3160-33
Powerllec™ Loader Boom Disassemble and Assemble	31-3140-32	Hydraulic Pump Manifold Remove and Install	31-3160-34
Hi-Vis Coupler Disassemble and Assemble	31-3140-38	Hydraulic Pump Manifold Disassemble and Assemble	31-3160-36
Group 3160—Hydraulic System			
General Oil Cleanup Procedure	31-3160-1	Ride Control Valve Remove and Install	31-3160-38
Hydraulic Component Failure Cleanup Procedure	31-3160-3	Ride Control Valve Disassemble and Assemble	31-3160-40
Follow-Up Oil Cleanup Procedure	31-3160-5	Pin Disconnect Valve Remove and Install	31-3160-41
Main Hydraulic Pump Remove and Install	31-3160-5	Pin Disconnect Valve Disassemble and Assemble	31-3160-42
Main Hydraulic Pump Disassemble and Assemble	31-3160-8	Hydraulic Fan Pump and Axle Circulation Pump Remove and Install	31-3160-43
Loader Control Valve Remove and Install	31-3160-9	Hydraulic Fan Motor Remove and Install	31-3160-44
Loader Control Valve Disassemble and Assemble	31-3160-11	Reversing Fan Valve Remove and Install	31-3160-46
Boom Section Disassemble and Assemble	31-3160-12	Reversing Fan Valve Disassemble and Assemble	31-3160-47
Bucket Section Disassemble and Assemble	31-3160-13		
Auxiliary Section Disassemble and Assemble	31-3160-14		

15. Install boom cylinder-to-boom pin (1).
16. Install cap screw and washer (2).
17. Remove lifting straps from each side.
18. Install bucket. See Bucket Remove and Install. (Group 3102.)
19. Install bucket linkage. See Bucket Linkage Seals and Bushings Remove and Install. (Group 3140.)
20. Install bucket cylinder. See Bucket Cylinder Remove and Install. (Group 3160.)



TX1032162A —UN—19NOV07

1— Boom Cylinder Pin

2— Cap Screw and Washer

Boom-Cylinder-To-Boom Pin

SW03989,0000744 -19-05SEP08-3/3

Frames

1— Cap Screw (7 used)
 2— Shim (as required)
 3— Guide Link (2 used)
 4— Bucket Link
 5— Bushing
 6— Bushing

7— Bushing
 8— Bellcrank
 9— Pin (2 used)
 10— Pin
 11— Pin (2 used)
 12— Leveling Link

13— Bushing (2 used)
 14— Bushing
 15— Lubrication Fitting (6 used)
 16— Shim (as required)
 17— Seal (4 used)
 18— Seal (6 used)

19— Shim (as required)
 20— Shim (as required)
 21— Bushing (5 used)
 22— Plate (2 used)
 23— Safety Sign (2 used)
 24— Seal (2 used)


SW03989,00004FB -19-26AUG08-2/6

⚠ CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



Escaping Fluid Under Pressure

1. Perform Hydraulic System Pressure and Accumulators Discharge. (Group 9025-25.)

2. Lower boom to ground and remove attachment from coupler.

Continued on next page

SW03989,00004FB -19-26AUG08-3/6

X9811—JUN—23AUG88

Frames

1— Cap Screw (7 used)
2— Shim (as required)
3— Guide Link (2 used)
4— Bucket Link
5— Bushing
6— Bushing

7— Bushing
8— Bellcrank
9— Pin (2 used)
10— Pin
11— Pin (2 used)
12— Leveling Link

13— Bushing (2 used)
14— Bushing
15— Lubrication Fitting (6 used)
16— Shim (as required)
17— Seal (4 used)
18— Seal (6 used)

19— Shim (as required)
20— Shim (as required)
21— Bushing (5 used)
22— Plate (2 used)
23— Safety Sign (2 used)
24— Seal (2 used)

SW03989,00004FD -19-26AUG08-2/6

1. Support boom with 10-ton shop stands. Roll bucket forward until touching ground. If bucket is not attached to coupler, roll coupler forward and support with 10-ton shop stand.

⚠ CAUTION: Prevent possible injury from crushing. Heavy component, use appropriate lifting device.

2. Support bellcrank (8) with appropriate lifting device.




Boom Support

T201101A —UN—13AUG04

Continued on next page

SW03989,00004FD -19-26AUG08-3/6

Frames



T202014

1— Powerllel Loader Boom
 2— Bushing
 3— Bushing

4— Bushing
 5— Bushing
 6— Seal

Powerllel Loader Boom

7— Seal
 8— Seal
 9— Seal

Continued on next page

SW03989,00004FF -19-26AUG08-4/5

T202014—UN—03AUG04

Follow-Up Oil Cleanup Procedure

SPECIFICATIONS	
Elemental Analysis PPM (Parts Per Million) Limit	
Iron Quantity	15 parts per million
Copper Quantity	15 parts per million
Silicon (Silica) Quantity	10 parts per million
Chromium Quantity	8 parts per million
Water Quantity	500 parts per million

Following catastrophic system failure and oil cleanup procedure, oil must be monitored closely. The following checks and tests are to help determine possible causes for contamination which could result in system failure. Systems that experience frequent contamination due to harsh conditions or frequent auxiliary component changes, additional filtering equipment is necessary.

1. Check elemental analysis for excess PPM (parts per million) for iron, copper, silicon (silica), chromium, and water.

Elemental Analysis PPM (Parts Per Million) Limit—Specification
 Iron—Quantity..... 15 parts per million

Copper—Quantity..... 15 parts per million
 Silicon (Silica)—Quantity..... 10 parts per million
 Chromium—Quantity..... 8 parts per million
 Water—Quantity..... 500 parts per million

2. If elemental analysis is above specification, oil filtering is necessary.

Every Six Months for validation purposes use sample valve on Super Caddy to check for correct instrument readings. Results from lab cannot be identical to Super Caddy particle counter readings, but a correlation must exist. If validation testing shows a discrepancy of more than one code per particle size, sample oil again. If discrepancy in instrument readings persist, the particle counter must be checked by PALL Corporation.


Main Hydraulic Pump Remove and Install

NOTE: Check main hydraulic pump flow before removing main hydraulic pump for repair. See Main Hydraulic Pump Flow Test. (Group 9025-25.) If main hydraulic pump does not meet test specification it must be removed. Internal components of the main hydraulic pump rotate group are not serviceable individually. Entire rotate group must be serviced as an assembly.

CAUTION: Prevent possible injury from unexpected machine movement. Install frame articulation lock bar before working in frame hinge area.

1. Install frame articulation lock bar and stop engine.

1— Fitting



Main Hydraulic Pump

TX1028840A —UN—31AUG07

Main Relief Valve Disassemble and Assemble

NOTE: Internal components of main relief valve are not serviceable.

1. Inspect parts for contamination, wear, or damage. Clean or replace as necessary.


IMPORTANT: Coat all internal surfaces with clean hydraulic oil before assembly.

2. Apply clean hydraulic oil to internal surfaces.
3. Apply petroleum jelly to new O-rings before installation.
4. Install main relief valve and tighten to specification.

Specification

Main Relief Valve—Torque.....	60 N·m 44 lb-ft
-------------------------------	--------------------

5. Check pressure setting. See Main Relief Valve Pressure Test. (Group 9025-25.)



Main Relief Valve

- | | |
|--------------------------|--------------------|
| 1— Valve Body | 5— Spring |
| 2— O-Ring | 6— Floating Poppet |
| 3— Floating Pilot Poppet | 7— Pin Poppet |
| 4— Retaining Spring Clip | |

TX1029356 —UN—14SEP07

SW03989,0000441 -19-25APR08-1/1

Load Sense Relief Valve Disassemble and Assemble


1. Loosen nut (2) and remove adjusting screw (1) from body.
2. Inspect parts for wear or damage. Replace if necessary.
3. O-rings (7), backup ring (4) and spring (9) are the only repair parts available.

IMPORTANT: Coat all internal surfaces with clean hydraulic oil.

4. Apply clean hydraulic oil to all internal surfaces during installation.
5. Apply petroleum jelly to new O-rings before installation.
6. Assemble load sense relief valve.
7. Install load sense relief valve and tighten to specification.

Specification

Load Sense Relief Valve—Torque.....	56.4 N·m 500 lb-in.
-------------------------------------	------------------------



Load Sense Relief Valve

- | | |
|--------------------|-----------------|
| 1— Adjusting Screw | 6— Inlet Screen |
| 2— Nut | 7— O-Ring |
| 3— Outlet | 8— Poppet |
| 4— Backup Ring | 9— Spring |
| 5— Inlet | |

8. Check pressure setting. See Load Sense Relief Valve Pressure Test and Adjustment. (Group 9025-25.)

TX1029117 —UN—10SEP07

SW03989,0000442 -19-24APR08-1/1

IMPORTANT: Avoid damage to wires. Do not twist control lever handle or knobs.

NOTE: Remove control lever support to access auxiliary function pilot control valve connections.

The pilot control valve uses Snap-to-Connect® (STC) Fittings. An STC tool is supplied with vehicle and located in operators manual packet.

9. Disconnect pilot control valve lines by performing the following:

- a. Clean around the STC fitting.
- b. Identify hydraulic lines for installation purposes.


IMPORTANT: Do not pry against release sleeve (5) or damage to fitting could result.

Do not force release sleeve beyond normal range of travel, otherwise release sleeve could fall off when hose is disconnected. If damage fitting is connected without the release sleeve installed, fitting will not disconnect again.


- c. Insert JDG1385 Snap-to-Connect (STC) Tool (4) between release sleeve (5) and shoulder (6) of fitting.
- d. Gently push, do not pry, release sleeve away from shoulder to disconnect the STC fitting.
- e. Pull hydraulic line to disconnect.
- f. Close all openings using caps and plugs.

10. Remove pilot control valve (7).
11. Repair or replace parts as necessary.
12. Install pilot control valve.
13. Connect pilot control valve hydraulic lines. See Hydraulic System Component Location. (Group 9025-15.)
14. Connect all electrical connectors to pilot control valve.
15. Remove vacuum and check hydraulic fluid level. Fill hydraulic oil reservoir if drained. See Check Hydraulic Oil Level or see Drain and Refill Hydraulic System Oil. (Operator's Manual.)
16. Install pilot control trim panel and switch pad.
17. Install right armrest assembly.
18. Turn battery disconnect to the ON position.
19. Operate machine and check for leaks at hydraulic line connections.
20. Close access panel.


Snap-to-Connect is a registered trademark of Eaton Corporation



JDG1385 Snap-to-Connect® Tool



Snap-to-Connect® Tool/Pilot Control Valve Lines



Pilot Control Lines (Single Lever with Auxiliary Function Pilot Control Valve Shown)

- | | |
|--|---|
| 4— JDG1385 Snap-to-Connect® (STC) Tool | 7— Pilot Control Valve |
| 5— Release Sleeve | 8— Pilot Control Valve Lines |
| 6— Shoulder | 9— Auxiliary Function Pilot Control Valve Lines |

21. Remove articulation lock bar.

TX1022106 —UN—17APR07

TX1022723A —UN—25APR07

T196380A —UN—24NOV03

Hydraulic System

Hydraulic System

- | | | | |
|--|--|--|---|
| 1— Fan Guard Retaining Cap Screw (6 used)
2— Washer (6 used)
3— Nut (2 used)
4— Hydraulic Fan Motor
5— Bracket | 6— Hydraulic Fan Motor Mounting Cap Screw (2 used)
7— Fan Housing
8— Washer (11 used)
9— Grille Retaining Cap Screw (11 used)
10— Grille | 11— Fan Blade Mounting Cap Screw (6 used)
12— Fan Blade
13— Hub Retaining Nut
14— Hub
15— Nut (6 used) | 16— Washer (4 used)
17— Bracket Mounting Cap Screw (4 used)
18— Fan Guard |
|--|--|--|---|

1. Turn battery disconnect switch to OFF position or disconnect negative battery cable.
2. Remove axle oil cooler (if equipped) and set aside. See Power Train Component Location. (Group 9020-15.)
3. Remove grille retaining cap screws (9), disconnect rear light electrical connectors, and remove grille (10).
4. Remove fan blade mounting cap screws (11) and remove fan blade (12).
5. Apply vacuum or drain hydraulic reservoir into appropriate container for storage or disposal. See Drain and Refill Capacities. (Operator's Manual.)
6. Tag and disconnect hydraulic lines to hydraulic fan motor. Close all openings using caps and plugs.
7. Remove fan guard retaining cap screws (1) and remove fan guard (18).
8. Remove hydraulic fan motor (4) with bracket (5) and hub (14).
9. Remove hub (14) and bracket (5) from hydraulic fan motor (4).
10. Remove hydraulic fittings from hydraulic fan motor.
11. Repair or replace parts as necessary.

12. Install hydraulic fittings to hydraulic fan motor.
13. Install bracket to hydraulic fan motor.

IMPORTANT: Avoid machine damage. Install new fan hub retaining lock nut.

14. Install hub to hydraulic fan motor. Tighten hub retaining nut (13) to specification.

Specification

Hub Retaining Nut—Torque.....	81 N·m 60 lb·ft
-------------------------------	--------------------

15. Install hydraulic fan motor (4) to fan housing (7).
16. Connect hydraulic lines.
17. Remove vacuum or fill hydraulic oil reservoir. See Drain and Refill Capacities. (Operator's Manual.)
18. Install fan guard (18).
19. Install fan blade (12) to hub (14).
20. Connect rear light electrical connectors and install grille (10).
21. Install axle oil cooler (if equipped).

AA95137,0001B54 -19-02OCT08-2/2

Dealer Fabricated Tools

• 311.15 mm (12.25 in.) of 50.80 mm (2.00 in.) x 4.76 mm (0.18 in.) Mild Steel Flat Stock (4 used).

• 558.80 mm (22.00 in.) lengths of 50.80 mm (2.00 in.) X 50.80 mm (2.00 in.) X 4.76 mm (0.18 in) Mild Steel Angle (2 used).

PM10405,00002C0 -19-20AUG08-2/2

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL