

# **450DLC Excavator Repair**

## **TECHNICAL MANUAL 450DLC Excavator Repair**

**TM2362 25JUN08 (ENGLISH)**

**For complete service information also see:**

**450DLC Excavator Operation and Tests . . . TM2361  
Undercarriage Appraisal Manual . . . . . SP326  
450DLC Operator's Manual . . . . . OMT221101**

**Worldwide Construction  
And Forestry Division**  
LITHO IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Recognize Safety Information

**This is the safety alert symbol. When this symbol is noticed on the machine or in this manual, be alert for the potential of personal injury.**

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On the machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T1133555 -UN-28AUG00

T1133588 -19-28AUG00

TX03679.00016CC -19-03JAN07-1/1

## Follow Safety Instructions

Read the safety messages in this manual and on the machine. Follow these warnings and instructions carefully. Review them frequently.

Be sure all operators of this machine understand every safety message. Replace operator's manual and safety labels immediately if missing or damaged.



T1133556 -UN-24AUG00

TX03679.00016F9 -19-03JAN07-1/1

## Operate Only If Qualified

Do not operate this machine unless the operator's manual has been read carefully, and you have been qualified by supervised training and instruction.

Operator should be familiar with the job site and surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to every work situation and work site.

TX03679.00016FA -19-03JAN07-1/1

## Park and Prepare for Service Safely

**Warn others of service work.** Always park and prepare your machine for service or repair properly.


- Park machine on a level surface and lower equipment to the ground.
- Place pilot control shutoff lever in “lock” position. Stop engine and remove key.
- Attach a “Do Not Operate” tag in an obvious place in the operator’s station.



Securely support machine or equipment before working under it.

- Do not support machine with boom, arm, or other hydraulically actuated attachments.
- Do not support machine with cinder blocks or wooden pieces that may crumble or crush.
- Do not support machine with a single jack or other devices that may slip out of place.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



T133332 -19-14DEC01

TS229 -JUN-23AUG88

TX03679,00016E9 -19-24JAN07-1/1

## Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -JUN-23AUG88

DX,RCAP -19-04JUN90-1/1


## Torque Values

### Angle Fitting

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).

*NOTE: Do not allow hoses to twist when tightening fittings.*

4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.



T6620AB -JUN-18OCT88

00  
0003  
7


**STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART**

Thread Size	N•m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

*NOTE: Torque tolerance is  $\pm 10\%$ .*

04T,90,K66 -19-29SEP99-2/2

### O-Ring Face Seal Fittings With Metric Hex Nut And Stud End For High Pressure Service Recommendations



T196337

- 1—90° Swivel Elbow
- 2—90° Adjustable Stud Elbow
- 3—Stud Straight
- 4—Bulkhead Union and Nut
- 5—External Hex Stud End Plug
- 6—Tube Nut
- 7—Swivel Nut
- 8—Stud End
- 9—Hex Nut
- 10—O-Ring
- 11—Identification Groove


**O-RING FACE SEAL FITTINGS WITH METRIC HEX NUT AND STUD END FOR HIGH PRESSURE, ABOVE 27 600 kPa (275.8 bar) (4,000 psi), TORQUE VALUES—Tolerance is +15 -20% unless otherwise specified**

Nominal Tube OD or Hose ID			O-Ring Face Seal Hose or Tube Swivel Nut			Bulkhead Nut	
Metric Tube OD	Inch Tube OD or Hose ID		Thread Size	Hex Size	Torque	Hex Size	Torque
mm	Dash Size	mm (in.)	in.	mm	Nm (lb-ft)	mm	Nm (lb-ft)
4	-2	3.18 (0.125)	—	—	—	—	—
5	-3	4.78 (0.188)	—	—	—	—	—
6	-4	6.35 (0.250)	9/16-18	17	24 (18)	22	32 (24)
8	-5	7.92 (0.312)	—	—	—	—	—
10	-6	9.53 (0.375)	11/16-16	22	37 (27)	27	42 (31)
12	-8	12.70 (0.500)	13/16-16	24	75 (55)	30	93 (69)
16	-10	15.88 (0.625)	1-14	30	103 (76)	36	118 (87)
20	-12	19.05 (0.750)	1-3/16-12	36	152 (112)	41	175 (129)
22	-14	22.23 (0.875)	1-3/16-12	36	152 (112)	41	175 (129)
25	-16	25.40 (1.000)	1-7/16-12	41	214 (158)	46	247 (182)
28	—	—	—	—	—	—	—
32	-20	31.75 (1.250)	1-11/16-12	—	286 (211)	50	328 (242)
38	-24	38.10 (1.500)	2-12	—	326 (240)	60	374 (276)

Continued on next page

OUT3035.0000421 -19-14JAN04-1/2

Track Roller Disassemble and Assemble



TX1008198

1—Roller

2—Axle

3—Bracket

4—Plug

Continued on next page

MD46667,00000AE -19-03AUG06-1/7

01  
0130  
3

TX1008198 -UN-24MAY06

## Track System

Apply equal pressure with the fingers at four equally spaced points on seal ring face. Seal must “pop”

into place so O-ring and seal ring is seated squarely in bore.

*NOTE: A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.*

10. Clean seal ring face using clean oil and lint-free tissues. Apply a thin film of oil to each seal ring face.
11. Install roller (8) and thrust washer (5). Tighten cap screws (9).

### Track Carrier Roller—Specification

Thrust Washer-to-Axle Cap  
Screw—Torque ..... 64 N•m  
47 lb-ft

12. Install O-ring (4) and cover (3). Tighten cap screws (1).

### Track Carrier Roller—Specification

Cover-to-Roller Cap Screw—  
Torque..... 64 N•m  
47 lb-ft

13. Fill roller with 120 mL (4 fl oz) of clean oil. See Track Roller, Front Idler, and Carrier Roller Oil. (See Operator’s Manual.)
14. Apply cure primer and pipe sealant to threads of plug (2). Install plug.



01  
0130  
13

MD46667,00000B0 -19-02AUG06-2/2

## Metal Face Seal Inspection

1. Inspect for the following conditions to determine if seals can be reused:
  - a. The narrow, highly polished sealing area (5) must be in the outer half of seal ring face (4).
  - b. Sealing area must be uniform and concentric with the ID and OD of seal ring (1).
  - c. Sealing area must not be chipped, nicked, or scratched.

- 1—Seal Ring
- 2—Worn Area (shaded area)
- 3—Seal Ring Face
- 4—Outer Half of Seal Ring Face
- 5—Sealing Area (dark line)



TX1008208 -UN-24MAY06

Continued on next page

MD46667,00000D2 -19-02AUG06-1/3

## Track System

12. Install end of chain on sprocket and slowly turn sprocket in forward direction to pull chain across top of frame to front idler.
13. Pull ends of chain together. Install spacers and master pin using master pin pusher installer.
14. Install track shoe. See Track Shoe Remove and Install. (Group 0130.)
15. Perform Check and Adjust Track Sag. (Operator's Manual.)

01  
0130  
23

TX17984,0000009 -19-02AUG06-4/4



**CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

3. Attach track to hoist, remove from frame, and repair or replace.

**Track Adjuster and Recoil Spring—Specification**

Track Adjuster and Recoil

Spring—Weight..... 240 kg approximate  
530 lb approximate

4. See Track Adjuster and Recoil Spring Disassemble and Assemble and see Track Adjuster Cylinder Disassemble and Assemble. (Group 0130.)

5. Install track adjuster and recoil spring in track using hoist.


**Track Adjuster and Recoil Spring—Specification**

Adjusting Nut Out of Hole In

Frame—Distance..... 15 mm  
0.6 in

6. Install front idler and track chain.

See Front Idler Remove and Install and see Track Chain Remove and Install. (Group 0130.)



T6657CY -UN-25OCT88

01  
0130  
33

# Group 0250 Axle Shaft, Bearings, and Reduction Gears


## Travel Gearbox Remove and Install

1. Remove travel gearbox.

MD46667,00000C5 -19-02AUG06-1/5

Swing upperstructure 90° and lower bucket to raise track off the ground. Keep angle between boom and arm 90—110° and position round side of bucket on ground. Put a support stand under the undercarriage.

2. Disconnect track chain. See Track Chain Remove and Install. (Group 0130.)



02  
0250  
1


T6876FG -UN-06DEC88

MD46667,00000C5 -19-02AUG06-2/5



**CAUTION: The hydraulic oil tank is pressurized. High pressure release of oil can cause serious burns or penetrating injury.**

3. Push hydraulic oil tank pressure release button to release pressure in the hydraulic oil tank.



TX1000859 -UN-01DEC05

1—Hydraulic Oil Tank Pressure Release Button  
2—Hydraulic Oil Tank Cover


Continued on next page

MD46667,00000C5 -19-02AUG06-3/5

*Axle Shaft, Bearings, and Reduction Gears*

02  
0250  
11

## Hydraulic System



TX1009094

- |   |   |   |   |
|---|---|---|---|
| <p>1—Housing<br/>2—O-Ring (4 Used)<br/>3—Spring (2 Used)<br/>4—Piston (2 Used)<br/>5—Oil Seal<br/>6—Roller Bearing<br/>7—Shaft<br/>8—Steel Ball ( 2 Used)</p> | <p>9—Swash Plate<br/>10—Piston (9 Used)<br/>11—Retainer<br/>12—Holder<br/>13—Spring (9 Used)<br/>14—Cylinder Block<br/>15—Valve Plate<br/>16—Collar</p> | <p>17—Roller Bearing<br/>18—Plate (5 Used)<br/>19—Friction Plate (4 used)<br/>20—Backup Ring<br/>21—O-Ring<br/>22—O-Ring<br/>23—Backup Ring<br/>24—Brake Piston</p> | <p>25—O-Ring<br/>26—Spring (10 Used)<br/>27—Pin<br/>28—Pin (4 Used)<br/>29—Valve Housing<br/>30—Socket Cap Screw (9 Used)</p> |
|---|---|---|---|

8. Remove cap screws (30) and remove valve (29) and remove O-ring (25).

9. Replace parts as necessary.

10. Install O-ring (25).

11. Install valve (29).

12. Install and tighten cap screws (30).

### Specification

Valve-to-Travel Gearbox Cap	
Screw—Torque .....	400 N•m 295 lb-ft

Continued on next page

MD46667,00000BD -19-02AUG06-4/5

# Section 04 Engine

## Contents

	Page	Page
<b>Group 0400—Removal and Installation</b>		
Engine Remove and Install . . . . .	04-0400-1	
Turbocharger Remove and Install . . . . .	04-0400-6	
Turbocharger Disassemble and Assemble . . . . .	04-0400-8	
Turbocharger Inspection . . . . .	04-0400-16	
Exhaust Manifold Remove and Install . . . . .	04-0400-20	
Upper Valve Cover Remove and Install. . . . .	04-0400-21	
Lower Valve Cover Remove and Install. . . . .	04-0400-22	
Rocker Arm Shaft Assembly Remove and Install. . . . .	04-0400-24	
Rocker Arm Shaft Assembly Disassemble and Assemble . . . . .	04-0400-25	
Rocker Arm Shaft Assembly Inspection. . . . .	04-0400-26	
Intake Manifold Remove and Install. . . . .	04-0400-28	
Lead Valve Remove and Install. . . . .	04-0400-30	
Water Pump Remove and Install. . . . .	04-0400-31	
Water Pump Disassemble and Assemble. . . . .	04-0400-32	
Cylinder Head Remove and Install . . . . .	04-0400-35	
Cylinder Head Disassemble and Assemble. . . . .	04-0400-38	
Cylinder Head Inspection . . . . .	04-0400-47	
Timing Gear Case Remove and Install . . . . .	04-0400-53	
Cylinder Block Disassemble and Assemble. . . . .	04-0400-59	
Cylinder Block Inspection . . . . .	04-0400-61	
Camshaft Remove and Install . . . . .	04-0400-63	
Camshaft Inspection . . . . .	04-0400-64	
Flywheel Remove and Install. . . . .	04-0400-66	
Flywheel Disassemble and Assemble . . . . .	04-0400-68	
Flywheel Housing Remove and Install. . . . .	04-0400-70	
Oil Pan Remove and Install. . . . .	04-0400-72	
Crankshaft Remove and Install . . . . .	04-0400-73	
Crankshaft Inspection . . . . .	04-0400-78	
Piston and Connecting Rod Remove and Install. . . . .	04-0400-85	
Piston and Connecting Rod Disassemble and Assemble. . . . .	04-0400-88	
Piston and Connecting Rod Inspection . . . . .	04-0400-89	
Engine Oil Pump Remove and Install . . . . .	04-0400-95	
Engine Oil Pump Disassemble and Assemble. . . . .	04-0400-98	
Engine Oil Pump Inspection . . . . .	04-0400-100	
Engine Oil Cooler Remove and Install. . . . .	04-0400-102	
Engine Oil Cooler Disassemble and Assemble. . . . .	04-0400-104	
Thermostat Housing Remove and Install. . . . .	04-0400-106	
Thermostat Remove and Install. . . . .	04-0400-107	
Thermostat Inspection. . . . .	04-0400-108	
Primary Exhaust Gas Recirculation (EGR) Cooler Remove and Install. . . . .	04-0400-109	
Secondary Exhaust Gas Recirculation (EGR) Cooler Remove and Install . . . . .	04-0400-110	
High Pressure Fuel Pump Remove and Install. . . . .	04-0400-111	
High Pressure Fuel Rail Remove and Install. . . . .	04-0400-113	
Fuel Injection Nozzle Remove and Install. . . . .	04-0400-114	
Starter Motor Remove and Install . . . . .	04-0400-116	
Serpentine Belt Remove and Install . . . . .	04-0400-117	
Alternator Remove and Install . . . . .	04-0400-118	

04

Removal and Installation


1—Turbine Housing	12—Lock Nut	23—Piston Ring	82—Thrust Sleeve
2—Compressor Impeller	14—Bearing (2 used)	35—Clamp	83—Thrust Bearing
3—Bearing Housing	15—Bearing	63—Insert	84—Thrust Ring
5—Turbine Back Cover	17—Snap Ring	72—O-Ring	85—Turbocharger
6—Shaft and Turbine Impeller	18—Snap Ring (2 used)	73—O-Ring	86—Snap Ring
7—Compressor Housing	22—Piston Ring	80—Oil Deflector	87—Turbocharger (complete)

GD61784,0000003 -19-02AUG06-2/16

**IMPORTANT:** When assembling the relationships between compressor cover, bearing housing, and turbine housing is very important.

1. Remove clamp (35).
2. Make reference marks on the turbine housing (1), compressor housing (7) and bearing housing to ensure proper assembly.

1—Turbine Housing  
7—Compressor Housing  
35—Clamp



Turbocharger


04  
0400  
9

TX1008230 -UN-06JUN06

GD61784,0000003 -19-02AUG06-3/16

3. Remove turbine housing (1).

1—Turbine Housing



Turbocharger Housing

TX1008256 -UN-06JUN06

Continued on next page


GD61784,0000003 -19-02AUG06-4/16

Removal and Installation

7. Install a new piston ring into insert and measure piston ring joining section clearance.

Specification	
Piston Ring Joining Section—	
Clearance .....	0.05—0.25 mm 0.002—0.010 in.

- 23—Piston ring
- 63—Insert
- 90—Joining section



TX1008281 -JUN-06JUN06

04  
0400  
19

TX17984.000001D -19-31JUL06-7/7

*Removal and Installation*

- 1—Gasket
- 2—Plug
- 3—Spring

- 4—Nut
- 5—Intake Pipe
- 6—Intake Air Temperature Sensor

- 7—Cap Screw
- 8—Gasket

- 9—Intake Manifold

1. Remove lead valves. See Lead Valve Remove and Install. (Group 0400.)
2. Disconnect wiring harness.
3. Remove air inlet pipe and install plug in turbocharger outlet.
4. Remove final fuel filter. See Final Fuel Filter Remove and Install. (Group 0560.)
5. Remove fuel injector pressure lines.
6. Remove intake pipe (5) and discard gasket (8). Close openings using caps and plugs.
7. Remove intake manifold (9) and discard gaskets (1).
8. Inspect and repair as needed.
9. Install intake manifold. Tighten nuts to specification.

**Specification**

Intake Manifold Nut—Torque..... 20 N•m  
32 lb-ft

10. Install intake pipe. Tighten cap screws to specification.

**Specification**

Intake Pipe Cap Screw—  
Torque..... 39 N•m  
29 lb-ft

11. Install fuel injector lines. Tighten to specification.

**Specification**

Fuel Injector Line Fittings—  
Torque..... 39 N•m  
29 lb-ft

12. Install Final Fuel Filter. See Final Fuel Filter Remove and Install. (Group 0560.)

13. Connect wiring harness.

14. Install lead valves. See Lead Valve Remove and Install. (Group 0400.)

04  
0400  
29

Removal and Installation


4. Measure clearances of the idle gear C.

	<b>Specification</b>	
Idle Gear C—Clearance .....		0.05-0.14 mm new
		0.25 mm limit of use
		0.002-0.006 in. new
		0.01 in. limit of use

5. Remove the O-ring for the gear case.

6. Remove idle gear shaft C.

21—Idle Gear C



TX1009926 -JUN-20JUL06

04  
0400  
39

TX17984,0000027 -19-03AUG06-2/23

7. Remove idle gear C.

8. Remove gear case.

9. Remove split collar using 1-8523-5013-0 Compressor.

10. Remove upper spring sheet.

11. Remove valve spring and valve.

12. Number each valve cylinder.


13. Remove valve spring.

14. Remove lower spring sheet.


15. Remove valve.

16. Remove valve stem oil seal.

6—Split Collar  
21—Idle Gear C



TX1009927 -JUN-20JUL06




TX1009930 -JUN-20JUL06

Continued on next page

TX17984,0000027 -19-03AUG06-3/23

Removal and Installation

6. Inspect the valve stem end for wear. Repair slight abrasions using an oil stone.



TX1009940 -UN-20JUL06

TX17984.0000028 -19-03AUG06-3/9


7. Measure the amount of wear of valve stem at the three points shown.

**Specification**

Intake Valve Stem—OD ..... 10 mm new  
9.92 mm limit of use  
0.394 in. new  
0.391 in. limit of use

**Specification**

Exhaust Valve Stem—OD ..... 10 mm new  
9.90 mm. limit of use  
0.394 in. new  
0.390 in. limit of use



04  
0400  
49

TX1009941 -UN-20JUL06

Continued on next page

TX17984.0000028 -19-03AUG06-4/9


Removal and Installation

31. Install crankshaft pulley cap screws and tighten in sequence to specification.

**Specification**

Crankshaft Pulley-to-Crankshaft  
 Cap Screws—Torque ..... 267 N•m  
 197 lb-ft

32. Install oil pan. See Oil Pan Remove and Install. (Group 0400.)
33. Install cylinder head. See Cylinder Head Remove and Install. (Group 0400.)
34. Install alternator. See Alternator Remove and Install. (Group 0400.)




TX1010148 -UN-18JUL06

04  
0400  
59

TX17984.0000029 -19-03AUG06-10/10

**Cylinder Block Disassemble and Assemble**

1. Remove oil pressure relief valve (2) and gasket (1).
2. Remove oil pressure switch (7), adapter (6) and gasket (5).
3. Remove oil jets (8).
4. Remove cylinder liners (3).
5. Perform Cylinder Block Inspection. (Group 0400.)



T145045

- 1—Gasket
- 2—Oil Pressure Relief Valve
- 3—Cylinder Liner (6 used)
- 4—Cylinder Block
- 5—Gasket
- 6—Adapter
- 7—Oil Pressure Switch
- 8—Oil Jet (6 used)
- 9—Banjo Fitting (6 used)
- 10—Lower Crankcase

T145045 -UN-08FEB02


Continued on next page

TX17984.000002A -19-31JUL06-1/3

Removal and Installation

2. Remove ring gear (1) a hammer and drift or brass punch.
3. Inspect and repair as necessary.

1—Ring Gear  
2—Flywheel



T144417

T144417 -UN-08FEB02

04  
0400  
69

TX17984,0000031 -19-31JUL06-2/3




**CAUTION:** Prevent possible burn injury. Hot equipment and fluids can cause burns to unprotected skin. Wear gloves and protective cloths when working with hot equipment and fluids.

4. Heat ring gear uniformly with torch.

**Specification**

Ring Gear—Temperature ..... 200°C or less  
390°F or less

5. Install ring gear on flywheel with largest chamfer side to flywheel. Push ring gear on until bottomed out on flywheel.



TX1008651 -UN-16JUN06

TX17984,0000031 -19-31JUL06-3/3

**CAUTION:** Prevent possible crushing injury from heavy component. Use appropriate lifting device.

**IMPORTANT:** Crankshaft must not be ground as it has been treated by soft nitriding to enhance crankshaft strength.



1. When slinger remains on crankshaft, use 1-8521-0027-0 Slinger Remover to remove it.

**Specification**

Crankshaft—Weight..... 155 kg approximate  
340 lb approximate

2. Use 1-8521-0064-0 Crankshaft Gear Remover and remove crankshaft gear (3).

- 1—Dowel Pin
- 2—Crankshaft
- 3—Crankshaft Gear



T144471

TX1010143 -UN-18JUL06

04  
0400  
79

T144471 -UN-08FEB02

Continued on next page

GD61784.0000011 -19-03AUG06-2/9

*Removal and Installation*

15. Verify that piston rings rotate smoothly in piston ring grooves.

GD61784,0000015 -19-24JUL06-2/2

**Piston and Connecting Rod Inspection**

1. Insert piston ring horizontally (in position it would be in if it were installed in piston) into cylinder liner bore.
2. Push ring into cylinder liner bore until it reaches point where bore is smallest. Do not allow ring to slant, it must remain perfectly horizontal.
3. Measure piston ring gap using a feeler gauge.

**Specification**

1st Compression Ring, 3rd Compression Ring, Oil Ring—	
Gap.....	0.35—0.50 mm new 1.0 mm limit of use 0.014—0.02 in. new 0.039 in. limit of use
2nd Compression Ring—Gap .....	0.80—0.95 mm new 1.5 mm limit of use 0.031—0.037 in. new 0.059 in. limit of use

Piston ring must be replaced when ring gap exceeds specification.

Continued on next page

GD61784,0000016 -19-02AUG06-1/6

04  
0400  
89


Removal and Installation

13. Install pilot gear in oil pump housing.
14. Install driven gears in oil pump housing.
15. Install oil pump housing cover.
16. Tighten cap screws (9 and 11) to specification.

**Specification**

Oil Pump Cover-to-Oil Pump  
Housing Cap Screw—Torque..... 18 N•m  
159 lb-in.

T144817



1—Oil Pump Drive Gear  
2—Pilot Gear Shaft

**Specification**

Oil Pump Cover-to-Oil Pump  
Housing Cap Screw M10—  
Torque ..... 39 N•m  
29 lb-ft

17. Install relief valve.
18. Install spring.
19. Install spring seat.
20. Install cotter pin. Bend long leg of cotter pin 90°.
21. Install ball.
22. Install cover. Tighten cap screws (1) to specification.

**Specification**


Oil Pump Relief Valve  
Cover-to-Oil Pump Housing—  
Torque ..... 18 N•m  
159 lb-in.

T144817 -UN-08FEB02

04  
0400  
99

TX17984,000003B -19-01AUG06-2/2

**Primary Exhaust Gas Recirculation (EGR) Cooler Remove and Install**



**TX1010294**

- |  |  |                    |                |
|--|--|--------------------|----------------|
| 1—Spacer (3 used)                                | 3—Cap Screw (3 used)                               | 5—Water Inlet Pipe | 7—Nut (3 used) |
| 2—Primary Exhaust Gas Recirculation (EGR) Cooler | 4—Secondary Exhaust Gas Recirculation (EGR) Cooler | 6—Air Duct         |                |

1. Drain engine coolant. See Drain Cooling System. (Operator's Manual.)
2. Remove water inlet pipe (5).
3. Remove water return pipe.
4. Remove primary exhaust gas recirculation (EGR) cooler (6) and discard gaskets.
5. Repair and replace as necessary.
6. Install primary exhaust gas recirculation (EGR) cooler with new gaskets.
7. Install water return pipe.
8. Install water inlet pipe.
9. Perform Cooling System Fill and Deaeration Procedure. (Operator's Manual.)

GD61784.0000020 -19-01AUG06-1/1

04  
0400  
.109

TX1010294 -UN-20JUL06

# Section 05 Engine Auxiliary System

## Contents

### Page

#### Group 0510—Cooling System

Radiator Remove and Install . . . . .	.05-0510-1
Hydraulic Oil Cooler Remove and Install . . . . .	.05-0510-2
Intercooler Remove and Install . . . . .	.05-0510-4
Fuel Cooler Remove and Install . . . . .	.05-0510-6
Cooling Package Remove and Install . . . . .	.05-0510-7
Fan, Fan Guard, and Fan Shroud Remove and Install . . . . .	.05-0510-19
Coolant Recovery Tank Remove and Install . . . . .	.05-0510-20


#### Group 0520—Intake System

Air Intake System Leakage Check . . . . .	.05-0520-1
Air Cleaner Remove and Install . . . . .	.05-0520-2

#### Group 0560—External Fuel Supply System

Fuel Tank Remove and Install . . . . .	.05-0560-1
Primary Fuel Filter (Water Separator) Remove and Install . . . . .	.05-0560-3
Final Fuel Filter Remove and Install . . . . .	.05-0560-4

Cooling System



05  
0510  
9

TX1010436

3—Rear Cover  
4—Cap Screw (20 used)

5—Front Cover  
6—Intercooler

7—Cooling Package  
8—Cap Screw (4 used)

9—Cooling Package Door

Continued on next page

GD61784,0000026 -19-01AUG06-3/19

Cooling System

39. Close cooling package door (9).



**CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

40. Install rear engine hood.

**Specification**

Rear Engine Hood—Weight..... 23 kg approximate  
50 lb approximate

41. Install front engine hood.

**Specification**

Front Engine Hood—Weight..... 32 kg approximate  
71 lb approximate

42. Perform Cooling System Fill and Deaeration Procedure. (Group 1830.) Approximate capacity is 46 L (12 gal).

43. Fill hydraulic oil. See Hydraulic Oil. Approximate capacity is 322 L (85 gal).

GD61784,0000026 -19-01AUG06-19/19

**Fan, Fan Guard, and Fan Shroud Remove and Install**

See Fan Drive Motor Remove and Install. (Group 3360.)

TX17984,000004A -19-18JUL06-1/1

05  
0510  
19

# Section 07 Dampener Drive (Flex Coupling)

## Contents

### Page

#### Group 0752—Elements


Dampener Drive (Flex Coupling) Remove and  
Install . . . . .07-0752-1

**Counterweight Remove and Install**

**CAUTION:** Avoid crushing injury from heavy component. Use appropriate lifting device.

1. Attach appropriate lifting device to lifting bracket on counterweight.

	Specification
Counterweight—Weight.....	9150 kg 20,200 lb



Counterweight

TX1009184 -UN-05JUL06

Continued on next page

TX17984.0000055 -19-16JUN06-1/3

Removal and Installation

- 0—Cover
- 1—Tray
- 3—Cap (5 used)

- 4—Air Duct
- 7—Electrical Connector Terminal


- 11—Screw (6 used)
- 12—Cap Screw with Washer

- 13—Mechanical Lighter
- 14—Isolator (3 used)

- 13. Remove trim cover (0) and rear tray (1) behind seat.

TX17984,0000056 -19-07JUL06-6/11

- 14. Remove cap screws (18, and 23) that attach bracket to cab.
- 15. Remove fresh air duct (24) and filter on left side of cab.
- 16. Remove fresh air duct (22) behind A/C unit.
- 17. Remove cap screws (19) that hold MCF (21) to back of cab and lay MCF to the side.
- 18. Feed electrical connectors through hole (20) in back of cab.
- 19. Disconnect electrical connectors (25) from the rear corners of the cab.



Panel Behind Seat

- 18—Cap Screw
- 19—Cap Screw
- 20—Hole in Rear of Cab
- 21—MCF (main controller)
- 22—Fresh Air Duct
- 23—Cap Screw
- 24—Fresh Air Duct
- 25—Electrical Connectors

TX1006392A -UN-10JUL06

Continued on next page

TX17984,0000056 -19-07JUL06-7/11

18  
1800  
5

*Operator Enclosure*


**1—Black Ceramic Coating  
Range**

Continued on next page

AH91621,00002B2 -19-26JUL06-5/22


18  
1810  
7

Operator Enclosure



TX1008302 -UN-31MAY06

AH91621.00002B2 -19-26JUL06-17/22



TX1008303 -UN-31MAY06

Dam Rubber

Continued on next page

AH91621.00002B2 -19-26JUL06-18/22

18  
1810  
17

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

*Seat and Seat Belt*

0—Seat Assembly  
2—Cushion Cover  
3—Pad  
4—Cushion  
5—Pad  
6—Frame  
7—Cable

8—Handle  
9—Stand  
10—Spring  
11—Seat Slide Track Kit  
14—Lever Kit  
15—Bearing Kit

16—Compressor  
17—Lever  
18—Torsional Damper  
19—Air Spring Seat Kit  
20—Valve  
21—Hose Kit

22—Seat Suspension  
23—Seat Suspension Boot Kit  
24—Seat Adjustment Cable Kit  
25—Wiring Lead  
26—Head Rest  
27—Heater

TX17984.000005E -19-05JUN06-2/2

18  
1821  
7

## Evacuate R134a System



**CAUTION: Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.**

**Do not remove high pressure relief valve. Air conditioning system will discharge rapidly causing possible injury.**

1. See Refrigerant Cautions and Proper Handling. (Group 1830.)
2. Connect refrigerant recovery system. See R134a Refrigerant Recovery/Recycling and Charging Station Installation Procedure. (Group 1830.)
3. Open low-side and high-side valves on refrigerant recovery/recycling and charging station.
4. Follow charging station manufacturers' instructions to evacuate system.
5. Evacuate system until low-side gauge vacuum reading is to specification.

Vacuum specification listed is for sea level conditions. Subtract the specified value for elevation above sea level.

### Specification

Evacuate System—Vacuum..... 98 kPa  
 980 mbar  
 29 in. Hg

#### Value to Subtract for Elevation

Above Sea Level—Vacuum..... 3.4 kPa from 98 kPa for each  
 300 m elevation above sea  
 level  
 34 mbar from 980 mbar for  
 each 300 m elevation above  
 sea level  
 1 in. Hg from 29 in. Hg for each  
 1000 ft elevation above sea  
 level

If the specified vacuum reading cannot be obtained in 15 minutes, check the system for leaks. See Refrigerant Leak Test. (Group 9031-25.)

6. Close low-side and high-side valves when specified vacuum reading is obtained.
7. Turn vacuum pump off.
8. Observe the gauge for 5 minutes to see if the vacuum decreases. A vacuum decrease more than the specification indicates a leak in the system.

### Specification

Allowable System Decrease—  
 Vacuum..... 3.4 kPa  
 34 mbar  
 1 in. Hg

Repair the leak. See Refrigerant Leak Test. (Group 9031-25.)

9. Start the vacuum pump.

Open low-side and high-side valves.

Continue to evacuate the system for 30 minutes.

### Specification

Evacuation Procedure—Time..... 30 minutes

10. Close low-side and high-side valves. Turn vacuum pump off.
11. Perform Charge R134a System. (Group 1830.)

# Section 33 Excavator

## Contents

	Page	Page
<b>Group 3302—Buckets</b>		
Bucket Remove and Install . . . . .	33-3302-1	
Bucket Pin-Up Data . . . . .	33-3302-4	
<b>Group 3340—Frames</b>		
Bucket Links Remove and Install . . . . .	33-3340-2	
Arm Remove and Install . . . . .	33-3340-4	
Boom Remove and Install . . . . .	33-3340-9	
Inspect Pins, Bushings and Bosses—Front Attachment . . . . .	33-3340-16	
Bushings and Seal Remove and Install . . . . .	33-3340-20	
<b>Group 3360—Hydraulic System</b>		
Apply Vacuum to Hydraulic Oil Tank . . . . .	33-3360-1	
Hydraulic Circuit Pressure Release Procedure . . . . .	33-3360-2	
Pump 1 and 2 Remove and Install . . . . .	33-3360-3	
Pump 1 and 2 Disassemble and Assemble . . . . .	33-3360-10	
Pump 1 and 2 Inspection . . . . .	33-3360-21	
Pump 1 and 2 Start-Up Procedure . . . . .	33-3360-22	
Pump 1 and 2 Regulator Remove and Install . . . . .	33-3360-24	
Pump 1 and 2 Regulator Disassemble and Assemble . . . . .	33-3360-26	
Pilot Pump Remove and Install . . . . .	33-3360-30	
Pilot Pump Disassemble and Assemble . . . . .	33-3360-31	
Pilot Filter and Pressure Regulating Valve Remove and Install . . . . .	33-3360-32	
Pilot Filter and Pressure Regulating Valve Disassemble and Assemble . . . . .	33-3360-34	
Pilot Shutoff Solenoid Valve Remove and Install . . . . .	33-3360-34	
Pilot Shutoff Solenoid Valve Disassemble and Assemble . . . . .	33-3360-36	
Fan Drive Pump Remove and Install . . . . .	33-3360-38	
Fan Drive Pump Disassemble and Assemble . . . . .	33-3360-42	
Fan Drive Pump Regulator Remove and Install . . . . .	33-3360-47	
Fan Drive Pump Regulator Disassemble and Assemble . . . . .	33-3360-48	
Fan Drive Motor Remove and Install . . . . .	33-3360-52	
Fan Drive Motor Disassemble and Assemble . . . . .	33-3360-74	
Fan Drive Reversing Control Valve Remove and Install . . . . .	33-3360-76	
Fan Drive Reversing Control Valve Disassemble and Assemble . . . . .	33-3360-82	
Fan Drive System Relief Valve Remove and Install . . . . .	33-3360-83	
Solenoid Valve Manifold Remove and Install . . . . .	33-3360-85	
Solenoid Valve Remove and Install—Power Dig (SG), Travel Speed (SI), Boom Mode (SC) and Boom Flow Rate (SF) . . . . .	33-3360-86	
Pump Case Drain Filter and Bypass Valve Remove and Install . . . . .	33-3360-88	
Pilot Control Valve Remove and Install . . . . .	33-3360-89	
Pilot Control Valve Disassemble and Assemble . . . . .	33-3360-94	
Boom Up Shockless Valve Remove and Install . . . . .	33-3360-101	
Boom Up Shockless Valve Disassemble and Assemble . . . . .	33-3360-104	
Travel Pilot Control Valve Remove and Install . . . . .	33-3360-105	
Travel Pilot Control Valve Disassemble and Assemble . . . . .	33-3360-108	
Pilot Accumulator Remove and Install . . . . .	33-3360-112	
Pilot Check Valve Manifold Remove and Install . . . . .	33-3360-115	
Digging Sensor Manifold Remove and Install . . . . .	33-3360-119	
Travel Sensor Manifold Remove and Install . . . . .	33-3360-121	
Pilot Signal Manifold Remove and Install . . . . .	33-3360-123	
Pilot Signal Manifold Disassemble and Assemble . . . . .	33-3360-126	
Counterweight Pilot Control Valve Remove and Install . . . . .	33-3360-129	
Counterweight Pilot Control Valve Disassemble and Assemble . . . . .	33-3360-132	
Counterweight Slow Return Valve Remove and Install . . . . .	33-3360-133	
Counterweight Shutoff Valve Remove and Install . . . . .	33-3360-135	

Continued on next page

Frames

- 1—Pin Fastener
- 2—Cap Screw (4 used)
- 3—Nut (8 used)
- 4—Bucket
- 5—O-Ring (4 used)

- 6—Seal (2 used)
- 7—Link
- 8—Washer
- 9—Washer
- 10—Washer

- 11—Washer
- 12—Link
- 13—Link
- 14—Pin Fastener

- 15—Pin Fastener
- 16—Cylinder
- 17—Arm
- 18—Pin

 **CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

1. Lower bucket (4) to the ground with flat surface resting on the ground to prevent roll over.

	Specification	
Bucket—Weight .....		1633 kg approximate 3600 lb approximate

	Specification	
Bucket Link—Weight .....		185 kg approximate 408 lb approximate

	Specification	
Arm Link—Weight.....		53 kg approximate 118 lb approximate

2. Slide O-ring (5) onto boss on bucket.
3. Remove parts (1—3) and (18). Remove bucket.

 **CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

	Specification	
Bucket Cylinder—Weight.....		390 kg approximate 840 lb approximate

4. Support bucket cylinder using wood blocks.
5. Remove parts (2 and 3).
6. Remove O-ring (5) and seal (6).


7. Remove washers (8—11).
8. Remove pin fasteners (14 and 15).
9. Remove links (7 and 13).
10. Remove bucket link (12) and links.
11. Replace parts as needed.
12. Inspect seals and bushings in links (12). See Bushings and Seal Remove and Install. (Group 3340.)

**IMPORTANT: To prevent the seizure and galling of new or cleaned pins and bushings, apply grease to pins and bushings before assembly. Grease may not flow to all points of pin and bushing at the initial lubrication causing metal-to-metal contact. After assembly, lubricate pivot joint until grease escapes from joint. Then lubricate every 4 hours for the next 20 hours, then daily for the next 30 to 100 hours, and then at the regular maintenance interval.**

13. Apply grease to pin fasteners and link pin bores.
14. Install links, bucket, and pins.

CP94658,0000010 -19-02AUG06-2/2

Frames



TX1010567

- 1—Light
- 2—Wiring Harness
- 3—Wiring Connector

- 4—Cap Screw (2 used)
- 5—Washer (2 used)
- 6—Retaining Plate

- 7—Boom Pin
- 8—Shim (2 used)

- 9—Thrust Plate
- 10—Thrust Plate

**CAUTION:** Prevent possible crushing injury from heavy component. Use appropriate lifting device.

**NOTE:** Maintain clearance between boom and thrust plate at 1.5 mm (0.06 in.) or less with the use of shims.

18. Support boom with hoist and install boom pin (7), thrust plates (9 and 10) equally to each side. Add shims (8) to attain boom thrust clearance.

	Specification
Boom with Arm Cylinder—	
Weight.....	3370 kg approximate 7430 lb approximate

	Specification
Boom Pin—Weight .....	116 kg approximate 257 lb approximate

	Specification
Boom Thrust Plate—Clearance.....	0—1.5 mm 0—0.06 in.

19. Install retaining plate (6).

	Specification
Boom Pin Cap Screw—Torque .....	400 N•m 295 lb-ft

20. Connect wiring connector (3).

TX1010567 -UN-28JUL06

33  
3340  
13

Continued on next page


TX17984,0000073 -19-15MAY08-7/10

## Apply Vacuum to Hydraulic Oil Tank

**CAUTION:** High pressure release of oil from pressurized system can cause serious burns or penetrating injury.

1. Release pressure from hydraulic oil tank by pushing pressure release button (A).
2. Assemble fittings and hydraulic oil line adapter from D15032NU Vacuum Pump Kit, and JT07085A Vacuum Pump Set.


A—Pressure Release Button



JH38101,0000038 -19-27JUL06-1/2

3. Install JT03001 Tee, 7/16-20 M 37° x 7/16-20 F 37° Sw x 7/16-20 M 37° to line (1).
4. Install hydraulic oil line adapter from D15032NU Vacuum Pump Kit, and JT07085A Vacuum Pump Set to JT03001 Tee, on line (1). Refer to pump instructions for operating information.

1—Line  
2—Hydraulic Oil Tank



JH38101,0000038 -19-27JUL06-2/2


*Hydraulic System*

33  
3360  
11

### Pump 1 and 2 Inspection

1. See Pump 1 and Pump 2 Disassemble and Assemble.  
(Group 3360.)

- 1—Swash Plate
- 2—Plate
- 3—Slipper (9 used)
- 4—Piston (9 used)
- 5—Retainer
- 6—Spherical Bushing
- 7—Spring (9 used)
- 8—Cylinder



TX1010289 -UN-21JUL06


JH38101.000002C -19-26JUL06-1/5

2. Clearance between piston (4) outer diameter (d) and cylinder (8) bore diameter (D).

**Specification**

Bore Diameter and Piston  
Diameter—Clearance ..... 0.038 mm (0.001 in) new  
0.078 mm (0.003 in) maximum  
wear

**d—Outer Diameter**  
**D—Bore Diameter**



T144080 -UN-16JUL01


JH38101.000002C -19-26JUL06-2/5

3. Check free length (L) of spring (7).

**Specification**

Spring Length—Free Length ..... 40.9 mm (1.61 in) new length  
40.1 mm (1.58 in) minimum  
length

**L—Free Length**




T144081 -UN-16JUL01

Continued on next page

JH38101.000002C -19-26JUL06-3/5

**Pilot Pump Disassemble and Assemble**



A—Snap Ring  
 B—Seal  
 C—Mounting Flange  
 D—O-Ring (2 used)

E—Back-Up Ring (2 used)  
 F—Seal (2 used)  
 G—Bushing (2 used)  
 H—Key (2 used)

I—Bushing (2 used)  
 J—Driven Gear  
 K—Drive Gear  
 L—Housing

M—Cover  
 N—Cap Screw (4 used)  
 O—Dowel Pin (2 used)

1. Remove snap ring (A).
2. Remove cap screws (N).
3. Remove mounting flange (C).
4. Check bushings (G). If inside diameter and surface toward gear are rough or worn, replace pump.
5. Check gears (J and K) and housing (L). If gear teeth, shaft and inside of housing are rough or worn, replace pump.

Continued on next page


TX17984,000007E -19-01AUG06-1/2

Hydraulic System

11. Clean mounting surface and install new O-ring (1) on pump mounting face.
12. With hoist install pump with four socket head screws. Tighten to specifications.

**Specification**

Fan Pump Mounting Socket Head  
Screw—Torque..... 230 N•m  
170 lb-ft



TX1010764A -JUN-28JUL06

1—O-Ring

13. Connect wire harness connector to solenoid on fan pump control valve.
14. Install case drain hose to pump.
15. Install pilot hose to pump control valve.
16. Install inlet tube and outlet hose to pump with four bolt flange and socket head screws.

**Specification**

Fan Pump Hydraulic Four Bolt  
Flange Mounting Socket Head  
Screw—Torque..... 50 N•m  
37 lb-ft

17. Remove vacuum pump.
18. Fill fan pump case with hydraulic oil. See Pump 1 and 2 Start-Up Procedure. (Group 3360.)

TX04577,0000113 -19-01AUG06-5/5

33  
3360  
41

## Hydraulic System

1—Pin	18—Sleeve	34—O-Ring	52—O-Ring (3 used)
2—Sleeve	19—Spool	35—O-Ring (3 used)	53—Retaining Ring (2 used)
3—O-Ring (2 used)	20—Pin (2 used)	36—Cap Screw (2 used)	54—Adjusting Plug
4—O-Ring	21—Lever	37—Cap Screw (2 used)	57—Pin
5—Sleeve	22—Feedback Lever	38—O-Ring	58—O-Ring
6—Compensating Piston	23—Pin	39—Adjusting Screw	59—O-Ring
7—Compensating Rod	24—Pin	40—Adjusting Screw	60—O-Ring
8—Spring Set	25—Lever	41—Nut (2 used)	61—O-Ring
9—Spring	27—Pilot Piston	42—O-Ring	62—Cover
10—Spring	28—Spring Seat	43—Cover	63—Cap Screw (4 used)
11—Adjusting Disc	29—Spring	44—Nut	64—Plug (11 used)
13—Retaining Ring	30—Adjusting Disc	46—Adjusting Screw	65—Solenoid Valve
14—Spring Seat	31—O-Ring	48—Housing	66—Cap Screw (2 used)
15—Spring	32—Cap Screw (8 used)	49—Pin (2 used)	67—O-Ring (9 used)
16—Spring	33—Cover	51—Adjusting Plug	69—Plug
17—Retaining Ring			

13. Insert compensating rod (7) and lever (21) into housing (48).

14. Align pin (49) hole on lever (21) with the pin hole on housing (48). Align pin (20) in lever (21) with stepped part on compensating rod (7). Install lever (21) to housing (48).

15. Install retaining ring (17) to sleeve (18). Install sleeve (18) and spool (19) to housing (48).

**IMPORTANT: Check that spool (19) moves smoothly before installing feedback lever (22).**

16. Align the pin hole on spool (19) with hole on feedback lever (22). Install pin (23) through mounting hole of support plug (51).

17. Insert pilot piston (27) and lever (25) into housing (48).

**IMPORTANT: Check that piston (27) moves smoothly before installing lever (25).**

18. Align pin (26) in lever (25) with stepped part on pilot piston (27) and install lever (25).

19. Install O-ring (52) and pin (49) to adjusting plug (51).

20. Align pin (49) in adjusting plug (51) with pin hole on lever (25) and install adjusting plug (51). Install retaining ring (53) to housing (48).

21. Install O-ring (55) to adjusting plug (54). Install adjusting plug (54) to housing (48). Install retaining ring (56) to housing (48).

22. Install O-ring (31) to stopper (30).

23. Install spring seat (28), spring (29), and stopper (30) to housing (48).

24. Install O-ring (3) to stopper (11).

25. Install O-ring (42) to housing (48). Install spring seat (8), springs (9 and 10), and stopper (11) to housing (48). Install cover (43) to housing (48) with cap screws (32).

### Specification


Fan Drive Pump Regulator	
Adjusting Screw Cover Cap	
Screw—Torque .....	12 N•m 106 lb-in.

26. Install spring (15), spring seat (14) and retaining ring (13) to spool (19).

Hydraulic System

17. Install eye bolts in fan motor support. Attach hoist and chain to eye bolts as shown.

- 1—Eye Bolts
- 2—Fan Motor Support



Fan Motor Assembly

TX1010257A -UN-19JUL06

TX04577,000010A -19-02AUG06-15/33



**CAUTION:** Prevent possible crushing injury from heavy component. Use appropriate lifting device.


*NOTE:* For photo purpose only fan guard shows attached to motor hub but is not when this step is performed.

18. Remove six cap screws (1) from fan motor support with hoist attached. Slowly lift up and remove assembly from machine.

**Specification**


Fan Motor Support Assembly—  
Weight..... 95 kg approximate  
210 lb approximate

- 1—Cap Screws (6 used)



Fan Motor Assembly Mounting Hardware—Front

TX1010259A -UN-19JUL06



TX1010120A -UN-18JUL06

Continued on next page


TX04577,000010A -19-02AUG06-16/33

33  
3360  
61

Hydraulic System


16. With hoist install engine hood assembly with cap screws (1, 2 and 3).

- 1—Cap Screw—Left Side
- 2—Cap Screw—Right Side
- 3—Cap Screws—Center Support (4 used)




TX1010196A -JUN-19JUL06

Engine Hood Support Assembly—Right Side



TX1010197A -JUN-19JUL06

Engine Hood Support Assembly—Left Side



TX1010198A -JUN-19JUL06

Engine Hood Support Assembly—Center

Continued on next page

TX04577,000010A -19-02AUG06-30/33


33  
3360  
71

Hydraulic System

13. Install two covers (1) removed. Tighten to specification.

Specification	
Covers—Over Main Control	
Valve—Torque.....	90 N•m 66 lb-ft

- 1—Cap Screws (4 used)
- 2—Covers (2 used)



Cover—Center Over Main Control Valve

TX1009141 -UN-01AUG06

TX04577,000010D -19-01AUG06-11/11

*Hydraulic System*

2—Left Hand Upper Cover	6—Cap Screw	11—Right Hand Upper Rear	14—Label
3—Screw (8 used)	7—Left Hand Inside Cover	Cover	15—Case
4—Cap Screw, Washer and	8—Right Hand Upper Cover	12—Cap (2 used)	16—Cap (4 used)
Lock Washer (14 used)	9—Right Hand Outside Cover	13—Label	17—Screw (4 used)
5—Left Hand Outside Cover	10—Right Hand Inside Cover		

3. Remove caps (12).

4. Remove screws (3 and 17).

5. Remove cap screws (4 and 6).

6. Remove right and left hand covers (2, 5, 7, 8, 9, 10 and 11)

Continued on next page

TX17984.000008D -19-02AUG06-3/5

Hydraulic System

29. Secure cam by using a spanner wrench. Tighten screw joint by using a spanner wrench.

Specification

Screw Joint—Torque..... 68 N•m  
50 lb-ft

TX17984.000008E -19-03AUG06-8/8


Boom Up Shockless Valve Remove and Install



**CAUTION:** High pressure release of oil from pressurized system can cause serious burns or penetrating injury. Relieve pressure by pushing pressure release button.

1. Push pressure release button (1).

- 1—Pressure Release Button
- 2—Hydraulic Oil Tank Cover




T214924 -UN-17NOV05

TX17984.00000D9 -19-02AUG06-1/3

2. Remove cap screws (3) and cover (2) from main frame (1) under cab.

- 1—Main Frame
- 2—Cover
- 3—Cap Screw (6 used)



Cap Screws and Cover

TX1010156 -UN-18JUL06

33  
3360  
.101

Continued on next page

TX17984.00000D9 -19-02AUG06-2/3

**IMPORTANT: The quantity of shims has been determined during the performance testing at the factory. Install the shims together with the spools they came out of.**

- 20. Install spacers, shims and balance springs into spools.
- 21. Push balance springs by hand. Install spring guides to spools with the stepped end facing toward balance springs.
- 22. Apply hydraulic oil onto internal parts.
- 23. Insert the return springs into case.
- 24. While turning, install spools into the same port in case as they were before disassembly.
- 25. Install oil seals to bushings.
- 26. Apply grease to the inner surface of oil seals.
- 27. Install O-rings to bushings.
- 28. Install pushers into bushings.
- 29. Apply grease to the head of pushers.
- 30. Install the pushers into the case.
- 31. Install bushings by driving inner bushings from both ends with a bushing driver until the inside end of bushings are flush with the inside wall of holder.
- 32. Drive the outer bushings with a bushing driver so that the outside ends are flush with the outside of holder.
- 33. Install O-rings to pin. Apply grease to O-rings. Assemble pins and cams to holder.
- 34. Install spring pins to cams so that the pins are displaced with their slits at 90° from each other. Drive pins until they make contact with the stepped part of hole.

- 35. Crimp the hole edge of cams in two places where spring pins are inserted using a punch.
- 36. Install holder to case. Install cap screws and spring washers. Tighten cap screws to specification.

**Specification**

Holder-to-Case Cap Screws—	
Torque.....	49 N•m 36 lb-ft

- 37. Install rubber seats to pin.
- 38. Install dampers to pin with the lever facing top of travel pilot control valve.
- 39. Install cap screws and spring washers to secure damper and rubber seat to holder. Tighten cap screws to specification.

**Specification**

Damper-to-Holder Cap	
Screws—Torque .....	7 N•m 65 lb-in.

- 40. Apply grease to O-rings. Push O-rings to the end of pin.
- 41. Install brackets to pins aligning the inserting holes for spring pins.
- 42. Place a block of wood under bracket. Install spring pins into brackets so that the slits are displaced at 90° from each other. Drive spring pins until they contact the stepped end.
- 43. Crimp the hole edge of brackets where spring pins are inserted using a punch.
- 44. Install cover to holder. Tighten cap screws to specification.

**Specification**

Holder-to-Cover Cap Screws—	
Torque.....	5 N•m 44 lb-in.

- 45. Apply grease to the spring pin contact part of dampers.

33  
3360  
.111

## Hydraulic System

0—Bracket	6 —Bracket	11—Elbow Fitting (4 used)	16—Arm In Sensor
1—Cap Screw (4 used)	7—Cap Screw (2 used)	12—Boom Down Sensor	17—Arm Out Sensor
2—Digging Sensor Manifold	8—Travel Sensor Manifold	13—Boom Up Sensor	18—Right Travel Sensor
3—Cap Screw (2 used)	9—Cap Screw (2 used)	14—Bucket Dump Sensor	19—Left Travel Sensor
4—Adapter Fitting (12 used)	10—Adapter Fitting (4 used)	15—Bucket Curl Sensor	

2. Attach identification tags to lines and fittings. Disconnect hydraulic lines from digging sensor manifold (2). Close all openings using caps and plugs.
3. Remove cap screws (3) to remove digging sensor manifold (2) from bracket (0).
4. Repair or replace parts as necessary.
5. Install digging sensor manifold to bracket using cap screws.
6. Connect hydraulic lines. See Pilot Control Valve-to-Pilot Signal Manifold Component Location—Excavator Pattern. (Group 9025-15.)  
  
See Pilot Control Valve-to-Pilot Signal Manifold Component Location—Backhoe Pattern. (Group 9025-15.)

TX17984.00000DF -19-02AUG06-3/3


### Travel Sensor Manifold Remove and Install



**CAUTION:** High pressure release of oil from pressurized system can cause serious burns or penetrating injury. Relieve pressure by pushing pressure release button.

1. Release pressure by pushing hydraulic oil tank pressure release button (1).

1—Pressure Release Button  
2—Hydraulic Oil Tank Cover



T214924 -UN-17NOV05

Continued on next page

TX17984.00000E0 -19-02AUG06-1/3

33  
3360  
.121

## Hydraulic System


- |                                     |                                 |                                  |                         |
|-------------------------------------|---------------------------------|----------------------------------|-------------------------|
| 1—Lever                             | 5—Cap Screw (2 used)            | 9—Plate                          | 12—Cover                |
| 2—Grip                              | 6—Lock Washer (2 used)          | 10—Cap Screw and Washer (4 used) | 13—Catch                |
| 3—Cap Screw and Washer (2 used)     | 8—Cap Screw and Washer (2 used) | 11—Cover                         | 14—Cap Screw (2 used)   |
| 4—Counterweight Pilot Control Valve |                                 |                                  | 15—Lock Washer (2 used) |

4. Remove cover (12).

MM16633.0000030 -19-02AUG06-3/4

**CAUTION:** To avoid injury from escaping fluid under pressure, stop engine and relieve the pressure in the system before disconnecting or connecting hydraulic or other line. Tighten all connections before applying pressure.

5. Disconnect hoses from counterweight pilot control valve (4). Close all openings using caps and plugs. See Counterweight Removal Hydraulic System Line Connections. (Group 9025-15.)
6. Remove cover (11).
7. Remove counterweight pilot control valve.
8. Repair or replace parts as necessary.
9. Install counterweight pilot control valve (4).
10. Install cover (11).
11. Connect hoses to counterweight pilot control valve. See Counterweight Removal Hydraulic System Line Connections. (Group 9025-15.)
12. Install cover (12).
13. Check hydraulic oil level. See Check Hydraulic Oil Level. (Operator's Manual.)



X9811 -UN-23AUG88


33  
3360  
.131

MM16633.0000030 -19-02AUG06-4/4

## Hydraulic System

12. Remove cap screws (10) and spacers (11).
13. Remove control valve.
14. Repair or replace parts as necessary.

- 5—Control Valve
- 10—Cap Screw (4 used)
- 11—Spacer (4 used)



TX17984.0000093 -19-02AUG06-5/9

TX1010518 -UN-24JUL06

15. Install M12-1.75 metric lifting eyebolts such as JT05550 Metric Lifting Eyebolts to tapped holes (6—9).


**⚠ CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

16. Attach lifting device to control valve (5).

**Specification**

Control Valve—Weight ..... 400 kg approximate  
880 lb approximate

17. Lift and align control valve (5) to frame.



- 5—Control Valve
- 6—Tapped Hole
- 7—Tapped Hole
- 8—Tapped Hole
- 9—Tapped Hole

TX17984.0000093 -19-02AUG06-6/9

TX1010439 -UN-24JUL06


18. Apply PM38654 Thread Lock (high strength) to threads of cap screws (10).

19. Install cap screws (10) and spacers (11).

**Specification**

Cap Screw—Torque ..... 400 N•m  
295 lb-ft

- 5—Control Valve
- 10—Cap Screw (4 used)
- 11—Spacer (4 used)



TX17984.0000093 -19-02AUG06-7/9

TX1010518 -UN-24JUL06

33  
3360  
.141

Continued on next page

*Hydraulic System*

33  
3360  
.151

Hydraulic System

- |                                  |  |  |   |
|----------------------------------|--|--|---|
| 2—Right Control Valve (4-spool)  | 78—Arm Regenerative Valve—Switch Valve | 96—Sleeve                              | 114—30 mm Nut   |
| 60—Circuit Relief Valve (4 used) | 79—Sleeve                              | 97—Spring                              | 115—O-Ring  |
| 61—O-Ring (4 used)               | 80—O-Ring (2 used)                     | 98—Main Relief and Power Digging Valve | 116—Screw (first adjusting plug)                        |
| 62—Backup Ring (4 used)          | 81—Backup Ring (2 used)                | 99—Sleeve                              | 117—14 mm Plug—Main Relief Valve Isolation Check Valve  |
| 63—O-Ring (4 used)               | 82—Piston (2 used)                     | 100—Poppet                             | 118—Backup Ring   |
| 64—Sleeve (4 used)               | 83—Spool (2 used)                      | 101—Spring                             | 119—14 mm Plug—Travel Flow Combiner Circuit Check Valve |
| 65—Poppet (4 used)               | 84—O-Ring (2 used)                     | 102—O-Ring                             | 120—46 mm Plug—Travel Flow Combiner Valve               |
| 66—Piston (4 used)               | 85—Sleeve                              | 103—Backup Ring                        | 121—Spring  |
| 67—Spring (4 used)               | 86—Spring                              | 104—Valve Seat                         | 122—Spacer  |
| 68—Spring (4 used)               | 87—Guide (2 used)                      | 105—Poppet                             | 123—Spool   |
| 69—O-Ring (4 used)               | 88—O-Ring (2 used)                     | 106—Spring                             | 124—Plug  |
| 70—Backup Ring (8 used)          | 89—14 mm Fitting Plug (2 used)         | 107—O-Ring (4 used)                    | 125—O-Ring  |
| 71—O-Ring (4 used)               | 90—Bucket Regenerative Switch Valve    | 108—Cap (relief valve housing)         | 126—Plug  |
| 72—Valve Seat (4 used)           | 91—Check Valve (3 used)                | 109—41 mm Nut                          | 127—O-Ring  |
| 73—Pilot Poppet (4 used)         | 92—Spring (3 used)                     | 110—O-Ring                             |   |
| 74—Spring (4 used)               | 93—Backup Ring (3 used)                | 111—O-Ring                             |   |
| 75—O-Ring (4 used)               | 94—O-Ring (2 used)                     | 112—Sleeve (second adjusting plug)     |   |
| 76—Adjusting Screw (4 used)      | 95—Sleeve                              | 113—Orifice                            |   |
| 77—Nut (4 used)                  |  |  |   |

9. See Control Valve Operation for locations of control valve components.

**IMPORTANT: The circuit relief and main relief and power digging valves must be checked and adjusted after assemble to ensure that the pressure settings are correct.**

10. Before disassembling the circuit relief or main relief and power digging valves (60 and 98), make a mark on the adjusting plugs or adjusting screw and then record the number of turns to remove.

**CAUTION: The arm regenerative valve—switch valve and bucket regenerative switch valve contains a spring under load. Prevent injury from sudden release of spring by holding the 14 mm fitting plug as it is removed.**

11. Hold 14 mm fitting plug (89) as it is removed to release the force of spring (86 or 97).

12. Assemble circuit relief valves (60—77).

Tighten the valve seat (72) to sleeve (64) to specification.

**Specification**

Circuit Relief Valve—Valve Seat to Sleeve—Torque .....	100 N•m 74 lb-ft
--	---------------------

Tighten the circuit relief valves (60) to right control valve housing (2) to specification. Apply tighten force to the hexagonal part of sleeve.

**Specification**

Circuit Relief Valve to Right Control Valve Housing—Torque.....	100 N•m 74 lb-ft
---	---------------------

Perform Circuit Relief Valve Test and Adjustment to check and adjust pressure setting after assembly.

13. Assemble arm regenerative valve—switch valve (78—89)

Tighten 14 mm fitting plug (89) to specification.

**Specification**

Arm Regenerative Valve—Switch Valve—14 mm Fitting Plug to Sleeve—Torque .....	180 N•m 133 lb-ft
---	----------------------

Arm Regenerative Valve—Switch Valve to Right Control Valve Housing—Torque.....	180 N•m 133 lb-ft
--	----------------------

## Hydraulic System

4. Loosen coupling (1).

5. Remove hydraulic line (2).

6. Remove restriction valve (5).

7. Replace parts as necessary.

8. Install restriction valve (5).

9. Install hydraulic line (2).

10. Tighten coupling (1).

### Specification

Coupling—Torque..... 10 N•m  
90 lb-in.

11. Fill hydraulic system. See Change Hydraulic Tank Oil, Clean Suction Screen. (Operator's Manual.)

12. Bleed air from hydraulic system. See Bleed Air From Hydraulic System. (Operator's Manual.)


TX17984.000009E -19-02AUG06-3/3

## Hydraulic Oil Cooler Bypass Valve Remove and Install



**CAUTION: The hydraulic oil tank is pressurized. High pressure release of oil from pressurized system can cause serious burns or penetrating injury.**

1. Release hydraulic oil tank pressure by pushing release button on top of hydraulic oil tank.
2. Drain hydraulic tank. Hydraulic tank capacity is 331 L (85 gal) approximate. See Change Hydraulic Tank Oil, Clean Suction Screen. (Operator's Manual.)
3. Apply vacuum to hydraulic oil tank. See Apply Vacuum to Hydraulic Oil Tank. (Group 3360.)



TX1000859 -UN-01DEC05

- 1—Hydraulic Oil Tank Pressure Release Button  
2—Hydraulic Oil Tank Cover

Continued on next page

TX17984.00000EC -19-02AUG06-1/3

33  
3360  
.171

## Hydraulic System

**NOTE:** The following cylinder service tools are recommended to disassemble and assemble cylinders on this machine:

**Recommended Cylinder Service Tools—Specification**

HCS-40—Maximum Torque .....	54 232 N•m 40,000 lb-ft
HCS-60—Maximum Torque .....	81 349 N•m 60,000 lb-ft
HCS-60-L—Maximum Torque .....	81 349 N•m 60,000 lb-ft

Contact **Tricorp USA**, Palm Beach, Florida (www.tricorpusa.com) for more information.

3. Attach cylinder to service tool.

 **CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

**IMPORTANT: Avoid damage to cylinder barrel and cylinder rod. Pull cylinder rod straight out to protect sealing surfaces.**

4. Pull cylinder rod (1) straight out of cylinder barrel (18).

5. Completely extend cylinder rod (1).

6. Remove cap screw (8) from cylinder rod guide (9).

7. Remove cylinder rod guide (9) and cylinder rod (1) from cylinder barrel (18).

8. Attach cylinder rod (1) to service tool.

9. Mark cylinder rod (1) and nut (17) to aid in assembly.

10. Remove set screw (16).

11. Loosen nut (17) and remove piston (14) using ST3268 (125 mm) Special Wrench for Cylinder Piston Nut.

12. Inspect piston (14) for any damage.

13. Remove and discard seal ring (15), ring (12) and wear ring (13), from piston (14).

14. Remove packing ring (11) and cylinder rod guide (9) from cylinder rod (1).

15. Remove O-ring (10) and snap rings (2) and (7) from cylinder rod guide (9).

16. Remove dust seal (3), ring (5), seal (4), and bushing (6) using ST2671 (115 mm) Installing Bushing.

17. Inspect cylinder rod (1) and cylinder barrel (18) outside and inside for wear, scratches, and nicks that may cut or damage a seal or wear ring during assembly.

**Specification**

Cylinder Barrel—ID .....	170—170.063 mm 6.69—6.70 in.
--------------------------	---------------------------------

Continued on next page

MM16633.0000028 -19-08NOV06-2/5


Hydraulic System

21. Inspect seals and bushings on both rod end and head end of cylinder for wear and damage Perform Inspect Pins, Bushings and Bosses-Front Attachment. (Group 3340.)

**Specification**

Arm Cylinder Head End Bushing—ID.....	110.05—110.25 mm 4.333—4.341 in.
Arm Cylinder Rod End Bushing—ID.....	110.05—110.25 mm 4.333—4.341 in.

**24—Bushing**  
**25—Dust Seal**



Continued on next page

TF44157,0000008 -19-07NOV06-3/6

33  
3360  
.191


- 18. Check cylinder rod (1) for curvature using V-blocks and dial indicator.

**Specification**

Bucket Cylinder Rod—Curvature ..... 0.125 mm /1000 mm  
0.005 in. /39.37 in.

**Specification**

Bucket Cylinder Rod—OD After  
Re-plating ..... 119.943—120.027 mm



T6665XG -UN-27OCT88

- 19. Install bushing (9) and snap ring (10) to cylinder rod guide (3) using ST8036 (120 mm) Cylinder Head Maintenance Tool / Rod Outside Dimension 120 mm.
- 20. Install buffer ring (8) to the cylinder rod guide (3) with the lip toward the cylinder head end.
- 21. Install U-ring (7) with the lip toward the cylinder head end.
- 22. Install backup ring (6) and U-ring (7) to the cylinder rod guide (3).
- 23. Install new slide ring (5) to the cylinder rod guide (3).
- 24. Install wiper ring (2) with the lip toward the rod end of cylinder. Install to the cylinder rod guide (3) using ST8036 (120 mm) Cylinder Head Maintenance Tool / Rod Outside Dimension 120 mm.
- 25. Install O-ring (12) and backup ring (11) to cylinder rod guide (3).

Continued on next page


TF44157,000001A -19-08NOV06-4/6

33  
3360  
.201

### Swing Gearbox Remove and Install

**CAUTION:** High pressure release of oil from pressurized system can cause serious burns or penetrating injury. The hydraulic tank is pressurized. Relieve pressure by pushing pressure release button.

1. Release hydraulic oil tank pressure by pushing pressure release button (1) on top of hydraulic tank.
2. Drain hydraulic oil tank. Approximate capacity is 322 L (85 gal).




1—Pressure Release Button  
2—Hydraulic Oil Tank Cover

T214924 -UN-17NOV05

Continued on next page

TX17984,00000AA -19-02AUG06-1/3

- 39. Install spring pin (17) so the slit (39) in spring pin is to the end of the pin (18).
- 40. Install spring pin (17) into the hole of planetary pinion carrier (9).
- 41. Install thrust plate (5) to planetary pinion carrier (6) with the oil groove to sun gear (4).
- 42. Install needle bearings (21) to planetary gears (20).
- 43. Install planetary gears (20), thrust plates (19), pins (23) and spring pins (22) to first stage carrier (6).



Spring Pin

- 17—Spring Pin
- 18—Pin
- 39—Slit



**CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

- 44. Install the planetary pinion carrier (9) to the shaft (34).

**Specification**

Planetary Pinion Carrier—Weight ..... 23 kg approximate  
51 lb approximate

- 45. Install the sun gear (7) to the planetary pinion carrier (9) with the thinner side facing up towards the motor side.
- 46. Apply PM38654 Threadlocker to mating surfaces of ring gear (3) and housing (27).



**CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

- 47. Install ring gear to housing. Tighten cap screws (24).

**Specification**

Ring Gear—Weight ..... 23 kg approximate  
50 lb approximate

**Specification**

Ring Gear-to-Housing Cap  
Screws—Torque ..... 205 N•m  
150 lb-ft

- 48. Install the planetary pinion carrier (6) to the sun gear (7).

TX1009831 -JUN-17/JUL06

Mechanical Drive Elements

0—Outer Bearing Race  
1—Inner Bearing Race

2—Swing Bearing  
7—Lower Seal

8—Upper Seal  
9—Ball Bearing (86 used)

10—Support (86 used)



**CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

1. Place swing bearing (2) on clean, flat surface.

**Specification**

Swing Bearing—Weight..... 642 kg approximate  
1420 lb approximate

Keep hoist attached to outer bearing race (0) to aid in disassembly.

2. See Swing Bearing Upper Seal Install for replacement of damaged or torn upper seal (8). (Group 4350.)

See Swing Bearing Lower Seal Install for replacement of damaged or torn lower seal (7). (Group 4350.)


TX17984,00000AF -19-02AUG06-2/4

*NOTE: Taper pin may be tack welded or crimped.*

3. Grind tack weld (A) or crimp off of top of taper pin (B)
4. Drive taper pin out from the bottom side of swing bearing.
5. Remove loading plug (C) using a M10 x 1.5 pitch cap screw.

A—Tack Weld  
B—Taper Pin  
C—Loading Plug

T7974AA (CV)



T7974AA -JUN-30MAR93

Continued on next page

TX17984,00000AF -19-02AUG06-3/4

*Hydraulic System*

- 1—Plug
- 2—Spindle
- 3—Dust Seal

- 4—O-Ring
- 5—Bushing
- 6—Oil Seal (6 used)

- 7—Body
- 8—Ring
- 9—Snap Ring

- 10—O-Ring
- 11—Cover
- 12—Cap Screw (4 used)

12. Clean body and new bushing. Apply grease to body and new bushing.

13. Install bushing into body using the ST 2670 Pushing Tool or disks from JT01800 Bushing, Bearing, and Seal Driver Set and a press.

14. Install dust seal and O-ring (4).

Apply grease to lip of dust seal and O-ring in body.

15. Install oil seals to body.

 **CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.**

16. Place spindle with its upside down.

Install two M12 x 1.75 mm eyebolts into the body.

Lift and place body.

**Specification**

Spindle—Weight ..... 22 kg approximate  
50 lb approximate

Body—Weight ..... 29 kg approximate  
60 lb approximate

17. Install the body onto spindle by tapping the circumference of body evenly.

18. Install snap ring to spindle.

19. Install O-ring (10) to body.

20. Install cover to body.

21. Tighten cap screws (12) to specification.

**Specification**

Cover to Body Cap Screws—  
Torque ..... 88 N•m  
65 lb-ft

TX17984.00000B3 -19-27JUL06-4/4

## Hydraulic System

3. Remove crossover relief valve (1).

**NOTE:** Crossover relief valves are not repairable.  
Replace only.


4. Install crossover relief valve (1).

### Specification

Crossover Relief Valve—Torque..... 175 N•m  
130 lb-ft

5. Perform Swing Motor Crossover Relief Valve Test and Adjustment. (Group 9025-25.)

1—Crossover Relief Valve (4 used)



T139531B -UN-30APR01


TX17984,00000EF -19-01AUG06-2/2

## Swing Motor Make-Up Check Valve Remove and Install



**CAUTION:** High pressure release of oil from pressurized system can cause serious burns or penetrating injury. The hydraulic tank is pressurized. Relieve pressure by pushing pressure release button.

1. Release hydraulic oil tank pressure by pushing pressure release button (1) on top of hydraulic tank.
2. Pull a vacuum in hydraulic oil tank using a vacuum pump or drain hydraulic oil tank. See Apply Vacuum to Hydraulic Oil Tank. (Group 3360.)



1—Pressure Release Button  
2—Hydraulic Oil Tank Cover

T214924 -UN-17NOV05

Continued on next page

TX17984,00000F0 -19-03AUG06-1/2



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL