

450H, 550H, 650H Crawler Dozer Repair

**TECHNICAL MANUAL
H-Series Crawler Dozer
TM1744 24APR19 (ENGLISH)**

Sean Wright
15161 N Goodwill Rd
Titusville
PA
16354
United States (US)
swwright1988@gmail.com
<https://therepairmanual.com>

**Worldwide Construction
And Forestry Division**
PRINTED IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Avoid High-Pressure Fluids

This machine uses a high-pressure hydraulic system. Escaping fluid under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping fluid. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic fluid penetrates your skin, see a doctor immediately. Injected fluid must be removed surgically within hours or gangrene may result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



T133509—UN—15APR13


T133840—UN—20SEP00

TX03679,00016D3 -19-07SEP06-1/1

Beware of Exhaust Fumes

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in an enclosed space, provide adequate ventilation. Use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring outside air into the area.



T133546—UN—24AUG00

TX03679,00016D4 -19-23JUN08-1/1

Safety

Q—Hour Meter: Use to determine when your machine needs periodic maintenance.


R—Under-Seat Heater ON/OFF Switch: Push upper half of switch to turn heater on. Push lower half to turn heater off.

S—Transmission Speed Setting Gauge Display—If Equipped: When the machine is started, the transmission gauge speed setting default range of SP1.6 will be

displayed in the gauge window (1). The speed range is displayed as a two digit value. The values can range from SP1.0 to SP3.0. When the transmission speed control button (located on FNR lever) is pressed and held in the “Up” position, the range SP value can reach a maximum value of SP3.0. When the speed control button is held in the “Down” position, the value will decrease to a minimum of SP1.0.

HG31779,00000AB -19-11JUL02-2/2

Instrument Panel (Later Machines)



T1157945B—UN—22JUL02

- | | | | |
|--|--|--|------------------------------------|
| 1—Select Button | 8—Engine Air Filter Restriction Indicator (Yellow) | 12—Transmission Oil Temperature Indicator (Yellow) | 17—Transmission Oil Pressure Gauge |
| 2—Display Window | 9—Hydraulic Oil Filter Indicator (Yellow) | 13—Check Service Code Indicator (Yellow) | 18—Under-Seat Heater ON/OFF Switch |
| 3—Engine Coolant Temperature Gauge | 10—Hydraulic Oil Temperature (Yellow) | 14—Stop Indicator (Red) | 19—Key Switch |
| 4—Engine Oil Pressure Gauge | 11—Transmission Oil Filter Indicator (Yellow) | 15—Start Aid Button | |
| 5—Fuel Level Gauge | | 16—Front and Rear Work Lights Switch | |
| 6—Seat Belt/Park Brake Indicator (Red) | | | |
| 7—Engine Alternator Voltage Indicator (Yellow) | | | |


IMPORTANT: When the STOP-engine indicator is activated, stop engine immediately and investigate cause of problem. DO NOT start engine until problem has been corrected.

Each display indicator light is color-coded to indicate the severity of the situation. Red is a high-level warning, yellow is a low-level warning and clear indicates a condition.

When a red indicator lights, an audible alarm will sound. Stop the engine immediately and investigate the cause of the problem.

HG31779,0000091 -19-04JUN02-1/1

450H and 450H-LT Crawler Dozer Dimensions



T118300

T118300—UN—11NOV98

NOTE: Specifications and design subject to change without notice. Whenever applicable, specifications are in accordance with ICED and SAE standards. Except where otherwise noted, these specifications

are based on a unit with roll-over protective structure, full fuel tank, 80 kg (175 lb) operator, and standard equipment.

Item	Measurement	Specification
A—Overall Height—ROPS or Cab	Height	2590 mm (8 ft 6 in.)
B—Blade	Height	826 mm (2 ft 8.6 in.)
C—Blade Lift	Height	773 mm (2 ft 6 in.)
D—Digging	Depth	528 mm (1 ft 9 in.)
E—Blade Tilt		
90 inch Blade (Right Side)	Distance	313 mm (1 ft)
97 inch Blade (Right Side)	Distance	337 mm (1 ft 1.3 in.)
115 inch Blade (Right Side) (450H-LT)	Distance	400 mm (1 ft 4 in.)
F—Blade Tilt		
90 inch Blade (Left Side)	Distance	313 mm (1 ft)
97 inch Blade (Left Side)	Distance	337 mm (1 ft 1.3 in.)
115 inch Blade (Left Side) (450H-LT)	Distance	400 mm (1 ft 4 in.)
G—450H Overall (Without Winch)	Length	3937 mm (12 ft 11 in.)
G—450H Overall (With Winch)	Length	4496 mm (14 ft 9 in.)

Continued on next page

CED,OUO1032,1142 -19-07NOV98-1/2

General Specifications

550H Crawler Dozer Weights

Item	Measurement	Specification
SAE Operating Weight	Weight	7620 kg (16,800 lb)
Optional Equipment		
Rock Guards (4)	Weight	131 kg (288 lb)
Deluxe Seat (add)	Weight	9 kg (20 lb)
Cab with Heater (add)	Weight	268 kg (590 lb)
Cab with Air Conditioning (add)	Weight	306 kg (675 lb)
ROPS Heater	Weight	12 kg (26 lb)
High Intensity Lights	Weight	4 kg (9 lb)
Retrieval Hitch	Weight	23 kg (50 lb)
Extended Draw Bar	Weight	33 kg (72 lb)
4000S Winch	Weight	653 kg (1437 lb)
Winch Fairlead, Four Roller	Weight	85 kg (187 lb)
Radial Ripper	Weight	335 kg (738 lb)
Parallelogram Ripper	Weight	592 kg (1306 lb)

CED,OOU1032,1380 -19-25MAR99-1/1

General Specifications

650H-LGP Crawler Dozer Weights

Item	Measurement	Specification
SAE Operating Weight	Weight	8664 kg (19,100 lb)
Optional Equipment		
Rock Guards (4)	Weight	131 kg (288 lb)
Swamp Shoe	Weight	72 kg (158 lb)
Deluxe Seat (add)	Weight	9 kg (20 lb)
Cab with Heater (add)	Weight	268 kg (590 lb)
Cab with Air Conditioning (add)	Weight	306 kg (675 lb)
ROPS Heater	Weight	12 kg (26 lb)
High Intensity Lights	Weight	4 kg (9 lb)
Front Tow Hook	Weight	15 kg (33 lb)
Retrieval Hitch	Weight	23 kg (50 lb)
Extended Draw Bar	Weight	33 kg (72 lb)
4000S Winch	Weight	653 kg (1437 lb)
Winch Fairlead, Four Roller	Weight	85 kg (187 lb)
Radial Ripper	Weight	335 kg (738 lb)
Parallelogram Ripper	Weight	592 kg (1306 lb)


CED,OUO1032,1381 -19-25MAR99-1/1

650H and 650H-LGP Other Information

- **Lubrication:** Pressure system with full-flow spin-on filter and oil-to-water cooler.
- **Air Cleaner:** Dual stage dry-type with safety element, pre-cleaner, and dash mounted restriction indicator.
- **Cooling Fan:** Blower-type.
- **Transmission:** Dual-path, electronic-controlled, hydrostatic drive; load-sensing feature automatically adjusts speed and power to match changing load conditions; each individual track is powered by a variable-displacement piston pump and two-speed fixed-displacement motor combination; decelerator controls speed from holding to 8.0 km/h (5.0 mph).
- **Final Drives:** Heavy-duty triple-reduction final drives attach directly to the main frame and are isolated from track frame and dozer frame loads.
- **Steering:** Single-lever steering and direction control; full power turns, counter rotation, and infinitely variable track speeds provide unlimited maneuverability and optimum control; hydrostatic steering eliminates steering clutches and brakes.
- **Brakes:** Hydrostatic (dynamic) braking stops the machine whenever the direction-control lever is moved to neutral, whenever the decelerator is depressed to the end of travel, or whenever the brake pedal is depressed.
- **Automatic Park Brake:** Exclusive safety feature engages wet, multiple-disk brakes automatically whenever the engine stops, whenever the operator applies the brake pedal, or whenever the neutral start lever lock is in stop position; machine cannot be driven with brake applied, reducing wear out or need for adjustment.
- **Undercarriage:** John Deere Dura-Trax™ features large deep-heat treated components; pins and bushings are sealed for life; rollers and idlers are permanently sealed and lubricated; full-length track frame covers reduce material build up and ease cleaning.

CED,OUO1032,1388 -19-25MAR99-1/1

Service Recommendations for Metric Series Four Bolt Flange Fitting



Metric Series Four Bolt Flange Fitting

A—Sealing Surface
B—Split Flange

C—Pinched O-Ring
D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install the correct O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install four cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.
5. After components are properly positioned and cap screws are hand tightened, tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART ^a		
Thread ^b	N·m	lb·ft
M6	12	9
M8	30	22
M10	57	42
M12	95	70
M14	157	116
M16	217	160
M18	334	246
M20	421	318

^aTolerance $\pm 10\%$. The torques given are enough for the given size connection with the recommended working pressure. Increasing cap screw torque beyond these amounts will result in flange and cap screw bending and connection failures.

^bMetric standard thread.

04T,90,K175 -19-29SEP99-1/1

T6880BB—UN—15APR13

Section 01 Tracks

Contents

	Page		Page
Group 0130—Track System			
Essential Tools.....	01-0130-1	Hydraulic Track Tension Adjuster	
Service Equipment and Tools.....	01-0130-1	Remove and Disassemble	01-0130-52
Other Material.....	01-0130-3	Assemble and Install	01-0130-54
Specifications	01-0130-4	Track Idler Recoil Spring	
Rock Guards and Chain Guides		Remove and Install	01-0130-55
Remove and Install	01-0130-8	Disassemble and Assemble	01-0130-56
Carrier Roller		Sprocket	
Measure Wear.....	01-0130-9	Remove and Install	01-0130-60
Remove and Install	01-0130-9	Track Frame	
Disassemble and Assemble.....	01-0130-10	Remove and Install	01-0130-60
Inspect Metal Face Seals.....	01-0130-13	Frame Wear Strips	
Check Oil Level.....	01-0130-14	Remove and Install	01-0130-61
Track Roller		Group 0199—Dealer Fabricated Tools	
Measure Wear.....	01-0130-15	DF1041 Track Nut Removal Tool	01-0199-1
Remove and Install	01-0130-15	DFT1087 Track Recoil Spring	
Disassemble and Assemble.....	01-0130-16	Disassembly and Assembly	
Check Oil Level.....	01-0130-17	Guard Tool.....	01-0199-2
Test for Leakage.....	01-0130-17	ST4920 Track Recoil Spring	
Test for Leakage.....	01-0130-17	Disassembly and Assembly	
Inspect Metal Face Seals.....	01-0130-18	Tool.....	01-0199-3
Track Shoe			
Measure Grouser Wear.....	01-0130-19		
Remove and Install	01-0130-20		
Link			
Measure Height.....	01-0130-21		
Track Bushing Outer Diameter			
Measure	01-0130-22		
Track Pitch			
Measure	01-0130-23		
Track Sag			
Check.....	01-0130-24		
Adjust.....	01-0130-25		
Sealed Track Chain			
Remove.....	01-0130-26		
Turn Pins and Bushings	01-0130-31		
Disassemble and Assemble Using Track			
Press	01-0130-31		
Install.....	01-0130-31		
Lubricated Track Chain			
Remove and Install (Saw Tooth)	01-0130-33		
Disassemble to Turn Bushings and Lubricate			
Chain	01-0130-35		
Assemble to Turn Bushings and Lubricate			
Chain	01-0130-36		
Disassemble and Assemble to Turn Pins and Not			
Lubricate.....	01-0130-43		
Front Idler			
Measure Wear.....	01-0130-47		
Remove and Install	01-0130-47		
Disassemble, Inspect, and Assemble	01-0130-48		
Adjustment Procedure.....	01-0130-50		
Check Oil Level.....	01-0130-51		

Track System

1. Use a chain and hoist when removing rock guards. Inspect parts, replace if necessary.
2. Tighten rock guard cap screws.

Rock Guard—Specification

Rock Guard-to-Track Frame Cap	
Screws—Torque.....	203 N·m (150 lb-ft)
Rock Guard-to-Spacer-to-Rock Guard Cap	
Screws—Torque.....	278 N·m (205 lb-ft)

3. Tighten chain guide cap screws.

Chain Guides—Specification

Chain Guides-to-Track Frame Cap	
Screws—Torque.....	203 N·m (150 lb-ft)
Chain Guide-to-Spacer-to-Rock Guard Cap	
Screws—Torque.....	278 N·m (205 lb-ft)

CED,OUTX547,66 -19-10JUN02-2/2


Measure Carrier Roller Wear

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.

1. Use calipers to measure most worn area of roller running surface.
2. Measure caliper tip spread to the nearest 0.5 mm (0.002 in.) using the scale.
3. Flat spots on roller thread indicates roller is not free to turn.

Carrier Roller—Specification

450H and 550H Carrier	
Roller Wear—Outside	
Diameter.....	152.4 mm (6.0 in.)
100% Worn.....	139.7 mm (5.5 in.)
650H Carrier Roller	
Wear—Outside	
Diameter.....	160.0 mm (6.3 in.)
100% Worn.....	147.0 mm (5.8 in.)



T5819AC —UN—01NOV88


CED, TX03399, 5059 -19-16MAR99-1/1

Remove and Install Carrier Roller Assembly

Carrier Roller—Specification

Bracket-to-Frame Cap	
Screw—Torque.....	620 N·m (460 lb-ft)

1— Cap Screw (2 used)




T118482B —UN—16NOV98

CED, TX03399, 5060 -19-28OCT98-1/1

Measure Track Shoe Grouser Wear

Measure grouser height of several track shoes to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment and D05231ST 300 mm Ruler from JT05518 or JT05523 Undercarriage Inspection Service Tool Kit.

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.



T93612 —UN—23FEB89

Item	Measurement	Specification
Track Shoe		
450H and 550H Single Bar Grouser New Shoe	Height	48.0 mm (1.89 in.)
450H and 550H Single Bar Grouser 100% Worn	Height	20.0 mm (0.8 in.)
Track Shoe		
650H Single Bar Grouser New Shoe	Height	50.0 mm (1.97 in.)
650H Single Bar Grouser 100% Worn	Height	23.0 mm (0.91 in.)

CED.OUTX547,77 -19-16MAR99-1/1

Track System

9. Pull track chain apart. Remove spacers (B) and washers (A) from between left and right track links.
10. Operate crawler and rotate track in the reverse direction. Slowly, unwrap track off drive sprocket.
11. Place a jack under both crossbars and raise crawler to provide clearance. Block crawler up securely.



T93558—UN—01NOV88

A—Washer (4 used)

B—Spacer (2 used)

Continued on next page

CED,OUTX547,83 -19-08APR99-5/6

Track System

12. Install a thrust ring on each end of pin.
13. Move completed split link assembly to rear seat of saddle.



T96278—UN—27OCT88

CED,OUTX547,89 -19-16MAR99-7/14

14. Apply LOCTITE® plastic gasket to link bore. The sealant prevents loss of vacuum or lubricant leakage through pin to link joint.



T96279—UN—27OCT88

LOCTITE is a registered trademark of Loctite Corp.

Continued on next page

CED,OUTX547,89 -19-16MAR99-8/14

Track System

1— Idler Assembly
2— Shaft
3— Bracket (2 used)
4— O-Ring (2 used)
5— Spring Pin (4 used)

6— Metal Face Seal (2 used)
7— Bushing (2 used)
8— Pipe Plug
9— Shim (as required)

10— Guide (2 used)
11— Washer (8 used)
12— Cap Screw (8 used)
13— Wear Plate (2 used)

14— Washer (4 used)
15— Cap Screw (4 used)

1. Remove cap screws and washers to remove wear strips and shims.
2. Drive pins (5) out.

IMPORTANT: Keep metal face seals (6) lubricated and together at all times while disassembled.

3. Remove brackets (3), O-rings (4) and metal face seals (6).
4. Remove shaft (2) and inspect bushings (7). Replace if necessary.
5. Install new bushings. Drive in bushings until bottomed.

IMPORTANT: Lubricate idler bushings with oil before installing shaft.

6. Apply clean hydraulic oil to bushings (7).
7. Inspect metal face seals. See [Inspect Metal Face Seals](#) in this group.
8. Install new metal face seals, if necessary.
9. Install shaft (2), O-rings (4), and brackets (3).
10. Drive in spring pins (5).
11. Install guides, wear plates and shims. See [Idler Adjustment Procedure](#) in this group.
12. Fill idler with oil. See [Check Idler Oil Level](#) in this group.



CED.OUTX547,93 -19-08APR99-2/2

Track System

14. Install 10-ton jack on bottom of compression tool.
15. Put caps, tube and recoil spring (D) in compression tool so spring is centered.
16. Install DFT1087 ¹ Recoil Spring Guard Tool (F). (See Group 0199 for instructions to make tool.)
17. Install plate (A) and nuts (B) to secure spring.
18. Operate jack to compress spring.
19. Apply John Deere NEVER-SEEZ ® Lubricant to threads of special cap screw (C). Install special cap screw through hole (E). Be sure cap screw threads fully engage end cap.
20. Slowly release jack and remove nuts and plate.
21. Install spring assembly. (See procedure in this group.)

A—Plate
 B—Nut (4 used)
 C—Cap Screw Head

D—Recoil Spring
 E—Hole in Plate
 F—DFT1087 Recoil Spring Guard Tool



T7126AA—UN—15SEP89

T7247BN—UN—09APR90

NEVER-SEEZ is a registered trademark of Emhart Chemical Group.

¹Dealer Fabricated Tool. See Group 0199 for instructions to make tool.

CED.OUTX547,100 -19-02APR99-4/4

Section 02
Axles and Suspension Systems

Contents

Page

Group 0201—Drive Axle Housing and Support

Service Equipment and Tools	02-0201-1
Other Material	02-0201-1
Specifications	02-0201-1
Final Drive	
Remove and Install	02-0201-2

**Group 0250—Axle Shaft, Bearings, and
Reduction Gear**

Essential Tools	02-0250-1
Other Material	02-0250-1
Specifications	02-0250-1
Disassemble and Assemble	02-0250-2


Group 0299—Dealer Fabricated Tools

DF1063 Final Drive Lift Bracket	02-0299-1
DFT1166 Final Drive Lifting Bracket	
Adapter	02-0299-2
DFT1167 Final Drive Lifting Bracket	
Adapter Spacer	02-0299-3

Axle Shaft, Bearings, and Reduction Gear

16. Remove bearing (1) from axle shaft.
17. Remove and discard seal assembly (2).
18. Clean and inspect housing and parts.

1— Bearing 2— Seal




T118852B —UN—11DEC98

CED,OUTX547,65 -19-20JAN09-9/26

19. Remove parts (2—6) as shown.
20. Inspect final drive input gear (4) and bearing cones (3 and 5). Replace as necessary.
21. Install bearing cup (2) into brake housing.
22. Install bearing cup (6) into housing half (7).
23. Install bearing cones (3 and 5) onto final drive input gear (4).

1— Brake Housing 5— Bearing Cone
 2— Bearing Cup 6— Bearing Cup
 3— Bearing Cone 7— Housing
 4— Final Drive Input Gear




T118987

T118987 —UN—14DEC98

CED,OUTX547,65 -19-20JAN09-10/26

24. Remove parts (1—4) as shown.
25. Inspect second idler pinion gear (3) and bearing cones (1 and 4). Replace as necessary.
26. Install bearing cones (1 and 4) onto second idler pinion gear (3).

1— Bearing Cone 3— Second Idler Pinion Gear
 2— Second Idler Ring Gear 4— Bearing Cone







T118988

T118988 —UN—14DEC98

Continued on next page

CED,OUTX547,65 -19-20JAN09-11/26

DFT1167 Final Drive Lifting Bracket Adapter Spacer



T118674

T118674—UN—01DEC98

To be used with DFT1166 Final Drive Lifting Bracket Adapter when installing DFT1063 Final Drive lifting Bracket.



Material: 1/2 in. 1020 Steel Plate

CED, TX03399, 5085 -19-19APR06-1/1

CAUTION: To avoid injury from escaping fluid under pressure, stop engine and relieve the pressure in the system before disconnecting or connecting hydraulic or other lines. Tighten all connections before applying pressure.

19. Disconnect line (1). Close all openings using caps and plugs.
20. Disconnect fittings (2 and 3) and remove line.
21. Disconnect lines (6, 7, and 9).
22. Disconnect wiring connectors (5 and 11). Disconnect wire terminal (8).
23. Disconnect wiring connector (10) (450H, 550H S.N.—910010) (650H S.N.—924717).
24. Remove cap screws (4) from hydraulic pump and remove pump. Set pump aside.

- | | |
|---|---|
| 1— Line (Front Pump Tee Fitting-to-Cooler Bypass Valve) | 7— Line (L.H. Motor Tee Fitting-to-Oil Cooler Bypass Valve) |
| 2— Tee Fitting (Front Pump) | 8— Oil Cooler Bypass Valve Wire Terminal |
| 3— Line Fitting (Rear Pump) | 9— Line (Park Brake) |
| 4— Hydraulic Pump Mounting Cap Screws (4 used) | 10— Speed Sensor Wiring Connector (450H, 550H S.N.—910010) (650H S.N.—924717) |
| 5— Rear Directional Control Solenoid Wiring Connector | 11— Front Directional Control Solenoid Wiring Connector |
| 6— Line (Oil Cooler Bypass Valve-to-Reservoir) | |




X9811 —UN—23AUG88

T118454A —UN—10DEC98

CED,TX03399,5046 -19-12AUG03-5/15

25. Disconnect lines (2—5, 7 and 8). Close all openings using caps and plugs.
For ease of removal and installation of pumps, lines can be tied together and pulled up and out of the way.
26. Remove cap screws (1 and 6) and remove rear pump mounting bracket.

- | | |
|---|--|
| 1— Hydrostatic Pump-to-Rear Mount Bracket Cap Screws (2 used) | 5— Line (Rear Pump Forward Outlet Port-to-L.H. Motor "A" Port) |
| 2— Line (Front Charge Pump-to-Rear Charge Pump Tee-Fitting) | 6— Rear Pump Mount Bracket-to-Frame Cap Screws (4 used) |
| 3— Line (Front Pump Reverse Outlet Port-to-R.H. Motor "A" Port) | 7— Tee-Fitting |
| 4— Line (Front Pump Forward Outlet Port-to-R.H. Motor "B" Port) | 8— Line (Rear Pump Reverse Outlet Port-to-L.H. Motor "B" Port) |




T118455A —UN—10DEC98

Continued on next page

CED,TX03399,5046 -19-12AUG03-6/15

Single Lever Control (SLC) Exploded View (With Speed Lever, If Equipped)



T119911

T119911—UN—29JAN99


Continued on next page

CED,OUO1066,258-19-26MAR99-1/2

Controls Linkage

8. Remove two socket head cap screws (1), retaining plate (2) and detent spring (3).
9. Remove nut (4), socket head cap screw (8), spacer (5), washer (7) and detent lever (9).
10. Remove tube (6) from detent lever.

- | | |
|------------------------------------|--------------------------|
| 1— Socket Head Cap Screws (2 used) | 6— Tube |
| 2— Retaining Plate | 7— Washer |
| 3— Detent Spring | 8— Socket Head Cap Screw |
| 4— Nut | 9— Detent Lever |
| 5— Spacer | |




T119643B—UN—19/JAN99

CED.OUTX547,108 -19-29SEP99-6/27

11. Remove socket head cap screws from steer sensor (1) and forward/reverse sensor (2).
Remove sensors and O-rings.
12. Remove cover (3) and neutral start switch (4).

- | | |
|---------------------------|-------------------------|
| 1— Steer Sensor | 3— Cover |
| 2— Forward/Reverse Sensor | 4— Neutral Start Switch |



T119644B—UN—19/JAN99

T119645B—UN—19/JAN99

Continued on next page

CED.OUTX547,108 -19-29SEP99-7/27

Controls Linkage

53. If removed, install boot (3) and switch (2) in grip (1).



T124646B—UN—17SEP99

CED,OUTX547,108 -19-29SEP99-24/27

54. Install and tighten screws (1—3).



T124645B—UN—17SEP99

Continued on next page

CED,OUTX547,108 -19-29SEP99-25/27

Hydrostatic System

1— Charge Pump Housing/End Cap	12— Piston Assembly ¹	26— Bearing Cage	45— Seal Ring (2 used)
2— Gasket	13— Socket Head Cap Screw (3 used)	27— Slider Block	46— O-Ring (2 used)
3— Valve Plate	14— Retaining Plate	28— Socket Head Cap Screw	47— O-Ring (2 used)
4— Retaining Ring ¹	15— Lip Seal	29— Cap Screw	48— Servo Cylinder (2 used)
5— Spring Retainer ¹	16— Seal Carrier	30— Slider Block	49— Cap Screw (6 used)
6— Spring ¹	17— O-Ring	31— Bearing	50— Cap Screw (2 used)
7— Spring Seat ¹	18— Retaining Ring	32— Servo Arm Assembly	51— Lever Assembly
8— Cylinder Block ¹	19— Bearing	33— Swashplate Hold-Down Spring	52— O-Ring
9— Speed Sensor Ring	20— Spacer (4 used)	34— Spring Pin	53— Side Cover Insert
10— Slipper Guide Bearing (2 used)	21— Cap Screw (4 used)	35— Guide	54— Side Cover
11— Slipper Guide ¹	22— Pump Housing	36— Swashplate	55— Cap Screw (6 used)
	23— Speed Sensor (450H, 550H S.N. —910010) (650H S.N. —924717)	37— Washer	56— Nut (2 used)
	24— Alignment Pin (2 used)	38— Cage Locator Link	57— Swashplate Lever Spring (2 used)
	25— Alignment Pin (2 used)	39— Bearing Cage Link Pin	58— Shim (2 used)
		40— Not Used	
		41— Bearing Race (2 used)	
		42— Pump Shaft	
		43— Servo Piston	
		44— O-Ring (2 used)	

¹Serviced as an assembly.

CED,OUO1004,520 -19-13APR99-2/2

Disassemble Hydrostatic Pumps

CAUTION: The weight of the hydrostatic pump is approximately 60 kg (133 lb). Use proper lifting equipment and safety precautions. Failure to do so may cause personal injury.


Hydrostatic Pump—Specification

Hydrostatic Pump—Weight..... 60 kg (133 lb) Approximate

IMPORTANT: Absolute cleanliness is essential when working on hydraulic components.

NOTE: Orientate double boss of pump housing on holding fixture as shown.

1. Mount the hydrostatic pump on a D01006AA Bench-Mounted Holding Fixture.
2. Remove displacement control valve assembly. (See [Disassemble and Assemble Displacement Control Valve](#) in this group.)



A—Socket Head Cap Screw (3 used)
B—Retaining Plate
C—Seal Carrier
D—Shaft


3. Remove speed sensor (front pump only).

4. Remove socket head cap screws (A) and retaining plate (B).

NOTE: The bearings on shaft (D) are slip fit in the housing bore.

5. Remove seal carrier (C) and shaft (D) with bearings. Lightly tap on opposite end of shaft to aid in removal.


A—Socket Head Cap Screw (3 used)
B—Retaining Plate
C—Seal Carrier
D—Shaft



Continued on next page

CED,OUTX547,110 -19-28JUN02-2/22

Charge Pump and Pump Controls Exploded View



T119676

T119676 —UN—22JAN99


- | | | | |
|------------------------------------|-------------------------------------|---|---------------------------------------|
| 1— O-Ring | 15— Multi-Function Valve (2 used) | 25— O-Ring (3 used) | 37— Charge Pump Shaft |
| 2— Socket Head Cap Screw (4 used) | 16— O-Ring | 26— Electronic Displacement Control (EDC) | 38— Alignment Pin |
| 3— Flange Adapter | 17— O-Ring | 27— Socket Head Cap Screws (4 used) | 39— Port Plate ¹ |
| 4— O-Ring | 18— Charge Relief Valve Housing | 28— O-Ring | 40— Charge Pump Gear Set ¹ |
| 5— Retaining Plate | 19— Charge Relief Poppet | 29— Gasket | 41— Key |
| 6— Cap Screw (6 used) | 20— Spring | 30— Orifice | |
| 7— Charge Pump Cover | 21— Adjustment Screw | 31— Nut | |
| 8— Bushing | 22— Orifice | 32— O-Ring | |
| 9— Coupling | 23— Pump Displacement Control Valve | 33— Nut | |
| 10— Manifold | 24— Socket Head Cap Screw (6 used) | 34— O-Ring | |
| 11— Nut | | 35— Charge Pump Housing/End Cap | |
| 12— O-Ring | | 36— Bushing | |
| 13— Tube | | | |
| 14— Socket Head Cap Screw (2 used) | | | |

¹ Serviced as an assembly.

CED,OUO1008,147 -19-17DEC98-1/1

Disassemble and Assemble Neutral Charge Relief Valve

1. Disconnect lines and remove relief valve from top of front hydrostatic pump. Note orientation of valve to aid in assembly.
2. Remove parts (2—8). Clean and inspect all parts for wear or damage.
3. Install new O-rings and assemble valve.
4. Perform neutral charge relief pressure test. (See Neutral Charge Relief Pressure Test in Operation and Test Manual, Group 9026-25.)



T119677B

- | | |
|--------------------|-------------|
| 1— Valve Housing | 5— O-Ring |
| 2— Poppet | 6— Lock Nut |
| 3— Spring | 7— Lock Nut |
| 4— Adjusting Screw | 8— O-Ring |

T119677B —UN—19JAN99

CED,OUO1004,523 -19-19JAN99-1/1


Assemble Hydrostatic Pump

NOTE: Apply clean hydrostatic oil to all internal parts before assembly

IMPORTANT: Components must be installed in proper position with original orientation to prevent premature pump failure. Bearing races must be completely seated in housing.

Inspect bearing cage wear patterns in bearing race and swash plate to determine remaining service life.

1. Install bearing races (A) in housing.
2. Lubricate and install bearing cage on the bearing races.



A—Bearing Race (2 used)

RW/25758 —UN—16JUN97

RX16216015,17A -19-14APR10-1/17

IMPORTANT: Damage to polished surfaces can cause premature pump failure. Be careful when handling parts with polished surfaces to prevent nicks or scratches.

NOTE: Either side of slipper guide can be installed against slippers. Flip slipper guide if excessive wear is on top bearing surface.

3. Inspect slipper guide surface, install smoothest side away from slippers.

Clean slipper guide bearing screw holes on swash plate surface using M8 tap.

NOTE: Apply clean hydrostatic oil to all internal parts before assembly.



Piston Assemblies

4. Install the piston assemblies into the slipper guide.
5. Apply clean hydrostatic oil on slippers. Center the pistons and guide on the swash plate.

Continued on next page

RX16216015,17A -19-14APR10-2/17


T8464BL —UN—14JUN95

Hydrostatic System

11. Loosen socket head cap screws (1 and 2) on front cover.

1— M12 Socket Head Cap Screws (4 used)


2— M10 Socket Head Cap Screws (4 used)



T119215

T119215 —UN—27.JAN99

CED,OUO1004,548 -19-13APR99-4/17



T119211

T119211 —UN—27.JAN99

1— M10 x 75 Cap Screw
2— M12 x 75 Cap Screw (4 used)

3— M12 x 40 Cap Screw (2 used)
4— End Cap
5— Gasket

6— Valve Plate
7— Alignment Pin (2 used)
8— Seal Ring (2 used)

9— Motor Housing

12. Rotate motor 180° on work surface.

13. Remove cap screws (1—3) from end cap (4).

NOTE: Watch for seal rings (8) and alignment pins (7) when separating end cap from motor housing.

14. Separate end cap (4) from motor housing (9).


15. Remove gasket (5), seal rings (8) and alignment pins (7).

16. Remove valve plate (6).

Continued on next page

CED,OUO1004,548 -19-13APR99-5/17

Disassemble and Assemble Loop Flushing Valve



T119208

T119208—UN—27JAN99

1— Valve Cap (2 used)
2— O-Ring (2 used)

3— Spring (2 used)
4— Shoulder Washer (2 used)

5— Spool Valve
6— Motor End Cap

1. Remove rear access plate from machine.
NOTE: Clean thoroughly around plugs before removing.

2. Remove valve caps (1) and parts (2—5).
3. Clean and inspect parts.

NOTE: Shoulder of washers (4) must face out toward springs when assembled.

4. Install parts (1—5). Tighten valve caps (1) to specifications.


Hydrostatic Motor—Specification

Loop Flushing Valve
Caps—Torque..... 41 N·m (30 lb-ft)

5. Install rear access plate on machine.

CED,OUO1004,551 -19-13APR99-1/1

Hydrostatic System







T139656

T139656 —UN—17APR01

Continued on next page

CED, TX03399, 5044 -19-05MAR04-2/3

DFT1168 Right Hand Hydrostatic Motor Lifting Bracket



T118914

T118914—UN—06/AN99

A—12 mm (0.472 in.) hole B—M10 x 1.5 drill and tap hole

Used with DFT1132 Hydrostatic Motor Removal and Installation Tool to remove and install hydrostatic right hand motor (without winch option).

Material required:

- 2 in. x 2 in. x 1/4 in. angle iron
- 5/16 x 1-1/2 in. cap screw

Cap screw must be welded to angle iron.


CED,OUO1008,160 -19-13APR99-1/1

Removal and Installation

27. Install parts (6—10).

6— Fuel Return Line
7— Speed Control Linkage
8— Start Relay Cap Screw (2
used)

9— Ground Strap
10— Start Solenoid Positive
Cable
11— Rear Hood Bracket with
Air Cleaner




T117449B —UN—29SEP98

Continued on next page

CED,TX03399,5009 -19-11FEB00-10/11

DFT1119 Pump Support



T7955AA—UN—23APR93

Pump support is used with a small winch hoist to support the hydrostatic pumps when an engine is removed.

Two end stands are needed.

Drill the holes through the square steel tubing so they are centered.

Material required:

- C3 x 5 Steel Channel
- 88.9 x 88.9 x 6.35 mm (3.5 x 3.5 x 0.250 in.) Square Steel Tubing

- 76.2 x 76.2 x 6.35 mm (3 x 3 x 0.250 in.) Square Steel Tubing
- 63.5 x 63.5 x 6.35 mm (2.5 x 2.5 x 0.250 in.) Square Steel Tubing
- 19 mm (3/4 in.) flat bar stock
- M10 x 89 mm or 3/8 x 3 1/2 in. D Grade (SAE Grade 5) Cap Screw (2 used)
- M10 or 3/8 in. D Grade (SAE Grade 5) Nut (2 used)

CED, TX03399, 2297 -19-19APR06-1/1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Remove and Install Fan Blade and Shroud (450H, 550H) (650H S.N.—924717)

1. Remove engine side shields.
2. Release belt tension adjuster to loosen belt.
3. Disconnect compressor wiring lead connector (4).
4. Remove cap screws (5) and set compressor to right side.
5. Remove fan guard (6).
6. Remove fan blade, spacer and pulley (2).
7. To remove shroud, remove hood. (See Remove and Install Hood, Group 1910.)
8. Disconnect upper oil cooler hose (1), radiator hose (3) and coolant over flow tube from coolant tank.
9. Remove cap screws and turn shroud 90° and tilt up.
10. Install shroud, connect cooler hose, radiator hose, and coolant over flow tube.

NOTE: To aid in assembly, use two M10 x 50 mm cap screws to draw in spacer and pulley to fan drive hub.

11. Install fan pulley, spacer and fan. Tighten fan cap screws to specifications.

Fan Blade and Shroud —Specification

Fan Blade Cap
Screws—Torque..... 73 N·m (54 lb-ft)

12. Install fan guard. Tighten cap screws to specifications.

Fan Blade and Shroud —Specification

Fan Guard Cap
Screws—Torque..... 16—19 N·m (142—168 lb-in.)


13. Install compressor. Tighten cap screws to specifications.

Fan Blade and Shroud—Specification

Compressor Cap
Screws—Torque..... 35 N·m (26 lb-ft)

14. Connect compressor wire lead connector.
15. Install fan belt and engine side shields. Install hood if removed. (See Remove and Install Hood, Group 1910.)

- | | |
|--------------------------|--------------------------|
| 1— Upper Oil Cooler Hose | 4— Wiring Lead Connector |
| 2— Pulley | 5— Cap Screws (4 used) |
| 3— Radiator Hose | 6— Fan Guard |



T117466B —UN—30SEP98

T117467B —UN—30SEP98

OUT3019.0000081 -19-23APR19-1/1

Engine Speed Control

- | | | | |
|----------------------------------|--------------------------|----------------------------|------------------------|
| 1— Cable | 6— Angle Bracket | 12— Spring Washer (5 used) | 18— Lower Slider Plate |
| 2— Clamp (2 used) | 7— Washer | 13— Lock Nut | 19— Grip |
| 3— Throttle Lever | 8— Cap Screw | 14— Cap Screw | 20— Cap Screw |
| 4— Friction Disk Washer (2 used) | 9— Washer (2 used) | 15— Washer | 21— Washer |
| 5— Yoke with Locking Collar | 10— Nut (3 used) | 16— Spring | |
| | 11— Notched Metal Washer | 17— Upper Slider Plate | |


1. Lower equipment to the ground.
2. Remove left engine side shields
3. Remove dash and foot rest.
4. Remove parts as required.
5. Install parts.
6. Install spring washers (12) with concave side toward notched metal washer (11).
7. Apply instant gel adhesive to throttle lever (3) and install grip (19).
8. Tighten nut (13) to initiate a 67—76 N (15—17 lb) (force) movement on lever in the forward direction.

Speed Control Lever—Specification

Lever to Initiate
 Movement in Forward
 Direction—Force..... 67—76 N (15—17 lb)

9. Adjust linkage. (See [Engine Speed Control Linkage Adjustment](#) in Operation and Test Manual, Group 9010-20.)

CED,OUTX547,123 -19-23MAR01-2/4



T118917

- | | | |
|----------------------|------------------------|-------------------|
| 1— Decelerator Pedal | 3— Bellcrank | 5— Torsion Spring |
| 2— Shaft | 4— Spring Pin (4 used) | |

10. Remove and install parts as necessary.
11. Adjust. (See [Engine Speed Control Linkage Adjustment](#) in Operation and Test Manual, Group 9010-20.)

Continued on next page

CED,OUTX547,123 -19-23MAR01-3/4

T118917—UN—21DEC98

Mounting Frame

- | | | | |
|---|---|---|----------------------------|
| 1— Right Hand Side Rail Frame | 6— Rubber Mount (4 used) | 11— Washer (12 used) | 15— Nut (4 used) |
| 2— Left Hand Side Rail Frame | 7— Washer (8 used) | 12— Flywheel Cover-to-Engine | 16— Nut (4 used) |
| 3— Washer (28 used) | 8— Side Rails-to-Main Frame Cap | Flywheel Cap Screw (12 used) | 17— Locking Plate (4 used) |
| 4— Front and Rear Side Rails-to-Engine Cap Screw (14 used) | 9— Cover | 13— Bracket | |
| 5— Rear Support Bracket-to-Rear Hydraulic Pump Cap Screw (2 used) | 10— Pump-to-Flywheel Cover Cap Screw (4 used) | 14— Rear Pump Support-to-Side Rail Cap Screw (4 used) | |

Item	Measurement	Specification
Engine and Power Train Mounting Parts		
Side Rails-to-Engine Cap Screws	Torque	130 N·m (96 lb-ft)
Pump-to-Flywheel Cover Cap Screws	Torque	140 N·m (103 lb-ft)
Flywheel Cover to Engine Flywheel Cap Screws	Torque	73 N·m (54 lb-ft)
Rear Pump Support Bracket-to-Side Rails Cap Screws	Torque	140 N·m (103 lb-ft)
Rear Support Bracket-to-Rear Hydrostatic Pump Cap Screws	Torque	140 N·m (103 lb-ft)
Side Rails to Main Frame Cap Screws	Torque	320 N·m (236 lb-ft)

CED, TX03399, 5021 -19-13APR99-2/2

Section 11 Park Brake

Contents

	Page
Group 1100—Removal and Installation	
Other Material.....	11-1100-1
Brake Valve	
Remove and Install	11-1100-1
Park Brake	
Remove and Install	11-1100-3
Group 1115—Control Linkage	
Service Equipment and Tools	11-1115-1
Other Material.....	11-1115-1
Specifications	11-1115-1
Brake Pedal Control Linkage	
Remove and Install	11-1115-2
Park Lock Linkage	
Remove and Install	11-1115-3
Group 1160—Hydraulic System	
Other Material.....	11-1160-1
Specifications	11-1160-1
Brake Valve	
Disassemble and Assemble.....	11-1160-2
Park Brake	
Disassemble and Assemble.....	11-1160-3

Control Linkage

1— Knob	10— Nylon Washer	20— Spring (2 used)	30— Nut
2— Lever	11— Needle Bearing (2 used)	21— Pin (2 used)	31— Linkage Rod
3— Cap Screw (2 used)	12— Bracket	22— Washer (8 used)	32— Nut
4— Lever Upper Stop (Boss)	13— Nylon Washer	23— Lock Nut	33— Ball Joint
5— Lever Down Stop (Boss)	14— Bellcrank	24— Cap Screw	34— Cap Screw
6— Switch	15— Groove Pin	25— Lock Nut	35— Washer (2 used)
7— Socket Head Cap Screw (2 used)	16— Washer (5 used)	26— Washer	36— Washer (2 used)
8— Cam	17— Cotter Pin	27— Shoulder Cap Screw	37— Cap Screw (2 used)
9— Spring Pin	18— Pin	28— Brake Pedal	
	19— Pin Guide (2 used)	29— Yoke	

4. Remove lower dash panel (3).

NOTE: Before disassembly, mark the position of cam (8) and bellcrank (14) in relation to lever (2) to aid in assembly.

5. Position park lock lever (2) in the unlocked position (down) and remove shoulder cap screw (27), washer (26) and lock nut (25) to disconnect brake pedal (28) from yoke (29).

Remove cap screw (34), washers (35) and linkage rod assembly.

6. Remove cap screw (3) to remove lever upper stop (4). Rotate park brake lever up and remove cap screw (3) and lever down stop (5).

NOTE: Park brake lock lever should be in the unlocked position (down) to relieve tension on springs (20).

7. With park lever down, loosen cap screws (37).

8. Rotate right side of park lock assembly toward the operator and remove springs (20) and washers (16) by lifting springs and washers off of pins (21).

9. Remove cap screws (37), washers (36) and park lock linkage assembly.

10. Remove parts (21—24) from firewall anchor.

11. Remove switch (6).

IMPORTANT: Support assembly so needle bearings (11) do not receive an impact when driving out pins (9 and 15).

12. Remove pin (9) to remove cam (8) and nylon washer (10).

13. Remove pin (15).

14. Slide lever (2) out of bracket (12), removing washer (13) and bellcrank (14).

15. Remove bearings (11) from bracket (12).

16. Remove yoke (29) and ball joint (33) from linkage rod, if required. Count and record number of turns to aid in reassembly or replacement.

17. Clean and inspect all parts. Replace as required.

18. Install yoke (29) and ball joint (33) on linkage rod (31). Step of yoke (29) should face as shown.

19. Install bearings (11) flush into bracket (12) adding grease during assembly.

20. Clean cap screw (3) and apply cure primer. Apply thread lock and sealer (medium strength) to cap screw and install lever upper stop (4).

21. Install lever (2) through smaller side of bracket, bellcrank (14), nylon washer (13) and opposite side of bracket.

22. Install nylon washer (10) onto lever.

IMPORTANT: Support assembly so needle bearings (11) do not receive an impact when driving in pins (9 and 15).

23. Install cam (8) using pin (9) in orientation shown on illustration or as marked in disassembly.

24. Install bellcrank (14) using pin (15) in orientation shown in illustration or as marked in disassembly. Install pin flush in center of bellcrank.

25. Clean threads of lever (2) and apply cure primer. Apply thread lock and sealer (medium strength) to threads and install knob (1) with symbols facing outward.

26. Install parts (16—19). Install pin guides (19) and pin (18) in direction shown.

27. Install switch (6) using socket head cap screws (7).

28. Install parts (21—24) on firewall anchor. Tighten nut and then back off 1/2 turn.

29. Loosely install park lock assembly in machine using cap screws (37) and washers (16).

30. With the park lock lever in the unlocked position (down) and the right side of the park lock assembly rotated toward the operator, place washers (16) and spring (20) over pin (21). Install opposite end of spring over pin guide (19). Repeat steps for other side.

31. Rotate park lock lever to the locked position (up), while working pins (21) into pin guides (19). Rotate park lock assembly forward to the firewall and tighten cap screws (37).

32. Apply cure primer to threads of cap screw (3). Apply thread lock and sealer (medium strength) and install lever down stop (5) onto bracket (12).


33. Rotate park lock lever to unlocked position (down) and install park lock linkage rod by connecting ball joint (33) to left side of bellcrank assembly (14) and yoke (29) to brake pedal as shown. Make sure step of yoke (29) faces as shown.

Continued on next page

CED, OUTX547, 131 -19-08APR99-3/4

Group 1511 Drawbar

Remove and Install Drawbar



T118709

1— Plate
2— Washer (4 used)

3— Pin
4— Quick Lock Pin

5— Cap Screw (4 used)

T118709—UN—02DEC88


CED,OUTX547,133 -19-20OCT98-1/1

IMPORTANT: During freezing weather, batteries must be charged after water is added to prevent battery freezing. Charge battery using a battery charger or by running the engine.


3. Fill each cell to within specified range with distilled water. DO NOT overfill.

A—Battery Post
B—Fill Tube

C—Electrolyte Level Range



Single Level Fill Tube Application




Dual Level Fill Tube Application

CED,OUTX547,137 -19-14APR99-2/2

T6996DB—UN—10FEB89

T6996DA—UN—10FEB89



TX1075579

**CAB HARNESS (W5)
COMPONENT LOCATION (2 OF 8)**


Cab Harness (W5) Component Location 2 of 8 (S.N. 883589—)

REV 3.0

TX1075579—UN—13APR10

Continued on next page

CED,OUTX547,143-19-15JUN10-5/22



TX1075574

**CAB HARNESS (W5)
COMPONENT LOCATION (6 OF 8)**

Cab Harness (W5) Component Location 6 of 8 (S.N. —883588)

REV 3.0


TX1075574—UN—13APR10

Continued on next page

CED.OUTX547,143 -19-15JUN10-15/22

Y5
A/C
COMPRESSOR
CLUTCH
SOLENOID

V6
A/C
COMPRESSOR
CLUTCH
DIODE



Y1
FUEL
SHUT-OFF
SOLENOID

B11
ENGINE OIL
PRESSURE
SWITCH/SENDER

B19
ENGINE OIL
PRESSURE SWITCH

TX1075562

ENGINE HARNESS (W6)
COMPONENT LOCATION (2 OF 4)

Engine Component Location 2 of 4

REV 3.0

TX1075562—UN—13APR10

Y5—Air Conditioning
Compressor Clutch
Solenoid


V6—Air Conditioning Clutch
Diode

B11— Engine Oil Pressure
Switch/Sender

B19— Engine Oil Pressure Switch Y1— Fuel Shut-Off Solenoid

Continued on next page

CED.OUTX547,145 -19-15JUN10-3/7



TX1075567

**TRANSMISSION HARNESS (W7)
COMPONENT LOCATION (3 OF 5)**

Transmission Component Location 3 of 5

B16— Hydraulic Filter Restriction Switch
M11— Washer Motor
M13— Washer Motor

Y2— Start Aid Solenoid

REV 3.0

TX1075567—UN—13APR10


Continued on next page

CED,OUTX547,146-19-09JUN10-6/10

IMPORTANT: If all wire strands are not crimped into contact, cut off wire at contact and repeat contact installation procedure.

NOTE: Readjust crimping tool for each crimping procedure.

8. Inspect contact to be certain all wires are in crimped barrel.




TS0135—UN—23AUG88

CED,OUTX547,150 -19-14APR99-4/4

Replace Connectors

IMPORTANT: Identify wire color locations with connector terminal letters.

1. Open connector body (A).



TS0127—UN—23AUG88

TX,1674,QQ1181 -19-14APR99-1/4

2. Insert JDG364 Extraction Tool over terminal contact in connector body.




TS0128—UN—23AUG88

Continued on next page

TX,1674,QQ1181 -19-14APR99-2/4

Instruments and Indicators



T117816

(S.N. —875552) Shown


- | | | | |
|--|---|---|--|
| <p>A—Winch Oil Pressure Indicator—If Equipped (Red)</p> <p>B—Check Service Code Indicator (Clear)</p> <p>C—STOP-Engine Indicator (Red)</p> <p>D—Engine Coolant Temperature Indicator (Red)</p> <p>E—Engine Oil Pressure Indicator (Red)</p> | <p>F—Transmission Oil Temperature Indicator (Red)</p> <p>G—Hydraulic Oil Filter Restriction Indicator (Yellow)</p> <p>H—Fasten Seat Belt/Park Lock On Indicator (Clear)</p> <p>I—Transmission Oil Filter Indicator (Yellow)</p> | <p>J—Voltage Indicator (Yellow)</p> <p>K—Engine Air Filter Restriction Indicator (Yellow)</p> <p>L—Engine Oil Pressure Gauge</p> <p>M—Engine Water Temperature Gauge</p> <p>N—Fuel Gauge</p> <p>O—Transmission Oil Pressure Gauge</p> | <p>P—Front and Rear Work Lights Switch</p> <p>Q—Hour Meter</p> <p>R—Under-Seat Heater ON/OFF Switch</p> |
|--|---|---|--|

Continued on next page

CED.OUTX547,209 -19-10JUN10-3/5

T117816 —UN—22JAN99

Remove and Install Counterweight



T118712

1—Rear Counterweight
2—Front Counterweight

3—Washer (14 used)
4—Cap Screw (6 used)

5—Cap Screw (6 used)
6—Tow Hook
7—Cap Screw (2 used)

⚠ CAUTION: Components are heavy, use proper lifting device.

T118712—UN—02DEC98

CED.OUTX547,163 -19-21OCT98-1/1

Removal and Installation


26. Disconnect brake valve return hose (A) from reservoir. Close all openings using caps and plugs.
27. Disconnect brake valve charge pressure hose (B) from pump quick coupler.

**A—Brake Valve-to-Reservoir
Hose**

**B—Hydraulic Pump-to-Brake
Valve Hose**



T117191B—UN—14SEP98



T117190B—UN—14SEP98


Continued on next page

CED.TX03399.5019 -19-06APR99-9/13

Removal and Installation

28. Connect transmission and engine main wiring harness connectors (A and B) and cable (C).

- A—Transmission Main Wiring Harness Connector
- B—Engine Main Wiring Harness Connector
- C—Cable



T116814B—UN—20AUG98

CED.OUTX466,1177 -19-16APR99-11/12

29. Install cover under fuel tank (B) and rear access cover (A).

30. Install floor plate and floor mat.

31. Install molding strip to front of cab/ROPS.

32. Connect wiring to horn and install hood and precleaner.

33. Install engine side shields.

34. Fill radiator with coolant. (See [Fuel and Lubricants](#) in Group 0004.)

Cab/ROPS—Specification

Cooling System—Capacity..... 11.3 L (3 gal) (Approximate)


35. Fill hydraulic reservoir if drained. [See Hydraulic and Hydrostatic Oil](#). (Group 9004.)

Specification

Hydraulic Reservoir—Capacity..... 32 L (8.5 gal) (Approximate)

NOTE: If air conditioning system is being turned on for the first time, set engine rpm at slow idle to avoid possible high pressure discharge of extra refrigerant oil that is in all new compressors.

36. **For Cabs Equipped With Air Conditioning System:**



450H Shown

- A—Rear Access Cover
- B—Cover Under Fuel Tank


Charge air conditioning system. (See [Recover, Evacuate and Charge Air Conditioning System](#) in Group 1830.)

37. Check and adjust engine rpm. (See [Engine Speed Control Linkage Adjustment](#) in Operation and Test Manual, Group 9026-20.)

T116662B—UN—27AUG98

CED.OUTX466,1177 -19-16APR99-12/12

Remove and Install Standard Seat




TP52109

TP52109—UN—16JAN99

Continued on next page

CED,OUTX547,168 -19-12APR99-1/5

Seat and Seat Belt




Seat Suspension Kits (Deluxe Seat)

Continued on next page

CED.OUO1066,274 -19-12APR99-7/10

R134a Refrigerant Theory of Operation



TX1075559

R134a Refrigerant Theory of Operation

- | | | | |
|---------------------|------------------------|-----------------------|---------------------|
| A—Compressor | E—High Pressure Liquid | H—Receiver/Dryer | L—Blowers |
| B—High Pressure Gas | F—High Pressure Switch | I—Expansion Valve | M—A/C Freeze Switch |
| C—Condenser Fans | G—Low Pressure Switch | J—Low Pressure Liquid | N—Low Pressure Gas |
| D—Condenser | | K—Evaporator | |

The compressor (A) draws low pressure gas (N) from the evaporator (K) and compresses it into high pressure gas (B). Increasing the pressure of the R134a refrigerant causes its boiling point to rise to a temperature higher than the outside air temperature.

High pressure gas (B) leaves the compressor (A) and passes through the condenser (D), the condenser fans (C) draws air through the condenser core which cools the R134a refrigerant. Cooling the refrigerant causes it to condense and it leaves the condenser (D) as a high pressure liquid (E).

The refrigerant flows from the receiver/dryer (H) to the expansion valve (I). The expansion valve (I) is a variable orifice used to cause a pressure and temperature drop in the refrigerant causing refrigerant to vaporize. The expansion valve (I) is one of the dividing lines between the high side and low side of the air conditioning system. At this point in the system, the high pressure/high temperature liquid R134a is sprayed into the evaporator (K) where it changes and becomes a gas.

The high pressure liquid passes through two switches (F and G). These switches monitor R134a refrigerant

pressure. Should the pressure become too great or too small, either the high or low pressure switch will open and stop the compressor, interrupting the cycle. From the switches the high pressure liquid flows into the receiver/dryer (H) where moisture and contaminants are removed.

The expansion valve diaphragm is activated by sensing temperature and pressure within the valve body. The internal bulb senses the evaporator outlet or discharge temperature and pressure of R134a as it passes through the valve back to the low pressure or suction side of the compressor. See [Expansion Valve Operation](#) in this group for additional information on theory of operation.

If too much refrigerant is flowing into evaporator, the liquid refrigerant will still be evaporating as it leaves the evaporator, causing a low temperature at the evaporator outlet. The low temperature causes the expansion valve variable orifice to decrease in size, restricting refrigerant flow. If the evaporator outlet temperature is too warm, the orifice will increase in size, allowing more refrigerant into evaporator.

Continued on next page

CED,OUTX547,171 -19-15JUN10-1/2

TX1075559—UN—13APR10

16. Reinstall evaporator.

17. Go to Step 22.

18. To Flush Evaporator Through Expansion Valve:

Connect flusher outlet hose to connection of receiver/dryer outlet hose using JT03188 Adapter.

19. Attach a hose and aerator nozzle to compressor inlet line using JT02101 Adapter. Put nozzle in a container to collect solvent.

20. Repeat Steps 8, 9 and 10 to flush evaporator.

NOTE: Purging the evaporator circuit takes 12—15 minutes to thoroughly remove solvent.

21. Disconnect hose from aeration nozzle to check circuit for solvent. Hold hose close to a piece of cardboard. Continue purging until cardboard is dry.

22. Install a new receiver-dryer compatible with R134a refrigerant. Tighten connections and mounting bracket.

23. Add required oil. (See procedure in this group.)

24. Install compressor, and connect refrigerant lines to manifold.


25. Connect clutch coil wire. Install drive belt.

26. Purge system. (See procedure in this group.)

CED, TX03399, 2293 -19-16APR99-2/2

6. Disconnect lines and bracket from expansion valve (14).
7. Remove two screw (12) and remove expansion valve
8. Remove bracket (13).
9. Remove two cap screw and remove plate (10).
10. Remove cover (11) and remove evaporator or heater core.

- | | |
|----------------------------------|---------------------|
| 10— Plate | 13— Bracket |
| 11— Evaporator/Heater Core Cover | 14— Expansion Valve |
| 12— Cap Screw (2 used) | |




T118221B —UN—03NOV98


CED,OUTX547,182 -19-16APR99-2/3

11. Install evaporator or heater core.
12. Install (11, 10, 13, and 14). Tighten cap screws.
13. Connect (4—6, 8 and 9). Tighten cap screws (3 and 7).
14. Connect hoses (1 and 2).
15. Install access cover and tighten cap screws.
16. Install new receiver/dryer.
17. Apply refrigerant oil to new O-rings and immediately connect lines.
18. Add oil. (See R134a Component Oil Charge in this group.)
19. Evacuate and charge the air conditioning system. (See procedure in this group.)


- | | |
|---|---|
| 1— Receiver-Dryer Hose-to-Condenser | 8— A/C Blower Fans and Switch Connector |
| 2— Receiver-Dryer Hose from Evaporator | 9— Low Pressure Switch Connector |
| 3— Cap Screw (2 used) | 10— Plate |
| 4— Two Heater Hoses-to-Under the Seat Heater Core | 11— Evaporator/Heater Core Cover |
| 5— A/C Harness Connector-to-Cab Harness Connector | 12— Cap Screw (2 used) |
| 6— Expansion Valve Hose-to-Compressor | 13— Bracket |
| 7— Cap Screw (8 used) | 14— Expansion Valve |



T118221B —UN—03NOV98



T118220B —UN—05NOV98



T118219B —UN—03NOV98

CED,OUTX547,182 -19-16APR99-3/3

Section 19
Sheet Metal and Styling

Contents

	Page
Group 1910—Hood and Engine Enclosure	
Specifications	19-1910-1
Hood	
Remove and Install	19-1910-2
Hood Support and Engine Side Shields	
Remove and Install	19-1910-4
Group 1921—Grille and Grille Housing	
Specifications	19-1921-1
Grille and Grille Housing	
Remove	19-1921-2
Install	19-1921-4

Grille and Grille Housing

1— Handle (2 used)
2— Washer (4 used)
3— Cap Screw (2 used)
4— Head Light Plate

5— Standard Grille
6— Hose Guard
7— Cap Screw (6 used)
8— Washer (12 used)

9— Cap Screw (6 used)
10— Nut (2 used)
11— Washer (4 used)
12— Cap Screw (4 used)

13— Grille Housing

Continued on next page

CED,TX03399,5003 -19-07JUN01-2/8


Group 2004 Horn and Warning Devices

Remove and Install Reverse Warning Alarm

1. Remove cap screws (1).
2. Remove panel (2)
3. Disconnect reverse warning alarm wiring leads.
4. Remove cap screws and remove reverse warning alarm.
5. Install alarm, connect wiring leads, and install panel and tighten cap screws.

1— Cap Screw (2 used)

2— Panel



T1187185 —UN—02DEC98

CED,OUTX547,185 -19-21OCT98-1/1


Adjust Reverse Warning Alarm Volume

IMPORTANT: The reverse warning alarm is set on high volume at the factory. It may be necessary to adjust the volume to meet local regulations.

1. To change alarm to low volume, remove nut (1) and disconnect wire from "POS HI" terminal.
2. Attach wire to "POS LOW" terminal (2). Install nut and tighten.

1— Nut


2— POS LOW Terminal



T118715B —UN—02DEC98

CED,OUTX547,186 -19-16APR99-1/1

Hydraulic System



T119603

Thru Drive Hydraulic Pump (S.N. —894133)

T119603—UN—18JAN99

Continued on next page

TX,3260,SS2327 -19-16JAN04-5/6

Hydraulic System

Blades

- 1— Cap Screw (4 used)
- 2— Retainer Plate (4 used)
- 3— Pin (4 used)

- 4— Blade and Cutting Edges
- 5— Bushing (8 used)
- 6— Bushing (6 used)

- 7— C-Frame
- 8— Bushing (2 used)
- 9— Cap Screw (4 used)
- 10— Cap

- 11— Shim (16 used)
- 12— Mounting Socket (Welded On)

1. Lower all equipment to the ground.
2. Stop engine and operate control valves to relieve pressure in the hydraulic system.
3. Attach lifting chain to blade.
4. Remove cap screw (1) and retainer (2) on left side. Drive upper and lower pins (3) out.
5. Remove rubber bushings.
6. Remove retainer (2) and cap screw (1) on right side of angle cylinder rod end. Drive pin (3) out.
7. Remove rubber bushings.
8. Install a chain and hoist to blade.
9. Remove strut retainer (2) and cap screw (1), lift up on blade and drive out pin (3).
10. Remove rubber bushings.
11. Remove pivot cap screws (9) and remove shims (11).
12. Remove blade.
13. Install blade, rubber bushings and pins.
14. If pin does not line up on right angle cylinder, loosen angle cylinder lines to relieve pressure to adjust cylinder rod.
15. Install pivot cap screws. When tightening pivot cap screws, angle blade to maximum on both sides. Tighten cap screw.

⚠ CAUTION: The approximate weight of blade is 426 kg (940 lb).

Blade—Specification

Blade—Weight.....426 kg (940 lb) (Approximate)

Blade—Specification

Pivot Cap
Screws—Torque..... 624 N-m (460 lb-ft)

CED,OUTX547,192 -19-17JUL02-2/2

Group 3240 Frames

Specifications

Item	Measurement	Specification
C-Frame		
C-Frame with Blade	Weight	1040 kg (2294 lb) (Approximate)
C-Frame	Weight	375 kg (826 lb) (Approximate)

CED, TX03399, 2352 -19-10JUN02-1/1


Remove and Install Dozer C-Frame (S.N. —903158)

NOTE: C-Frame can be removed with blade attached.

1. Lower all equipment to the ground.
2. Stop engine. Operate all control valves to release pressure in hydraulic system.
3. Remove blade if necessary. (See [Remove and Install Dozer Blade](#) in Group 3201.)

NOTE: If equipped with heavy duty grille, remove upper hose guard.

4. Remove clamp (1).
5. Remove hose guard (2).



1—Hose Clamp
2—Hose Guard


3—Cylinder Hose (4 used)

T119392B—UN—07JAN99

CED, OUTX547, 196 -19-17JUN02-1/4

⚠ CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



6. Disconnect four hoses (3). Close all openings using caps and plugs.

Continued on next page

CED, OUTX547, 196 -19-17JUN02-2/4

X9811—UN—23AUG88

Disassemble and Assemble Hydraulic Control Valve

IMPORTANT: Keep all components for each valve section together as a set.

1. To aid in assembly, identify each section with a mark.
2. Place valve in a vertical position having the inlet section down and supported by wood blocks.
3. Remove nuts (8) and tie rods (7).
4. Carefully remove sections (1—6) so as not to lose or damage O-rings (11), load checks (10), and springs (9). Keep load checks and valve sections together as a set.

IMPORTANT: Use care not to damage or score mating surfaces of valve sections.


5. Inspect O-rings between each section for wear or damage. Replace as necessary.
6. Inspect springs and load checks for scoring, wear, or damage. Replace as necessary.
7. Apply clean hydraulic oil to all internal parts.
8. Install load check, spring, and O-ring into each spool section.
9. Assemble sections (1—6), making sure load checks, springs, and O-rings remain in position.

IMPORTANT: Tighten tie rod and nuts evenly to prevent valve spool binding or leakage between sections.


10. Tighten tie rod nuts (8) to specifications.

Hydraulic Control Valve—Specification

Control Valve Assembly	
5/16-18 in. Tie Rod	
Nuts—Torque.....	19 ± 2 N·m (168 ± 18 lb-in.)
Control Valve Assembly	
3/8-24 in. Tie Rod	
Nuts—Torque.....	44.7 ± 4.7 N·m (396 ± 42 lb-in.)



T118810



T119779

- 1— Inlet Section
- 2— Auxiliary Section
- 3— Angle Section
- 4— Tilt Section
- 5— Lift Section
- 6— Outlet Section

- 7— Tie Rod (3 used)
- 8— Nut (6 used)
- 9— Spring (1 in each spool section)
- 10— Load Check (1 in each spool section)
- 11— O-Ring (1 between each section)

T118810—UN—10DEC98

T119779—UN—22JAN99

CED, TX03768, 2527 -19-09APR99-1/1

Hydraulic System

IMPORTANT: Tightening work ports relief using jam nut on end of relief will cause damage to work ports relief. Do not tighten work ports relief using jam nut on end of relief.

Hydraulic Control Valve—Specification

Angle Valve Circuit	
Relief—Torque.....	45 ± 4 N·m 33 ± 3 lb.-ft.

9. Assemble work ports reliefs (14) into housing (1).
Tighten reliefs to specification.

CED,OUO1004,533 -19-14,JUL09-2/2

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL