

544J Loader Repair

(Serial No. 611800-)

TECHNICAL MANUAL 544J Loader Repair (S.N. 611800—)

TM10244 16JAN08 (ENGLISH)

For complete service information also see:

544J Loader Operation and Test (S.N. 611800—)	TM10229
544J Loader Operator's Manual (S.N. 611800—)	OMT229869
Alternators and Starting Motors.....	CTM77
POWERTECH™ 4.5 L and 6.8 L Diesel Engines—Base Engine	CTM104
TeamMate™ IV 1200 and 1400 Series Inboard Planetary Axles	CTM442
POWERTECH E™ 4.5 & 6.8L Diesel Engines—Level 16 Electronic Fuel System with Denso HPCR	CTM502
Super Caddy Oil Cleanup Procedure.....	CTM310
120 Series Hydraulic Cylinders	TM-H120A
125 Series Hydraulic Cylinders	TM-H125A

**Worldwide Construction
And Forestry Division**

LITHO in U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T1133555 -UN-28AUG00

T1133588 -19-28AUG00

TX03679,00016CC -19-01OCT07-1/1

Follow Safety Instructions

Read the safety messages in this manual and on the machine. Follow these warnings and instructions carefully. Review them frequently. Keep safety signs in good condition. Replace missing or damaged safety signs. Replacement safety signs are available from your authorized John Deere dealer.

Be sure all operators of this machine understand every safety message. Replace operator's manual and safety labels immediately if missing or damaged.



T1133556 -UN-24AUG00


TX03679,00016F9 -19-18OCT07-1/1

Avoid Backover Accidents

Before moving machine, be sure all persons are clear of machine path. Turn around and look directly for best visibility. Use mirrors to assist in checking all around machine. Keep windows and mirrors clean, adjusted, and in good repair.

Be certain reverse warning alarm is working properly.

Use a signal person when backing if view is obstructed or when in close quarters. Keep signal person in view at all times. Use prearranged hand signals to communicate.



T-141673 -UN-04MAY01

TX03679,000179C -19-20APR01-1/1

Avoid Machine Tip Over

Use seat belt at all times.

Do not jump if the machine tips. You will be unlikely to jump clear and the machine may crush you.

Load and unload from trucks or trailers carefully. Be sure truck is wide enough and on a firm level surface. Use loading ramps and attach them properly to truck bed.


Be careful on slopes. Avoid sharp turns. Balance loads so weight is evenly distributed and load is stable. Carry tools and loads close to the ground to aid visibility and lower center of gravity. Use extra care on soft, rocky or frozen ground.

Know the capacity of the machine. Do not overload. Be careful with heavy loads. Using oversize buckets or lifting heavy objects reduces machine stability.

Ensure solid footing. Use extra care in soft ground conditions that may not uniformly support the wheels, especially when raising the boom. Do not operate close to banks or open excavations that may cave in and cause machine to tip or fall.



**USE
SEAT
BELT**



T133716 -19-14SEP00

T-141676 -UN-04MAY01

T-141672 -UN-04MAY01


TX03679,000179D -19-02MAY01-1/1

Powered Wheels and Fasteners

Before attempting any demounting operation, always completely deflate tire. Remove protective cap (A) and valve core (B) from valve. Remove valve nut (C).

Inspect all parts for damage. Replace parts as necessary.

- A—Protective Cap
- B—Valve Core
- C—Valve Nut



Wheel Air Valve and Protective Cap

T7751GU -JN-22OCT92

01
0110
3

SJ25320,000047C -19-07AUG07-2/2

CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

Specification	
Machine—Weight (approximate)	13 518 kg 29 802 lb

8. Raise rear of machine using floor jack. Install floor stands under frame on each side and under rear corners of frame.

CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

9. Remove wheels. See Wheel Remove and Install. (Group 0110.)

IMPORTANT: Do not reuse drive shaft universal joint cap screws. Replace cap screws to avoid machine damage.


10. Remove cap screws to disconnect drive shaft.

CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

Specification	
Axle and Differential with Oscillating Supports—Weight (approximate).....	953 kg 2100 lb

11. Install low-lift jack under axle assmby.


1—Floor Stand (4 used)



Floor Stand Under Frame

TX1005981A -UN-04APR06

02
0200
7



Positioning Floor Stands

TX1005982A -UN-04APR06

Continued on next page

SJ25320,0000442 -19-10JUL07-3/6

Group 0225
Axle Shafts and U-Joints

02
0225
1

Hydraulic System

1—O-Ring (4 used)	10—Washer (4 used)	19—O-Ring	28—Pump
2—Elbow Fitting (4 used)	11—Washer (2 used)	20—Hydraulic Hose	29—Cap Screw (2 used)
3—O-Ring (4 used)	12—Nut (2 used)	21—Hydraulic Hose	30—Cover
4—Hydraulic Hose	13—Hydraulic Hose	22—Tee Fitting (2 used)	31—Gasket
5—Hydraulic Hose	14—Hydraulic Hose	23—Hydraulic Hose	32—O-Ring (2 used)
6—O-Ring (4 used)	15—Filter (2 used)	24—Hydraulic Hose	33—Elbow Fitting (2 used)
7—O-Ring (2 used)	16—Elbow Fitting (2 used)	25—Elbow Fitting (2 used)	34—Hydraulic Hose
8—Bracket (2 used)	17—O-Ring (2 used)	26—O-Ring (4 used)	35—Hydraulic Hose
9—Cap Screw (4 used)	18—O-Ring	27—O-Ring (2 used)	36—Hydraulic Hose

When repairing pumps tighten valve section cap screws to following specification.

Fan Pump—Specification

Pump Section Cap Screws—	
Torque.....	51—58 N.m 38—43 lb-ft

Axle Circulating Pump—Specification

Pump Section Cap Screws—	
Torque.....	14—18 N.m 10—13 lb-ft


For more information on axle circulation system, see Power Train Component Location. (Group 9020-15.)

02
0260
5

SJ25320,0000447 -19-25JUL07-2/2

Gears, Shafts, Bearings and Power Shift Clutch


9. Remove cap screws and separate input shaft from drive plate.



T112415 -UN-05DEC97

SJ25320,0000468 -19-18MAY07-8/10


10. Remove speed sensor from converter housing.



T108720 -UN-17APR97

SJ25320,0000468 -19-18MAY07-9/10

11. Remove cap screws and remove converter lower housing.




T108729 -UN-17APR97

SJ25320,0000468 -19-18MAY07-10/10

03
0350
3


23. Remove bearing outer race and pull output shaft out of the housing bore.



MH66O88,00005B5 -19-18MAY07-18/19

T108790 -UN-18APR97

24. Remove the snap ring and separate the ball bearing from the shaft.



MH66O88,00005B5 -19-18MAY07-19/19

T108791 -UN-29APR97

03
0350
13


Clutches, Input and Output Shafts Install

IMPORTANT: High tolerance bearings are used in all clutch pack applications. Use only John Deere sourced bearings when replacing.

NOTE: If bearings are reused, they must be assembled in the same bores they were removed from.

1. Install all bearing outer races into the housing cover until contact is obtained.

- AB—Output Shaft
- AN—Input Shaft
- K1—First Speed Clutch
- K2—Second Speed Clutch
- K3—Third Speed Clutch
- K4—High-Range Forward Clutch
- KR—Reverse Clutch
- KV—Low-Range Forward Clutch




T109004 -UN-30APR97

Continued on next page

SJ25320,000047F -19-24JUL07-1/31

Gears, Shafts, Bearings and Power Shift Clutch


3. Separate plate carrier from shaft.



SJ25320,000044A -19-18MAY07-3/10

T108794 -UN-18APR97

4. Remove clutch pack.



SJ25320,000044A -19-18MAY07-4/10

T108795 -UN-18APR97

5. Preload compression spring with DFT1149 Pre-Load Clutch Pack Compression Ring Tool in press and remove snap ring. For instructions to make tool, see DFT1149 Pre-Load Clutch Pack Compression Ring Tool. (Group 9900.)


6. Remove piston from carrier.



SJ25320,000044A -19-18MAY07-5/10

T108761 -UN-17APR97

7. Remove O-rings from piston.




SJ25320,000044A -19-18MAY07-6/10

T108758 -UN-29APR97

Continued on next page

18. Install pre-assembled plate carrier until all plates are engaged.




Assemble Plate Carrier

T108675 -UN-10APR97

03
0350
33

SJ25320,000044B -19-18MAY07-16/19

19. Ensure carrier face is flush with shaft spline.




Carrier Face Flush with Shaft Spline

T108676 -UN-10APR97

Continued on next page

SJ25320,000044B -19-18MAY07-17/19

13. Lubricate and install the O-ring.



O-Ring Installation


T109088 -UN-29APR97

03
0360
5

SJ25320,000046A -19-21JUN07-9/13

IMPORTANT: Tightening the two assembly screws will cause transmission pump failure. Do Not tighten the two assembly screws, they are used to hold pump together for installation and are not to be torqued or removed.

14. Install transmission pump.



Transmission Pump Installation

T109089 -UN-15APR97

Continued on next page


SJ25320,000046A -19-21JUN07-10/13

Hydraulic System

1—Cap Screw (32 used)	11—Piston (Dampening Valve) (6 used)	20—Gasket	29—Piston (Pressure Control Valve) (6 used)
2—Clamp (Clip)	12—Spring (6 used)	21—Housing	30—Spring (6 used)
3—Cover	13—Spring	22—Retaining Plate (3 used)	31—Orifice (6 used)
4—Wiring Harness	14—Piston—System Pressure Reducing Valve	23—Cap Screw (3 used)	32—Gasket
5—Gasket	15—Valve Block (Control)	24—Gasket	33—Plate (Center)
6—Solenoid Valve—Proportional (3 used)	16—O-Ring (8 used)	25—Cover	34—Gasket
7—Cap Screw (3 used)	17—Drain Plug (8 used)	26—Cap Screw (14 used)	35—Manifold Plate
8—Plate (3 used)	18—Spring	27—Solenoid Valve—Proportional (3 used)	36—Cap Screw (18 used)
9—Housing	19—Piston (System Pressure Regulating Valve)	28—Cap Screw (18 used)	37—Screen (6 used)
10—Gasket			


MH66O88.00005BC -19-18MAY07-3/29

1. Remove cap screws (26), and remove cover (25) and gasket (24).
2. Disconnect wiring harness connectors to solenoid valves (27).
3. Remove cap screws (23) and retaining plates (22), and remove three solenoid valves (27).



Control Valve

T108686 -UN-16APR97



Solenoid Valves Pulled Out

T108687 -UN-16APR97

Continued on next page

MH66O88.00005BC -19-18MAY07-4/29

03
0360
15

Hydraulic System


41. Insert three solenoid valves (6) equipped with O-ring, and fasten by means of retaining plate (22) and screw (23).

NOTE: Install retaining plate with the claw facing the housing bottom.

42. Tighten screw to specification.

Specification

Solenoid Valve-to-Retaining Plate	
Screw—Torque.....	5 N•m 44 lb-in.



T108698 -UN-16APR97

Solenoid Valves Tightening


03
0360
25

MH66O88,00005BC -19-18MAY07-23/29

43. Fasten harness connectors to solenoid valves.
44. Screw two alignment studs in housing and assemble flat gasket (24) and cover (25). Tighten screw (M341095) (26) to specification.

Specification

Alignment Stud-to-Cover Screw—	
Torque	5 N•m 44 lb-in.



T108699 -UN-30APR97

Alignment Studs Placement

Continued on next page

MH66O88,00005BC -19-18MAY07-24/29

Remove & Installing Oil Tubes In Transmission Cover


1. All pipe can be removed by using a small pry bar inside the cover.

Oil Tube Swaging Tool for Tube Installation	
Two Tubes In Transmission Cover	JDG1133 Oil Tube Swaging Tool


IMPORTANT: Oil tubes must be positioned slightly below housing surface on opposite side.

2. Install two oil tubes in transmission cover using JDG1133 Swaging Tool.
3. Insert swaging tool into oil tube end in bore until seated against tools edge (A).
4. Slide rolling pin (C) down until seated. Start turning pin with wrench. Pressure will slowly increase. Turn approximately 10 to 12 full turns.

- A—Tool Edge
- B—JDG1131 Oil Tube Swaging Tool (used for Suction Tube)
- C—Rolling Pin



Transmission Cover



Similar JDG1131 (used for Suction Tube) Shown

T108658 -UN-09MAY97

03
0360
35

T112178B -UN-12NOV97

Removal and Installation


22. Remove positive battery cables (10) and wires E01 WHT (11) from starter.

23. Remove ground wire (12) from starter.

NOTE: It is not necessary to disconnect air conditioning hoses from compressor or receiver-dryer when removing compressor.

24. Remove air conditioning compressor. Use tie band to secure compressor aside.

25. Remove fuel return hose from fuel rail on right side of engine. Close all openings using caps and plugs.



Starter

- 10—Positive Battery Cables
- 11—Wires E01 WHT
- 12—Ground Wire

TX1021043A -UN-26MAR07


04
0400
7

CS33148,000238B -19-25MAY07-4/10

NOTE: Rotate the engine so the drive shaft U-joint bolts are accessible.

26. Remove four cap screws (14) from the engine-to-torque converter drive shaft (15) U-joints at the torque converter housing (13).

- 13—Torque Converter Housing
- 14—U-Joint Retaining Cap Screw (4 used)
- 15—Drive Shaft



Drive Shaft Cap Screws

TX1020406A -UN-12MAR07

Continued on next page

CS33148,000238B -19-25MAY07-5/10

Cold Weather Starting Aids

1. Turn battery disconnect switch to the OFF position.
2. Drain engine coolant into an appropriate container for storage or disposal.

Specification

Engine Coolant—Capacity
(approximate)..... 22 L
5.9 gal

3. Remove power cord (A).
4. Loosen engine coolant heating element nut (C).
5. Remove heating element assembly from block.

CAUTION: Personal injury could occur. Do not plug coolant heater into electrical power unless heating element is immersed in coolant. Sheath could burst.


Use a heavy-duty grounded cord to connect coolant heater to electrical power.

6. Disassemble parts (B—G).
7. Repair or replace parts as necessary.
8. Assemble parts (B—G).
9. Install heating element assembly into cylinder block so flats on threaded portion of element are vertical.
10. Turn element clockwise until element contacts casting and then counterclockwise until element contacts casting. Move element to the center position.
11. Hold flats on threaded portion of element using a wrench. Tighten engine coolant heating element nut (C) to specification.

Specification

Engine Coolant Heater Element
Nut—Torque 34 N•m
25 lb-ft

12. Install power cord (A).



Heating Element Assembly

- A—Power Cord
- B—Cap
- C—Engine Coolant Heating Element Nut
- D—Adapter
- E—Gasket
- F—O-Ring
- G—Heating Element

T6427AO -UN-21OCT88

05
0505
3

Continued on next page

CS33148,000238D -19-18MAY07-2/3

Cooling System




CAUTION: Prevent possible crushing injury from heavy component. Use appropriate lifting device.

4. Remove cooling package access doors (1).

Specification

Access Door—Weight (approximate).....	31 kg 68 lb
---------------------------------------	----------------

5. Remove inspection panels between engine and radiator.
6. Disconnect electrical connector from cooling package plenum below radiator.



Access Doors

1—Cooling Package Access Door (3 used)

TX1021341A -UN-12APR07

TW70818,000006F -19-18MAY07-2/7


7. Attach hose to radiator drain valve (2). Drain engine coolant. See Drain and Refill Capacities. (Operator's Manual.)

Specification

Engine Coolant—Capacity (approximate).....	22.5 L 5.9 gal
--	-------------------

NOTE: For assembly purposes, identify all lines before removing.

8. Remove refrigerant. See R134a System Evacuate. (Group 1830.)



2—Radiator Drain Valve

TX1022753A -UN-26APR07

05
0510
9

Continued on next page

TW70818,000006F -19-18MAY07-3/7

Group 0530
External Exhaust System

05
0530
1

Section 07 Dampener Drive

Contents

Page

Group 0752—Elements

Output Dampener Remove and Install.07-0752-1

Hydraulic System

- 1—Isolator
- 2—Cap Screw (3 used)
- 3—Lock Nut (3 used)

- 4—Washer (4 used)
- 5—Rubber Mount (3 used)
- 6—Cap Screw (4 used)

- 7—Washer (4 used)
- 8—Support Bracket
- 9—Spacer (4 used)

- 10—Lower Steering Column
- 11—Steering Valve

NOTE: Avoid dropping the steering valve. Support steering valve before removing cap screws (2).

- 7. Support steering valve, and remove cap screws (2), lock nuts (3), washers (4) and rubber mounts (5).
- 8. Remove steering valve assembly.
- 9. Remove cap screws (6), washers (7).
- 10. Remove support bracket (8), spacers (9) and lower steering column (10) from steering valve (11).
- 11. Repair or replace parts as necessary.
- 12. Install lower steering column, spacers, and support bracket to steering valve.
- 13. Install washers and cap screws to support bracket, tighten to specification.

Specification

Bracket-to-Valve Cap Screw—
Torque..... 27 N•m
20 lb-ft

- 14. Install the rubber mounts to support bracket.
- 15. Install steering valve assembly into machine.
- 16. Install washers, cap screws and lock nuts.

NOTE: When installing lower isolator cap screw, align cutout on shaft with isolator.

- 17. Install lower isolator cap screw. Tighten to specification.

Specification

Lower Isolator Cap Screw—
Torque..... 57 N•m
42 lb-ft

- 18. Connect hydraulic steering lines. Remove vacuum or fill hydraulic reservoir. See Drain and Refill Capacities. (Operator's Manual.)
- 19. Install cover to steering column.
- 20. Install front cab panel.

TW70818.0000054 -19-25OCT07-5/5

09
0960
5

Section 10 Service Brakes

Contents

Page

Group 1011—Active Elements

Service Brake Assembly Remove and Install	10-1011-1
Brake Pedal and Linkage Disassemble and Assemble	10-1011-2

Group 1060—Hydraulic System

Brake Valve Remove and Install	10-1060-1
Brake Accumulator Remove and Install	10-1060-3

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Section 11 Park Brake

Contents

Page

Group 1111—Active Elements

Park Brake Remove and Install11-1111-1

Park Brake Disassemble and Assemble11-1111-4

Group 1160—Hydraulic System

Park Brake Release Solenoid Valve Remove
and Install11-1160-1

Park Brake Release Solenoid Valve Remove and Install




CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

1. Perform Hydraulic System Pressure and Accumulators Discharge. (Group 9025-25.)



Escaping Fluid Under Pressure

X9811 -UN-23AUG88

Continued on next page

CS33148,0002308 -19-23MAY07-1/2

Frame Installation

- 5. Press lower seal (I) into seal spacer (H) with lips facing out. The seal must seat against seal spacer shoulder.
- 6. Install seal spacer (H) in bottom of loader frame bore.
- 7. Press first bearing cup into bore against seal spacer.

IMPORTANT: Do not apply load to bearing cone when pressing in cup. Use old bearing race to apply load on new bearing cup to prevent bearing damage.

- 8. Install first bearing cone in cup.

IMPORTANT: Use the same spacer (K) which was removed from the bearing set. Spacer is not interchangeable with other bearings.

- 9. Install bearing spacer.
- 10. Press second bearing cup into bore against spacer. Install second bearing cone.

- 11. Install upper seal (C) into cover with lip facing out. Press seal to cover shoulder.
- 12. Hold cover in place, measure gap between cover and frame, take readings in three places. Cover must contact top of bearing. Calculate the average of these three reading to determine shim pack required.
- 13. Install shims to obtain the specified preload of bearings.

Specification

Upper Pivot Bearing—Preload 0.03—0.13 mm
0.001—0.005 in.

- 14. Apply grease to the top of bearing, fill cavity above bearing to machined surface, to prevent moisture from entering bearing through shims.
- 15. Tighten cap screws (L) to specification. Rotate inner race of bearing after tightening.

Specification

Upper Pivot Bearing Cover Cap
Screw—Torque 128 N•m
95 lb-ft

17
1740
7

Section 18 Operator's Station

Contents

	Page	Page
Group 1800—Removal and Installation		
Cab Remove	18-1800-1	
Cab Install	18-1800-7	
Group 1810—Operator Enclosure		
Windowpanes Remove and Install	18-1810-1	
Cab Door Hold-Open Release Adjust	18-1810-1	
Front and Rear Windshield Wiper Motor Remove and Install	18-1810-2	
Group 1830—Heating and Air Conditioning		
Air Conditioning System Fittings		
Reference Chart	18-1830-1	
R134a Refrigerant Cautions	18-1830-3	
R134a Compressor Oil Charge Check	18-1830-3	
R134a Compressor Oil Removal	18-1830-4	
R134a Component Oil Charge	18-1830-5	
Leak Testing	18-1830-6	
Refrigerant Hoses and Tubing Inspection	18-1830-6	
R134a Refrigerant Recovery, Recycling, and Charging Station Installation Procedure	18-1830-7	
R134a System Recover	18-1830-8	
R134a System Evacuate	18-1830-9	
R134a System Charge	18-1830-10	
Air Conditioner System Cleaning		
Procedures	18-1830-12	
Air Conditioner System Purge	18-1830-13	
Air Conditioner System Flush	18-1830-14	
Air Conditioning Module with Heater/Evaporator Coil	18-1830-16	
Heater/Evaporator Coil Remove and Install	18-1830-18	
Expansion Valve Remove and Install	18-1830-20	
Freeze Control Switch Remove and Install	18-1830-20	
Freeze Control Switch Bench Test	18-1830-21	
Heater Control Valve Remove and Install	18-1830-22	
Heater Control Valve Leak Check	18-1830-23	
Main Blower Assembly Remove and Install	18-1830-24	
Pressurizer Motor Assembly Remove and Install	18-1830-25	
Receiver-Dryer and Condenser Remove and Install	18-1830-25	
		A/C Binary Pressure Switch Remove and Install 18-1830-29
		Fresh Air Filter Remove and Install 18-1830-30
		Recirculating Air Filter Remove and Install 18-1830-33
		Compressor Remove and Install 18-1830-34
		Compressor Clutch—R134a Disassemble and Assemble 18-1830-36
		Clutch Hub Clearance—R134a Check 18-1830-37



Windowpanes Remove and Install

The adhesive used to hold the windowpanes in place is a urethane adhesive that is used on most automobile windshields. Urethane adhesive manufactured by Loctite Corporation or equivalent is recommended. Do not use any other type of adhesive. It is also recommended that an auto glass dealer install the windowpanes.

IMPORTANT: Windowpanes must have an ultra-violet barrier around the edge of the glass since ultra-violet rays will deteriorate the adhesive. Windowpanes ordered through John Deere Parts have the ultra-violet barrier. If the windowpane is purchased through a glass dealer, the dealer must put an ultra-violet barrier on the glass. Do not apply paint to the border of the glass.

If an auto glass dealer is not installing the windowpanes, use the following procedure:

1. Purchase urethane adhesive from your local auto glass dealer.
2. If window frame is removable, remove frame from cab.
3. Scrape broken glass off existing adhesive. Do not remove adhesive from window frame or cab.

IMPORTANT: Adhesive will not stick to bare metal.

4. If existing adhesive is removed from frame and paint is scraped off window frame, paint window frame. Paint must be fully cured before installing windowpane.
5. Trim existing adhesive so it has a smooth surface.
6. Follow the manufacturer's instructions for using the adhesive.
7. Apply a 6 mm (1/4 in.) bead of adhesive on top of the existing adhesive.
8. Put a new windowpane into position. Use hand pressure to force windowpane down around the edges until even with metal frame.
9. If windowpane is installed directly on cab, use duct tape to hold it in place while adhesive cures.
10. Allow adhesive to cure for 24 hours before operating machine.

18
1810
1

T52,1810,C19 -19-05JUN98-1/1

Cab Door Hold-Open Release Adjust

1. Remove door striker cover from left rear side of ROPS.
2. Adjust cable length so door release latch releases door when lever is moved 1/3 of full travel distance.
3. Apply PM37418 Thread Lock and Sealer (Medium Strength) to cable eye retaining nut. Cable eye must remain loose.

SJ25320,00004A0 -19-18MAY07-1/1

R134a Refrigerant Cautions



CAUTION: Do not allow liquid refrigerant to contact eyes or skin. Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.

If liquid refrigerant contacts eyes or skin, Do not rub the area. Splash large amounts of COOL water on affected area. Go to a physician or hospital immediately for treatment.

Do not allow refrigerant to contact open flames or very hot surfaces such as electric welding arc, electric heating element and lighted smoking materials.

Do not heat refrigerant over 52°C (125°F) in a closed container. Heated refrigerant will

develop high pressure which can burst the container.

Keep refrigerant containers away from heat sources. Store refrigerant in a cool place.

Do not handle damp refrigerant container with your bare hands. Skin may freeze to container. Wear gloves.

If skin freezes to container, pour COOL water over container to free the skin. Go to a physician or hospital immediately for treatment.

18
1830
3

TX,9031,HH1465 -19-19AUG94-1/1

R134a Compressor Oil Charge Check

Remove compressor if R134a leakage was detected and repaired. See Compressor Remove and Install. (Group 1830.)

Drain oil from the compressor and record the amount. See R134a Compressor Oil Removal. (Group 1830.)

NOTE: Drain oil and save if this is a new compressor.

If the oil drained from a compressor removed from operation is very black or the amount of oil is less than 6 mL (0.2 fl oz), perform the following:

1. Remove and discard the receiver-dryer.
2. Remove, clean, but do not disassemble the flow control hydraulic valve.
3. Flush the complete system with TY16134 air conditioning flushing solvent.
4. If the compressor is serviceable, pour flushing solvent in the manifold ports and internally wash out the old oil.
5. Install the flow control hydraulic valve.
6. Install a new receiver-dryer.
7. Install required amount of TY22025 refrigerant oil in the compressor. See R134a Component Oil Charge. (Group 1830.)
8. Connect all components, evacuate and charge the system.

SJ25320,0000583 -19-18MAY07-1/1

Air Conditioner System Purge

IMPORTANT: Air compressors used for purging systems require a water separator. Purging without a separator adds moisture, creating hydrofluoric acid when combined with refrigerant oil. Acid is corrosive to metal tubing.

1. Connect dry nitrogen hose to gauge manifold center hose.
2. Connect gauge manifold suction hose to compressor suction port. Open valves.
3. Connect gauge manifold discharge hose to compressor discharge post. Open valve. Disconnect discharge hose from gauge manifold to allow purging nitrogen to atmosphere.
4. Open nitrogen tank valve and adjust regulator to 275 kPa (2.75) bar (40 psi). Purge system for two minutes. Disconnect nitrogen supply.
5. Evacuate system. See R134a System Evacuate. (Group 1830.)

18
1830
13

CS33148,0002399 -19-18MAY07-1/1

Heater Control Valve Leak Check

1. Connect water pressure hose to control valve inlet and turn the valve arm to the closed position.
2. Check for leakage from the valve outlet.

NOTE: The heater control valve is not serviceable.

3. Replace heater control valve if required.

TX,1830,MM3165 -19-21MAY07-1/1

18
1830
23

Recirculating Air Filter Remove and Install


NOTE: The cab recirculating air filter is located next to the seat.

1. Turn latch (A) holding grille. Remove grille.
2. Remove filter.



CAUTION: Reduce compressed air to less than 210 kPa (2 bar) (30 psi) when using for cleaning purposes. Clear area of bystanders, guard against flying chips, and wear personal protection equipment, including eye protection.

3. Clean filter in one of these ways:
 - Tap it on a flat surface with the dirty side down.
 - Use compressed air opposite to the normal air flow.
 - Wash the filter in warm, soapy water. Flush the filter and let it dry before using the air conditioner.
4. Install filter.
5. Install grille.



A—Air Filter Latch

T105-695B -UN-12DEC06


18
1830
33

Section 31 Loader

Contents

	Page	Page
Group 3102—Bucket		
Bucket Remove and Install	31-3102-1	
Powerllec™ Pin-On Bucket Remove and Install	31-3102-5	
Welded Bucket Cutting Edges Remove and Install	31-3102-7	
Bolt-On Cutting Edges and Wear Plates Remove and Install	31-3102-8	
Cracked Cutting Edge Repair	31-3102-10	
Group 3140—Frames		
NeverGrease™ Pin Joints	31-3140-1	
Loader Bucket Tilt Linkage Remove and Install	31-3140-4	
Bucket Linkage Seals and Bushings Remove and Install	31-3140-7	
Loader Boom Bushings and Seals Remove and Install	31-3140-9	
Boom Remove and Install	31-3140-11	
Powerllec™ Leveling Link Disassemble and Assemble	31-3140-16	
Powerllec™ Bellcrank Remove and Install	31-3140-20	
Powerllec™ Bucket Cylinder Remove and Install	31-3140-24	
Powerllec™ Bucket Link Disassemble and Assemble	31-3140-30	
Powerllec™ Guide Links Remove and Install	31-3140-36	
Powerllec™ Coupler Disassemble and Assemble	31-3140-40	
Powerllec™ Loader Boom Disassemble and Assemble	31-3140-44	
Hi-Vis Coupler Disassemble and Assemble	31-3140-50	
Group 3160—Hydraulic System		
Hydraulic Oil Cleanup Procedure Using Portable Filter Caddy	31-3160-1	
Hydraulic Pump Remove and Install	31-3160-2	
Hydraulic Pump Disassemble and Assemble	31-3160-5	
Loader Control Valve Remove and Install	31-3160-8	
Loader Control Valve Disassemble and Assemble	31-3160-10	
Auxiliary Valve Section Disassemble and Assemble	31-3160-12	
Bucket Valve Section Disassemble and Assemble	31-3160-13	
Boom Valve Section Disassemble and Assemble	31-3160-14	
Inlet Valve Section Disassemble and Assemble	31-3160-15	
Outlet Valve Section Disassemble and Assemble	31-3160-16	
Circuit Relief Valve Disassemble and Assemble	31-3160-17	
Bucket Circuit Relief Valve Disassemble and Assemble	31-3160-18	
Load Sense Relief Valve Disassemble and Assemble	31-3160-19	
Boom Anticavitation Valve Disassemble and Assemble	31-3160-20	
Boom Cylinder Remove and Install	31-3160-20	
Bucket Cylinder Remove and Install	31-3160-23	
Boom and Bucket Cylinder Repair	31-3160-25	
Boom or Bucket Cylinder Bushings and Seals Remove and Install	31-3160-25	
Loader Start-Up Procedure	31-3160-26	
Hydraulic Reservoir Remove and Install	31-3160-28	
Pilot Control Valve Remove and Install	31-3160-32	
Pilot Control Valve Disassemble and Assemble	31-3160-34	
Boom Down Accumulator Remove and Install	31-3160-39	
Pressure Reducing Valve Manifold Remove and Install	31-3160-41	
Pressure Reducing Valve Manifold Disassemble and Assemble	31-3160-42	
Ride Control Valve Remove and Install	31-3160-45	
Ride Control Valve Disassemble and Assemble	31-3160-48	
Pin Disconnect Valve Remove and Install	31-3160-50	
Pin Disconnect Valve Disassemble and Assemble	31-3160-53	
Fan Drive and Axle Circulation Pump Remove and Install	31-3160-54	

Bucket



T109256

1—Wear Plate (2 used)

2—Cap Screw (8 used)

3—Washer (8 used)

4—Nut (8 used)

CAUTION: Prevent possible injury from crushing. Heavy component, use appropriate lifting device.

1. Remove cap screws (3) and remove cutting edges (2 and 4) from bucket using appropriate lifting device.
2. Remove cap screws (2) and wear plates (1).
3. Install new wear plates and cap screws. Tighten to specification.

4. Install cutting edge in position using appropriate lifting device and install new cap screws. Tighten to specification.


Specification

Cutting Edge-to-Bucket Cap	
Screw—Torque	495 N•m 365 lb-ft
Wear Plates-to-Bucket Cap	
Screw—Torque	300 N•m 225 lb-ft

SJ25320,0000498 -19-18MAY07-2/2

31
3102
9
T109256 -UN-29APR97

Loader Boom Bushings and Seals Remove and Install



T108266

Boom Bushings Seals and Shims (with standard bushings)

A—Bushing (6 used)

B—Seal (12 used)

C—Loader Boom

Boom with Standard Bushing Joint

1. Lower bucket to the ground and remove bucket from boom.

CAUTION: Prevent possible injury from crushing. Heavy component, use appropriate lifting device.

2. Remove bucket cylinder and tilt linkage.

3. Disconnect boom cylinder rod ends from boom.

4. Remove boom pivot pins from machine frame and remove boom.

5. Remove bushings from boom using discs from driver set.

6. Apply PM37566 Silver-Grade Anti-Seize lubricant or an equivalent on outer surface of new bushings and bores. Center new bushings in boom bores and press seals against bushings with lips outward.

7. Install boom on machine and install cylinders, linkage and bucket. Install shims in original locations. Adjust shims as required.

Continued on next page

SJ25320.000048D -19-15JAN08-1/3

Frames

11. Using appropriate lifting device, install Powerllel™ leveling link in position as identified during removal.
12. Install shims in original locations. Measure clearances and adjust shims as required.

Specification

Powerllel™ Leveling	
Link-to-Loader Frame—Clearance	
(maximum).....	3 mm
	0.12 in.
Powerllel™ Leveling	
Link-to-Bellcrank—Clearance	
(maximum).....	3 mm
	0.12 in.

13. Install pins.
14. Install light brackets if removed.

31
3140
19

SJ25320,000048E -19-16MAY07-5/5

Frames

21. Install bellcrank-to-Powerllel™ bucket cylinder pin (11).

SJ25320,0000490 -19-16MAY07-7/7

31
3140
29

Frames

1—Powerlle™ Loader Boom
2—Bushing
3—Bushing

4—Bushing
5—Bushing

6—Seal
7—Seal

8—Seal
9—Seal

- | | |
|---|--|
| <p>19. Remove seals (6—9) from Powerlle™ loader boom.</p> <p>20. Remove bushings (2—5) from Powerlle™ boom using disks from driver set.</p> <p>21. Apply PM37566 Silver-Grade Anti-Seize lubricant or an equivalent on outer surface of new bushings and bores.</p> <p>22. Install Powerlle™ bucket link bushings (2—5) below outer surface of Powerlle™ loader boom using disks from driver set.</p> | <p>23. Install seals (6—9) against bushings (2—5) with lips toward outside of bore.</p> <p>24. Install boom, cylinders, linkage, and bucket. Install shims in original locations. Adjust shims as required.</p> <p>25. Connect return-to-dig wire harness and hydraulic lines.</p> |
|---|--|

Specification

Powerlle™ Bucket Link
Bushing—Distance below outer
face of boom..... 9—11 mm
0.355—0.433 in.

31
3140
49

SJ25320.0000494 -19-21MAY07-77

Hydraulic System

Hydraulic Pump Disassemble and Assemble



1. Perform Hydraulic Pump Remove and Install. (Group 3160.)

Continued on next page

CS33148,000230C -19-18MAY07-1/3

31
3160
5

Inlet Valve Section Disassemble and Assemble



T201852

Inlet Valve Section Disassemble and Assemble

1—System Relief Valve

2—Plug (2 used)

3—Orifice Assembly (2 used)

Item	Measurement	Specification
System Relief Valve	Torque	59—66 N•m 43—49 lb-ft
Plug	Torque	20—27 N•m 177—240 lb-in.
Orifice Assembly	Torque	3.5—4.5 N•m 30—40 lb-in.

31
3160
15

T201852 -UN-26JUL04

Boom and Bucket Cylinder Repair

To repair 120 Series cylinders, See Disassemble Cylinder.
(120 Series Hydraulic Cylinders, TM-H120A, Group 01.)


To repair 125 Series cylinders, See Disassemble Cylinder.
(125 Series Hydraulic Cylinders, TM-H125A, Group 01.)

DW09104,00000C3 -19-20NOV03-1/1

Boom or Bucket Cylinder Bushings and Seals Remove and Install

Boom and Bucket with Standard Bushings

1. Remove seals (B).
2. Remove bushings (A).
3. Install and center new bushings in bore.
4. Install new seals. Press seals into bore tight against bushing with lip facing outward.
5. For initial lubrication, apply NEVER-SEEZ[®] Lubricant or an equivalent to bushings and seals.



Cylinder with Standard Bushings and Seals

A—Bushings
B—Seals

T6172BE -JUN-27OCT88

31
3160
25

Boom and Bucket with NeverGrease[™] Pin Joints

IMPORTANT: Replacement of NeverGrease[™] Pin Joints option requires special methods for replacement of bushings and shims. If not followed the service life may be decreased.

See NeverGrease[™] Pin Joints. (Group 3140.)

1. Remove bushings with hydraulic puller set D01047AA.
2. Install bushings with hydraulic puller. Do not use any lubrication. Make sure alignment is noted. Center bushing in bore.

*NEVER-SEEZ is a trademark of Emhart Chemical Group.
NeverGrease is a trademark of Deere & Company*


TX,31,ME150 -19-11DEC07-1/1

Hydraulic System

NOTE: Parts shown are for reference only.

2. Disassemble and assemble parts as shown. Not all the parts shown are serviceable individually.

- 1—Auxiliary
- 2—Auxiliary
- 3—Boom Lower Valve
- 4—Bucket Lower Valve
- 5—Ride Control Valve
- 6—Ride Control Valve
- 7—Bucket Lift Valve
- 8—Boom Lift Valve



Bottom View of Pilot Control Lever Two Lever with Auxiliary Shown

TX1022235 -UN-17APR07

Continued on next page

CS33148,000230D -19-18MAY07-2/6

31
3160
35

Ride Control Valve Remove and Install




CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

1. Perform Hydraulic System Pressure and Accumulators Discharge. (Group 9025-25.)



Escaping Fluid Under Pressure

X9811 -UN-23AUG88

31
3160
45

Continued on next page

MM61211,0001765 -19-18MAY07-1/3

Hydraulic System

2. Remove the axle circulation pump hydraulic lines (1). Close all openings using caps and plugs.
3. Remove the fan drive pump hydraulic lines (2). Close all openings using caps and plugs.


NOTE: The fan drive and axle circulation pump is removed and installed as a unit.

4. Remove pump retaining cap screws (3).
5. Install pump and pump retaining cap screws and tighten to specification.

Specification

Fan Drive and Axle Circulation Pump Mounting Cap Screw—	
Torque	55 N•m 41 lb-ft

6. Install fan drive pump hydraulic lines.
7. Install axle circulation pump hydraulic lines.



Fan Drive and Axle Circulation Pump

- 1—Axle Circulation Pump Hydraulic Line (4 used)
- 2—Fan Drive Pump Hydraulic Line (2 used)
- 3—Fan Drive and Axle Circulation Pump Retaining Cap Screw (2 used)

TX1021561A -JUN-09APR07

31
3160
55

SJ25320.0000467 -19-27APR07-2/2

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL