

**YAMAHA**

**YZF-R1**

**'98**

**4XV1-AE1**

**SERVICE MANUAL**




CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



EB102000

**IMPORTANT INFORMATION**

**PREPARATION FOR REMOVAL AND DISASSEMBLY**

1. Before removal and disassembly, remove all dirt, mud, dust, and foreign material.
2. Use only the proper tools and cleaning equipment.  
Refer to "SPECIAL TOOLS".
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EB102010

**REPLACEMENT PARTS**

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EB102020

**GASKETS, OIL SEALS AND O-RINGS**

1. When overhauling the engine, replace all gaskets, seals, and O-rings. All gasket surfaces, oil seal lips, and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.



## SPECIFICATIONS

### GENERAL SPECIFICATIONS

Item	Standard	Limit
<b>Dimensions</b>		
Overall length	2,035 mm (except for N, S, SF) 2,095 mm (for N, S, SF)	----
Overall width	695 mm	----
Overall height	1,095 mm	----
Seat height	815 mm	----
Wheelbase	1,395 mm	----
Minimum ground clearance	140 mm	----
Minimum turning radius	3,400 mm	----
<b>Weight</b>		
Wet (with oil and a full fuel tank)	198 kg	----
Dry (without oil and fuel)	177 kg	----
Maximum load (total of cargo, rider, passenger, and accessories)	197 kg	----




## CHASSIS SPECIFICATIONS

Item	Standard	Limit
<b>Frame</b>		
Frame type	Diamond	----
Caster angle	24°	----
Trail	92 mm	----
<b>Front wheel</b>		
Wheel type	Cast wheel	----
Rim		
Size	17 × MT3.50	----
Material	Aluminum	----
Wheel travel	135 mm	----
Wheel runout		
Max. radial wheel runout	----	1 mm
Max. lateral wheel runout	----	0.5 mm
<b>Rear wheel</b>		
Wheel type	Cast wheel	----
Rim		
Size	17 × MT6.00	----
Material	Aluminum	----
Wheel travel	130 mm	----
Wheel runout		
Max. radial wheel runout	----	1 mm
Max. lateral wheel runout	----	0.5 mm
<b>Front tire</b>		
Tire type	Tubeless	----
Size	120/70 ZR17 (58W)	----
Model (manufacturer)	MEZ3 FRONT (METZELER) (for GB) TX15 (MICHELIN) (for N, D, NL, B, E, P, I, GR)	----
Tire pressure (cold)		
0 ~ 90 kg	250 kPa (2.5 kg/cm <sup>2</sup> , 2.5 bar)	----
90 ~ 197 kg	250 kPa (2.5 kg/cm <sup>2</sup> , 2.5 bar)	----
High-speed riding	250 kPa (2.5 kg/cm <sup>2</sup> , 2.5 bar)	----
Min. tire tread depth	----	1.6 mm




Crankcase tightening sequence:






- ① Radiator cap
- ② Thermostat
- ③ Thermostat housing
- ④ Water pump






- J Route the wire harness and turn signal leads under the rear cowling mounting post on the tail/brake light bracket.
- K Insert the tail/brake light coupler and turn signal leads between the tail/brake light and tail/brake light bracket.
- L Position the ground coupler over the oil level relay lead.
- M Fasten the starter relay lead, ground lead, and wire harness with a plastic locking tie.
- N Fasten the battery negative lead and wire

- harness with a plastic locking tie.
- O Route the fuel tank overflow hose and fuel tank breather hose in front of the crankcase breather hose and under the fuel hose and EXUP servomotor.
- P Fasten the sidestand switch lead, engine oil level switch lead, generator lead, and wire harness with a plastic locking tie.



EB302010

FUEL TANK



Order	Job/Part	Q'ty	Remarks
	<b>Removing the fuel tank</b>		Remove the parts in the order listed. Refer to "SEATS".
1	Bolt		
2	Bolt		
3	Fuel sender coupler		Disconnect.
4	Fuel hose		<b>NOTE:</b> _____ Before disconnecting the fuel hose, set the fuel cock to "OFF". _____
5	Fuel tank overflow hose	1	
6	Fuel tank breather hose	1	
7	Fuel tank	1	
8	Fuel tank side panel	2	
			For installation, reverse the removal procedure.



- g. Measure the valve clearance again.
- h. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



- 7. Install:
  - all removed parts

**NOTE:** \_\_\_\_\_  
For installation, reverse the removal procedure. Note the following points.

- 8. Install:
  - timing chain guide (exhaust side)
  - timing chain tensioner
  - pickup coil rotor cover
  - cylinder head cover
  - spark plugsRefer to "CAMSHAFTS" in chapter 4.

EB303010

**SYNCHRONIZING THE CARBURETORS**

**NOTE:** \_\_\_\_\_  
Prior to synchronizing the carburetors, the valve clearance and the engine idling speed should be properly adjusted and the ignition timing should be checked.

- 1. Stand the motorcycle on a level surface.

**NOTE:** \_\_\_\_\_  
Place the motorcycle on a suitable stand.

- 2. Remove:
  - rider seat
  - fuel tank
  - Refer to "SEATS" and "FUEL TANK".

# MEASURING THE COMPRESSION PRESSURE/ CHECKING THE ENGINE OIL LEVEL




Refer to the following table.

Compression pressure (with oil applied into the cylinder)	
Reading	Diagnosis
Higher than without oil	Piston wear or damage → Repair.
Same as without oil	Piston ring(-s), valve(-s), cylinder head gasket or piston possibly defective → Repair.



## 7. Install:

- spark plug

 13 Nm (1.3 m · kg)

EB303070

## CHECKING THE ENGINE OIL LEVEL

- Stand the motorcycle on a level surface.

### NOTE:

- Place the motorcycle on a suitable stand.
- Make sure that the motorcycle is upright.



- Start the engine, let it idle for several minutes, and then stop it.

### 3. Check:

- engine oil level

The engine oil level should be between the minimum level mark (a) and maximum level mark (b).

Below the minimum level mark → Add the recommended engine oil to the proper level.



### Recommended oil

Refer to the chart for the engine oil grade which is best suited for certain atmospheric temperatures.

### API standard


SE or higher grade  
(Non-Friction modified)

3. Start the engine, warm it up for several minutes, and then turn it off.

4. Check:  
• coolant level

**NOTE:**


Before checking the coolant level, wait a few minutes until the coolant has settled.




EB303230

**CHECKING THE COOLING SYSTEM**

1. Remove:
  - bottom cowling
  - side cowlings
 Refer to "COWLINGS".
2. Check:
  - radiator ①
  - radiator inlet hose ②
  - radiator outlet hose ③
  - oil cooler ④
  - oil cooler inlet hose ⑤
  - oil cooler outlet hose ⑥
  - water jacket joint inlet hose ⑦
  - water pump inlet pipe ⑧
  - water pump outlet pipe ⑨
 Cracks/damage → Replace.  
Refer to "COOLING SYSTEM" in chapter 5.
3. Install:
  - side cowlings
  - bottom cowling
 Refer to "COWLINGS".





EB304081

**ADJUSTING THE SHIFT PEDAL**

**NOTE:** \_\_\_\_\_

The shift pedal position is determined by the installed shift rod length **Ⓐ**.

1. Measure:

- installed shift rod length **Ⓐ**  
Incorrect → Adjust.



**Installed shift rod length  
305 mm**

2. Adjust:

- installed shift rod length **Ⓐ**



- Loosen both locknuts **Ⓚ**.
- Turn the shift rod **Ⓐ** in direction **Ⓛ** or **Ⓚ** to obtain the correct shift pedal position.

Direction <b>Ⓛ</b>	Installed shift rod length increases.
Direction <b>Ⓚ</b>	Installed shift rod length decreases.

- Tighten both locknuts.
- Make sure that the installed shift rod length is within specification.



EB304092

**ADJUSTING THE DRIVE CHAIN SLACK**

**NOTE:** \_\_\_\_\_

The drive chain slack must be checked at the tightest point on the chain.

**CAUTION:** \_\_\_\_\_

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.


1. Stand the motorcycle on a level surface.

**⚠ WARNING** \_\_\_\_\_

Securely support the motorcycle so that there is no danger of it falling over.

**NOTE:** \_\_\_\_\_

Place the motorcycle on a suitable stand so that the rear wheel is elevated.



EB304170

## CHECKING THE TIRES

The following procedure applies to both of the tires.

### 1. Measure:

- tire pressure  
Out of specification → Regulate.

### **⚠ WARNING**

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded motorcycle could cause tire damage, an accident or an injury.

**NEVER OVERLOAD THE MOTORCYCLE.**


Basic weight (with oil and a full fuel tank)	198 kg	
Maximum load*	197 kg	
Cold tire pressure	Front	Rear
Up to 90 kg load*	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar)	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar)
90 kg ~ max- imum load*	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar)	290 kPa (2.9 kgf/cm <sup>2</sup> , 2.9 bar)
High-speed riding	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar)	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar)

\* total of cargo, rider, passenger and accessories

### **⚠ WARNING**

**It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.**






Order	Job/Part	Q'ty	Remarks
3	Clutch cable	1	
4	Crankcase breather hose	1	
5	Starter motor lead	1	Disconnect.
6	Ground lead	1	Disconnect.
7	Starter motor	1	
8	Stator coil assembly coupler	1	Disconnect.
9	Pickup coil coupler	1	Disconnect.
10	Oil level switch connector	1	Disconnect.
11	Neutral switch	1	
12	Speed sensor	1	
			For connecting, reverse the disconnection procedure.








PICKUP COIL



Order	Job/Part	Q'ty	Remarks
	<b>Removing the pickup coil and pickup coil rotor</b>		Remove the parts in the order listed.
	Rider seat and fuel tank		Refer to "SEATS" and "FUEL TANK" in chapter 3.
	Bottom cowling and right side cowling		Refer to "COWLINGS" in chapter 3.
	Engine oil		Drain. Refer to "CHANGING THE ENGINE OIL" in chapter 3.
	Generator rotor cover		Refer to "GENERATOR".
1	Clutch cable	1	
2	Clutch cable holder	1	
3	Pickup coil lead holder	1	
4	Pickup coil rotor cover	1	
5	Pickup coil rotor cover gasket	1	
6	Dowel pin	2	




EB405450

**CHECKING THE CLUTCH BOSS**

1. Check:
  - clutch boss splines  
Damage/pitting/wear → Replace the clutch boss.

**NOTE:**


Pitting on the clutch boss splines will cause erratic clutch operation.



EB405460

**CHECKING THE PRESSURE PLATE**


1. Check:
  - pressure plate ①  
Cracks/damage → Replace.
  - bearing ②  
Damage/wear → Replace.




EB405470

**CHECKING THE PULL LEVER SHAFT AND PULL ROD**

1. Check:
  - pull lever shaft pinion gear teeth ①
  - pull rod teeth ②  
Damage/wear → Replace the pull rod and pull lever shaft as a set.
2. Check:
  - pull rod bearing  
Damage/wear → Replace.


**CHECKING THE STARTER CLUTCH**

1. Check:
  - starter clutch gear
  - starter clutch idle gear  
Chips/pitting/roughness/wear → Replace the defective part(-s).



### 3. Check:

- oil pump operation  
Unsmooth → Repair or replace the defective part(-s).  
Refer to "WATER PUMP" in chapter 5.




EB411410

### CHECKING THE RELIEF VALVE

#### 1. Check:

- relief valve body ①
  - relief valve ②
  - spring ③
  - O-ring ④
- Damage/wear → Replace the defective part(-s).




EB411421

### CHECKING THE OIL DELIVERY PIPE AND OIL PIPE

#### 1. Check:

- oil delivery pipe ①
  - oil pipe ②
- Damage → Replace.  
Obstruction → Wash and blow out with compressed air.



EB411430

### CHECKING THE OIL STRAINER

#### 1. Check:

- oil strainer ①
- Damage → Replace.  
Contaminants → Clean with engine oil.

EB411701

### ASSEMBLING THE OIL PUMP

#### 1. Lubricate:

- inner rotor
- outer rotor
- impeller shaft  
(with the recommended lubricant)




CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



EB412131

## REMOVING THE CONNECTING RODS AND PISTONS


The following procedure applies to all of the connecting rods and pistons.

### 1. Remove:

- connecting rod cap ①
- big end bearings

### NOTE:

Identify the position of each big end bearing so that it can be reinstalled in its original place.



### 2. Remove:


- piston pin clips ①
- piston pin ②
- piston ③
- connecting rod ④

### CAUTION:

Do not use a hammer to drive the piston pin out.

### NOTE:

- For reference during installation, put identification marks on the piston crown.
- Before removing the piston pin, deburr the piston pin clip groove and the piston pin bore area in the piston. If both areas are deburred and the piston pin is still difficult to remove, remove it with the piston pin puller ④.




**Piston pin puller**  
90890-01304


### 3. Remove:

- top ring
- 2nd ring
- oil ring

### NOTE:

To remove a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.






EB412110

**REMOVING THE CRANKSHAFT**

1. Remove:
  - crankshaft ①
  - crankshaft journal upper bearings (from the upper crankcase)

**NOTE:** \_\_\_\_\_  
 Identify the position of each crankshaft journal upper bearing so that it can be reinstalled in its original place.



EB412403

**CHECKING THE CRANKSHAFT**

1. Measure:
  - crankshaft runout
 Out of specification → Replace the crankshaft.

	<p><b>Max. crankshaft runout</b>  <b>0.03 mm</b></p>
--	--

2. Check:
  - crankshaft journal surfaces
  - crankshaft pin surfaces
  - bearing surfaces
 Scratches/wear → Replace the crankshaft.






**CHECKING THE CRANKSHAFT JOURNAL BEARINGS**

1. Measure:
  - crankshaft-journal-to-crankshaft-journal-bearing clearance
 Out of specification → Replace the crankshaft journal bearings.

	<p><b>Crankshaft-journal-to-crankshaft-journal-bearing clearance</b>  <b>0.004 ~ 0.028 mm</b></p>
--	---



**CAUTION:** \_\_\_\_\_  
 Do not interchange the crankshaft journal bearings. To obtain the correct crankshaft-journal-to-crankshaft-journal-bearing clearance and prevent engine damage, the crankshaft journal bearings must be installed in their original positions.



EB413100

**REMOVING THE TRANSMISSION**

1. Remove:

- main axle assembly ①  
(with the Torx® wrench T30)



- Insert two bolts ② of the proper size, as shown in the illustration, into the main axle assembly bearing housing.
- Tighten the bolts until they contact the crankcase surface.
- Continue tightening the bolts until the main axle assembly comes free from the upper crankcase.



EB413400

**CHECKING THE SHIFT FORKS**

The following procedure applies to all of the shift forks.

1. Check:

- shift fork cam follower ①
- shift fork pawl ②  
Bends/damage/scoring/wear →  
Replace the shift fork.

2. Check:

- shift fork guide bar  
Roll the shift fork guide bar on a flat surface.  
Bends → Replace.

**⚠ WARNING**

**Do not attempt to straighten a bent shift fork guide bar.**



EB500020

**INSTALLING THE RADIATOR**

## 1. Fill:


- cooling system  
(with the specified amount of the recommended coolant)  
Refer to "CHANGING THE COOLANT" in chapter 3.

## 2. Check:


- cooling system  
Leaks → Repair or replace any faulty part.

## 3. Measure:

- radiator cap opening pressure  
Below the specified pressure →  
Replace the radiator cap.  
Refer to "CHECKING THE RADIATOR".



Order	Job/Part	Q'ty	Remarks
5	Water pump seal	1	For installation, reverse the removal procedure.
6	Oil seal	1	
7	Bearing	1	



Order	Job/Part	Q'ty	Remarks
14	Fuel feed pipe	1	$l = 37 \text{ mm}$
15	Fuel feed pipe	1	$l = 32 \text{ mm}$
16	Fuel feed pipe	1	$l = 29 \text{ mm}$
17	Pipe	1	$l = 73 \text{ mm}$
18	Pipe	1	$l = 68 \text{ mm}$
19	Pipe	1	$l = 66 \text{ mm}$
20	Throttle stop screw	1	
21	Throttle position sensor	1	
22	Throttle position sensor bracket	1	
23	Carburetor	4	
			For installation, reverse the removal procedure.




2. Check:

- throttle position sensor (removed from the carburetor)



- Disconnect the throttle position sensor coupler.
- Remove the throttle position sensor from the carburetor.
- Connect the pocket tester ( $\Omega \times 1k$ ) to the throttle position sensor.



Tester positive probe → blue ①  
 Tester negative probe → black/blue ②

- Measure the throttle position sensor maximum resistance.  
 Out of specification → Replace the throttle position sensor.

**Throttle position sensor maximum resistance**  
 4.0 ~ 6.0 k $\Omega$  at 20 °C  
 (blue — black/blue)

- Connect the pocket tester ( $\Omega \times 1k$ ) to the throttle position sensor coupler.

Tester positive probe → yellow ③  
 Tester negative probe → black/blue ②

- While slowly opening the throttle, check that the throttle position sensor resistance is within the specified range.

The resistance does not change or it changes abruptly → Replace the throttle position sensor.

The slot is worn or broken → Replace the throttle position sensor.

**NOTE:**


Check mainly that the resistance changes gradually when turning the throttle, since the readings (from closed to wide-open throttle) may differ slightly from those specified.

**Throttle position sensor resistance**  
 0 ~ 5 ± 1.0 k $\Omega$  at 20 °C  
 (yellow — black/blue)










Order	Job/Part	Q'ty	Remarks
13	Brake hose	2	
14	Brake master cylinder holder	1	
15	Brake master cylinder	1	
16	Front brake switch	1	
			For installation, reverse the removal procedure.


EB702303




Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the front brake calipers</b>		Remove the parts in the order listed.
			The following procedure applies to both of the front brake calipers.
①	Brake pad clip	2	
②	Brake pad pin	1	
③	Brake pad spring	1	
④	Brake pad	2	
⑤	Brake caliper piston	4	
⑥	Brake caliper piston seal	8	
⑦	Bleed screw	1	
			For assembly, reverse the disassembly procedure.

EB703001



**FRONT FORK**




Order	Job/Part	Q'ty	Remarks
	<b>Removing the front fork legs</b>		Remove the parts in the order listed. The following procedure applies to both of the front fork legs.
	Front wheel		Refer to "FRONT WHEEL AND BRAKE DISCS".
	Front cowling inner panels		Refer to "COWLINGS" in chapter 3.
1	Front fender	1	
2	Upper bracket pinch bolt	1	
3	Cap bolt	1	
4	Handlebar pinch bolt	1	
5	Lower bracket pinch bolt	2	
6	Front fork leg	1	
			For installation, reverse the removal procedure.



12311702



c. Install the rod puller and adapter onto the damper rod.

	<b>Rod puller</b> 90890-01437 <b>Adapter</b> 90890-01436
---	---


d. Install the fork spring, spring seat, and spacer.

**NOTE:** Install the spring with the smaller pitch  $\text{\textcircled{a}}$  facing up  $\text{\textcircled{A}}$ .

e. Press down on the spacer with the fork spring compressor  $\text{\textcircled{7}}$ .


f. Pull up the rod puller and install the rod holder  $\text{\textcircled{8}}$  between the nut  $\text{\textcircled{1}}$  and the spacer  $\text{\textcircled{4}}$ .

**NOTE:** Use the side of the rod holder that is marked "B".

	<b>Fork spring compressor</b> 90890-01441 <b>Rod holder</b> 90890-01434
---	--


g. Remove the rod puller and adapter.

h. Install the nut  $\text{\textcircled{1}}$  and position it as specified  $\text{\textcircled{b}}$ .

	<b>Distance <math>\text{\textcircled{b}}</math></b> 11 mm
---	--

i. Install the damper adjusting rod and cap bolt, and then finger tighten the cap bolt.

j. Hold the cap bolt and tighten the nut to specification.


	<b>Nut</b> 15 Nm (1.5 m • kg)
---	----------------------------------

k. Remove the rod holder and fork spring compressor.

**⚠ WARNING**

- The fork spring is compressed.
- Always use a new cap bolt O-ring.





- b. Remove the bearing race from the lower bracket with a floor chisel ② and hammer.
- c. Install a new dust seal and new bearing races.

**CAUTION:**

If the bearing race is not installed properly, the steering head pipe could be damaged.

**NOTE:**

- Always replace the bearing balls and bearing races as a set.
- Whenever the steering head is disassembled, replace the dust seal.





- 4. Check:
  - upper bracket
  - lower bracket (along with the steering stem)
  - Bends/cracks/damage → Replace.

EB705700

**INSTALLING THE STEERING HEAD**

- 1. Lubricate:
  - upper bearing
  - lower bearing
  - bearing races



	<p><b>Recommended lubricant</b> Lithium soap base grease</p>
---	--



- 2. Install:
  - lower ring nut ①
  - rubber washer ②
  - upper ring nut ③
  - lock washer ④

Refer to "CHECKING AND ADJUSTING THE STEERING HEAD" in chapter 3.





EB801000

## SWITCHES

### CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

#### CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester  
90890-03112

#### NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.


The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.

#### NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between blue/red and red when the switch is set to "P $\leq$ ". There is continuity between blue/red and blue, between brown/blue and red, and between blue/yellow and blue/black when the switch is set to "ON".



EB802415

**12. Relay unit**

- Remove the relay unit from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$ ) to the relay unit terminals as shown.
- Check the starting circuit cutoff relay for continuity.

Tester positive probe → sky blue ①	Continuity
Tester negative probe → blue/yellow ②	
Tester positive probe → blue/yellow ②	No continuity
Tester negative probe → sky blue ①	

**NOTE:**  
When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the tester readings correct?

↓ YES

↓ NO

Replace the relay unit.

EB802416

**13. Wiring**

- Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?

↓ NO


↓ YES

Properly connect or repair the ignition system's wiring.

Replace the ignitor unit.

# STARTER MOTOR

**ELEC**




18210401

5. Measure:
  - brush length **a**
 Out of specification → Replace the brushes as a set.



**Min. brush length**  
**5 mm**




18210602

6. Measure:
  - brush spring force
 Out of specification → Replace the brush springs as a set.



**Brush spring force**  
**7.03 ~ 10.63 N (717 ~ 1,084 gf)**

7. Check:
  - gear teeth
 Damage/wear → Replace the gear.
8. Check:
  - bearing
  - oil seal
 Damage/wear → Replace the defective part(-s).




EB803701

## ASSEMBLING THE STARTER MOTOR

1. Install:
  - brush seat **1**

**NOTE:**

Align the tab **a** on the brush seat with the slot **b** in the starter motor rear cover.




2. Install:
  - starter motor yoke **1**
  - O-rings **2** **New**
  - starter motor front cover **3**
  - starter motor rear cover **4**
  - bolts

**5 Nm (0.5 m · kg)**

**NOTE:**


Align the match marks **a** on the starter motor yoke with the match marks **b** on the front and rear covers.



EB806000

# SIGNALING SYSTEM

## CIRCUIT DIAGRAM



# COOLING SYSTEM

**ELEC**



EB807010

## TROUBLESHOOTING

- The radiator fan motor fails to turn.
- The coolant temperature meter needle fails to move when the engine is warm.

Check:

1. main, signal system, and radiator fan motor fuses
2. battery
3. main switch
4. radiator fan motor
5. thermo switch
6. temperature sender
7. wiring (the entire cooling system)

**NOTE:**

- Before troubleshooting, remove the following part(-s):
  - 1) rider seat
  - 2) bottom cowling
  - 3) front cowling inner panels
  - 4) left side cowling
  - 5) windshield
- Troubleshoot with the following special tool(-s).



**Pocket tester**  
90890-03112

EB802400

### 1. Main, signal system and radiator fan motor fuses

- Check the main, signal system, and radiator fan motor fuses for continuity. Refer to "CHECKING THE FUSES" in chapter 3.
- Are the main, signal system, and radiator fan motor fuses OK?

YES

NO

Replace the fuse(-s).

EB802401

### 2. Battery

- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



**Open-circuit voltage**  
12.8 V or more at 20 °C

• Is the battery OK?

YES

NO

- Clean the battery terminals.
- Recharge or replace the battery.

EB802411

### 3. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

YES

NO


Replace the main switch.

EB807400

### 4. Radiator fan motor (test 1)

- Disconnect the radiator fan motor coupler from the wire harness.
- Connect the battery (12 V) as shown.

**Battery positive lead → blue ①**  
**Battery negative lead → black ②**



• Does the radiator fan motor turn?

YES

NO

The radiator fan motor is faulty and must be replaced.




EB811402

3. EXUP servomotor operation (with the servomotor coupler disconnected from the wire harness)

- Disconnect the EXUP cables from the EXUP servomotor pulley.
- Disconnect the EXUP servomotor coupler from the wire harness.
- Connect the battery leads to the EXUP servomotor coupler (servomotor side) as shown.

Battery positive terminal → black/yellow ①  
 Battery negative terminal → black/red ②



- Check that the EXUP servomotor pulley rotates several times.

**CAUTION:**

To prevent damaging the EXUP servomotor, perform this test within a few seconds of connecting the battery.

- Does the EXUP servomotor pulley turn?




Replace the EXUP servomotor.

EB811403

4. EXUP servomotor resistance

- Disconnect the EXUP servomotor coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1k$ ) to the EXUP servomotor coupler.

Tester positive probe → white/black ①  
 Tester negative probe → yellow/blue ②




- Measure the EXUP servomotor resistance.



EXUP servomotor resistance  
 5.3 ~ 9.8 k $\Omega$   
 (between white/black and yellow/blue)

- Connect the pocket tester ( $\Omega \times 1k$ ) to the EXUP servomotor coupler.

Tester positive probe → white/black ①  
 Tester negative probe → white/red ③



- While slowly turning the EXUP servomotor pulley by hand, measure the EXUP servomotor resistance.



EXUP servomotor resistance  
 (when the pulley is turned one full rotation)  
 0 ~ approximately 7.5 k $\Omega$   
 (between white/black and white/red)

- Is the EXUP servomotor OK?



The EXUP servomotor is faulty and must be replaced.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL