


1984 - 1986

M.R.252

8981 320 374 U.S.A./Canada Edition



Includes I.S. Notes
1E - 9E



Jeep[®]

CJ-7/Scrambler

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



GENERAL



TOWING – BREAKDOWN RECOVERY

TOWING PROCEDURES

Safety Precautions

- secure loose or protruding parts of a damaged vehicle
- the end of the vehicle being towed should be lifted a minimum of 100 mm (4 in) off the ground; check the opposite end for adequate ground clearance
- always use a safety chain system that is independent of the lifting and towing attachment
- do not allow any of the towing equipment to bear on the fuel tank
- do not go under the vehicle while it is lifted by the towing equipment
- do not allow passengers to ride in a towed vehicle
- always observe all state and local laws regarding such items as warning signals, night illumination, speed, etc.
- do not attempt a towing operation that could jeopardize the operator, any bystanders or other motorists

CAUTION: To prevent driveline damage, shift the transmission and transfer case into the positions outlined in the general towing instructions.


Front Towing – Front End Raised

Attach J-hooks over the axle outboard of the springs.

Tow hooks or chains must not be attached to the bumper or to the constant velocity (CV) joints.


Place a tow bar under the spring shackles.

Attach safety chains around the spring shackles.



86368

SEE
I.S.
N
O
T
E
S



ENGINES




GENERAL INFORMATION

SPECIAL TOOLS

SEE
I.S.
N
O
T
E
S

| Tool Ref. | Description | Required | Recommended |
|------------|--|----------|-------------|
| J-22248 | Timing Case Cover Alignment and Seal Installation Tool | ■ | |
| J-21882 | Oil Pump Inlet Tube Installation Tool | ■ | |
| J-22534-01 | Valve Spring Removal and Installation Tool | ■ | |
| J-22534-04 | | ■ | |
| J-22534-05 | | ■ | |
| J-9256 | Timing Case Cover Oil Seal Removal Tool | | ■ |
| J-22794 | Air Hose Adapter | | ■ |
| J-21884 | Hydraulic Valve Tappet Removal and Installation Tool | | ■ |
| J-8520 | Dial Indicator Set | | ■ |
| J-21791 | Vibration Damper Removal Tool | | ■ |
| J-5959-04 | C-Clamp and Rod Extension | | ■ |
| J-9163 | Screw (used with J-22248) | | ■ |
| J-5601 | Piston Ring Compressor | | ■ |
| J-23600 | Belt Tension Gauge | | ■ |
| J-23600-B | Belt Tension Gauge | | ■ |
| J-29550 | Belt Tension Gauge | | ■ |
| J-24460-01 | Cooling System Pressure Tester and Adapter | | ■ |
| J-9789-C | Universal Carburetor Gauge Kit | | ■ |
| J-10174-01 | Main Jet Removal and Installation Tool | | ■ |
| J-23738 | Hand Operated Vacuum Pump | | ■ |
| ET-501-82 | Fuel Feedback System Tester | ■ | |
| ET-501-84 | Fuel Feedback System Tester Adapter | ■ | |
| | Tach/Dwell Meter | | ■ |



ENGINES




GENERAL SERVICE AND DIAGNOSIS

Service Diagnosis – Performance (Continued)


| Condition | Possible Cause | Correction |
|---|---|--|
| FAULTY HIGH SPEED OPERATION (Continued) | (16) Intake manifold restricted. (17) Worn distributor shaft. (18) Improper feedback system operation. | (16) Remove restriction or replace manifold. (17) Replace shaft. (18) Refer to Feedback System Diagnosis. |
| MISFIRE AT ALL SPEEDS | (1) Faulty spark plug(s). (2) Faulty spark plug wire(s). (3) Faulty distributor cap or rotor. (4) Faulty ignition coil. (5) Primary ignition circuit shorted or open intermittently. (6) Improperly seated valve(s). (7) Faulty hydraulic tappet(s). (8) Improper feedback system operation. (9) Faulty valve spring(s). (10) Worn camshaft lobes. (11) Air leak into manifold. (12) Improper carburetor adjustment. (13) Fuel pump volume or pressure low. (14) Blown cylinder head gasket. (15) Intake or exhaust manifold passage(s) restricted. (16) Incorrect trigger wheel installed in distributor. | (1) Clean or replace spark plug(s). (2) Replace as necessary. (3) Replace cap or rotor. (4) Test coil and replace as necessary. (5) Troubleshoot primary circuit and repair as necessary. (6) Test cylinder compression, repair as necessary. (7) Clean or replace tappet(s). (8) Refer to Feedback System Diagnosis. (9) Inspect and test valve spring tension, repair as necessary. (10) Replace camshaft. (11) Check manifold vacuum and repair as necessary. (12) Adjust carburetor. (13) Replace fuel pump. (14) Replace gasket. (15) Pass chain through passage(s) and repair as necessary. (16) Install correct trigger wheel. |
| POWER NOT UP TO NORMAL | (1) Incorrect ignition timing. (2) Faulty distributor rotor. (3) Trigger wheel loose on shaft. (4) Incorrect spark plug gap. (5) Faulty fuel pump. | (1) Adjust timing. (2) Replace rotor. (3) Reposition or replace trigger wheel. (4) Adjust gap. (5) Replace fuel pump. |

SEE I.S. NOTES





ENGINES


TUNE-UP PROCEDURES



SEE
I.S.
N
O
T
E
S




840115



ENGINES

TUNE-UP PROCEDURES



SEE
I.S.
N
O
T
E
S

Idle Speed Adjustment – Six-Cylinder Engine

WARNING: Use extreme caution when the engine is operating. Do not stand in a direct line with the fan. Do not put your hands near the pulleys, belts or fan. Do not wear loose clothing.

Connect a calibrated, expanded scale tachometer to the ignition coil negative (TACH) terminal.

Start and allow the engine to attain normal operating temperature.

The carburetor choke and intake manifold heater must be off. This occurs when the engine coolant heats to approximately 71°C (160°F).

NOTE: When adjusting the idle speed, place manual transmissions in the neutral position and automatic transmissions in DRIVE. Turn all accessories off.

WARNING: Set the parking brake firmly. Do not accelerate the engine.

Disconnect and plug the vacuum hose connected to the Sole-Vac vacuum actuator. Disconnect the holding solenoid wire connector.

Adjust the carburetor curb (slow) idle speed adjustment screw to obtain the specified curb (slow) idle speed rpm, if not within specifications. Refer to the Specifications chart and the Vehicle Emission Control Information label located under the hood.

Apply a direct source of vacuum to the vacuum actuator. Use Vacuum Pump Tool J-23738, or equivalent.

When the throttle positioner is fully extended, turn the vacuum actuator adjustment screw on the throttle lever until the specified engine rpm is obtained.

Disconnect the vacuum source from the vacuum actuator.

If equipped, turn the air conditioner ON.

With a jumper wire, apply voltage (12V) to energize the holding solenoid. Hold the throttle open manually to allow the throttle positioner to fully extend.

NOTE: Without the vacuum actuator, the throttle must be opened manually to allow the Sole-Vac throttle positioner to fully extend.

If the holding solenoid idle speed is not within specification, adjust the Sole-Vac (hex-head adjustment screw) to obtain the specified engine rpm. Refer to the Specifications chart and the Vehicle Emission Control Information label located under the hood.

Remove the jumper wire from the Sole-Vac holding solenoid wire connector.

Connect the Sole-Vac holding solenoid wire connector.


Connect the original hose to the vacuum actuator.

Remove the tachometer.



ENGINES

2.46 LITER (150 CID) FOUR-CYLINDER ENGINE



SHORT ENGINE ASSEMBLY (SHORT BLOCK)

A service replacement short engine assembly (short block) may be installed whenever the original cylinder block is defective or damaged beyond repair. It consists of the cylinder block, piston and rod assemblies and crankshaft.

NOTE: The camshaft must be procured separately and installed before the engine is installed in the vehicle.

NOTE: For identification, short engine assemblies have the letter S stamped on the same machined surface where the build date code is stamped for complete engine assemblies.

Installation includes the transfer of components from the defective or damaged original engine.

Follow the appropriate procedures for cleaning, inspection and torque tightening as outlined in this chapter.

ENGINE MOUNTING

Resilient rubber cushions support the engine and transmission at three points: at each side on the centerline of the engine and at the rear between the transmission extension housing and the rear support crossmember.


Replacement of a cushion may be accomplished by supporting the weight of the engine or transmission at the area of the cushion.

SEE
I.S.
N
O
T
E
S



ENGINES

2.46 LITER (150 CID) FOUR-CYLINDER ENGINE



Remove the bridge and pivot assembly and rocker arms from above the No. 1 cylinder.

Rotate the crankshaft until No. 4 piston is at top dead center (TDC) on the compression stroke.

Rotate the crankshaft counterclockwise (viewed from the front of the engine) 90 degrees.

Install Dial Indicator Set J-8520 (or equivalent) on the end of the No. 1 cylinder intake valve push rod. Use rubber tubing to secure the stem on the push rod.

Set the dial indicator pointer at zero.

Rotate the crankshaft clockwise (viewed from the front of the engine) until the dial indicator pointer indicates 0.305-mm (0.012-in) travel distance (lift).

The timing notch index on the vibration damper should be aligned with the TDC mark on the timing degree scale.

If the timing notch is more than 13 mm (1/2 in) away from the TDC mark in either direction, the valve timing is incorrect.

If the valve timing is incorrect, the cause may be a broken camshaft pin. It is not necessary to replace the camshaft because of pin failure. A spring pin is available for service replacement.

VIBRATION DAMPER AND PULLEY


Removal

Remove the drive belt(s).

Remove the retaining bolts and separate the vibration damper pulley from the vibration damper.

Remove the vibration damper retaining bolt and washer.


Use Vibration Damper Removal Tool J-21791-01 to remove the damper from the crankshaft.



J-21791-01


84179

SEE
I.S.
N
O
T
E
S



ENGINES

2.46 LITER (150 CID) FOUR-CYLINDER ENGINE



Installation


Lubricate the camshaft with AMC Engine Oil Supplement (EOS), or equivalent.

Install the camshaft carefully to prevent damaging the camshaft bearings.

Turn the tensioner lever (1) to the unlocked (down) position.


Pull the tensioner block (2) toward the tensioner lever to compress the spring. Hold the block and turn the tensioner lever to the locked (up) position.

SEE
I.S.
N
O
T
E
S




84186

Install the timing chain, crankshaft sprocket and camshaft sprocket with the timing marks (A) aligned.




84184

NOTE: To verify correct installation of the timing chain, turn the crankshaft to position the camshaft sprocket timing mark at approximately the one o'clock position. This positions the crankshaft sprocket timing mark where the adjacent tooth meshes with the chain at the three o'clock position. Count the number of chain pins between the timing marks on both sprockets. There must be 20 pins.




84187



ENGINES

2.46 LITER (150 CID) FOUR-CYLINDER ENGINE



Installation

NOTE: To ensure self-priming of the oil pump, fill the pump with petroleum jelly before installing the oil pump cover. Do not use grease.

Apply a bead of Loctite 515 sealant, or equivalent, and install the pump cover. Tighten the cover screws with 8 N·m (70 in-lbs) torque.

NOTE: Rotate the gears to ensure that a binding condition does not exist before installing the oil pump.

Install the oil pump (2) with a replacement gasket (3). Tighten the short screw with 14 N·m (10 ft-lbs) torque and long screw with 23 N·m (17 ft-lbs) torque.

Install the oil pan with replacement gaskets and seals. Refer to Oil Pan Installation.

Fill the oil pan with replacement engine oil to the specified level.

Oil Pump Overhaul

Refer to the MOT. 2.46L manual for the oil pump overhaul procedure.

Oil Pressure Gauge

Refer to Chapter C – Electrical for operation, diagnosis and replacement of the oil pressure gauge.


PISTONS AND CONNECTING RODS

Replacement as an Assembly

NOTE: The following procedure is used to service the piston and connecting rod assemblies with the engine installed in the vehicle.


Removal

Remove the cylinder head cover. Refer to Cylinder Head Cover Removal for the procedure.




SEE
I.S.
NOTES

84103



ENGINES



4.2 LITER (258 CID) SIX-CYLINDER ENGINE


GENERAL

SEE
I.S.
N
O
T
E
S

Description


| Vehicle | Engine | Displacement | Bore mm (in) | Stroke mm (in) | Comp. Ratio | Carburetor | Oil Capacity |
|----------|------------|-----------------|--------------------|----------------------|----------------|------------|--|
| 87 88 | 6-cylinder | 4.2L 258 CID | 95.25 (3.75) | 98.93 (3.895) | 9.2:1 | 2-Venturi | 4.75L 5.0 qts. 4.1 imp qts. (w/o filter change) |

86348(J)



ENGINES

4.2 LITER (258 CID) SIX-CYLINDER ENGINE



SHORT ENGINE ASSEMBLY (SHORT BLOCK)

A service replacement short engine assembly (short block) may be installed whenever the original cylinder block is defective or damaged beyond repair.

It consists of a cylinder block, piston and rod assemblies and crankshaft.

NOTE: The camshaft must be procured separately and installed before the engine is installed in the vehicle.


NOTE: For identification, short engine assemblies have the letter S stamped on the same machined surface where the build date code is stamped for complete engine assemblies.

Installation includes the transfer of components from the defective or damaged original engine.

Follow the appropriate procedures for cleaning, inspection and torque tightening as outlined in this manual and the MOT, 4.2L manual.

ENGINE MOUNTING

Resilient rubber cushions support the engine and transmission at three points: at each side on the centerline of the engine (1 and 2) and at the rear between the transmission adapter housing and the rear support crossmember.




- 1 - Frame Support
- 2 - Cushions
- 3 - Engine Mounting Brackets

42578

Replacement of a cushion may be accomplished by supporting the weight of the engine or transmission at the area of the cushion.


CAUTION: Before raising the engine, remove the screws that attach the fan shroud to the radiator to prevent damage to the shroud by the fan.

SEE
I.S.
NOTES




ENGINES

4.2 LITER (258 CID) SIX-CYLINDER ENGINE



Install a dial indicator (1) with a piece of rubber tubing (2) between the dial indicator plunger and the push rod (3).

SEE
I.S.
NOTES



Rotate the crankshaft until the heel of the cam lobe (push rod in the down position) is under the valve tappet. Set the dial indicator pointer at zero.

Rotate the crankshaft until the push rod is at its maximum upward position. Note the travel distance on the dial indicator. Refer to the Specifications chart for the correct cam lobe lift.

Repeat the procedure for each cam lobe.

Valve Timing

Disconnect the spark plug wires and remove the spark plugs.

Remove the cylinder head cover. Refer to Cylinder Head Cover Removal for the procedure.

Remove the capscrews, bridge and pivot assembly, and rocker arms from above the No. 1 cylinder.

Alternately loosen each capscrew, one turn at a time, to avoid damaging the bridge.

Rotate the crankshaft until the No. 6 piston is at top dead center (TDC) on the compression stroke.

Rotate the crankshaft counterclockwise (viewed from the front of the engine) 90 degrees.

Install a dial indicator (J-8520 or equivalent) on the end of the No. 1 cylinder intake valve push rod. Use rubber tubing to secure the indicator stem on the push rod.


Set the dial indicator pointer at zero.

Rotate the crankshaft clockwise (viewed from the front of the engine) until the dial indicator pointer indicates 0.305-mm (0.012-in) travel distance (lift).


The timing notch index on the vibration damper should be aligned with the TDC mark on the timing degree scale.

If the timing notch is more than 13 mm (1/2 in) away from the TDC mark in either direction, the valve timing is incorrect.

If the valve timing is incorrect, the cause may be a broken camshaft pin. It is not necessary to replace the camshaft because of pin failure. A spring pin is available for service replacement.



ENGINES



4.2 LITER (258 CID) SIX-CYLINDER ENGINE

Remove the fan and shroud.

Disconnect the radiator overflow tube (or coolant recovery bottle tube), radiator hoses and automatic transmission fluid cooler pipes (if equipped).

Remove the radiator.

If equipped with air conditioning:

- remove the A/C compressor drive belt idler pulley
- disconnect and remove the alternator

CAUTION: Do not loosen or disconnect any air conditioner system fittings. Move the condenser and receiver/drier aside as a complete assembly.


- remove the A/C condenser attaching bolts and move the condenser and receiver/drier assembly up and out of the way

Remove the drive belt(s).

Remove the crankshaft vibration damper and pulley (V-belt drive only). Refer to the removal procedure.

Remove the timing case cover. Refer to the removal procedure.

Rotate the crankshaft until the zero degree (0°) timing mark on the crankshaft sprocket is closest to and on the center line with the timing mark on the camshaft sprocket (1).




86210

Remove camshaft sprocket retaining bolt.


Remove the crankshaft oil slinger.

Remove the sprockets and chain as an assembly.




86177

SE
I.S
N
O
T
E
S



ENGINES



4.2 LITER (258 CID) SIX-CYLINDER ENGINE

Installation

NOTE: To ensure self-priming of the oil pump, fill the pump with petroleum jelly before installing the oil pump cover. Do not use grease.

SEE
I.S.
NOTES

Install the oil pump with a replacement gasket. Tighten the short screws with 14 N·m (10 ft-lbs) torque and the long screws with 23 N·m (17 ft-lbs) torque.

NOTE: Rotate the gears to ensure that a binding condition does not exist before installing the oil pump.

Install the oil pan with replacement gaskets and seals. Refer to Oil Pan Installation for the procedure. Fill the oil pan with replacement engine oil to the specified level.

Oil Pump Overhaul

Refer to the MOT. 4.2L manual for the oil pump overhaul procedure.

Oil Pressure Gauge

Refer to Chapter C – Electrical for operation, diagnosis and replacement of the oil pressure gauge.

PISTONS AND CONNECTING RODS

Replacement As An Assembly


NOTE: The following procedure is for servicing the piston and connecting rod assemblies with the engine installed.


Removal

Remove the cylinder head cover. Refer to Cylinder Head Cover Removal for the procedure.

Remove the capscrews (1), bridge (2) and pivot (3) assemblies and rocker arms (4). Alternately loosen the capscrews, one turn at a time, to avoid damaging the bridge.


Remove the push rods (5).






ENGINES


COOLING SYSTEMS




ENGINE DRIVE BELT ARRANGEMENTS




SIX-CYLINDER ENGINE WITH ALTERNATOR, POWER STEERING PUMP, AND A/C COMPRESSOR




FOUR- AND SIX-CYLINDER ENGINE WITH ALTERNATOR




FOUR- AND SIX-CYLINDER ENGINE WITH ALTERNATOR AND POWER STEERING PUMP



SIX-CYLINDER ENGINE WITH SERPENTINE DRIVE AND ALTERNATOR (CALIFORNIA ONLY)





SIX-CYLINDER ENGINE WITH SERPENTINE DRIVE, ALTERNATOR, A/C COMPRESSOR AND POWER STEERING PUMP (CALIFORNIA ONLY)



SIX-CYLINDER ENGINE WITH SERPENTINE DRIVE, ALTERNATOR AND POWER STEERING PUMP (CALIFORNIA ONLY)


1. Water Pump
2. Alternator
3. Power Steering Pump
4. A/C Compressor
5. Drive Pulley
6. Idler Pulley





ENGINES


COOLING SYSTEMS



FAN

There are several types of metal fans available for all engines. Most engines with a standard cooling system use a four-bladed rigid fan. Certain engines are fitted with standard equipment multi-bladed viscous drive (Tempatrol) fans.

SEE
I.S.
NOTES



- 1 - Silicone Fluid Chamber
- 2 - Mounting Flange
- 3 - Fan Blade Attaching Bolts (4)

42415

Fan blade assemblies are balanced within 0.25 ounce and should not be altered in any way. Replace a damaged or bent fan. Do not attempt repair. Refer to the Cooling System Components chart for fan applications.

CAUTION: Fans are designed to be compatible with certain applications only. Do not attempt to increase the cooling capacity by installing a fan not intended for a given engine. Fan or water pump damage and noise may result.

Replacement

Removal

Disconnect the fan shroud from the radiator, if equipped.

Remove the belt(s).

Remove the attaching nuts and remove the fan and drive as a unit.


Remove the fan shroud.

The Tempatrol drive unit should be replaced if there is an indication of a fluid leak, noise or if roughness is detected when turning by hand. If the drive cannot be turned by hand, or if the leading edge of the fan can be moved more than 6.35 mm (1/4 in) front to rear, replace the drive unit.


If it is necessary to replace either the Tempatrol fan blade unit or the drive unit separately, use the following procedure.

CAUTION: Engines equipped with a serpentine (single) drive belt have a reverse rotating water pump and viscous (Tempatrol) fan drive assembly. The components are identified by the words REVERSE stamped on the cover of the viscous drive and inner side of the fan, and REV cast into the water pump body. Do not install components that are intended for non-serpentine drive belts.

CAUTION: To prevent silicone fluid from draining into the fan drive bearing and contaminating the lubricant, do not place the Tempatrol fan unit on the work bench with the rear mounting flange down.



ENGINES



COOLING SYSTEMS

Drops Slowly: indicates a small leak or seepage is occurring. Examine all connections for seepage or slight leakage with a flashlight. Inspect the radiator, hoses, gasket edges and heater. Seal small leak holes with AMC Sealer Lubricant, or equivalent. Repair the leak holes and reinspect the system with pressure applied.

Drops Quickly: indicates that a serious leakage is occurring. Examine the system for serious external leakage. If no leaks are visible, inspect for internal leakage.

NOTE: Large radiator leak holes should be repaired by a reputable radiator repair shop.

Internal Leakage Inspection

Remove the oil pan drain plug and drain a small amount of engine oil. Coolant, being heavier, will drain first, or operate the engine to churn the oil, then examine the dipstick for water globules.

Inspect the transmission dipstick for water globules.

Inspect the transmission fluid cooler for leakage. Refer to Transmission Fluid Cooler Leakage Test.

WARNING: Use extreme caution when the engine is operating. Do not stand in a direct line with the fan. Do not put your hands near the pulleys, belts or fan. Do not wear loose clothing.

Operate the engine without the pressure cap on the radiator until the thermostat opens.

Attach a pressure tester (J-24460-01) to the filler neck. If the pressure builds up quickly, a leak exists as result of a faulty cylinder head gasket or crack. Repair as necessary.

WARNING: Do not allow pressure to exceed 103.4 kPa (15 psi). Turn the engine Off. To release the pressure, rock the tester from side to side. When removing the tester, do not turn the tester more than 1/2 turn if the system is under pressure.

If there is no immediate pressure increase, pump the pressure tester until the indicated pressure is within the system range.

Vibration of the gauge pointer indicates compression or combustion leakage into the cooling system.

CAUTION: Do not disconnect the spark plug wires while the engine is operating.

Isolate the compression leak by shorting each spark plug to the cylinder block. The tester gauge pointer should stop or decrease vibration when the spark plug for the leaking cylinder is shorted because of the absence of combustion pressure.


CAUTION: Do not operate the engine with a spark plug shorted for more than a minute, otherwise the catalytic converter may be damaged.

Combustion Leakage Test (Without Pressure Tester)

NOTE: Do not waste reusable coolant. If the solution is clean and is being drained only to service the cooling system, drain the coolant into a clean container for reuse.


WARNING: Do not remove the cylinder block drain plugs or loosen the radiator draincock with the system hot and pressurized because serious burns from coolant can occur.

SEE
I.S.
NOTES



ENGINES

FUEL SYSTEMS



The following procedures apply to a complete overhaul with the carburetor removed from the engine.

A complete disassembly is not necessary when performing adjustments.

In most instances, service adjustments of the individual circuits can be completed without removing the carburetor from the engine.

A complete carburetor overhaul includes disassembly, thorough cleaning, inspection, and replacement of all gaskets and worn or damaged parts.

It also includes curb idle speed adjustment, idle mixture adjustment (if removal of the adjustment screw was necessary) and fast idle speed adjustment after the carburetor is installed.

NOTE: When using an overhaul kit, use all the parts included in the kit.

NOTE: Flooding, hesitation on acceleration, and other performance problems are in many instances caused by the presence of dirt, water or other foreign matter in the carburetor. To aid in diagnosing a problem, carefully remove the carburetor from the engine without removing the fuel from the bowl. Examine the bowl contents and filter for contamination as the carburetor is disassembled.


Disassembly

NOTE: The choke cover is not adjustable.

CAUTION: This procedure below must be followed to retain the original rivet hole size.


Remove the choke cover:

- drill out the rivet heads with a 3-mm (1/8-in) or No. 30 drill bit
- after the rivet heads are removed, drive out the remaining portion of the rivets with a 3-mm (1/8-in) punch





840178

SEE
I.S.
NOTES




ENGINES

FUEL SYSTEMS



Initial Idle Mixture Adjustment –



840209


Install and position the idle mixture adjustment screw at the same number of turns from the lightly seated position as recorded during disassembly.

After carburetor installation, refer to the Service Adjustment Procedures for the final idle mixture adjustment.

TRC (Anti-Diesel) Adjustment –

The TRC (anti-diesel) adjustment screw is statically set at 3/4 of a turn from the throttle valve closed position during factory assembly and normally does not require readjustment.

To adjust, turn the adjustment screw (4) counterclockwise to the throttle valve closed position and then clockwise 3/4 of a turn.



84641


Install the carburetor on the engine and perform the idle speed and mixture adjustments. Refer to the Service Adjustment Procedures.

SEE
I.S.
NOTES




ENGINES


FUEL SYSTEMS



MODEL BBD CARBURETOR (EXPLODED)


SEE
I.S.
N
O
T
E
S





ENGINES

FUEL SYSTEMS



Choke Adjustment (On- or Off-Engine)

NOTE: The choke adjustment is preset during factory assembly and should not normally require readjustment. The choke should be serviced only if absolutely necessary or during major carburetor overhaul.

The automatic choke adjustment is accomplished by removing the housing cover retainers and rotating the cover in the desired direction as indicated by the arrow on the face of the cover.

NOTE: Break-away torq-head cover retaining screws are used to discourage indiscriminate choke adjustment.

Position the choke cover at the following basic setting as indicated by index key color:

- gold index key – set the choke index at 0
- red index key – set the choke index at one-notch rich
- green index key – set the choke index at two-notches rich

NOTE: The richer the choke setting, the greater length of time that spring tension is exerted against the linkage to hold the choke valve in a closed position. As the electric heater relaxes the spring tension, the fast idle cam weight opens the choke valve.

Fast Idle Speed Adjustment

WARNING: Use extreme caution when the engine is operating. Do not stand in a direct line with the fan. Do not put your hands near the pulleys, belts or fan. Do not wear loose clothing.

Adjust the fast idle speed with the engine at normal operating temperature and the EGR valve vacuum hose disconnected and plugged.

Connect a tachometer to the ignition coil negative (TACH) terminal and observe it for the adjustment.

Position the fast idle speed adjustment screw in contact with and against the shoulder of the second step of the fast idle cam.

Refer to the Specifications chart and adjust the engine speed for the correct rpm. Adjust by turning the fast idle speed adjustment screw.

Disconnect the tachometer.

Idle Speed Adjustment

Install the carburetor, fuel pipe, vacuum hoses etc., if removed. Refer to the installation procedure.


WARNING: Use extreme caution when the engine is operating. Do not stand in a direct line with the fan. Do not put your hands near the pulleys, belts or fan. Do not wear loose clothing.

Connect a tachometer to the ignition coil negative (TACH) terminal.

Start and allow the engine to attain the normal operating temperature.


The carburetor choke and intake manifold heater must be off. This occurs when the engine coolant heats to approximately 71°C (160°F).

SEE
I.S.
N
O
T
E
S




ENGINES

TAC SYSTEM




TAC SYSTEM-FOUR-CYLINDER ENGINE

SEE
I.S.
NOTES




1. Cover
2. Molded Ambient Air Duct Adapter
3. Flexible Duct
4. Adapter
5. Heat Stove
6. Heated Air Tube
7. Vacuum Motor
8. Filter Element
9. Elbow
10. PCV Filter Retainer
11. Reverse Delay Valve
12. Grommet
13. Stud
14. Check Valve
15. Air Cleaner Body
16. Thermal Switch

85035



ENGINES



FUEL FEEDBACK SYSTEMS

Altitude Jumper Wire

The altitude jumper wire is located in the engine compartment taped to the CEC system wire harness.

The jumper wire provides the MCU with an indication of whether or not the vehicle is being operated above or below a 6 400-meter (4,000-foot) altitude.


The jumper wire is normally not connected to engine ground. For vehicles operated above 6 400 meters (4,000 feet), the jumper wire must be connected to engine ground.

To connect the altitude jumper wire, remove the tape and extend the wire to the engine ground screw located next to the ignition coil. Remove the screw and attach the eyelet terminal to the engine.

NOTE: Additional engine ground wire connectors are also attached to the engine with the screw.

MCU Outputs


Based on the information received from the various MCU inputs, the MCU generates a number of outputs that provide the correct air/fuel mixture, ignition timing and engine idle speed.



- 10. Mixture Control Solenoid/Stepper Motor
- 11. Idle Relay
- 12. Sole-Vac Throttle Positioner
- 13. Idle Solenoid
- 14. Upstream and Downstream Solenoids
- 15. P.C.V. Solenoid


SEE
I.S.
N
O
T
E
S

85062




ENGINES


FUEL FEEDBACK SYSTEMS



SEE
I.S.
N
O
T
E
S




*NOTE: BEFORE REPLACING MCU, IF ENGINE FAILS TO START, CHECK FOR FAILURE OF IGNITION MODULE, COIL, DISTRIBUTOR, ETC. REFER TO IGNITION SYSTEMS -CHAPTER C.




ENGINES

FUEL FEEDBACK SYSTEMS




DIAGNOSTIC TEST 6


NOTE: WHEN APPLICABLE, DIAGNOSTIC CONNECTOR TERMINALS CAN BE USED AS TEST POINTS INSTEAD OF MCU CONNECTOR TERMINALS.



SEE
I.S.
NOTES




ENGINES




FUEL FEEDBACK SYSTEMS

SEE
I.S.
NOTES




- C - Vacuum Switch Solenoid
- 1 - Common (D)
- 2 - Normally Closed - NC (E)
- 3 - Springloaded Pin
- 4 - Normally Open - NO (Vent)

81147A




- B - Coolant Temperature Switch
- 1 - Insulator

81146




- A - Stepper Motor Connector
- 1 - Orange
- 2 - Tan
- 3 - Violet
- 4 - Red
- 5 - Brown

81144




- 1 - 4-in Hg Vacuum Switch
- 2 - 10-in Hg Vacuum Switch
- 3 - Green Color
- 4 - Natural Color

81147B



ENGINES

FUEL FEEDBACK SYSTEMS




DIAGNOSTIC TEST 4

CLOSED LOOP OPERATIONAL TEST

CAUTION: SAFETY SHIELD MUST BE IN PLACE AT TOP OF CARBURETOR AIR CLEANER.

START AND WARM ENGINE UNTIL COOLANT TEMPERATURE HAS STABILIZED. REMOVE AIR COVER AND INCREASE ENGINE SPEED TO 2000 RPM AND MAINTAIN WHILE OBSERVING CARBURETOR STEPPER MOTOR METERING PINS.



SEE
I.S.
NOTES



ENGINES

EXHAUST SYSTEMS



RESTRICTED EXHAUST SYSTEM DIAGNOSIS

A partially restricted or blocked exhaust system usually results in loss of power and/or backfire up through the carburetor.

If the vacuum stabilizes at 53.88 - 70.73 kPa (16 - 21 in. Hg), the restriction or blockage is either in the exhaust pipe, catalytic converter, muffler or tail pipe.

If the vacuum stabilizes below the 53.88 kPa (16 in. Hg) with the exhaust pipe disconnected, the exhaust manifold is restricted.

Stop the engine, connect the exhaust pipe and remove the muffler.

Start the engine and increase the engine speed to 2000 rpm. Observe the vacuum gauge.

If the vacuum stabilizes below 53.88 kPa (16 in. Hg), the restriction or blockage is in the catalytic converter.

If the vacuum is normal, the muffler or tail pipe is restricted.

NOTE: In the event of a catalytic converter failure, always inspect the muffler and ensure converter debris has not entered the muffler.

Stop the engine.

Disconnect the tachometer and vacuum gauge.

Remove the exhaust manifold. Refer to the removal procedure.

Inspect the ports of the exhaust manifold for casting flash by dropping a length of chain into each port.

NOTE: Do not use a wire or a light to inspect the ports. The restricted opening may be large enough for a wire or light to pass through but small enough to cause excessive back pressure at high engine rpm.

SEE
I.S.
NOTES

Verify that the condition is not caused by ignition or fuel system problems, then perform a visual inspection of the exhaust system.

If the restriction cannot be located by visual inspection, perform the following procedure.

Attach a vacuum gauge to the intake manifold.

Connect a tachometer to the ignition coil negative (TACH) terminal.

WARNING: Use extreme caution when the engine is operating. Do not stand in a direct line with the fan. Do not put your hands near the pulleys, belts or fan. Do not wear loose clothing.

Start the engine and observe the vacuum gauge. The gauge should indicate a vacuum of 53.88 - 70.73 kPa (16 - 21 in. Hg).


Increase the engine speed to 2000 rpm and observe the vacuum gauge.

The vacuum will decrease when the speed is increased rapidly, but should stabilize at 53.88 - 70.73 kPa (16 - 21 in. Hg) and remain constant.


If the vacuum remains below 53.88 kPa (16 in. Hg), the exhaust system is restricted or blocked. Stop the engine and proceed with the next step.

Disconnect the exhaust pipe at the manifold.

Start the engine and increase the speed to 2000 rpm. Observe the vacuum gauge.




ELECTRICAL




CONTENTS

| | | | |
|----------------------------------|----|-------------------------------------|-----|
| GENERAL INFORMATION | 1 | IGNITION SYSTEM | 58 |
| Special Tools | 1 | General | 58 |
| BATTERIES | 4 | Special Tools | 59 |
| General | 4 | Torque Specifications..... | 59 |
| Special Tools | 4 | Specifications | 59 |
| Torque Specifications..... | 4 | Components | 60 |
| Specifications | 5 | Diagnosis | 61 |
| Battery Codes | 5 | Testing..... | 69 |
| Battery Replacement | 6 | Distributor Replacement | 71 |
| Battery Maintenance..... | 7 | Distributor Component | |
| Battery Charging..... | 8 | Replacement..... | 74 |
| Battery Testing | 10 | CRUISE COMMAND | 77 |
| Diagnosis And Repair | | General | 77 |
| Simplification (DARS) | | Special Tools | 77 |
| Chart | 13 | Diagnosis | 78 |
| CHARGING SYSTEM | 16 | Testing..... | 81 |
| General | 16 | Testing With AM PC-1-R | |
| Special Tools | 16 | Tester | 85 |
| Torque Specifications..... | 16 | Adjustments | 89 |
| Specifications | 17 | Component Replacement..... | 90 |
| Alternator | 17 | ENGINE INSTRUMENTATION | 93 |
| Diagnosis | 17 | General | 93 |
| Testing – Off-Vehicle | 23 | Special Tools | 93 |
| Alternator Replacement..... | 29 | Specifications | 94 |
| Alternator Overhaul | 30 | Diagnosis | 97 |
| Drive Belt Adjustment | 34 | Instrument Cluster Replacement..... | 99 |
| STARTING SYSTEM | 35 | Gauge And Meter | |
| General | 35 | Replacement..... | 100 |
| Special Tools | 35 | Diagnosis And Repair | |
| Torque Specifications..... | 36 | Simplification (DARS) | |
| Specifications | 36 | Charts | 103 |
| Troubleshooting | 38 | LIGHTING SYSTEMS | 124 |
| On-Vehicle Testing..... | 40 | Special Tools | 124 |
| Off-Vehicle Testing..... | 45 | Torque Specifications..... | 124 |
| Starter Motor Replacement – | | Specifications | 125 |
| Four-Cylinder | 49 | Exterior Lighting..... | 125 |
| Starter Motor Replacement – | | Interior Lighting Systems..... | 132 |
| Six-Cylinder..... | 50 | Switches | 132 |
| Starter Motor Overhaul..... | 51 | | |
| Neutral Safety Switch | | | |
| Replacement..... | 57 | | |



ELECTRICAL

BATTERIES



SEE I.S. NOTES

- 38.8°C divided by 5.5°C (70°F divided by 10°F), each 5.5°C (10°F) difference equals 7
- 7 multiplied by 0.004 (temperature correction factor) equals 0.028
- temperature is below 26.6°C (80°F), therefore, the temperature correction is subtracted
- temperature corrected specific gravity is 1.212 (1.240 minus 0.028)
- a fully charged battery should have a temperature corrected specific gravity of 1.250 - 1.265

| State of Charge | Specific Gravity (Cold and Temperate Climates) |
|-----------------|---|
| Fully Charged | 1.265 |
| 75% Charged | 1.225 |
| 50% Charged | 1.190 |
| 25% Charged | 1.155 |
| Discharged | 1.120 |

60340

If the specific gravity of all cells is above 1.235, but the variation between cells is more than 50 points (0.050), it is an indication that the battery is unserviceable. Remove the battery from the vehicle for additional testing.

If the specific gravity of one or more cells is less than 1.235, recharge the battery at a rate of approximately five amps until three consecutive specific gravity tests, taken at one-hour intervals, are constant.


If the cell specific gravity variation is more than 50 points (0.050) at the end of the charge period, replace the battery.

When the specific gravity of all cells is above 1.235 and variation between cells is less than 50 points (0.050), the battery may be tested under heavy load.


Heavy Load Test

NOTE: The following instructions refer to Amserv Battery-Alternator-Regulator-Starter Motor Tester, model AMA 21-317, or equivalent.

Before performing the Heavy Load Test, the battery must be fully charged. Refer to Slow Charge.



ELECTRICAL CHARGING SYSTEM



Test Results


Current flow exceeding 5.0 amps indicates internally shorted windings.

NOTE: The winding resistance and ammeter indication will vary slightly with winding temperature changes. A current flow that is less than the specified value indicates excessive winding resistance. An alternate test method is to determine the field winding resistance by connecting an ohmmeter to the two slip rings. If the resistance is less than 2.2 ohms at 27°C (80°F), the windings are internally shorted. If the resistance is more than 3.0 ohms at 27°C (80°F), the windings have excessive resistance.

Stator Windings Short Circuit-to-Ground Test

To perform this test, separate the rear housing and stator from the rotor and front housing assembly. Disconnect the stator winding terminals from the bridge rectifier (and diode trio) terminal studs. Refer to Alternator Overhaul for the procedure. The test is performed with an ohmmeter set for the x1000 scale or with a 110-volt test lamp.

Touch one test lead probe to the bare metal surface of the stator core and the other test lead probe to the end of one stator winding. Because all three stator winding terminals are soldered together, it is not necessary to test each winding. The ohmmeter should indicate infinite resistance (no pointer movement) or the test lamp should not light.



84912

Test Results

If the ohmmeter indicates other than an infinite resistance or the test lamp lights, the stator windings have a short circuit to the core (ground) and must be replaced.

SEE
I.S.
N
O
T
E
S

TROUBLESHOOTING


The Service Diagnosis chart may be used to isolate the source of the problem when the starter motor either rotates the engine too slowly, will not rotate the engine or has abnormal drive engagement.

SEE
I.S.
NOTES

If the starter motor rotating speed is normal and the drive pinion gear engages properly with the ring gear but the engine does not start, a problem exists either in the fuel system or ignition system.

STARTER MOTOR OVERHAUL


SIX-CYLINDER



Starter Motor—Exploded View

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Seal 2. Drive End Housing 3. Bushing 4. Drive Yoke Return Spring 5. Washer 6. Retainer 7. Snap Ring 8. Pinion Gear Drive Mechanism 9. Drive Yoke 10. Solenoid Contact Point Actuator 11. Spacer 12. Movable Pole Shoe 13. Armature 14. Pivot Pin 15. Solenoid Contact Point Assembly 16. Drive Yoke Cover | <ol style="list-style-type: none"> 17. Hold-In Coil Terminal 18. Field Winding Screw 19. Bushing 20. Frame 21. Insulator 22. Insulated Brush 23. Field Winding 24. Sleeve 25. Terminal 26. Ground Brush 27. Pole Shoe 28. Brush Holder and Insulator 29. Spring 30. Brush End Plate 31. Through Bolt 32. Terminal Screw |
|---|---|

SEE I.S. NOTES



ELECTRICAL IGNITION SYSTEM



Chart 1 RESULT


STEP

SEQUENCE

RESULT

6

● TURN IGNITION OFF



CONNECT OHMMETER BETWEEN COIL POSITIVE TERMINAL AND DASH CONNECTOR FW



RESISTANCE TOO HIGH (1.40 OHMS OR MORE)



REPAIR RESISTANCE WIRE




RESISTANCE ACCEPTABLE (1.35 ± .05 OHMS)

7

7

● IGNITION REMAINS OFF



CONNECT OHMMETER BETWEEN DASH CONNECTOR FW AND IGNITION SWITCH TERMINAL I1



RESISTANCE ACCEPTABLE (LESS THAN 0.1 OHM)



REPLACE IGNITION SWITCH OR REPAIR SWITCH WIRE FROM BATTERY



RESISTANCE TOO HIGH (MORE THAN 0.1 OHM)




- POOR TERMINAL CONNECTIONS AT DASH CONNECTOR OR IGNITION SWITCH
- DEFECTIVE WIRING



- PROCEED TO COIL TEST




SEE
I.S.
NOTES




ELECTRICAL

CRUISE COMMAND



GENERAL

The cruise command is a closed loop electro-mechanical servo system that consists of the following components: electronic regulator (1), speed sensor (2), servo (3), control switch (4), vacuum storage can and check valve and the release mechanisms, which consist of a mechanical vacuum vent and brake lamp switch.



840253


Cruise Command operation is limited to speeds above 48 km/h (30 mph).

WARNING: Do not use the Cruise Command when driving on slippery or congested roads.

SEE I.S. NOTES


SPECIAL TOOLS

| Tool Ref. | Description | Required | Recommended |
|------------------|----------------------|----------|-------------|
| AM PC-1-R | Tester | | ■ |
| J-21008 | Continuity Test Lamp | | ■ |



ELECTRICAL

CRUISE COMMAND



To adjust the regulator for engagement speed complaints, drive the vehicle on a level road surface and check operation.

If the actual engagement speed is 3.2 km/h (2 mph) or more above the selected engagement speed, stop the vehicle, turn the regulator centering screw approximately 1/16 of a turn counterclockwise and check the engagement speed again. Readjust the speed as needed. If the actual engagement speed is 3.2 km/h (2 mph) or more below the selected engagement speed, stop the vehicle, turn the regulator centering screw 1/16 of a turn clockwise and check the engagement speed again.

SEE
I.S.
NOTES

Vacuum (Mechanical) Vent Valve Adjustment

Depress the brake or clutch pedal and hold in the depressed position.

Move the vacuum vent valve toward the bracket on the pedal as far as possible.

Release the brake or clutch pedal.

COMPONENT REPLACEMENT

Regulator Replacement

The regulator is mounted on a bracket under the instrument panel near the headlamp switch. Remove the screws or tie straps and unplug the connector. Insert a suitable thin tool to depress the tab inside the hole on the regulator identified by "Terminal Release." To install, plug the connector into the regulator and install the screws.

Servo Replacement

Removal

Remove the retaining nuts and cable housing from the servo.

Spread the clip that connects the cable to the servo and remove.

Disconnect the vacuum hoses from the servo.

Remove the retaining nut and servo from the bracket. Note the position of the ground cable.

Disconnect the wire harness connector under the instrument panel. Carefully maneuver the wire harness through the dash panel and remove the servo.

Installation

Install the servo and nut on the bracket. Tighten with 7 N·m (60 in-lbs) torque. Ensure the ground cable is positioned on the stud.

Maneuver the wire harness through the dash panel and connect the connector.

Attach the cable to the servo and squeeze the clip to retain the cable.













NOTE: Mounting studs are not equally spaced from the hole in the servo. Ensure the housing is installed correctly.

Connect the vacuum hoses.

DIAGNOSIS AND REPAIR SIMPLIFICATION (DARS) CHARTS

PROBLEM: FUEL GAUGE NOT FUNCTIONING PROPERLY

Chart 1

| STEP | SEQUENCE | RESULT |
|----------|---|--|
| 1 | <p>● NOTE POSITION OF FUEL GAUGE POINTER</p> <p>● TURN IGNITION SWITCH ON AND WAIT 2 MINUTES FOR GAUGE TO WARM UP</p> <p>● OBSERVE POINTER</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p>POINTER DOES NOT MOVE</p> <p>POINTER MOVES TO INCORRECT POSITION</p> <p>POINTER MOVES TO MAXIMUM AND STAYS</p> <p>POINTER PULSATES MORE THAN WIDTH OF POINTER</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center; font-weight: bold;">BEFORE STARTING TEST:</p> <div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-right: 5px; display: flex; align-items: center; justify-content: center;"> ✓ </div> <p>ENGINE MUST BE WARM</p> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-right: 5px; display: flex; align-items: center; justify-content: center;"> ✓ </div> <p>FUEL TANK MUST BE NEITHER COMPLETELY FULL NOR COMPLETELY EMPTY</p> </div> </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right; margin-top: 10px;">  REPLACE CVR </p> | <div style="display: flex; flex-direction: column; gap: 20px;"> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">2</div> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">17</div> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">9</div> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">STOP</div> </div> |
| 2 | <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>✓ CHECK 3-AMP FUSE AT FUSE PANEL</p> </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  <p>FUSE BLOWN</p> </div> <div style="text-align: center;">  <p>FUSE NOT BLOWN</p> </div> </div> | <div style="display: flex; flex-direction: column; gap: 20px;"> <div style="text-align: right; padding-right: 10px;">GO TO CHART 2 STEP 1</div> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">3</div> </div> |
| 3 | <p>OBSERVE TEMPERATURE GAUGE</p> <p>TEMPERATURE GAUGE POINTER DOES NOT MOVE</p> <p>TEMPERATURE GAUGE POINTER INDICATES PROPERLY</p> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> | <div style="display: flex; flex-direction: column; gap: 20px;"> <div style="text-align: right; padding-right: 10px;">GO TO CHART 3 STEP 1</div> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; font-size: 24px; font-weight: bold;">4</div> </div> |

SEE I.S. NOTES



ELECTRICAL

ENGINE INSTRUMENTATION




Chart 4 RESULT


STEP

SEQUENCE


RESULT

SEE I.S. NOTES

10




DISCONNECT SENDING UNIT WIRE FROM GAUGE




POINTER DROPS FROM MAXIMUM


→



REPLACE SENDING UNIT WIRE


→






POINTER REMAINS AT MAXIMUM

→




REPLACE GAUGE

→



11




DISCONNECT SENDING UNIT WIRE

CONNECT ONE TESTER LEAD TO GROUND AND ONE LEAD TO SENDING UNIT WIRE

- TURN IGNITION SWITCH ON
- ADJUST TESTER TO SELECT OHM VALUES LISTED IN SENDING UNIT RESISTANCE CHART.


OBSERVE GAUGE INDICATION AT EACH OHM SETTING.



GAUGE INDICATIONS NOT ACCURATE AT EACH OHM SETTING


→

12




GAUGE INDICATIONS ACCURATE AT EACH OHM SETTING

→




REPLACE SENDING UNIT

→



80314D

bulb. Clean the lens and reflector before installing.



1. Housing
2. Backup Lamp Bulb
3. Gasket
4. Tail-Stop Directional Lamp Bulb
5. Side Marker Lamp Bulb
6. Lens

841291

Taillamp Housing Replacement

Disconnect the wiring, remove the taillamp lens, and remove the screws attaching the taillamp assembly body and remove.

Side Marker Bulb Replacement

Remove the lens attaching screws, lens and gasket. Clean the lens and reflector before installing.

Pull the side marker bulb straight out of the socket.

To install the new bulb, push straight into the socket.

Position the lens gasket and lens and install the screws.

Back Up Lamp

To replace the bulb remove the taillamp lens.

Remove old bulb and install new bulb.


License Plate Lamp

The left taillamp illuminates the license plate.

Fog Lamps


The switch (1) is located on the far left side of the instrument panel.

NOTE: Fog lamps are turned off by the circuit relay when the high beam driving lamps are turned on. The circuit relay is located on the right front wheelhouse panel near the blower motor.




841262

SEE I.S. NOTES



ELECTRICAL

CHASSIS WIRING HARNESS




Move the slider to the extreme right (ACCESSORY position).

NOTE: The right side of the ignition switch is downward from the steering wheel.

Position the actuator rod in the slider hole (1).

SEE
I.S.
NOTES



85000

Install the switch to the steering column but do not tighten the attaching screws.

Lightly push the switch down the column (away from the steering wheel) to remove the lash in the actuator rod, while holding the key in the ACCESSORY position. Be careful not to move the slider out of the detent.


Tighten the attaching screws securely.

Connect the white connector and then the black connector to the ignition switch.


Install the steering tube cover, if removed.

FUSE PANEL

The fuse panel is located on the passenger compartment side of the dash panel, attached to the main harness connector.



REAR VIEW



FRONT VIEW


90199

CIRCUIT BREAKERS

Headlamps are protected by a 24-amp circuit breaker located in the headlamp switch.

IE CONNECTORS


C100



VIEWED FROM DASH PANEL

| ENGINE | FUNCTION |
|--------------------|--|
| V10 W/TR LT BLU | ENGINE TEMPERATURE START |
| BLACK | BRAKE WARNING |
| BLACK | BRAKE WARNING |
| RED W/TR | IGNITION FEED |
| BRN | A/C COMPRESSOR HEADLAMP ON |
| V10 | ENGINE OIL PRESSURE |
| ORN | FOG LAMP FEED |
| RED | ELECTRONIC ENGINE CONTROL FEED |
| LT BRN | HEATER BLOWER MOTOR FEED |
| RED | FUSED IGNITION ON FEED |
| YEL | WINDSHIELD WASHER PUMP FEED |
| ORN | UNDERHOOD LAMP FEED |
| WHT W/TR | BACKUP LAMP FEED |
| GRN W/TR | LH FRONT TURN LAMP FEED |
| GRY | LH HEADLAMP LO BEAM FEED |
| RED W/TR | HORN FEED |
| GRY W/TR | LH HEADLAMP HI BEAM FEED |
| RED | BATTERY FEED |
| ORN | 4-WHEEL DR IND LAMP |
| WHT | PARK AND MARKER LAMP FEED |
| GRN | RH FRONT TURN LAMP FEED |
| DK GRN | TACHOMETER COIL SIGNAL EMISSION MAINT. LAMP |


C102



C103



C108






C123




BACKUP LAMP

UNDERHOOD LAMP, COURTESY LAMPS, DOME LAMP





CLUTCH



SERVICE DIAGNOSIS

Clean oil and dirt from the clutch cover with a solvent and allow the cover to air dry.

Sand the pressure plate surface lightly using a fine emery cloth.

Lubricate the cover release lever pivots with chassis grease.

NOTE: Apply lubricant to the pivots sparingly. Excessive lubricant could result in grease contamination of the pressure plate and driven plate surfaces.

Inspect the crankshaft pilot bushing for heavy scoring, an angular wear pattern, or discoloration. Replace as necessary. Be sure to soak the bushing in engine oil before installation.

NOTE: If the pilot bushing displays an angular-type wear pattern, check and correct the clutch housing alignment before proceeding.

Inspect the condition of the splines on the transmission clutch shaft and in the driven plate hub. If severely worn, galled, or corroded, replace the clutch shaft or driven plate. Corrosion, rust, or burrs can be removed from the splines using an oilstone or fine-tooth file. Install the driven plate on the clutch shaft. The driven plate must move freely on the shaft.

If the components inspected in the previous steps are in good condition, proceed to the next step. If one or more problems were discovered during the inspection procedure, repair as necessary and proceed to the next step.

Check the clutch housing alignment. Correct the alignment if necessary and proceed to the next step.

Apply a thin film of chassis grease to the transmission clutch shaft splines. Do not apply

grease to the shaft pilot hub.

Install the pilot bushing lubricating wick.

Install the transmission and clutch components.

Lower the vehicle.

CLUTCH PEDAL PULSATION

Clutch pedal pulsation can be described as a rapid up-and-down or pumping-type movement of the pedal that is not accompanied by any noise.

Pulsation is usually caused by incorrect clutch release lever height or clutch housing misalignment. Check the clutch operation as follows.

Start the engine, slowly depress the clutch pedal until the throwout bearing makes initial contact with the clutch release levers, and check for pulsation.

NOTE: Some minor pulsation is normal.


Continue to depress the clutch pedal while checking for pulsation until the pedal is fully depressed.

If pulsation is not evident or is minor, discontinue the repair. If pulsation is very rapid and can be felt throughout the vehicle, refer to Clutch Related Vibrations. If the vehicle displays pulsation symptoms, proceed to the next step.

Remove the transmission and the clutch components.



Remove the pilot bushing lubricating wick and soak the wick in engine oil.

SEE
I.S.
NOTES



CLUTCH

CLUTCH SERVICE – FOUR-CYLINDER MODELS



84016

CLUTCH ASSEMBLY INSTALLATION

Install the pilot bushing lubricating wick.

Insert Clutch Alignment Tool J-33169 in the hub of the clutch driven plate (2) and position the plate on the flywheel. Be sure that the alignment tool is fully seated in the pilot bushing.

NOTE: Be sure that the side of the driven plate, marked flywheel side, is positioned against the flywheel.

Position the clutch cover (1) on the flywheel and over the driven plate.

Align the driven plate and the clutch cover using the alignment tool and install the cover attaching bolts finger-tight only.

CAUTION: To avoid warping the clutch cover, tighten the cover attaching bolts a few turns at a time only.

Tighten the clutch cover bolts alternately and evenly with the specified torque.

CLUTCH COMPONENT INSPECTION AND SERVICE


Clutch Pilot Bushing Removal

Remove the clutch assembly. Refer to Clutch Assembly Removal in this section.


Obtain and lubricate the replacement pilot bushing with engine oil.

Remove the pilot bushing lubricating wick and soak the wick in engine oil.

Remove the old bushing using Removal Tool J-5822 and Slide Hammer J-2619-01.



GEARBOXES




GENERAL INFORMATION

TORQUE SPECIFICATIONS


| Component | Service Set-To Torque | Service Recheck Torque |
|--|-----------------------|------------------------------|
| Model T4/T5 Transmission | | |
| Backup Lamp Switch | 20 N·m (15 ft-lbs) | 20-34 N·m (15-25 ft-lbs) |
| Fill Plug | 31 N·m (23 ft-lbs) | 20-41 N·m (15-30 ft-lbs) |
| Shift Control Housing Bolt | 18 N·m (13 ft-lbs) | 15-20 N·m (11-15 ft-lbs) |
| Transmission-to-Clutch Housing Bolt | 75 N·m (55 ft-lbs) | 61-65 N·m (45-65 ft-lbs) |
| Universal Joint Clamp Strap Bolt | 19 N·m (14 ft-lbs) | 16-24 N·m (12-18 ft-lbs) |
| Model T-176 Transmission | | |
| Backup Lamp Switch | 20 N·m (15 ft-lbs) | 14-27 N·m (10-20 ft-lbs) |
| Drain and Fill Plugs | 20 N·m (15 ft-lbs) | 14-27 N·m (10-20 ft-lbs) |
| Front Bearing Cap Bolts | 18 N·m (13 ft-lbs) | 15-20 N·m (11-15 ft-lbs) |
| Shift Housing-to-Transmission Case Bolts | 18 N·m (13 ft-lbs) | 15-20 N·m (11-15 ft-lbs) |
| Support Plate Bolts | 24 N·m (18 ft-lbs) | 20-27 N·m (15-20 ft-lbs) |
| Model 300 Transfer Case | | |
| Bottom Cover Bolts | 20 N·m (15 ft-lbs) | 14-27 N·m (10-20 ft-lbs) |
| Cover Plate Bolts | 47 N·m (35 ft-lbs) | 34-54 N·m (25-40 ft-lbs) |
| Front Bearing Cap Bolts | 47 N·m (35 ft-lbs) | 34-54 N·m (25-40 ft-lbs) |
| Front/Rear Yoke Locknuts | 163 N·m (120 ft-lbs) | 163-203 N·m (120-150 ft-lbs) |
| Input Shaft Support Screws | 14 N·m (10 ft-lbs) | 9-14 N·m (7-10 ft-lbs) |
| Lockplate Bolts | 31 N·m (23 ft-lbs) | 27-34 N·m (20-25 ft-lbs) |
| Shift Fork Setscrews | 19 N·m (14 ft-lbs) | 16-24 N·m (12-18 ft-lbs) |

SEE
I.S.
N
O
T
E
S



GEARBOXES

MODEL T4 AND T5 TRANSMISSIONS



Install:

- the transfer case shift lever
- the shifter shaft
- the link pins
- the control link assembly

Connect the front propeller shaft to the transfer case yoke. Tighten the clamp strap bolts with 20 N·m (15 ft-lbs) torque. Be sure the shaft and yoke are aligned according to the reference marks made during disassembly.

Connect the vent hose to the transfer case.

Connect the wire to the four-wheel drive indicator switch.

Connect the speedometer cable.

Install the rear crossmember. Tighten the crossmember attaching nuts and bolts with 41 N·m (30 ft-lbs) torque.

Remove the safety stand used to support the engine.

Connect the rear propeller shaft to the transfer case yoke. Tighten the clamp strap bolts with 20 N·m (15 ft-lbs) torque. Be sure the shaft and yoke are aligned according to the reference marks made during disassembly.

Check and correct the transmission and transfer case lubricant levels, if necessary.

Lower the vehicle.


Install the shift lever and housing on the transmission and tighten the housing bolts with 14 N·m (10 ft-lbs) torque.

Use RTV sealant, or an equivalent, to seal the housing to the transmission case. Be sure the shift lever is properly engaged with the offset lever before tightening the housing bolts.

Position the shift lever boot on the floorpan and install the boot attaching screws.


NOTE: For overhaul procedures, refer to B.V. T4/5.

SEE
I.S.
N
O
T
E
S



GEARBOXES


MODEL T-176 TRANSMISSION



Remove the front bearing cap (1), seat the front bearing fully on the clutch shaft and install the bearing retaining snap ring.

Apply a thin film of sealer to the front bearing cap gasket and position the gasket on the case. Be sure the gasket notch is aligned with the oil return hole in the case.

Remove the front bearing cap oil seal using a screwdriver and install the replacement oil seal using Tool J-25233.



841011

Install the front bearing cap. Tighten the cap bolts with 16 N·m (12 ft-lbs) torque.

Install the locating ring on the rear bearing. If necessary, reseal the bearing in the case using a rawhide mallet.

CAUTION: When installing the countershaft, be careful not to damage the thrust washers. Be sure they are aligned with the case bores and gear bores before tapping the countershaft into place.

Install the countershaft as follows:


- turn the transmission case on end, positioning the case at the edge of the workbench with the clutch shaft pointing downward; be sure the countershaft bore in the front of the case is accessible
- have an assistant hold the case in position
- align the countershaft gear bores with the thrust washers and case bores and tap the shaft into place; do not let the arbor tool drop on the floor while the shaft is being installed

Shift the synchronizer sleeves into all the gear positions and check the operation. If the clutch shaft and mainshaft appear to bind in the Neutral position, check for synchronizer rings sticking on the tapered portion of the gears. Use a screwdriver to free any sticking blocking rings.

Fill the transmission with 1.7 liters (3.5 pts) of AMC/Jeep Manual Transmission Fluid, Part no. 8983 000 000.


Position the new shift control housing gasket on the case and install the control housing. Tighten the housing bolts with 16 N·m (12-ft-lbs) torque.

SEE
I.S.
N
O
T
E
S



GEARBOXES

MODEL 300 TRANSFER CASE



Remove the socket head screws attaching the input shaft support (1) to the case and remove the support, rear output shaft gear (2) and input shaft (3) as an assembly.


NOTE: The support has been coated with a sealant. Use a putty knife to break the seal, and work the knife around the support to loosen and remove it.

Remove the rear output shaft clutch sleeve from the case.

Remove and discard the snap ring (4) retaining the rear output shaft gear on the input shaft and remove the gear.

Remove and discard the input shaft bearing snap ring.

Remove the input shaft and bearing (5) from the support. Tap the end of the input shaft with a plastic mallet to aid removal.



Remove the input shaft bearing and end play shims from the shaft using an arbor press.

Remove the input shaft oil seal from the support. Discard the seal.

Remove the intermediate shaft lockplate bolt and lockplate.

Remove the intermediate shaft. Tap the shaft out of the case using a brass punch and plastic mallet.

Remove and discard the intermediate shaft O-ring seal.

Remove the intermediate gear assembly and thrust washers.

NOTE: The thrust washers have locating tabs which must fit in the notches in the case at assembly.

Remove the needle bearings and bearing spacers from the intermediate gear.

NOTE: There are 48 needle bearings and three bearing spacers in the intermediate gear.

Remove the rear bearing cap attaching bolts and remove the cap. Use a plastic mallet to tap on the output shaft to aid in the cap removal.

NOTE: The rear bearing cap has been coated with a sealant. Use a putty knife to break the seal, and work the knife around the cap to loosen and remove it.

Remove the end play shims and speedometer drive gear from the rear output shaft.

Remove and discard the rear output shaft oil seal. Remove the bearings and bearing races from the rear bearing cap.

SEE
I.S.
NOTES



AUTOMATIC TRANSMISSION

GENERAL INFORMATION



Band Adjustments

999

| | |
|-------------------------|---|
| Front Band Turns* | 2 |
| Rear Band Turns* | 4 |

NOTE: *999 backed off from 8 N·m (72 in-lb)

840604


Fluid Capacity

The fluid capacity for the Model 999 transmission is 8 liters (17 pints) and reflects the combined or total amount required for both the transmission and torque converter.

TRANSMISSION AND TORQUE CONVERTER IDENTIFICATION

Transmission Code and Part Numbers

A seven-digit transmission part number (1) is stamped on the left side of the case just above the oil pan mating surface. This number is followed by a four-digit code number (2) which indicates the date of manufacture. The final four-digit number group (3) stamped on the case represents the transmission serial number.



Torque Converter Identification

Because the lockup mechanism is completely enclosed within the converter and not visible, lockup converters have an identifying decal attached to the front cover. The decal is circular in shape and states the converter type and stall ratio, such as Lockup and LS (low stall) or HS (high stall).

Torque Converter Service

The torque converter is a welded assembly and is not serviceable. If diagnosis indicates a malfunction has occurred, or if the converter becomes contaminated with foreign material, replace the converter as an assembly only. Do not attempt to repair or flush the unit. In addition, never attempt to interchange lockup and conventional converters. The transmission input shaft and valve body required for lockup operation are different.

SEE
I.S.
N
O
T
E
S

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



AUTOMATIC TRANSMISSION

DIAGNOSTIC AND TEST PROCEDURES




AIR PRESSURE TESTS

CAUTION: Use dry, filtered compressed air only when performing air pressure tests. Pressures of 207 - 689 kPa (30 - 100 psi) are required to perform the tests.

Air pressure testing is used as a diagnostic tool before transmission removal and also as a method of confirming proper clutch, band and servo operation after repair. The tests involve substituting air pressure for fluid pressure by applying air pressure to the appropriate case passages after the valve body has been removed.

SEE
I.S.
NOTES



84082

Front Clutch Test

Place one or two fingers on the clutch housing and apply air pressure to the front clutch apply passage (1).

Movement of the piston can be felt and a soft thud may be heard as the clutch applies. While air pressure is applied, check for excessive air leakage.

Rear Clutch Test

Place one or two fingers on the clutch housing and apply air pressure to the rear clutch apply passage (2). Movement of the piston can be felt and a soft thud may be heard as the clutch applies. While air pressure is applied, check for excessive or unusual air leakage.

Front Servo Test

Apply air pressure to the front servo apply passage (3). The servo rod should extend and cause the band to tighten around the drum. While air pressure is applied, check for excessive air leakage. Spring tension should release the servo when air pressure is removed.

Rear Servo Test

Apply air pressure to the rear servo apply passage (4). The servo rod should extend and cause the band to tighten around the drum. While air pressure is applied, check for excessive air leakage. Spring tension should release the servo when air pressure is removed.

CONVERTER HOUSING FLUID LEAK DIAGNOSIS

When diagnosing converter housing fluid leaks, two facts must be established before attempting repair. First, it must be verified that a leak condition does actually exist and second, the real source of the leak must be determined. Failure to establish these facts beforehand can result in incorrect and unnecessary repairs.

In some cases, suspected converter housing fluid leaks may not be leaks at all. They may be the result of residual fluid in the converter housing or excess fluid spilled during factory filling or initial transmission operation. These



AUTOMATIC TRANSMISSION

OIL FILTER



REMOVAL

Raise the vehicle.

Remove the oil pan and drain the fluid.

Inspect the fluid and the filter for friction material or metal particles which indicate worn or damaged parts.

Remove the three screws attaching the filter to the valve body and remove the filter.

INSTALLATION

Install a replacement filter and tighten the filter attaching screws with 4 N·m (35 in-lbs) torque.

Clean and install the oil pan and a replacement pan gasket. Tighten the pan bolts with 17 N·m (150 in-lbs) torque.

Lower the vehicle.

Fill the transmission with AMC/Jeep/Renault Automatic Transmission Fluid or equivalent labeled Dexron II®. Refer to Fluid Level and Condition for the refill procedure.

SEE
I.S.
N
O
T
E
S




STEERING AND FRONT AXLE



CONTENTS

| | |
|-------------------------------------|------------|
| Axle Shaft | 146 |
| Axle Shaft Universal Joint | 147 |
| Steering Knuckle Removal | 148 |
| Steering Knuckle Ball Studs | 150 |
| Steering Knuckle Installation | 152 |
| Axle Shaft Seal | 153 |
| Spindle Bearing | 154 |
| Axle Housing Inner Oil Seal | 154 |
| Axle Removal | 154 |
| Axle Installation | 155 |
| Turning Angle Adjustment | 156 |
| Differential Overhaul | 156 |
| FRONT DRIVE HUBS | 170 |
| General | 170 |
| Specifications | 170 |
| Lubrication | 170 |
| Diagnosis | 172 |
| Hub Service | 173 |
| Hub Removal/Installation | 173 |

SEE
I.S.
N
O
T
E
S



STEERING AND FRONT AXLE




STEERING COLUMNS

Service Diagnosis—Turn Signal


| Condition | Possible Cause | Correction |
|---|---|--|
| TURN SIGNAL WILL NOT CANCEL | (1) Loose switch mounting screws. (2) Switch or anchor bosses broken. (3) Broken, missing or out of position detent, or cancelling spring. | (1) Tighten screws. (2) Replace switch. (3) Reposition springs or replace switch as required. |
| TURN SIGNAL DIFFICULT TO OPERATE | (1) Turn signal lever loose. (2) Switch yoke broken or distorted. (3) Loose or misplaced springs. (4) Foreign parts and/or materials in switch. (5) Switch mounted loosely. | (1) Tighten mounting screw. (2) Replace switch. (3) Reposition springs or replace switch. (4) Remove foreign parts and/or material. (5) Tighten mounting screws. |
| TURN SIGNAL WILL NOT INDICATE LANE CHANGE | (1) Broken lane change pressure pad or spring hanger. (2) Broken, missing or misplaced lane change spring. (3) Jammed wires. | (1) Replace switch. (2) Replace or reposition as required. (3) Loosen mounting screws, reposition wires and retighten screws. |
| TURN SIGNAL WILL NOT STAY IN TURN POSITION | (1) Foreign material or loose parts impeding movement of switch yoke. (2) Defective switch. | (1) Remove material and/or parts. (2) Replace switch. |

SEE I.S. NOTES




STEERING AND FRONT AXLE

STEERING COLUMNS



Disengage the remote rod from the lock rack.

Remove the screws attaching the shroud to the housing and remove the housing from the shroud.




84700

SEE
I.S.
N
O
T
E
S


NOTE: On vehicles with automatic transmission, the remote rod and shift quadrant light wire will be removed as an assembly along with the upper housing.

Remove the thrust cup (1) from the upper housing.



840770

Remove the wave washer from the key release lever pivot. Remove the key release lever and spring (1).



840321



STEERING AND FRONT AXLE


STEERING COLUMNS



Disengage the remote rod from the lock rack.

NOTE: On vehicles with automatic transmission, the remote rod and shift quadrant light wire will be removed as an assembly along with the upper housing.

Remove the upper bearing race (1) and bearing seat (2) from the steering shaft.




84745

Reinstall the tilt lever and place the column in the full upward tilt position.

WARNING: The tilt spring guide is under strong spring pressure.

Remove the tilt spring (1), guide and retainer (2) using a screwdriver. Press the retainer in and turn it counterclockwise until the retainer tabs align with the housing lugs. Be sure the screwdriver blade just fits into the retainer slot.




840334

Place the housing in the center (nontilt) position.

Remove the housing pivot pins using Tool J-21854-1 or equivalent.

SEE
I.S.
N
O
T
E
S



STEERING AND FRONT AXLE



MANUAL STEERING GEAR

GENERAL

The manual steering gear used on Jeep vehicles is a recirculating ball design. The steering gear wormshaft and ball nut are in line with the steering shaft in the column. The steering ratio of this unit is 24:1.


The steering gear wormshaft and column steering shaft are connected by a removable flexible coupling. The coupling permits independent removal of the steering gear or column.

The steering gear ball nut is mounted on the wormshaft and is driven through steel ball bearings which circulate in the spiral grooves machined in the wormshaft and ball nut. The bearings act as a rolling thread between the wormshaft and ball nut. The ball nut is directly engaged by the pitman shaft sector teeth.

SEE
I.S.
N
O
T
E
S

SPECIAL TOOLS


| Tool Ref. | Description | Required | Recommended |
|-----------|-----------------------|----------|-------------|
| J-2619-01 | Slide Hammer | | ■ |
| J-5755 | Bearing Cup Installer | | ■ |
| J-5822 | Bearing Cup Puller | | ■ |
| J-6632-01 | Pitman Arm Puller | | ■ |
| J-7754 | Torque Wrench | | ■ |



STEERING AND FRONT AXLE



MANUAL STEERING GEAR



84758

Cleaning and Inspection

Clean the housing and pitman shaft with solvent and dry using clean cloths or compressed air.

Inspect the housing for cracks, porosity, damaged threads and gasket surface scoring or distortion.

Inspect the pitman shaft bore contact surface and the sector teeth for wear, pitting, or other damage.


Insert the pitman shaft in the housing bore and check for shaft or housing bore wear. The shaft should exhibit a smooth, bind free fit and not display any visible side play when installed in the bore.

If the shaft appears loose and is not visibly worn, trial fit a replacement shaft in the housing bore. If the replacement shaft is also loose, replace the housing. However, if the replacement shaft fits properly, replace the pitman shaft.

Measure adjuster screw fit and end play in the pitman shaft T-slot. When installed, the screw must rotate freely and not bind in any position.

Measure end play by inserting a feeler gauge (7) between the screw head and the T-slot surface.

End play must not exceed 0.05 mm (0.002 in). If the end play exceeds the specified limit, select and install a replacement shim that will provide the specified clearance.



84759

Inspect the wormshaft upper bearing and bearing cup for wear, looseness, flat spots, pitting, cracks, or other damage. If either the bearing or bearing cup is damaged, both parts must be replaced.


If the cup is loose in the housing, trial fit a replacement cup. If the replacement cup is also loose, replace the housing. If the replacement cup fits properly, replace only the bearing cup.

SEE
I.S.
NOTES



STEERING AND FRONT AXLE

POWER STEERING GEAR



LEAK INSPECTION

The actual source of steering gear fluid leaks should always be determined before attempting repairs. Because an inaccurate diagnosis can result in ineffective repair, proper inspection procedure is necessary. The most common fluid leak sources are shown in the following diagrams.

SEE
I.S.
N
O
T
E
S



STEERING AND FRONT AXLE


POWER STEERING GEAR



Inspect the poppet check valve located under the pressure connector seat. Replace the valve if it is scored, cracked, chipped or deformed.

Inspect the ball plug (1) in the housing. If leakage past the ball occurred before disassembly or if it is raised above the housing surface, seat the ball in the housing using a punch; then spray the ball and housing with Loctite Solvent No. 7559, or an equivalent. Dry with compressed air and cover the ball and housing ball area with Loctite 290, or an equivalent sealer. Allow to cure for about two hours before installation.

Inspect the retaining ring grooves and seal surfaces. If they are chipped, scored, cracked or worn, replace the housing.



840363

Assembly


Clean the housing thoroughly in solvent.

Lubricate the housing bore, bearings, seals and washers with power steering fluid.

Install the needle bearing using Bearing Remover/Installer Tool J-21553 and Driver Handle J-8092. Install the bearing (1) in the housing bore until it is approximately 0.76 mm (0.030 in) below the shoulder in the housing bore.

CAUTION: Do not bottom the seal against the end of the housing counterbore.

Insert the single lip seal (2) and backup washer (3) in the housing bore. Using Seal Installer Tool J-21553, install the seal and washer in the bore only far enough to provide clearance for the double lip seal (4), backup washer (5), and retaining ring (6).




840365

SEE
I.S.
N
O
T
E
S



STEERING AND FRONT AXLE

POWER STEERING GEAR




Worm Shaft Bearing Preload

CAUTION: The following adjustment procedures must be performed exactly as described and in the sequence outlined. Failure to do so can result in damage to the gear internal components and improper steering response. Always adjust worm bearing preload first; then adjust pitman shaft overcenter drag torque.


Seat the adjuster plug firmly in the housing using Spanner Tool J-7624. Approximately 27 N·m (20 ft-lbs) torque is required to seat the housing.

Place an index mark (1) on the gear housing opposite one of the holes in the adjuster plug.



84802

Measure back (counterclockwise) 13 mm (1/2 in) from the index mark and remark the housing (2).



84803

Turn the adjuster plug counterclockwise until the hole in the plug is aligned with the second mark on the housing.

Install the adjuster plug locknut and tighten it with 115 N·m (85 ft-lbs) torque. Be sure the adjuster plug does not turn when tightening the locknut.

Turn the stub shaft clockwise to the stop, then turn the shaft back 1/4 turn.

SEE
I.S.
NOTES



STEERING AND FRONT AXLE



POWER STEERING PUMP

| Condition | Possible Cause | Correction |
|---|---|--|
| FOAMING MILKY POWER STEERING FLUID, LOW FLUID LEVEL AND POSSIBLE LOW PRESSURE | Further possible causes could be: (6) Sticking flow control valve (7) Insufficient pump pressure output (8) Excessive internal pump leakage (9) Excessive internal gear leakage | In order to diagnose conditions such as listed in (6), (7), (8), (9) a pressure test of the entire power steering system is required. (1) Check for leaks and correct. Bleed system. Extremely cold temperatures will cause system aeration should the oil level be low. If oil level is correct and pump still foams, remove pump from vehicle and separate reservoir from body. Check welsh plug and body for cracks. If plug is loose or body is cracked, replace body |
| | (1) Air in the fluid, and loss of fluid due to internal pump leakage causing overflow | |
| LOW PUMP PRESSURE | (1) Flow control valve stuck or inoperative. (2) Pressure plate not flat against cam ring | (1) Remove burrs or dirt or replace. Flush system. (2) Correct |
| MOMENTARY INCREASE IN EFFORT WHEN TURNING WHEEL FAST TO RIGHT OR LEFT | (1) Low oil level in pump. (2) Pump belt slipping (3) High internal leakage | (1) Add power steering fluid as required (2) Tighten or replace belt (3) Check pump pressure. (See pressure test) |
| STEERING WHEEL SURGES OR JERKS WHEN TURNING WITH ENGINE RUNNING ESPECIALLY DURING PARKING | (1) Low oil level (2) Loose pump belt (3) Steering linkage hitting engine oil pan at full turn (4) Insufficient pump pressure (5) Sticking flow control valve | (1) Fill as required (2) Adjust tension to specification (3) Correct clearance (4) Check pump pressure. (See pressure test). Replace flow control valve if defective (5) Inspect for varnish or damage, replace if necessary |
| EXCESSIVE WHEEL KICKBACK OR LOOSE STEERING | (1) Air in system | (1) Add oil to pump reservoir and bleed by operating steering. Check hose connectors for proper torque and adjust as required |

SEE
I.S.
N
O
T
E
S




STEERING AND FRONT AXLE



STEERING LINKAGE

The connecting rod is threaded on one end and has a ball-end assembly at the opposite end. An adjusting tube and removable ball end complete the connecting rod assembly. It is attached to the right hand steering arm. The threaded end, with the adjusting tube and removable ball end, is attached to the pitman arm.



840811

SEE
I.S.
NOTES

TORQUE SPECIFICATIONS

| Component | Service Set-To Torque | Service Recheck Torque |
|--|-------------------------|------------------------------|
| Connecting Rod Clamp Bolt | 16 N·m (12 ft-lbs) | 14-20 N·m (10-15 ft-lbs) |
| Connecting Rod End-to-Pitman Arm Nut (9/16-18) | 81 minimum (60 minimum) | |
| Pitman Arm-to-Pitman Shaft Nut | 251 N·m (185 ft-lbs) | 217-285 N·m (160-210 ft-lbs) |
| Steering Damper Bracket U-Bolts | 16 N·m (12 ft-lbs) | 11-20 N·m (8-15 ft-lbs) |
| Steering Damper Locknut (3/8-24) | 30 N·m (22 ft-lbs) | 22-38 N·m (16-28 ft-lbs) |
| Steering Damper Locknut (7/16-20) | 41 N·m (30 ft-lbs) | 33-49 N·m (24-36 ft-lbs) |
| Upper Ball Stud Retaining Nut | 136 N·m (100 ft-lbs) | |
| Lower Ball Stud Jamnut | 108 N·m (80 ft-lbs) | |
| Upper Ball Stud Split Ring Seat | 68 N·m (50 ft-lbs) | |
| Tie Rod Clamp Bolt (5/16-24) | 16 N·m (12 ft-lbs) | 14-20 N·m (10-15 ft-lbs) |
| Tie Rod Stud Nuts | 54 minimum (40 minimum) | |
| Wheel Nuts | 102 N·m (75 ft-lbs) | 88-122 N·m (65-90 ft-lbs) |



STEERING AND FRONT AXLE



FRONT AXLE

AXLE HOUSING SERVICE

The front axle housing should be inspected periodically for weld cracks or other damage that could cause loss of lubricant, affect driving characteristics, or result in front end misalignment.

NOTE: If the vehicle is driven through water that is deep enough to cover the front hubs, the steering knuckles and brake components should be disassembled and inspected for water-dirt contamination and water damage. All the components should be cleaned thoroughly, examined carefully, and lubricated as necessary before assembly. During the inspection, pay particular attention to the axle bearings, spindle bearings and brake components. Damaged or contaminated parts should be replaced.

FRONT WHEEL ALIGNMENT

Toe-in and caster are the only adjustable front alignment angles. Camber is built into the axle during manufacture and cannot be adjusted.

An alignment rack should be used to check the alignment angles. The use of a rack will ensure more accurate readings and avoid the possibility of incorrect adjustments.

Toe-in is adjusted by lengthening or shortening the steering tie rod. Caster is adjusted by installing tapered shims between the front axle spring mounting pad and front spring. Refer to Front Wheel Alignment for measurement and adjustment procedures.

HIGH STEERING EFFORT

High steering effort or slow return of the steering mechanism after turns may be the result of excessive steering knuckle ball stud preload. If this condition occurs and all other items

affecting the steering effort are functioning normally, the ball stud preload should be checked as follows.

Ball Stud Preload Measurement

Raise the vehicle.

Remove the front wheels.

If the vehicle has a steering damper, disconnect the damper at the tie rod and move the damper aside.

Unlock the steering column.

Disconnect the steering connecting rod. Disconnect the connecting rod at the right-side steering knuckle.

Remove the cotter pin and retaining nut attaching the tie rod to the right-side steering knuckle. Discard the cotter pin.

Rotate both the steering knuckles through a complete arc several times. Work from the right side of the vehicle to rotate the knuckles.

Assemble a socket and 68 N·m (0-50 ft-lbs) capacity torque wrench and install the wrench on the tie rod retaining nut.

NOTE: The torque wrench must be positioned at a 90 degree angle to the steering knuckle arm to obtain an accurate reading.

Rotate the knuckles slowly and steadily through a complete arc and measure the torque required to rotate the knuckles:

- if the reading is less than 34 N·m (25 ft-lbs), turning effort is within the specifications and

SEE
I.S
N
O
T
E
S



STEERING AND FRONT AXLE



FRONT AXLE

Install the wheels.

Remove the support stands and lower the vehicle.

Check the front wheel alignment.

Check the turning angle.

TURNING ANGLE ADJUSTMENT

The turning angle stopscrews are located at the rear of the steering knuckle just above the axle centerline. If adjustment is necessary, proceed as follows.

SEE
I.S.
N
O
T
E
S

Loosen the locknut on the turning angle stopscrew.

Using a turntable to measure the angle, adjust the stopscrew to obtain the proper turning angle (see Specifications).

Tighten the stopscrew locknut.

NOTE: Turning the adjusting screw inward increases the turning angle. Turning the screw outward decreases the turning angle.

Turning Angle Specifications

Set the turning angle at 30-31 degrees.


DIFFERENTIAL OVERHAUL

Specifications

Differential Specifications Model 30 Front Axle

| | |
|--|-----------------------------|
| Differential Bearing Preload | 0.38mm (.015 in) |
| Differential Side Gear-to- Case Clearance | 0.000-0.15mm (.000-.006 in) |
| Ring Gear | 0.12-0.22mm (.005-.009 in) |
| Pinion Bearing Break-Away Preload | |
| Original Bearings | 2-3 N·m (15-25 in-lbs) |
| New Bearings | 2-5 N·m (20-40 in-lbs) |


841321



STEERING AND FRONT AXLE



FRONT AXLE



84848

Raise the spring and install the front spring shackle to the spring attaching bolts.

Remove the jack stand.

Install the tie plate and U-bolts. Tighten the U-bolt nuts as follows:

1/2-20 – 75 N·m (55 ft-lbs)

9/16-18 – 136 N·m (100 ft-lbs)

Tighten the spring shackle to the spring attaching bolts on CJ and Scrambler models with 33 N·m (24 ft-lbs) torque.

Install the stabilizer bar link to the tie plate attaching nut.

Install the shock absorber. Tighten the shock absorber to the tie plate retaining nut with 61 N·m (45 ft-lbs) torque.

Install the axle shafts.

Install the axle housing cover.

Fill the axle with the specified lubricant.

SEE
I.S.
N
O
T
E
S




REAR AXLE

GENERAL DESCRIPTION



Remove the axle hub using Puller J-25109-01 (1).



840479

SEE
I.S.
NOTES

Inspection

Inspect the hub for loose or distorted wheel mounting studs and inspect the keyway and tapered bore for wear, damaged serrations or cracks. Replace the hub if worn or damaged.

Installation

NOTE: The methods for installing original and replacement hubs are different. Refer to the following two procedures for the appropriate installation method.

Original Hub Installation

Align the keyway in the hub with the axle shaft key and slide the hub onto the shaft as far as possible.

Install the axle shaft thrust washer and nut.

Install the brake drum and drum retaining screws. If the brakeshoes were retracted to ease drum removal, adjust the drum-to-brakeshoe clearance before installing the drum. Refer to the Service Brake Adjustment section.

Install the wheel.

Lower the vehicle.

Apply the parking brake.

Tighten the axle shaft nut with 339 N·m (250 ft-lbs) torque.

Install a replacement cotter pin in the nut. If the cotter pin hole is not aligned, tighten the nut to the next castellation. Do not loosen the nut to align the cotter pin hole.

Release the parking brake.

Raise vehicle, remove wheel and install axle shaft dust cap and reinstall the wheel and lower vehicle.

Replacement Hub Installation

NOTE: When a replacement axle shaft is installed, a replacement hub must also be installed. However, a replacement hub may be installed on an original axle shaft if the shaft serrations are not worn or damaged.

Align the keyway in the hub with the axle shaft key and slide the hub onto the shaft as far as possible.




REAR AXLE



STANDARD DIFFERENTIAL OVERHAUL


Remove the pinion shaft lockpin (3) using a punch that is 76-mm long by 5-mm in diameter (3-in. long by 3/16-in. in diameter) (4).



Measure and record the differential side gear-to-case, clearance for assembly reference. Insert equal thickness feeler gauges between each gear and case to measure the clearance.

NOTE: To ensure an accurate measurement, do not remove either feeler gauge until the clearance at both gears has been measured.

Remove the pinion shaft (1) using a punch and hammer and remove the thrust block (2).




Rotate the pinion gears on the side gears until the pinion gears are aligned with the case opening. Remove the pinion gears and thrust washers and remove the side gears and thrust washers.

Remove the pinion nut using Tools J-8614-01.

Remove the axle yoke using Tools J-8614-01, 02 and 03.

Install the axle housing cover to prevent the pinion gear from falling out of the housing during removal.

SEE
I.S.
NOTES



REAR AXLE

STANDARD DIFFERENTIAL OVERHAUL



Axle Assembly

Install the axle housing cover.

Install the propeller shaft. Align the yoke and the shaft using the reference marks made at disassembly.

Install the axle shafts, oil seals and retainers, shaft bearing end play shims, brake support plates, hubs, drums and wheels.

Check and correct the axle shaft end play as necessary. Refer to Axle Shaft End Play Adjustment procedure in this chapter.

Fill the axle with AMC/Jeep Rear Axle Lubricant, 75W-90, grade API GL-5.

Connect all brake lines and bleed the brakes.

Remove the supports and lower the Vehicle.

SEE I.S. NOTES



SPECIAL TOOLS

| Tool Ref. | Description | Required | Recommended |
|------------------|---------------------------|----------|-------------|
| J-24649-1 | Yoke Runout Gauge | | ■ |
| J-25512-2 | Lube Fitting Adapter Tool | | ■ |

TORQUE SPECIFICATIONS

| Component | Service Set-To Torque | Service Recheck Torque |
|----------------------------------|---|--------------------------|
| Pinion Yoke Nut | Add 0.56 N·m (5 in-lbs) torque measured at disassembly. | |
| Universal Joint Clamp Strap Bolt | 20 N·m (15 ft-lbs) | 18-24 N·m (13-18 ft-lbs) |

Universal Joint Angle Chart

| | Front | | Rear | |
|------------------|----------|--------|----------|--------|
| | OK Range | Set-To | OK Range | Set-To |
| CJ/ Scrambler | 3°-5° | 4° | 4°-6° | 5° |

840942

SEE
I.S.
N
O
T
E
S

| | | |
|--|-------------------|--|
|  | SUSPENSION |  |
| WHEELS AND TIRES | | |

SPECIAL TOOLS

| Tool Ref. | Description | Required | Recommended |
|----------------|--------------------------|----------|-------------|
| J-25103 | Wheel Bearing Nut Wrench | | ■ |

TORQUE SPECIFICATIONS


| Component | Service Set-To Torque | Service Recheck Torque |
|-------------------------------|-----------------------|------------------------------|
| Caliper Mounting Pins | 20 N·m (15 ft-lbs) | 20-24 N·m (15-18 ft-lbs) |
| Wheel Retaining Nuts | 115 N·m (85 ft-lbs) | 88-122 N·m (65-90 ft-lbs) |
| Outer Locknut | 68 N·m (50 ft-lbs) | 68 N·m min. (50 ft-lbs min) |
| Inner Locknut (Adjusting Nut) | 68 N·m (50 ft-lbs)* | 68 N·m min. (50 ft-lbs min) |

*Back off 1/6 turn (45° - 65°) while rotating the wheel

GENERAL

Tire Construction

Standard equipment tires on the CJ-7 and Scrambler models are of the radial-ply construction. Radial-ply tires have belts (1) under the tread (2) which encircle the tire and extend from tread shoulder to tread shoulder. However, these tires are constructed with the body cord plies at right angles to the tread centerline. The plies cross the tread centerline at an angle of approximately 90 degrees. Because the body cord plies radiate from the tread centerline, this type of construction is designated radial-ply.



840626


SUSPENSION

WHEELS AND TIRES

TIRE REPAIR

Punctured tires should be removed from the wheel and permanently repaired from the inside using a combination repair plug and vulcanized patch. When repairing punctures, always follow the manufacturer's instructions for repair kit installation.

Punctures are repairable only in the tread area (1).



84860

SEE
I.S.
N
O
T
E
S

Never attempt to repair punctures in the tire shoulders or sidewalls. In addition, never attempt to repair any tire that has sustained the following damage:

- bulges or blisters
- ply separations
- broken, cut or cracked beads
- fabric cracks or cuts

- tires worn to the fabric or if wear indicators are visible
- punctures larger than 6 mm (1/4 in) in diameter

Externally applied repair plugs, blowout patches and aerosol sealants should be considered as emergency-type repairs only. Tires repaired in this fashion should not be driven at speeds over 64 km/h (40 mph) or for more than 121 km (75 mi) before a permanent repair is made.

WHEEL MAINTENANCE AND CONDITION



The condition of the wheels should be checked frequently. Replace any wheel that is cracked, bent, severely dented, has excessive runout or has broken welds. The tire inflation valve should also be inspected frequently for wear, leaks, cuts or looseness and should be replaced if damaged or worn.

Clean all the wheels with a mild soap and water solution only and rinse thoroughly with water. Never use abrasive or caustic materials, especially on aluminum or chrome-plated wheels, as the surface will be etched or the plating severely damaged. After cleaning aluminum or chrome-plated wheels, apply a coating of protective wax to preserve the finish and lustre.

WHEEL BALANCING

Wheel balancing may be performed using on- or off-vehicle equipment. However, when using on-vehicle balancing equipment, observe the following precautions:


- on vehicles with a Trac-Lok rear axle, do not use on-vehicle equipment to balance the rear wheels; instead, remove the wheels and

| | | |
|--|--|--|
|  | <h2 style="margin: 0;">BRAKE SYSTEM</h2> <h3 style="margin: 0;">GENERAL DESCRIPTION</h3> |  |
|--|--|--|

The brake system utilizes front disc and rear drum braking surfaces.

The brake hydraulic system consists of a dual reservoir master cylinder (1), combination valve (2), front disc brake calipers (3), rear drum brake wheel cylinders (4), and the connecting brake pipes, hoses and fittings.

The primary piston in the master cylinder transfers pressure to the front brakes. The secondary master cylinder piston transfers pressure to the rear brakes.




70166

SPECIAL TOOLS


| Tool Ref. | Description | Required | Recommended |
|-------------------|---------------------------------------|----------|-------------|
| J-8002 | Wheel Cylinder Clamps | | ■ |
| J-8057 | Brake Spring Plier Tool or Equivalent | | ■ |
| J-21177-01 | Drum Brake Clearance Gauge | | ■ |
| J-25103 | Wheel Bearing Nut Wrench | | ■ |
| J-26869 | Metering Valve Tool (Type-W Valve) | | ■ |
| J-33028 | Dust Boot Installer | ■ | |

SEE I.S. NOTES



BRAKE SYSTEM

DIAGNOSIS



J. VEHICLE MOVES TO ONE SIDE WHEN BRAKES ARE APPLIED (cont'd.)

POSSIBLE CAUSES

- (10) Loose suspension component attaching or mounting bolts.
- (11) Brake combination valve failure.

CORRECTIONS

- (10) Tighten suspension bolts. Replace worn suspension components.
- (11) Replace combination valve.

K. CHATTER OR SHUDDER WHEN BRAKES ARE APPLIED (Pedal pulsation and roughness may also occur.)

POSSIBLE CAUSES

- (1) Brakeshoes distorted, bent, contaminated, or worn.
- (2) Caliper anchor plate or support plate loose.
- (3) Excessive thickness variation of rotor(s).

CORRECTIONS

- (1) Replace brakeshoes in axle sets.
- (2) Tighten mounting bolts.
- (3) Refinish or replace rotors in axle sets.

L. NOISY BRAKES (Squealing, clicking, scraping sound when brakes are applied.)

POSSIBLE CAUSES

- (1) Bent, broken, distorted brakeshoes.
- (2) Excessive rust on outer edge of rotor braking surface.
- (3) Brakelining worn out — shoes contacting drum or rotor.
- (4) Broken or loose holdown or return springs.
- (5) Rough or dry drum brake support plate ledges.
- (6) Cracked, grooved, or scored rotor(s) or drum(s).
- (7) Incorrect brakelining and/or shoes (front or rear).

CORRECTIONS

- (1) Replace brakeshoes in axle sets.
- (2) Remove rust.
- (3) Replace brakeshoes and lining in axle sets. Refinish or replace drums or rotors.
- (4) Replace parts as necessary.
- (5) Lubricate support plate ledges.
- (6) Replace rotor(s) or drum(s). Replace brakeshoes and lining in axle sets if necessary.
- (7) Install specified shoe and lining assemblies.

M. PULSATING BRAKE PEDAL

POSSIBLE CAUSE

- (1) Out of round drums or excessive lateral runout in disc brake rotor(s).

CORRECTION

- (1) Refinish or replace drums, re-index rotors or replace.

SEE
I.S.
N
O
T
E
S



SPECIAL TOOLS

| Tool Ref. | Description | Required | Recommended |
|----------------|--------------------------|----------|-------------|
| J-25103 | Wheel Bearing Nut Wrench | | ■ |

TORQUE SPECIFICATIONS

| Component | Service Set-To Torque | Service Recheck Torque |
|-----------------------------|-------------------------|---------------------------|
| Caliper Mounting Pins | 40 N·m (30 ft-lbs) | 34-47 N·m (25-35 ft-lbs) |
| Wheel Lug Nuts | 102 N·m (75 ft-lbs) | 88-108 N·m (65-80 ft-lbs) |
| Wheel Bearing Outer Locknut | 68 N·m (50 ft-lbs) min. | |
| Outer Bearing Inner Locknut | 68 N·m (50 ft-lbs)* | |

*Back off 1/6 turn while rotating the wheel.

REMOVAL

Raise and support the vehicle.

Remove the wheel.

Remove the caliper. Refer to Rear Brakeshoe Removal and Installation.

Remove the bolts attaching the hub body to the hub clutch and remove the hub body.

Remove the retaining ring from the axle shaft and remove the hub clutch and bearing assembly.

Straighten the lip of the outer locknut retaining washer.

Remove the outer locknut and retaining washer and remove the inner locknut and retaining washer.

Remove the hub and rotor.

Remove the wheel bearings from the rotor.


INSPECTION

Raise and support the front of the vehicle.

Remove the front wheels.


Remove the caliper (do not disconnect the brake line).

SEE I.S. NOTES



BRAKE SYSTEM


REAR WHEEL CYLINDER



REMOVAL

Raise and support the rear of the vehicle and remove:

- the wheel lug nuts
- the wheel
- the brakeshoes
- the pipe fitting (1) from the wheel cylinder
- the wheel cylinder attaching bolts (2), and the wheel cylinder




84047

INSTALLATION

CAUTION: Wipe the end of the pipe fitting (1) to remove foreign matter before connecting it to the wheel cylinder.

Position the wheel cylinder (3) on the backing plate and connect the pipe fitting to the wheel cylinder. Hand tighten the connection only.

Install the wheel cylinder attaching bolts (4). Tighten the mounting bolts with the specified torque.



84048


Using a pipe fitting wrench, tighten the brake pipe fitting at the wheel cylinder with the specified torque.

Install the brakeshoes.


Adjust the brakes, center the shoes and install:

- the brake drum
- the wheel
- the wheel lug nuts

SEE
I.S.
NOTES



HEATING AND AIR CONDITIONING



HEATING SYSTEM

Service Diagnosis

| Condition | Possible Cause | Correction |
|---|--|--|
| BLOWER MOTOR WILL NOT TURN AT ANY SPEED | <ol style="list-style-type: none">(1) Blown fuse(2) Loose connection(3) Defective ground(4) Faulty switch(5) Faulty motor(6) Faulty resistor | <ol style="list-style-type: none">(1) Replace fuse(2) Inspect and tighten(3) Clean and tighten(4) Replace switch(5) Replace motor(6) Replace resistor |
| BLOWER MOTOR TURNS AT ONE SPEED ONLY | <ol style="list-style-type: none">(1) Faulty switch(2) Faulty resistor | <ol style="list-style-type: none">(1) Replace switch(2) Replace resistor |
| BLOWER MOTOR TURNS BUT DOES NOT CIRCULATE AIR | <ol style="list-style-type: none">(1) Intake blocked(2) Fan not secured to the motor shaft | <ol style="list-style-type: none">(1) Clean intake(2) Tighten securely |
| HEATER WILL NOT HEAT | <ol style="list-style-type: none">(1) Coolant does not reach proper temperature(2) Heater core blocked internally(3) Heater core air-bound(4) Blend-air door not in proper position | <ol style="list-style-type: none">(1) Check and replace thermostat if necessary(2) Flush or replace core if necessary(3) Purge air from core(4) Adjust cable |
| HEATER WILL NOT DEFROST | <ol style="list-style-type: none">(1) Control cable adjustment incorrect(2) Defroster hose damaged | <ol style="list-style-type: none">(1) Adjust control cable(2) Replace defroster hose |

80587A


SEE
I.S.
N
O
T
E
S




HEATING AND AIR CONDITIONING



AIR CONDITIONER SYSTEM




When the valve stem (B) is turned clockwise to the front-seated (full-in) position, the the compressor is isolated from the system. This position is used for removing the compressor or for checking the compressor oil level.



When the valve stem (C) is mid-positioned, the gauge port is open. This position is used for charging, discharging, evacuating and checking the system pressure.

Discharge Service Valve Adapters

When it is necessary to connect a service hose to the discharge service valve, one of the adapters listed in the chart is required.




Discharge Service Valve Adapters

| MANUFACTURER | PART NUMBER | | |
|--------------|-------------|-------------|--------|
| | Straight | Right Angle | Flex |
| Kent Moore | J-25498 | J-25499 | — |
| K-D Tools | KD-2409 | — | — |
| Draf Tools | AC 354 | — | AC 355 |

83093


SEE
I.S.
N
O
T
E
S

1. To Service Port
2. To Hose
3. To Compressor




HEATING AND AIR CONDITIONING

AIR CONDITIONER SYSTEM



When installing a replacement temperature control thermostat, insert the capillary tube (1) into the evaporator coil (2) a minimum of 5 cm (2 in).

CAUTION: Handle the tube with care to avoid bends or kinks that could cause the thermostat to malfunction.



1. Capillary Tube – Insert into Coil a Minimum of 5.1 cm (2 in)
2. Evaporator Coil
3. Insulation
4. Upper Part of Case

41094

CONDENSER

Removal

Discharge the refrigerant from the system. Refer to the discharge procedure.

NOTE: Discharge the system slowly to prevent loss of compressor oil.

WARNING: Do not loosen the radiator draincock when the cooling system is hot and pressurized because serious burns from hot coolant can result.

Drain the radiator. Drain the coolant into a clean container.

Remove the fan shroud and radiator.

Disconnect the pressure pipe fitting from the condenser.

Remove the condenser attaching screws and tilt the bottom of the condenser toward the engine.

NOTE: Plug all the open connections to prevent entry of dirt and moisture.

From the underside of the vehicle, disconnect the receiver/drier-to-evaporator hose fitting from the receiver/drier.

Remove the condenser and receiver/drier as an assembly.

Remove the receiver/drier from the condenser, if necessary.

Installation

If removed, attach the receiver/drier to the condenser.

Place the condenser in position and connect the receiver/drier-to-evaporator hose fitting to the receiver/drier.

Install the condenser attaching screws.

Connect the pressure pipe fitting to the condenser.

Install the radiator and fan shroud.

SEE
I.S.
NOTES




HEATING AND AIR CONDITIONING

AIR CONDITIONER SYSTEM



Insert Seal Sleeve Protector J-29640 over the compressor shaft.




CAUTION: Do not touch the replacement seal lapping surfaces.

Dip the mating surfaces of the seal lapping surfaces in clean compressor oil.


Engage the slots of Seal Removal and Installation Tool J-29639 in the slots in the seal cage and insert the seal assembly firmly into place in the compressor seal cavity.

SEE
I.S.
NOTES



Twist the tool in the opposite direction to disengage the tool from the seal cage.

CAUTION: When installing the shaft seal O-ring, do not scratch the O-ring groove with the O-ring hook.



ACCESSORIES

STORAGE COMPARTMENT




GENERAL

A storage compartment is available on all CJ models.

The storage compartment can be locked with a key. It is also bolted to the body side panels for added security.


Removal

Open the storage compartment and remove the attaching screws and washers (1).



840958

SEE
I.S.
NOTES



ACCESSORIES

RADIO SOUND SYSTEMS



0.5-capacitor installed at the battery connection of the switch or the flasher. It is less likely, but possible, that the low frequency components of the interruptions are reaching audio stages of the radio. The test is to check if the noise is present with the volume control turned down. If so, install a 1000-mfd condenser.

Horn Noise

The diagnosis and cure for a growling noise in the radio when the horn is operated is the same as for Turn Signals and Stop Lamps. The suppressor capacitors are installed at the point where the battery lead feeds the horn relay.

Be sure the horn relay cover is not loose.

Accessories

Electric windshield wipers, blower motors, window regulator motors, or any brush-type motors, generally can be suppressed by installing 0.25-mfd capacitors at the terminals.

ANTENNAS


AM and AM/FM Models

The mast of the antenna is not grounded. The base of the antenna is grounded to the vehicle sheet metal. The coaxial shield (the wire mesh) surrounding the center conductor wire of the antenna lead-in cable is grounded to the radio and the antenna base.

Tests

There are three antenna tests to be made with the use of an ohmmeter:

- mast to ground
- tip of the mast to the tip of the conductor
- body ground to the battery ground



85118




I.S.

INFORMATIONS SERVICE
SERVICE INFORMATION
SERVICE-INFORMATIONEN
SERVICE INFORMATION
INFORMACIONES SERVICIO
INFORMAZIONI SERVIZIO
SERVICEINFORMASJONER
SERVICE INFORMATIE
SERVICEINFORMATION
INFORMAÇÃO SERVIÇO

3E

MAY 1984
ENGLISH EDITION

CJ/SCRAMBLER



ENGINES — FUEL SYSTEMS

Attention: Workshop and Parts Department

FOUR-CYLINDER ENGINE COLD OPERATION

Information

The choke on some 1984 four-cylinder YFA carburetors, may open too quickly after cold starts resulting in poor cold engine operation.

Service correction involves changing choke opening time as outlined in the following procedure.

Procedure

1. Remove the carburetor as outlined on page B-208 of the M.R. 252 manual.
2. Disconnect the vacuum break supply hose from the vacuum supply tube in the carburetor base (Fig. 1).
3. Increase the diameter of the orifice in the vacuum supply tube with a 7/64-in. (0.109-in.) drill bit (Fig. 1).

NOTE: Be sure to remove all chips with compressed air after drilling out the orifice.




Fig. 1




I.S.

INFORMATIONS SERVICE
SERVICE INFORMATION
SERVICE INFORMATIONEN
SERVICE INFORMATION
INFORMACIONES SERVICIO
INFORMAZIONI SERVIZIO
SERVICEINFORMASJONER
SERVICE INFORMATIE
SERVICEINFORMATION
INFORMAÇÃO SERVIÇO

7E

**JULY 1985
ENGLISH EDITION**

1986 CJ MODELS



GENERAL

Attention: Workshop, Parts Department

WORKSHOP MANUAL UPDATE AND REVISIONS

This I.S. Note contains information unique to 1986 Jeep CJ models. Only those items that apply to 1986 CJ models are outlined in this I.S. Note. All other service information in the M.R. 252 remains unchanged. The only M.R. 252 section affected by these updates/revisions is the specification and identification section of the GENERAL chapter.


Filing Instructions

- File this I.S. Note in the M.R. 252 Manual



AUTOMATIC TRANSMISSIONS


OVERHAUL



SPECIAL TOOLS


| Tool Ref. | Description | Required | Recommended |
|-------------------|---|----------|-------------|
| J-24040-A | Input Shaft Bushing Installer (727) | ■ | |
| J-24041-A | Input Shaft Bushing Remover (727) | ■ | |
| J-24042 | Front Clutch Spring Compressor and Overrunning Clutch Cam Installer (727) | ■ | |
| J-24044 | Detent Ball Retainer | ■ | |
| J-24045 | Pump Rotor Alignment Tool (727) | ■ | |
| J-24048 | Extension Housing Bushing Remover/Installer (727) | ■ | |
| J-24049-A | Oil Pump Bushing Remover/Installer | ■ | |
| J-24055 | Oil Pump Bushing Remover/Installer (727) | ■ | |
| J-24063-01 | Kickdown Band Adjustment Adapter | ■ | |
| J-24064 | Front Clutch Bushing Remover/Installer | ■ | |
| J-24108-A | Pilot Studs | ■ | |
| J-5853-B | Torque Wrench (0-250 in-lbs) | | ■ |
| J-8001 | Dial Indicator Set | | ■ |
| J-24026 | Transmission Holding Fixture | | ■ |
| J-9617 | Front Pump Oil Seal Installer | ■ | |
| J-3387-2 | Pilot Studs | ■ | |
| J-21005-01 | Front Pump Oil Seal Installer (727) | ■ | |
| J-21232-01 | Front Pump Oil Seal Remover | ■ | |
| J-22205 | Front Pump Oil Seal Remover (Legs) | ■ | |
| J-23327 | Front Clutch Spring Compressor | ■ | |
| J-24031 | Kickdown Valve Gauge | ■ | |

SEE
I.S.
N
O
T
E
S




AUTOMATIC TRANSMISSIONS

OVERHAUL



SEE
I.S.
NOTES



84462

NOTE: Tag the springs and valves for reassembly reference.

Remove the upper and lower screws from the spring retainer and adjustment screw bracket (1). Hold the spring retainer firmly against the spring force while removing the last screw.

Remove the spring retainer line (2) and the throttle pressure adjusting screws (3). Do not disturb the screw settings. Remove the line

pressure (4) and torque converter valve regulator springs (5). Tag the springs for assembly reference.

Remove the line pressure regulator (6) and torque converter control valves (7).

Install Detent Ball Retainer Tool J-24044 around detent ball casing (8).



AUTOMATIC TRANSMISSIONS

OVERHAUL



Install the fail-safe valve (7) and spring (8) into the housing.

Install the lockup valve (5) and spring (6) into the housing.

Install the end plate and attaching screws (4).

Install lockup module housing (3) and oil tube (1) to the valve body (2).

Install attaching screws.

Install the oil filter.

Measure the throttle and line pressure settings.

NOTE: If pressures were satisfactory before disassembly, do not change the line or throttle pressure adjusting screw settings.

Valve Body Without Lock-Up


Disassembly

CAUTION: Do not clamp any part of the valve body or transfer plate in a vise. Any slight distortion of the body or plate will cause sticking valves or excessive leakage or both. When removing and installing valves or plugs, slide them in or out very carefully. Do not use force to remove or install valves.

NOTE: When disassembling the valve body, identify all valve springs with a tag for assembly reference.

Remove the oil filter attaching screws (A) and oil filter (B).

NOTE: The oil filter screws are longer than the transfer plate screws.



84476

Remove the transfer plate assembly retaining screws and remove the transfer plate assembly (1).

Remove the screws attaching the stiffener and separator plates to the transfer plate and separate these parts.

SEE
I.S.
N
O
T
E
S



AUTOMATIC TRANSMISSIONS

OVERHAUL




SEE
I.S.
NOTES

Valve Body Hydraulic Control Pressure Adjustments

There are two hydraulic control pressure adjustments that can be performed on the valve body, they are: Line pressure and throttle pressure adjustment.

Because line and throttle pressure are interdependent (each affects shift quality and timing), both adjustments must be performed properly and in the correct sequence which is; line pressure adjustment first – throttle pressure adjustment last.



84487

Line Pressure Adjustment

Measure the distance from the valve body to the inner edge of the adjusting screw using the accurate steel scale.

The distance measured should be 33.4 mm (1-5/16 inches).

If adjustment is required, turn the adjusting screw (A) in or out to obtain 33.4 mm (1-5/16 inch) setting.

NOTE: The 33.4 mm (1-5/16 inches) setting is an approximate setting. Because of manufacturing tolerances, it may be necessary to vary from this dimension to obtain the desired pressure. One complete turn of the adjusting screw changes line pressure approximately 9kPa (1-2/3 psi). Turning the adjusting screw counterclockwise increases pressure while turning the screw clockwise decreases pressure.




AUTOMATIC TRANSMISSIONS

OVERHAUL



Thread the Bushing Installer Tool J-24038 onto Driver Handle J-8092.



84508

Position the replacement bushing on the installer tool and install the bushing straight into the shaft bore until the tool bottoms.

Assembly

Install the pump rotors in the housing.

Install the reaction shaft support and tighten the attaching bolts to 18 N·m (160 in-lbs) torque.


Install the O-ring seal around the pump housing flange.

Install the oil seal pump housing with the seal lip facing inward.

Install the oil seal on Installer Tool J-21005.

Install the seal straight into the housing until the tool bottoms.

Thoroughly clean the reaction shaft support assembly.



AUTOMATIC TRANSMISSIONS

OVERHAUL



SEE
I.S.
NOTES

Inspection

Inspect the friction material on driving discs. Replace all discs that are charred, glazed, heavily pitted, flaking or if the friction material can be scraped off easily. Inspect the driving disc inner splines for wear or other damage.

Inspect the steel plates and pressure plate surfaces for over heating, scoring, and damaged driving lugs. Inspect all discs and plates for distortion. Replace warped or coned discs or plates.

Inspect the steel plate lug grooves in the retainer for smooth surfaces. The plates must slide freely in these grooves. Inspect the clutch piston ball check. The ball should move freely in its cage. Inspect the seal ring surfaces in the clutch retainer for nicks or deep scratches. Light scratches will not interfere with sealing. Inspect the piston spring, wave spring, and spacer for distortion or breakage.

Inspect the seal ring grooves in the input shaft and piston retainer for nicks, burrs, and wear.

Inspect the rear clutch to front clutch thrust washer. The washer should be 1.55 to 1.60 mm (0.061 to 0.063 in) thick.

Input Shaft Bushing Replacement – Model 727


Clamp the input shaft in a vise using brass protective jaws.

CAUTION: Do not clamp the seal ring land or bearing journal.

Thread Bushing Remover Tool J-24041 straight into the bushing as far as possible by hand.

Using a wrench, thread the puller into the bushing three to four additional turns to fully engage the puller threads into the bushing.

Thread Slide Hammer Bolts Tool J-7004-3 into the puller.



84523

Bump outward with the slide hammers to remove the bushing.

Thoroughly clean the input shaft and remove any chips generated by the bushing removal.


Grip the old bushing with pliers and remove it from the tool.

NOTE: Be careful to protect the remover tool threads when using the tool.



AUTOMATIC TRANSMISSIONS

OVERHAUL



Remove the light, position the support (1) over the pilot studs and install the support in the case using a wooden block and hammer.

Install and tighten the support attaching bolts to 17 N·m (150 in-lbs) torque.


Cam Replacement – Model 727

The overrunning clutch cam and spring retainer should be removed only if replacement is necessary.

Remove the setscrew from the case.

Remove the bolts attaching the output shaft support to the rear of the case.

Insert a punch through the bolt holes and drive the cam (A) out of the case.




84533

NOTE: Move the punch from one bolt hole to another in a clockwise direction after each punch stroke to drive the cam out of the case evenly.

CAUTION: The output shaft support must be installed in the case before the overrunning clutch cam can be installed. If the support must be replaced, drive it out the rear of the case using a wooden block and hammer.

Thread two Pilot Stud Tools J-3387-2 into the case.




84534

SEE
I.S.
N
O
T
E
S



AUTOMATIC TRANSMISSIONS

OVERHAUL



SEE
I.S.
NOTES

Rear Band Adjustment

Loosen the locknut and back the nut off five turns.

Tighten the band adjusting screw to the specified torque.

CAUTION: If Adapter Tool J-24063 is used to adjust the band, tighten the adjusting screw to one half the specified torque only.

Back off the adjusting screw to specifications.

Hold the adjusting screw in position and tighten the locknut to the specified torque.

Install the oil pan and gasket.

Front Band Adjustment

Loosen the locknut and back the nut off five turns.


Be sure the band adjusting screw turns freely in the case. Lubricate the screw, if necessary.

Tighten the band adjusting screw to the specified torque using Torque Wrench J-5853 and an 8 mm (5/16 in) square socket.

CAUTION: If Adapter Tool 2-24063 is used to adjust the band, tighten the adjusting screw to one half the specified torque only.


Back off the adjusting screw to specifications.

Hold the adjusting screw in position and tighten the locknut to the specified torque.




T4/5 MANUAL TRANSMISSION

T4 MANUAL TRANSMISSION OVERHAUL




Remove the countershaft rear bearing (19) with a brass drift (20) and arbor press. Note the position of the bearing for assembly reference. The bearing identification numbers face outward when the bearing is correctly installed.



86239


Move the countershaft rearward, tilt it upward and remove it from the case. Remove the countershaft front thrust washer from the case. Note the position of the washer for assembly reference.

Remove the countershaft rear bearing spacer (21).




86240

SEE
I.S.
N
O
T
E
S



T4/5 MANUAL TRANSMISSION

T4 MANUAL TRANSMISSION OVERHAUL




Install the fourth gear blocking ring on the output shaft.

Install the output shaft rear bearing race.

Install the clutch shaft in the transmission case and engage the shaft in the third-fourth gear synchronizer sleeve and blocking ring.


Install a replacement oil seal in the front bearing cap with Tool J-26625.



86266

Coat the reverse gear shift lever pivot pin bolt threads with Loctite sealant. Install the reverse gear shift lever, pivot pin bolt and retaining C-clip (9). Ensure that the reverse gear shift lever fork is engaged in the reverse idler gear. Tighten the shift lever pivot pin bolt with 58 N·m (43 ft-lbs) torque.

SEE
I.S.
N
O
T
E
S




86265


Install a replacement rear oil seal in the adapter housing with Tool J-29184.

Install the front bearing race in the front bearing cap. Do not install the shims at this time.

Install the front bearing cap. Do not apply sealant at this time.




86232




T4/5 MANUAL TRANSMISSION

T5 MANUAL TRANSMISSION OVERHAUL




Remove the countershaft rear bearing spacer (32).



86288


Use a hammer and punch to remove the roll pin (33) from the forward end of the reverse idler gear shaft.

Remove the reverse idler gear shaft (34) and gear (35) from the transmission case. Note the position of the idler gear for assembly reference.




Remove the countershaft front bearing from the transmission case with an arbor press.

Remove the clutch shaft front bearing with Tools J-29721 and J-22912-01.




Remove the adapter housing rear oil seal with a flat drift and hammer.

SEE
I.S.
NOTES




T4/5 MANUAL TRANSMISSION

T5 MANUAL TRANSMISSION OVERHAUL




Install the fifth driven gear (19) and retaining snap ring (18) on the rear of the output shaft (20).



86274


Install the countershaft rear bearing spacer (30) and retaining snap ring (29).



86285

SEE
I.S.
NOTES


Insert the fifth-reverse gear shift rail through the opening in the rear of the case and install it in the fifth-reverse gear shift lever. Rotate the rail (27) during installation to simplify engagement with the lever.




86283

Install the fifth gear on the countershaft.

Install the fifth-reverse gear shift lever over-center link spring (B).




86305




GENERAL DESCRIPTION


ENGINE IDENTIFICATION INFORMATION



CYLINDER BLOCK COMPONENTS – 4.0L/4.2L


SEE
I.S.
NOTES





GENERAL DESCRIPTION

ENGINE SPECIFICATIONS



ENGINE SPECIFICATIONS – 4.2L (Continued)

| CYLINDER HEAD | USA Inches* | METRIC Millimeters* |
|------------------------------------|--------------------------------|--------------------------------|
| Combustion Chamber Volume | 64.45-67.45cc | |
| Valve Arrangement..... | EI-IE-IE-EI-EI-E | |
| Valve Guide ID (Integral)..... | 0.3735-0.3745 | 9.487-9.512 |
| Valve Stem-to-Guide Clearance..... | 0.001-0.003 | 0.03-0.08 |
| Intake Valve Seat Angle | 30° | |
| Exhaust Valve Seat Angle..... | 44.5° | |
| Valve Seat Width | 0.040-0.060 | 1.02-1.52 |
| Valve Seat Flareout..... | 0.0025 | 0.064 |
| Cylinder Head Flatness..... | 0.001/1-0.002/6 (0.008 max) | 0.03/25-0.05/152 (0.20 max) |

LUBRICATION SYSTEM

| | | |
|--|--|---|
| Engine Oil Capacity | 4 quarts (Add 1 quart with filter change) | 3.8 liters (Add 0.9 liter with filter change) |
| Normal Operating Pressure | 13 psi at 600 rpm; 37-75 psi (max) at 1600+ rpm | 89.6 kPa at 600 rpm; 255.1-517.1 kPa (max) at 1600+ rpm |
| Oil Pressure Relief..... | 75 psi (max) | 517.1 kPa (max) |
| Gear-to-Body Clearance (Radial)..... | 0.002-0.004 (.002 preferred) | 0.051-0.102 (.051 preferred) |
| Gear End Clearance, Plastigage | 0.002-0.006 (0.002 preferred) | 0.051-0.152 (0.051 preferred) |
| Gear End Clearance, Feeler Gauge..... | 0.004-0.008 (0.007 preferred) | 0.1016-0.2032 (0.1778 preferred) |

PISTONS

| | | |
|--|---|--|
| Weight (less pin)..... | 510-514 grams | |
| Piston Pin Bore | 1.651-1.655 | 41.94-42.04 |
| Centerline-to-Piston Top | 0.0009-0.0017 | 0.023-0.043 |
| Piston-to-Bore Clearance | (0.0012-0.0013 preferred) | (0.030-0.033 preferred) |
| Piston Ring Gap Clearance – Compression (both) | 0.010-0.020 | 0.25-0.51 |
| Piston Ring Gap Clearance – Oil Control Steel Rails | 0.010-0.025 | 0.25-0.64 |
| Piston Ring Side Clearance No. 1 Compression..... | 0.0017-0.0032 (0.0017 preferred) | 0.043-0.081 (0.043 preferred) |
| No. 2 Compression..... | 0.0017-0.0032 (0.0017 preferred) | 0.043-0.081 (0.043 preferred) |
| Oil Control | 0.001-0.008 (0.003 preferred) | 0.03-0.20 (0.08 preferred) |
| Piston Ring Groove Height Compression (both) | 0.0795-0.0805 | 2.019-2.045 |
| Oil Control | 0.188-0.1895 | 4.78-4.80 |
| Piston Ring Groove Diameter No. 1 and No. 2 | 3.324-3.329 | 84.43-84.56 |
| Oil Control | 3.329-3.339 | 84.56-84.81 |
| Piston Pin Bore Diameter | 0.9308-0.9313 | 23.642-23.655 |
| Piston Pin Diameter | 0.9304-0.9309 | 23.632-23.645 |
| Piston-to-Pin Clearance..... | 0.0003-0.0005 loose (0.0005 preferred) | 0.008-0.013 loose (0.013 preferred) |
| Piston-to-Pin Connecting Rod | 2000 lbf press-fit | 8.9kN press-fit |

| ROCKER ARMS, PUSH RODS AND TAPPETS | USA Inches* | METRIC Millimeters* |
|---------------------------------------|----------------|------------------------|
| Rocker Arm Ratio..... | 1.6:1 | |
| Push Rod Length..... | 9.710-9.730 | 248.63-247.14 |
| Push Rod Diameter | 0.312-0.315 | 7.92-8.00 |
| Hydraulic Tappet Diameter | 0.904-0.9045 | 22.962-22.974 |
| Tappet-to-Bore Clearance | 0.001-0.0025 | 0.03-0.05 |

VALVES


| | | |
|---|---------------|-----------------|
| Valve Length (Tip-to-Gauge Dim. Line)..... | 4.7895-4.8045 | 121.653-122.034 |
| Valve Stem Diameter | 0.3715-0.3725 | 9.436-9.462 |
| Stem-to-Guide Clearance | 0.001-0.003 | 0.03-0.08 |
| Intake Valve Head Diameter..... | 1.782-1.792 | 45.26-45.52 |
| Intake Valve Face Angle | 29° | |
| Exhaust Valve Head Diameter..... | 1.401-1.411 | 35.59-35.84 |
| Exhaust Valve Face Angle | 44° | |
| Maximum Allowable Removed for Tip Refinishing..... | 0.010 | 0.25 |

VALVE SPRINGS

| | | |
|--------------------------------------|-------------------------|-----------------------|
| Free Length | 1.99 approx. | 50.55 approx. |
| Spring Tension Valve Closed | 64-72 lbf at 1.786 | 285-320 N at 45.4 |
| Valve Open | 188-202 lbf at 1.411 | 836-898 N at 35.84 |
| Inside Diameter..... | 0.948-0.968 | 24.08-24.59 |


*Unless Otherwise Specified

SEE
I.S.
NOTES



CYLINDER BLOCK

DISASSEMBLY




OIL PUMP GEAR END CLEARANCE MEASUREMENT

Remove the cover retaining screws and cover from the pump body.

SEE
I.S.
N
O
T
E
S

Preferred Method

Place a strip of Plastigage (A) across the full width of each gear.



Install the pump cover and tighten the screws to 8 N·m (70 in-lbs) torque.


Remove the pump cover and determine the amount of clearance by measuring the width of compressed Plastigage with the scale on the Plastigage envelope.

The correct clearance by this method is 0.051 – 0.152 mm (0.002 – 0.006 in.). The preferred measurement is 0.051 mm (0.002 in.).

Alternate Method


Place a straightedge (A) across the ends of the gears and the pump body.

Select a feeler gauge (B) that fits snugly but freely between the straightedge and the pump gears.




Using this method the correct clearance is 0.051 – 0.152 mm (0.002 – 0.006 in.), with the preferred measurement being 0.051 mm (0.002 in.).

If the gear end clearance is excessive, replace the oil pump assembly.



CYLINDER BLOCK ASSEMBLY



CONNECTING ROD INSTALLATION


The connecting rods are made of malleable iron and are balanced assemblies with bearing inserts at the crankshaft journal end. The piston pin is 8.9 kN (2 000 pounds-force) press-fitted into the rod.

A squirt hole in the crankshaft end of the connecting rod provides lubrication for the camshaft lobes, distributor drive gear, cylinder walls and piston pins. The squirt hole faces the camshaft when the connecting rod is installed correctly.

Misaligned or bent connecting rods can cause abnormal wear on pistons, piston rings, cylinder walls, connecting rod bearings and crankshaft connecting rod journals. If wear patterns or damage to any of these components indicate the probability of a misaligned connecting rod, inspect it for correct rod alignment.

Replace misaligned or bent rods. Refer to Side Clearance Measurement.


Example of abnormal contact areas (A) caused by locking tabs that have not been fully seated or are bent:



86202A

SEE
I.S.
NOTES

Example of scoring on the lower (B) and upper (C) bearing surfaces:



86203A

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL