

NISSAN
STANZA
ALTIMA
MODEL U13 SERIES

QUICK REFERENCE INDEX

GENERAL INFORMATION _____	GI
MAINTENANCE _____	MA
ENGINE MECHANICAL _____	EM
ENGINE LUBRICATION AND COOLING SYSTEMS _____	LC
ENGINE FUEL AND EMISSION CONTROL SYSTEM _____	EF & EC
ACCELERATOR CONTROL, FUEL AND EXHAUST SYSTEMS _____	FE
CLUTCH _____	CL
MANUAL TRANSAXLE _____	MT
AUTOMATIC TRANSAXLE _____	AT
FRONT AXLE & FRONT SUSPENSION _____	FA
REAR AXLE & REAR SUSPENSION _____	RA
BRAKE SYSTEM _____	BR
STEERING SYSTEM _____	ST
BODY _____	BF
HEATER & AIR CONDITIONING _____	HA
ELECTRICAL SYSTEM _____	EL

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

HOW TO READ WIRING DIAGRAMS

SUPER MULTIPLE JUNCTION (SMJ)

- The "SMJ" indicated in wiring diagrams is shown in a simplified form. The terminal arrangement should therefore be referred to in the foldout at the end of the Service Manual.
- The foldout should be spread to read the entire wiring diagram.


Example



AGI012

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

LIFTING POINTS AND TOW TRUCK TOWING



Board-on Lift

CAUTION:

Make sure vehicle is empty when lifting.


- The board-on lift attachment (LM4086-0200) set at front end of vehicle should be set on the front of the sill under the front door opening.
- Position attachments at front and rear ends of board-on lift.

AGI016



Garage Jack and Safety Stand

WARNING:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands when you have to get under the vehicle.
- Place wheel chocks at both front and back of the wheels on the ground.



Use safety stand adapter as shown for stable support.



SGI737

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST





BF

HA

EL

GENERAL MAINTENANCE

Item	Reference page	
Parking brake Check that the lever has the proper travel and confirm that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	BR-33	GI
Automatic transmission "Park" mechanism Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that your vehicle is held securely with the selector lever in the "P" position without applying any brakes.	—	MA
UNDER THE HOOD AND VEHICLE		
The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).		EM
Windshield washer fluid Check that there is adequate fluid in the tank.	—	LC
Engine coolant level Check the coolant level when the engine is cold.	MA-20	EF & EC
Radiator and hoses Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, rot or loose connections.	LC-8	FE
Brake and clutch fluid levels Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoir.	MA-14, 15	CL
Battery Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines.	EL-10	MT
Engine drive belts Make sure that no belt is frayed, worn, cracked or oily.	MA-8	AT
Engine oil level Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-11	FA
Power steering fluid level and lines Check the level when the fluid is cold and the engine is turned off. Check the lines for proper attachment, leaks, cracks, etc.	MA-18	RA
Automatic transaxle fluid level Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-15	BR
Exhaust system Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-18	ST
Underbody The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—	BF
Fluid leaks Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioning after use is normal. If you should notice any leaks or if gasoline fumes are evident, check for the cause and correct it immediately.	—	HA
		EL



Changing Spark Plugs

1. Disconnect ignition wires from spark plugs at boot. Do not pull on the wire.

2. Remove spark plugs with spark plug wrench.

Spark plug:

Standard type

BKR5E-11

Cold type

BKR6E-11

BKR7E-11

3. Check plug gap of each new spark plug.

Gap: 1.0 - 1.1 mm (0.039 - 0.043 in)

4. Install spark plugs. Reconnect ignition wires according to Nos. indicated on them.

Spark plug:

⚙️: 20 - 29 N·m

(2.0 - 3.0 kg-m, 14 - 22 ft-lb)

Checking Vapor Lines

1. Visually inspect vapor lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration.
2. Inspect vacuum relief valve of fuel tank filler cap for clogging, sticking, etc.

Refer to EF & EC section ("Inspection", "EVAPORATIVE EMISSION (EVAP) SYSTEM").

Checking Valve Clearance

If engine runs with unusual mechanical noise, refer to EM section ("Inspection", "CYLINDER HEAD").

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

CONTENTS (Cont'd.)

Replacement Of Connecting Rod Bushing		
(Small end)	49	
Flywheel/Drive Plate Runout.....	49	
Assembly	49	
Piston	49	
Crankshaft.....	50	
SERVICE DATA AND SPECIFICATIONS (SDS)	52	
General Specifications	52	
Compression Pressure.....	52	
Inspection and Adjustment	52	
Cylinder Head	52	
Valve	52	
Valve spring.....	52	
Valve lifter.....	53	
Valve guide.....	53	
Valve clearance adjustment	54	
Available shims	54	
Valve seat.....	55	GI
Cylinder Block.....	56	
Camshaft And Camshaft Bearing	57	
Piston, Piston Ring And Piston Pin	58	MA
Piston.....	58	
Piston pin.....	58	
Piston ring	58	EM
Connecting Rod.....	58	
Crankshaft.....	59	
Bearing Clearance.....	59	LC
Available Main Bearing	59	
Standard	59	EF & EC
Undersize (service)	60	
Available Connecting Rod Bearing	60	
Standard	60	FE
Undersize (service)	60	
Miscellaneous Components	60	CL
		MT
		AT
		FA
		RA
		BR
		ST
		BF
		HA
		EL

OIL PAN



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL

Removal

1. Remove engine under cover.
2. Drain engine oil.
3. Remove steel oil pan bolts.




4. Remove steel oil pan.
 - (1) Insert Tool between aluminum oil pan and steel oil pan.
 - Be careful not to damage aluminum mating surface.
 - Do not insert screwdriver, or oil pan flange will be deformed.

TIMING CHAIN


Removal (Cont'd)

LOWER TIMING CHAIN


1. Remove upper timing chain.
Refer to EM-18.



2. Remove oil pan.
Refer to EM-11.
3. Remove crankshaft pulley.
4. Remove front cover




5. Remove the following parts.
 - Lower timing chain tensioner
 - Tension arm
 - Lower timing chain guide
6. Remove lower timing chain and idler sprocket.



Inspection


Check for cracks and excessive wear at roller links. Replace chain if necessary.



Installation

LOWER TIMING CHAIN

1. Install crankshaft sprocket.
 - Make sure that mating marks of crankshaft sprocket face front of engine.
2. Position crankshaft so that No. 1 piston is set at TDC.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CYLINDER HEAD

Inspection (Cont'd)

CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):


Standard

Less than 0.02 mm (0.0008 in)

Limit

0.04 mm (0.0016 in)

2. If it exceeds the limit, replace camshaft.



SEM926C

CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

Standard cam height:

Intake

42.415 - 42.605 mm (1.6699 - 1.6774 in)

Exhaust


42.415 - 43.005 mm (1.6699 - 1.6931 in)

Cam wear limit:

Intake & Exhaust

0.2 mm (0.008 in)

2. If wear is beyond the limit, replace camshaft.



SEM549A

CAMSHAFT JOURNAL CLEARANCE

1. Install camshaft bracket and tighten bolts to the specified torque.
2. Measure inner diameter of camshaft bearing.

Standard inner diameter:

#1 journal

28.000 - 28.025 mm (1.1024 - 1.1033 in)

#2 to #5 journals

24.000 - 24.025 mm (0.9449 - 0.9459 in)

3. Measure outer diameter of camshaft journal.

Standard outer diameter:

#1 journal

27.935 - 27.955 mm (1.0998 - 1.1006 in)

#2 to #5 journals


23.935 - 23.955 mm (0.9423 - 0.9431 in)

4. If clearance exceeds the limit, replace camshaft and/or cylinder head.


Camshaft journal clearance:

Standard 0.045 - 0.090 mm (0.0018 - 0.0035 in)

Limit 0.12 mm (0.0047 in)



SEM295D



SEM012A

CAMSHAFT END PLAY

1. Install camshaft and thermostat housing in cylinder head.
2. Measure camshaft end play.


Camshaft end play:

Standard

0.070 - 0.15 mm (0.0028 - 0.0059 in)

Limit

0.20 mm (0.0079 in)



SEM296D

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

CYLINDER BLOCK



- ① Piston rings
- ② Piston
- ③ Piston pin
- ④ Snap ring
- ⑤ Connecting rod
- ⑥ Connecting rod bearing

- ⑦ Crankshaft
- ⑧ Main bearing cap
- ⑨ Rear plate (M/T)
- ⑩ Flywheel (M/T)
- ⑪ Dust cover (A/T)
- ⑫ Main bearing

- ⑬ Rear plate (A/T)
- ⑭ Drive plate (A/T)
- ⑮ Drive plate reinforcement
- ⑯ Rear oil seal
- ⑰ Rear oil seal retainer
- ⑱ Cylinder block

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

CYLINDER BLOCK

Assembly (Cont'd)




5. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - **Be careful not to scratch cylinder wall by connecting rod.**
 - **Arrange so that front mark on piston head faces toward front of engine.**

GI

MA

EM



- b. Install connecting rod bearing caps.
Tighten connecting rod bearing cap nuts to the specified torque.

LC


EF &
EC

Connecting rod bearing nut:

- (1) Tighten to 14 to 16 N·m
(1.4 to 1.6 kg-m, 10 to 12 ft-lb).
- (2) Tighten bolts 60 to 65 degrees clockwise with an angle wrench, or if an angle wrench is not available, tighten them to 38 to 44 N·m (3.9 to 4.5 kg-m, 28 to 33 ft-lb).

FE

CL



6. Measure connecting rod side clearance.

Connecting rod side clearance:

- Standard**
0.2 - 0.4 mm (0.008 - 0.016 in)
- Limit**
0.6 mm (0.024 in)

MT

AT

FA

If beyond the limit, replace connecting rod and/or crankshaft.

RA

BR

ST

BF

HA

EL

ENGINE LUBRICATION AND COOLING SYSTEM

SECTION LC

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

CONTENTS

PRECAUTIONS	2	Checking Cooling System Hoses	8
Precautions for Supplemental Restraint System		Checking Cooling System For Leaks	9
“AIR BAG”	2	Checking Radiator Cap	9
Liquid Gasket Application Procedure	2	Water Pump	9
PREPARATION	3	Removal	10
Special Service Tools	3	Inspection	10
ENGINE LUBRICATION SYSTEM	4	Installation	10
Lubrication Circuit	4	Thermostat	11
Oil Pressure Check	5	Inspection	11
Oil Pump	5	Radiator	12
Removal	5	SERVICE DATA AND SPECIFICATIONS (SDS)	13
Regulator Valve Inspection	6	Engine Lubrication System	13
Oil Pressure Relief Valve Inspection	7	Oil pressure check	13
Oil Pump Inspection	7	Oil pump	13
ENGINE COOLING SYSTEM	8	Engine Cooling System	13
Cooling Circuit	8	Thermostat	13
System Check	8	Radiator	13

ENGINE COOLING SYSTEM

Thermostat



INSPECTION

1. Check valve seating condition at ordinary room temperatures. It should seat tightly.
2. Check valve opening temperature and maximum valve lift.


		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Maximum valve lift	mm/°C (in/°F)	10/90 (0.39/194)

3. Then check if valve is closed at 5°C (9°F) below valve opening temperature.
 - Apply a continuous bead of liquid gasket to mating surface of water inlet.
 - After installation, run engine for a few minutes, and check for leaks.
 - Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

GI
 MA
 EM
LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



Vehicle Speed Sensor (VSS)


The vehicle speed sensor provides a vehicle speed signal to the speedometer and the speedometer sends a signal to the ECM. The speed sensor consists of a pulse generator, which is installed in the transaxle. For diagnosis, refer to EF & EC-103.

GI

MA

EM

LC



Knock Sensor (KS)


The knock sensor is attached to the cylinder block and senses engine knocking conditions.

A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is sent to the ECM. For diagnosis, refer to EF & EC-118.

EF & EC

FE

CL



Fuel Filter


The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

MT

AT

FA

RA



Data Link Connector (DLC) for CONSULT


The data link connector for CONSULT is located beside the fuse lid.

BR

ST

BF

HA



Exhaust Gas Recirculation (EGR) Valve

The EGR valve controls the quantity of exhaust gas to be led to the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum is applied in response to the opening of the throttle valve. For diagnosis, refer to EF & EC-109.

EL

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Radiator Fan Control (Cont'd)


OPERATION

Vehicle speed km/h (MPH)	Air conditioning switch	Air conditioning triple-pressure switch	Engine coolant temperature °C(°F)		
			95 (203)	100 (212)	105 (221)
0 - 20 (0 - 12)	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	LOW		HIGH
		ON	HIGH		
20 - 80 (12 - 50)	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	LOW		HIGH
		ON	LOW		HIGH
80 (50) or more	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	OFF	LOW	HIGH
		ON	OFF	LOW	HIGH

Fail-safe System

CPU MALFUNCTION

Input/output signal line



Outline

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit.

In former models, engine starting was difficult under the previously mentioned conditions. But with the provisions in this fail-safe system, it is possible to start the engine.

Fail-safe system activating condition when ECM is malfunctioning

The fail-safe mode operates when the computing function of the ECM is judged to be malfunctioning. When the fail-safe system activates, i.e. if a malfunction condition is detected in the CPU of the ECM, the MALFUNCTION INDICATOR LAMP on

the instrument panel lights to warn the driver.

Engine control with fail-safe system, operates when ECM is malfunctioning

When the fail-safe system is operating, fuel injection, ignition timing, and so on are controlled under certain limitations.

Cancellation of fail-safe system when ECM is malfunctioning

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from OFF to ON.

TROUBLE DIAGNOSES


How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

INTERMITTENT PROBLEM SIMULATION

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under

Service procedure and note the result.



	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Crankshaft position sensor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feedback control	Oxygen sensor	Suspended	Disconnect oxygen sensor harness connector.
		ECM	Operation check	Perform on-board diagnostic system (On-board Diagnostic Test Mode II) at 2,000 rpm.
4	Idle speed	IAC valve-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electrical connection (Electric continuity)	Harness connectors and wires	Poor electrical connection or improper wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	ECM	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioning, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Rotate throttle position sensor body.
10	Ignition spark position	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition coil adapter (SST).

- Select the "Variable factor" when the symptom occurs. Perform the "Service procedure" to try to simulate the intermittent problem.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Consult (Cont'd)

SELF-DIAGNOSTIC RESULTS DIAGNOSTIC TEST MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CRANKSHAFT POSITION SEN*	<ul style="list-style-type: none"> • Either 1° or 180° signal is not entered for the first few seconds during engine cranking. • Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace crankshaft position sensor.)
MASS AIR FLOW SEN	<ul style="list-style-type: none"> • The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
COOLANT TEMP SEN	<ul style="list-style-type: none"> • The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
VEHICLE SPEED SEN	<ul style="list-style-type: none"> • The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (pulse generator)
IGN SIGNAL-PRIMARY*	<ul style="list-style-type: none"> • The ignition signal in primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> • Harness and connector • Power transistor unit
ECM	<ul style="list-style-type: none"> • ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
EGR SYSTEM**	<ul style="list-style-type: none"> • EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> • EGR valve • EGR and canister control solenoid valve
OXYGEN SEN	<ul style="list-style-type: none"> • The oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Oxygen sensor • Fuel pressure • Injectors • Intake air leaks
KNOCK SENSOR	<ul style="list-style-type: none"> • The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Knock sensor
EGR TEMP SENSOR**	<ul style="list-style-type: none"> • The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • EGR temperature sensor
THROTTLE POSI SEN	<ul style="list-style-type: none"> • The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor
INJECTOR LEAK**	<ul style="list-style-type: none"> • Fuel leaks from injector. 	<ul style="list-style-type: none"> • Injector

*: Check items causing a malfunction of crankshaft position sensor circuit first, if both "CRANKSHAFT POSITION SENSOR" and "IGN SIGNAL-PRIMARY" come out at the same time.

** : The diagnostic item marked "****" is applicable to vehicles for California only.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)

5

■ IGN TIMING ADJ ■

— CONDITION SETTING —

IGN/T FEEDBACK: HOLD

=== MONITOR ===

CKPS•RPM (REF) 650rpm
IGN TIMING 20BTDC
CLOSED TH/POS ON

SEF221M

6

■ THRTL POS SEN ADJ ■

ADJ MONITOR

THRTL POS SEN 0.44V


=== MONITOR ===


CKPS•RPM (REF) 687rpm
CLOSED TH/POS ON

SEF222M

6

CONNECT


H.S. 




SEF148I

7

DISCONNECT

T.S. 



Closed throttle position switch connector

SEF096M

5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine speed fall to 650 ± 50 rpm (A/T in "N" position)?

OR

When disconnecting throttle position sensor harness connector, does engine speed fall to 650 ± 50 rpm (A/T in "N" position)?

N.G. Adjust engine speed by turning idle adjusting screw.

6

CHECK THROTTLE POSITION SENSOR IDLE POSITION. (MT model only).

1. Perform "THRTL POS SEN. ADJ." in "WORK SUPPORT" mode.

2. Check that output voltage of throttle position sensor is approx. 0.3 to 0.7V. (Throttle valve fully closes.) and "CLOSED TH/POS" stays "ON".

OR

Measure output voltage of throttle position sensor using voltmeter, and check that it is approx. 0.3 to 0.7V. (Throttle valve fully closed.)

N.G. 1. Adjust output voltage by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "CLOSED TH/POS" stays "ON" using CONSULT.

7

CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (AT model only).

Check closed throttle position switch OFF → ON engine speed with circuit tester, closing throttle valve manually.


Closed throttle position switch OFF → ON engine speed 900 ± 150 rpm ("N" position)

N.G. 1. Adjust continuity signal by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "CLOSED TH/POS" stays "ON" using CONSULT.

(Go to **B** on next page.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES




SEF380I

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions

1
CHECK BATTERY AND STARTER.
Check battery and starter operation. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("SDS", "STARTING SYSTEM — Starter —").

N.G. Repair or replace.

O.K.




SEF229M

2
CHECK FUEL PRESSURE.
1. Turn ignition switch "ON".
2. Perform "FUEL PUMP RELAY" in "ACTIVE TEST" mode.
3. Pinch fuel feed hose with fingers.
Is fuel pressure pulsation felt on the fuel feed hose?

No Check fuel pump and circuit. Refer to EF & EC-134.

OR
1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

Yes




SEF084M

3
CHECK IGNITION SPARK.
1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

O.K.




SEF282G

4
CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.

N.G. Repair or replace spark plug(s).

O.K.

(Go to (A) on next page.)







SEF879J

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)


5

■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

START

SEF3791



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF





HA

EL

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Disconnect crankshaft position sensor harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal (b) and ground.
Voltage: Battery positive voltage

N.G. Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Check harness continuity between terminal (a) and engine ground.
Continuity should exist.

N.G. Repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
 1) Reconnect crankshaft position sensor harness connector.
 2) Start engine.
 3) Read crankshaft position sensor signals in "DATA MONITOR" mode with CONSULT.
rpm: 700 ± 50

N.G. Repair harness or connectors.

OR
 1) Disconnect ECM harness connector.
 2) Check harness continuity between terminal (c) and ECM terminals (31), (40) (1° signal), terminal (d) and ECM terminals (22), (30) (180° signal).
Continuity should exist.

CHECK COMPONENT
 (Crankshaft position sensor).
 Refer to EF & EC-159.

N.G. Replace crankshaft position sensor.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 14 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.




TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 33

OXYGEN SENSOR (Diagnostic trouble code No. 33) (MALFUNCTION INDICATOR LAMP ITEM)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



INSPECTION START

A
CHECK OVERALL FUNCTION.
1) Turn ignition switch "ON".
2) Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt for 5 seconds after ignition switch is turned "ON".

O.K. INSPECTION END




B
CHECK POWER SUPPLY.
1) Turn ignition switch "OFF".
2) Disconnect fuel pump relay.
3) Turn ignition switch "ON".
4) Check voltage between terminals ①, ③ and ground.
Voltage: Battery positive voltage

N.G. Check the following.

- Harness connectors (E103), (M7)
- Joint connector (E3)
- 15A fuse
- Harness continuity between fuse and fuel pump relay

 If N.G., repair harness or connectors.



C
CHECK GROUND CIRCUIT.
1) Turn ignition switch "OFF".
2) Disconnect fuel pump harness connector.
3) Check harness continuity between terminal (b) and body ground, terminal (a) and terminal (5).
Continuity should exist.

N.G. Check the following.

- Harness connectors (B1), (M6)
- Harness connectors (M7), (E103)
- Harness continuity between fuel pump and body ground
- Harness continuity between fuel pump and fuel pump relay


 If N.G., repair harness or connectors.

D
CHECK OUTPUT SIGNAL CIRCUIT.
1) Disconnect ECM harness connector.
2) Check harness continuity between ECM terminal (104) and terminal (2).
Continuity should exist.

N.G. Check the following.

- Harness connectors (M7), (E103)
- Harness connectors (M49), (F23)
- Harness continuity between ECM and fuel pump relay




 If N.G., repair harness or connectors.



(A)

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM inspection table


TER-MINAL NO.	ITEM	CONDITION	DATA	GI
1	Ignition signal	Engine is running. └ Idle speed	0.2 - 0.3V	MA
		Engine is running. └ Engine speed is 2,000 rpm.	Approximately 0.8V	EM
3	Ignition check	Engine is running. └ Idle speed	BATTERY POSITIVE VOLTAGE (11 - 14V)	LC
4	ECM relay (Self-shutoff)	Engine is running. └ Ignition switch "OFF" └ For approximately 1 second after turning ignition switch "OFF"	0 - 1V	EF & EC
		Ignition switch "OFF" └ Approximately 1 second after turning ignition switch "OFF"	BATTERY POSITIVE VOLTAGE (11 - 14V)	FE CL MT
8	EGR temperature sensor	Engine is running. └ EGR system is not operating.	Less than 5V	AT
		Engine is running. └ EGR system is operating.	0 - 1.0V	FA
9	Radiator fan relay (Low speed)	Engine is running. └ Radiator fans are not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	RA
		Engine is running. └ Radiator fans are operating at low speed.	Approximately 0.7V	BR
10	Radiator fan relay (High speed)	Engine is running. └ Radiator fans are not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	ST
		Engine is running. └ Radiator fans are operating at high speed.	Approximately 0.7V	BF
11	Air conditioning relay	Engine is running. └ Both A/C switch and blower switch are "ON".	Approximately 0.7V	HA
		Engine is running. └ A/C switch is "OFF".	BATTERY POSITIVE VOLTAGE (11 - 14V)	EL
16	Mass air flow sensor	Engine is running. └ Idle speed	0.8 - 3.0V Output voltage varies with engine speed.	
18	Engine coolant temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine water temperature.	

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM RELAY AND FUEL PUMP RELAY

Check continuity between terminals ③ and ⑤.




SEF054F

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If N.G., replace relay.

INHIBITOR RELAY (A/T models with ASCD)

Check continuity between terminals ⑥ and ⑦.




AEC157

Conditions	Continuity
12V direct current supply between terminals ① and ②.	Yes
No current supply	No

If N.G., replace relay.

INHIBITOR RELAY (A/T models without ASCD) AND RADIATOR FAN RELAY-1

Check continuity between terminals ③ and ⑤.




SEF090M

Conditions	Continuity
12V direct current supply between terminals ① and ②.	Yes
No current supply	No

If N.G., replace relay.

RADIATOR FAN RELAYS-2 AND -3

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.




SEC202B

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If N.G., replace relay.

POWER STEERING PRESSURE SWITCH

1. Disconnect power steering pressure switch harness connector.
2. Check continuity between terminals.



AEC249

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

FUEL SYSTEM

Fuel Tank


WARNING:

When replacing fuel line parts, be sure to observe the following:

- Put a "CAUTION: INFLAMMABLE" sign in workshop.
- Be sure to furnish workshop with a CO₂ fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to disconnect battery ground cable before conducting operations.
- Drain fuel from Fuel Tank and put drained fuel in an explosion-proof container and put lid on securely.

CAUTION:

- Before disconnecting fuel hose, release fuel pressure from fuel line. Refer to MA section ("Changing Fuel Filter", "ENGINE MAINTENANCE").
- Do not disconnect any fuel line unless absolutely necessary.
- Plug hose and pipe openings to prevent entry of dust or dirt.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose clamps excessively to avoid damaging hoses.
- When installing fuel check valve, be careful of its designated direction. Refer to EF & EC section ("Inspection", "EVAPORATIVE EMISSION (EVAP) SYSTEM").
- Tighten bolts to specified torque.
- After installation, run engine and check for leaks at connections.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder (Cont'd)

INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL






Operating Cylinder



INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Piston spring, for wear or damage
- Dust cover, for cracks, deformation or damage



Differential Side Oil Seal Replacement

1. Drain gear oil from transaxle.
2. Remove drive shafts — Refer to FA section (“Removal”, “FRONT AXLE — Drive Shaft”).
3. Remove differential oil seal.

4. Install differential oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts — Refer to FA section (“Installation”, “FRONT AXLE — Drive Shaft”).

Striking Rod Oil Seal Replacement

1. Remove transaxle control rod from yoke.
2. Remove yoke retaining pin.
 - **Be careful not to damage boot.**

3. Remove striking rod oil seal.

4. Install striking rod oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL



DISASSEMBLY




14. Remove reverse check assembly.



15. Remove retaining pin and detach the selector.



16. Remove drain plug for convenience in removing retaining pin which holds striking lever to striking rod.



17. Remove retaining pin and then withdraw striking lever and striking rod.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA


EL

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




3. Install 2nd synchronizer cone, inner & outer baulk rings. Insert springs and 1st & 2nd coupling sleeve.
4. Install 2nd main gear.
 - Ensure four protrusions of 2nd synchronizer cone are set in 2nd main gear holes.



5. Press on 3rd main gear.



6. Press on 4th main gear.



7. Press on 5th main gear.
8. Select proper snap ring of 5th main gear to minimize clearance of groove and then install it.
 - Allowable clearance of groove:**
0 - 0.15 mm (0 - 0.0059 in)
 - Snap ring of 5th main gear:**
Refer to MT-41.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)




8. Measure with feeler gauge distance between gauging cylinder and shoulder of gauging plunger.
9. Use feeler gauge reading to select correct mainshaft preload shim(s).

Mainshaft bearing adjusting shim:

Refer to MT-42.

10. Install selected mainshaft bearing adjusting shim and mainshaft bearing outer race.
11. Check total turning torque after assembly — Refer to MT-36.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

AUTOMATIC TRANSAXLE

SECTION AT


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS

PREPARATION	2	Self-Diagnostic Procedure (Without CONSULT).....	37
PRECAUTIONS	7	Judgement Of Self-Diagnosis Code	39
A/T CONTROL DIAGRAM	8	Revolution Sensor Circuit Check	41
Hydraulic Control Circuits	8	Vehicle Speed Sensor Circuit Check	42
Electrical Control Chart	9	Throttle Position Sensor Circuit Check.....	43
Mechanical Operation	9	Shift Solenoid Valve A Circuit Check	44
Cross-Sectional View	10	Shift Solenoid Valve B Circuit Check	45
TROUBLE DIAGNOSES	11	Overrun Clutch Solenoid Valve Circuit Check ...	46
How to Perform Trouble Diagnoses for Quick and Accurate Repair	11	Torque Converter Clutch Solenoid Valve Circuit Check	47
Fail-Safe Remarks	12	Fluid Temperature Sensor Circuit And TCM (A/T Control Module) Power Source Circuit Checks	48
Preliminary Check	13	Engine Speed Signal Circuit Check	50
A/T Fluid Check	13	Line Pressure Solenoid Valve Circuit Check	51
Fluid leakage check	13	Inhibitor Switch, Overdrive Switch And Closed Throttle Position Switch Circuit Checks	52
Fluid condition check	13	Diagnostic Procedure 1	56
Fluid level check	13	(SYMPTOM: OD OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".)	
Road Testing	13	Diagnostic Procedure 2	57
Description.....	13	(SYMPTOM: Engine cannot be started with selector lever in "P" or "N" position or engine can be started with selector lever in "D", "2", "1" or "R" position.)	
1. Check before engine is started	14	Diagnostic Procedure 3	57
2. Check at idle	15	(SYMPTOM: Vehicle moves when it is pushed forward or backward with selector lever in "P" position.)	
3. Cruise test	17	Diagnostic Procedure 4	58
With CONSULT.....	17	(SYMPTOM: Vehicle moves forward or backward when selecting "N" position.)	
Without CONSULT.....	20	Diagnostic Procedure 5	59
Cruise test — Part 1	20	(SYMPTOM: There is large shock when changing from "N" to "R" position.)	
Cruise test — Part 2	23		
Cruise test — Part 3	25		
Vehicle speed when shifting gears	26		
Vehicle speed when performing lock-up	26		
Shift schedule (Comfort pattern)	27		
Shift schedule (Auto power pattern).....	27		
Diagnosis by CONSULT	28		
A/T Component Parts Application.....	29		
Data Analysis.....	30		
A/T Electrical Parts Location	31		
Circuit Diagram for Quick Pinpoint Check	32		
Wiring Diagram	34		
Self-diagnosis	36		
Self-Diagnostic Procedure (With CONSULT).....	36		

A/T CONTROL DIAGRAM

Electrical Control Chart



AAT003

Mechanical Operation

Shift position	Reverse clutch	High clutch	Forward clutch	Overrun clutch	Band servo			Forward one-way clutch	Low one-way clutch	Low & reverse brake	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK
R	○									○		REVERSE
N												NEUTRAL
D*4	1st		○	*1◎				●	●			Automatic shift 1 ↔ 2 ↔ 3 ↔ 4
	2nd		○	*1◎	○			●				
	3rd		○	*1◎	*2(X)	(X)		●		○		
	4th		○	(X)	*3(X)	(X)	○			○		
2	1st		○	○				●	●			Automatic shift 1 ↔ 2 ↔ 3
	2nd		○	○	○			●				
1	1st		○	○				●		○		Locks (held stationary) in 1st speed 1 ← 2 ← 3
	2nd		○	○	○			●				

*1: Operates when overdrive switch is in "OFF" position.

*2: Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

*3: Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

*4: A/T will not shift to 4th when overdrive switch is in "OFF" position.

○: Operates

◎: Operates when throttle position is less than 3/16.

●: Operates during "progressive" acceleration.

(X): Operates but does not affect power transmission.

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

12. After finishing cruise test part 1, touch "STOP".

★RECORD 4/8 ☆NO FAIL

ENGINE SPEED	768rpm
GEAR	1
RANGE	N•P
VEHICLE SPEED	0km/h
THROTTLE POSI	0.0/8
LINE PRES DTY	29%
TCC S/V DUTY	4%
SHIFT S/V A	ON
SHIFT S/V B	ON

STOP

AAT078

13. Touch "DISPLAY".

■ REAL-TIME DIAG ■

*****NO FAILURE*****

STORE (RECORD1)

RECORD2 **DISPLAY**

SAT301C

14. Touch "PRINT".

ENG SPEED	GEAR	RANGE
18:01	(rpm)	
00''39	704	1 D
00''26	704	1 D
00''13	704	1 D
00''00	704	1 D
00''13	704	1 D
00''26	704	1 D
00''39	704	1 D

PRINT GRAPH

SAT913F

15. Touch "PRINT" again.

ENG SPEED	GEAR	RANGE
18:01	(rpm)	
00''39	704	1 D
00''26	704	1 D
00''13	704	1 D
00''00	704	1 D
00''13	704	1 D
00''26	704	1 D
00''39	704	1 D

ALL ITM **PRINT**

SAT914F

16. Check the monitor data printed out.

17. Continue cruise test part 2 and 3.

ENG SPEED	GEAR	RANGE	CAR SPEED	THRTL OPEN
18:01	(rpm)		SEN (km/h)	-ING (/8)
00''39	704	1 D	0	0.0
00''26	704	1 D	0	0.0
00''13	704	1 D	0	0.0
00''00	704	1 D	0	0.0
00''13	704	1 D	0	0.0
00''26	704	1 D	0	0.0
00''39	704	1 D	0	0.0
00''52	704	1 D	0	0.0
00''65	704	1 D	0	0.0

SAT915F

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Diagnosis by CONSULT (Cont'd)

A/T COMPONENT PARTS APPLICATION

DIAGNOSTIC ITEM		MODE		
		SELF-DIAGNOSTIC RESULTS	DATA MONITOR	
INPUT	Vehicle speed sensor 1 (A/T)	X	X	GI
	Vehicle speed sensor 2 (meter)	X	X	MA
	Throttle position sensor	X	X	EM
	Fluid temperature sensor	X	X	LC
	Battery positive voltage	X	X	LC
	Engine speed (rpm)	X	X	EF & EC
	Selector lever switch (overdrive switch)	—	X	EF & EC
	ASCD — cruise signal	—	X	FE
	ASCD — OD cut signal	—	X	FE
	Kickdown switch	—	—	CL
	Power shift switch	—	—	CL
	Closed throttle position switch	—	X	MT
	Wide open throttle position switch	—	X	MT
	Shift solenoid valve A (feedback)	—	X	AT
	Shift solenoid valve B (feedback)	—	X	AT
	Overrun clutch solenoid valve (feedback)	—	X	AT
	Hold mode switch	—	—	FA
	"1" position switch	—	X	FA
	"2" position switch	—	X	RA
"D" position switch	—	X	RA	
Park/Neutral position switch	—	X	BR	
"R" position switch	—	X	BR	
DATA	Gear position	—	X	ST
	Range position	—	X	ST
	Vehicle speed	—	X	BF
	Throttle position	—	X	BF
OUTPUT	Shift solenoid valve A	X	X	HA
	Shift solenoid valve B	X	X	HA
	Overrun clutch solenoid valve	X	X	EL
	Line-pressure solenoid valve	X	X	EL
	Torque converter clutch solenoid valve	X	X	EL

X: Applicable —: Not applicable
 DATA = internal TCM calculation


TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

JUDGEMENT OF SELF-DIAGNOSIS CODE


Flickers of OD OFF indicator lamp: Damaged circuit

All judgement flickers are same.




All circuits that can be confirmed by self-diagnosis are O.K.

4th judgement flicker is longer than others.




Shift solenoid valve A circuit is short-circuited or disconnected.
Go to **SHIFT SOLENOID VALVE A CIRCUIT CHECK (AT-44)**.

1st judgement flicker is longer than others.




Revolution sensor circuit is short-circuited or disconnected.
Go to **REVOLUTION SENSOR CIRCUIT CHECK (AT-41)**.

5th judgement flicker is longer than others.




Shift solenoid valve B circuit is short-circuited or disconnected.
Go to **SHIFT SOLENOID VALVE B CIRCUIT CHECK (AT-45)**.

2nd judgement flicker is longer than others.




Vehicle speed sensor circuit is short-circuited or disconnected.
Go to **VEHICLE SPEED SENSOR CIRCUIT CHECK (AT-42)**.

6th judgement flicker is longer than others.




Overrun clutch solenoid valve circuit is short-circuited or disconnected.
Go to **OVERRUN CLUTCH SOLENOID VALVE CIRCUIT CHECK (AT-46)**.

3rd judgement flicker is longer than others.



Throttle position sensor circuit is short-circuited or disconnected.
Go to **THROTTLE POSITION SENSOR CIRCUIT CHECK (AT-43)**.

7th judgement flicker is longer than others.



Torque converter clutch solenoid valve circuit is short-circuited or disconnected.
Go to **TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT CHECK (AT-47)**.

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

C





☆ MONITOR	☆ NO FAIL	▼
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	


RECORD

SAT952F





C

AAT084A




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Diagnostic Procedure 5

SYMPTOM:

There is large shock when changing from "N" to "R" position.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA

EL


TROUBLE DIAGNOSES



Diagnostic Procedure 14

SYMPTOM:

Lock-up is not released when accelerator pedal is released.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

REVOLUTION SENSOR

- For removal and installation, refer to AT-90.
- Check resistance between terminals ①, ② and ③.



Terminal No.		Resistance
①	②	500 - 650Ω
②	③	No continuity
①	③	No continuity


SOLENOID VALVES AND FLUID TEMPERATURE SENSOR

- For removal and installation, refer to AT-88.
- Check resistance between two terminals.

Solenoids


Solenoid	Terminal No.	Resistance (Approx.)
Shift solenoid valve A	⑥	25Ω
Shift solenoid valve B	⑦	
Overrun clutch solenoid valve	⑧	
Line pressure solenoid valve	①	3.2Ω
Torque converter clutch solenoid valve	⑤	13.4Ω

Ground (Bracket)



ON-VEHICLE SERVICE

Control Valve Assembly and Accumulator (Cont'd)




GI
MA
EM
LC
EF &
EC
FE
CL
MT

6. Remove control valve assembly by removing fixing bolts ⊕, ⊗ and ●.

Bolt length, number and location are shown in the illustration.

- Be careful not to drop manual valve and 3-R accumulator return spring.
7. Disassemble and inspect control valve assembly if necessary — Refer to AT-130.

AT



8. Remove 3-R and N-D accumulators by applying compressed air if necessary.

- Hold each piston with a rag.

FA

RA


BR

ST

BF

HA


EL




INSTALLATION

- Set manual shaft in Neutral, then align manual plate with groove in manual valve.
- After installing control valve on to transmission case, make sure that selector lever can be moved to all positions.

Key Interlock Cable



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



REMOVAL

1. Remove snap pin temporarily and remove key interlock cable from vehicle.
2. Unlock slider from adjuster holder and remove rod from cable.
3. Install rod to control device with snap pin.


INSTALLATION

1. Set key interlock cable to steering lock assembly and install lock plate.
2. Clamp cable to steering column and fix to control cable with band.
3. Set control lever to "P".
4. Insert rod into adjuster holder.
5. Install casing cap to bracket.
6. Move slider in order to fix adjuster holder to rod.

DISASSEMBLY


Unit: mm (in)

- ① 5 bolts $l = 40$ (1.57)
- ⊗ 6 bolts $l = 33$ (1.30)
- 2 bolts $l = 43.5$ (1.713)




SAT647E

9. Remove control valve assembly according to the following procedures.
 - a. Remove control valve assembly mounting bolts ①, ⊗ and ●.



- b. Remove stopper ring from terminal body.



- c. Push terminal body into transmission case and draw out solenoid harness.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

DISASSEMBLY




36. Remove needle bearing from overrun clutch hub and check for damage or wear.

GI

MA

EM

LC




37. Remove forward clutch assembly from transmission case.

EF &
EC

FE

CL




38. Remove needle bearing from transmission case.

MT

AT

FA

RA



39. Remove output shaft assembly according to the following procedures.

a. Remove side cover bolts.


- Do not mix bolts (A) and (B).
- Always replace bolts (A) as they are self-sealing bolts.

BR

ST

BF

HA




b. Remove side cover by lightly tapping it with a soft hammer.

- Be careful not to drop output shaft assembly as output shaft assembly may be removed together with side cover.


EL

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



4. Install oil pump cover on oil pump housing.
 - a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly on oil pump housing assembly, then remove masking tape.
 - b. Tighten bolts in a crisscross pattern.



5. Install new seal rings carefully after packing ring groove with petroleum jelly and attach hooks.
 - **Do not spread gap of seal ring excessively while installing. The ring may be deformed.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Control Valve Upper Body



- | | | |
|-------------------------|----------------------------------|-----------------------|
| ① Upper body | ⑬ Return spring | ②⑤ Plug |
| ② Retainer plate | ⑭ Torque converter relief valve | ②⑥ Retainer plate |
| ③ Sequence valve | ⑮ Retainer plate | ②⑦ Return spring |
| ④ Retainer plate | ⑯ Plug | ②⑧ 1st reducing valve |
| ⑤ Plug | ⑰ Overrun clutch reducing valve | ②⑨ Plug |
| ⑥ Return spring | ⑱ Return spring | ③① Retainer plate |
| ⑦ 1-2 accumulator valve | ⑲ Pilot valve | ③② Return spring |
| ⑧ Retainer plate | ⑳ Return spring | ③③ Retainer plate |
| ⑨ Plug | ㉑ Retainer plate | |
| ⑩ Return spring | ㉒ 1-2 accumulator retainer plate | |
| ⑪ Lock-up control valve | ㉓ Return spring | |
| ⑫ Retainer plate | ㉔ 1-2 accumulator piston | |

AT-139


SAT538F

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

8. Check operation of reverse clutch.
Refer to AT-146.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



5. Set Tool on spring retainer and install snap ring while compressing return springs.

- Set Tool directly over return springs.

- Do not align snap ring gap with spring retainer stopper.

6. Install drive plates, driven plates, retaining plate and dish plate for overrun clutch.

- Take care with order of plates.
7. Install snap ring for overrun clutch.

8. Measure clearance between overrun clutch retaining plate and snap ring.

If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard 0.7 - 1.1 mm (0.028 - 0.043 in)

Allowable limit 1.7 mm (0.067 in)

Overrun clutch retaining plate: Refer to AT-211.

9. Install drive plates, driven plates, retaining plate and dish plate for forward clutch.

- Take care with order of plates.
10. Install snap ring for forward clutch.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer (Cont'd)


3. Remove snap ring from bearing retainer.




4. Remove needle bearing from bearing retainer.




5. Remove idler gear bearing inner race from idler gear.



6. Remove idler gear bearing outer race from transmission case.



7. Press out reduction gear bearing inner race from reduction gear.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS


Final Drive — RE4F04A (Cont'd)




- Remove differential side bearing outer race, and side bearing adjusting shim from transmission case.




- Remove speedometer drive gear.



- Drive out pinion mate shaft lock pin.



- Draw out pinion mate shaft lock pin.
- Remove pinion mate gears and side gears.



INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, side gears and pinion mate gears.
- Check washers for wear.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

ASSEMBLY

Adjustment (Cont'd)



3. Place final drive assembly on transmission case.
4. Install transmission case on converter housing and tighten transmission case fixing bolts to the specified torque.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL



— RE4F04A —

5. Attach dial indicator on differential case at converter housing side.
6. Insert Tool into differential side gear from transmission case side.
7. Move Tool up and down and measure dial indicator deflection.



— RE4F04V —

5. Set Tool on differential case at converter housing side and attach dial indicator on Tool.
6. Insert the other Tool viscous coupling from transmission case side.
7. Move Tool up and down and measure dial indicator deflection.

— RE4F04A and RE4F04V —

8. Select proper thickness of differential side bearing adjusting shim(s).

Suitable shim thickness = Dial indicator deflection
+ Specified bearing preload

Differential side bearing adjusting shim:


Refer to AT-212.

Bearing preload:

0.05 - 0.09 mm (0.0020 - 0.0035 in)

ASSEMBLY

Assembly (Cont'd)



17. Install bearing race, needle bearing and high clutch hub on front sun gear.


- Apply petroleum jelly to needle bearing.
- Pay attention to direction of needle bearing.

GI

MA

EM

LC




18. Install high clutch hub and front sun gear on transmission case.

EF &
EC

FE

CL



19. Install needle bearings on high clutch drum.


- Apply petroleum jelly to needle bearings.
- Pay attention to direction of needle bearings.

MT

AT

FA

RA




20. Remove paper rolled around input shaft.

21. Install input shaft assembly in reverse clutch.

- Align teeth of reverse clutch drive plates before installing.

ST

BF



22. Install reverse clutch assembly on transmission case.

- Align teeth of high clutch drive plates before installing.

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Engine	KA24DE	
Automatic transaxle model	RE4F04A	RE4F04V
Automatic transaxle assembly		
Model code number	80X05	80X06
Transaxle gear ratio		
1st	2.785	
2nd	1.545	
3rd	1.000	
4th	0.694	
Reverse	2.272	
Final drive	3.619	
Recommended oil	Genuine Nissan Automatic Transmission Fluid (ATF) or equivalent DEXRON II E™ type fluid	
Oil capacity ℓ (US qt, Imp qt)	8.3 (8-3/4, 7-1/4)	8.5 (9, 7-1/2)

Specifications and Adjustments

VEHICLE SPEED WHEN SHIFTING GEARS




Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
	Auto power	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
Half throttle	Comfort	42 - 50 (26 - 31)	78 - 86 (48 - 53)	124 - 132 (77 - 82)	74 - 82 (46 - 51)	40 - 48 (25 - 30)	5 - 13 (3 - 8)	62 - 70 (39 - 43)
	Auto power	45 - 53 (28 - 33)	84 - 92 (52 - 57)	132 - 140 (82 - 87)	86 - 94 (53 - 58)	52 - 60 (32 - 37)	5 - 13 (3 - 8)	62 - 70 (39 - 43)

VEHICLE SPEED WHEN PERFORMING LOCK-UP

Throttle position	Shift pattern	OD switch (shift range)	Vehicle speed km/h (MPH)	
			Lock-up "ON"	Lock-up "OFF"
2/8	Comfort	ON [D ₄]	105 - 113 (65 - 70)	53 - 61 (33 - 38)
		OFF [D ₃]	86 - 94 (53 - 58)	83 - 91 (52 - 57)
	Auto power	ON [D ₄]	108 - 116 (67 - 72)	53 - 61 (33 - 38)
		OFF [D ₃]	88 - 94 (55 - 58)	83 - 91 (52 - 57)

PRECAUTIONS AND PREPARATION

Preparation (Cont'd) COMMERCIAL SERVICE TOOLS

Tool name	Description
Attachment Wheel alignment	
Flare nut crows foot	
Torque wrench	

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

FRONT AXLE — Wheel Hub and Knuckle


Assembly (Cont'd)




4. Pack grease seal lip with multi-purpose grease.



5. Install outer grease seal.




6. Install inner grease seal.



7. Press wheel hub into knuckle.

Maximum load P:
29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)
Be careful not to damage grease seal.



8. Check bearing operation.

(1) Add load P with press.

Load P:

34.3 - 49.0 kN

(3.5 - 5.0 ton, 3.9 - 5.5 US ton, 3.44 - 4.92 Imp ton)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

FRONT SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.





- | | | |
|----------------------------|---------------------------|---------------------------|
| ① Bound bumper assembly | ⑪ Stabilizer | ⑳ Cotter pin |
| ② Upper spring seat | ⑫ Compression rod bushing | ㉑ Wheel bearing cap |
| ③ Strut mounting insulator | ⑬ Transverse link | ㉒ Washer |
| ④ Plain washer | ⑭ Cotter pin | ㉓ Baffle plate |
| ⑤ Cap | ⑮ Drive shaft | ㉔ Knuckle |
| ⑥ Spacer | ⑯ Cap | ㉕ Strut assembly |
| ⑦ (Polyuretane tube) | ⑰ Stopper bolt | ㉖ Dynamic damper assembly |
| ⑧ Coil spring | ⑱ Cotter pin | |
| ⑨ Front suspension member | ㉒ Insulator (Rubber) | |
| ⑩ Stabilizer clamp | ㉓ Adjusting cap | |

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

PRECAUTIONS AND PREPARATION

Preparation (Cont'd) COMMERCIAL SERVICE TOOLS

Tool name	Description	
Flare nut crows foot		GI MA
Torque wrench		EM LC
		EF & EC
		FE
		CL
		MT
		AT
		FA
		RA
		BR
		ST
		BF
		HA
		EL

REAR SUSPENSION — Coil Spring and Strut Assembly

Inspection (Cont'd)

UPPER RUBBER SEAT AND BUSHING

Check rubber parts for deterioration or cracks.
Replace if necessary.

GI

STRUT MOUNTING INSULATOR

- Check cemented rubber-to-metal portion for melting or cracks.
- Check rubber parts for deterioration.

MA

EM

COIL SPRING

Check for cracks, deformation or other damage.
Replace if necessary.

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL





Assembly

1. Locate upper spring seat as shown.



2. After placing coil spring in position on lower spring seat, release spring compressor gradually.

CONTROL VALVE



Proportioning Valve

INSPECTION

CAUTION:

- Carefully monitor brake fluid level at master cylinder.
- Use new brake fluid "DOT 3".
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on paint areas, wash it away with water immediately.
- Depress pedal slowly when raising front brake pressure.
- Check rear brake pressure 2 seconds after front brake pressure reaches specified value.
- For models with ABS, disconnect harness connectors from ABS actuator relay before checking.



1. Connect Tool to air bleeders of front and rear brakes on either LH and RH side.
2. Bleed air from the Tool.
3. Check rear brake pressure by depressing brake pedal (increasing front brake pressure).

Unit: kPa (kg/cm², psi)

	Without ABS	With ABS
Applied pressure (Front brake) D ₁	5,394 (55, 782)	5,884 (60, 853)
Output pressure (Rear brake) D ₂	2,452 - 2,844 (25 - 29, 356 - 412)	3,334 - 3,727 (34 - 38, 483 - 540)

If output pressure is out of specifications, replace dual proportioning valve (separated type) or master cylinder assembly (built-in type).

4. Bleed air after disconnecting the Tool. Refer to BR-5.



REMOVAL (Separated type)

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Loosen flare nut.
4. Remove proportioning valve mounting bolt, then remove flare nut.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

Pad Replacement

WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.

CAUTION:

- When cylinder body is open, do not depress brake pedal or piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA

EL



1. Remove master cylinder reservoir cap.
2. Remove lower pin bolt.



3. Open cylinder body upward. Then remove pad retainers and inner and outer shims.

Standard pad thickness:

11.0 mm (0.433 in)


Pad wear limit:

2.0 mm (0.079 in)

- Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.


REAR DISC BRAKE

Pad Replacement (Cont'd)



6. When installing new pads, push piston into cylinder body by turning piston clockwise.

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.



- | | | |
|-----------------|-----------------|----------------|
| ① Spring | ⑫ Inner shim | ⑳ Spring |
| ② Toggle lever | ⑬ Pin bolt | ㉑ Spring cover |
| ③ Cam | ⑭ Copper washer | ㉒ Piston seal |
| ④ Cam boot | ⑮ Cable guide | ㉓ Spacer |
| ⑤ Torque member | ⑯ Cylinder | ㉔ Wave washer |
| ⑥ Pin boot | ⑰ Strut | ㉕ Bearing |
| ⑦ Side pin | ⑱ O-ring | ㉖ Adjuster nut |
| ⑧ Outer shim | ㉒ Push rod | ㉗ Piston cup |
| ⑨ Outer pad | ㉓ Key plate | ㉘ Piston |
| ⑩ Pad retainer | ㉔ Snap ring | ㉙ Piston boot |
| ⑪ Inner pad | ㉕ Spring seat | |

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


ANTI-LOCK BRAKE SYSTEM

Removal and Installation


CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth.

FRONT WHEEL SENSOR



REAR WHEEL SENSOR



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TROUBLE DIAGNOSES


Circuit Diagram for Quick Pinpoint Check

- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown on BR-44.
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES



Electrical Components Inspection


WHEEL SENSOR

Check resistance between terminals (a) and (b).
Resistance: 1.0 - 1.25kΩ



MOTOR RELAY

Condition	Continuity existence between terminals (3) and (4)
Battery positive voltage not applied between terminals (1) and (2).	No
Battery positive voltage applied between terminals (1) and (2).	Yes



SOLENOID VALVE RELAY

Condition	Continuity existence between terminals (30) and (87a)	Continuity existence between terminals (30) and (87)
Battery positive voltage not applied between terminals (85) and (86).	Yes	No
Battery positive voltage applied between terminals (85) and (86).	No	Yes

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL

STEERING WHEEL AND STEERING COLUMN




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Removal (With air bag)

STEERING WHEEL

Remove air bag module and spiral cable. Refer to BF section ("Removal — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM").




STEERING COLUMN

CAUTION:


The rotation of the spiral cable (SRS "Airbag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.

POWER STEERING GEAR AND LINKAGE


Assembly (Cont'd)




3. Insert new rack oil seal.
 - Place plastic film into rack oil seal to prevent damage by rack teeth.
 - Do not forget to remove plastic film after rack oil seal is positioned properly.
 - Make sure lips of rack oil seal face each other.




4. Install center bushing and rack oil seal with rack assembly.



5. Tighten end cover assembly with a suitable tool.



6. Fasten end cover assembly to gear housing by staking.



7. Set rack gear in neutral position.
Rack stroke "L":
Refer to SDS, ST-28.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SECTION BF

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



CONTENTS

GENERAL SERVICING	2	INSTRUMENT PANEL	23
Precautions.....	2	Removal — Instrument panel assembly	23
Supplemental Restraint System “AIR BAG”.....	2	Head-Up Display (Hud)	24
Circuit Breaker Inspection.....	2	INTERIOR AND EXTERIOR	26
Clip and Fastener.....	3	Interior.....	26
BODY END	5	Side And Floor Trim	26
Body Front End.....	5	Removal — Body side trim	26
Removal — Front bumper assembly.....	5	Door Trim Removal — Door trim.....	27
Body Rear End and Opener.....	7	Room Trim.....	28
Removal — Rear bumper assembly	7	Removal — Headlining	28
DOOR	9	Luggage Room Trim	29
Front Door	9	Exterior	30
Rear Door.....	10	① Front hood insulator	31
Power Window and Power Door Lock.....	11	② Cowl top grille and cowl top front	
Door Lock Timer.....	11	sealing rubber	31
Wiring Diagram.....	12	③ Front windshield molding	31
DOOR — Trouble Diagnoses for Power Window	14	Windshield upper and side molding.....	32
Symptom Chart	14	④ Sunroof lid weatherstrip	32
Main Power Supply and Ground Circuit Check.....	15	⑤ Body side drip weatherstrip	32
Procedure 1	15	⑥ Door weatherstrip	33
Main power supply.....	15	⑦ Body side welt	33
Ground circuit.....	15	⑧ Door waist outside molding.....	33
Procedure 2	15	⑨ Front door corner cover	34
Power supply for power window amp.		⑩ Rear windshield molding.....	34
(front and rear passengers).....	15	⑪ Trunk lid weatherstrip.....	34
Ground circuit for power window amp.		⑫ Rear combination lamp	35
(front and rear passengers).....	15	⑬ Side guard molding	35
Procedure 3	15	⑭ Center mudguard	36
Power supply for ignition signal.....	15	⑮ Front door parting seal.....	36
Component Layout.....	16	SEAT	37
Circuit Diagram for Quick Pinpoint Check	17	Front Seat.....	37
Diagnostic Procedure 1	18	Rear Seat	38
Diagnostic Procedure 2	19	2-POINT MOTORIZED AUTOMATIC SEAT BELT	
Diagnostic Procedure 3	20	SYSTEM	40
Diagnostic Procedure 4	21	Unit Location	40
Electrical Components Inspection	22	Wiring Diagram	42
Power Window Motor	22	Description.....	44
Power Window Switch.....	22	Function	44

DOOR

Front Door


- When removing door, be sure not to scratch vehicle body.
- After adjusting door or door lock, check door lock operation.




Bell crank adjustment

Lock door after setting door lock assembly and inside handle in position.


Move bell crank in direction of arrow (shown in figure at left) to take up knob free play, and secure with bolts.




Hinge-body adjustment



Striker adjustment






Door adjustment



: N·m (kg·m, ft·lb)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


DOOR – Trouble Diagnoses for Power Window



Diagnostic Procedure 2

SYMPTOM:

Passenger power windows cannot be operated by main switch and passenger switch.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

INTERIOR AND EXTERIOR

Interior (Cont'd)

LUGGAGE ROOM TRIM



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SEAT

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses



Preliminary Check (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Diagnostic Procedure 4 (Cont'd)



A

C

1) Disconnect connector from rear switch assembly.
2) Check continuity.

	Terminals
LH side	(36) - (53) (56) - Ground (B6), (B14)
RH side	(35) - (53) (56) - Ground (B6), (B14)

Continuity should exist.

N.G. → Repair harness.

O.K. →

D

Does continuity exist?

	Connector	Terminals
LH side	(B4)	(53) - Ground
RH side	(B16)	(53) - Ground

Yes → Repair harness. There will be incorrect grounding between terminals (36) and (53) or (35) and (53).

No →

Go to REAR LIMIT SWITCH in Electrical Components Inspection. (Refer to BF-67.)

O.K. → (Go to B below.)

N.G. →

Check rear limit switch harness for open or short circuit.

N.G. → Repair rear limit switch harness.

O.K. →

Replace rear switch assembly.

B

Is this the second time?

Yes → Replace control module.


No →

Reinstall any part removed.

Go to PROCEDURE 1 (STEP 3) or PROCEDURE 2 (STEP 3) in Preliminary Check. (Refer to BF-48 or BF-50.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SUNROOF




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

BODY ALIGNMENT

Underbody

MEASUREMENT




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF**
- HA
- EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Removal — Air Bag Module and Spiral Cable (Cont'd)



- Do not drop or impact air bag module. If any portion is deformed or cracked, replace the module.
- Do not expose the air bag module to temperatures exceeding 100°C (212°F).
- Do not allow oil, grease or water to come in contact with the air bag module.




3. Set steering wheel in the neutral position.
4. Disconnect horn connector and remove nuts.
5. Using steering wheel puller, remove steering wheel. Be careful not to over-tighten puller bolt on steering wheel.



6. Attach spiral cable to stopper.
7. Remove steering column cover.
8. Disconnect connector and remove the four screws. The spiral cable can then be removed.

Installation — Air Bag Module and Spiral Cable

1. Connect spiral cable connector and tighten with screws. Install steering column cover.



2. Remove stopper by pulling two pin guides.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA



EL

TROUBLE DIAGNOSES – Supplemental Restraint System (SRS)





Diagnostic Procedure 1

SYMPTOM: Warning lamp flashes.



Diagnostic Procedure 2

SYMPTOM: Warning lamp does not come on.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

PRECAUTIONS

Precautions for Servicing Compressor

- Attach a blind plug to the suction port (low pressure) and discharge port (high pressure) of the compressor to prevent oil from leaking out and dust from getting inside. GI
- Do not keep the compressor in the upside down position or laid on its side for more than 10 minutes. MA
- When replacing or repairing compressor, be sure to remove oil from the compressor and check the oil quantity extracted. EM
- When replacing with a new compressor, be sure to remove oil from the new compressor so that the quantity of oil remaining in the new compressor is equal to the quantity collected from the removed compressor. See the section "LUBRICATION OIL". LC
- Pay attention so as not to allow dirt and oil to attach on the friction surfaces between clutch and pulley. If the surface is contaminated with oil, wipe it off by using a clean waste cloth moistened with thinner. EF & EC
- After completing the compressor service operation, be sure to rotate the compressor shaft more than five turns in both directions by hand to equalize oil distribution inside the compressor, then run the compressor for about one hour by idling the engine. FE
- When the compressor magnet clutch has been replaced, be sure to check the magnet clutch for normal operation by applying voltage to the clutch.

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

PREPARATION

Precautions for Service Equipment

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturers instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

Be certain to follow the manufactures instructions for tester operation and tester maintenance.



VACUUM PUMP

The lubrication oil contained inside the vacuum pump is not compatible with the specified lubrication oil for HFC-134a (R-134a) A/C systems. Since the vent side of the vacuum pump is exposed to atmospheric pressure, it is possible for the vacuum pump lubrication oil to migrate out of the pump into the service hose if the pump is switched off after evacuation (vacuuming) and the service hose is not isolated from the vacuum pump.

To prevent the migration of vacuum pump lubrication oil into service hoses, it is necessary to use a valve (which can be manually opened or closed) near the connection of the service hose to the pump.

- On a vacuum pump which is equipped with an isolator valve (usually part of the vacuum pump), closing this valve will isolate the service hose from the pump.
- For pumps without an isolator valve, be certain that the service hose is equipped with a manual shut off valve near the pump end of the hose.
- Hoses which contain an automatic shut off valve at the end of the service hose must be disconnected from the vacuum pump to prevent the migration of lubrication oil: as long as the hose is connected, the valve is open and lubrication oil may migrate.

One-way valves which open when vacuum is applied and close under a no vacuum condition are not recommended, because this valve may restrict the pump's ability to pull a deep vacuum.



MANIFOLD GAUGE SET

Be certain that the gauge face indicates R-134a or 134a. Be certain that the manifold gauge set has the 1/2"-16 ACME threaded connections for service hoses, and that no refrigerants other than HFC-134a (R-134a) (along with only specified lubrication oils) have been used with the manifold gauge set.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

COMPRESSOR — Model DKV-14C (ZEXEL make)





Compressor Clutch (Cont'd)

INSTALLATION

- Install the field coil.

Be sure to align the coil's pin with the hole in the compressor's front head.

- Install the field coil harness clip using a screwdriver.



- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.

- Install the drive plate on the drive shaft, together with the original shim(s). Press the drive plate down by hand.

- Using the clutch disc wrench to prevent drive plate rotation, tighten the bolt to 12 to 15 N·m (1.2 to 1.5 kg-m, 9 to 11 ft-lb) torque.

After tightening the bolt, check that the pulley rotates smoothly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST




BF

HA

EL

DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)


Gauge indication	Refrigerant cycle	Probable cause	Corrective action	
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p style="text-align: center;">AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> • Check and repair or replace malfunctioning parts. • Check compressor oil for contamination. 	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EF & EC</p> <p>FE</p>
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p style="text-align: center;">AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>	<p>CL</p> <p>MT</p> <p>AT</p>
	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)</p>	<p>Replace compressor.</p>	<p>FA</p> <p>RA</p> <p>BR</p>
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p style="text-align: center;">AC353A</p>	<ul style="list-style-type: none"> • There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. • Liquid tank inlet and expansion valve are frosted. 	<p>Liquid tank inside is clogged a little.</p>	<ul style="list-style-type: none"> • Replace liquid tank. • Check compressor oil for contamination. 	<p>ST</p> <p>BF</p>
	<ul style="list-style-type: none"> • Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. • Expansion valve inlet may be frosted. • Temperature difference occurs somewhere in high-pressure side 	<p>High-pressure pipe located between receiver drier and expansion valve is clogged.</p>	<ul style="list-style-type: none"> • Check and repair malfunctioning parts. • Check compressor oil for contamination. 	<p>HA</p> <p>EL</p>

TROUBLE DIAGNOSES — Manual Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 6

Insufficient heating



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 2 (Cont'd)



A

↓

Reconnect push control module and mode door motor harness connectors.

D

CHECK FOR OUTPUT OF PUSH CONTROL MODULE.

Do approx. 12 volts exist between push control module harness terminal No. ⑦ and ⑧ when mode is switched from "VENT" to "DEF" or when mode is switched from "DEF" to "VENT"?

Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
⊖	⊖	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counterclockwise


N.G. → Replace push control module.

O.K.

↓

Replace mode door motor.

- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL



Electrical Components Inspection

FAN SWITCH

Check continuity between terminals at each position.

TERMINAL	POSITION				
	OFF	1	2	3	4
28					○
29				○	○
30			○	○	○
31		○	○	○	○
32		○	○	○	○
104		○	○	○	○

GI

MA

EM


LC

EF &
EC

FE

CL

MT



BLOWER MOTOR

Check blower motor for smooth rotation.


- Ensure that there are no foreign particles inside the intake unit.

AT

FA

RA

BR




BLOWER RESISTOR

Check continuity between terminals.

ST

BF

HA




A/C SWITCH

Check continuity between terminals.

EL

TROUBLE DIAGNOSES – Auto Air Conditioning

Self-diagnosis (Cont'd)



If temperature shown on display greatly differs from actual temperature, check sensor circuit at first then inspect sensor itself according to the procedures described in **Control System Input Components**. Refer to HA-114.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 4

Insufficient heating



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR




ST

BF

HA


EL

TROUBLE DIAGNOSES — Auto Air Conditioning



Diagnostic Procedure 1






SYMPTOM: Ambient sensor circuit is open or shorted. (\mathcal{L} or ECON \mathcal{L} is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)



Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Diagnostic Procedure 9

SYMPTOM: Blower motor operation is malfunctioning under out of Starting Fan Speed Control.

- Perform Preliminary Check 5 before referring to the following flow chart.




Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SYSTEM DESCRIPTION – Auto Air Conditioning

Control System Input Components (Cont'd)


AMBIENT SENSOR



The ambient sensor is attached to hood lock stay. It detects ambient temperature and converts it into a resistance value which is then input to the auto amplifier.

After disconnecting ambient sensor harness connector, measure resistance between terminals ③④ and ③⑨ at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
- 15 (5)	12.73
- 10 (14)	9.92
- 5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07



SUNLOAD SENSOR

The sunload sensor is located on the right defroster grille. It detects sunload entering through windshield by means of a photo diode and converts it into a current value which is then input to the auto amplifier.

Measure voltage between terminals ②⑥ and ③⑧ at vehicle harness side, using the table below.

Input current mA	Output voltage V
0	5.0
0.1	4.1
0.2	3.1
0.3	2.2
0.4	1.3
0.5	0.4

- When checking sunload sensor, select a place where sun shines directly on it.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COMPRESSOR

Model	DKV-14C
Type	Vane rotary
Displacement cm ³ (cu in)/Rev	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	Poly V type

LUBRICATION OIL

Model	ZEXEL make DKV-14C
Name	Nissan A/C System Oil Type R
Part No.	KLH00-RAGR0
Capacity ml (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Compressor (Service part) charging amount	200 (6.8, 7.0)

REFRIGERANT

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.70 - 0.80 (1.54 - 1.76)

Inspection and Adjustment

ENGINE IDLING SPEED

When A/C is ON

- Refer to EF & EC section ("Inspection and Adjustments", "SERVICE DATA AND SPECIFICATIONS").

BELT TENSION

- Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

COMPRESSOR

Model	DKV-14C
Clutch disc-pulley clearance mm (in)	0.3 - 0.6 (0.012 - 0.024)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

POWER SUPPLY ROUTING Wiring Diagram (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident. ... Replace.

GI
MA
EM
LC

Service Data and Specifications (SDS)

STARTER

EF &
EC

Type	M1T73881ZC		S114-754	
	MELMAC		HAP	
	Reduction gear type			
Applied model	A/T		M/T	
System voltage	V	12		
No-load				
Terminal voltage	V	11.0		
Current	A	Less than 88	Less than 85	
Revolution	rpm	More than 3,000	More than 2,950	
Minimum diameter of commutator	mm (in)	28.8 (1.134)	28.0 (1.102)	
Minimum length of brush	mm (in)	12.0 (0.472)	10.5 (0.413)	
Brush spring tension	N (kg, lb)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	14.7 - 17.7 (1.5 - 1.8, 3.3 - 4.0)	
Clearance of bearing metal and armature shaft	mm (in)	—	0.03 - 0.3 (0.0012 - 0.0118)	
Clearance "ℓ" between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	0.05 - 1.5 (0.0020 - 0.0591)	
Installed current	A	140	120	


FE
CL
MT
AT
FA
RA
BR
ST
BF

HA



HEADLAMP

Schematic (For Canada)



MEL840B




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

METER AND GAUGES


Inspection/Speedometer and Vehicle Speed Sensor (Cont'd)

SYMPTOM: Speedometer indication flutters.



Inspection/Speedometer and Fuse

SYMPTOM: Speedometer does not go back to 0 km/h (0 MPH).



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL