

Edition: August 2004  
 Revision: July 2005  
 Publication No. SM5E-1S50U1



**FX35/FX45**

**MODEL S50 SERIES**



**INFINITI**

© 2005 NISSAN MOTOR CO.,LTD.

**QUICK REFERENCE INDEX**

<b>A GENERAL INFORMATION</b>	GI General Information
<b>B ENGINE</b>	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	ACC Accelerator Control System
	AT Automatic Transmission
<b>C TRANSMISSION/ TRANSAXLE</b>	
<b>D DRIVELINE/AXLE</b>	TF Transfer
	PR Propeller Shaft
	FFD Front Final Drive
	RFD Rear Final Drive
	FAX Front Axle
	RAX Rear Axle
	FSU Front Suspension
	RSU Rear Suspension
<b>E SUSPENSION</b>	WT Road Wheels & Tires
	BR Brake System
	PB Parking Brake System
<b>F BRAKES</b>	BRC Brake Control System
	PS Power Steering System
	SB Seat Belts
<b>G STEERING</b>	SRS Supplemental Restraint System (SRS)
<b>H RESTRAINTS</b>	BL Body, Lock & Security System
<b>I BODY</b>	GW Glasses, Window System & Mirrors
	RF Roof
	EI Exterior & Interior
	IP Instrument Panel
	SE Seat
	ATC Automatic Air Conditioner
	SC Starting & Charging System
<b>J AIR CONDITIONER</b>	LT Lighting System
	DI Driver Information System
	WW Wiper, Washer & Horn
	BCS Body Control System
	LAN LAN System
	AV Audio Visual, Navigation & Telephone System
	ACS Auto Cruise Control System
	PG Power Supply, Ground & Circuit Elements
	MA Maintenance
	LDX Alphabetical Index
<b>K ELECTRICAL</b>	
<b>L MAINTENANCE</b>	
<b>M INDEX</b>	

**A**  
**B**  
**C**  
**D**  
**E**  
**F**  
**G**  
**H**  
**I**  
**J**  
**K**  
**L**  
**M**

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of Nissan Motor Company Ltd., Tokyo, Japan.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

5. When self-diagnosis mode is started, DTC are shown on set vehicle speed indicator.

**CAUTION:**

- DTC will disappear after 5 minutes.
  - When more than one malfunctions are detected, a maximum of 3 code numbers can be stored; the latest malfunction will be displayed first.
6. Check [ACS-41, "Diagnostic Trouble Code \(DTC\) Chart"](#), and repair or replace if necessary.
  7. After repair, erase DTC stored in the ICC unit.
  8. DTC 55 will be shown.
  9. Turn ignition switch OFF to exit the diagnosis.
  10. Perform ICC system running test (drive vehicle with ICC system ON), and make sure that ICC warning lamp (Orange) does not illuminate.

**Self-Diagnostic Erasing Method**

1. Stop the vehicle and turn the ignition switch OFF.
2. Turn ignition switch ON and start self-diagnosis.
3. During self-diagnosis mode, press CANCEL switch 5 times, and DISTANCE switch 5 times in this order.

**CAUTION:**

- Press them within 10 seconds after pressing CANCEL switch at first.
  - When operation is not completed within 10 seconds, start again from above go to 2.
4. DTC 55 will be shown.
- CAUTION:**  
DTC of an existing malfunction will not be erased.
5. Turn ignition switch OFF to exit the diagnosis.
  6. Perform ICC system running test (drive vehicle with ICC system ON), and make sure that ICC system warning lamp (Orange) does not illuminate.

# PREPARATION






PFP:00002

## PREPARATION

### Special Service Tools

ACS002L9

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST2505S001 (J-34301-C) Oil pressure gauge set 1. ST25051001 ( — ) Oil pressure gauge 2. ST25052000 ( — ) Hose 3. ST25053000 ( — ) Joint pipe 4. ST25054000 ( — ) Adapter 5. ST25055000 ( — ) Adapter	 <p>Measuring line pressure</p>
KV31103600 (J-45674) Joint pipe adapter (With ST25054000)	 <p>Measuring line pressure</p>
ST33400001 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.	 <ul style="list-style-type: none"> <li>● Installing rear oil seal (2WD models)</li> <li>● Installing oil pump housing oil seal</li> </ul>
KV31102400 (J-34285 and J-34285-87) Clutch spring compressor a: 320 mm (12.60 in) b: 174 mm (6.85 in)	 <p>Installing reverse brake return spring retainer</p>
ST25850000 (J-25721-A) Sliding hammer a: 179 mm (7.05 in) b: 70 mm (2.76 in) c: 40 mm (1.57 in) d: M12X1.75P	 <p>Removing oil pump assembly</p>

# TROUBLE DIAGNOSIS

ACS002M0

## Check at Idle

### 1. CHECK STARTING THE ENGINE

---

1. Park vehicle on level surface.
2. Move selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Start engine.

Does the engine start?

YES >> GO TO 2.

NO >> Stop the road test and go to [AT-194, "Engine Cannot Be Started in "P" or "N" Position"](#) .

### 2. CHECK STARTING THE ENGINE

---

1. Turn ignition switch to ON.
2. Move selector lever in "D", "M" or "R" position.
3. Start engine.

Does the engine start in each position?

YES >> Stop the road test and go to [AT-194, "Engine Cannot Be Started in "P" or "N" Position"](#) .

NO >> GO TO 3.

### 3. CHECK "P" POSITION FUNCTIONS

---

1. Move selector lever to "P" position.
2. Turn ignition switch OFF.
3. Disengage the parking brake.
4. Push the vehicle forward or backward.
5. Engage the parking brake.

When you push the vehicle with disengaging the parking brake, does it move?

YES >> Enter a check mark at "In "P" Position Vehicle Moves When Pushed" on the [AT-47, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

NO >> GO TO 4.

### 4. CHECK "N" POSITION FUNCTIONS

---

1. Start engine.
2. Move selector lever to "N" position.
3. Disengage the parking brake.

Does vehicle move forward or backward?

YES >> Enter a check mark at "In "N" Position Vehicle Moves" on the [AT-47, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

NO >> GO TO 5.

### 5. CHECK SHIFT SHOCK

---

1. Engage the brake.
2. Move selector lever to "D" position.

When the transmission is shifted from "N" to "D", is there an excessive shock?

YES >> Enter a check mark at "Large Shock ("N" to "D" Position)" on the [AT-47, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

NO >> GO TO 6.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

## 4. CHECK SELF-DIAGNOSIS CODE

Check A/T CHECK indicator lamp. Refer to [AT-104, "Judgement Self-diagnosis Code"](#).  
 If the system does not go into self-diagnostics. Refer to [AT-114, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#), [AT-170, "DTC P1815 MANUAL MODE SWITCH"](#), [AT-187, "CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT"](#), [AT-188, "BRAKE SIGNAL CIRCUIT"](#).


>> **DIAGNOSIS END**

### Judgement Self-diagnosis Code


If there is a malfunction, the lamp lights up for the time corresponding to the suspect circuit.

No.	Malfunctioning item	No.	Malfunctioning item
1	Revolution sensor <a href="#">AT-118</a>	10	A/T fluid temperature sensor <a href="#">AT-136</a>
2	Direct clutch solenoid valve <a href="#">AT-158</a> , <a href="#">AT-160</a>	11	Turbine revolution sensor <a href="#">AT-141</a>
3	Torque converter clutch solenoid valve <a href="#">AT-125</a> , <a href="#">AT-127</a>	12	A/T interlock <a href="#">AT-145</a>
4	Line pressure solenoid valve <a href="#">AT-129</a>	13	A/T 1st engine braking <a href="#">AT-148</a>
5	Input clutch solenoid valve <a href="#">AT-150</a> , <a href="#">AT-152</a>	14	Start signal <a href="#">AT-109</a>
6	Front brake solenoid valve <a href="#">AT-154</a> , <a href="#">AT-156</a>	15	Accelerator pedal position sensor <a href="#">AT-133</a>
7	Low coast brake solenoid valve <a href="#">AT-166</a> , <a href="#">AT-168</a>	16	Engine speed signal <a href="#">AT-123</a>
8	High and low reverse clutch solenoid valve <a href="#">AT-162</a> , <a href="#">AT-164</a>	17	CAN communication line <a href="#">AT-106</a>
9	PNP switch <a href="#">AT-114</a>		

All circuits that can be confirmed by self-diagnosis are OK.



Example: No.4 Line pressure solenoid valve



SCIA5767E

# DTC P1752 INPUT CLUTCH SOLENOID VALVE

ACS002P0

## Diagnostic Procedure

### 1. CHECK INPUT SIGNAL

#### With CONSULT-II

1. Turn ignition switch ON. (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "I/C SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch disengaged. Refer to <a href="#">AT-21</a> .	0.6 - 0.8 A
	Input clutch engaged. Refer to <a href="#">AT-21</a> .	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

#### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 2.

### 2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-183, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-243, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#) .  
NG >> Repair or replace damaged parts.

### 4. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-158, "DTC Confirmation Procedure"](#) .

#### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 2.


# TROUBLE DIAGNOSIS FOR SYMPTOMS

## 4. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Refill ATF.




## 5. CHECK LINE PRESSURE

Check line pressure at idle with selector lever in "D" position. Refer to [AT-54, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 8.
- NG - 1 >> Line pressure high: GO TO 6.
- NG - 2 >> Line pressure low: GO TO 7.



## 6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-243, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-290, "DISASSEMBLY"](#) .
3. Check the following.
  - Oil pump assembly. Refer to [AT-308, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

## 7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-243, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-290, "DISASSEMBLY"](#) .
3. Check the following.
  - Oil pump assembly. Refer to [AT-308, "Oil Pump"](#) .
  - Power train system. Refer to [AT-290, "DISASSEMBLY"](#) .
  - Transmission case. Refer to [AT-290, "DISASSEMBLY"](#) .


OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.


# ON-VEHICLE SERVICE

11. Disconnect A/T fluid temperature sensor 2 connector.

**CAUTION:**  
Be careful not to damage connector.




12. Straighten terminal clips to free terminal cord assembly and A/T fluid temperature sensor 2 harness.




13. Disconnect revolution sensor connector.

**CAUTION:**  
Be careful not to damage connector.




14. Straighten terminal clips to free revolution sensor harness.



15. Remove bolts A, B and C from control valve with TCM.


Bolt symbol	Length mm (in)	Number of bolts
A	42 (1.65)	5
B	55 (2.17)	6
C	40 (1.57)	1




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DISASSEMBLY

9. Remove bearing race from oil pump assembly.




10. Remove needle bearing from front sun gear.




11. Remove front sun gear assembly from front carrier assembly.

**NOTE:**

Remove front sun gear by rotating left/right.




12. Remove seal rings from input clutch assembly.



13. Remove front carrier assembly from rear carrier assembly. (With input clutch assembly and rear internal gear.)

**CAUTION:**


Be careful to remove it with needle bearing.




# ASSEMBLY

41. Install bearing race in rear carrier assembly.

**CAUTION:**  
Apply petroleum jelly to bearing race.




42. Install rear carrier assembly in direct clutch drum.




43. Install needle bearing (rear side) to mid carrier assembly.

**CAUTION:**  
Apply petroleum jelly to needle bearing.




44. Install needle bearing (front side) to mid carrier assembly.

**CAUTION:**  
Apply petroleum jelly to needle bearing.



45. Install mid carrier assembly in rear carrier assembly.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# AIR CONDITIONER CONTROL

## Stop Signal:

At the end of each transmission, a stop operation, in-operation, or internal malfunction message is delivered to the unified meter and A/C amp. This completes one data transmission and control cycle.



## AIR MIX DOOR CONTROL (AUTOMATIC TEMPERATURE CONTROL)

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a predetermined value by the temperature setting, ambient temperature, in-vehicle temperature and amount of sunload.

## FAN SPEED CONTROL

Blower speed is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.

With pressing AUTO switch, the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

## INTAKE DOOR CONTROL

The intake doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON-OFF operation of the compressor.

## OUTLET DOOR CONTROL

The outlet door is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

# TROUBLE DIAGNOSIS


AJS0014X

## Blower Motor Circuit

SYMPTOM: Blower motor operation is malfunctioning.

### INSPECTION FLOW


1. Confirm symptom by performing the following operational check.



**OPERATIONAL CHECK - Blower**

- Press fan control (UP) switch. Blower should operate on low speed.
- Press fan control (UP) switch, and continue checking blower speed and fan symbol until all speeds are checked.

**If OK (symptom cannot be duplicated), perform complete operational check (\*1).  
If NG (symptom is confirmed), continue with STEP-2 following.**



RJIA1994E

\*1 [ATC-61, "Operational Check"](#)

\*2 [ATC-113, "Intake Sensor Circuit"](#)

\*3 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No.4.

\*4 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No.6.

\*5 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No.13.

\*6 [ATC-81, "DIAGNOSIS PROCEDURE FOR BLOWER MOTOR"](#)

\*7 [ATC-42, "SYMPTOM TABLE"](#)

\*8 [ATC-104, "Ambient Sensor Circuit"](#)

\*9 [ATC-107, "In-vehicle Sensor Circuit"](#)

\*10 [ATC-110, "Sunload Sensor Circuit"](#)

\*11 [EC-208, "DTC P0117, P0118 ECT SENSOR" \(VQ35DE\) or EC-914, "DTC P0117, P0118 ECT SENSOR" \(VK45DE\)](#)

# HEATER & COOLING UNIT ASSEMBLY

## HEATER & COOLING UNIT ASSEMBLY

PFP:27110

### Removal and Installation REMOVAL


AJS0015J

1. Use a refrigerant collecting equipment (for HFC-134a) to discharge refrigerant.
2. Drain coolant from cooling system. Refer to [CO-11, "Changing Engine Coolant"](#) (VQ35DE) or [CO-37, "Changing Engine Coolant"](#) (VK45DE).
3. Remove cowl top cover. Refer to [EI-23, "COWL TOP"](#) .
4. Remove high-pressure pipe 2 mounting clip.
5. Remove low-pressure flexible hose bracket mounting bolt.
6. Disconnect low-pressure pipe 1 and high-pressure pipe 2 from evaporator.
  - a. Set a disconnecter [High-pressure side (SST: 9253089908), Low-pressure side (SST: 9253089916)] on A/C piping.
  - b. Slide a disconnecter toward vehicle front until it clicks.
  - c. Slide A/C piping toward vehicle front and disconnect it.



#### CAUTION:

**Cap or wrap the joint of the pipe with suitable material such as vinyl tape to avoid the entry of air.**

7. Remove electric throttle control actuator (VQ35DE). Refer to [EM-19, "INTAKE MANIFOLD COLLECTOR"](#) .



8. Disconnect two heater hoses from heater core.
9. Remove instrument panel assembly. Refer to [IP-11, "Removal and Installation"](#) .
10. Remove blower unit. Refer to [ATC-121, "BLOWER UNIT"](#) .




# AUDIO

## Wiring Diagram - AUDIO - / Base System

AKS007X2

AV-AUDIO-01



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

10	8	4	2
9	7	6	5
M58			
W			

REFER TO THE FOLLOWING.  
 (E211) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2070E

# INTEGRATED DISPLAY SYSTEM

## DRIVE COMPUTER

Refer to Owner's Manual for drive computer operating instructions.

### TRIP Switch

When "TRIP" switch is pressed, display TRIP screen. As TRIP information, it indicates journey time (TIME), trip odometer (DIST), average vehicle speed (AVG).

Pressing "TRIP" switch once cycles display from TRIP 1→TRIP 2→Display OFF→TRIP 1.

#### "TIME"


- Journey time indication is performed by reset or battery connection.
- When pushing "TRIP RESET" or "TRIP" switch more than approximately 1.5 seconds, journey time will be reset.
- If journey time is reset, journey distance and average speed will be reset at the same time.

#### "DIST"

- Trip odometer indication is performed by vehicle speed signal.
- When pushing "TRIP RESET" or "TRIP" switch more than approximately 1.5 seconds, driving distance will be reset.
- If trip odometer is reset, journey time and average speed will be reset at the same time.

#### "AVG"

- Average speed indication is performed by running distance and running time.
- Indication will be renewed every 30 seconds.
- When pushing "TRIP RESET" or "TRIP" switch more than approximately 1.5 seconds, average speed will be reset.
- After reset operation, the displays shows "\*" for 30 seconds.



### FUEL ECON Switch

When "FUEL ECON" switch is pressed, display FUEL ECON screen. As FUEL ECON information, it indicates average fuel consumption (AVG), distance to empty (DTE).


Pressing "FUEL ECON" switch once cycles display from FUEL ECON→Display OFF→FUEL ECON.

#### "AVG" (Average Fuel Consumption)

- Average fuel consumption indication is performed by fuel consumption signal and vehicle speed signal after system is reset.
- Indication will be renewed every 30 seconds.
- When pushing "TRIP RESET" or "FUEL ECON" switch more than approximately 1.5 seconds, average fuel economy will be reset.
- After reset operation, the display shows "\*.\*" until the vehicle is driven 500 m (1,600 ft.) or 30 seconds has passed.

#### "DTE" (Distance to Empty)

- Distance to empty receives via CAN communication and indicates values calculated by meter.
- Display range is max 999 miles (max 999 km).
- If low-fuel WARNING is received from meter via CAN communication, distance to empty indication will be "\*".
- Indication will be renewed every 30 seconds.




# NAVIGATION SYSTEM

## Schematic—NAVI—

AKS0071S

\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).



TKWM2083E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

# NAVIGATION SYSTEM


## 5. CHECK 3: AUDIO-TX COMMUNICATION SIGNAL

Check signal between display control unit harness connector M76 terminal 40 (LG) and ground with CONSULT-II or oscilloscope.

**40 (LG) - Ground** : Refer to [AV-121, "Terminals and Reference Value for Display Control Unit"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace audio unit.




## 6. CHECK 4: AUDIO-RX COMMUNICATION SIGNAL

Check signal between display control unit harness connector M76 terminal 42 (B/Y) and ground with CONSULT-II or oscilloscope.

**42 (B/Y) - Ground** : Refer to [AV-121, "Terminals and Reference Value for Display Control Unit"](#) .

OK or NG

- OK >> Replace audio unit.
- NG >> Replace display control unit.



## Display Communication Line Check (Between Display Control Unit and Display)

AKS007JJ

### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect display connector and display control unit connector.
3. Check continuity between display control unit and Display.


Terminals				Continuity
Display control unit		Display		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M76	36 (PU)	M63	11 (PU)	Yes
	38 (LG)		22 (LG)	

4. Check continuity between display control unit and ground.

Terminals			Continuity
Display control unit		Terminal	
Connector	Terminal (Wire color)		
M76	36 (PU)	Ground	No
	38 (LG)		


OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.




# INFINITI MOBILE ENTERTAINMENT SYSTEM

3. Remove screws (4) with power tool.



4. Pull DVD display unit to downside, and remove rear display unit from mounting plate.



## INSTALLATION

Installation is the reverse order of removal.

### **CAUTION:**







**Put metal clip hook in mounting plate, and press it securely.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# POWER DOOR LOCK SYSTEM

FIG. 5

BL-D/LOCK-05



REFER TO THE FOLLOWING.  
 (B1), (B201), (D31) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M4) -ELECTRICAL UNITS

TIWH0037E

# REMOTE KEYLESS ENTRY SYSTEM


## 3. CHECK GROUND CIRCUIT

Check continuity between back door closure motor connector D109 terminal 8 and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness.




## 4. CHECK BACK DOOR SWITCH

Check continuity between back door closure motor D109 terminals 7 and 8.

Terminals		Back door condition	Continuity
7	8	Open	Yes
		Close	No

OK or NG

- OK >> GO TO 5.
- NG >> Replace back door closure motor.




## 5. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

**58 (L) – Ground : Approx. 9V**

OK or NG

- OK >> Check condition of harness and connector.
- NG >> Replace BCM.



A  
B  
C  
D  
E  
F  
G  
H  
BL  
J  
K  
L  
M

# INTELLIGENT KEY SYSTEM

## DOOR LOCK FUNCTION MALFUNCTION


Before conducting the diagnosis in the following table, check all power door lock system function. Refer to [BL-21, "POWER DOOR LOCK SYSTEM"](#) .

Symptom	Diagnoses service procedure	Refer to page
Door lock/unlock does not operate when door request switch operation is used (power door lock system is normal).	1. Check door lock/unlock setting	<a href="#">BL-120</a>
	2. Check outside key antenna	<a href="#">BL-140</a>
	3. Intelligent Key battery inspection	<a href="#">BL-152</a>
	4. Replace Intelligent Key unit	<a href="#">BL-151</a>
Door lock/unlock do not operate using door request switch operated (power door lock system is normal).	1. Check door switch	<a href="#">BL-133</a>
	2. Check key switch (Intelligent Key unit input)	<a href="#">BL-129</a>
	3. Check ignition knob switch	<a href="#">BL-132</a>
	4. Replace Intelligent Key unit	<a href="#">BL-151</a>
Driver side selective door unlock function does not operate, when door request switch is operated. (All other door lock function is OK.)	1. Check selective door unlock setting	<a href="#">BL-120</a>
	2. Replace BCM	<a href="#">BCS-16</a>
Passenger side selective door unlock function does not operate, when door request switch is operated. (All other door lock function is OK.)	1. Check selective door unlock setting	<a href="#">BL-120</a>
	2. Check passenger side select unlock relay	<a href="#">BL-149</a>
	3. Replace Intelligent Key unit	<a href="#">BL-151</a>
Hazard lamps do not flash during door lock operation using door request switch operated. (Turn signal lamp operation is normal.) (All other door lock function is OK.)	1. Check key reminder setting	<a href="#">BL-120</a>
	2. Replace BCM	<a href="#">BCS-16</a>
	3. Replace Intelligent Key unit	<a href="#">BL-151</a>
Hazard lamps do not flash during door lock operation using door request switch operated. (Turn signal lamps do not operate.)	Check hazard function	<a href="#">BL-150</a>
Intelligent Key warning buzzer does not sound during door lock/unlock operation using Intelligent Key (regardless of whether Intelligent Key remote controller button or request switch operation is used).	1. Check if the operation confirmation Intelligent Key warning buzzer was cancelled by the CONSULT-II settings change function	<a href="#">BL-120</a>
	2. Check Intelligent Key warning buzzer	<a href="#">BL-139</a>
	3. Replace Intelligent Key unit	<a href="#">BL-151</a>
Door lock/unlock operation confirmation Intelligent Key warning buzzer sounds, but door lock actuator does not operate. (And hazard lamps do not flash.)	1. Check CAN communication	<a href="#">BL-128</a>
	2. Replace Intelligent Key unit	<a href="#">BL-151</a>

# BACK DOOR AUTO CLOSURE SYSTEM

## OPEN OPERATION

- When passenger side door unlock and back door shuts, back door opener switch is pushed.
- Back door closure control unit receives the signal, closure motor is operated in an open direction, and back door opens.
- Closure motor is operated in the close direction and stops at a neutral position when the following conditions detected after turning on open switch.
  - When back door is in half-open state, and
  - 5 seconds past without opening back door.



A  
B  
C  
D  
E  
F  
G  
H  
BL  
J  
K  
L  
M



# IVIS (INFINITI VEHICLE IMMOBILIZER SYSTEM-NATS)

## MODELS WITHOUT INTELLIGENT KEY SYSTEM


BL-NATS-03

▬ : DATA LINE


REFER TO PG-POWER.



(M5)  
W



(M25)  
W



(M38)  
BR

REFER TO THE FOLLOWING.

- (E21) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4), (M90) -ELECTRICAL UNITS

# BODY REPAIR

## Precautions In Repairing High Strength Steel

AIS0034X

High strength steel is used for body panels in order to reduce vehicle weight. Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

### HIGH STRENGTH STEEL (HSS) USED IN NISSAN VEHICLES

Tensile strength	Nissan/Infiniti designation	Major applicable parts
373 N/mm <sup>2</sup> (38kg/mm <sup>2</sup> ,54klb/sq in)	SP130	<ul style="list-style-type: none"><li>● Front &amp; rear side member assembly</li><li>● Hoodledge assembly</li><li>● Lower dash</li><li>● Hood</li><li>● Other reinforcements</li></ul>

SP130 is the most commonly used HSS.

SP150 HSS is used only on parts that require much more strength.

A  
B  
C  
D  
E  
F  
G  
H  
BL  
J  
K  
L  
M


# VACUUM LINES

## VACUUM LINES

PFP:41920

### Removal and Installation


AFS001N8



- |                  |                |   |
|------------------|----------------|---|
| 1. Clamp         | 2. Vacuum hose | 3. Clamp                                |
| 4. Vacuum piping | 5. Clamp       | 6. Check valve inclusion position stamp |
| 7. Vacuum hose   | 8. Clamp       | 9. Brake booster                        |

#### CAUTION:

- Because vacuum hose contains a check valve, it must be installed in the correct direction. Refer to the stamp or label to confirm correct installation. The brake booster will not operate normally if hose is installed in the wrong direction.
- Insert vacuum hose for at least 24 mm (0.94 in).
- Do not use lubricating oil during assembly.



#### Inspection VISUAL INSPECTION

Check for improper assembly, damage and deterioration.

AFS001N9

# TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Item (Unit)	Data monitor item selection			Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
CRANKING SIG (ON/OFF)	-	-	×	Cranking condition (ON/OFF) status is displayed.
4WD FAIL REQ (ON/OFF)	-	-	×	AWD fail-safe signal (ON/OFF) status is displayed.
2WD/4WD (2WD/4WD)	-	-	×	Distinguish 2WD and AWD

×:Applicable

-:Not applicable

Note: Serves as EBD warning lamp.

## ACTIVE TEST

### CAUTION:

- Do not perform active test while driving.
- Make sure to completely bleed air from the brake system.
- Active test can not be performed when EBD, ABS, TCS or VDC operation is malfunction.
- ABS and brake warning lamps turn on during the active test.


## Operation Procedure

1. Connect CONSULT-II and CONVERTER to data link connector and start engine.

### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which performs CAN communication.

2. Touch "START (NISSAN BASED VHCL)" on the display screen.
3. Touch "ABS".  
If "ABS" is not indicated, go to [GI-39. "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
4. Touch "ACTIVE TEST".
5. The test item selection screen is displayed.
6. Touch necessary test item.



7. With the "MAIN SIGNALS" display shown in reverse, touch "START".
8. The "ACTIVE TEST" screen will be displayed, so perform the following test.


## Solenoid Valve Operation Chart

Operation	ABS solenoid valve			ABS solenoid valve (ACT)		
	UP	KEEP	DOWN	UP	ACTUATOR UP	ACTUATOR KEEP
FR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
FR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
FR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
FR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
RR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
RR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF

# RADIATOR

[VQ35DE]

- Pull negative-pressure valve to open it, and make sure that it close completely when released.
- Make sure that there is no dirt or damage on the valve seat of radiator cap negative-pressure valve.
- Make sure that there are no unusualness in the opening and closing conditions of negative-pressure valve.



- Check radiator cap relief pressure.


**Standard:**

**78 - 98 kPa (0.8 - 1.0 kg/cm<sup>2</sup> , 11 - 14 psi)**

**Limit:**

**59 kPa (0.6 kg/cm<sup>2</sup> , 9 psi)**

- When connecting radiator cap to the radiator cap tester (commercial service tool) and the radiator cap tester adapter [SST], apply engine coolant to the cap seal surface.



- Replace radiator cap if there is an unusualness related to the above three.

**CAUTION:**

**When installing radiator cap, thoroughly wipe out the radiator filler neck to remove any waxy residue or foreign material.**

## Checking Radiator

ABS008FX

Check radiator for mud or clogging. If necessary, clean radiator as follows.

- Be careful not to bend or damage radiator fins.
  - When radiator is cleaned without removal, remove all surrounding parts such as radiator cooling fan assembly and horns. Then tape harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downward.
  2. Apply water again to all radiator core surfaces once per minute.
  3. Stop washing if any stains no longer flow out from radiator.
  4. Blow air into the back side of radiator core vertically downward.
    - Use compressed air lower than 490 kPa (5 kg/cm<sup>2</sup> , 71 psi) and keep distance more than 30 cm (11.81 in).
  5. Blow air again into all the radiator core surfaces once per minute until no water sprays out.

# COMBINATION METERS

## SPEEDOMETER

ABS actuator and electric unit (control unit) provides a vehicle speed signal to the unified meter and A/C amp. with CAN communication line. After unified meter and A/C amp. received the vehicle speed signal, it changes the signal to 8 pulse signal and provides the 8 pulse signal to the combination meter for the speedometer.

## TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm). ECM provides an engine speed signal to unified meter and A/C amp. with CAN communication line. Unified meter and A/C amp. provides an engine speed signal to combination meter for tachometer with communication line between unified meter and A/C amp. and combination meter.

## WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. ECM provides an engine coolant temperature signal to unified meter and A/C amp. with CAN communication line. Unified meter and A/C amp. provides a engine coolant temperature signal to combination meter for water temperature gauge with communication line between unified meter and A/C amp. and combination meter.

## FUEL GAUGE


The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable ground signal supplied

- from unified meter and A/C amp. terminal 36
- through the fuel level sensor unit and fuel pump (main) terminals 5 and 2, and
- through the fuel level sensor unit (sub) terminals 2 and 1
- to unified meter and A/C amp. terminal 28 for the fuel gauge.

Unified meter and A/C amp. provides a fuel level signal to combination meter for fuel gauge with communication line between unified meter and A/C amp. and combination meter.

## Component Parts and Harness Connector Location

AKS005M1



PKIB1955E

# A/T INDICATOR

PFP:24814




AKS005NI

## A/T INDICATOR

### Wiring Diagram — AT/IND —

## DI-AT/IND-01

▬ : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM1282E

# LANE DEPARTURE WARNING SYSTEM

Monitored Item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
WARN LANE RH [ON/OFF]	×	×	Displays warning for right lane.
VALID POS LH [VLD/INVLD]	×	×	Displays lateral position for left lane marker is valid.
VALID POS RH [VLD/INVLD]	×	×	Displays lateral position for right lane marker is valid.
AIMING DONE [OK/NG]	×	×	Displays camera aiming done.
AIMING RESULT [OK/NOK]	×	×	Displays camera aiming result.
FCTRY AIM YAW [deg]	×	×	Displays camera unit installation condition.
FCTRY AIM ROLL [deg]	×	×	Displays camera unit installation condition.
FCTRY AIM PIT [deg]	×	×	Displays camera unit installation condition.
XOFFSET [pixel]	×	×	Displays camera unit installation condition.

## ACTIVE TEST

### CAUTION:

- Never perform the active test while driving.
  - Active test cannot be started while LDW indicator lamp is illuminated.
1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen. Refer to [DI-98, "CONSULT-II BASIC OPERATION"](#).
  2. Touch any field, "BUZZER DRIVE", "SYSTEM ON LAMP DRIVE" and "INDICATOR LAMP DRIVE", on selection screen.
  3. Touch necessary item and "START".
  4. Active test screen will be shown.

### Active Test Item

Active test item	Operation item	Function	Reference page
BUZZER DRIVE	LDW chime	This test is able to check LDW chime operation.	<a href="#">DI-101</a>
SYSTEM ON LAMP DRIVE	LDW system ON indicator	This test is able to check LDW system ON indicator operation.	<a href="#">DI-102</a>
INDICATOR LAMP DRIVE	LDW indicator lamp	This test is able to check LDW indicator lamp operation.	<a href="#">DI-102</a>


## BUZZER DRIVE

Touch "ON" and "OFF" to check if LDW chime operates as follows.

### "BUZZER DRIVE"

**Touch "ON" : LDW chime is activated.**


**Touch "OFF" : LDW chime is not activated.**



# INDEX FOR DTC

[VQ35DE]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0302	0302	CYL 2 MISFIRE	<a href="#">EC-285</a>
P0303	0303	CYL 3 MISFIRE	<a href="#">EC-285</a>
P0304	0304	CYL 4 MISFIRE	<a href="#">EC-285</a>
P0305	0305	CYL 5 MISFIRE	<a href="#">EC-285</a>
P0306	0306	CYL 6 MISFIRE	<a href="#">EC-285</a>
P0327	0327	KNOCK SEN/CIRC-B1	<a href="#">EC-295</a>
P0328	0328	KNOCK SEN/CIRC-B1	<a href="#">EC-295</a>
P0335	0335	CKP SEN/CIRCUIT	<a href="#">EC-300</a>
P0340	0340	CMP SEN/CIRC-B1	<a href="#">EC-307</a>
P0345	0345	CMP SEN/CIRC-B2	<a href="#">EC-307</a>
P0420	0420	TW CATALYST SYS-B1	<a href="#">EC-316</a>
P0430	0430	TW CATALYST SYS-B2	<a href="#">EC-316</a>
P0441	0441	EVAP PURG FLOW/MON	<a href="#">EC-322</a>
P0442	0442	EVAP SMALL LEAK	<a href="#">EC-327</a>
P0444	0444	PURG VOLUME CONT/V	<a href="#">EC-336</a>
P0445	0445	PURG VOLUME CONT/V	<a href="#">EC-336</a>
P0447	0447	VENT CONTROL VALVE	<a href="#">EC-343</a>
P0451	0451	EVAP SYS PRES SEN	<a href="#">EC-350</a>
P0452	0452	EVAP SYS PRES SEN	<a href="#">EC-353</a>
P0453	0453	EVAP SYS PRES SEN	<a href="#">EC-359</a>
P0455	0455	EVAP GROSS LEAK	<a href="#">EC-367</a>
P0456	0456	EVAP VERY SML LEAK	<a href="#">EC-375</a>
P0460	0460	FUEL LEV SEN SLOSH	<a href="#">EC-385</a>
P0461	0461	FUEL LEVEL SENSOR	<a href="#">EC-387</a>
P0462	0462	FUEL LEVL SEN/CIRC	<a href="#">EC-389</a>
P0463	0463	FUEL LEVL SEN/CIRC	<a href="#">EC-389</a>
P0500	0500	VEH SPEED SEN/CIRC*5	<a href="#">EC-391</a>
P0506	0506	ISC SYSTEM	<a href="#">EC-393</a>
P0507	0507	ISC SYSTEM	<a href="#">EC-395</a>
P0550	0550	PW ST P SEN/CIRC	<a href="#">EC-397</a>
P0605	0605	ECM	<a href="#">EC-402</a>
P0700	0700	TCM	<a href="#">AT-113</a>
P0705	0705	PNP SW/CIRC	<a href="#">AT-114</a>
P0710	0710	ATF TEMP SEN/CIRC	<a href="#">AT-136</a>
P0720	0720	VEH SPD SEN/CIR AT*5	<a href="#">AT-118</a>
P0725	0725	ENGINE SPEED SIG	<a href="#">AT-123</a>
P0740	0740	TCC SOLENOID/CIRC	<a href="#">AT-125</a>
P0744	0744	A/T TCC S/V FNCTN	<a href="#">AT-127</a>
P0745	0745	L/PRESS SOL/CIRC	<a href="#">AT-129</a>
P1031	1031	A/F SEN1 HTR (B1)	<a href="#">EC-405</a>
P1032	1032	A/F SEN1 HTR (B1)	<a href="#">EC-405</a>
P1051	1051	A/F SEN1 HTR (B2)	<a href="#">EC-405</a>



\*1 [EC-59](#)

\*2 [EC-63](#)

\*3 [EC-64](#)

PBIB2320E

## How to Display SRT Status

### WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown in the figure.

"INCMP" means the self-diagnosis is incomplete and SRT is not set. "CMPLT" means the self-diagnosis is complete and SRT is set.

### WITH GST

Selecting Service \$01 with GST (Generic Scan Tool)

SRT STATUS	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	CMPLT
EGR SYSTEM	INCMP

SEF713Y

# TROUBLE DIAGNOSIS

[VQ35DE]

## Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

ABS006KS

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	<a href="#">EC-668</a>
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			<a href="#">EC-99</a>
	Injector circuit	1	1	2	3	2		2	2			2			<a href="#">EC-661</a>
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			<a href="#">EC-39</a>
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		<a href="#">EC-51</a>
	Incorrect idle speed adjustment						1	1	1	1		1			
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	<a href="#">EC-424</a> , <a href="#">EC-426</a>
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			<a href="#">EC-78</a>
	Ignition circuit	1	1	2	2	2		2	2			2			<a href="#">EC-648</a>
Power supply and ground circuit		2	2	3	3	3		3	3			2	3		<a href="#">EC-164</a>
Mass air flow sensor circuit		1			2										<a href="#">EC-186</a> , <a href="#">EC-195</a>
Engine coolant temperature sensor circuit								3			3				
Air fuel ratio (A/F) sensor			1	2	3	2		2	2			2			<a href="#">EC-488</a> , <a href="#">EC-497</a> , <a href="#">EC-506</a> , <a href="#">EC-516</a> , <a href="#">EC-526</a> , <a href="#">EC-536</a> , <a href="#">EC-548</a>
Throttle position sensor circuit							2			2					<a href="#">EC-213</a> , <a href="#">EC-278</a> , <a href="#">EC-479</a> , <a href="#">EC-481</a> , <a href="#">EC-633</a>
Accelerator pedal position sensor circuit				3	2	1									<a href="#">EC-483</a> , <a href="#">EC-619</a> , <a href="#">EC-626</a> , <a href="#">EC-640</a>
Knock sensor circuit				2								3			<a href="#">EC-295</a>
Crankshaft position sensor (POS) circuit		2	2												<a href="#">EC-300</a>
Camshaft position sensor (PHASE) circuit		3	2												<a href="#">EC-307</a>

**5. CHANGE ENGINE OIL**

1. Stop the engine.
2. Change engine oil.

**NOTE:**

This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving condition.

>> **INSPECTION END**

**6. CHECK FUEL PRESSURE**

Check fuel pressure. (Refer to [EC-99, "Fuel Pressure Check"](#) .)

OK or NG

OK >> GO TO 9.

NG (Fuel pressure is too high)>>Replace fuel pressure regulator, refer to [EC-99, "Fuel Pressure Check"](#) .  
GO TO 8.

NG (Fuel pressure is too low)>>GO TO 7.

**7. DETECT MALFUNCTIONING PART**

1. Check the following.
  - Clogged and bent fuel hose and fuel tube
  - Clogged fuel filter
  - Fuel pump and its circuit (Refer to [EC-668, "FUEL PUMP CIRCUIT"](#) .)
2. If NG, repair or replace the malfunctioning part. (Refer to [EC-99, "Fuel Pressure Check"](#) .)  
If OK, replace fuel pressure regulator.

>> GO TO 8.

**8. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 9.

**9. PERFORM POWER BALANCE TEST**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Make sure that the each cylinder produces a momentary engine speed drop.

OK or NG

OK >> GO TO 12.

NG >> GO TO 10.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

---

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.



# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ35DE]

## BANK 2


EC-FUELB2-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.


- (F102) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (E201) -FUSE BLOCK-JUNCTION BOX (J/B)



TBWM0387E

## 5. CHECK GROUND CONNECTIONS

Loosen and retighten ground three screws on the body. Refer to [EC-170, "Ground Inspection"](#) .



OK or NG

OK >> GO TO 6.

NG >> Repair or replace ground connections.

## 6. CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT

1. Disconnect knock sensor harness connector.
2. Check harness continuity between knock sensor terminal 2 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F20, F252
- Harness connectors F102, M82
- Harness for open or short between knock sensor terminal 2 and ground

>> Repair open circuit or short power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-163, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection KNOCK SENSOR

ABS00600

Check resistance between knock sensor terminal 1 and ground.


#### NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

**Resistance: Approximately 532 - 588 kΩ [at 20°C (68°F)]**

#### CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



SEF111Y


# DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VQ35DE]

ABS006R5

## Wiring Diagram


### EC-VENT/V-01




REFER TO PG-POWER.

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M





M90  
B



E7  
GY



REFER TO THE FOLLOWING.  
 (E211), (B1) -SUPER MULTIPLE JUNCTION (SMJ)



**⑧ WITH GST**

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed sensor signal in Service \$01 with GST.  
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-392, "Diagnostic Procedure"](#) .

**Diagnostic Procedure**

ABS006SD

**1. CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"**Refer to [BRC-12, "TROUBLE DIAGNOSIS"](#) .**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace.

**2. CHECK DTC WITH "UNIFIED METER AND A/C AMP."**Refer to [DI-5, "COMBINATION METERS"](#) .>> **INSPECTION END**



# DTC P1128 THROTTLE CONTROL MOTOR

[VQ35DE]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	L/W	Throttle control motor (Close)	<p><b>[Ignition switch: ON]</b></p> <ul style="list-style-type: none"> <li>● Engine stopped</li> <li>● Selector lever: D</li> <li>● Accelerator pedal: Fully released</li> </ul>	<p>0 - 14V★</p>  <p>PBIB1104E</p>
5	L/B	Throttle control motor (Open)	<p><b>[Ignition switch: ON]</b></p> <ul style="list-style-type: none"> <li>● Engine stopped</li> <li>● Selector lever: D</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	<p>0 - 14V★</p>  <p>PBIB1105E</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

ABS006TV

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten ground three screws on the body. Refer to [EC-170, "Ground Inspection"](#).




PBIB2625E

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair or replace ground connections.

## 2. CHECK ACCELERATOR PEDAL POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 6 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 3.



## 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check the following.

- Harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
90	APP sensor terminal 6	<a href="#">EC-621</a>
49	Refrigerant pressure sensor terminal 1	<a href="#">EC-675</a>
68	PSP sensor terminal 1	<a href="#">EC-398</a>
48	EVAP control system pressure sensor terminal 3	<a href="#">EC-355</a>

- ECM pin terminal.

OK or NG

- OK >> GO TO 4.  
 NG >> Repair short to ground or short to power in harness or connectors.

## 4. CHECK COMPONENTS

Check the following.


- Refrigerant pressure sensor (Refer to [ATC-90, "COMPONENT INSPECTION"](#) .)
- Power steering pressure sensor (Refer to [EC-401, "Component Inspection"](#) .)
- EVAP control system pressure sensor (Refer to [EC-352, "Component Inspection"](#) .)

OK or NG

- OK >> GO TO 7.  
 NG >> Replace malfunctioning component.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E18, F48
- Fuse block (J/B) connector E201
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse


>> Repair or replace harness or connectors.

## Component Inspection ICC STEERING SWITCH

1. Disconnect combination switch (spiral cable) harness connector.
2. Check continuity between combination switch (spiral cable) terminals 14 and 15 with pushing each switch.

Switch	Condition	Resistance [ $\Omega$ ]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 5,500
CANCEL switch	Pressed	Approx. 310
	Released	Approx. 5,500
RESUME/ACCELERATE switch	Pressed	Approx. 2,600
	Released	Approx. 5,500
SET/COAST switch	Pressed	Approx. 1,400
	Released	Approx. 5,500
DISTANCE switch	Pressed	Approx. 740
	Released	Approx. 5,500

If NG, replace ICC steering switch.



PBIB1621E

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-629, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# REFRIGERANT PRESSURE SENSOR

[VQ35DE]



## REFRIGERANT PRESSURE SENSOR

PFP:92136

### Component Description

ABS006YL

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.




## ENGINE CONTROL SYSTEM

PFP:23710

### System Diagram

ABS00E3X


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



PBIB2554E

## EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

### <Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

### <Driving Pattern B>






Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (\*2 in OBD SYSTEM OPERATION CHART).

# TROUBLE DIAGNOSIS

[VK45DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	BR	Intake valve timing control solenoid valve (bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Warm-up condition ● Engine speed: 2,000rpm	7 - 12V★ 
12	R/G	Power steering pressure sensor	[Engine is running] ● Steering wheel: Being turned	0.5 - 4.5V
			[Engine is running] ● Steering wheel: Not being turned	0.4 - 0.8V
13	Y	Crankshaft position sensor (POS)	[Engine is running] ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 2.0V★ 
			[Engine is running] ● Engine speed: 2,000 rpm	1.0 - 2.0V★ 
14	W	Camshaft position sensor (PHASE)	[Engine is running] ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★ 
			[Engine is running] ● Engine speed: 2,000 rpm	1.0 - 4.0V★ 
15	W	Knock sensor (bank 1)	[Engine is running] ● Idle speed	Approximately 2.5V
16	R/L	Heated oxygen sensor 1 (bank 1)	[Engine is running] ● Warm-up condition ● Engine speed: 2,000 rpm	0 - Approximately 1.0V (Periodically change)

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

### Description

ABS007J

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### On Board Diagnosis Logic

ABS007K

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000*1 1000*1	CAN communication line	<ul style="list-style-type: none"> <li>● ECM cannot communicate to other control units.</li> <li>● ECM cannot communicate for more than the specified time.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (CAN communication line is open or shorted)</li> </ul>
U1001*2 1001*2			

\*1: This self-diagnosis has the one trip detection logic.

\*2: The MIL will not light up for this diagnosis.

### DTC Confirmation Procedure

ABS007L

1. Turn ignition switch ON and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-864, "Diagnostic Procedure"](#).

## DTC P0112, P0113 IAT SENSOR


PF2:22630

### Component Description

ABS007JT

The intake air temperature sensor is built-into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
25 (77)	3.32	1.94 - 2.06
80 (176)	1.23	0.295 - 0.349

\*: These data are reference values and are measured between ECM terminal 34 (Intake air temperature sensor) and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**



### On Board Diagnosis Logic

ABS007JU

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Intake air temperature sensor</li> </ul>
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### DTC Confirmation Procedure


ABS007JV

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-912. "Diagnostic Procedure"](#)



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



**DTC P0134, P0154 HO2S1**

PFP:22690

**Component Description**

ABS007LD

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1 to 0V.



**CONSULT-II Reference Value in Data Monitor Mode**

ABS007LE


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.

**On Board Diagnosis Logic**

ABS007LF

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.




DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Heated oxygen sensor 1</li> </ul>
P0154 0154 (Bank 2)			

**9. CHECK FUNCTION OF INJECTOR-II**

Provide battery voltage between the following terminals, and then interrupt it. Listen to each injector operating sound.

Cylinder	Harness connector	terminal	
		(+)	(-)
1	F201	5	3
3			2
5			1
7			6
2	F221	5	3
4			2
6			1
8			6



**Operating sound should exist.**

OK or NG

OK >> GO TO 10.

NG >> Perform trouble diagnosis for INJECTOR CIRCUIT, refer to [EC-1351](#) .

**10. CHECK INJECTOR**

1. Turn ignition switch OFF.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Remove injector gallery assembly. Refer to [EM-192, "FUEL INJECTOR AND FUEL TUBE"](#) . Keep fuel hose and all injectors connected to injector gallery.
4. Disconnect all injector harness connectors.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injectors.
7. Crank engine for about 3 seconds.  
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 11.

NG (Drips.)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-854, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

# DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VK45DE]

## DTC P0420, P0430 THREE WAY CATALYST FUNCTION

PF2:20905


### On Board Diagnosis Logic

ABS00E5B

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> <li>● Three way catalyst (Manifold) does not operate properly.</li> <li>● Three way catalyst (Manifold) does not have enough oxygen storage capacity.</li> </ul>	<ul style="list-style-type: none"> <li>● Three way catalyst (Manifold)</li> <li>● Exhaust tube</li> <li>● Intake air leaks</li> <li>● Fuel injector</li> <li>● Fuel injector leaks</li> <li>● Spark plug</li> <li>● Improper ignition timing</li> </ul>
P0430 0430 (Bank 2)			

### DTC Confirmation Procedure

ABS00E5C

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

#### TESTING CONDITION:

**Do not hold engine speed for more than the specified minutes below.**

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Make sure that "COOLAN TEMP/S" indicates more than 70°C (158°F).  
If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches to 70°C (158°F).
7. Open engine hood.



## 5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between EVAP control system pressure sensor terminal 1 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B201, M81
- Harness connectors M82, F102
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 32 and EVAP control system pressure sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.  
NG >> GO TO 8.

## 8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B201, M81
- Harness connectors M82, F102
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 9. CHECK RUBBER TUBE

1. Disconnect rubber tube connected to EVAP canister vent control valve.
2. Check the rubber tube for clogging.

OK or NG

- OK >> GO TO 10.  
NG >> Clean the rubber tube using an air blower, repair or replace rubber tube.



# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VK45DE]

BANK 2

EC-IVCB2-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



TBWM0220E

# DTC P1146, P1166 HO2S2

[VK45DE]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
55	W/R	Heated oxygen sensor 2 (bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>– After keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B/R	Sensor ground (Heated oxygen sensor)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VK45DE]

## 4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.

**Water should not exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Replace EVAP control system pressure sensor.

## 5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Refer to [EC-1091, "Component Inspection"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 6.  
OK (Without CONSULT-II)>>GO TO 7.  
NG >> Replace EVAP control system pressure sensor.

## 6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 **With CONSULT-II**

1. Turn ignition switch OFF.
2. Reconnect harness connectors disconnected.
3. Start engine.
4. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 8.  
NG >> GO TO 7.

ACTIVE TEST	
PURG VOL CONT/V	0 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %

PBIB0147E

## 7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-1240, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.  
NG >> Replace EVAP canister purge volume control solenoid valve.

## 8. CHECK RUBBER TUBE FOR CLOGGING

1. Disconnect rubber tube connected to EVAP canister vent control valve.
2. Check the rubber tube for clogging.

OK or NG

- OK >> GO TO 9.  
NG >> Clean the rubber tube using an air blower.

## 9. CHECK EVAP CANISTER VENT CONTROL VALVE

Refer to [EC-1081, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.  
NG >> Replace EVAP canister vent control valve.

# DTC P1706 PNP SWITCH


[VK45DE]

ABS00DC9


## Wiring Diagram

EC-PNP/SW-01

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)


\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TBWM0521E

## COMPONENT DESCRIPTION


### Power Valve

The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the VIAS control solenoid valve.



### VIAS Control Solenoid Valve

The VIAS control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.



## CONSULT-II Reference Value in Data Monitor Mode

ABS007WL

MONITOR ITEM	CONDITION		SPECIFICATION
VIAS S/V	● Engine speed: Idle	Selector lever: P or N and/or Engine speed: More than 5,000 rpm	ON
		Except above	OFF



# ASC D BRAKE SWITCH

[VK45DE]

## Wiring Diagram

ABS007XL

### EC-ASCBOF-01



M90  
B



2  
1 E208  
BR

4 3  
2 1 E210  
W

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E201) -FUSE BLOCK-JUNCTION BOX (J/B)

TBWM0426E


# BACK DOOR WINDOW MOLDING

PFP:90352

AIS003C0

## BACK DOOR WINDOW MOLDING

### Removal and Installation



- |                          |                           |                             |
|--------------------------|---------------------------|-----------------------------|
| 1. Dam rubber            | 2. Back door window glass | 3. Bond                     |
| 4. Back door outer panel | 5. Back door inner panel  | 6. Back door window molding |
| 7. Clip                  | 8. Back door panel        |                             |

### REMOVAL

Remove back door window molding. Refer to [GW-13, "REMOVAL"](#).

#### NOTE:

Apply a strip of protective tape along the contour of back door window glass (molding) to prevent paint surface from being damaged.

### INSTALLATION

Install back door window molding. Refer to [GW-14, "INSTALLATION"](#).

#### NOTE:

- Clean adhesive portion of back door window glass and around circumference with white gasoline.
- Apply dam rubber to upper and side surfaces of glass.
- Attach back door window molding to side face of glass.

- Do not spill engine oil on drive belts.
6. Drain engine coolant. Refer to [CO-11, "Changing Engine Coolant"](#) .
- CAUTION:**
- Perform this step when the engine is cold.
  - Do not spill engine coolant on drive belts.
7. Remove engine cover with power tool. Refer to [EM-19, "INTAKE MANIFOLD COLLECTOR"](#) .
  8. Remove air hose from air duct to mass air flow sensor side and electric throttle control actuator side. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .
  9. Removal engine rear lower slinger, and install engine rear slinger [SST: 10006 31U00 ( — )] to sling engine assembly for positioning. Refer to [EM-8, "Special Service Tools"](#) .

**Slinger bolts:**


 : 28.0 N·m (2.9 kg·m, 21 ft·lb)

10. Remove front suspension member. Refer to [FSU-17, "FRONT SUSPENSION MEMBER"](#) .
11. Remove drive belts. Refer to [EM-15, "DRIVE BELTS"](#) .
12. Remove alternator stay. Refer to [SC-23, "CHARGING SYSTEM"](#) .
13. Remove starter motor. Refer to [SC-10, "STARTING SYSTEM"](#) .
14. Remove idler pulley and bracket assembly. Refer to [EM-64, "TIMING CHAIN"](#) .
15. Disconnect oil cooler water hoses, and remove oil cooler water pipe mounting bolt. Refer to [LU-14, "OIL COOLER"](#) .
16. Disconnect A/T fluid cooler hoses, and remove A/T fluid cooler tube. Refer to [AT-270, "TRANSMISSION ASSEMBLY"](#) .
17. Remove crankshaft position sensor (POS).

**CAUTION:**

- Handle carefully to avoid dropping and shocks.
- Do not disassemble.
- Do not allow metal powder to adhere to magnetic part at sensor tip.
- Do not place sensors in a location where they are exposed to magnetism.

18. Remove oil filter, as necessary. Refer to [LU-10, "OIL FILTER"](#) .
19. Remove oil cooler, as necessary. Refer to [LU-14, "OIL COOLER"](#) .
20. Remove oil pan (lower) as follows:
  - a. Loosen mounting bolts in reverse order as shown in the figure to remove.




- b. Insert the seal cutter [SST] between oil pan (upper) and oil pan (lower).

**CAUTION:**

- Be careful not to damage the mating surfaces.
- Do not insert a screwdriver, this will damage the mating surfaces.


- c. Slide the seal cutter by tapping on the side of tool with a hammer. Remove oil pan (lower).




# TIMING CHAIN

[VQ35DE]

- Install timing chain (primary) so the mating mark (punched) on camshaft sprocket is aligned with the yellow link on timing chain, while the mating mark (notched) on crankshaft sprocket is aligned with the orange one on timing chain, as shown in the figure.
- When it is difficult to align mating marks of timing chain (primary) with each sprocket, gradually turn camshaft using wrench on the hexagonal portion to align it with the mating marks.
- During alignment, be careful to prevent dislocation of mating mark alignments of timing chains (secondary).




8. Install internal chain guide, slack guide and timing chain tensioner (primary).



# CYLINDER BLOCK

[VQ35DE]

6. Drain engine coolant by removing water drain plugs from cylinder block both sides at "B" and "C" and cylinder block front side at "A" as shown in the figure.




7. Remove drive plate with power tool. Fix crankshaft with a ring gear stopper [SST: KV1011770 (J44716)], and remove mounting bolts.

- Loosen mounting bolts in diagonal order.

**CAUTION:**

- Do not disassemble drive plate.
- Never place drive plate with signal plate facing down.
- When handling signal plate, take care not to damage or scratch it.
- Handle signal plate in a manner that prevents it from becoming magnetized.



8. Remove the following parts:

- Intake manifold collector; Refer to [EM-19, "INTAKE MANIFOLD COLLECTOR"](#) .
- Intake manifold; Refer to [EM-24, "INTAKE MANIFOLD"](#) .
- Oil pans (lower and upper); Refer to [EM-30, "OIL PAN AND OIL STRAINER"](#) .
- Front and rear timing chain case; Refer to [EM-64, "TIMING CHAIN"](#) .
- Cylinder head; Refer to [EM-100, "CYLINDER HEAD"](#) .

9. Remove knock sensor.

**CAUTION:**


Carefully handle sensor avoiding shocks.

## ENGINE ROOM COVER

PFP:14049

## Components

ABS00DFK



PBIC2754E

1. Engine cover

2. Battery cover

3. Air duct (inlet)

## Removal and Installation

ABS006I6

## REMOVAL

**CAUTION:**

Do not damage or scratch cover when installing or removing.

- Major parts and inspection points under each cover are as follows; (numbered as in the figure)

**1 : Upper side of engine assembly and power steering reservoir tank**

**2 : Relay and battery**

**3 : Engine assembly front side, drive belts and cooling fan**

## INSTALLATION

Install in the reverse order of removal.


4. Crank the engine, and then make sure that engine oil comes out from intake valve timing control cover oil hole. End crank after checking.

**WARNING:**

Be careful not to touch rotating parts (drive belt, idler pulley, and crankshaft pulley, etc.).

**CAUTION:**

Engine oil may squirt from intake valve timing control solenoid valve installation hole during cranking. Use a shop cloth to prevent the engine components and the vehicle. Do not allow engine oil to get on rubber components such as drive belt or engine mount insulators. Immediately wipe off any splashed engine oil.




- Clean oil groove between oil strainer and intake valve timing control solenoid valve if engine oil does not come out from intake valve timing control cover oil hole. Refer to [LU-23, "LUBRICATION SYSTEM"](#) .
5. Remove components between intake valve timing control solenoid valve and camshaft sprocket (INT), and then check each oil groove for clogging.
    - Clean oil groove if necessary. Refer to [LU-23, "LUBRICATION SYSTEM"](#) .
  6. After inspection, install removed parts.

## Valve Clearance INSPECTION


ABS006IL

In cases of removing/installing or replacing camshaft and valve-related parts, or of unusual engine conditions due to changes in valve clearance (found malfunctions during starting, idling or causing noise), perform inspection as follows:

1. Remove rocker covers (right and left bank). Refer to [EM-197, "ROCKER COVER"](#) .
2. Measure the valve clearance as follows:
  - a. Set No. 1 cylinder at TDC of its compression stroke.
    - Rotate crankshaft pulley in clockwise to align TDC identification notch (without paint mark) with timing indicator on front cover.



- Make sure that both intake and exhaust cam noses of No. 1 cylinder (engine front side of left bank) are located as shown in the figure.
- If not, turn crankshaft one revolution (360 degrees) and align as shown in the figure.




# CYLINDER BLOCK

[VK45DE]

- Measure the distortion on the cylinder block upper face at some different points in six directions with straightedge and feeler gauge.

**Limit : 0.1 mm (0.004 in)**

- If it exceeds the limit, replace cylinder block.



## MAIN BEARING HOUSING INNER DIAMETER


- Install main bearing caps and main bearing without installing main bearings, and tighten main bearing cap bolts to the specified torque. Refer to [EM-249, "ASSEMBLY"](#) for the tightening procedure.
- Measure the inner diameter of main bearing housing with bore gauge.

**Standard : 68.944 - 68.968 mm (2.7143 - 2.7153 in)**

- If out of the standard, replace cylinder block and main bearing caps as assembly.

### NOTE:

Cylinder block cannot be replaced as a single part, because it is machined together with main bearing caps.



## PISTON TO CYLINDER BORE CLEARANCE

### Cylinder Bore Inner Diameter

- Using bore gauge, measure cylinder bore for wear, out-of-round and taper at six different points on each cylinder. ("X" and "Y" directions at "A", "B" and "C") ("Y" is in longitudinal direction of engine)

**Standard inner diameter:**

**93.000 - 93.030 mm (3.6614 - 3.6626 in)**

**Wear limit:**

**0.2 mm (0.008 in)**

**Out-of-round (Difference between "X" and "Y"):**

**0.015 mm (0.0006 in)**

**Taper limit (Difference between "A" and "C"):**



**0.01 mm (0.0004 in)**

- If the measured value exceeds the limit, or if there are scratches and/or seizure on the cylinder inner wall, hone or re-bore the inner wall.
- Oversize piston is provided. When using oversize piston, re-bore cylinder so that the clearance of the piston-to-cylinder bore satisfies the standard.

### CAUTION:

When using oversize piston, use oversize pistons for all cylinders with oversize piston rings.

**Oversize (OS) : 0.2 mm (0.008 in)**



# FRONT DRIVE SHAFT

[AWD]

7. Install boot securely into grooves (indicated by \* marks) shown in the figure.


**CAUTION:**

**If there is grease on boot mounting surfaces (indicated by\* marks) of shaft and housing, boot may come off. Remove all grease from surfaces.**

8. Make sure boot installation length "L" is the length indicated below. Insert a flat-bladed screwdriver or similar tool into smaller side of boot. Bleed air from boot to prevent boot deformation.

**Boot installation Length "L":**

**157.8 – 159.8 mm (6.21 – 6.29 in)**



A  
B  
C

FAX

**CAUTION:**


- Boot may break if boot installation length is less than standard value.
- Take care not to touch the tip of screwdriver to inside surface of boot.

9. Install new larger and smaller boot bands securely.

- a. For one-touch clamp band:

**NOTE:**

- Discard old boot bands; replace with new ones with a suitable tool.




E  
F  
G

- Secure boot band so that dimension "M" shown below right satisfies the following:

**Large diameter side : 3.0 mm (0.118 in)**


**Small diameter side : 2.0 mm (0.079 in)**



H  
I  
J

- b. For low profile type band:

- i. Set boot band in the specified grooves. Fit band's pawl to the grooves and tack them.




M

# FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

## FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY PFP:17042

### Removal and Installation

ABS005YZ



1. Retainer
2. Main fuel level sensor unit, fuel filter - and fuel pump assembly
3. O-ring
4. Sub fuel level sensor unit

### REMOVAL

#### WARNING:


Read "General Precautions" when working on the fuel system. Refer to [FL-3, "General Precautions"](#).

1. Check fuel level on fuel gauge. If fuel gauge indicates more than the level as shown in the figure (full or almost full), drain fuel from fuel tank until fuel gauge indicates level as shown in the figure or below.

#### NOTE:

Because fuel will be spilled when removing main and sub fuel level sensor units for the top of the fuel is above the main and sub fuel level sensor units installation surface.

- As a guide, fuel level becomes the position as shown in the figure or below when approximately 20 ℓ (5-1/4 US gal, 4-3/8 Imp gal) of fuel are drained from fuel tank.
  - In a case that fuel pump does not operate, perform the following procedure.
    - a. Insert hose of less than 25 mm (0.98 in) in diameter into fuel filler tube through fuel filler opening to draw fuel from fuel filler tube.
    - b. Disconnect fuel filler hose from fuel filler tube. Refer to [FL-10, "FUEL TANK"](#).
    - c. Insert fuel tube into fuel tank through fuel filler hose to draw fuel from fuel tank.
2. Release the fuel pressure from the fuel lines. Refer to [EC-99, "FUEL PRESSURE RELEASE"](#) (VQ35DE) or [EC-789, "FUEL PRESSURE RELEASE"](#) (VK45DE).
  3. Open fuel filler lid.



# HOW TO USE THIS MANUAL

## Multiple Switch

The continuity of multiple switch is described in two ways as shown below.


- The switch chart is used in schematic diagrams.
- The switch diagram is used in wiring diagrams.

### Example

(SWITCH CHART)

WIPER SWITCH		OFF	INT	LO	HI	WASH
1						○
2				○		
3	○	○	○			
4	○	○	○			
5		○				
6		○	○	○	○	

(SWITCH DIAGRAM)



Continuity circuit of wiper switch

SWITCH POSITION	CONTINUITY CIRCUIT
OFF	3-4
INT	3-4, 5-6
LO	3-6
HI	2-6
WASH	1-6

SGI875

GI

B

C

D

E

F

G

H

I

J

K

L

M


# WINDSHIELD GLASS

## WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

## CAUTION:

- When a windshield glass is to be reused, do not use a cutting knife or power cutting tool.
- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.



7. Remove the windshield glass, using suction.

## INSTALLATION

- Use a genuine Nissan Urethane Adhesive Kit (if available) or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger room air pressure when a door is closed.
- The molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

## WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the windshield in case of an accident.

## CAUTION:

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidities. The curing time will increase under lower temperature and lower humidity.

## Repairing Water Leaks for Windshield

Leaks can be repaired without removing and reinstalling glass.

If water is leaking between the urethane adhesive material and body or glass, determine the extent of leakage. This can be done by applying water to the windshield area while pushing glass outward.

To stop the leak, apply primer (if necessary) and then urethane adhesive to the leak point.

# POWER WINDOW SYSTEM


## 5. CHECK HARNESS CONTINUITY 2

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check continuity between front power window switch (passenger side) connector D36 terminal 15 and front power window motor (passenger side) connector D38 terminal 5.

**15 (GY) – 5 (GY) : Continuity should exist.**

OK or NG

- OK >> Replace front power window motor (passenger side).  
 NG >> Repair or replace harness.




## Limit Switch Circuit Check (Rear LH or RH) / With Front and Rear Anti-Pinch System

AIS004QP

### 1. CHECK REAR POWER WINDOW SWITCH LIMIT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between rear power window switch (LH or RH) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage [V] (Approx.)
	(+)	(-)		
D58 (LH) D78 (RH)	15 (R)	Ground	Rear (LH or RH) side door window is between fully-open and just before fully-closed position (ON)	0
			Rear (LH or RH) side door window is between just before fully-closed position and fully-closed position (OFF)	5



OK or NG

- OK >> Limit switch circuit is OK.  
 NG >> GO TO 2.


### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window motor (LH or RH) connector.
3. Check continuity between rear power window motor (LH or RH) connector D59 (LH), D79 (RH) terminal 4 and ground.

**4 (OR) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



# REAR WINDOW DEFOGGER


AIS004RF

## Passenger Side Door Mirror Defogger Circuit Check

### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (passenger side) connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D32	1 (L)	Ground	Rear window defogger switch ON	Battery voltage
			Rear window defogger switch OFF	0



OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace harness.


### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror (passenger side) connector D32 terminal 2 and ground.

**2 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace harness.




### 3. CHECK DOOR MIRROR DEFOGGER

1. Connector door mirror connector.
2. Check continuity between each door mirror connector D32 (passenger side) terminals 1 and 2.

**1 (L) – 2 (B) : Continuity should exist.**

OK or NG

- OK >> Check condition of harness and connector.  
NG >> Replace door mirror (passenger side).



## Rear Window Defogger Signal Check

AIS004RG

### 1. CHECK REAR WINDOW DEFOGGER SWITCH LAMP

A/C and AV switch self-diagnosis is performed. Refer to [AV-37, "A/C and AV Switch Self-Diagnosis Function"](#)

Does rear window defogger switch light?

- YES >> GO TO 2.  
NO >> Replace A/C and AV switch.

## HOW TO USE CHECK SHEET TABLE

Check sheet table	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DISPLAY	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-
Display unit	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	UNKWN	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-	-	CAN COMM CIRCUIT (U1000)	-

① Unit names displayed on CONSULT-II  
 ② "No indication": Put a check mark to it if the unit name described in step 1 is not displayed on "SELECT SYSTEM" screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)  
 ③ "-": Column not used (Unit communicating with CONSULT-II excluding CAN communication line)  
 ④ "NG": Display "NG" when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if "NG" is displayed.  
 ⑤ "UNKWN": Display "UNKWN" when the diagnosed unit does not transmit the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
 "UNKWN": Display "UNKWN" when the diagnosed unit does not receive the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
 "-": Column not used (It is not necessary for CAN communication trouble diagnosis.)

Unit that performs CAN communication diagnosis

Use when the initial conditions are reproduced

Use when the initial conditions are not reproduced

PKIB5977E

- Unit names displayed on CONSULT-II
- "No indication": Put a check mark to it if the unit name described in step 1 is not displayed on "SELECT SYSTEM" screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)  
"-": Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
- "NG": Display "NG" when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if "NG" is displayed.  
"-": Column not used (Initial diagnosis is not performed.)
- "UNKWN": Display "UNKWN" when the diagnosed unit does not transmit the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.
- "UNKWN": Display "UNKWN" when the diagnosed unit does not receive the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
"-": Column not used (It is not necessary for CAN communication trouble diagnosis.)

**NOTE:**

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-12, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced. Refer to [LAN-16, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-73, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DISPLAY	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
Display unit	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB4445E



PKIB4309E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-117, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DISPLAY	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display unit	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
LDW	No indication	—	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB4435E



PKIB4302E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 3)

[CAN]

## Case 18

Check CAN communication circuit. Refer to [LAN-164, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	✓	—	✓	—	✓	—	✓	—	✓	—	✓	✓	✓	CAN COMM CIRCUIT (U1000)	✓
A/T	—	NG	UNKWN	✓	—	—	✓	—	—	—	✓	—	✓	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	✓	✓	—	—	—	—	✓	—	✓	—	—	✓	—	—	—
ICC	—	NG	✓	✓	✓	—	—	—	✓	—	—	✓	✓	—	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	✓	—	—	—	—	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB4420E

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 20

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-218, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
LDW	No indication	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB4400E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

**15G (L) - 11 (L) : Continuity should exist.**  
**14G (R) - 15 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



### Inspection Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit Circuit

AKS00CD8

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E205
  - Harness connector B5

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


#### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

**11 (L) - 3 (L) : Continuity should exist.**  
**15 (R) - 10 (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



AKS00CCT

## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



AKS00CCU

## LDW Camera Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (unit side and harness side).
  - LDW camera unit connector
  - Harness connector R1
  - Harness connector M31

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



## Unified Meter and A/C Amp. Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M34 terminals 2 (L) and 3 (R).

**2 (L) - 3 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace Intelligent Key unit.  
 NG >> Repair harness between Intelligent Key unit and data link connector.



## Data Link Connector Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).  
 NG >> Repair harness between data link connector and BCM.



## BCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

# CAN SYSTEM (TYPE 10)


[CAN]

PFP:23710

AKS00FDU

## CAN SYSTEM (TYPE 10)

### Component Parts and Harness Connector Location




# HEADLAMP - XENON TYPE -

## Wiring Diagram — H/LAMP —

AKS007ME

### LT-H/LAMP-01



▬ : DATA LINE

REFER TO PG-POWER.



DATA LINK CONNECTOR (M5)

NEXT PAGE

TO LT-H/LAMP-04

BCM (BODY CONTROL MODULE) (M3), (M4)

COMBINATION SWITCH (M17)



REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4) -ELECTRICAL UNITS



TKWM0815E

# AUTO LIGHT SYSTEM

## Wiring Diagram — AUTO/L —

AKS007EX

LT-AUTO/L-01



REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) , (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3) , (M4) -ELECTRICAL UNITS

TKWM0817E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 5. CHECK TURN SIGNAL LAMPS SHORT CIRCUIT

1. Disconnect rear combination lamp unit connector.
2. Check continuity (short circuit) between front combination lamp LH harness connector E44 terminal 4 (G) and ground.

**4 (G) – Ground : Continuity should not exist.**


3. Check continuity (short circuit) between front combination lamp RH harness connector E24 terminal 4 (PU) and ground.

**4 (PU) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



## 6. CHECK BULB

Check bulb standard of each turn signal lamp is correct.

OK or NG

OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Replace turn signal lamp bulb.

## Rear Turn Signal Lamp Does Not Operate

AKS007IF

### 1. CHECK TAIL LAMPS AND STOP LAMPS

Make sure tail lamps and stop lamps is illuminated.

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.

### 2. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminal 45 (G/W) and rear combination lamp control unit harness connector B65 terminal 4 (OR).

**45 (G/W) – 4 (OR) : Continuity should exist.**


3. Check continuity between BCM harness connector M4 terminal 46 (BR/W) and rear combination lamp control unit harness connector B65 terminal 5 (PU).

**46 (BR/W) – 5 (PU) : Continuity should exist.**

OK or NG

OK >> Replace rear combination lamp control unit.

NG >> Repair harness or connector.



# MAP LAMP

## MAP LAMP

PFP:26430


### Bulb Replacement

AKS007ED

1. Remove lens using clip driver or suitable tool.
2. Remove bulb.

**Map lamp : 12V - 8 W**

3. Installation is the reverse order of removal.




### Removal and Installation

#### REMOVAL

AKS007EE

1. Insert a clip driver or suitable tool back of map lamp and pull down it to disengage pawl.
2. Pull down map lamp in direction shown by the arrow in the figure.
3. Disconnect map lamp connector and remove map lamp.





#### INSTALLATION

Installation is the reverse order of removal.


# ILLUMINATION

LT-ILL-06


◊DM◊ : WITH MEMORY MIRROR  
 ◊OM◊ : WITHOUT MEMORY MIRROR




(M18) BR  
 (M19) W



(M51) W



(M68) W  
 (M69) BR



(M96) GY

TKWM2052E

# PERIODIC MAINTENANCE

## Schedule 1 EMISSION CONTROL SYSTEM MAINTENANCE

ALS000G6

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. [ ]: At the mileage intervals only


MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	3.75 (6)	7.50 (12)	11.25 (18)	15 (24)	18.75 (30)	22.5 (36)	26.25 (42)	30 (48)	
Drive belts	NOTE (1)									MA-14, MA-22
Air cleaner filter	NOTE (2)								[R]	MA-18, MA-25
EVAP vapor lines									I*	MA-21, MA-28
Fuel lines									I*	MA-17, MA-25
Fuel filter	NOTE (3)									-
Engine coolant	NOTE (4)									MA-15, MA-22
Engine oil		R	R	R	R	R	R	R	R	MA-18, MA-25
Engine oil filter [Use part No. 15208 31U00 (for VK45DE), 15208 65F00 (for VQ35DE) or equivalent.]		R	R	R	R	R	R	R	R	MA-19, MA-26
Spark plugs (PLATINUM-TIPPED type)		Replace every 105,000 miles (169,000 km).								MA-20, MA-27
Intake & exhaust valve clearance*	NOTE (5)									EM-93, "Valve Clearance", EM-219, "Valve Clearance"

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54)	37.5 (60)	41.25 (66)	45 (72)	48.75 (78)	52.5 (84)	56.25 (90)	60 (96)	
Drive belts	NOTE (1)								I*	MA-14, MA-22
Air cleaner filter	NOTE (2)								[R]	MA-18, MA-25
EVAP vapor lines									I*	MA-21, MA-28
Fuel lines									I*	MA-17, MA-25
Fuel filter	NOTE (3)									-
Engine coolant	NOTE (4)								R*	MA-15, MA-22
Engine oil		R	R	R	R	R	R	R	R	MA-18, MA-25
Engine oil filter [Use part No. 15208 31U00 (for VK45DE), 15208 65F00 (for VQ35DE) or equivalent.]		R	R	R	R	R	R	R	R	MA-19, MA-26

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02

PRE-  
CEDING  
PAGE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M

REFER TO THE FOLLOWING.

M1, M2, E201, E203

-FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM1306E

## Engine room harness

C2	(E1)	B/2	: Fusible link holder
C2	(E2)	GY/2	: Fusible link holder
C1	(E3)	B/2	: IPDM E/R (Intelligent power distribution module engine room)
C1	(E4)	W/4	: IPDM E/R (Intelligent power distribution module engine room)
B1	(E5)	B/4	: IPDM E/R (Intelligent power distribution module engine room)
D2	(E6)	W/6	: IPDM E/R (Intelligent power distribution module engine room)
C1	(E7)	GY/16	: IPDM E/R (Intelligent power distribution module engine room)
C1	(E8)	W/12	: IPDM E/R (Intelligent power distribution module engine room)
D2	(E9)	W/16	: IPDM E/R (Intelligent power distribution module engine room)
F1	(E10)	—	: Fuse and fusible link block
C2	(E11)	—	: Fuse, fusible link and relay box
F1	(E12)	L/4	: Accessory relay-2
B1	(E13)	BR/6	: Rear window defogger relay
B1	(E14)	GY/6	: ICC brake hold relay
A1	(E15)	L/4	: Daytime light relay
B1	(E16)	—	: Relay box
D1	(E17)	GY/6	: To (E47) (With VK engine)
D1	(E18)	GY/9	: To (E48) (With VQ engine)
D1	(E19)	B/8	: To (E49)
B1	(E20)	GY/2	: Hood switch
B2	(E21)	—	: Body ground
A2	(E22)	B/2	: Front side marker lamp RH
A2	(E23)	GY/3	: Clearance lamp RH
A1	(E24)	B/8	: Front combination lamp RH
A3	(E25)	B/2	: To (E101)
A3	(E26)	GY/2	: Washer level sensor
A3	(E27)	BR/2	: Rear washer motor
A3	(E28)	GY/2	: Front washer motor
C2	(E29)	B/8	: To (E121) (With VQ engine)
C2	(E30)	GY/1	: To (E303)
C2	(E31)	—	: Body ground
A2	(E32)	B/3	: Refrigerant pressure sensor
A2	(E33)	GY/2	: Front wheel sensor RH
B3	(E34)	B/2	: Ambient sensor
C3	(E35)	B/1	: Horn low
C3	(E36)	B/1	: Horn low
C4	(E37)	B/1	: Horn high
C4	(E38)	B/1	: Horn high

B4	(E39)	GY/6	: ICC sensor
B4	(E40)	Y/2	: Crash zone sensor
C4	(E41)	GY/4	: Cooling fan motor (With VK engine)
E3	(E42)	B/2	: Front side marker lamp LH
D3	(E43)	GY/3	: Clearance lamp LH
E3	(E44)	B/8	: Front combination lamp LH
D5	(E45)	BR/2	: Front fog lamp LH
E4	(E46)	GY/2	: Front wheel sensor LH
D3	(E49)	—	: Body ground
E3	(E50)	—	: Body ground
D3	(E51)	—	: Body ground
E1	(E52)	GY/2	: Brake fluid level switch
E3	(E53)	B/3	: Pressure sensor
E2	(E54)	GY/6	: Brake booster
D2	(E55)	BR/3	: To (E141)
F2	(E56)	SMJ	: ABS actuator and electric unit (Control unit)
F2	(E57)	GY/5	: Front wiper motor

## Front fog lamp RH sub-harness

A4	(E101)	B/2	: To (E25)
A4	(E102)	BR/2	: Front fog lamp RH

## Cooling fan sub-harness (With VQ engine)

C3	(E121)	DGY/8	: To (E29)
B3	(E122)	GY/4	: Cooling fan motor-1
C3	(E123)	GY/4	: Cooling fan motor-2

## ICC sub-harness

D2	(E141)	BR/3	: To (E55)
E3	(E142)	B/3	: Brake pressure sensor

★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working**  
 according to **WORK FLOW of TROUBLE DIAGNOSES** in EC section.

A  
B  
C  
D  
E  
F  
PS  
H  
I  
J  
K  
L  
M

# SECTION PS

## POWER STEERING SYSTEM

### CONTENTS

<b>PRECAUTIONS</b> .....	<b>3</b>	Components (With Automatic Drive Positioner) ....	17
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	Disassembly and Assembly .....	18
Precautions Necessary for Steering Wheel Rotation After Battery Disconnect .....	3	DISASSEMBLY .....	18
OPERATION PROCEDURE .....	3	ASSEMBLY .....	18
Precautions for Steering System .....	3	<b>POWER STEERING GEAR AND LINKAGE</b> .....	<b>19</b>
<b>PREPARATION</b> .....	<b>5</b>	Removal and Installation .....	19
Special Service Tools (SST) .....	5	REMOVAL .....	19
Commercial Service Tools .....	6	INSTALLATION .....	20
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>		INSPECTION AFTER INSTALLATION .....	21
<b>TROUBLESHOOTING</b> .....	<b>7</b>	Disassembly and Assembly .....	22
NVH Troubleshooting Chart .....	7	DISASSEMBLY .....	23
<b>POWER STEERING FLUID</b> .....	<b>8</b>	INSPECTION AFTER DISASSEMBLY .....	25
Checking Fluid Level .....	8	ASSEMBLY .....	26
Checking Fluid Leakage .....	8	<b>POWER STEERING OIL PUMP</b> .....	<b>31</b>
Air Bleeding Hydraulic System .....	8	On-Vehicle Inspection and Service .....	31
<b>STEERING WHEEL</b> .....	<b>10</b>	CHECKING RELIEF OIL PRESSURE (VQ35DE MODELS) .....	31
On-Vehicle Inspection and Service .....	10	CHECKING RELIEF OIL PRESSURE (VK45DE MODELS) .....	31
CHECKING CONDITION OF INSTALLATION ...	10	Removal and Installation (VQ35DE Models) .....	32
CHECKING STEERING WHEEL PLAY .....	10	REMOVAL .....	32
CHECKING NEUTRAL POSITION ON STEERING WHEEL .....	10	INSTALLATION .....	33
CHECKING STEERING WHEEL TURNING FORCE .....	10	Removal and Installation (VK45DE Models) .....	33
CHECKING FRONT WHEEL TURNING ANGLE..	11	REMOVAL .....	33
Removal and Installation .....	11	INSTALLATION .....	33
<b>STEERING COLUMN</b> .....	<b>12</b>	Disassembly and Assembly (VQ35DE Models) ....	33
Removal and Installation .....	12	INSPECTION BEFORE DISASSEMBLY .....	33
REMOVAL .....	12	DISASSEMBLY .....	34
INSPECTION AFTER REMOVAL .....	14	INSPECTION AFTER DISASSEMBLY .....	34
INSTALLATION .....	14	ASSEMBLY .....	34
INSPECTION AFTER INSTALLATION .....	14	Disassembly and Assembly (VK45DE Models) ....	37
Components (Without Automatic Drive Positioner)..	15	INSPECTION BEFORE DISASSEMBLY .....	37
Disassembly and Assembly .....	15	DISASSEMBLY .....	37
DISASSEMBLY .....	15	INSPECTION AFTER DISASSEMBLY .....	38
ASSEMBLY .....	16	ASSEMBLY .....	38
		<b>HYDRAULIC LINE</b> .....	<b>41</b>
		Components .....	41
		Removal and Installation .....	43
		Component .....	44
		Removal and Installation .....	45

# SERVICE DATA AND SPECIFICATIONS (SDS)

---

A  
B  
C

# SECTION RFD

## REAR FINAL DRIVE

RFD

### CONTENTS

<p><b>PRECAUTIONS</b> ..... 2</p> <p>    Service Notice or Precautions ..... 2</p> <p><b>PREPARATION</b> ..... 3</p> <p>    Special Service Tools ..... 3</p> <p>    Commercial Service Tools ..... 6</p> <p><b>NOISE, VIBRATION AND HARSHNESS (NVH)</b></p> <p><b>TROUBLESHOOTING</b> ..... 7</p> <p>    NVH Troubleshooting Chart ..... 7</p> <p><b>DESCRIPTION</b> ..... 8</p> <p>    Cross-Sectional View ..... 8</p> <p><b>DIFFERENTIAL GEAR OIL</b> ..... 9</p> <p>    Changing Differential Gear Oil ..... 9</p> <p>        DRAINING ..... 9</p> <p>        FILLING ..... 9</p> <p>    Checking Differential Gear Oil ..... 9</p> <p>    OIL LEAKAGE AND OIL LEVEL ..... 9</p> <p><b>FRONT OIL SEAL</b> ..... 10</p> <p>    Removal and Installation ..... 10</p> <p>        REMOVAL ..... 10</p> <p>        INSTALLATION ..... 11</p> <p><b>SIDE OIL SEAL</b> ..... 12</p> <p>    Removal and Installation ..... 12</p> <p>        REMOVAL ..... 12</p> <p>        INSTALLATION ..... 12</p>	<p><b>REAR FINAL DRIVE ASSEMBLY</b> ..... 14</p> <p>    Removal and Installation ..... 14</p> <p>        COMPONENTS ..... 14</p> <p>        REMOVAL ..... 14</p> <p>        INSTALLATION ..... 15</p> <p>    Disassembly and Assembly ..... 16</p> <p>        COMPONENTS ..... 16</p> <p>        ASSEMBLY INSPECTION AND ADJUSTMENT.. 17</p> <p>        DISASSEMBLY ..... 21</p> <p>        INSPECTION AFTER DISASSEMBLY ..... 25</p> <p>        ADJUSTMENT AND SELECTION OF ADJUST-         ING WASHERS ..... 25</p> <p>        ASSEMBLY ..... 30</p> <p><b>SERVICE DATA AND SPECIFICATIONS (SDS) ..... 36</b></p> <p>    General Specifications ..... 36</p> <p>    Inspection and Adjustment ..... 36</p> <p>        DRIVE GEAR RUNOUT ..... 36</p> <p>        DIFFERENTIAL SIDE GEAR CLEARANCE ..... 36</p> <p>        PRELOAD TORQUE ..... 36</p> <p>        BACKLASH ..... 36</p> <p>        COMPANION FLANGE RUNOUT ..... 36</p> <p>        SELECTIVE PARTS ..... 36</p>
--	---

E

F

G

H

I

J

K

L

M

# SHOCK ABSORBER

---

## INSPECTION AFTER DISASSEMBLY

### Bound Bumper and Bushing

Check bound bumper and bushing for cracks, deformation or other damage. Replace if necessary.

## ASSEMBLY

- Refer to [RSU-7, "Components"](#) for tightening torque. Assembly in the reverse order of disassembly.

### NOTE:

- Refer to component parts location and do not reuse non-reusable parts.
- Make sure piston rod on shock absorber is not damaged when attaching components to shock absorber.

# CHARGING SYSTEM

## PRELIMINARY INSPECTION

### 1. CHECK BATTERY TERMINALS CONNECTION

Check if battery terminals are clean and tight.

OK or NG

OK >> GO TO 2.

NG >> Repair battery terminals connection.

### 2. CHECK FUSE AND FUSIBLE LINK

Check for blown alternator and combination meter fuses.

Unit	Power source (Power supply terminals)	Fuse No.
Alternator	Battery ("S" terminal)	33
Combination meter	Ignition switch ON ("L" terminal)	14

OK or NG

OK >> GO TO 3.

NG >> If fuse is blown, be sure eliminate cause of malfunction before installing new fuse.

### 3. CHECK "E" TERMINAL CONNECTION

Check if "E" terminal is clean and tight.

OK or NG

OK >> GO TO 4.

NG >> Repair "E" terminal connection.

### 4. CHECK ALTERNATOR DRIVE BELT TENSION

Check alternator drive belt tension. Refer to [EM-173, "Checking Drive Belts"](#) (VK45DE) or [EM-15, "Checking Drive Belts"](#) (VQ35DE).

OK or NG

OK >> INSPECTION END

NG >> Repair as needed.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

SC

# AUTOMATIC DRIVE POSITIONER

## 8. CHECK GROUND CIRCUIT (AUTOMATIC DRIVE POSITIONER CONTROL UNIT)

Check continuity between the automatic drive positioner control unit connector M50 terminal 40, 48 and ground.


**40 (B) – Ground : Continuity should exist.**

**48 (B) – Ground : Continuity should exist.**

OK or NG

OK >> Driver seat control unit circuit is OK.

NG >> Repair or replace harness between automatic drive positioner control unit and ground.



## CONSULT-II Function (AUTO DRIVE POS.)

AIS002YF

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

CONSULT-II diagnosis items	Inspection item, self-diagnosis mode		Content
AUTO DRIVE POSITIONER	WORK SUPPORT*1		Changes the setting for each function.
	SELF-DIG RESULTS		Check the self-diagnosis results.
	DATA MONITOR	Selection from menu	Displays the input data to driver seat control unit and automatic driving positioned control unit on real-time basis.
	CAN DIAGNOSTIC SUPPORT MONITOR		The results of transmit / receive diagnosis of CAN communication can be read
	ACTIVE TEST*3		Gives a drive signal to a load to check the operation.
	DRIVER SEAT CONTROL UNIT PART NUMBER		Displays driver seat control unit part No.
BCM*2	DATA MONITOR	Selection from menu	Displays the input data to BCM on real-time basis

\*1: For setting automatic drive positioner functions only.

\*2: Refer to [BL-38. "Data Monitor"](#).


\*3: During vehicle driving, do not perform active test.

## CONSULT-II INSPECTION PROCEDURE

### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.



3. Turn ignition switch "ON".

# AUTOMATIC DRIVE POSITIONER

## Key Switch Circuit Check (Without Intelligent Key)

AIS003G1


### 1. CHECK KEY SWITCH

#### With CONSULT-II

Touch "BCM". With "IGN KEY SW" on the DATA MONITOR, Check ON/OFF operation.

\*: Refer to [BL-38, "Data Monitor"](#)

Monitor item [OPERATION or UNIT]	Contents	
IGN KEY SW*	"ON/ OFF"	Key inserted (ON)/key removed (OFF) status judged from the key-in detection switch is displayed.



#### Without CONSULT-II

GO TO 2.

OK or NG

OK >> Key switch circuit is OK.

NG >> GO TO 2.

### 2. CHECK KEY SWITCH AND KEY LOCK SOLENOID POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect key switch connector.
3. Check voltage between key switch connector M23 terminal 2 and ground.

**2 (L/R) – Ground : Battery voltage.**

OK or NG

OK >> GO TO 3.

NG >> Check harness between key switch and fuse.



### 3. CHECK KEY SWITCH


Check continuity between key switch connector M23 terminal 1 and 2.

Con- nector	Terminal		Condition	Continuity
M23	1	2	Key is inserted in ignition key cylinder.	Yes
			Key is removed from ignition key cylinder.	No

OK or NG

OK >> GO TO 4.

NG >> Replace key switch.



## TROUBLE DIAGNOSIS

Diagnostic item	Explanation	Repair order "Recheck SRS at each replacement"
PRE-TEN FRONT RH [OPEN]	● Front RH pre-tensioner circuit is open.	1. Visually check the wiring harness connections. 2. Replace the harness if it has visible damage. 3. Replace the front RH seat belt. 4. Replace the diagnosis sensor unit. 5. Replace the related harness.
PRE-TEN FRONT RH [VB-SHORT]	● Front RH pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN FRONT RH [GND-SHORT]	● Front RH pre-tensioner circuit is shorted to ground.	
PRE-TEN FRONT RH [SHORT]	● Front RH pre-tensioner circuit is shorted between lines.	
CURTAIN MODULE LH [OPEN]	● LH side curtain air bag module circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the LH side curtain air bag module. 4. Replace the diagnosis sensor unit. 5. Replace the related harness.
CURTAIN MODULE LH [VB-SHORT]	● LH side curtain air bag module circuit is shorted to a power supply circuit.	
CURTAIN MODULE LH [GND-SHORT]	● LH side curtain air bag module circuit is shorted to ground.	
CURTAIN MODULE LH [SHORT]	● LH side curtain air bag module circuit is shorted between lines.	
CURTAIN MODULE RH [OPEN]	● RH side curtain air bag module circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the RH side curtain air bag module. 4. Replace the diagnosis sensor unit. 5. Replace the related harness.
CURTAIN MODULE RH [VB-SHORT]	● RH side curtain air bag module circuit is shorted to a power supply circuit.	
CURTAIN MODULE RH [GND-SHORT]	● RH side curtain air bag module circuit is shorted to ground.	
CURTAIN MODULE RH [SHORT]	● RH side curtain air bag module circuit is shorted between lines.	
CONTROL UNIT	● Diagnosis sensor unit is malfunctioning.	1. Visually check the wiring harness connection. 2. Replace the diagnosis sensor unit.




### NOTE:

- Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using air bag warning lamp or CONSULT-II each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

# TROUBLE DIAGNOSIS

TF-AWD-03

A  
B  
C  
TF  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

TDWM0035E

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL