

8

5

3

8

5


3

H



Service Manual

(S/N 508411001–508417999)
(S/N 509711001–509717999)
(S/N 510250001 & Above)
(S/N 510375001 & Above)
(S/N 512815001–512815999)
(S/N 510125001 & Above)
(S/N 512311001 & Above)



MELROE
INGERSOLL-RAND

6720755 (6–99)

Printed in U.S.A.



© Melroe Company 1999

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SAFETY INSTRUCTIONS


WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0299

The following publications provide information on the safe use and maintenance of the loader and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the loader gives operating information as well as routine maintenance and service procedures. It is a part of the loader and must stay with the machine when it is sold. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat loader dealer.
- The loader has machine signs (decals) which instruct on the safe operation and care. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat loader dealer.
- The loader has a plastic Operator's Handbook fastened to the operator cab. Its brief instructions are convenient to the operator. The Handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The EMI Safety Manual (available in Spanish) delivered with the loader gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer. This course is intended to provide rules and practices for correct operation of the Bobcat loader. The course is available in English and Spanish version.
- The Service Safety Training Course is available from your Bobcat dealer. This course provides information for safe and correct service procedures for Bobcat Skid-Steer loaders.
- The Bobcat Skid-Steer Loader Safety Video is available from your Bobcat Dealer.



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

LIFT ARM SUPPORT DEVICE

WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by a lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.

W-2059-0991

Engaging the Lift Arm Support Device

Maintenance and service work can be done with the lift arms lowered.

If the lift arms must be raised for service, use the following procedure:

Put jackstands under the rear corners of the loader.

Disconnect the spring (Item 1) [A] from the lift arm support device retaining pin (Item 2) [A]. Hold onto the lift arm support device and remove the retaining pin.

Lower the lift arm support device on top of the lift cylinder. Hook the free end of the spring (Item 1) [B] to the lift arm support device so there will be no interference with the support device engagement.

With the operator in the seat, seat belt fastened and seat bar lowered, start the engine.

Raise the lift arms, until the lift arm support device drops onto the lift cylinder rod [C].




Lower the lift arms slowly until the support device is held between the lift arm and the lift cylinder. Stop the engine. Raise the seat and move pedals until both pedals lock.

Install pin (Item 1) [C] into the rear of the lift arm support device below the cylinder rod.

WARNING

Service lift arm support device if damaged or if parts are missing. Using a damaged lift arm support or with missing parts can cause lift arms to drop causing injury or death.

W-2271-1197



ENGINE LUBRICATION SYSTEM (Cont'd)

Replacing Oil And Filter (Cont'd)

Remove the oil filler cap (Item 1) [A].

Put 8 qts. (7,6 L) of oil in the engine. (See Oil Chart, Page 1-16.)


Start the engine and let it run for several minutes. Stop the engine. Check for leaks at the oil filter. Add oil as needed if it is not at the top mark on the dipstick.



WARNING

Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. Failure to use care around combustibles can cause explosion or fire which can result in injury or death.

W-2103-1285



LUBRICATING THE LOADER

Procedure

Lubricate the loader as specified in the *SERVICE SCHEDULE*, Page 1–3 for the best performance of the loader.

Record the operating hours each time you lubricate the Bobcat loader.





Always use a good quality lithium based multi-purpose grease when you lubricate the loader. Apply the lubricant until extra grease shows.

Lubricate the following locations on the loader:

1. Rod End Lift Cylinder (Both Sides) [A].
2. Base End Lift Cylinder (Both Sides) [B].

3. Lift Arm Pivot Pin (Both Sides) [C].

4. Base End Tilt Cylinder [D].





HYDRAULIC / HYDROSTATIC SYSTEM OPERATIONS

To Be Used With HYDRAULIC / HYDROSTATIC FLOW CHART

For Model
853H

Chart #6720956 (Printed March 2003)

CHART LEGEND

- | | |
|--|---|
| 1 RESERVOIR, Cap.: . . . 15.5 Qts. (14,7 L) | 30 LOAD CHECK VALVE (2) |
| 2 BREATHER, 5 Micron | 31 RESTRICTOR |
| 3 FILL CAP | 32 RELIEF VALVE (HIGH FLOW)
3250-3350 PSI (22409-23098 kPa) |
| 4 SCREEN, 60 Mesh | 33 PORT RELIEF, . . 3500 PSI (24132 kPa) |
| 5 REAR AUXILIARY QUICK COUPLERS
(OPTIONAL) | 34 ELECTRICAL SOLENOID VALVE |
| 6 CHECK VALVE, 225-290 PSI
(1551-2000 kPa) | 35 MAIN RELIEF VALVE, . . 2550-2600 PSI
(17582-17927 kPa) |
| 7 HYDROSTATIC MOTOR | 36 HYDRAULIC FILTER, #4 Media |
| 8 PORT RELIEF VALVE (OPTIONAL)
2550-2600 PSI (17582-17927 kPa) | 37 CHECK VALVE, 1 PSI (7 kPa) |
| 9 FRONT AUXILIARY VALVE | 38 DIFFERENTIAL PRESSURE SWITCH
(Normally Closed) 36-44 PSI
(248-303 kPa) |
| 10 OPEN CHECK PILOT VALVE (OPTIONAL)
30 PSI (207 kPa) | 39 BY-PASS VALVE, 44-55 PSI
(310-379 kPa) |
| 11 ELECTRICAL VALVE SOLENOIDS | 40 CHARGE FILTER, #4Media |
| 12 RELIEF VALVE (HIGH FLOW)
3250-3350 PSI (22409-23098 kPa)
@ 18 GPM (68,1 L/min.) | 41 FLUID TEMPERATURE SENSOR |
| 13 ELECTRICAL SELECTIVE VALVE | 42 LOCK VALVE (OPTIONAL) |
| 14 CHECK VALVE | 43 PORT BLOCK |
| 15 CASE DRAIN COUPLER | 44 COLD OIL BY-PASS VALVE, . . . 85 PSI
(586 kPa) |
| 16 FRONT AUXILIARY QUICK COUPLERS | 45 HYDROSTATIC PUMP |
| 17 HIGH FLOW QUICK COUPLERS | 46 DISPLACEMENT CONTROL VALVE |
| 18 SIDE SHIFT QUICK COUPLERS | 47 CHARGE PRESSURE SENSOR |
| 19 TILT CYLINDER | 48 CHARGE RELIEF VALVE
100° F. (38° C.) Fluid @ Full RPM
Neutral 310-330 PSI (2137-2275 kPa)
Stroked 300-320 PSI (2069-2206 kPa) |
| 20 LIFT CYLINDER | 49 HIGH PRESSURE RELIEF/REPLENISHING
VALVE, 5000 PSI (34475 kPa) |
| 21 BUCKET POSITION VALVE | 50 CHARGE PUMP, 11.0 GPM (41,6 L/min.) |
| 22 FLOW ADJUSTMENT VALVE | 51 TOW VALVES |
| 23 FLOW CONTROL SPOOL | 52 HYDRAULIC PUMP, . . . @ 2750 RPM
@ 1150 PSI (7929 kPa)
a. 18.0 GPM (68,1 L/min.)
b. 6.0 GPM (22,7 L/min.) |
| 24 CHECK VALVE | 53 OIL COOLER |
| 25 UN-LOADING SPOOL/PRESS. RELIEF
VALVE | |
| 26 CONTROL VALVE POWER-BEYOND
OUTLET | |
| 27 AUXILIARY ELECTRICAL SOLENOIDS | |
| 28 ANTI-CAVITATION VALVE | |
| 29 HYDRAULIC CONTROL VALVE | |

HYDRAULIC/HYDROSTATIC SCHEMATIC

853 (S/N 508415216-17999)
 (S/N 510126792 AND ABOVE)
 (S/N 510250692 AND ABOVE)
 (S/N 512811001-15999)


(Printed June 1999)
 MC2397LU

LEGEND

- | | | | |
|--|---|---|--|
| <p>① RESERVOIR:
 Capacity 15.5 Qts (14,7 L)</p> <p>② SPRING LOADED FILTER BYPASS
 VALVE: 45-55 PSI (311-379 kPa)</p> <p>③ DIFFERENTIAL PRESSURE SWITCH:
 36-44 PSI (248-303 kPa)
 853 PLUS - Normally Closed
 853 BASE - Normally Closed</p> <p>④ CHECK VALVE - FILTER</p> <p>⑤ FLOW DIVIDER ADJUSTMENT VALVE</p> <p>⑥ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - FLOW CONTROL
 SPOOL</p> <p>⑦ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - UNLOADING
 SPOOL</p> <p>⑧ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - FOR REAR
 AUXILIARY - NORMALLY OPEN
 ("D2")</p> <p>⑨ RELIEF VALVE - PORT: (OPTIONAL)
 3100 PSI (21371 kPa)</p> <p>⑩ SOLENOID ACTIVATED DIRECTIONAL
 CONTROL VALVE - AUXILIARY
 (OPTIONAL)</p> <p>⑪ CHECK VALVE - BUCKET POSITION
 VALVE</p> <p>⑫ RELIEF/ANTICAVITATION VALVE -
 PORT (TILT BASE END):
 2500 PSI (17238 kPa)</p> | <p>⑬ RELIEF VALVE - PORT:
 3500 PSI (24132 kPa)</p> <p>⑭ LOAD CHECK VALVE</p> <p>⑮ ONE WAY RESTRICTOR VALVE</p> <p>⑯ RELIEF VALVE - MAIN:
 2550-2600 PSI (17582-17927 kPa)
 at Front Quick Couplers</p> <p>⑰ SHUTTLE RELIEF VALVE:
 225-290 PSI (1551-2000 kPa)</p> <p>⑱ DRIVE MOTOR SHUTTLE VALVE</p> <p>⑲ TOW VALVE</p> <p>⑳ RELIEF/REPLENISHING VALVE - HIGH
 PRESSURE:
 STANDARD . 4350 PSI (29990 kPa)
 OPTIONAL . 5000 PSI (34475 kPa)</p> <p>㉑ DISPLACEMENT CONTROL VALVE</p> <p>㉒ CHARGE PUMP 11.0 GPM
 (41,6 L/M in.) at 2850 RPM</p> <p>㉓ HYDRAULIC PUMP
 18.0 GPM (68,1 L/min.)
 at 2750 RPM</p> | <p>㉔ FILTER</p> <p>㉕ RELIEF VALVE - CHARGE:
 140°F. (60°C.) Fluid at Full RPM
 Neutral 310-330 PSI
 (2137-2275 kPa)
 Stroked 300-320 PSI
 (2069-2206 kPa)</p> <p>㉖ MUFLER (if Equipped)</p> <p>㉗ CHARGE PRESSURE SENSOR</p> <p>㉘ FLUID TEMPERATURE SENSOR</p> <p>㉙ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - FOR REAR
 AUXILIARY - NORMALLY OPEN
 ("D1")</p> <p>㉚ SOLENOID ACTIVATED DIRECTIONAL
 CONTROL VALVE - FRONT
 AUXILIARY (OPTIONAL ON 853 BASE)</p> <p>㉛ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - FOR REAR
 AUXILIARY - NORMALLY CLOSED
 ("P1" and "F1")</p> <p>㉜ FILTER</p> <p>㉝ SOLENOID ACTIVATED DIRECTIONAL
 CONTROL VALVE</p> <p>㉞ FILTER - HYDROSTATIC (CANISTER)</p> <p>㉟ PILOT ACTIVATED DIRECTIONAL
 CONTROL VALVE - FOR REAR
 AUXILIARY - NORMALLY CLOSED
 ("P2" and "F2")</p> <p>㊱ FILTER - HYDRAULIC (CANISTER)</p> <p>㊲ FILTER</p> | <p>㊳ FIXED CAPACITY DISPLACEMENT
 BIDIRECTIONAL HYDROSTATIC
 MOTOR</p> <p>㊴ ANTICAVITATION VALVE</p> |
|--|---|---|--|

NOTE: Unless otherwise specified,
 springs have NO significant
 pressure value.

HYDRAULIC/HYDROSTATIC SCHEMATIC
 HI-FLOW MACHINE
 853 (S/N 512811001 AND ABOVE WITH JEM AUXILIARY VALVE)
 (Printed June 1999)
 MC2399U



——— WORKING CIRCUITS
 - - - PILOT PRESSURE
 ····· DRAIN CIRCUITS
 - - - COMPONENTS

HYDRAULIC CYLINDERS (Cont'd)

Disassembly

Use the following tools to disassemble the cylinder:

MEL1074 – O-ring Seal Hook
Spanner Wrench

The lift and tilt cylinders internal components are similar, the differences are listed below:

- Tilt rod diameter is larger.
- Piston relief area is slightly different.
- No spacer in the tilt cylinder.

Hold the hydraulic cylinder over a drain pan and move the rod in and out slowly to remove the fluid from the cylinder.

Put the base end of the cylinder in a vise.



Use a spanner wrench to loosen the head [A] & [B].

Lift Cylinder: Remove the head and the rod assembly from the cylinder [C]. Put the rod end in a vise.

Lift Cylinder: Remove the nut (Item 1) [C], piston (Item 2) [C], spacer (Item 3) [C] (if so equipped) and head (Item 4) [C].

Tilt Cylinder: Remove the head and rod assembly from the cylinder [D]. Put the rod end in a vise.

Tilt Cylinder: Remove the nut (Item 1) [D], piston (Item 2) [D] and head (Item 3) [D].



DUAL PRESSURE MAIN RELIEF VALVE (S/N 512811001 & Above) W/Select Valve (JEM) (Cont'd)

Checking The High Setting (Cont'd)

Install the hose (Item 1) [A] on the secondary auxiliary quick couplers as shown.

NOTE: The hose loop (Item 1) [A] (with .070 inch orifice), provides restriction and pilot pressure necessary to shift the dual stage main relief valve to the high pressure setting.



WARNING

When the engine is running during service, the steering levers must be in neutral and the parking brake engaged. Failure to do so can cause injury or death.

W-2006-0284

Start the engine and run at low idle RPM. Increase the engine speed to full RPM. Push the mode switch (Item 1) [B] twice (on the instrument panel) to engage the front auxiliary hydraulics *detent*, the lights (Items 2 & 3) [B] will come ON.

NOTE: The High Horsepower switch should be in the OFF position.

Push the button (Item 1) [C] to engage the *detent* position to the front auxiliary quick couplers.




Push and hold the button (Item 2) [C] for fluid flow through the secondary auxiliary couplers and hose loop.

Watch the flow meter on the hydraulic tester to be sure the flow is correct.

There should be approximately 18.0 GPM (68,1 L/min.) free flow. Turn the restrictor control on the tester, until the main relief valve opens. The correct pressure for the main relief is 3000 PSI (20685 kPa).

Release the button (Item 2) [C] and push the button (Item 1) [C] to disengage the *detent* position to the front auxiliary quick couplers.

If the relief pressure is not correct, stop the engine. Replace or adjust the main relief valve. (See Page 2-27.)



HYDRAULIC FILTER HOUSING

Removal And Installation

⚠ WARNING


Never work on a machine with the lift arms up unless the lift arms are secured by an approved lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.

W-2059-0598

⚠ DANGER

AVOID DEATH

- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop.
- Keep out of this area when lift arms are raised unless supported by an approved lift arm support. Replace if damaged. 531 45






SW 98 6717343

Disconnect the tubelines from the inlet of the hydraulic filter [A].

Disconnect the hose (Item 1) [B] from the outlet of the filter.

Remove the two mounting bolts and remove the hydraulic filter and housing [C].

Installation: Tighten the mounting bolts to 25 ft.-lbs. (34 Nm) torque.



HYDROSTATIC SYSTEM

	Page Number
COLD OIL BY-PASS VALVE Removal And Installation	3-21
DRIVE BELT Replacing The Drive Belt	3-27
DRIVE BELT SHIELD Removal And Installation	3-26
FIXED TENSIONER PULLEY Adjusting The Drive Belt	3-41
Assembly	3-36
Checking Pulley End Play	3-40
Disassembly	3-34
Removal And Installation	3-33
FRONT PANEL Removal And Installation	3-5
HYDROSTATIC CHARGE OIL FILTER Removal And Installation	3-19
HYDROSTATIC MOTOR Removal And Installation	3-17
HYDROSTATIC PUMP Removal And Installation	3-23
Replenishing/High Pressure Relief Valve	3-25
HYDROSTATIC SYSTEM INFORMATION Replenishing Valve Function	3-4
Tow Valves	3-4
OIL COOLER Removal And Installation	3-42
SPRING LOADED TENSIONER PULLEY Adjusting The Drive Belt	3-32
Assembly	3-30
Disassembly	3-29
Parts Identification	3-28
STEERING LEVERS Adjusting Lever Freeplay	3-10
Adjusting The Steering Neutral Setting	3-13
Adjusting The Wheel RPM Forward Compared To Reverse Travel ...	3-11
Adjusting The Wheel RPM Left Compared To Right Side	3-14
Disassembly And Assembly	3-7
Neutral Pre-Adjustment Checks	3-9
Hydrostatic Pump Neutral Adjustment	3-15
TROUBLESHOOTING Chart	3-3

HYDROSTATIC SYSTEM

STEERING LEVERS (Cont'd)

Adjusting The Wheel RPM Forward Compared To Reverse Travel

Read this adjustment completely to become familiar with the procedure before beginning the adjustment.

NOTE: This procedure adjusts the position of the steering levers in the panel when in neutral. Levers centered in steering panel give equal travel forward compared to reverse.

1. Disconnect the two bolts of the pintle links (both sides) (Item 1) [A].
2. Fully lower steering lever stop and tighten (both sides) (Item 1) [B].





NOTE: Before measuring, move the steering lever a small amount to be sure the cam is in the detent pocket with no freeplay.

3. Move the lever to full forward, measure the distance from the U-bolt to the lock nut. Record this measurement [C].

EXAMPLE ONLY: 3.66 inch (82,0 mm)

4. Move the lever to full reverse, measure the distance from the U-bolt to the lock nut. Make a record of this measurement [D].

EXAMPLE ONLY: 2.76 inch (70,0 mm)



COLD OIL BY-PASS VALVE

Removal And Installation

WARNING

Never work on a machine with the lift arms up unless the lift arms are secured by an approved lift arm support device. Failure to use an approved lift arm support device can allow the lift arms or attachment to fall and cause injury or death.


W-2059-0598

DANGER

AVOID DEATH

- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop.
- Keep out of this area when lift arms are raised unless supported by an approved lift arm support. Replace if damaged.

531 45



6W 98 6717343





Remove the cold oil by-pass valve plug, spring and poppet to check for damage [A].

Replace the plug, spring and poppet if necessary.

Disconnect the cold oil by-pass valve outlet tubeline [B].

Disconnect the charge pump outlet hose from the tee on the by-pass valve [C].


Disconnect the oil cooler inlet tubeline from the tee fitting [D].



SPRING LOADED DRIVE BELT TENSIONER PULLEY (Cont'd)


Assembly (Cont'd)

Install the first retainer washer (Item 1) [A] and spring washer (Item 2) [A] over the roll pins.




Install the second retainer washer (Item 1) [B], the washer (Item 2) [B] and the bolt (Item 3) [B]. Tighten the bolt to 28–32 ft.-lbs. (38–45 Nm) torque.

Fill the grease cap 1/4 full (approximately 1/2–3/4 oz.) of grease.



Press the grease cap (Item 1) [C] onto the pulley assembly (Item 2) [C]. Press on the outer formed edge of the grease cap.

NOTE: When pressing the grease cap onto the pulley assembly, do not press down on the arrow indicator plate. Support the hub assembly so that it contacts only the hub and not the arrow indicator plate.



FIXED TENSIONER PULLEY (Cont'd)

Adjusting The Drive Belt

See the *SERVICE SCHEDULE* Page 1-1 for the service interval.

To adjust the drive belt between the engine flywheel and the hydrostatic pump pulley, use the following procedure:

Raise the operator cab. (See Page 1-1.)

Remove the belt shield. (See Page 3-26.)

Use the following tools to check the belt tension:



MEL1404 – Bar
MEL1406 – Spring Scale

1. Install the tool on the drive belt. The pin (Item 1) [A] must be pulled tight against the engine drive pulley.
2. Make a mark (Item 2) [A] on the cast flange just above the tool handle.
3. Install the spring scale on the tool handle. The line of pull (Item 3) [A] on the spring scale must be at approximately 90° from the tool handle.
4. Loosen bolt (Item 4) [A] and jam nut (Item 5) [A].
5. Tighten adjustment nut (Item 6) [A] to increase belt tension; loosen to decrease belt tension.
6. Tighten bolt (Item 4) [A] and jam nut (Item 5) [A].

NEW BELT: (less than .5 hours use): With 14 lbs. (62 N) for force, the tool should move 1.25 inches (32,0 mm) (the width of the tool handle). Run the engine approximately 5 minutes and readjust the tension.

USED BELT: (more than .5 hours use): With 12 lbs. (52 N) of force, the tool should move 1.25 inches (32,0 mm) (the width of the tool handle).

Always readjust if a tension check results in a reading of less than 10 lbs. (44N) of force.



AXLE SEAL

Removal And Installation

Lift and block the loader. (See Page 1–1.)

Remove the tire/wheel assembly.

Installation: Tighten the wheel nuts to 105–115 ft.-lbs. (142–155 Nm) torque.

Remove the bolts (Item 1) [A] and plate.

Installation: Tighten the bolts to 175–190 ft.-lbs. (240–260 Nm) torque.

Remove the two wheel studs (Item 2) [A] across from each other.

Install puller (Item 1) [B] on the wheel hub.

WARNING





NEVER STAND IN-LINE OF THE HUB WHEN REMOVING A HUB FROM AN AXLE. The hub has a tapered fit on the axle end and can come off the axle with great force and cause serious injury.

W-2186-0395

Remove the hub from the axle.

Remove the key (Item 1) [C] from the axle.


Drill a hole into the axle seal [D].




REDUCTION GEARCASE (Cont'd)

Disassembly (Cont'd)


Remove the bolt from the disc hub [A].




Remove the bolt and washer [B].



Remove the disc hub and key [C].



Put the gearcase housing in the press and remove the output shaft [D].



MAIN FRAME

	Page Number
BOB-TACH	
Bob-Tach Lever And Wedge	5-9
Bob-Tach Stops	5-10
Removal And Installation	5-7
FUEL TANK	
Fuel Level Sender	5-16
Inlet Screen	5-16
Removal And Installation	5-15
LIFT ARMS	
Removal And Installation	5-11
OPERATOR CAB	
Removal And Installation	5-5
OPERATOR CAB GAS CYLINDER	
Disassembly And Assembly	5-4
Removal And Installation	5-3
REAR DOOR	
Bumper Removal And Installation	5-14
Door Latch And Catch Adjustment	5-14
Door Latch Removal And Installation	5-14
Hood Removal And Installation	5-14
Removal And Installation	5-13
REAR GRILL	
Removal And Installation	5-12

**MAIN
FRAME**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

LIFT ARMS

Removal And Installation


Roll the Bob-Tach (Item 1) [A] fully forward.

Stop the engine.

Remove the Bob-Tach (Item 1) [A] from the lift arms (Page 5–7).

Install the slings (Item 2) [A] on the lift arms.

Connect a chain hoist to the slings [A].




Remove the retainer bolt and nut (Item 1) [B] from the rod end lift cylinder pivot pin (both sides).

Installation: Tighten the retainer bolt and nut to 18–20 ft.-lbs. (24–27 Nm) torque.

Raise the lift arms with the chain hoist so there is enough clearance to remove the rod end pivot pin.

Remove the lift cylinder rod end pivot pin (both sides).

Lower the lift arms.




Disconnect the auxiliary hydraulic tubelines and hoses (Item 1) [C] if so equipped (both sides).


Remove the retainer bolt and nut (Item 2) [C] from the lift arm pivot pin.

Installation: Tighten the retainer bolt and nut to 18–20 ft.-lbs. (24–27 Nm) torque.

Remove the lift arm pivot pin.

Raise the lift arms with the chain hoist and remove from the loader frame.







853 BOSS - WIRING SCHEMATIC

S/N 508412461-15055
 S/N 509711335-15096
 S/N 510250001-50161
 S/N 510375001-75092
 (Printed June 1999)
 MC2563


CONTROLS HARNESS - 6703878




CAB HARNESS (BOSS) - 6704407




TRANSDUCER HARNESS - 6704345



REAR LIGHT HARNESS - 6704232



ENGINE HARNESS (BOSS) - 6704234



RED = RED
 RNG = ORANGE
 BLK = BLACK
 LBL = LIGHT BLUE
 DBL = DARK BLUE
 LGN = LIGHT GREEN
 DGN = DARK GREEN
 YEL = YELLOW
 PNK = PINK
 WHT = WHITE
 BRN = BROWN
 TAN = TAN
 PUR = PURPLE
 GRY = GREY

WIRES CONNECT BY LETTER ACROSS CONNECTORS

SOME CONNECTOR BODIES NOT SHOWN FOR DRAWING CLARITY

TROUBLESHOOTING

Chart

The following troubleshooting chart is provided for assistance in locating and correcting problems. Many of the recommended procedures must be done by authorized Bobcat Service Personnel only.

WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manuals, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0199

PROBLEM	CAUSE
Battery will not take a charge.	2, 3, 4
Alternator will not charge.	1, 4
Starter will not turn the engine.	2, 3, 4, 6, 7, 8, 9

KEY TO CORRECT THE CAUSE
<ol style="list-style-type: none">1. Alternator belt is loose or damaged.2. Battery connections are dirty or loose.3. Battery is damaged.4. The cable & wire connection are not making a good contact.5. The alternator is damaged.6. The engine is locked.7. The starter is damaged.8. The wiring or the solenoid is damaged.9. Check the fuses.


ALTERNATOR (Cont'd)

Assembly

Reverse the order of disassembly.

Place the rotor in soft jaws when tightening the shaft nut. Tighten to 50 ft.-lbs. (68 Nm) torque **[A]**.

Install the rear case half and the remaining parts.



ENGINE SERVICE


	Page Number
AIR CLEANER HOUSING	
Removal And Installation	7-8
BELT SHIELD	
Removal And Installation	7-38
CAMSHAFT	
Camshaft Bearings	7-79
Checking	7-78
Removal And Installation	7-78
Tappets	7-79
Tappet Installation	7-80
CAMSHAFT GEAR	
Removal And Installation	7-76
COOLANT RECOVERY TANK	
Removal And Installation	7-9
CRANKSHAFT	
Checking The Crankshaft	7-67
Checking Tuffriding Coating	7-67
Removal And Installation	7-67
CRANKSHAFT GEAR	
Removal And Installation	7-69
CYLINDER LINERS	
Checking The Cylinder Bore	7-63
Installation	7-63
Removal	7-63
CYLINDER HEAD	
Cylinder Head Surface Alignment	7-52
Exhaust Manifold	7-52
Removal And Installation	7-51
ENGINE	
Removal And Installation	7-30
ENGINE COMPRESSION	
Checking	7-41
ENGINE MOUNTS	
Removal And Installation	7-39
ENGINE MUFFLER	
Removal And Installation	7-7
ENGINE SPEED CONTROL	
Removal And Installation	7-6

**ENGINE
SERVICE**

RADIATOR (Cont'd)


Removal And Installation (Cont'd)

Disconnect the over-fill hose (Item 1) [A].




If so equipped, disconnect the wires from the water level sensor (Item 1) [B].

Remove the radiator from the loader.




Installation: Be sure the rubber bumpers (Item 2) [A] are located at each side (Item 1) [C] before installing the radiator tabs into the loader frame.



FAN GEARBOX (Cont'd)

Disassembly (Cont'd)

Remove the screw and washer (Item 1) [A] from the shaft.




Remove the snap ring from the cap end of the housing [B].




Press the shaft from the housing [C].

NOTE: Both bearings may come out of the housing with the shaft. If one bearing remains in the housing, use a non metal object to tap the bearing from the housing.




Press the bearing from the tapered end of the shaft [D].



ENGINE (Cont'd)

Removal And Installation (Cont'd)


Disconnect the wires (Item 1 & 2) [A] at the filter.



Disconnect the electrical harness connectors (Item 1) [B].


Disconnect the ground wire and harness clamp (Item 2) [B].

NOTE: The electrical harness will be removed with the engine.



Disconnect the hose (Item 1) [C] from the oil cooler.

Disconnect the hose (Items 2 & 3) [C] from the hydrostatic pump.



IMPORTANT

When making repairs on hydrostatic and hydraulic systems, clean the work area before disassembly and keep all parts clean. Always use caps and plugs on hoses, tubelines and ports to keep dirt out. Dirt can quickly damage the system.

I-2003-0284

VALVE CLEARANCE

Adjustment

Make the valve clearance adjustment with engine stopped and cold.

The correct clearance is 0.016 inch (0,41 mm) with the engine cold **[A]**.

Put the correct size feeler gauge between the rocker arm and the valve stem. Turn the adjustment bolt until the clearance is correct **[B]**.

Use the following sequence to set the valve clearance:

Cylinder No.	Front		Rear	
	1	2	3	4
Valve arrangement	I	E	I	E
Piston in No. 1 cylinder is at TDC on compression stroke	•	•		•
Piston in No. 4 cylinder is at TDC on compression stroke			•	•

ENGINE COMPRESSION

Checking

The tools listed will be needed to do the following procedure:

OEM1074 – Engine Compression Kit
MEL1268 – Compression Gauge Test Adapter

The engine must be at operating temperature.

Remove the glow plugs **[C]**. (See Page 7–40.)

Install the correct compression adapter into the cylinder head.





Connect the compression gauge **[D]**.

The engine must be turning at about 175 RPM.

The compression must be between 300–500 PSI (2069–3448 kPa) with no more than 50 PSI (345 kPa) difference between cylinders.

The engine has an open crankcase ventilation system.

The ventilation hose comes from the valve cover tube (Item 1) **[D]** and passes down the side of the engine block.



CYLINDER HEAD

Removal And Installation

The tools listed will be needed to do the following procedure:

MEL1267 – Cylinder Head Bolt Wrench

Clean all the debris from the cylinder head and engine.

Remove the coolant from the engine and radiator.
Remove the radiator hoses.

Remove the fuel injectors and fuel tubelines. (See Page 7–48.)

Remove the valve cover nuts in the correct sequence **[A]**.

Installation: Tighten the nuts to 6–13 ft.-lbs. (8–17 Nm) torque in the correct sequence **[A]**.

Remove the rocker arm assembly bolts in the correct sequence **[B]**.

Installation: Tighten the bolts in the correct sequence to 36–43 ft.-lbs. (49–58 Nm) torque.

Remove the cylinder head bolts in the correct sequence **[C]**.

Installation: Lubricate the bolts and tighten them in two steps as listed, in the correct numerical sequence **[D]**.





	Step 1	Step 2
New Bolts	29 ft.-lbs. (39 Nm)	59–67 ft.-lbs. (80–91 Nm)
Used Bolts	62 ft.-lbs. (83 Nm)	72–80 ft.-lbs. (97–108 Nm)

NOTE: When removing the head, do not use a sharp tool between the head and the engine block. Always put the cylinder head on a flat surface, such as wood, to prevent damage to the machined surface.

Remove the head from the engine.

See Page 7–53 for removing and reconditioning the valves.


After the cylinder head is installed, adjust the valve clearance. (See Page 7–41.)




PISTON AND CONNECTING ROD (Cont'd)

Assembly


Heat the piston to about 140°F (60°C) [A].




Assemble the piston and connecting rod [B].



Install the piston to the connecting rod. The piston head front mark (Item 1) [C] and the connecting rod "ISUZU" casting mark (Item 2) [C] must be facing the same direction.



Install the piston pin. Install the snap rings [D].




TIMING GEARCASE COVER

Removal And Installation


Remove the alternator and belt. (See Page 6-1.)

Remove the bolt at the crankshaft pulley [A].


Installation: Tighten the bolt to 123–152 ft.-lbs. (167–206 Nm) torque.




Use a puller to remove the crankshaft pulley [B].



Remove the bolts which fasten the noise dampening shield to the timing case cover [C].



Remove the noise dampening shield [D].




OIL PAN

Removal

Remove the oil drain plug and remove the oil.

Remove the fastening bolts and nuts from the oil pan [A].





Installation

Clean the surface on the oil pan and engine block.


Put Three Bond (TB-1207B) at the front and rear main bearing caps (Item 1) [B] & [C].

Put liquid gasket on the oil pan surface area of the engine block.



Install the oil pan. Install and tighten the bolts in the sequence shown [D].

Tighten the bolts and nuts to 13–18 ft.-lbs. (19–26 Nm) torque.



SYSTEM ANALYSIS

Page Number

BOSS® DIAGNOSTIC TOOL Procedure	8-3
BOSS® INSTRUMENT PANEL Removal And Installation	8-9
MONITOR SERVICE CODE Chart	8-5
BOSS® UNIT Removal And Installation	8-8
RPM SENSOR Adjustment	8-4
SENDER AND SENSOR Component	8-3
Service Checks	8-3
TROUBLESHOOTING THE BOSS® & LCD DISPLAY Chart	8-7

B.O.S.S. – Bobcat Operation Sensing System

L.C.D. – Liquid Crystal Diode

**SYSTEMS
ANALYSIS**

SPECIFICATIONS

	Page Number
DECIMAL & MILLIMETER EQUIVALENTS	
Chart	9-17
ENGINE SPECIFICATIONS	
Camshaft	9-6
Connecting Rod & Bearing	9-6
Crankshaft	9-7
Cylinder Head	9-5
Cylinder Liners	9-6
Fuel System	9-7
Idler Gear	9-7
Oil Pump	9-7
Pistons, Pins & Rings	9-6
Rocker Arm	9-5
Tappets	9-5
Valve Springs	9-5
Valve, Valve Guide & Seat Insert	9-5
HYDRAULIC CONNECTION SPECIFICATIONS	
Flare Fitting	9-12
O-ring Face Seal Connection	9-12
O-ring Flare Fitting	9-13
Port Seal Fitting	9-15
Straight Thread O-ring Fitting	9-12
Tubelines And Hoses	9-12
HYDRAULIC/HYDROSTATIC FLUID SPECIFICATIONS	
Specifications	9-16
LOADER SPECIFICATIONS	
Capacities	9-4
Controls	9-3
Drive System	9-4
Electrical	9-4
Engine	9-3
Hydraulic System	9-4
Loader Dimensions	9-3
Operation & Performance	9-3
Tires	9-4
TORQUE SPECIFICATIONS FOR BOLTS	
Torque For General SAE Bolts	9-10
Torque For General Metric Bolts	9-11
TORQUE SPECIFICATIONS FOR LOADER	
Specifications	9-9
U.S. TO METRIC CONVERSION	
Chart	9-17

SPECIFICATIONS

TORQUE SPECIFICATIONS FOR BOLTS (Cont'd)

Torque For General Metric Bolts

Thread Size (Dia. x Pitch)	Material		
	Head Mark 4	Head Mark 7	Head Mark 10
M 5 x 0.8		3–4 ft.-lbs. (4–5 Nm)	
M 6 x 1.0		6–7 ft.-lbs. (8–9 Nm)	6–9 ft.-lbs. (8–12 Nm)
M 8 x 1.25	6–9 ft.-lbs. (8–12 Nm)	11–16 ft.-lbs. (15–22 Nm)	18–25 ft.-lbs. (24–34 Nm)
M 10 x 1.25	13–18 ft.-lbs. (18–24 Nm)	22–30 ft.-lbs. (30–41 Nm)	36–50 ft.-lbs. (49–68 Nm)
M 12 x 1.25	22–30 ft.-lbs. (30–41 Nm)	40–54 ft.-lbs. (54–73 Nm)	69–87 ft.-lbs. (94–118 Nm)
M 14 x 1.25	36–50 ft.-lbs. (49–68 Nm)	58–80 ft.-lbs. (79–108 Nm)	116–137 ft.-lbs. (157–186 Nm)



SERVICE MANUAL REVISION

850-002
Revision Number
10 July 1991
Date

ROUTE TO ATTENTION	
PARTS MANAGER	<input type="checkbox"/>
SERVICE MANAGER	<input checked="" type="checkbox"/>
SALES MANAGER	<input type="checkbox"/>

AFFECTING:

Product BOBCAT LOADER

Model 853

Manual No. 6720755 (2-91)

Revise your Service Manual with the enclosed page(s) as shown below.

TAKE OUT

1-25, 1-26
1-29

HYDRAULIC/HYDROSTATIC FLOW CHART
For Model
853
Chart #6720800 (Printed February 1991)
CHART LEGEND

3-7, 3-8
3-9, 3-10

4-9, 4-10

5-7, 5-8

8-7, 8-8

PUT IN

1-25 (Revised July 91), 1-26 (Revised July 91)
1-29 (Revised July 91)

HYDRAULIC/HYDROSTATIC FLOW CHART
For Model
853
Chart #6720800 (Printed July 1991)
CHART LEGEND & FLUID FLOW EXPLANATION

3-7, 3-8 (Revised July 91)
3-9 (Revised July 91), 3-10

4-9 (Revised July 91), 4-10 (Revised July 91)

5-7 (Revised July 91), 5-8

8-7 (Revised July 91), 8-8



SERVICE MANUAL REVISION

850-007
Revision Number
30 December 1992
Date

ROUTE TO ATTENTION	
PARTS MANAGER	<input type="checkbox"/>
SERVICE MANAGER	<input checked="" type="checkbox"/>
SALES MANAGER	<input type="checkbox"/>

AFFECTING:

Product BOBCAT LOADER

Model 853

Manual No. 6720755 (2-91)

Revise your Service Manual with the enclosed pages as shown below.

TAKE OUT

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 & Above) & 853H
(Printed January 1992) 1 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 & Above) & 853H
(Printed January 1992) 2 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 & Above) & 853H
(Printed January 1992) 3 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 & Above) & 853H
(Printed January 1992) 4 Of 4 Pages

PUT IN

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 Thru 12360) & 853H (S/N 11308 & Below)
(Printed December 1992) 1 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 Thru 12360) & 853H (S/N 11308 & Below)
(Printed December 1992) 2 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853 (S/N 11354 Thru 12360) & 853H (S/N 11308 & Below)
(Printed December 1992) 3 Of 4 Pages

WIRING DIAGRAM (P/N 6720958)
Model 853H (S/N 11308 & Below)
(Printed December 1992) 4 Of 4 Pages

WIRING DIAGRAM (P/N 6722313)
Model 853 Base (S/N 25001 & Above)
(Printed December 1992) 1 Of 3 Pages

WIRING DIAGRAM (P/N 6722313)
Model 853 Base (S/N 25001 & Above)
(Printed December 1992) 2 Of 3 Pages

WIRING DIAGRAM (P/N 6722313)
Model 853 Base (S/N 25001 & Above)
(Printed December 1992) 3 Of 3 Pages

WIRING DIAGRAM (P/N 6722312)
Model 853 (S/N 12361 & Above) & 853H (S/N 11309 & Above)
Model 853 Plus (S/N 50001 & Above) & 853H Plus (S/N 75001 & Above)
(Printed December 1992) 1 Of 4 Pages

WIRING DIAGRAM (P/N 6722312)
Model 853 (S/N 12461 & Above) & 853H (S/N 11335 & Above)
Model 853 Plus (S/N 50001 & Above) & 853H Plus (S/N 75001 & Above)
(Printed December 1992) 2 Of 4 Pages

WIRING DIAGRAM (P/N 6722312)
Model 853 (S/N 12361 & Above) & 853H (S/N 11309 & Above)
Model 853 Plus (S/N 50001 & Above) & 853H Plus (S/N 75001 & Above)
(Printed December 1992) 3 Of 4 Pages

WIRING DIAGRAM (P/N 6722312)
Model 853H (S/N 11309 & Above) & 853H Plus (S/N 75001 & Above)
(Printed December 1992) 4 Of 4 Pages

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL