

# 688C Excavator

## Table of Contents

DIVISION/SECTION	SECTION NO.	FORM-NO
<b>1 GENERAL</b>		
Sectional Index		7-32410
Safety, General Information and Torque Specifications.....	1001 *	8-86530
Specifications.....	1002	7-32351
<b>2 ENGINE</b>		
Sectional Index		7-32420
Engine Removal and Installation.....	2000	8-89000
Radiator and Oil Cooler.....	2001	8-89010
Specifications Details.....	2402	8-24163
Cylinder Head and Valve Train.....	2415	8-24173
Cylinder Block.....	2425	8-24183
Lubrication System.....	2445	8-24193
Cooling System.....	2455	8-24203
Turbocharger.....	2465	8-25550
Turbocharger Failure Analysis.....	2565	9-78235
<b>3 FUEL SYSTEM</b>		
Sectional Index		7-32430
Fuel System and Filters.....	3410	8-24212
Fuel Injection Pump and Drive Gear.....	3412	8-27080
Fuel Injectors.....	3413	8-24233
<b>4 ELECTRICAL</b>		
Sectional Index		7-32440
Electrical Schematics and Troubleshooting.....	4001 *	8-89021
Battery Testing, Maintenance and Booster Battery Connections.....	4002	7-32080
Starter Motor.....	4003	8-89040
Alternator.....	4004	8-89050
<b>5 TRACK</b>		
Sectional Index		7-32470
Tracks, Rollers and Idlers.....	5002	7-32130
Track Troubleshooting.....	5502	7-33730
<b>6 POWER TRAIN</b>		
Sectional Index		7-32450
Drive Motor and Final Drive Transmission.....	6002	7-32290
Swing Motor and Reduction Gears.....	6003	7-32230

\* Schematic Set Sections

THIS TABLE OF CONTENTS REPLACES LEP 8-88992

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Hydraulic System

### Low Pressure Pump

Comprises one body with a fixed flow for the servo-steering hydraulic circuits,

Maximum flow at 2000 rpm: .....	24 l/min	6.3 US gpm
Operating pressure .....	28 Bar	406 psi

### Flow Setting Times

Boom Up .....	3.3 to 3.5 seconds
Dipper In .....	4.7 to 4.9 seconds
Bucket In .....	3.3 to 3.5 seconds

### Flow Setting Valve Rates (cylinder large chamber):

Boom raising .....	148 to 155 l/min	36.7 to 38.4 US gpm
Boom lowering .....	28 to 45 l/min	6.9 to 11.1 US gpm
Bucket opening .....	75 to 100 l/min	18.6 to 24.8 US gpm
Bucket closing .....	95 to 105 l/min	23.5 to 26 US gpm
Dipper extension .....	110 to 125 l/min	27.2 to 31 US gpm
Dipper retraction .....	122 to 130 l/min	30.2 to 32.2 US gpm
Right-hand travel in forward drive .....	88 to 95 l/min	23.2 to 25 US gpm
Left-hand travel in forward drive .....	88 to 95 l/min	23.2 to 25 US gpm
Right and left-hand travel in forward drive .....	176 to 190 l/min	46.5 to 50.1 US gpm
Offset backhoe .....	25 to 35 l/min	6.6 to 9.2 US gpm

Hydraulic Oil Test Temperature .....	50°C	120°F
--------------------------------------	------	-------

### Pressure Settings

Attachment Flow Cut-off Valve (LS1) .....	360 to 370 Bar	5221 to 5366 psi
Attachment Valve Bank Main Relief Valve .....	435 to 445 Bar	6309 to 6454 psi
Regulator		
Torque Regulator Valve,		
97 l/min (25.6 US gpm) engine speed 2020 rpm at a pressure of ..	275 Bar	3988 psi
Load Sensing Valve (LS) .....	18 to 20 bar	261 to 290 psi
Travel Flow Cut-off Valve (LS2) .....	405 to 415 Bar	5874 to 6019 psi

### Circuit Relief Valves:

Boom : raising .....	380 to 405 Bar	5511 to 5874 psi
Boom : lowering .....	400 to 435 Bar	5801 to 6309 psi
Bucket : opening, closing .....	380 to 405 Bar	5511 to 5874 psi
Dipper : extension, retracting .....	380 to 405 Bar	5511 to 5874 psi
Swing : right, left .....	320 to 330 Bar	4641 to 4786 psi
Travel : forward drive, reverse drive .....	420 to 435 Bar	6091 to 6309 psi
Boom and Dipper Anti-Drift Valve .....	390 to 410 Bar	5656 to 5946 psi
Boom and Dipper Safety Valve .....	390 to 410 Bar	5656 to 5946 psi
Low Flow (Clamshell Swing) .....	130 to 150 Bar	1885 to 2175 psi
Offset boom .....	180 to 200 Bar	2610 to 2900 psi

## Intake Valves

Tappet Clearance (Cold) .....	0.254 mm
Face Angle .....	29 Degrees
Face Run-Out .....	0.038 mm
Valve Head Edge Thickness, Minimum .....	1.50 mm
Length .....	128.84 to 129.46 mm
OD of Stem .....	7.960 to 7.980 mm
Minimum Service Limit .....	7.940 mm
OD of Head .....	44.870 to 45.130 mm
Seat Angle .....	30 Degrees
Seat Contact Width .....	1.32 to 1.92 mm
Seat Run-Out .....	0.10 mm
Insert Height .....	6.84 to 6.96 mm
OD of Insert .....	47.063 to 47.089 mm
ID of Insert .....	Tapered
Valve Recession Below Head Surface .....	0.99 to 1.52 mm
Maximum Service Limit .....	1.52 mm
ID of Valve Guide Bore .....	8.019 to 8.039 mm
Maximum Service Limit .....	8.089 mm


## Exhaust Valves

Tappet Clearance (Cold) .....	0.508 mm
Face Angle .....	44 Degrees
Face Run-Out .....	0.038 mm
Valve Head Edge Thickness, Minimum .....	1.50 mm
OD of Head .....	41.870 to 42.130 mm
OD of Stem .....	7.960 to 7.980 mm
Minimum Service Limit .....	7.940 mm
Length .....	128.74 to 129.36 mm
Insert Seat Angle .....	45 Degrees
Seat Contact Width .....	1.47 to 2.07 mm
Seat Run-Out .....	0.10 mm
Insert Height .....	6.65 to 6.77 mm
OD of Insert .....	43.713 to 43.739 mm
ID of Insert .....	Tapered
Valve Recession Below Head Surface .....	0.99 to 1.52 mm
Maximum Service Limit .....	1.52 mm
ID of Valve Guide Bore .....	8.019 to 8.039 mm
Maximum Service Limit .....	8.089 mm

## Valve Springs


Free Length .....	55.63 mm
Total Coils .....	7.25
Wire Diameter .....	4.830 to 4.930 mm
Compressed to 38.53 mm .....	(Valve Open) 785 to 839 N
Maximum Service Limit .....	765 N
Compressed to 49.25 mm .....	(Valve Closed) 285 to 321 N
Minimum Service Limit .....	270 N

### STEP 12




Remove the retaining bolt and spacer and remove the engine ground strap.

### STEP 13




Disconnect the wires from the oil filter.

### STEP 14




Disconnect the wires from the alternator.

### STEP 15




Disconnect the wires from the starter motor.

### STEP 16




Loosen the nuts on the exhaust muffler clamp.


### STEP 17



Remove the mounting bolts and spacers. Remove the exhaust muffler and bracket.

**STEP 68**


Install the heater hose and tighten the clamp.

**STEP 69**

Install the wiring harness carrier and install and tighten the mounting bolts and spacers.

**STEP 70**

Fill the radiator with specified engine coolant. Install and tighten the radiator cap. Fill the coolant recovery reservoir with specified engine coolant up to the upper mark. Install and tighten the cap. Fill the engine with specified engine oil up to the FULL mark on the engine oil dipstick.

**STEP 71**

Install the key and turn the master disconnect switch to the ON position.


Don 8-89000

**STEP 72**

Remove air from the fuel system. Refer to Section 3410.




**WARNING:** *Never operate the engine in a closed building. Proper ventilation is required under all circumstances.*

**STEP 73**

Push down the heater control in the cab to allow circulation of engine coolant and to allow trapped air to collect at the air bleed screw. Start and run the engine for five minutes. Stop the engine.





**WARNING:** *Hot engine coolant will spray out of air bleed screw. To avoid injury, care must be taken when removing air from the cooling system.*

**STEP 74**


Open the air bleed screw. When there is a flow of engine coolant without air bubbles, tighten the air bleed screw.

**STEP 24**


Connect the oil cooler feed hose and block to the oil cooler and install the clip.

**STEP 25**


Connect the bottom and top radiator hoses and tighten the clamps.

**STEP 26**

Connect the lower oil cooler hose and tighten the clamp.

**STEP 27**

Fill the radiator with the specified engine coolant. Install the radiator cap. Fill the coolant recovery bottle to the upper mark.

**STEP 28**

Install the battery securing bolts and nuts. Install the batteries and install and tighten the battery securing clamps.

Connecting the negative (-) cable last, connect the battery cables.

Install the battery cover.

## Connecting Rod

Bushing .....	Steel Backed Leaded Bronze
Bushing ID Installed (Ream to Size).....	40.053 to 40.067 mm
Maximum Service Limit .....	40.092 mm
Bearing Liners .....	Replaceable
Journal ID Without Bearing Liners .....	72.987 to 73.013 mm
Bearing Oil Clearance .....	0.038 to 0.116 mm
Maximum Service Limit .....	0.129 mm
Side Clearance.....	0.100 to 0.300 mm
Maximum Service Limit .....	0.330 mm
Connecting Rod Bend (Maximum)	
Without Bushing .....	0.200 mm
With Bushing .....	0.150 mm
Connecting Rod Twist (Maximum)	
Without Bushing .....	0.500 mm
With Bushing .....	0.300 mm
Connecting Rod Bolt Maximum.....	59.25

## SPECIFICATIONS

Number of Batteries Required .....	2
Voltage of Each Battery .....	12 volts
Reserve Capacity .....	160 minutes
Cold Cranking Capacity at -17°C (0°F) .....	800 amps
Load for Capacity (Load) Test.....	400 amps

## MAINTENANCE

### Electrolyte Level

If the battery is a maintenance free battery, check the level of the electrolyte every 1000 hours of operation or six months, whichever occurs first. For all other batteries, check the level of the electrolyte every 250 hours of operation.

**NOTE:** *A maintenance free battery will have words Maintenance Free on the decal on the top of the battery. If the center part of the decal has been removed for access to the battery caps, it is possible that the words Maintenance Free have been removed from the decal.*

Check the level of the electrolyte more often during hot weather. The use of a large amount of water by the battery can be caused by high battery temperature or a voltage regulator setting that is too high. Keep the electrolyte level above the top of the plates in the battery at all times to prevent damage to the battery.

**NOTE:** *On maintenance free batteries it is necessary to remove the center part of the decal for access to the battery caps. Do not discard the center part of the decal. Install the center part of decal after the battery caps have been installed.*

If the level of the electrolyte is low, add distilled water or other clean water until the electrolyte is just below the cell opening. Do not add more water than is needed. Too much water can cause bad performance, a short service life, and corrosion around the battery.

**NOTE:** *Add water only. DO NOT add electrolyte.*


### Inspecting and Cleaning a Battery

If damage causes an electrolyte leak, replace the battery.


Inspect the battery at regular intervals for dirt, corrosion, and damage. Electrolyte and dirt on the top of the battery can cause the battery to discharge by making a passage for the current to flow.

If the battery must be cleaned, remove the battery from the battery carrier and clean the battery, cable terminals, and the battery carrier. When available, use Case Battery Saver and cleaner according to the instructions on the container. Case Battery Saver and Cleaner also helps prevent corrosion. If Case Battery Saver and Cleaner is not available, use baking soda and water as a cleaner. **DO NOT** permit any type of cleaner to enter the cells of the battery.

Install the battery in the machine and make sure the fasteners are tight. Apply Case Battery Saver and Cleaner or Urethane Seal Coat to the cable terminals to prevent corrosion. See the Parts Counter Catalog. **DO NOT** apply grease.

**STEP 7**

Open the cover for the main circuit board, located at the rear of the cab.

**STEP 8**

Check the condition of fuse F1 and fuse F2. Check for loose or corroded connections at relay K1 and relay K2.

**STEP 9**

Check for damaged insulation or broken wires in the starting system circuit. Repair or replace any damaged or broken wires. Refer to the electrical schematic in Section 4001.

**STEP 10**

If the starter motor still does not operate correctly, do the Starter and Starter Solenoid Test on page 6.

## Inspection

Use a clean, dry cloth to clean the drive clutch, the armature, the field frame, and the starter solenoid. Use cleaning solvent to clean the remainder of the parts.


### Brushes

#### STEP 51

Measure the length of the brushes connected to the brush holder. If the length of any brush is less than 8.5 mm (5/16 inch), both of the brushes must be replaced. Measure the length of the brushes connected to the field coil. If the length of any brush is less than 8.5 mm (5/16 inch), both of the brushes must be replaced.

### Brush Holder


#### STEP 52



Connect one probe of the multimeter to the brush holder frame and the other probe to each insulated brush holder in turn. There must be no continuity. Replace the assembly if there is continuity.

### Armature


#### STEP 53 (Winding Ground Test)



Place one probe of the multimeter to a commutator segment and the other probe to the armature core. There must be no continuity. If there is continuity, the armature has a ground and must be replaced.


Don 8-89040

#### STEP 54 (Continuity Test)




Place the probes of the multimeter to two segments of the commutator. If there is no continuity, the winding has an open circuit and the armature must be replaced.

#### STEP 55



Put the armature on vee-blocks as shown and check the run out of the armature with a dial indicator. The runout must not be more than 0.03 mm (0.001 inch). If necessary, put the armature in a lathe and remove enough material to make the run out less than 0.03 mm (0.001 inch).

#### STEP 56




Place the armature on vee-blocks and check for distortion. If the armature is distorted it must be replaced.

## SPECIAL TORQUES

Alternator Mounting Bolts.....	24 Nm	18 lb ft
Pulley Retaining Nut.....	68 Nm	50 lb ft


## SPECIAL TOOLS




1. Multimeter  
CASE Part Number CAS-1559



2. Sun Electric VAT-33 Tester



3. 1000 Watt Soldering Iron




4. Torque Wrench (Nm or lb ft)

## Inspection


**NOTE:** Use a multimeter set to read ohms for the inspection.

### STEP 21




Check the stator resistance. The resistance in each coil must be 0.22 ohms. If the resistance in a coil is not 0.22 ohms, refer to STEP 25 and install a new stator.

### STEP 22



Check the stator for a short circuit. Make sure the rectifier bridge does not touch the stator. Connect one lead of the multimeter to the housing of the stator. Connect the other lead of the multimeter to each of the three leads from the stator. If the pointer of the multimeter moved, there is a short circuit in the stator. Refer to STEP 25 and install a new stator.

### STEP 23



Check the positive diodes in the rectifier bridge.

- a. Connect the negative lead of the multimeter to the output (B+) terminal. Connect the positive lead of the multimeter to one of the leads for the positive diodes. The positive diodes are the three diodes that are closest to the output (B+) terminal. Read the multimeter.
- b. Reverse the multimeter leads. Read the multimeter.
- c. There must be a high reading and a low reading. If the readings are the same, replace the rectifier bridge.
- d. Repeat this step for the other two positive diodes.

# Section 5002


TRACKS, ROLLERS AND IDLERS

For 688 Crawler Excavators

5002

# SPRING

## Disassembly and Assembly




5002A


# Section 5502

TRACK TROUBLESHOOTING

5502


**STEP 7**

Remove the drive motor mounting screws.


**STEP 8**

Remove the plastic plugs from the threaded holes in the drive motor. Install two M12(1.75) x 50 mm bolts into the threaded holes to remove the drive motor. Remove the two M12(1.75) x 50 mm bolts.


## Disassembly

**STEP 9**


Remove and discard the o-ring from the drive motor.

**STEP 11**

Remove the rear housing and seal housing.

**STEP 10**

Install the motor in a vise fitted with soft jaw plates. Put marks on the front, rear and seal housings. Remove the screws from the drive motor.

**STEP 12**

Mark each piston and piston socket to indicate the location of each piston. Remove each piston.


## BRAKE

### Disassembly

#### STEP 1


Remove the drive motor. Refer to Drive Motor Removal, Page 4, STEPS 1 to 8.

#### STEP 2




Remove and discard the o-rings from the brake housing.

#### STEP 3




Install the brake spring compressor (refer to Tools to be made Locally, Page 3), use a sleeve between the brake spring compressor and the brake cover, tighten until the snap ring can be removed. Remove the brake spring compressor and sleeve.

#### STEP 4




Remove the snap ring.

#### STEP 5




Remove the brake cap.

#### STEP 6




Remove the springs from the brake piston.

**STEP 30**




Remove the snap ring.

**STEP 31**




Remove the washer.

**STEP 32**




Remove the pinion gear.

**STEP 33**




Remove the bearings.

**STEP 34**




Remove the snap ring.


**STEP 35**




Remove the thrust washer from the second stage carrier.

**STEP 82**


Install the first stage carrier.

**STEP 83**


Install the pinion shaft.

**STEP 84**


Install a new o-ring onto the planetary cover.

**STEP 85**

Install the planetary cover. Apply a coat of Loctite 242 to the retaining screws and tighten to a torque of 85 Nm (65 lb ft).


**STEP 86**

Install a new seal assembly into the hub.


**STEP 87**

Install a new o-ring onto the brake housing and lubricate with petroleum jelly.


### SPECIAL TOOLS



1. TORQUE WRENCH



2. BEARING OVEN  
CAS-10133




3. LOCTITE 573  
CASE PART NO K965910



4. LOCTITE 242  
CASE PART NO B17422


### Tool To Be Made Locally

1. BRAKE SPRING COMPRESSOR




1/2 X 6 INCH U.N.F. BOLT

# Swing Motor Cross Sectional Drawing




EA2977

**STEP 33**




Put the bearing and inner bearing race in a bearing oven CAS-10133 (Refer to Page 3 Special Tools) and heat to a temperature of 80°C (176°F)

**STEP 34**



Install new seals. Wear heat protective gloves and put the bearing and inner bearing race onto the swing gear shaft and install the collar.


**STEP 35**



Install a new swing gear housing bearing.


Don 7-32230

**STEP 36**





Install the swing gear.

**STEP 37**



Install the shims.

**STEP 38**



Install a new lip seal and o-ring.


EA2967A

## Removal



**WARNING:** When the machine is operating, the engine systems and the hydraulic pump systems heat up to a high temperature. To avoid the possibility of being burnt by hot metal or scalded by hot oil, allow the machine to cool before starting any maintenance work.


### STEP 1



EA2836

Put the machine on level ground. Lower the attachment to the ground. Stop the engine and allow the systems to cool.


### STEP 2



C08203

Operate the emergency foot pump while operating the hand control levers in all directions to release the pressure in all the hydraulic circuits.


### STEP 3



C119385

Turn the master disconnect switch, located under the right hand side of the walkway, to the OFF position and remove the key.


### STEP 4



C11231C

Remove the breather to release the pressure in the hydraulic oil tank. Install and tighten the breather.

## IDENTIFICATION OF MAJOR COMPONENTS



## SPECIFICATIONS


The high pressure pump comprises two bodies: one body with a variable flow for the attachment and travel hydraulic circuits and one body with a fixed flow for the upperstructure swing hydraulic circuit.

Boom Circuit Flow .....	150 l/min	40 US gpm
Dipper Circuit Flow .....	125 l/min	33 US gpm
Bucket Circuit Flow .....	100 l/min	27 US gpm
Travel Circuit Flow .....	184 l/min	49 US gpm
Upperstructure Swing Flow .....	44 l/min	11 US gpm
Hydraulic Oil Tank Capacity .....	100 litres	26.4 US gallons
Hydraulic Oil Type.....	MS1230 Hydraulic Fluid	

## SPECIAL TORQUES

Hydraulic Oil Tank Drain Plugs .....	30 Nm	22 lb ft
Low Pressure Pump to High Pressure Pump Mounting Bolts .....	50 Nm	37 lb ft
High Pressure Pump to Engine Mounting Bolts .....	44 Nm	32.5 lb ft

## SPECIAL TOOLS




1. TORQUE WRENCH (Nm, lb ft)  
(CAS 10037)




2. LOCTITE 241  
(3049702R91)

**STEP 51**




Remove and discard the shaft seal from the seal retainer.

**STEP 52**




Use a hydraulic press to remove the shaft assembly from the pump housing.


**STEP 73**

Install the fixed flow pump body.

**NOTE:** Make sure the dowel pin in the pump body is aligned with the hole in the swash plate.

**STEP 74**


Install and tighten the fixed flow pump body retaining screws.

**STEP 75**



Install a new o-ring. Install the low pressure pump. Install and tighten the mounting bolts and washers to a torque of 50 Nm (37 lb ft).

**STEP 76**

Clean the surfaces of the rear housing and the regulator. Install a new gasket onto the regulator.


**STEP 77**

Install the regulator onto the rear housing.

**STEP 78**

Install and tighten the regulator mounting bolts.


**STEP 13**



Remove the remaining regulator mounting bolts.

C18412

**STEP 14**




Remove the regulator. Remove and discard the gasket.

C18414

**Disassembly**


**STEP 15**



Remove the swash plate.

C18535


**STEP 17**



Remove the regulator cover. Remove and discard the o-rings.

C18603


**STEP 16**



Remove the regulator cover retaining screws.

C18601

**STEP 18**



Remove the regulator cover retaining screws.

C18609

**NOTE :** Care must be taken when removing the regulator cover retaining screws. The regulator cover is under spring pressure from the regulator and adjustable flow valve springs.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**STEP 56**


C18615

Install the adjustable flow valve spring.

**STEP 57**


C18613

Install the regulator spring.

**STEP 58**

C18611

Install new o-rings. Install the regulator cover onto the springs. Compress the springs and install and tighten the regulator cover retaining screws.

**STEP 59**

C18535


Install the swash plate onto the swash control pivot pin.

## Disassembly

### STEP 15

Clean the outside of the attachment valve bank to prevent contamination of the valve bores when the valves have been removed.


### STEP 16



T122A012

Remove the two anti-cavitation valve retaining screws from the attachment valve.

### STEP 17




T122A014

Remove the anti-cavitation valve. Refer to Steps 94 to 106 for disassembly and assembly of the anti-cavitation valve.

**NOTE:** Mark the location of all components to be removed from the attachment valve bank to ensure that they are assembled in the correct position.


### STEP 18



T125010

Loosen the circuit relief valve.

### STEP 19



T125008

Remove the circuit relief valve. Remove and discard the O-ring.

**NOTE:** Refer to Steps 114 to 120 for disassembly and assembly of the circuit relief valve.


### STEP 20



T124013


Loosen the two Allen screws securing the lower end cap.

**STEP 64**




Install the valve spool assembly.

**STEP 65**




Install a new O-ring in the upper end cap.

**STEP 66**



Install the upper end cap.

**STEP 67**



Install and tighten the end cap retaining screws to a torque of 9 to 11 Nm (72 to 96 lb in).

**STEP 68**



Install a new back-up ring and O-ring on the circuit relief valve. Install the circuit relief valve.


**STEP 69**



Tighten the circuit relief valve to a torque of 75 to 95 Nm (55 to 70 lb ft).


## Assembly

### STEP 109




Clean and inspect the component parts of the main relief valve for wear or damage. If any of the parts are worn or damaged, replace the main relief valve.

### STEP 110




Install a new back-up ring and O-ring on the valve body.

### STEP 111




Install a new back-up ring and O-ring on the adjusting plug.

### STEP 112




Assemble the parts of the main relief valve.

### STEP 113




Install the valve body in a soft jawed vise. Install the adjusting plug into the valve body the same amount of turns noted on removal.

**STEP 11**


D01630

Make an alignment mark for correct assembly and remove the brake release valve from the inlet/outlet section.

**STEP 12**


D01632

Remove and discard the o-rings.

**STEP 13**


D01634

Make a note of its position and remove the restrictor.

**STEP 14**


D01401

Remove the locknuts from the valve retaining studs.

**STEP 15**

D01402

Remove the nuts that fasten the mounting plate to the valve retaining studs.


**STEP 16**

D01405

Remove the drive valve mounting plate.

**NOTE:** Lubricate all parts and o-rings with clean hydraulic oil.


**STEP 58**



D01832

Install a new o-ring.


**STEP 59**



D01830

Install the valve.


**STEP 60**



D01828

Install and tighten the connector to the brake release valve.


**STEP 61**



D01824

Install a new o-ring.


**STEP 62**



D01822


Install the spool in the same position noted during disassembly.


**STEP 63**



D01820


Install the spring seat onto the end of the spool.



**STEP 24**


B21810

Remove the studs from the inlet body.

**STEP 25**


B21812

Remove and discard the o-rings.

**STEP 26**


B21814

Remove the flow regulator valve assembly.

**STEP 27**


B21820

Remove the plug from the bottom of the inlet body. Using a 3mm Allen key, remove the orifice screw from the inlet body.

**STEP 28**

B21934

Remove the fittings.

**STEP 29**

B22002A

Remove the plug.


# Section 8007

COUNTER ROTATION VALVE

For 688 Crawler Excavators


8007

**STEP 33**




Install the shuttle valve balls between ports 1 and 5 and ports 3 and 7. Apply Loctite 270 to the threads of the screws and install and tighten the screws.

**STEP 34**




Install two new o-rings onto the manifold.

**STEP 35**




Install the manifold to the control spool housing as marked on disassembly and install and tighten the screws.

**STEP 36**




Install the ball.

**STEP 37**



Install and tighten the capscrew.


**STEP 38**




Install the shuttle valve.

# Disassembly and Assembly

## STEP 8




**STEP 29**



E025014

Remove the pressure limiter valve from the valve body.

**STEP 30**



E025021

Remove and discard the O-rings and back-up rings from the pressure limiter valve.


**STEP 31**



E025026

Remove the plug. Remove and discard the O-ring.


**STEP 32**



E025032

Remove the hydraulic connectors from the valve block and spool caps. Remove and discard the O-rings.


**STEP 33**



E025034

Remove the load check valve plug. Remove the spring and valve. Remove and discard the O-ring.

**STEP 34**




E029005

Remove the two Allen screws securing the relief valve to the valve block.

**STEP 86**

Refer to Section 8001 to test the pressure setting of the swing relief valves, adjust the pressure if required.


**STEP 87**

T138011




T138017

Position the valve cover, install and tighten the five retaining screws and spacers.

**STEP 88**

E028020




E028016

Position the right hand side cover plate, install and tighten the four retaining screws and spacers.

**STEP 89**

Install the access panel under the hydraulic oil tank.

# Tube and Hose Installation



# Section 8012

DRIVE SPEED LIMITER

For 688 Crawler Excavators

8012

# Section 8013

DRIVE BRAKE RELEASE VALVE


For 688 Crawler Excavators

8013



**WARNING:** *Never operate the engine in a closed building. Proper ventilation is required under all circumstances.*

## STEP 28



Start and run the engine at LOW IDLE. Fully extend all the attachment cylinders. Stop the engine. Check the level of oil in the hydraulic oil tank. The level of oil must reach level 2 on the indicator on the front of the hydraulic oil tank. If oil is required, remove the plug from the top of the filter housing. Screw in the funnel and add specified hydraulic oil as required. Remove the funnel and install and tighten the plug.

## STEP 29


Start and run the engine. Drive the machine forwards and then rearwards. Stop the engine.

## STEP 30


Check for and repair any hydraulic oil leaks at the drive brake release valve.

## STEP 31


Install the valve cover and install and tighten the retaining bolts and spacers. Install the access panel under the hydraulic oil tank.

**STEP 28**

Install new o-rings onto the control cartridge guides. Install the control cartridges into the control cartridge guides.

**STEP 29**


Install the control cartridge assemblies.

**STEP 30**

Install the spacer. Install the cover plate. For the left hand control lever only, make sure that the hole in the cover plate for the horn wire is in line with the slot in the valve body.

**STEP 31**

Apply Loctite 242 to the lower threads of the universal joint. Install and tighten the universal joint to a torque of 30 Nm (22 lb ft). Remove the two nuts used to remove and to install the universal joint.

**STEP 32**


Install the control cam onto the universal joint and turn until the control cam comes into contact with the control cartridges.

**STEP 33**

While holding the control cam in position, install and tighten the control lever to a torque of 25 Nm (18 lb ft). For the left hand control lever only, push the horn wire through the hole in the cover plate and install the connector. Put the protective boot into the correct position over the cover plate.


**NOTE:** Lubricate all the parts and o-rings with clean hydraulic oil.

### STEP 16




Install new o-rings onto the valve body. Make sure that the dowels are in place. Install the valve body onto the port block.

### STEP 17




Install a new o-ring onto the retaining screw. Install and tighten the retaining screw to a torque of 60 Nm (44 lb ft).

### STEP 18




Install the large spring into the correct hole.

### STEP 19




Install the spool assembly into the correct hole.

### STEP 20



Install new o-rings onto the control cartridge guide. Install the control cartridge into the control cartridge guide.

### STEP 21




Install the control cartridge assembly and tighten to a torque of 11 Nm (8 lb ft).

### STEP 22

Repeat STEPS 18 to 21 for the other spool and control cartridge assembly.



## Installation

### STEP 17




Install suitable lifting equipment and install the hydraulic oil tank.

### STEP 18




Install and tighten the mounting bolts, spacers and nuts.

### STEP 19




Remove the cap. Connect and tighten the low pressure pump suction hose.

### STEP 20




Install and tighten the suction hose between the hydraulic oil tank and the hydraulic pump.

# Assembly




80187

**STEP 7**




Disconnect and cap the hoses from the bucket cylinder.

**STEP 8**



Remove the retaining and pivot pins from the bucket cylinder. Lower the cylinder to the ground and remove the lifting equipment.

## Flow Setting Valve Disassembly



734230E

**NOTE:** Servicing is limited to replacing the flow setting valve cartridge, joints and seals.

### STEP 24

Remove cartridge 17.

### STEP 25

Take out cartridge from its location, fitted with flow setting valve shock-absorber 18 and spring 19.

### STEP 26

Remove and discard the o-ring 20 and joint 21.

### STEP 27

Take out the spool 22 to make a visual check.

### STEP 28

Remove plug 23.

### STEP 29

Remove and discard the o-ring 24 and joint 25.

# Section 9001

## UPPERSTRUCTURE AND TURNTABLE BEARING


For 688 Crawler Excavators

9001

# TURNTABLE BEARING

## Removal

### STEP 27




Remove the hydraulic swivel, Refer to Section 8200. Install suitable lifting equipment onto the turntable bearing. Remove the turntable bearing lower retaining bolts and spacers and remove the turntable bearing.

**NOTE:** *The turntable bearing weighs 135 kg (300 lb).*

## Removal


### STEP 1



EA2833

Park the machine on level ground in the position shown and stop the engine.


### STEP 2



C06203

Operate the emergency foot pump while operating the boom and dipper control levers to release pressure in the hydraulic system.


### STEP 3



130

Remove the lower side engine access panel under the hydraulic oil tank. Remove the pin and pull the knob down to close the hydraulic oil tank shut-off valve.


### STEP 4



C00214

Fasten identification tags to the hoses. Disconnect and cap the boom cylinder hoses from the manifold.


### STEP 5



E067016

Fasten identification tags to the hoses and tubes. Disconnect and cap the bucket and dipper hoses from the tubes.


### STEP 6





Disconnect the working lamp cable.

# TOOLS TO BE MADE

**IMPORTANT:** *The welding of this assembly must be carried out by an able welder.*




EA 3062




EA 3065

4. CAB LIFTING BRACKET

**STEP 19**




C06228



C06230

Remove the retaining clip and the pivot arm.


**STEP 20**



C06218

Remove the wiper motor drive lever.


**STEP 21**



C06223

Remove the wiper motor mounting plate screws.


**STEP 22**



C06225

Remove the mounting plate.

**STEP 23**



C06234

Remove the retaining clip, thrust washers and the idler shaft.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL