

821 Loader  
Service Manual

Table of Contents

Description	Section No.	Form No.
<b>General</b>		
<b>Tab 1</b>		
Section Index - General		8-13190
Loctite Product Chart		8-98900
Standard Torque Specifications	1001	8-71600
Fluids and Lubricants	1002	8-13201
<b>Engine</b>		
<b>Tab 2</b>		
Section Index - Engine		8-13210
Engine Removal and Installation and Radiator Removal and Installation	2001	8-13220
Stall Tests	2002	8-13230
Specifications Details	2403	8-28423
Cylinder Head and Valve Train	2415	8-28432
Cylinder Block, Pistons, Rods, Camshaft, Main Bearings, Oil Seals, and Flywheel	2425	8-28442
Lubrication System	2445	8-28452
Cooling System	2455	8-28462
Turbocharger	2465	8-28470
Turbocharger Failure Analysis	2565	9-78235
<b>Fuel System</b>		
<b>Tab 3</b>		
Section Index - Fuel System		8-13240
Fuel System and Filters	3410	8-28480
Fuel Injection Pump and Drive Gear	3412	8-28492
Fuel Injectors	3413	8-28501
<b>Electrical System</b>		
<b>Tab 4</b>		
Section Index - Electrical		8-13250
Specifications, Schematics, Troubleshooting, and Using Booster Batteries to Start the Engine	4001	8-11942
Starter and Starter Solenoid - Delco-Remy	4002	8-11951
Starter and Starter Solenoid - Nippondenso	4002	8-17920
45 Ampere Alternator	4003	8-73840
Batteries	4004	8-71701
Instrument Cluster	4005	8-73851
65 Ampere Alternator	4006	8-73860
<b>Steering</b>		
<b>Tab 5</b>		
Section Index - Steering		8-13261
Removal and Installation of Steering Components	5001	8-13271
Steering Troubleshooting and Pressure Check	5002	8-13282
Steering Control Valve	5003	8-73901
Flow Control Valve	5004	8-13290
Steering Cylinder	5005	8-13302
Center Pivot	5006	8-13311
Auxiliary Steering Pump and Valve - Early Production	5007	8-11991
Auxiliary Steering Motor and Pump - Late Production	5008	7-43960

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# ENGINE OIL RECOMMENDATIONS


Use Case IH Engine Oil of the correct viscosity. See the chart for the temperatures and the recommended viscosity.

## AMBIENT AIR TEMPERATURE RANGES




B850639AJ

**STEP 55**




Have another person help you with this step. Remove both batteries.

**STEP 58**




Remove the additional counterweight.

**STEP 56**




If your machine is equipped with additional counterweights, connect suitable lifting equipment to one of the additional counterweights. The weight of an additional counterweight is 500 pounds (227 kg) or 1000 pounds (453 kg).

**STEP 59**




Connect suitable lifting equipment to the large counterweight. The weight of the large counterweight is 1200 pounds (545 kg).

**STEP 57**



Loosen and remove the outside nuts and hardened washers from the studs that fasten the additional counterweight.

**STEP 60**



Loosen and remove the inside nuts and hardened washers from the studs for the large counterweight.


**NOTE:** If your machine is equipped with large counterweights only, loosen and remove the nuts and hardened washers from the bolts that fasten the large counterweights to the machine.

## ENGINE INSTALLATION

### STEP 142


Make sure the torque converter is installed on the transmission. Three splined shafts must be engaged for the torque converter to be installed correctly.

### STEP 143




Install a stud 2-3/4 inches (70 mm) long with 10 mm threads in one of the holes in the flex plates so the stud is to the left side as shown. Make sure the flex plates are not bent or damaged.

### STEP 144




Carry the engine over the frame.

### STEP 145




Move the engine forward and lower the engine.

### STEP 146




Push the engine toward the front. Have another person align the stud with the hole in the flywheel.

### STEP 147



Install the cap screws and lock washers that fasten the clamps for the wire harness, and the bracket for the heater hose to the flywheel housing. Install the remaining cap screws and lock washers that fasten the transmission to the flywheel housing. Tighten the cap screws to 480 to 528 pound-inches (54 to 60 Nm).


**STEP 226**

Align the holes in the large counterweight with the holes in the frame and install the studs that fasten the large counterweight. Install the inside nuts and hardened washers on the studs and tighten the inside nuts but not all the way.

**NOTE:** *If your machine is equipped with large counterweights only, install the bolts, hardened washers, and nuts that fasten the large counterweights to the machine. The nuts and hardened washers must be installed on the inside.*

**STEP 227**

Repeat steps 225 and 226 for the other large counterweight.


**STEP 228**

Tighten the inside nuts for both large counterweights to 175 to 225 pound-feet (237 to 305 Nm).


**NOTE:** *If your machine is equipped with large counterweights only, tighten the nuts on the bolts to 600 pound-feet (813 Nm).*

**STEP 229**

If your machine is equipped with additional counterweights, connect suitable lifting equipment to one of the additional counterweights. The weight of an additional counterweight is 500 pounds (227 kg) or 1000 pounds (453 kg). Align the additional counterweight with the studs and install the additional counterweight.

**STEP 230**

Install the hardened washers and nuts and tighten the nuts but not all the way.

**STEP 231**

Remove the lifting equipment and tighten the outside nuts to 550 to 650 pound-feet (745 to 881 Nm).

## Piston

Type.....	Cam Ground
Material.....	Aluminum Alloy
OD at 12 mm From the Bottom, 90 Degrees From Piston Pin	
Standard Size Piston.....	113.833 to 113.847
Minimum Service Limit.....	113.776 mm
ID of Piston Pin Bore.....	45.006 to 45.012 mm
Maximum Service Limit.....	45.025 mm
Width of 1st Ring Groove (Top).....	3.50 mm
Width of 2nd Ring Groove (Intermediate).....	3.08 to 3.10 mm
Width of 3rd Ring Groove (Oil Ring).....	4.040 to 4.060 mm
Protrusion Above Cylinder Block (Maximum).....	0.380 mm
Protrusion Above Cylinder Block (Minimum).....	0.018 mm

## Piston Rings

No. 1 Compression 6T830 and 6TA830.....	Key Stone Type (Barrel Face)
End Gap in 114.020 ID.....	0.40 to 0.70 mm (See Note)
No. 1 Compression 6-830 Engine.....	Key Stone Type Barrel Face
End Gap in 114.020 ID.....	0.40 to 0.70 mm (See Note)
Side Clearance.....	Use Keystone Gauge
No. 2 Compression.....	Rectangular Type (Taper Face)
End Gap in 114.020 ID.....	0.40 to 0.70 mm (See Note)
Side Clearance.....	0.70 to 0.125 mm
No. 3 Oil Control Rings.....	Two Piece
End Gap in 114.020 ID.....	0.30 to 0.60 mm (See Note)
Side Clearance.....	0.020 to 0.065 mm

NOTE: Add 0.09 mm gap for every 0.03 mm of bore wear up to maximum worn limit.

## Cylinder Head

Warpage (Maximum) Total Across Head.....	0.20 mm
Maximum material Removal.....	1.00 mm
Minimum Head Height.....	115.75 mm
Valve Guide Bore.....	15.931 to 15.971 mm
Insert Bore (Intake).....	53.897 to 53.927 mm
Insert Bore Depth (Intake).....	12.00 to 12.20 mm
Insert Bore (Exhaust).....	46.997 to 47.027 mm
Insert Bore Depth (Exhaust).....	9.63 to 9.83 mm


## Lifters

Material.....	Hardened Iron
OD of Lifter.....	15.929 to 15.980 mm
Minimum Service Limit.....	15.925 mm

## Connecting Rod


Bushing.....	Steel Backed Leaded Bronze
Bushing ID Installed (Ream to Size).....	45.023 to 45.035 mm
Bearing Liners.....	Replaceable
Journal ID Without Bearing Liners.....	80.987 to 81.013 mm
Bearing Oil Clearance.....	0.033 to 0.117 mm
Side Clearance.....	0.100 to 0.300 mm
Maximum Service Limit.....	0.330 mm
Connecting Rod Bend (Maximum)	
Without Bushing.....	0.200 mm
With Bushing.....	0.150 mm
Connecting Rod Twist (Maximum)	
Without Bushing.....	0.500 mm
With Bushing.....	0.300 mm

## STEP 24




Push the valve springs down with a valve spring compressor and remove the valve keepers.

## STEP 25




Remove the valve spring retainers and the valve springs.

## STEP 26




Remove the valve and valve guide seals from the cylinder head. Discard the valve guide seals.

## STEP 27




Remove and discard the valve spring seat from the cylinder head (If Equipped).

## STEP 28




Clean the cylinder head completely, removing carbon and other deposits. Check for cracks and any sign of damage in the area of the fire ring contact.

## STEP 29




Check the cylinder head surface for warpage. Use a straight edge and feeler gauge. Clean the machined surface of the head. Use a heavy, accurate straight edge to check for warpage at each side and between all cylinders. Also, check for end-to-end warpage in six positions or more.

**IMPORTANT:** *If the measurement is more than 0.020 mm, the cylinder head must be machined or replaced. Replace the cylinder head if the head height is less than 115.75 mm, after the head is machined.*



### 30 Degree Intake Valves



# Section 2425

## CYLINDER BLOCK


Crankshaft, Pistons, Rods, Sleeves, Camshaft,  
Bearings, Seals and Flywheel

6-830 Diesel Engine

2425


**IMPORTANT:** *This engine was made using the metric measurement system. All measurements and checks must be made with metric tools to make sure of an accurate reading when inspecting parts.*

**STEP 42**




Install the puller stud into the installation tool.

**STEP 45**




Remove the sleeve installation tool from the crankshaft.

**STEP 43**




Install the wear sleeve with the chamfer toward the crankshaft.

**STEP 46**




Install a new front cover gasket.

**STEP 44**




Install the cup and push the sleeve on the crankshaft.

**STEP 47**




Install the front cover. Tighten the bolts to a torque of 21 to 27 Nm.


**STEP 104**

T90870

Measure the diameter of the piston pin. If the diameter is less than 44.993 mm the piston pin must be replaced.


**STEP 105**

T90867




T90888

Measure the piston pin bore. If the piston pin bore is more than 45.025 mm the piston must be replaced.

**STEP 106**


T90871

Measure the diameter of the piston across the thrust face 12 mm from the bottom of the piston, at right angles of the piston pin holes. Replace the piston if the diameter is less than 113.776 mm.

**STEP 107**

T91006


Break an old piston ring in half and use the broken ring half to clean the piston ring grooves. Too much deposit in the ring grooves can force the rings out and will cause scoring.

**STEP 108**

T90879


Check the side clearance of the oil ring in the piston. Insert a feeler gauge between the upper surface of a new ring and the piston lands to check the clearance. Replace the piston if side clearance is more than 0.065 mm.

**STEP 178**




Remove the main bearing liners from the engine.

**STEP 180**




Remove the oil spray nozzle from the bearing carrier.

**STEP 179 Prior to Serial Number 4487830**



119L91


**Engine Serial Number 4487830 and After**



118L91


Clean the oil spray nozzles with a small wire, if a nozzle is damaged it must be replaced.

## STEP 251




Disconnect the fuel filter inlet line from the lift pump.

## STEP 254




Remove the valve cover.

## STEP 252




Remove the lift pump bolts and the lift pump from the cylinder block.

## STEP 255




Remove the rocker arm bolts and the rocker arm assembly.

## STEP 253



Remove the breather from the valve cover.

## STEP 256




Remove the rocker arm oil supply tube.

**IMPORTANT:** A new oil supply tube must be installed if the supply tube is made of nylon material.

## Ring Gear Removal and Installation


### STEP 320



T69212


Remove the ring gear from the flywheel, using a drift and hammer. Work around the circumference of the ring gear.

### STEP 322



Install the flywheel. Tighten the retaining bolts to a torque of 130 to 141 Nm.

### STEP 321




T69213

Heat the new ring gear, 400° to 450°F (204° to 232°C), in oil or in an oven. Do not use a torch to heat the ring gear.

Install the ring gear on the flywheel.

## Oil Pump Installation


### STEP 10



Install the oil pump and pump bolts. Tighten the bolts to a torque of 21 to 27 Nm. Follow the torque sequence above.


**NOTE:** Bolt torque that is too high or uneven, will cause damage to the oil pump. There will be a small clearance between the oil pump flange and the cylinder block.

### STEP 11




Clean the seal surface on the crankshaft with loctite safety solvent. See Section 2425 in the service manual for front cover installation.

### STEP 12



Install the crankshaft pulley and pulley bolts. Tighten the bolts to a torque of 180 to 212 Nm.


### STEP 13



Install the fan pulley and pulley bolts. Torque the fan pulley bolts to a torque of:



Grade 8.8 Size M8 .....	26 to 31 Nm
Grade 10.9 Size M8 .....	37 to 43 Nm
Grade 8.8 Size M10 .....	51 to 62 Nm
Grade 10.9 Size M10 .....	51 to 62 Nm

### STEP 14




Lift the fan belt tensioner pulley and install the fan belt.

### Installation




#### STEP 15




Install the thermostats and gasket into the cylinder block. The thermostats must point up toward the outlet pipe.

#### STEP 16




Install the thermostat housing. Install the thermostat housing bolts and tighten to a torque of 21 to 27 Nm.

**STEP 25**




Remove the compressor wheel.

**STEP 26**





Lift the center housing from the turbine shaft.

**STEP 27**




Remove the heat shield.

**STEP 28**



Remove the seal ring from the turbine shaft.


**STEP 29**



Turbocharger center housing.


## Installation

### STEP 92




Install a new gasket on the exhaust manifold.

### STEP 95




Install a new gasket on the oil drain tube.

### STEP 93




Install the turbocharger on the exhaust manifold.

### STEP 96




Install the oil drain tube bolts and tighten the bolts to a torque of 18 lb ft (24 Nm)(2.4 kgm).

### STEP 94




Install the turbocharger mounting nuts and tighten to a torque of 24 lb ft (32 Nm)(3.2 kgm).

### STEP 97



Connect and tighten the oil supply tube to the turbocharger and the filter housing.


### STEP 5



Make sure there is fuel in the fuel tank. Loosen the air removal screw and actuate the hand primer pump. Close the air removal screw when clear fuel with no bubbles flows from the screw.

**NOTE:** *If the hand lever on the primer pump can not be actuated, turn the engine over until the pump can be actuated.*


### STEP 6



Loosen the air removal screw on the fuel inlet line. Actuate the hand primer pump. Close the air removal screw when clear fuel with no air bubbles, flows from the screw.

**NOTE.** *If the hand lever on the primer pump can not be actuated, turn the engine until the pump can be actuated.*

### STEP 7




Loosen the fuel return line fitting on the injection pump. Actuate the hand primer pump. Tighten the fuel return line on the injection pump when clear fuel with no air bubbles, flows from the fitting.

**NOTE:** *If the hand lever on the primer pump can not be actuated, turn the engine until the pump can be actuated.*

## Injection Pump Gear Installation


### STEP 45



Install the drive gear on the injection pump shaft. The drive gear does not have timing marks.


**NOTE:** *The ID of the drive gear is tapered to fit the injection pump shaft. There is not a key slot in the drive gear.*

### STEP 46



Install the washer and nut on the injection pump shaft and tighten to a torque of approximately 20 Nm.


### STEP 47



Remove the cover and pull the timing pin out of the injection pump.


Rac 8-28492

### STEP 48




Install the timing pin into the injection pump. The small end must be toward the tab in the injection pump.

### STEP 49



Install the timing pin cover and tighten to a torque of 13 to 17 Nm.

### STEP 50




Pull the lock pin out of the camshaft gear.

### SPECIAL TORQUES

	U.S. Value	Metric Value
Injector Retaining Bolt.....	18 lb ft	24 Nm (2.4 kgm)
Leak Off Bolt.....	7 lb ft	9 Nm (0.9 kgm)
Nozzle Cap Nut.....	18 lb ft	24 Nm (2.4 kgm)


### SPECIAL TOOLS




CAS-1858  
INJECTOR BORE  
CLEANING TOOL




MAGNIFYING GLASS  
66-0135



CAS-1815 INJECTOR PULLER ADAPTER




CAS-10091 OR CAS-10249  
DIESEL FUEL INJECTION  
NOZZLE TESTER



66-0558 ORIFICE  
CLEANING WIRES


**STEP 27**



Install the pressure spring in the nozzle holder.


**NOTE:** Clean all parts in clean diesel fuel before assembly.

**STEP 30**




Put a small amount of clean fuel on the nozzle valve and slide the nozzle valve up and down a number of times in the nozzle tip to make sure that there is free movement.

**STEP 28**




Install the spring seat on the pressure spring. The small diameter end of the spring seat must be toward the pressure spring.

**STEP 31**




Align the dowel pin holes in the nozzle tip assembly with the dowel pins in the stop valve assembly. Install the nozzle tip assembly on the valve stop assembly.

**STEP 29**



Install the valve stop assembly. Align the dowel pins that are in the valve stop with the dowel pin holes that are in the nozzle holder.

**STEP 32**



Add lubrication to the nozzle shoulder. Do not put grease on the holder or the threads of the cap nut. Install the cap nut over the end of the nozzle tip assembly and turn the cap nut clockwise two or three times.

## ①9 Ether Injection Switch

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
---------------------	----------------	--------------------------------------

**NOTE:** *Disconnect the wires from the ether switch.*

Between terminals of switch	Continuity	Bad ether switch.
-----------------------------	------------	-------------------

**NOTE:** *Put the master disconnect switch and the key switch in the ON positions.*

Terminal for wire 21N to ground	24 volts	Check circuit 21N.
---------------------------------	----------	--------------------

## ②0 Air/Brake Pressure Switch

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
---------------------	----------------	--------------------------------------

**NOTE:** *Put the master disconnect switch in the ON position. Put the key switch in the ON position.*

Terminal for wire 25S to ground	24 volts	Check the circuit between the air/brake pressure switch and the relay No. 2 transmission clutch cutout on page 13 and 23. Also check relay No. 2.
---------------------------------	----------	---

**NOTE:** *Start and run the engine at 1000 rpm (r/min) until the air pressure indicator lamp goes off. Stop the engine. Disconnect the wires from the clutch cutout pressure switch.*

Between the terminals of the air/brake pressure switch	Continuity	Bad clutch cutout pressure switch.
--	------------	------------------------------------

## ②1 Cab Power Relay

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
---------------------	----------------	--------------------------------------

Terminal for wire 0 to ground	Continuity	Bad ground circuit.
-------------------------------	------------	---------------------

**NOTE:** *Put the master disconnect switch in the ON position.*
















Battery terminal to ground	24 volts	Check circuit to batteries.
----------------------------	----------	-----------------------------

**NOTE:** *Put the key switch in the ON position.*

Terminal for wire 13C to ground	24 volts	Check key switch (12). Also check circuit 13C.
---------------------------------	----------	--

Terminal for switched power	24 volts	Bad cab power relay.
-----------------------------	----------	----------------------

CLUTCH CUTOUT AND TRANSMISSION SHIFTER - EARLY PRODUCTION



## ⑧ Engine Oil Pressure Switch

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for 0 to ground	Continuity	Bad ground circuit.

**NOTE:** Put the master disconnect switch in the ON position. Put the key switch in the ON position.

Terminal for wire 31P to ground	Approximately 5 volts	Check instrument cluster (1).
---------------------------------	-----------------------	-------------------------------

**NOTE:** If the readings are good, replace the low air pressure switch.

## ⑨ Low Air or Brake Pressure Switch

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for 0 to ground	Continuity	Bad ground circuit.

**NOTE:** Put the master disconnect switch in the ON position. Put the key switch in the ON position.

Terminal for wire 31L to ground	Approximately 9 volts	Check instrument cluster (1).
---------------------------------	-----------------------	-------------------------------

**NOTE:** If the readings are good, replace the low air pressure switch.




## ⑩ Master Warning Lamp

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Bulb	Good	Bad bulb.

**NOTE:** Put the master disconnect switch in the ON position. Put the key switch in the ON position.

Terminal for wire 19C to ground	24 volts	Bad 5 ampere fuse in fuse block No. 1.
Between terminal for wire 31W and terminal 4 in the instrument cluster connector	Continuity	Bad circuit between the master warning lamp and the instrument cluster (1). Also check the instrument cluster (1).

GAUGES AND SENDERS, RADIO, AIR DRYER HEATER, AND ROTATING BEACON - EARLY PRODUCTION



#### ④ Front LH Flood Lamp

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for wire 0 to ground	Continuity	Bad ground circuit.
Bulb	Good	Bad bulb.
<b>NOTE:</b> Put the master disconnect switch in the ON position. Put the key switch in the ON position. Put the light switch in the ON position.		
Terminal for wire 42F to ground	24 volts	Bad circuit between the front LH flood lamp and the light switch (10). Also check the light switch (10).

#### ⑤ Front RH Flood Lamp

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for wire 0 to ground	Continuity	Bad ground circuit.
Bulb	Good	Bad bulb.
<b>NOTE:</b> Put the master disconnect switch in the ON position. Put the key switch in the ON position. Put the light switch in the ON position.		
Terminal for wire 42F to ground	24 volts	Bad circuit between the front RH flood lamp and the light switch (10). Also check the light switch (10).





#### ⑥ RH Head Lamp

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for wire 0 to ground	Continuity	Bad ground circuit.
Bulb	Good	Bad bulb.
<b>NOTE:</b> Put the master disconnect switch in the ON position. Put the key switch in the ON position. Put the light switch in the ON position.		
Terminal for wire 41D to ground	24 volts	Bad circuit between the RH head lamp and the light switch (10). Also check the light switch (10).

#### ⑦ Rear LH Flood Lamp

<u>Check Points</u>	<u>Reading</u>	<u>Possible Cause of Bad Reading</u>
Terminal for wire 0 to ground	Continuity	Bad ground circuit.
Bulb	Good	Bad bulb.
<b>NOTE:</b> Put the master disconnect switch in the ON position. Put the key switch in the ON position. Put the light switch in the ON position.		
Terminal for wire 42R to ground	24 volts	Bad circuit between the rear LH flood lamp and the light switch (10). Also check the light switch (10).


AIR CONDITIONING, FRONT WIPER, AND WASHER - EARLY PRODUCTION



## TABLE OF CONTENTS

SPECIFICATIONS .....	3
NO LOAD TEST .....	4
STARTER SOLENOID TESTS .....	6
STARTER .....	8
Disassembly .....	8
Inspection .....	14
Brush Holder and Brushes.....	14
Replacing Bushings .....	15
Field Coil Test .....	17
Replacing the Field Coil .....	17
Assembly .....	21
Checking Pinion Clearance .....	27
STARTER SOLENOID .....	29
Disassembly .....	29
Assembly .....	32

6. Press a new seal into the shift lever housing.




1. Seal

*Typical of Procedure*

### Starter Drive Housing

1. Press the bushing out of the starter drive housing




*Typical Starter Drive Housing*

2. Put the new bushing in a container of SAE 20 engine oil for two minutes.


3. Fill the wick in the starter drive housing with SAE 20 engine oil.

4. Put the bushing in position in the bore of the starter drive housing



1. Bushing


5. Press the bushing into the bore until the bushing is even with the top of the bore.



**IMPORTANT:** *DO NOT* ream the bushing. The bushing is made of sintered bronze. Reaming the bushing, using any method, will prevent oil in the wick from going through the bushing to lubricate the armature shaft.


4002-30

**STEP 95**




Remove the contact assembly.

**STEP 97**




Remove the gasket.

**STEP 96**



Remove the terminals from the wire terminals.


**STEP 11**



**B5443289M**

Remove and discard the O-ring.


**STEP 12**



**B5450289M**

Remove the thrust washer.


**STEP 13**



**B5443689M**

Remove and discard the O-rings.


**STEP 14**



**B5450489M**

Make an alignment mark on the field frame and the brush holder.


**STEP 15**



**B5451189M**

Remove the screws and lock washers that fasten the brushes to the brush holder.

**STEP 16**



**B5450989M**

Remove the brushes.





## Parking Brake

Turn the key switch from OFF to ON and wait three seconds for the instrument cluster to complete the self-test. If the warning lamp does not illuminate during the self-test, the instrument cluster is bad and must be replaced.

After the self-test the warning lamp must be illuminated only when the key switch is in the ON position and the parking brake is applied.

If the warning lamp does not illuminate when the parking brake lever is all the way up, the cause can be:

1. An open circuit in the wire that connects the parking brake switch to the instrument cluster. The wire (yellow) is connected to the No. 16 terminal in the connector for the instrument cluster.

2. An open circuit in the wire that connects the parking brake switch to the ground connection.
3. The parking brake switch is bad.

If the warning lamp illuminates when the parking brake lever is all the way down, the cause can be:

1. A short circuit to ground in the wire that connects the lamp switch to the instrument cluster. The wire (yellow) is connected to the No. 16 terminal in the connector for the instrument cluster.
2. The parking brake switch is bad.

## MASTER WARNING LAMP

The master warning lamp is mounted on the steering column and is controlled by the instrument cluster.


The master warning lamp must illuminate continuously during the self-test. Turn the key switch from OFF to ON and wait three seconds for the instrument cluster to complete the self-test. If the master warning lamp does not illuminate during the self test, check for a bad bulb. If the bulb is good check for an open circuit in the wires that connect the master warning lamp to the instrument cluster and to the ground connection. If there is not an open circuit, the instrument cluster is bad and must be replaced.

The master warning lamp must illuminate intermittently when any of the following warning lamps are illuminated. If the master warning lamp does not illuminate, the instrument cluster is bad and must be replaced.

1. Engine oil pressure
2. Air pressure
3. Auxiliary steering
4. Engine coolant temperature
5. Parking brake, when transmission is in FORWARD or REVERSE
6. Alternator
7. Transmission oil temperature
8. Hydraulic oil temperature


The master warning lamp must illuminate intermittently when the top two bars of the engine temperature gauge are illuminated. If the master warning lamp does not illuminate, the instrument cluster is bad and must be replaced.

**STEP 44**




Install bearing retaining plate.

**STEP 47**




Install the rotor in the front housing.

**STEP 45**




Install a new front bearing on the rotor shaft if it has been removed. Install bearing and spacer ring with a hydraulic press.

**STEP 48**




Install and tighten the four screws that hold the rotor in the front housing.

**STEP 46**




Install a new rear bearing on the rotor shaft if it has been removed. Install bearing using a hydraulic press.

**STEP 49**



Assemble the front housing and rear housing making sure the reference marks align.




B891829J

# Section

# 5002


## STEERING TROUBLESHOOTING AND PRESSURE CHECK

**STEP 6**




Lift the gerotor set, the drive shaft spacer, the drive shaft, and the spacer plate as an assembly from the body.

**STEP 7**




Separate the drive shaft spacer, the drive shaft, the gerotor set, and the spacer plate.

**STEP 8**




Remove the rotor from the stator.

**STEP 9**




Remove and discard the O-ring from the stator.

**STEP 10**




Remove and discard the O-ring from the end plate.

**STEP 11**



Remove and discard the O-ring from the body.


**STEP 74**



**B9078606M**

Install the Ferry head screws.


**STEP 76**



**B9078613M**

Tighten the Ferry head screws to 225 to 275 pound-inches (25 to 31 Nm) in the sequence shown in step 75.

**STEP 75**



**B9078616M**

Tighten the Ferry head screws to 100 to 150 pound-inches (11 to 17 Nm) in the sequence shown.

## Assembly

1. Install the wide seal (5) in the gland (18). The wide seal (5) must be installed so that the lips of the wide seal (5) are toward the small end of the gland (18). The wide seal (5) can be difficult to install. Use tools that will not damage the wide seal (5).

2. Install the narrow seal (15) in the gland (18).

3. Install the bushing (10) in the gland (18).

4. Install the wiper (4) in the gland (18).

5. Install the O-ring (16) on the gland (18). The O-ring (16) must be toward the small end of the gland (18).

6. Install the backup ring (17) on the gland (18). The backup ring (17) must be toward the large end of the gland (18). If the backup ring (17) is not flat on both sides, the side that is not flat must be toward the O-ring (16).

7. Fasten the rod eye on the piston rod (1) in the vise.

8. Lubricate the piston rod (1) and the bore in the gland (18) with clean hydraulic oil.

**NOTE:** *If a new gland (18) is being installed, write the part number of the cylinder on the gland (18).*

9. Push the gland (18) onto the piston rod (1). If necessary, use a soft hammer to drive the gland (18) onto the piston rod (1).

10. Put a support below and near the end of the piston rod (1). Put a cloth between the support and the piston rod (1) to prevent damage to the piston rod (1).

11. Install a new wear ring (6) on the piston (9).

12. Install a new backup ring (7) on the piston (9).

13. Install a new seal (8) over the backup ring (7).

14. Clean the threads on the end of the piston rod and the threads of the cap screw using Loctite cleaning solvent. Allow to dry. Apply Loctite 242 to the piston rod threads 1/4 inch from the open end of the piston rod so that there is 1/2 inch of Loctite 242 on the piston rod threads. **DO NOT** apply Loctite to the first 1/4 inch of the piston rod threads.

15. Install the cap screw (11) and hardened washer (12) in the piston (9).

16. Install the piston (9) on the piston rod (1) and start the cap screw (11) into the piston rod (1).

17. Tighten the cap screw (11) to the torque shown in the illustration.

18. Fasten the tube (20) in the vise or other holding equipment. Be careful not to damage the tube (20).

19. Apply petroleum jelly to the O-ring (16) and backup ring (17) on the gland (18) and to the sealing surface in the tube (20).

20. Lubricate the piston (9) and the inside of the tube (20) with clean hydraulic oil.

21. Push the piston (9) straight into the tube (20). Be careful not to damage the wear ring (6) and seal (8) on the piston (9).

22. When the piston (9) is in the smooth part of the tube (20), start the gland (18) into the tube (20).

23. If the original parts are being assembled:

a. Tighten the gland (18) to 100 to 400 pound-feet (135 to 542 Nm) until the holes for the lock screw (19) are aligned.

b. Install and tighten the lock screw (19).

c. If, after tightening the gland, the lock screw (19) holes are not aligned, a new hole for the lock screw (19) must be drilled. See the next step.


24. If a new gland (18) or a new tube (20) is being assembled:

a. Tighten the gland (18) to 100 to 400 pound-feet (135 to 542 Nm).

b. Use a No. 26 drill and drill a hole half in the gland (18) and half in the tube (20). Drill to a depth of 7/16 inch (11 mm). Do not drill within 1/2 inch (12 mm) of a hole for the gland wrench.

c. Install and tighten the lock screw (19).


**STEP 41**



Use the ram, hand pump, and a suitable driver and remove the bearings and spacer from the bottom pivot.


**NOTE:** *The spacers are matched to the bearing sets. Do not mix the spacers. Do not use old spacers if new bearing sets are being installed.*

**STEP 42**




Use an acceptable driver and press the seals out of the bearing retainers.

**STEP 95**




Tighten the six outer cap screws to 220 pound-feet (298 Nm).

**STEP 96**




Tighten the three inner cap screws to 245 pound-feet (332 Nm).

**STEP 97**




Install the insulator, bolt, flat washer, hardened washer, and nut that fasten each side of the ROPS cab or ROPS canopy to the front of the rear frame. Tighten the bolts to 570 to 630 pound-feet (772 to 854 Nm).

**STEP 98**




Remove the floor jack from under the center of the rear frame.

**STEP 99**




Remove the blocks from between the rear axle and the rear frame.

**STEP 100**




Remove the floor jack from under the front center of the rear frame.

**STEP 43**




Remove the backup ring from the outlet fitting.

**STEP 46**




Install the backup ring.

**STEP 44**




Remove the O-ring from the outlet fitting.

**STEP 47**




Remove the O-ring from each slotted plug.

**STEP 45**




Install a new O-ring on the outlet fitting.

**STEP 48**




Install a new O-ring on each slotted plug.

**STEP 109**



Install the small check valve in the valve sleeve.

**STEP 111**




Tighten the large plug.

**STEP 110**



Use the large plug to push the parts into the bore of the valve body, and start the large plug into the threads in the bore.


**STEP 112**



Install the fitting in the top of the valve body.


# Assembly

## STEP 26




Install the Woodruff key.

## STEP 27




Use an acceptable driver and press the fan onto the shaft.

## STEP 28




Use an acceptable driver and press the bearing onto the shaft.

## STEP 29




Press the bearing onto the shaft.

## STEP 30




Align the brush holder with the commutator end cover and install and tighten the cap screws.

## STEP 31




Install the brush springs.

## SPECIAL TOOLS




B4187189M

CAS-2020 lever used for Removal and Installation of Hydraulic Pump. Shown in use in Step 114.



B430842M

CAS-1960 Used to turn flywheel. Shown in use in step 145.




B4188389M

CAS-1927 Guide Studs. Used to Remove and Install the Transmission Control Valve. Instructions for use are in step 241.

## REMOVAL OF FRONT AXLE

### STEP 1



B8974214M

Loosen and remove the nuts and lock washers from the bolts that hold the center bearing.


### STEP 2



B8974220M


Loosen and remove the Ferry head screws and clamps.

**STEP 84**




Disconnect the tube from the filters.

**STEP 87**




Loosen and remove the nut and lock washer that hold the clamp for the hose to the reservoir.

**STEP 85**




Remove the tube.

**STEP 88**




If equipped with air conditioning, loosen and remove the nuts, lock washers and bolts that hold the condenser. Do not remove the condenser now.

**STEP 86**



If equipped with air conditioning, loosen and remove the nut and lock washer that hold the clamp for the wiring harness and the clamp for the hoses.


**STEP 89**



Disconnect the hose from the pressure protection valve.

**STEP 174**


Install the rear drive shaft and the clamps and Ferry head screws.

**STEP 175**


Tighten the Ferry head screws to 55 to 60 pound-feet (75 to 81 Nm).

**STEP 176**


Install new gaskets and the screen for the filler tube. Install the cap screws and tighten the cap screws to 230 to 275 pound-inches (26 to 31 Nm).

**STEP 177**


Engage the parking brake cable with the mounting bracket and tighten the bottom nut.

**STEP 178**

Install the clevis pin and a new cotter pin.

**STEP 179**

Install the filter.

**STEP 180**

Install a new gasket for the pump. Use gasket sealant to hold the gasket.

# Section 6002

TRANSMISSION SPECIFICATIONS, SCHEMATIC,  
AND TROUBLESHOOTING - ZF TRANSMISSION  
WITH CLARK SHIFTER

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## LUBRICATION PRESSURE CHECK

### Test Equipment Required

0 to 100 psi (689 kPa, 7 bar) gauge  
1 5/16-12 tee connector


### Test Procedure

1. Block the machine tires.
2. Apply the parking brake.
3. Heat the oil to an operating temperature of 176° to 212°F (80° to 100°C).
4. Install pressure gauge in the line from the cooler to the transmission.

*NOTE: Be careful when disconnecting and connecting the line from the cooler. Leakage can result if excessive force is used.*

5. Run engine at full throttle.

6. While in the cab, put transmission in each gear and record the readings in the chart at the end this section. Pressure must be 3 to 18 psi (20.7 to 124 kPa, 0.2 to 0.8 bar).



6. If any readings in step 5 were not correct, do the following procedure:

- a. Make sure that the key switch is in the OFF position.
- b. Remove the screws which fasten the cover at the upper front part of the steering pedestal.
- c. Remove the cover from the steering pedestal.
- d. See the wiring diagrams in Section 4001 and disconnect the two pairs of connectors which fasten the controller harness to the pedestal harness. Turn the key switch to the ON position and check for system voltage at wire 25V of the pedestal harness. If the reading is not system voltage, wire 25V between the transmission control module and the controller harness is bad. Repair or replace as necessary. If the reading is system voltage, turn the key switch to the OFF position and connect a jumper wire between wire 25V of the pedestal harness and the red wire of the controller harness. This jumper wire will supply current to the transmission controller during the test in step 6e.

e. Put the key switch in the ON position. Check for system voltage at each wire of the controller harness in each shifter position. The readings must be as shown in the chart to the right. If any readings are not correct, the transmission controller is bad and must be replaced. If all readings are correct, the problem is in the wiring between the transmission controller and the transmission control module. See the wiring diagrams in Section 4001 and use an ohmmeter to check for open circuits in the wiring. Connect the harness and continue if no problem is found.

7. Clutch Cutout - To find a problem in the clutch cutout circuit, put the key switch in the ON position. Check for voltage between test point 35 and 22 during any of the three following conditions:

- a. Left-hand brake pedal pushed down while the left-hand side of the declutch switch on the right-hand console is pushed down.
- b. Parking brake applied.
- c. Low brake pressure.

**921 ONLY NOTE:** *If the park brake switch is in the off position and the key switch is turned off, the park brake will automatically apply. To release the brake, turn the key switch on and move the park brake switch to the on position. Then move the park brake switch to the off position. This will reset the relay for proper test conditions.*

The indication at test point 22 must be zero volts when the cut out is activated during any of the above three conditions. The indication must be system voltage when none of the above three conditions is present. If either indication is not correct, see Section 4001 and check for a problem in the clutch cutout circuit. If the indications are both correct, but the clutch cutout does not work correctly, the problem is in the transmission control module.

Controller Positions

Wire Colors	Forward				Reverse			Neutral			
	1	2	3	4	1	2	3	1	2	3	4
pink					x	x	x				
green			x	x			x			x	x
yellow	x	x	x	x							
violet	*	*	*	*	*	*	*	*	*	*	*
blue	x			x	x			x			x
gray								x	x	x	x
black	x	x	x	x	x	x	x	x	x	x	x

\* When the down shift button is pressed in any controller position, there must be system voltage at the violet wire. When the down shift button is released, the reading at the violet wire must be zero volts for any controller position.


## CLUTCH PRESSURE CHECKS

### Test Equipment Required

0 to 400 psi (2758 kPa) gauge with hose long enough to take readings in the cab, 10 mm, 90 degree elbow adapter.

### Test Procedure


1. Block the machine tires.
2. Apply the parking brake.
3. Heat the oil to an operating temperature of 176° to 212°F (80° to 100°C).
4. While in the cab, run engine at full throttle.
5. Take reading at desired gear test point. Record the reading in the chart at the end of this section. Clutch pressures must be 220 to 250 psi (1517 to 1724 kPa).



B910868J


- |                |                 |
|----------------|-----------------|
| 1. First Gear  | 4. Fourth Gear  |
| 2. Second Gear | 5. Forward Gear |
| 3. Third Gear  | 6. Reverse Gear |

**STEP 17**




Remove the filter from the transmission housing.

**STEP 18**




Remove the torque converter from the transmission.

**STEP 19**




Remove the cap screws and nut from the torque converter housing.

**STEP 20**




Loosen the torque converter housing with a rubber hammer.

**STEP 21**




Remove the torque converter housing.

**STEP 22**




Remove the cap screws from the bearing cover.

**STEP 82**




Remove the control valve harness. Do not lose the gaskets.

**STEP 83**



Remove the number one valve spool from the bore.


**STEP 84**



Remove the spring from the same bore.


**NOTE:** *Fasten an identification tag to each spool and spring, and identify each bore for proper assembly.*

**STEP 85**




Remove the number four valve spool from the bore.

**STEP 86**




Remove the spring from the same bore.

**STEP 87**



Loosen the support plate Allen head screw. Slide the support plate away from the bore.


**STEP 159**



**B6232889M**

Install the solenoid valve support plates using the Allen head screws.


**STEP 160**



**B6232589M**

Connect the wires to the solenoid valves.


**STEP 161**



**B6232289M**

Install the O-ring on the solenoid valve cover.


**STEP 162**



**B6231689M**


Install the solenoid valve cover and engage the spring clip.

**STEP 225**



Install the remaining two cap screws and tighten all the cap screws to 204 to 221 pound-inches (23 to 25 Nm).

**STEP 226**



If the input gear does not rotate freely, tap the end of the shaft until the input gear rotates freely.

## INSPECTION OF THE FORWARD AND LOW CLUTCHES

### STEP 291

Check the teeth on the gears for wear and damage. If a tooth is badly damaged, be sure to inspect the gear that is in mesh with the damaged gear. Inspect the splines in the gears for wear and damage, be sure to inspect the shaft that the gear is installed on.


### STEP 292

Check the ball, roller and needle bearings for flat areas, pitting and other damage. Check the cages, inner races and outer races for damage also.

### STEP 293

Check each metal and friction disc with a straight edge to be sure each part is flat. If a metal or friction disc is not flat, a new part must be installed during assembly. If the friction discs are smooth or almost smooth, use new parts during assembly. Inspect the metal discs for pitting, scoring or other damage. If there is any damage, use new parts during assembly. Also, check the splines for wear. Inspect the bore and shaft in the clutch housing for damage that will cause leakage when the clutch is assembled. Use new parts as required during assembly.


**STEP 360**



Remove the friction and metal discs.


**NOTE:** *The discs must be soaked in transmission fluid until assembly.*

**STEP 361**




Place the clutch assembly in a press with preload compressor CAS-1932.

**STEP 362**




Slowly apply pressure until the snap ring can be removed.

**STEP 363**




Slowly release the pressure of the press and remove preload compressor CAS-1932.

**STEP 364**



Remove the guide ring from the shaft.


**STEP 365**



Remove the upper spring guide.


## DISASSEMBLY OF THE FOURTH AND THIRD CLUTCHES

### STEP 430




Remove the shim(s) from the fourth gear.

### STEP 433




Remove the fourth gear from the clutch assembly.

### STEP 431




Remove the slotted thrust washer.

### STEP 434




Remove the tab thrust washer from the clutch plate pack.

### STEP 432




Remove the plastic thrust washer.


### STEP 435



Remove the thrust plate.


**STEP 504**

Install the retaining ring.

**STEP 505**

Use caliper CAS-1938 and measure the distance from the face at the clutch housing to the pressure plate.

Example: Dimension A = 0.21 inch (5.4 mm)

**STEP 506**

Pry the pressure plate until it is against the retaining ring. Use caliper CAS-1938 and measure the distance from the face of the pressure plate to the clutch housing.

Example: Dimension B = 0.12 inch (3.0 mm)

**STEP 507**


Determine the end play by subtracting the figure determined in step 506 from the figure determined in step 505.

Example: Dimension A	0.21 inches	(5.4 mm)
Dimension B	– 0.12 inches	(3.0 mm)
Dimension C	0.09 inches	(2.4 mm)


**IMPORTANT:** *The required disc clearance is 0.08 to 0.15 inch (2.0 to 2.9 mm). This value must be corrected by the installation of a metal compensation disc of the appropriate thickness.*

If the calculated disc clearance is larger than 0.15 inch (2.9 mm) it must be reduced by changing the metal discs for thicker ones. The thicker metal discs must be put nearer the piston than the pressure plate.

If the calculated disc clearance is smaller than 0.08 inch (2.0 mm) it must be corrected by using thinner metal discs. The thinner metal discs must be put nearer the pressure plate than the piston.


**STEP 508**

Install the roller bearing in the fourth gear.

**STEP 509**


Install the fourth gear on the clutch pack. Make sure the discs are aligned so that the fourth gear is fully seated in the clutch pack.

**STEP 584**



Install the slotted and plastic thrust washers for the reverse and second gear clutch assembly in the transmission housing. The slotted washer fits the tab in the transmission housing.


**STEP 585**



Use caliper CAS-1938 and measure the distance from the housing to the plastic thrust washer.

Example: Dimension A = 9.93 inches (252.2 mm).


**STEP 586**



Use caliper CAS-1938 and measure the distance from the contact area of the bearing rollers to the flange face.

Example: Dimension B = 0.89 inch (22.6 mm).


**STEP 587**



Use caliper CAS-1938 and measure the distance from the plane surface of the second gear to the contact area of the reverse gear.

Example: Dimension C = 8.99 inches (228.3 mm).


**STEP 588**



Use caliper CAS-1938 and measure the distance from the plane surface of the reverse gear to the face of the rollers.


Example: Dimension D = 0.01 inch (0.2 mm).

STEP 665



Connect the pressure hose from the control valve to the channel plate.

**STEP 62**



Press the pinion shaft out of the roller bearing.

## INSPECTION OF PARTS OF DIFFERENTIAL CARRIER

Clean all parts in cleaning solvent.

Inspect the rollers in the tapered roller bearings for flat areas, pitting, scoring and other damage. Also check the inner race for damage. If any of these defects are found, a new bearing and bearing cup must be installed.


Inspect the bearing cups for flat areas, pitting, scoring and other damage. If any of these defects are found, a new bearing cup and bearing must be installed.

Inspect the teeth on the pinion gear and the ring gear for pitting, scoring and broken teeth. The ring gear and pinion gear must be replaced as a set.

Inspect the thrust washer for scoring, pitting and other damage. If one thrust washer must be replaced, all thrust washers must be new.


Inspect the teeth on the pinion gears and side gears for pitting, scoring and broken teeth. Also inspect the thrust surface and bore of each pinion gear. If one pinion gear is to be replaced, all pinion gears must be new. Check the splines in the side gears for wear.

**STEP 122**



Prevent the thrust screw from turning and tighten the lock nut.

**STEP 123**




Bend the locks against the head of each cap screw.

**STEP 124**




Bend the locks into each adjusting ring.

**STEP 125**




Loosen and remove the nut.

**STEP 126**




Remove the hardened washer.

**STEP 127**




Remove the yoke.

### STEP 198




Put an acceptable driver on the inner race of the wheel bearing.

### STEP 200



Use acceptable equipment and remove the bearing cups as required.

### STEP 199



Drive the seal and wheel bearing out of the planetary housing.

## INSPECTION OF PARTS OF PLANETARY

Clean all parts in cleaning solvent.

Discard the seal and O-rings.

Inspect the rollers in the wheel bearings for flat areas, pitting, scoring and other damage. Also check the inner race for damage. If any of these defects are found, a new wheel bearing and bearing cup must be installed.

Inspect the bearing cups for flat areas, pitting, scoring and other damage. If any of these defects are found, a new bearing cup and wheel bearing must be installed.

Inspect the pinion shafts and the bore of the pinion gears for wear and damage. Inspect the teeth of the pinion gears, ring gear and sun gear for wear, pitting, scoring and other damage. Use new parts as required.


Inspect the splines on the spindle and in the hub of the ring gear for wear and other damage.

6005-4

### STEP 7

Remove paint or rust from the shaft and apply WD40 or similar oil to loosen any rust between the inner race and the shaft.

### STEP 8



Loosen and remove the Ferry head screws and clamps.

### STEP 9




Disengage the universal joint from the yoke and remove the front drive shaft. If necessary, use brass hammer to drive the shaft out of the center bearing.

## INSTALLATION OF FRONT DRIVE SHAFT

### STEP 10


Apply antiseize compound to the shaft.

### STEP 11



Install the front drive shaft and the clamps and Ferry head screws.

### STEP 12



Tighten the Ferry head screws to 55 to 60 pound-feet (75 to 81 Nm).

## TABLE OF CONTENTS

WHEEL NUTS.....2  
     General Information.....2  
     Torque Specification.....2  
 TIRE PRESSURE.....2  
 CHANGING TIRES .....3  
 INSTALLING A WHEEL .....3

### WHEEL NUTS

#### General Information

The wheel nuts must be tightened after every 20 hours of operation until the wheel nuts stay tight:

If the machine is new.

If a wheel has been removed and installed.

#### Torque Specification


150 pound-feet (203 Nm) in the sequence shown on page 6006-3, then a final torque of 560 to 600 pound-feet (759 to 813 Nm) in the same sequence.

### TIRE PRESSURE

20.5 x 25 16 PR L2 .....	55 psi (379 kPa, 3.8 bar)
20.5 x 25 16 PR L3 .....	50 psi (345 kPa, 3.4 bar)
23.5 x 25 12 PR L2 .....	45 psi (310 kPa, 3.1 bar)
23.5 x 25 12 PR L3 .....	40 psi (276 kPa, 2.8 bar)
23.5 x25 R25 RL-2F L2.....	55 psi (379 kPa, 3.8 bar)
20.5 x R25 Michelin, all	
Recommended pressure	
Front.....	60 psi (414 kPa, 4.1 bar)
Rear.....	40 psi (276 kPa, 2.8 bar)
Pressure range	
Front.....	55 to 65 psi (379 to 448 kPa, 3.8 to 4.5 bar)
Rear.....	25 to 45 psi (172 to 310 kPa, 1.7 to 3.1 bar)


### ASSEMBLY

#### STEP 44




If any of the passage plugs were removed, install the passage plugs in the body.

#### STEP 45




Install a new O-ring in the bore for the orifice plug.

#### STEP 46




Install the orifice plug in the body.

#### STEP 47




Install the balls in the body.

#### STEP 48




Install the springs.

#### STEP 49




Install the check valve plugs.



B891453J

## INSTALLING A BRAKE CALIPER



1. Use suitable lifting equipment to install the caliper (1) on the axle (4). The weight of the caliper is approximately 90 pounds (41 kg).

2. Install the cap screws and hardened washers that hold the caliper (1) to the mounting plate on the axle (4). Disconnect and remove the lifting equipment.


3. Tighten the cap screws that hold the caliper (1) to 340 to 420 pound-feet (461 to 569 Nm).

4. Remove the plug from the brake line (3) and connect the brake line (3) to the caliper (1).

5. Install the cap screw and lock washer that fasten the clamp (2) for the brake line (3) to the axle (4). Tighten the cap screw.


6. Remove the air from the brake system according to the instructions in this section.

7. Install the wheel and tire.



8. Install the hardened washers and wheel nuts. Tighten the wheel nuts with a hand wrench. DO NOT use an impact wrench to tighten the wheel nuts.

9. Tighten the wheel nuts to 150 pound-feet (203 Nm) in the sequence shown.



B890880J


# 7002

## SPECIFICATIONS, SCHEMATIC, TROUBLESHOOTING, LEAKAGE TESTS, AND ADJUSTMENTS

### TABLE OF CONTENTS

Specifications .....	7002-2	Air Pressure Test for the Air Reservoir Relief Valve .....	7002-10
Special Tools.....	7002-2	Air Pressure Test for the Hydraulic Reservoir Relief Valve .....	7002-10
Air System Schematic - Without Air Dryer .....	7002-3	Checking and Adjusting the Pressure Setting of the Pressure Reducing Valve.....	7002-10
Air System Schematic - With Air Dryer .....	7002-4	Air Dryer Check Valve Leakage Test .....	7002-11
Machines Without Air Dryer Troubleshooting Procedures .....	7002-5	Air Dryer Safety Valve Leakage Test .....	7002-12
Machines With Air Dryer Troubleshooting Procedures .....	7002-6	Air Dryer Discharge Valve Leakage Test .....	7002-14
Brake Valve Tests.....	7002-7	Checking and Adjusting the Pressure Setting of the Governor .....	7002-16
Leakage Tests .....	7002-7		
Operating Test.....	7002-8		
Checking and Adjusting the Pressure Setting of the Pressure Protection Valve.....	7002-9		

1. LED FOR  
AIR PRESSURE




B1072A88J

4. Run the engine at 1000 rpm (r/min) until the LED for air pressure is no longer illuminated.

5. Continue to run the engine until an audible discharge of air is released from the discharge valve exhaust cover on the air dryer.


6. Run the engine at low idle for two minutes to complete the discharge cycle.

7. Apply a soap solution to and around the discharge valve exhaust.




8. There must be only a small amount of leakage.


9. If there was excess leakage in step 8, see Section 7010, disassemble and inspect the discharge valve.

**STEP 43**


Remove the O-ring from the exhaust valve.

**STEP 44**


Remove the bottom spring seat.

**STEP 45**

Remove the O-ring.

**STEP 46**

If necessary, remove the bottom spring from the housing.


**STEP 47**

If necessary, remove the wear plate from the housing.

**Inspection**


1. Discard the gaskets and O-rings.
2. Clean all parts of the air compressor in cleaning solvent.

**STEP 89**




Install a new gasket on the top of the crankcase.

**STEP 92**




Install the cover.

**STEP 90**




Install the housing.

**STEP 93**




Install the cap screws, lock washers, and flat washers that fasten the cover to the housing.

**STEP 91**




Install a new gasket on top of the housing.

**STEP 94**




Tighten the cap screws evenly to 240 pound-inches (27 Nm).

**STEP 13**




Loosen and remove the cap screw from the piston.

**STEP 14**




Remove the washer.

**STEP 15**




Remove the retainer.

**STEP 16**



Remove the diaphragm.

**STEP 17**




Remove the O-rings from the spring retainer.

## MASTER CYLINDER


### Disassembly

#### STEP 21




Fasten the mounting bracket in a vise. Loosen and remove the nuts and lock washers that fasten the air chamber to the mounting bracket and the master cylinder.

#### STEP 22



Hold the air chamber in place and remove the master cylinder.


#### STEP 23



Remove the air chamber from the mounting bracket.

Bur 8-74070

#### STEP 24




Remove the mounting bracket from the vise. Fasten the master cylinder in the vise. Remove the boot from the master cylinder.

#### STEP 25




Hold the spacer in place and remove the snap ring.


#### STEP 26




Remove the spacer.

**STEP 33**


Fasten in a vise, a punch that will fit in the bore for the plug in the piston and put the piston on the punch.

**STEP 34**


Compress the spring and remove the valve.

**STEP 35**


Remove the valve retainer and spring.

**STEP 36**

Push the valve stem against the plug to remove the plug.

**STEP 37**

Remove the valve stem.


**STEP 38**

Remove the O-ring from the plug.

# Section 7009


DISC BRAKES  
GOODYEAR

**STEP 49**




Lubricate the O-rings with clean brake fluid.

**STEP 52**



Install a new backup ring in the inner groove in the cylinder.

**STEP 50**



Install the covers.

**STEP 53**



Install a new boot in the inner groove in the cylinder. Lubricate the pistons, O-rings, backup rings and boots with clean brake fluid.

**STEP 51**




Install a new O-ring in the outer groove in each open cylinder.

**STEP 54**




Install the pistons.

**STEP 15**




Remove the piston and the spring.

**STEP 16**




Remove the spring from the piston.

**STEP 17**




Remove the O-ring from the piston. Discard the O-ring.

**STEP 18**




Remove the discharge valve.

**STEP 19**




Remove the exhaust diaphragm.

**STEP 20**




Install a new exhaust diaphragm.


3. Loosen the filler cap in the reservoir to release the air in the reservoir.



4. Connect a vacuum pump to the reservoir.





5. Loosen and remove the cap screws and hardened washers that fasten the access covers to each side of the front frame. Remove the access covers.



6. Put identification tags on the hoses and tubes that are connected to the loader control valve.

7. Start the vacuum pump. Disconnect the hoses and tubes from the loader control valve. Install a plug in each hose and tube and a cap on each fitting.



8. Stop the vacuum pump.

9. Loosen and remove the self-locking nuts, flat washers, hardened flat washers and bolts that fasten the loader control valve to the front frame. The left front bolt fastens a support bracket for the hoses to the loader control valve.

10. Have another person help you at this time. Remove the loader control valve from the front frame.


## TABLE OF CONTENTS

SPECIFICATIONS .....	2
SPECIAL TOOLS .....	3
TROUBLESHOOTING PROCEDURES .....	4
TESTING THE HYDRAULIC PUMP .....	5
Test No. 1 - Primary Pump Output Test .....	5
Test No. 2 - Secondary Pump Output Test .....	6
TESTING AND ADJUSTING THE MAIN RELIEF VALVE .....	7
CIRCUIT RELIEF VALVES .....	8
ACCUMULATOR .....	9
PRESSURE REDUCING VALVE .....	10
CONTROL PRESSURE AT THE ENDS OF THE SPOOLS IN THE LOADER CONTROL VALVE .....	11
PRESSURE CHECK FOR THE UNLOADING VALVE .....	12
HYDRAULIC PUMP .....	13
HYDRAULIC FILTER .....	14
PRESSURE REDUCING VALVE .....	15
ACCUMULATOR .....	16
REMOTE CONTROL VALVE .....	17
AUXILIARY STEERING FLOW INDICATOR (Early Production) .....	18
LOADER CONTROL VALVE .....	19
FLOW CONTROL VALVE .....	20
AUXILIARY STEERING VALVE (Early Production) .....	21
AUXILIARY SHUTTLE VALVE (Late Production) .....	22
AUXILIARY STEERING PUMP (Early Production) .....	23
AUXILIARY STEERING PUMP (Late Production) .....	24
STEERING CONTROL VALVE .....	25
BYPASS VALVE FOR OIL COOLER .....	26
UNLOADING VALVE .....	27
HYDRAULIC SCHEMATIC (Early Production) .....	29
HYDRAULIC SCHEMATIC (Late Production) .....	30

## SPECIFICATIONS


Pump output	
Primary pump (rear) .....	47.3 gpm at 2200 rpm at 2000 psi (179 L/min at 2200 r/min at 13 790 kPa, 138 bar)
Secondary pump (front) .....	30.3 gpm at 2200 rpm at 2000 psi (115 L/min at 2200 r/min at 13 790 kPa, 138 bar)
Main relief valve pressure setting	
without auxiliary steering .....	2735 to 2885 psi (18 858 to 19 892 kPa, 189 to 199 bar)
with auxiliary steering .....	2860 to 2960 psi (19 720 to 20 409 kPa, 197 to 204 bar)
Steering relief valve pressure setting .....	See Section 5002
Hand pump pressure setting for circuit relief valves .....	3100 psi (21 374 kPa, 214 bar)
Accumulator pressure .....	300 to 325 psi (2068 to 2241 kPa, 21 to 22 bar)
Pressure reducing valve pressure setting .....	525 to 575 psi (3620 to 3965 kPa, 36 to 40 bar)
Pressure setting of unloading valve .....	2100 to 2300 psi (14 479 to 15 858 kPa, 145 to 158 bar) at full throttle

## 4 ACCUMULATOR



- 1. Inlet/Outlet
- 2. Piston
- 3. Nitrogen
- 4. Charging Valve

Charged with Nitrogen



B1938A88J

**DIRECTION OF FLOW**  
Shows the direction of oil flow through the system.

**PILOT PRESSURE**  
Pressure used to control another component in the system.

**CROSSOVER LINES**


**CONNECTING LINES**

**SCREEN OR FILTER**

**OIL COOLER**

**CHECK VALVE**  
Allows oil flow in one direction only.


**CYLINDER**  
Double acting.



**HYDRAULIC SCHEMATIC**  
(Late Production)


NOTE: ANTICAVITATION VALVES AND CIRCUIT RELIEF VALVES ARE USED ON LATE PRODUCTION MACHINES ONLY

**STEP 19**




Remove the gear housing.

**STEP 20**




Remove the thrust plate.

**STEP 21**




Remove the snap ring from the drive end cover.

**STEP 22**




Remove the seal retainer.

**STEP 23**



Remove the seal from the drive end cover.


**STEP 24**



Remove the seal from the seal retainer.


## ASSEMBLING THE VALVE SECTIONS

### STEP 6



**B8979122M**


Install new O-rings in the grooves in each section.



**B8979220M**


Install the valve sections on the studs in the correct sequence.

### STEP 7




**B8979214M**

### STEP 8



**B8978405M**

Tighten the nuts to 60 to 65 pound-feet (81 to 88 Nm).



**B8979220M**

8005-20

## Inspection

Clean all parts in cleaning solvent.


Inspect the spool for wear and damage. Inspect the springs for damage to the threads and inspect the threads in the ends of the spool for damage.

Inspect the spool bores for wear and damage. Inspect all machined surfaces for wear and damage.


Inspect the poppet and poppet seat for wear and damage. Inspect the spring for the poppet for damage.

### STEP 109

If necessary, remove the screen from the poppet.




a. Carefully remove the retaining ring.




b. Remove and discard the screen.

### STEP 110



Remove and discard the O-rings and backup ring from the body.


### STEP 111



**B8978722M**

Remove and discard the O-rings and backup ring from the adapter.

### STEP 112




**B6930688M**

Remove and discard the O-ring from the adjusting screw.

## Inspection

Clean all parts in cleaning solvent.

Inspect the spacer, poppet, screen, sleeve, and retaining ring for wear and damage. Inspect the plunger and seat for wear and damage. Inspect the springs for damage. Inspect all machined surfaces for wear and damage. Use new parts as required.



Circuit Relief Valve, Cross Section View

B892670J


## BUCKET AND LIFT CYLINDERS

### Disassembly

Clean the outside of the cylinder. If the hoses were removed with the cylinder, remove the hoses from the cylinder.

1. Fasten the tube (1) in an acceptable repair stand or other holding equipment. Do not damage the tube (1).
2. Loosen and remove the cap screws (2) and hardened washers (19) from the gland (3) and the tube (1).
3. Pull the piston rod (4) straight out of the tube (1) to prevent damage to the tube (1).
4. Fasten the piston rod eye or yoke in a vise and put a support under the piston rod (4) near the piston (8). Put a shop cloth between the support and the piston rod (4) to prevent damage to the piston rod (4).
5. Remove the retaining ring (12) that fastens the pin (11) in the piston (8) and piston rod (4).
6. Remove the pin (11) from the piston (8) and piston rod (4).
7. Turn the piston (8) off the piston rod (4) and remove the piston (8).
8. Remove the gland (3) from the piston rod (4).
9. Remove the seal (6) from the OD of the piston (8). On lift cylinders, there is also a backup ring (7). If you are disassembling a lift cylinder, remove this backup ring (7).
10. Remove the wear ring (5) from the OD of the piston (8).
11. Remove the backup rings (9) and the O-ring (10) from the ID of the piston (8).
12. Remove the O-ring (17), backup ring (16), wiper (13), wide seal (14), narrow seal (15), and bushing (18) from the gland (3).
13. See Inspection on page 3.


**STEP 7**



727228

Make marks on the body and plate.


**STEP 8**



727230

Loosen and remove the two Allen screws that fasten the plates to the body.


**STEP 9**



727302

Remove the plates from the body.


**STEP 10**



727304

Remove the posts from the body.


**STEP 11**



727308

Some control valves use shims between the body and posts. If equipped, remove the shims from the body.


**STEP 12**



727314

Remove the plunger assembly.


**STEP 62**



727636

Install the Allen screw and nut to fasten the coil to the plate. Tighten the Allen screw to 20 to 25 pound-inches (2.2 to 2.8 Nm).


**STEP 63**



727624

Bend the side of each terminal out and install the terminals into the connectors as shown above.

**STEP 64**



727614

Install the lever assembly in the metal plate.


**STEP 65**



727612

Install the metal plate and lever assembly on the plastic plate with the marks aligned.


**STEP 66**



727606

Install the sleeve in the body. The shoulder in the I.D. of the sleeve must be down.

**STEP 67**



727602

Install the spring.

## ACCUMULATOR

The accumulator must be discharged before the accumulator is disassembled.

### Discharging the Accumulator

1. Fasten the accumulator in a vise with soft jaws. Be careful not to damage the tube (1).
2. Loosen and remove the cap screws (2) and the protection bracket (3) from the gland (4).
3. Loosen and remove the cap (5) from the valve (6).

**NOTE:** *The pressure in the accumulator can be approximately 325 psi (2241 kPa, 22.4 bar). Make sure that the valve (6) end of the accumulator is away from you when discharging the accumulator.*

4. Use a small punch to push the valve core (7) in. Hold the valve core (7) in until all pressure is removed from the accumulator.

### Disassembly

1. Use the gland wrench to slowly loosen and remove the gland (4) from the tube (1).
2. Use a punch and push the piston (8) from the tube (1).
3. Remove the gland seal (10) from the gland (4).
4. Fasten the gland (4) in a vise with soft jaws. Be careful not to damage the gland (4).
5. Loosen and remove the valve core (7) from the valve (6).
6. Loosen and remove the valve (6) from the gland (4).
7. Remove the O-ring (9) from the valve (6).
8. Remove the wear rings (11 and 12) from the piston (8).
9. Remove the piston seal (13) from the piston (8).

### Inspection

1. Discard the O-ring (9), gland seal (10), wear rings (11 and 12), and the piston seal (13).
2. Clean all parts in cleaning solvent.

3. Illuminate the inside of the tube (1). Inspect the inside of the tube (1) for deep grooves and other damage. If there is damage to the tube (1), a new tube (1) must be used. Remove small scratches inside the tube (1) with emery cloth of medium grit. Use the emery cloth with a rotary motion.

4. Inspect the piston (8) for wear or damage that can cause nitrogen or oil leakage. Use a new piston (8) as required.


5. Inspect the gland (4) for wear or damage that can cause nitrogen leakage. Use a new gland (4) as required.

6. Inspect the valve (6) for wear or damage that can cause nitrogen leakage. Use a new valve (6) as required.


7. Inspect the valve core (7) for wear or damage that can cause nitrogen leakage. Use a new valve core (7) as required.


### Assembly

1. Install a new piston seal (13) on the piston (8).
2. Install new wear rings (11 and 12) on the piston (8).
3. Lubricate the bore in the tube (1), the wear rings (11 and 12), and the piston seal (13) on the piston (8) with clean oil.
4. Push the piston (8) straight into the tube (1).
5. Fasten the valve (6) in a vise with soft jaws.
6. Install the valve core (7) in the valve (6). Tighten the valve core (7) to 1.5 to 2.0 pound-inches (0.170 to 0.226 Nm).
7. Install the cap (5) on the valve (6).
8. Install a new O-ring (9) on the valve (6).
9. Lubricate the O-ring (5) on the valve (6) with clean oil.
10. Install the valve (6) in the gland (4). Tighten the valve (6) to 65 to 75 pound-feet (88 to 102 Nm).
11. Install a new gland seal (10) on the gland (4).
12. Lubricate the gland seal (10) on the gland (4) with clean oil. Apply antisieze compound to the threads on the gland (4).



Indications of a Problem in Condensor Operation (Continued)





- 1. Compressor
- 2. Hose
- 3. O-ring
- 4. Wire

- 5. Adjusting Rod
- 6. Nut
- 7. Bolt
- 8. Spacer

- 9. Rear Bracket
- 10. Front Bracket
- 11. Pivot Bolt
- 12. Adjusting Block


Compressor

B910511J

## REPLACING THE COIL OR CLUTCH ASSEMBLY

**NOTE:** *Special tools are from kit CAS-10747 shown on page 3.*


### STEP 1



B414307M

Fasten the compressor in a vise. Loosen and remove the three cap screws and lock washers from the cover on the clutch. Remove the cover. Loosen and remove the nut that holds the clutch plate.


### STEP 2



B414308M

Install the puller for the clutch plate.

### STEP 3



B414309M

Remove the clutch plate.


### STEP 4



B414313M

Remove the shield from the bore of the pulley. Remove the Woodruff Key.


### STEP 5



B414314M

Remove the large snap ring.

### STEP 6



B414315M

Remove the small snap ring.

# Section


# 9005

## LOADER

9005

## BUCKET HEIGHT CONTROL ADJUSTMENT


### STEP 28



B4191789M

Park the machine on a level surface and lower the loader frame so the bucket is flat on the floor.


### STEP 31



96589

Remove the cover.


### STEP 29



E042288M

Stop the engine and apply the parking brake.


### STEP 32



B4195489M

Start the engine and raise the loader frame until the rear actuator is even with the bucket height control switch. Stop the engine. Connect a chain hoist to the cross-member of the loader frame.


### STEP 30



B4196669

Loosen and remove the screws and hardened washers that fasten the cover.

### STEP 33



B4195989M

Loosen the nuts for the switch and adjust the nuts so there is 1/8 to 3/16 inch (3.2 to 5.0 mm) clearance between the switch and the actuator. Hold the switch in position and tighten the nuts.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL