

MAXXUM 110 EP
MAXXUM 115 EP
MAXXUM 120 EP
MAXXUM 125 EP
MAXXUM 130 EP
MAXXUM 140 EP
MAXXUM 110 Multicontroller EP
MAXXUM 115 Multicontroller EP
MAXXUM 120 Multicontroller EP
MAXXUM 125 Multicontroller EP
MAXXUM 130 Multicontroller EP
MAXXUM 140 Multicontroller EP
MAXXUM CVT 110
MAXXUM CVT 120
MAXXUM CVT 130
Tractor

SERVICE MANUAL

Part number 47665857

English

February 2014

Copyright © 2014 CNH Industrial Österreich GmbH. All Rights Reserved.

CASE II
AGRICULTURE


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



80736 1


Tightening sequence for 4 cylinder head bolts



80362 2


Tightening sequence for 6 cylinder engine cover nuts

38. Cut the cable ties securing the wiring loom to the air cleaner mounting frame.




BAIL07APH132AVA 38

39. Disconnect the grid heater electrical connector.




BAIL07APH140AVA 39

40. Disconnect the water-in-fuel sensor electrical connector.



BAIL07APH133AVA 40


41. Detach the wiring loom from the intake manifold.



BAIL07APH134AVA 41


35. Attach the grid heater fuseable link.

1. Install the retaining bolt.
2. Attach the retaining clips.



BAIL13TR00771AB 34

36. Connect the heater hose to the rear of the cylinder head.




BAIL12APH145AVA

BAIL12APH145AVA 35


37. Connect the wiring harness to the alternator.

1. Connect the electrical connectors.
2. Install new cable ties.



BAIL13TR00770AB 36

38. Connect the starter motor negative cables.



BAIL13TR00769AB 37

Fuel tank - Install

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

⚠ WARNING


Personal Protective Equipment (PPE) required.

When assembling, operating, or servicing the machine, wear protective clothing and PPE necessary for the particular procedure. Some PPE that may be necessary includes protective shoes, eye and/or face protection, hard hat, heavy gloves, filter mask, and hearing protection.

Failure to comply could result in death or serious injury.

W0353A


1. Using suitable lifting equipment and the assistance of another technician, raise the fuel tank to engage the hooking mechanism and install the fuel tank.



BAIL12APH040AVA

BAIL12APH040AVA 1


2. Install the fuel tank support bolt.



BAIL12APH036AVA


BAIL12APH036AVA 2

4. Remove the SCR muffler and catalyst upper front cover.




BAIL12APH085AVA 3

5. Remove the SCR muffler and catalyst upper rear cover retaining bolt. Detach the NOX sensor wiring harness from the cover. Remove the SCR muffler and catalyst upper rear cover.




BAIL12APH086AVA 4

6. Remove the SCR muffler and catalyst lower cover.



BAIL12APH087AVA 5

7. Remove the exhaust pipe clamp shield.



BAIL12APH006AVA 6


Coolant control valve - Remove

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

Prior operation:


Drain the coolant system, for further information refer to **Engine cooling system - Drain fluid (10.400)**.

1. Disconnect the Selective Catalytic Reduction (SCR) coolant control valve electrical connector.




BAIL12APH025AVA 1

2. Disconnect both coolant line connectors from the SCR coolant control valve.




BAIL12APH026AVA 2

3. Remove the SCR coolant control valve.




BAIL12APH027AVA 3

18. Connect the oil cooler hoses.



BAIL13TR00810AB 18


19. Install the right-hand air intake pipe.



BAIL12APH179AVA

BAIL12APH179AVA 19


20. Install the left-hand air intake pipe.



BAIL12APH178AVA

BAIL12APH178AVA 20

21. Install the right-hand front fender.



BAIL13TR00809AB 21

Contents

Transmission - 21

| | |
|---|-------|
| [21.112] Power shuttle transmission..... | 21.1 |
| [21.134] Power shuttle transmission external controls | 21.2 |
| [21.154] Power shuttle transmission internal components | 21.3 |
| [21.111] Semi-Powershift transmission | 21.4 |
| [21.133] Semi-Powershift transmission external controls | 21.5 |
| [21.103] Semi-Powershift transmission lubrication system..... | 21.6 |
| [21.152] Semi-Powershift transmission internal components | 21.7 |
| [21.504] Continuously Variable Transmission (CVT) | 21.8 |
| [21.505] Continuously Variable Transmission (CVT) external controls..... | 21.9 |
| [21.506] Continuously Variable Transmission (CVT) lubrication system | 21.10 |
| [21.507] Continuously Variable Transmission (CVT) internal components | 21.11 |
| [21.160] Creeper | 21.12 |
| [21.166] Overdrive..... | 21.13 |

Power shuttle transmission - Remove

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

Prior operation:

Remove the cab - see **Cab - Remove (90.150)**.

Remove the fuel tank - see .

Separate the engine and front support from the transmission - see .

⚠ WARNING

Heavy objects!

Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders.

Failure to comply could result in death or serious injury.

W0398A

⚠ WARNING


Avoid injury!

Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A


1. Disconnect the wiring harness as required to enable the separation of the transmission from the rear axle.
2. Remove the battery tray swivel pin (1) and remove the battery tray and battery.



BVE0342A

BVE0342A 1

5. Loosen the range shift cable adjustment nuts.




BVF1104A 4

6. Move the range shift cable (3) to equally distribute the freeplay until the range lever in the cab is in the position shown.
Tighten the adjustment nuts (1) and (2).


NOTE: Ensure the range lever in the cab is still located in the detent position.

NOTE: Ensure the range shift lever in the cab is not obstructed by the console when selecting a gear.




BVF1105A 5

7. Loosen the main shift selection cable adjustment nuts.



BVF1106B 6

8. Move the main shift selection cable (3) to remove the freeplay until the main shift lever in the cab is in the position shown.
Tighten the adjustment nut (1) to the bracket and tighten the adjustment nut (2).



BVF1107B 7

Clutch Range clutch - Disassemble (C1/C2)

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

Prior operation:

Clutch Range clutch - Remove (21.154)

⚠ WARNING


Avoid injury!

Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.


W0208A

1. Remove the lubrication oil supply tube (1)



BSF4632A 1

2. Remove the lubrication control valve block.




BSF4635A 2

| | |
|------------------------------|----------------------------|
| Main synchronizer 1-4, 5-8 | 0.5 mm (0.0197 in) |
| Forward/Reverse synchronizer | 0.8 mm (0.0315 in) |
| Hi/Lo synchronizer | 0.85 mm (0.0335 in) |

NOTE: The driveline oil specification and capacity is described in **Consumables ()**.

Semi-Powershift transmission - Torque


| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |



BVE0599A_49 1

Gear Selector Switches.

The upshift switch (1) and downshift switch (2) allows the operator to change between 8 basic ratios by sending a signal to the controller, without using the clutch pedal.




BSE2889C 16

Parking Brake Switch.

The parking brake has to be applied during calibration, if it is not applied an error code will be displayed.


The tractor will drive if the handbrake is applied but an audible alarm will be heard.



BRF1854B 17

Seat Switch.


The seat switch must be operated, i.e. operator seated, before the controller allows the engagement of the forward or reverse drive.



BRF1851B_263 18


NOTE: The clutch pedal will override a faulty seat switch.

26. Disconnect the differential lock oil pipes.




BAIL12APH066AVA 26

27. Remove the accumulator oil pipe.




BAIL12APH067AVA 27

28. Remove the differential lock pipe retaining bracket.



BAIL12APH068AVA 28

29. Remove the differential lock oil supply pipe and disconnect the trailer brake oil supply pipe.



BAIL12APH069AVA 29

Semi-Powershift transmission - Testing The tractor drives in all gears and in all ranges but has the following fault:

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

NOTE: - Transmission is noisy in operation

| N° | Test Point | Expected Result | Other Result (Possible Cause) |
|----|--|---|---|
| 1 | Condition Is the transmission lube warning light illuminated? | Result YES Action Go to test 2 | Action NO Go to test 3 |
| 2 | Condition Fault in the lube supply to transmission. Refer to Hydraulic Pressure Testing Transmission lubrication valve - Pressure test (21.103) . Is the transmission noisy after lube system repair? | Result YES Action Go to test 3 | Action |
| 3 | Condition Is the oil level correct? | Result YES Action Go to test 4 | Action NO Adjust as required and investigate reason for oil loss (leakage) |
| 4 | Condition Is the correct grade of oil used? | Result YES Action Suspect failure within transmission, worn bearings, worn or failed parts | Action NO Drain and refill with correct grade of oil |


Semi-Powershift transmission - Testing - Tractor drives in all gears and ranges but has the following fault:

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

NOTE: - Transmission clunks during inching.

| N° | Test Point | Expected Result | Other Result (Possible Cause) |
|----|---|---|-------------------------------------|
| 1 | Condition Perform Clutch spring calibration on C1 and C2 Clutches. Does Transmission still clunk? | Result YES Action Go to test 2 | Action NO Tractor okay |


5. Remove the front cover plate (1) and the O-rings (2).



BVE0705A 6


6. Remove the baffle plate (1) and the front roller bearing (4) from the front lower support shaft (3).
Remove the needle roller bearing (2).

NOTE: The front roller bearing (4) and the baffle plate (1) may remain in the front cover plate.




MMG 21 407 7

7. Remove the C1/C2 clutch (3), output gear (2) and the front lower support shaft (1).



BSF4023A 8

8. Remove the PTO/input shaft (1).



BVE0648A 9

Transmission internal controls - Travel adjust


| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

1. ADJUSTMENT OF FORWARD/REVERSE AND MAIN (1-4/5-8) SYNCHRONISERS

To gain access to the synchronizer forks and rails it is necessary to remove the cab mat and floor.

Remove the transmission cover plate to expose the shift rails (1) and forks (2).


The adjustment procedure is the same for both synchronisers.



BSF4019C

BSF4019C 1


2. Remove the detent spring, plunger and ball from the transmission cover.



BAIL09APH296AVA

BAIS09APH296AVA 2

3. Insert the special tool **380002598** into the plunger bore and position the tip of the special tool into the 2mm bore hole in the selector rail, midway between the forward and reverse detent positions. This will centralize and lock the selector rail in the neutral position.



BAIS09APH297AVA

BAIS09APH297AVA 3


4. Remove the two locking screws fixing the selector fork to the selector rail.

Continuously Variable Transmission (CVT) - Exploded view – Solenoid valves, sensors, hydraulic lines

| | |
|----------------|-----|
| MAXXUM CVT 110 | INT |
| MAXXUM CVT 120 | INT |
| MAXXUM CVT 130 | INT |


| Components | | | |
|------------|---|------------|---|
| 201 | O-Ring | 202 | Retainer Ring |
| 203 | Hydraulic tube | 204 | Retainer Ring |
| 205 | O-Ring | 206 | Hydraulic tube |
| 207 | Hydraulic tube | 208 | Hydraulic tube |
| 209 | Hydraulic tube | 210 | Bolt |
| 211 | O-Ring | 212 | O-Ring |
| 213 | Link | 214 | O-Ring |
| 215 | Retainer Ring | 216 | Cover cup |
| 217 | seal | 218 | seal |
| 219 | Pistons | 220 | seal |
| 221 | seal | 222 | Bolt |
| 223 | Bolt | 224 | Housing |
| 225 | Spool | 226 | Retainer Ring |
| 227 | Shimming | 228 | Spring |
| 229 | Spring | 230 | Screw plug |
| 231 | Filter | 232 | Bolt |
| 233 | O-Ring | 234 | O-Ring |
| 235 | Charge pressure sensor for the transmission | 236 | Temperature sensor for the transmission |
| 237 | O-Ring | 238 | Bolt |
| 239 | Valve block | 240 | O-Ring |
| 241 | Pressure sensor for clutch A | 242 | O-Ring |
| 243 | Pressure sensor for clutch B | 244 | O-Ring |
| 245 | Accumulator | 246 | Clutch A solenoid valve |
| 247 | Clutch B solenoid valve | 248 | Emergency-drain solenoid valve |
| 249 | O-rings | 250 | Solenoid valve for shift cylinder R1 |
| 251 | Solenoid valve for shift cylinder F2 | 252 | Bracket |
| 253 | Bracket | 254 | Bolt |
| 255 | cap | 256 | Fitting |
| 257 | O-Ring | 258 | Bolt |
| 259 | O-Ring | 260 | Pressure sensor for the transmission |
| 261 | Dowel pin | 262 | Seal |
| 263 | Dowel pin | 264 | Filter head |
| 265 | O-Ring | 266 | Blank Plug |
| 267 | Blank Plug | 268 | 'Neutral' Pressure Switch Restrictor. |
| 269 | Blank Plug | 270 | Blank Plug |
| 271 | Blank Plug | 272 | Blank Plug |
| 273 | Blank Plug | 274 | Bolt |

32. 1. Install the front brake valve block.
2. Connect the front brake pipe to the front brake valve block.




BAIL13TR01010AB 31

33. Connect the battery isolator electrical connector.




BAIL13TR01009AA 32

34. Attach the isolator bracket to the battery tray.



BAIL13TR01008AB 33

35. Install the battery tray cover.



BAIL13TR01007AB 34

Valve block - Install

| | |
|----------------|-----|
| MAXXUM CVT 110 | INT |
| MAXXUM CVT 120 | INT |
| MAXXUM CVT 130 | INT |

Continuously Variable Transmission (CVT) - Exploded view – Transmission output (21.504)


Continuously Variable Transmission (CVT) - Exploded view – Solenoid valves, sensors, hydraulic lines (21.504)

Prior operation:

Valve block - Assemble (21.505)

NOTE: If you removed the plugs from the housing or from the cover, perform the following steps. Coat the plugs with **LOCTITE® 243**. Install the plugs.

1. Push the piston (**219**) all the way into the shift cylinder.
2. Insert the dowel (**263**).




SS10F172 1

3. Shift the shift fork (**162**) into shift position **F2** (forward).
4. Install a new O-ring (**205**) on the supply line (**203**).

NOTE: Grease the O-rings with industrial Vaseline.

5. Insert all connectors (**213**) with new O-rings (**214**) into the housing.

NOTE: Grease the O-rings with industrial Vaseline.




SS10F224 2

6. Degrease the sealing surfaces. Apply **LOCTITE® 5205** evenly on the sealing surface on the valve block.
7. Apply **LOCTITE® 5205** evenly on the sealing surface on the valve block.


NOTE: When you apply the **LOCTITE®**, make sure that the oil holes remain free.

21. Fit the end plate (134).
22. Use a suitable tube (X) to press the end plate (134) downward.
23. Fit the circlip (135).



SS10F144 11

24. Fit the bearings (104) and the spacer ring (106).
25. Fit circlip (107).




SS10F154 12

26. Fit the tooth gear (inner disk carrier) (105).

NOTE: Rotate the tooth gear (inner disk carrier) (105) during the installation.


27. Fit the ring (103).
28. Use a suitable positioning tool to fit the bearing (102).



SS10F156 13


29. Screw the nut (101) onto the shaft.

NOTE: The nut (101) will tighten through torque at a later stage.



SS10F132 14


4. Install the creeper coupler assembly (2) and install the retaining ring to the pinion shaft (1).



BVE0366A 4


5. Position the creeper gear (2). Loosely install two M8 x 1.25 x 50 bolts (1) to support the creeper gear. Remove the creeper gear (2).

NOTE: Make sure the creeper gear is in the correct position so the open ends of the retaining ring can be seen.




BVE0356A_367 5

6. Install the creeper shaft (1) and the retaining ring (2).




BVE0364B 6

7. Remove the creeper gear support bolts (1).



BVE0363A 7

12. Install the 17th gear clutch supply pipe (1).




BVF0995A 11

13. Install the PTO torque sensor pick up disc.


NOTE: Use a suitable bar to hold the PTO torque sensor pick up disc.

NOTE: Apply **LOCTITE® 243** onto the retaining bolt threads.



BVE0331A_381 12


14. Install the PTO torque sensor (1).



BVE0330A_380 13


15. Install the lower link support to the rear axle housing taking the following into consideration:

- Thoroughly clean and degrease the mating surfaces and apply a bead of liquid gasket of approximately **2 mm (0.079 in)** in diameter to the rear axle housing. Install the lower link support. Tighten the retaining bolts to the specified torque value.



BVE0357B_383 14

14. Stake the retaining nut (1).




BVF0965A 14

Next operation:

Install the clutch - see **Front-Wheel Drive (FWD) clutch - Install (23.202)** .


Powered front axle - Torque

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |



BVE0625B 1

7. Slide out the air conditioning condenser from the radiator and reposition with the hoses still attached.




BVE0257B

BVE0257B 7

All Tractors


8. Loosen the hose clamps (1) and disconnect the coolant hoses from the radiator. Remove the radiator support (2).



BVE0258A

BVE0258A 8

9. Loosen the hose clamp (1) and disconnect the coolant hose.




BVE0321A

BVE0321A 9

Bevel gear set and differential carrier - Preload (Standard Class 4 Axle)


| | |
|-------------------------------|-----|
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

1. Install the inner bearing (1) onto the pinion shaft.




BAIL09APH213AVG 1

2. Using a suitable depth gauge micrometer, measure the distance from the top of the pinion shaft to the shoulder to obtain measurement (L).



BAIL08APH161AVA 2


3. Using a suitable micrometer, measure the thickness of the pinion nut to obtain measurement (G).



BAIL08APH164AVA 3

4. Using a depth micrometer, measure the distance (H1) between the upper surface of the special tool and the central threaded pin of the special tool **380000248/380000463 (1)**.

Disassemble the above parts, lubricate the bearings with oil and then re-assemble the parts, excluding the bearing spacer, in the differential housing.



40-25-26 SHG 3


5. Tighten the nut of the special tool **380000248/380000463 (1)**, while turning the special tool to ensure that the bearings are seated correctly. Install spacer for Suspended front axle. Using a depth micrometer, measure distance (H2).

The thickness of the adjustment shim required is calculated by:

$$\text{Shim } S1 = H2 - H1 + 0.05 \text{ mm}$$

If necessary, round the value obtained up to the nearest **0.05 mm**.

Leave the special tool in the differential housing for the pinion depth measurement.



40-25-34 SHG 4

Pinion To Crown Wheel Shimming Procedure

6. The pinion to crown wheel shimming procedure calculates the thickness of shims S2, positioned beneath the shoulder of the pinion gear to ensure that the theoretical conical point of the pinion aligns with the centre of the differential crown wheel.

Pinion Shimming Dimensions


7. H4 Dimension from Pinion Bearing to Centre line of Differential Casing

H3 **115 mm** Manufacturers Pinion Dimension $\pm C$ (Correction Factor) or **122.5 mm $\pm C$** for class IV axles

S2 Shim Thickness


The dimension H4 in the calculation of the shim thickness can be determined using the pinion adjustment special tool **380000249**

Both procedures are explained as follows.



40-25-42 SHG 5


22. Install the front wheel.
Tighten the wheel nuts to the specified torque, for further information refer to **Front wheels - Torque (44.511)**.



BAIL07APH064AVA

BAIL07APH064AVA 23


23. Using suitable lifting equipment install the front weights.



BAIL07APH062AVA

BAIL07APH062AVA 24

24. Install the retaining bolts to the front weights.




BAIL07APH063AVA

BAIL07APH063AVA 25

Suspended axle control valve - Overview

| |
|----------------|
| MAXXUM CVT 110 |
| MAXXUM CVT 120 |
| MAXXUM CVT 130 |


| |
|-----|
| INT |
| INT |
| INT |



BAIL13TR00736FB 1


- | | |
|------------------------|--|
| 1. Return to tank pipe | 2. Load sensing pipe |
| 3. Pressure feed | 4. Raise/Lower coils |
| 5. Lockout coils | 6. Piston feed |
| 7. Rod feed | 8. Accumulator 1 l Pre charge 19.0 - 21.0 bar (275.5 - 304.5 psi) |

36. Remove the PTO ground drive selector shaft retaining bolts.




BVE0391A 36

37. Remove the PTO ground drive selector shaft and remove the selector fork from the rear axle housing. Remove the detent plunger and spring (1).



BVE0392A 37

38. Remove the internal PTO clutch oil supply cut off valve (1).




BVE0393A 38

Next operation:


Connect the transmission to the rear axle, for further information refer to **Semi-Powershift transmission - Connect (21.111)**

Differential lock Dog clutch - Dynamic description

| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |



SS09D218 1



A - Trapped oil (Rear differential lock disengaged)

B - Pressure oil (Rear differential lock engaged)

Final drive housing - Install

| | |
|------------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |
| MAXXUM CVT Tier IV Efficient Power | INT |

Prior operation:


Driving wheel shaft - Adjust (27.120)

⚠ WARNING ⚠

Lift and handle all heavy components using lifting equipment of appropriate lifting capacity. Make sure that units or parts are supported by suitable slings or hooks. Make sure that no-one is in the vicinity of the load to be lifted. Failure to comply could result in serious injury or death.


B012

1. Install the friction disc (3), steel plate (2) and the outer ring gear (1).



BVE0350A 1


2. Install Special tool **380001113** and install the final drive assembly together with the half-shaft.




BVE0349A 2

8. Remove the split pin (1), remove the upper retaining pin (2) and remove the automatic pick-up hitch lift rod.

NOTE: Repeat this step for the right-hand side.




9. Disconnect the extending drawbar hydraulic supply and return pipes.




10. Support the extending drawbar and remove the retaining bolts.

NOTE: Repeat this step for the right-hand side.



11. Remove the extending drawbar assembly.
12. Disconnect the power take off (PTO) speed sensor electrical connector.




2. Install the power take off (PTO) housing.



WARNING

Always use suitable tools to align holes. **DO NOT USE HAND OR FINGERS.**


B020



BAIL07APH485BVA

BAIL07APH485BVA 2


3. Remove the support from the PTO housing.
Tighten to **211 Nm (155 lb ft)**.



BAIL07APH484AVA

BAIL07APH484AVA 3

4. Install the top central PTO housing retaining bolt.
Tighten to **211 Nm (155 lb ft)**.



BAIL07APH483AVA

BAIL07APH483AVA 4

Front Power Take-Off (PTO) housing - Install


| | |
|------------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |
| MAXXUM CVT Tier IV Efficient Power | INT |

⚠ **WARNING** ⚠


Handle all parts carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing - safety goggles, gloves and shoes.

B026

1. Install the PTO reduction gearbox and the retaining bolts. Tighten the retaining bolts to the specified torque value.



2. Install the PTO rear retaining bolt. Tighten to the specified torque value.




| | |
|--|----|
| Disassemble | 25 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT, MAXXUM CVT Tier IV Efficient Power --- INT | |
| Assemble | 27 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT, MAXXUM CVT Tier IV Efficient Power --- INT | |
| Install | 29 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT, MAXXUM CVT Tier IV Efficient Power --- INT | |

DIAGNOSTIC

Parking brake or parking lock

| | |
|--|----|
| Troubleshooting | 32 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT, MAXXUM CVT Tier IV Efficient Power --- INT | |


7. Install the inner brake disc into the ring gear.



BRB0162A

BRB0162A 7


8. Install the friction disc drive plate onto the driveshaft.



BRB0161A

BRB0161A 8


9. Install the friction disc.



BRB0160A

BRB0160A 9

10. Install the outer brake disc into the ring gear.




BRB0159A

BRB0159A 10

PARKING BRAKE ENGAGEMENT TEST (ITALIAN TRAILER BRAKES ONLY)

14. Insert fitting **380000550 (1)** in trailer brake coupler and connect it to a **0 - 40 bar (0 - 580 psi)** pressure gauge **380000552**, using the quick release coupler **380000543** and the hose **380000545**.




BVE0169A 4

15. With engine and oil in the conditions described at the beginning of this chapter, fully raise parking brake control lever.
16. Check if pressure is **0 bar (0 psi)** and light indicator is on.
17. If the pressure is not **0 bar (0 psi)** check the system as described in **Trailer brake valve - Troubleshooting (Italian Trailer brake) (33.220)**.
18. With the parking brake engaged disconnect pressure gauge and fitting **380000550 (1)**.

TRAILER BRAKE CIRCUIT SAFETY SWITCH TEST (ITALIAN TRAILER BRAKES ONLY)


19. Insert fitting **380000550 (1)** in trailer brake coupler and connect it to a **0 - 40 bar (0 - 580 psi)** pressure gauge **380000552**, using the quick release coupler **380000543** and the hose **380000545**.



BVE0169A 5


20. With the parking brake OFF and tractor brakes not applied, operate and hold the remote control valve lever and allow the system pressure relief valve to operate.
Keep this position for a few seconds and quickly release the control lever.
21. Check if parking brake disengagement pressure remains at the specified value between **11 - 12 bar (160 - 174 psi)**.
22. If the pressure is not **11 - 12 bar (160 - 174 psi)** check the system as described in **Trailer brake valve - Troubleshooting (Italian Trailer brake) (33.220)**.

8. Disconnect the balance pipe from the left-hand air tank.



BAIL07APH202AVA 6


9. Remove the left-hand air tank.



BAIL07APH204AVA 7


Right-hand air tank

10. Disconnect the electrical connector and the supply pipe.




BAIS06CCM650AVA 8

11. Disconnect the balance pipe from the right-hand air tank (1) loosen the air tank retaining nut (2) and remove the right-hand air tank.




BAIS06CCM648AVA 9




BSE2928A 8

Closed centre electro hydraulic remote valves (1) have a maximum **100 l/min** flow capacity per slice . The valve slices are available in either 3 or 4 valve configurations



BAIL10CVT038AAB 9

Mechanical remote valves have a flow of **72 - 80 l/min** depending on the operational pressure. The valves are used to operate external hydraulic cylinders, motors etc. Up to four remote control valves may be installed and are located at the rear of the tractor. All remote valves incorporate an automatic lock valve in the left- hand (raise) port to prevent inadvertent leak down of the implement.



BSE3664A 10


| Number of valves | Configuration |
|------------------|-------------------------------------|
| 2 | 2 Non Configurable |
| 2 | 2 Configurable |
| 3 | 1 Non Configurable + 2 Configurable |
| 4 | 2 Non Configurable + 2 Configurable |

All units have the option for ISO power beyond coupling.

5. 1. Raise the front of the vehicle.
 2. Remove the axle stands.
 3. Lower the front of the vehicle.
6. Check the transmission oil level.

Vehicles with standard axles

7. Remove the wooden wedges from between the front axle and front support.



BAIL07APH285AVA 5


Vehicles with suspended axles

8. Calibrate the front axle, for further information refer to **Electronic module Universal controller - H1 - Calibration procedures (55.640)**.

Next operation:

In stall the aftercooler, for further information refer to **Aftercooler - Install (10.310)**.


10. Install a **180 l/min (47.55 US gpm)** flow meter between the remote control valves number 1 and number 2. Ensure the inlet hose of the flow meter is installed into the extend port of valve number 1. Fully open the load valve on the flow meter. Set the hydraulic oil flow to maximum.



BVE0158A


BVE0158A 10

11. Set the remote control valve number 2 in the 'Float' position. Set the remote control valve number 1 in the 'Extend' position. Set the engine speed to **1500 rev/min** to observe the system operation pressure or **2200 rev/min** for the maximum system pressure.



BVE0159A

BVE0159A 11



BAIL09CCM090AVA

BAIL09CCM090AVA 12

12. Move the remote control valve lever for the remote control valve number 1 between the extend and neutral position.
13. The following pressures should be observed:
 • **2.1 - 2.9 bar (30.5 - 42 psi)**
 If the pressure reading is below **2.1 bar (30.5 psi)**, replace the hydraulic oil filters and re-test. If after re-test the charge pressure is still below the specification, check the supplementary lube valve, examine both the charge pressure filter dump valve and the charge pressure relief valve before disassembling the hydraulic oil pump to inspect for wear.

Single Remote Control Valve Operation - Lowering (Cylinder Retract)

- | | |
|--|---|
| 1. Flow Control Spool | 2. Metering Land |
| 3. Flow Control Adjuster | 4. Manually Adjusted Flow Control Restriction |
| 5. Spool Centring and Detent Mechanism | 6. Lower (Cylinder Retract) Port |
| 7. Raise (Cylinder Extend) Port | 8. Lock Valve |
| 9. Pin | 10. Main Control Spool |
| 11. Load Hold Check Valve | |



Pump Pressure




Return To Reservoir



Remote Valve Operating
Pressure

Mid-mount remote control valve Electrohydraulic remote valve - Static description

| | |
|-------------------------------|-----|
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 Multicontroller EP | INT |



BAIL11APH206AFB 1

- | | |
|------------------------------|----------------------|
| 1. Load Sensing Hose | 2. Pilot Return Line |
| 3. Pilot Line Pressure Hose | 4. Return Hose |
| 5. High Pressure Supply Hose | |

Tractors equipped with the Mid Mount Valve option are fitted with an armrest mounted joystick, a mid mount valve assembly, plumbing and loader mounting brackets ready for attaching the loader arms.

The Mid Mount Valve assembly is located underneath the cab on the right hand side. The base version has a two spool valve for raising and lowering the boom and tipping and curling the bucket when used with a loader. Three and four valve options are also available.

The valves are operated by means of a joystick control mounted on the right hand armrest of the seat. For front loader operation an electronic joystick is utilised with a push button switch **(1)** mounted on the top side of the handle and a proportional paddle switch **(2)** mounted on the side of the handle for EHR control.

Index

Hydraulic systems - 35

Auxiliary hydraulic pump and lines - 220

| | |
|--|---|
| Auxiliary hydraulic pump - General specification | 3 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |
| Auxiliary hydraulic pump - Install | 8 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |
| Auxiliary hydraulic pump - Overhaul | 5 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |
| Auxiliary hydraulic pump - Remove | 6 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |
| Auxiliary hydraulic pump - Torque | 3 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |



Frames and ballasting - 39

Frame - 100

**MAXXUM 110 EP , MAXXUM 110 Multicontroller EP , MAXXUM 115 EP
 , MAXXUM 115 Multicontroller EP , MAXXUM 120 EP , MAXXUM 120
Multicontroller EP , MAXXUM 125 EP , MAXXUM 125 Multicontroller EP ,
MAXXUM 130 EP , MAXXUM 130 Multicontroller EP , MAXXUM 140 EP ,
MAXXUM 140 Multicontroller EP , MAXXUM CVT 110 , MAXXUM CVT 120 ,
MAXXUM CVT 130**

Contents

Steering - 41

Hydraulic control components - 200

TECHNICAL DATA

Hydraulic control components

| | |
|--|---|
| Special tools | 4 |
| Torque | 4 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT | |
| General specification | 6 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT, MAXXUM CVT Tier IV Efficient Power --- INT | |

Fast steering control valve

| | |
|--------------|---|
| Torque | 8 |
|--------------|---|

FUNCTIONAL DATA

Power steering system

| | |
|--|----|
| Static description Fast Steer | 9 |
| Dynamic description | 12 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT | |
| Dynamic description Fast Steer System | 16 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT | |
| Hydraulic schema Fast Steer System | 20 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT | |
| Static description | 24 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |


Power steering control valve

| | |
|--|----|
| Exploded view (Steering Motor) | 26 |
| MAXXUM 110 EP --- INT, MAXXUM 110 Multicontroller EP --- INT, MAXXUM 115 EP --- INT, MAXXUM 115 Multicontroller EP --- INT, MAXXUM 120 EP --- INT, MAXXUM 120 Multicontroller EP --- INT, MAXXUM 125 EP --- INT, MAXXUM 125 Multicontroller EP --- INT, MAXXUM 130 EP --- INT, MAXXUM 130 Multicontroller EP --- INT, MAXXUM 140 EP --- INT, MAXXUM 140 Multicontroller EP --- INT | |

Fast steering control valve

| | |
|---------------------|----|
| Exploded view | 27 |
|---------------------|----|

Steering - Hydraulic control components



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Contents

Cab climate control - 50

| | |
|--------------------------------|------|
| [50.100] Heating | 50.1 |
| [50.104] Ventilation | 50.2 |
| [50.200] Air conditioning..... | 50.3 |

Control elements




SS08D105 1

| | | |
|---------------------------------------|---|--|
| Blower speed switch (1) | Selecting the blower speed manually overrides the selection made by the control unit. | Position "0": Blower switched off Position "A": Blower speed is automatically controlled by the controller. Position "I": Slow blower speed Position "II": Middle blower speed Position "III": Fast blower speed |
| Operating mode switch (2) | Determines the operating mode. | Position "ECON": Air conditioner is switched off Position "Middle": Air conditioner is switched on Position "MAX DEF": Dehumidifier/defroster mode |
| Temperature control potentiometer (3) | Determines the desired value of the cab temperature. | Position "LO": Maximum cooling power temperature range position 18-28. Desired cab temperature in °C/°F. Position "HI": Maximum heating power |

"AUTOMATIC" control mode


The automatic mode is selected by moving the blower speed switch (1) to position "A" automatic and the operating mode switch (2) to the middle position. Use the temperature control potentiometer (3) to set the desired temperature. In this mode the system attempts to maintain the desired temperature value selected by the driver (from 16 °C (61 °F) to 32 °C (90 °F) using the temperature control (ATC) and in order to do this varies the air temperature and the blower speed.

4. Insert bearing's circlip.




BAIL07APH430AVA 4

5. Place shims on compressor shaft.



BAIL07APH431AVA 5

6. Insert a new dust protection ring.




BAIL07APH429AVA 6

7. Attach coupling plate.

Attach the special tool (211-153/1, 211-153/2) to secure the coupling plate. Screw the locknut onto the drive shaft and tighten to **18 Nm (13 lb in)**.

NOTE: From→ pay attention to the woodruff key.




BAIL07APH428AVC 7

8. Measure the gap between the front plate of the coupling and belt pulley. The gap must be the same over the entire area and measure **0.4 - 0.8 mm (0.0157 - 0.0315 in)** .

Resistance test (testing an electrical component)

NOTE: Nominal resistance values are usually valid for a temperature of 20 °C (68.00 °F). With higher or lower tractor temperatures, the relative resistance values shown in the manual should vary accordingly.

1. Disconnect the electrical component from the vehicle by unplugging the connectors to expose the component connector for testing.
2. Set the digital multimeter to resistance measurement (**Ohm**). Measure the resistance in the circuit.
3. Insert the red and the black lead of the multimeter into the connector terminals (connector pins) as specified in the test procedure.
4. In order to verify the correct operation of a potentiometer, the resistance should be measured between the minimum and the maximum position. Therefore smoothly move the sliding contact between the minimum and the maximum position. Execute this measurement twice with the test leads in both connection possibilities (as illustrated).
5. In order to verify the correct operation of a switch, operate the switch while checking for an open circuit or a short circuit.
6. Compare the measured resistance values to the values specified in the test procedure.



SEZ55CAP9B-7 4

Electrical systems - Harnesses and connectors

| Code | Description | Frame |
|-------|-------------------------------|---|
| S-142 | Rotating Beacon Switch | Wire harnesses - Electrical schematic frame 40 (55.100) |
| S-143 | Rear Worklamp Switch | Wire harnesses - Electrical schematic frame 40 (55.100) |
| S-144 | Front Worklamp Switch | Wire harnesses - Electrical schematic frame 40 (55.100) |
| S-145 | Front Worklamps (Hood) Switch | Wire harnesses - Electrical schematic frame 40 (55.100) |

SOLENOID

| Code | Description | Frame |
|-------|--|--|
| Y-001 | Exhaust Brake Solenoid | Wire harnesses - Electrical schematic frame 12 (55.100) |
| Y-002 | Suspension Raise Solenoid | Wire harnesses - Electrical schematic frame 20 (55.100) |
| Y-003 | Suspension Lower Solenoid | Wire harnesses - Electrical schematic frame 20 (55.100) |
| Y-004 | Upper Lockout Solenoid | Wire harnesses - Electrical schematic frame 20 (55.100) |
| Y-005 | Lower Lockout Solenoid | Wire harnesses - Electrical schematic frame 20 (55.100) |
| Y-010 | Hydrostat bypass valve | Wire harnesses - Electrical schematic frame 12 (55.100) |
| Y-011 | High Pressure Pump Metering Valve | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-012 | Electronic Draft Control Valve Raise | Wire harnesses - Electrical schematic frame 17 (55.100) |
| Y-013 | Electronic Draft Control Valve Lower | Wire harnesses - Electrical schematic frame 17 (55.100) |
| Y-015 | Change Valve Solenoid | Wire harnesses - Electrical schematic frame 22 (55.100) |
| Y-016 | Front PTO Solenoid | Wire harnesses - Electrical schematic frame 21 (55.100) |
| Y-018 | Rear PTO Brake Solenoid | Wire harnesses - Electrical schematic frame 19 (55.100) |
| Y-019 | Rear PTO Solenoid | Wire harnesses - Electrical schematic frame 19 (55.100) |
| Y-021 | Brake De-Icer | Wire harnesses - Electrical schematic frame 47 (55.100) |
| Y-022 | Pneumatic Trailer Brake Solenoid | Wire harnesses - Electrical schematic frame 47 (55.100) |
| Y-023 | Park Brake Solenoid | Wire harnesses - Electrical schematic frame 47 (55.100) |
| Y-030 | Solenoid 17th Gear | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-031 | Solenoid 17th Gear - Dump Valve | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-037 | Hydraulic Trailer Brake Solenoid 1 / 2 | Wire harnesses - Electrical schematic frame 47 (55.100) |
| Y-038 | Diff Lock Solenoid | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-040 | 4WD Solenoid | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-044 | Auto Guidance Dump Solenoid | Wire harnesses - Electrical schematic frame 27 (55.100) |
| Y-045 | DEF/ADBLUE Heating control Valve | Wire harnesses - Electrical schematic frame 14 (55.100) |
| Y-046 | DEF/ADBLUE Injection Valve | Wire harnesses - Electrical schematic frame 14 (55.100) |
| Y-050 | Auto Guidance Turn Right Solenoid | Wire harnesses - Electrical schematic frame 27 (55.100) |
| Y-051 | Auto Guidance Turn Left Solenoid | Wire harnesses - Electrical schematic frame 27 (55.100) |
| Y-052 | Heating Valve | Wire harnesses - Electrical schematic frame 29 (55.100) |
| Y-061 | Injector, No.1 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-062 | Injector, No.2 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-063 | Injector, No.3 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-064 | Injector, No.4 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-065 | Injector, No.5 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-066 | Injector, No.6 Cylinder | Wire harnesses - Electrical schematic frame 13 (55.100) |
| Y-074 | Solenoid Clutch C3 | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-075 | Solenoid Clutch C4 | Wire harnesses - Electrical schematic frame 15 (55.100) |
| Y-082 | Air Condition Clutch | Wire harnesses - Electrical schematic frame 29 (55.100) Wire harnesses - Electrical schematic frame 30 (55.100) |

ASSEMBLY

| Code | Description | Frame |
|-------|-----------------|---|
| Z-001 | Blower Assembly | Wire harnesses - Electrical schematic frame 29 (55.100) |
| Z-002 | Fuse block | Wire harnesses - Electrical schematic frame 01 (55.100) Wire harnesses - Electrical schematic frame 02 (55.100) Wire harnesses - Electrical schematic frame 03 (55.100) Wire harnesses - Electrical schematic frame 04 (55.100) Wire harnesses - Electrical schematic frame 05 (55.100) Wire harnesses - Electrical schematic frame 06 (55.100) Wire harnesses - Electrical schematic frame 07 (55.100) |

Wire harnesses - Electrical schematic frame 11 START/CHARGING (LESS Battery Isolator)


MAXXUM 110 - 140 Multicontroller EP

| Component | Connector | Description |
|-----------|------------------------------------|--|
| F-100 | X923 | Supply Memory |
| F-101 | X924 | Reserve |
| G-001 | X605, X608, X815, X890, X892 | 12 V Battery |
| G-002 | X236, X237 | Alternator |
| M-003 | X231, X232 | Starter Motor |
| PF1 | X920 | Power Fuse, Main Power Supply B+ (250 A) |
| PF2 | X921 | Power Fuse, Power Supply UCM, PTO rear, ICU3 |
| PF8 | X823 | Mega Fuse, Grid & Fuel Heater (125 A) |
| PF9 | X922 | Power Fuse, Power Supply SCR System |

Additional Connectors:
X021, X023, X902

Wire Color Codes


| | | | |
|-----------------------|------------------|----------------------|-----------------------|
| BK Black | GN Green | PK Pink | BL Blue |
| TN Light Brown | BR Brown | OR Orange | LG Light Green |
| RD Red | GY Grey | LB Light Blue | |
| WH White | YE Yellow | VT Violet | |



SS11J028 3

Wire harnesses - Electrical schematic frame 24 INSTRUMENT CLUSTER MAXXUM 110 - 140 Multicontroller EP

| Component | Connector | Description | |
|---|-------------------|--|-----------------------|
| A-063 | X005, X009 | Instrument Cluster Unit | |
| S-022 | X223, X224 | Air Cleaner Switch | |
| S-028 | X474 | Hydraulic Filter Blocked (Vacuum Switch) | |
| S-037 | X260 | Low Hydraulic Charge Switch | |
| Additional Connectors: X020, X026, X762 | | | |
| Wire Colour Codes | | | |
| BK Black | GN Green | PK Pink | BL Blue |
| TN Light Brown | BR Brown | OR Orange | LG Light Green |
| RD Red | GY Grey | LB Light Blue | |
| WH White | YE Yellow | VT Violet | |



Sheet 31

SS13A969 2

LOW ROOF


| Component | Connector | Description |
|------------------|------------------|---------------------------------|
| E-029 | X205 | Worklamp Front Upper Left Hand |
| E-030 | X196 | Worklamp Grabrail Left Hand |
| E-031 | X182 | Worklamp Rear Left Hand |
| E-032 | X173 | Worklamp Rear Right Hand |
| E-033 | X206 | Worklamp Front Upper Right Hand |
| E-034 | X164 | Worklamp Grabrail Right Hand |
| E-035 | X185 | Rotating Beacon Left Hand |
| E-036 | X170 | Rotating Beacon Right Hand |
| K-031 | X183 | Front Worklamp Relay |
| K-032 | X203 | Rotating Beacon Relay |
| K-033 | X204 | Rear Worklamp Relay |
| S-142 | X188 | Rotating Beacon Switch |
| S-143 | X199 | Rear Worklamp Switch |
| S-144 | X189 | Front Worklamp Switch |
| S-145 | X198 | Front Worklamps (Hood) Switch |

Additional Connectors:

X106

Wire Color Codes

| | | | |
|-----------------------|------------------|----------------------|-----------------------|
| BK Black | GN Green | PK Pink | BL Blue |
| TN Light Brown | BR Brown | OR Orange | LG Light Green |
| RD Red | GY Grey | LB Light Blue | |
| WH White | YE Yellow | VT Violet | |




Electrical systems - Harnesses and connectors

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|---------|-------------|---|
| 1 | GN | 29 | MAIN FUEL SENDER SIGNAL |
| 2 | RD | 1013 | RIGHT HAND LAMPS |
| 3 | RD | 1014 | LEFT HAND LAMPS |
| 4 | GN | 810 | STOPLAMPS |
| 5 | TN / GN | 350 / 349 | TRAILER TURN LAMPS RH |
| 6 | TN / YE | 349 / 350 | TRAILER TURN LAMPS LH |
| 7 | YE | 7412 | - |
| 8 | GN | 7525 | TRANS SENSOR SUPPLY 5v |
| 9 | RD | 7160 | HYD LOW CHARGE WARNING |
| 10 | RD / PK | 7981 / 7985 | SOLENOID VALVE HYDROSTAT PLUS / TRANS REVERSE RANGE |
| 11 | WH | 2055 | PTO SYNCHRO GROUND SPEED ENGAGED |
| 12 | GN | 2095 | INSTRUMENT SIGNAL GROUND |
| 13 | BL / - | 7230 / - | NOT USED |
| 14 | BL | 7582 / - | NOT USED |
| 15 | PK / - | 7407 / - | NOT USED |
| 16 | OR | 3240 | RAISE SOLENOID PWR |
| 17 | VT / - | 9051 / - | NOT USED |
| 18 | OR | 3260 | LOWER SOLENOID PWR |
| 19 | WH / - | 7408 / 8045 | HYDROSTAT 1 SOLENOID GND / TRANS REV SOL RET |
| 20 | TN | 8010 | TRAILER BRAKE PRESSURE |
| 21 | BR | 8000 | TRAILER BRAKE SOLENOID |
| 22 | BR | 8000 | TRAILER BRAKE SOLENOID |
| 23 | OR | 3280 | SUSPENSION LOCKOUT SOLENOID UPPER |
| 24 | TN | 8010 | TRAILER BRAKE PRESSURE |
| 25 | BK/WH | 60 | SENSOR GROUND |
| 26 | TN | 8020 | TRAILER BRAKE PRESSURE |
| 27 | BL | 8060 | TRAILER BRAKE SUPPLY |
| 28 | WH | 3500 | POWER STEERING PRESSURE SIGNAL |
| 29 | TN | 3285 | SUSPENSION LOCKOUT SOLENOID LOWER |
| 30 | GY | 5515 | EHR +12V IGN. |
| 31 | RD | 5500 | EHR CAN HIGH |
| 32 | BL | 5510 | EHR CAN LOW |
| 33 | WH / - | 4055 / - | NOT USED |
| 34 | WH / - | 4056 / - | NOT USED |
| 35 | WH / - | 4057 / - | NOT USED |
| 36 | WH / - | 4058 / - | NOT USED |
| 38 | WH / - | 4054 / - | NOT USED |
| 39 | RD / BL | 5830 | HIGH FLOW PUMP LINK |
| 40 | RD / - | 8050 / - | NOT USED |
| 41 | BL / - | 7770 / - | NOT USED |
| 42 | GN | 7500 | TRANS OIL TEMP. SENSOR |
| 43 | YE / - | 7411 / - | NOT USED |
| 44 | BR / - | 8000 / - | NOT USED |
| 45 | YE | 7400 | TRANS RPM SPEED SENSOR TO TCM INPUT |
| 46 | YE | 7401 | TRANS RPM SPEED SENSOR |
| 47 | VT / - | 7581 / - | NOT USED |
| 48 | BR | 7130 | HYD FILTER WNG LP |
| 49 | VT | 8070 | TRAILER PARK BRAKE SOLENOID |
| 50 | VT / - | 7135 / - | NOT USED |
| 51 | YE | 2012 | TRANS OIL PRESSURE WARNING LAMP |


MAXXUM 110 - 140 EP

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------------|
| 1 | GN | 29 | MAIN FUEL SENDER SIGNAL |
| 2 | RD | 1013 | RIGHT HAND LAMPS |



SS12B035 19


RIGHT HAND CONSOLE



SS08F185


SS08F185 20

MAXXUM 110 - 140 EP



SS12A036 13

BEHIND RIGHT HAND SWITCH PANEL



SS07K168


SS07K168 14

X115B Power socket 30 Amp. — Cab inside

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------|
| 1 | BK | 57 | EARTH (ALL) |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.


MAXXUM 110 - 140 Multicontroller EP Maxxum CVT 110 - 130



SS08K160

SS08K160 15


BEHIND RIGHT HAND SWITCH PANEL



SS08F111


SS08F111 16

MAXXUM 110 - 140 EP



SS11N078 17

BEHIND RIGHT HAND SWITCH PANEL



SS08F111


SS08F111 18

X197A Front work light left-hand


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------|
| - | - | - | - |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.

HIGH ROOF



INA 25



SS08F147


SS08F147 26

X198 Front Worklamps (Hood) Switch


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-----------------------------|
| 2 | RD | 1013 | RIGHT HAND LAMPS |
| 3 | RD | 1092 | FRONT WORKLAMP RELAY SIGNAL |
| 7 | BK | 57 | EARTH (ALL) |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.

LOW ROOF



SS12A075 27



SS08F094

SS08F094 28

REAR RIGHT HAND C-PILLAR


X199 Rear Worklamp Switch

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|----------------------------|
| 2 | RD | 1013 | RIGHT HAND LAMPS |
| 3 | RD | 1090 | REAR WORKLAMP RELAY SIGNAL |
| 7 | BK | 57 | EARTH (ALL) |


NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.

NOTE: For the wiring color code refer to, **Wire harnesses - Identification (55.100)**.

Maxxum CVT 110 - 130



SVIL13TR00673AB 9



SS08H131

SS08H131 10

top of the transmission


X275 Hydrostat bypass valve – Cranking relay

Maxxum CVT 110 - 130


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-----------------------|
| 1 | OR | 9320 | - |
| 2 | BK | 57 | EARTH (ALL) |
| 4 | YE | 9321 | - |
| 5 | WH | 1001 | STARTER SOLENOID FEED |

NOTE: For the wiring color code refer to, **Wire harnesses - Identification (55.100)**.

Maxxum CVT 110 - 130



SVIL13TR00673AC 11



SS08H131

SS08H131 12

top of the transmission

X276 Diff. Lock Solenoid

16x16 Transmission

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------------|
| 1 | GN | 7080 | DIFF-LOCK SOLENOID FEED |
| 2 | BK | 57 | EARTH (ALL) |

24x24 Transmission

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------------|
| 1 | LG | 7080 | DIFF-LOCK SOLENOID FEED |
| 2 | BK | 57 | EARTH (ALL) |

Wire connectors - Component diagram 40


X400 Diverter solenoid valve – Control switch

MAXXUM 110 - 140 Multicontroller EP

MAXXUM CVT 110 - 130


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|------------------------|
| 2 | GN | 181 | BLOWER/GARU MOTOR FEED |
| 4 | BR | 9000 | DIVERTER VALVE |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.



SS10G064 1

INSIDE OF THE ARMREST UNIT



SS08F147 2


X401 Remote valve switch – Fender right-hand and left-hand

MAXXUM 110 - 140 Multicontroller EP

MAXXUM CVT 110 - 130


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|------------------------------|
| 1 | VT | 5574 | FENDER 3RD EHR SWITCH – UP |
| 2 | BR | 5200 | EDC VALVE SUPPLY |
| 3 | VT | 5576 | FENDER 3RD EHR SWITCH – DOWN |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.



SS08K183 3

RIGHT HAND REAR FENDER



SS08F072 4

X507 Upper Lockout Solenoid

MAXXUM 110 - 140 Multicontroller EP

MAXXUM 110 - 140 EP


16x16 Transmission

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|--|
| A | OR | 3280 | SUSPENSION LOCKOUT SOLENOID UPPER |
| B | TN | 3281 | SUSPENSION LOCKOUT SOLENOID UPPER RETURN (-) |


MAXXUM CVT 110 - 130

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-----------------------------------|
| A | OR | 3280 | SUSPENSION LOCKOUT SOLENOID UPPER |
| B | BK | 57 | EARTH (ALL) |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.




SS09F098 17




SS08M018 18

RIGHT HAND SIDE REAR OF TRANSMISSION



SVIL13TR00547AD 19



SS08M018 20

RIGHT HAND SIDE REAR OF TRANSMISSION


X508 Lower Lockout Solenoid

MAXXUM 110 - 140 Multicontroller EP


MAXXUM 110 - 140 EP

16x16 Transmission

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|--|
| A | TN | 3285 | SUSPENSION LOCKOUT SOLENOID LOWER |
| B | TN | 3286 | SUSPENSION LOCKOUT SOLENOID LOWER RETURN (-) |



RIGHT HAND FRONT AXLE




Automatic Climate Control (ATC)

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------|
| A | RD | - | - |
| B | BK/WH | - | - |


NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.

Standard climate control (up to 02/2013)



SS13G187 5

IN CAB BELOW OPERATOR'S SEAT




SS08F026

SS08F026 6


Automatic Climate Control (ATC)

Standard climate control (from 03/2013)



SVIL13TR00565AB 7

IN CAB BELOW OPERATOR'S SEAT



SS08F026

SS08F026 8

X774 Heating control valve


Automatic Climate Control (ATC)

Standard climate control (from 03/2013)

| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------|
| A | RD | - | - |
| C | YE | - | - |
| D | BK | - | - |


NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.

MAXXUM 110 - 140 Multicontroller EP MAXXUM 110 - 140 EP



SS12B151 15


REAR ENGINE RIGHT HAND



SS09G141


SS09G141 16

Maxxum CVT 110 - 130



SVIL13TR00556AD 17

REAR ENGINE RIGHT HAND



SS09G141


SS09G141 18

X894 Battery isolator

MAXXUM CVT 110 - 130


| POS. | COLOR | WIRE NUMBER | CIRCUIT REFERENCE |
|------|-------|-------------|-------------------|
| 1 | BK | 1 | BATTERY SUPPLY |

NOTE: For the wiring color code refer to, *Wire harnesses - Identification (55.100)*.



SVIL13TR00691AB 19


RIGHT-HAND SIDE BEHIND THE BATTERY HOUSING



SS09G141

SS09G141 20

13. Cover the area with insulating tape taking the tape well over each end of the repair. An overlap of at least **50.0 mm (2.0 in)** of tape at each end is necessary.
14. Ensure that the repair is satisfactory. Secure the repaired cable so that repeat damage can be avoided.



1Z002004112114 4

Battery - General specification

| | |
|-----------------------------|---------------------------------------|
| Temperature | Efficiency of a Fully Charged Battery |
| 25.0 °C (77.0 °F) | 100 % |
| -4.5 °C (23.9 °F) | 82 % |
| -24.0 °C (-11.2 °F) | 64 % |
| -27.5 °C (-17.5 °F) | 58 % |
| -31.0 °C (-23.8 °F) | 50 % |
| -34.5 °C (-30.1 °F) | 40 % |
| -37.5 °C (-35.5 °F) | 33 % |

| | | |
|--|---|---|
| | 140 Ah (800 cca) | 176 Ah (1300 cca) |
| Slow Charge Programs | 32 hours at 5 A 17 hours at 10 A | 46 hours at 5 A 23 hours at 10 A |
| Fast charge Program (emergencies only) | 9 hours at 18 A | 13 hours at 18 A |


Use the following table to determine the state of charge

| State of Charge | Corrected Specific Gravity @ 15 °C (59.0 °F) | Corrected Specific Gravity @ 25 °C (77.0 °F) | Average Battery Voltage |
|-----------------|---|---|-------------------------|
| 100 % | 1.295 | 1.287 | 12.76 V |
| 75 % | 1.253 | 1.246 | 12.52 V |
| 50 % | 1.217 | 1.210 | 12.30 V |
| 25 % | 1.177 | 1.170 | 12.06 V |
| Discharged | 1.137 | 1.130 | 11.84 V |

| | |
|-------------------------|---------------------|
| Specific Gravity | Fast charge up to : |
| 1.150 SG or less | 60 minutes |
| 1.151 - 1.175 SG | 45 minutes |
| 1.176 - 1.200 SG | 30 minutes |
| 1.201 - 1.225 SG | 15 minutes |
| | (Slow charge only) |

| Description | Battery Specification |
|--|-----------------------|
| Capacity (Ampere hour at 20 hour rate) | 140 / 176 |
| Cold Cranking Ampere Rating | 800 / 1300 |
| Voltage | 12 |
| Cells | 6 |
| Ground Terminal | Negative |


4. Detach the rear fender deflector and position it to one side.



BAIL12APH017AVA

BAIL12APH017AVA 4


5. Remove the Selective Catalytic Reduction (SCR) power converter cover.



BAIL12APH018AVA

BAIL12APH018AVA 5


6. Detach the SCR power converter from the fuel tank.



BAIL12APH019AVA

BAIL12APH019AVA 6


7. Pull back the slider (1), fully depress the locking latch (2) and pull on the connector body to disconnect the electrical connector and remove the SCR power converter.



BAIL12APH020AVA

BAIL12APH020AVA 7

BAIL.12APH127GVA



BAIL.12APH127GVA 1


Selective Catalytic Reduction (SCR) heated level sensor locally fabricated tool.

H Menu Navigation Procedure

Connect the special tool **380000843** to the diagnostic connector and turn the key start switch ON.

At key ON the ICU3 will automatically build a list of the controllers connected on the Controller Area Network (CAN), and will store it in the Electrically Erasable Programmable Read Only Memory (EEPROM).


The dot matrix display will show "HH MENU" to indicate that the "H" menu has been activated.



BAIL10CVT592AVA 3

To navigate the "H" menus use the navigation "up" key and "down" key to scroll through the options, and the "menu" key to select the required controller or "H" menu, and the "escape" key to back up a menu level.

- (1) "up" key
- (2) "down" key
- (3) "menu" key
- (4) "escape" key



BAIL09CCM800AVA 4

NOTE: Not all H menus will be available on every controller. If a controller does not implement a particular H menu, then it will not be shown when scrolling.

Steering Calibration 'U' Error Codes

| Code | Description | Possible Failure |
|------|---|--|
| U19 | Oil Temperature below 5°C | 1) Open circuit for the temperature sensor input to the transmission module 2) Faulty temperature sensor Note: Use the H9 menu in the transmission module to see if the temperature sensor input is OK |
| U21 | ERPM is below 1300, increase throttle | 1) Operator has not set the correct engine speed 2) Open circuit for the engine speed sensor going to the cluster – mechanical engines only 3) Instrument cluster is not powered 4) Broken CAN bus Note: Use the HE menu to see if the engine speed is being detected. |
| U71 | Calibration attempted while enable switch is off | 1) The enable switch is in the off position 2) The enable switch is in the on position at start up but needs to be cycled through off then on to enable the system |
| U72 | Proximity sensor input is out of range – open | 1) Incorrect position of steering wheel 2) Faulty proximity sensor Check the proximity sensor connection |
| U73 | Proximity sensor input is out of range – closed | 1) Incorrect position of steering wheel 2) Faulty proximity sensor Check the proximity sensor connection |
| U74 | LVDT calibration has been unsuccessful (out of range after 4th attempt) | 1) Faulty LVDT sensor 2) Faulty steering hydraulic valve 3) Incorrect assembly of hydraulic valve Check the LVDT sensor connection |

EDC - Error Codes

| Code | Description |
|------|--|
| 1002 | Radar not detected (when slip option enabled) |
| 1003 | Speed sensor error |
| 1004 | Wheel speed sensor - signal too high |
| 1006 | Slip control potentiometer error |
| 1008 | Raise / work switch failure (command arm) |
| 1009 | Both external switches operated at the same time |
| 1010 | Height limit control potentiometer error |
| 1012 | Drop rate control potentiometer error |
| 1014 | R/H load sensing pin – signal too low |
| 1015 | R/H load sensing pin – signal too high |
| 1016 | L/H load sensing pin – signal too low |
| 1017 | L/H load sensing pin – signal too high |
| 1018 | Both load sensing pins disconnected |
| 1019 | Load sensing pin 8V reference – voltage too low |
| 1020 | Load sensing pin 8V reference – voltage too high |
| 1021 | Draft sensitivity control potentiometer error |
| 1024 | Perform the hydraulic lift calibration |
| 1025 | Position control potentiometer error |
| 1027 | Lift arm position sensor – voltage too low |
| 1028 | Lift arm position sensor – voltage too high |
| 1029 | Hydraulic control valve disconnected |
| 1031 | Chassis harness disconnected |
| 1033 | Draft control potentiometer error |
| 1049 | Wheel speed sensor open circuit |
| 1063 | Hydraulic valve lower solenoid – open circuit |
| 1064 | Hydraulic valve raise solenoid – open circuit |
| 1065 | Hydraulic valve lower solenoid – short circuit |

Front Hitch Calibration 'U' Error Codes

| Code | Description | Possible Failure |
|------|---|---|
| U110 | Position potentiometer value too low or the hitch is not raised | Hitch was not raised before height limit control was changed from ON to OFF position |
| U111 | Position potentiometer value too high or the hitch is not lowered | Hitch was not lowered before height limit control was changed from ON to OFF position |

Steering Calibration 'U' Error Codes

| Code | Description | Possible Failure |
|------|---|---|
| U19 | Oil temperature below 5 °C | 1) Open circuit for the temperature sensor input to the transmission module 2) Faulty temperature sensor Note: Use the H9 menu in the transmission module to see if the temperature sensor input is okay |
| U21 | ERPM is below 1300, increase throttle | 1) Operator has not set the correct engine speed 2) Open circuit for the engine speed sensor going to the cluster – mechanical engines only 3) Instrument cluster is not powered 4) Broken CAN bus Note: Use the HE menu to see if the engine speed is being detected |
| U71 | Calibration attempted while enable switch is off | 1) The enable switch is in the off position 2) The enable switch is in the on position at start up but needs to be cycled through off then on to enable the system |
| U72 | Proximity sensor input is out of range – open | 1) Incorrect position of steering wheel 2) Faulty proximity sensor 3) Check the proximity sensor connection |
| U73 | Proximity sensor input is out of range – closed | 1) Incorrect position of steering wheel 2) Faulty proximity sensor 3) Check the proximity sensor connection |
| U74 | LVDT calibration has been unsuccessful (out of range after 4th attempt) | 1) Faulty LVDT sensor 2) Faulty steering hydraulic valve 3) Incorrect assembly of hydraulic valve 4) Check the LVDT sensor connection |

EPL Calibration 'U' Error Codes

| Code | Description | Possible Failure |
|------|--|--|
| U114 | Hand brake applied | 1) Blue cable (on the handbrake switch connector) cut off 2) Mismatch between the handbrake switch status hardwired to the EPL and the VCU_HB_SWITCH parameter in the VCU2EPL CAN message |
| U115 | Shuttle lever not in the park position | 1) Pins A4 or C7 of the EPL module short to ground 2) Pins A4 or C7 of the EPL module cut off 3) Pins A4 or C7 of the EPL module short to supply voltage 4) Shuttle lever damaged |
| U116 | APP position too high | 1) Wrong mechanical adjustment of the EPL transmission lever 2) Possible wear in the braking pads |
| U117 | APP position too low | 1) Stiffness of the system is too high – possible mechanical interferences 2) Wrong mechanical installation of the EPL |
| U118 | Error codes active preventing completion of initialization procedure | 1) High recovery level error code is being activated |
| U119 | Bowden cable not connected | 1) Bowden cable not connected |
| U120 | Inclinometer self test failed | 1) Inclinometer broken |
| U121 | Inclinometer calibration procedure not OK | – |

Once the required setting is displayed, press and hold either the “h” or “m” button for 1 second. The instrument cluster will beep and the setting will be stored.

Depress the "dimming" button to exit the menu at any time.


Electronic module Central Control Unit (CCU) - H2 - View stored calibration values

| | |
|---------------|------------------------|
| MAXXUM 110 EP | INT 24x24 Transmission |
| MAXXUM 115 EP | INT 24x24 Transmission |
| MAXXUM 120 EP | INT 24x24 Transmission |
| MAXXUM 125 EP | INT 24x24 Transmission |
| MAXXUM 130 EP | INT 24x24 Transmission |
| MAXXUM 140 EP | INT 24x24 Transmission |

The Central Control Unit (DW) is used to view stored calibration values for the following components:

- 24x24 Transmission
- EDC
- Rear PTO
- Steering Sensor


H2 Menu Screen Select Diagram



BAIL11APH383FVC

BAIL11APH383FVC 1


The lower central display will show "d _ _".



BVE0047A_569 5

When a switch is operated, a code will be displayed and an audible tone should be heard to indicate the correct function.

If a switch code is not displayed and the audible tone not heard, a 'wiggle' test can be performed on the related wiring while watching the display or listening for the audible tone, to help locate the fault.



BAIL06CCM423AVA 6

Refer to the table below for the switch numbers.

| Channel | Control unit plug connection | Pin number | Description |
|---------|------------------------------|------------|---|
| d0 | - | - | No switch activated or two switches activated at the same time |
| d1 | CN1B | 30 | EDC fender switch - Lower |
| d2 | CN1B | 29 | EDC fender switch - Raise |
| d3 | CN1B | 18 | EDC work switch (on EDC mouse) |
| d4 | CN1B | 20 | EDC raise switch (on EDC mouse) |
| d10 | CN3A | 16 | Seat switch |
| d11 | CN3A | 19 | Handbrake switch |
| d12 | CN3A | 10 | Left brake pedal switch |
| d13 | CN3A | 11 | Right brake pedal switch |
| d14 | CN1A | 8 | Clutch pedal switch (engine running and transmission in forward or reverse) |
| d15 | CN1B | 12 | Switch for the shuttle lever - Forwards |
| d16 | CN1B | 13 | Switch for the shuttle lever - Reverse |
| d17 | CN1B | 23 | Transmission downshift switch |
| d18 | CN1B | 22 | Transmission upshift switch |
| d19 | CN3A | 23 | Transmission range shift switch |
| d25 | CN3A | 6 | Transmission neutral switch (clutch depressed, change to neutral from forward or reverse) |
| d26 | CN1B | 26 | 16x16 Transmission high range switch |
| d27 | CN1B | 19 | 16x16 Transmission low range switch |
| d29 | CN1B | 24 | EDC raise / work switch (on EDC mouse) |
| d30 | CN3A | 14 | Transmission auto on / off switch |
| d34 | CN3A | 8 | Transmission creeper switch |
| d35 | CN3A | | Creeper selector fork disengaged switch |
| d36 | CN3A | 9 | Creeper selector fork engaged switch |

Electronic module Instrument control unit - H8 - Clear stored calibration information (EEPROM)

| | |
|-------------------------------|-----|
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

This menu clears calibration values and stored error codes by resetting all EEPROM values back to default. EEPROM is where all calibration values and error codes are stored. This memory is retained even if there is no power to the controller, i.e. if the battery is disconnected. There are two options available. "Clear net config" and "clear settings".

"Clear net config" is used to erase the stored network configuration, this will clear the current configuration stored in the instrument cluster and rebuild the configuration at the next key ON. This should be used if the cluster has been changed or if the HH menus are showing modules which are not fitted to the machine.


"Clear settings" will return all instrument cluster settings back to their default setting.

NOTE: To change any configuration settings H3 menu mode must be used. H8 will not affect these settings.

NOTE: To remove all stored error codes without erasing the calibration values use the HC menu.

The "CLEAR SETTINGS" option will clear all of the following information stored in the instrument cluster's non-volatile memory, and set the parameters to their default values (indicated in brackets).

H2 Menu Screen Select Diagram




BAIL10CVT008FVD

BAIL10CVT008FVD 1

16x16 Transmission Calibration Values

Use the "up", "down", and the "menu" keys to navigate the HH menus to H2 and the transmission symbol on the U1 controller.


The upper section of the display will show "Ch_ _"



BAIL10CVT066AVB

BAIL10CVT066AVB 2


The upper section of the display will automatically cycle through the software release, as the example shown and return to allow navigation of the "HH" menus



BAIL10CVT119AVB 3

When a switch is operated, a code will be displayed and an audible tone should be heard to indicate the correct function.

If a switch code is not displayed and the audible tone not heard, a 'wiggle' test can be performed on the related wiring while watching the display or listening for the audible tone, to help locate the fault.



BAIL09HHP256AVA

BAIL09HHP256AVA 3


| Identifier | Switch / Input |
|------------|--|
| d5 | Multi function handle (MFH) - Rear hitch work switch |
| d6 | MFH - Rear hitch raise switch |
| d17 | MFH - Downshift switch |
| d18 | MFH - Upshift switch |
| d19 | MFH - 2nd function switch |
| d92 | Front hitch height limit enable switch |
| d95 | EHR 1 program / motor mode switch |
| d96 | EHR 2 program / motor mode switch |
| d97 | EHR 3 program / motor mode switch |
| d98 | EHR 4 program / motor mode switch |
| d104 | MFH - Headland management control (HMC) step switch |
| d136 | MFH - Reverse switch |
| d137 | MFH - Forward switch |
| d153 | Joystick 1 - switch 1 |
| d154 | Joystick 1 - switch 2 |
| d155 | Joystick 1 - switch 3 |
| d159 | EHR flow control encoder switch |
| d165 | EHR float control switch |
| d177 | MFH - Autoguidance engage on/off switch |
| d178 | MFH EHR 1 extend switch |
| d179 | MFH EHR 1 retract switch |

Electronic module Auxiliary Control Unit (ACU) - HA - Demonstration mode

| | |
|---------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 140 EP | INT |


Used to demonstrate front axle suspension.

HA Menu Screen Select Diagram




Start the engine.

Select the HA menu by depressing the "dimming" button.



The required channel can be selected by using the "h" and "m" buttons.


Install the diagnostic connector **380000843** into the diagnostic socket.



BAIL07APH189AVA

Turn the ignition key switch ON.

Use the "up", "down", and the "menu" keys to navigate the HH menus to HF on the IG controller.
Select the HF menu by depressing the "menu" key.




BAIL10CVT269AVA

The top section of the display will then automatically cycle through as the example:

- 0712 Hardware identification
- 0400 Hardware version
- 0000 Hardware version
- 1303 Serial number
- 0605 Serial number

And return to allow navigation of the "HH" menus.



BAIL13TR01341AA

NOTE: The last three sets of 4 digits displayed represent the 12 digit module serial number. This number should correspond to the serial number shown on the module's label. Note that the serial number shown on the display will include leading zeros that may not be present on the module label. In this example the serial number is 13030605.

Depress the "menu" key to continue navigating the "HH" menus.

NOTE: *The default setting is VS (Viscostatic)*

Electronic module Universal controller - HA - Demonstration mode


| | |
|----------------|-----|
| MAXXUM CVT 110 | INT |
| MAXXUM CVT 120 | INT |
| MAXXUM CVT 130 | INT |

NOTE: The HA diagnostic menu is used to allow specific performance features of the vehicle to be turned off. This makes it possible for dealers to demonstrate the advantages of these features.

The features that can be demonstrated in this menu are:

- Engine power boost
- Front suspension

HA Menu Screen Select Diagram



BAIL13TR00645FA 1

Engine Power Boost Demonstration

Start the engine and allow it to idle.

Contents

Electrical systems - 55

Transmission control system - 024

FUNCTIONAL DATA



Transmission control valve solenoid

| | |
|--|---|
| Overview – Hydrostat bypass valve | 3 |
| MAXXUM CVT 110 --- INT, MAXXUM CVT 120 --- INT, MAXXUM CVT 130 --- INT | |

Synchronizer position sensors - Overview – F2/R1

| | |
|----------------|-----|
| MAXXUM CVT 110 | INT |
| MAXXUM CVT 120 | INT |
| MAXXUM CVT 130 | INT |

The synchronizer position sensor (1) is located on the right-hand side behind the steps.




Synchronizer position sensor (F2/R1) (B-044)

| | |
|--|-----------------------------------|
| Sensor version | PLCD - Displacement sensor |
| PIN 1 (voltage supply) | Ground |
| PIN 2 (signal) in shift position F2 | approx. 4 V |
| PIN 2 (signal) in shift position R1 | approx. 1 V |
| PIN 3 (power supply) | 5 V |
| PIN 4 (signal) in shift position F2 | approx. 1 V |
| PIN 4 (signal) in shift position R1 | approx. 4 V |
| Tightening torque | 6 - 8 Nm (4.4 - 5.9 lb ft) |

The options available are:

- FRT - EPL installed front-on
- SId - EPL installed side-on



BAIL13TR00823AA 7


To save the desired option, press and hold the navigation "up" or "down" key until the instrument cluster bleeps, indicating that the selection has been saved.

Depress the "menu" key to continue navigating through the "HH" menus.

Air-conditioning system control Temperature control potentiometer - Replace – by 02/2013


| | |
|-------------------------------|------------------------------------|
| MAXXUM 110 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 110 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 115 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 115 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 120 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 120 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 125 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 125 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 130 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 130 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 140 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 140 Multicontroller EP | INT Auto Temperature Control (ATC) |

1. Set the start switch to the "OFF" position.
Remove the panel.




SS08D010 1

2. Disconnect the knob (1) and remove the nut behind.
Disconnect the plug connection.
Replace the potentiometer.



SS08D102 2

3. Tighten the nut and connect the knob (1).
Connect the plugs.
4. Fit the panel.




SS08D010 3

Temperature sensor - Replace (Outside temperature)


| | |
|-------------------------------|------------------------------------|
| MAXXUM 110 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 110 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 115 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 115 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 120 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 120 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 125 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 125 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 130 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 130 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM 140 EP | INT Auto Temperature Control (ATC) |
| MAXXUM 140 Multicontroller EP | INT Auto Temperature Control (ATC) |
| MAXXUM CVT 110 | INT Auto Temperature Control (ATC) |
| MAXXUM CVT 120 | INT Auto Temperature Control (ATC) |
| MAXXUM CVT 130 | INT Auto Temperature Control (ATC) |

Removal


1. Turn the starter switch to the "OFF" position.
Remove the air circulation grating.



2. Remove the air circulation filter element.



3. Disconnect the plug connection.
Remove the sensor.



Fast steering control module - HB - Display stored fault codes


| | |
|-------------------------------|-----|
| MAXXUM 110 EP | INT |
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 EP | INT |
| MAXXUM 140 Multicontroller EP | INT |

NOTE: This menu is used to display fault codes which are stored in the EEPROM of the controller.

NOTE: A maximum of ten fault codes for each sub-system can be stored.

NOTE: Common to all sub-systems.

HB Menu Screen Select Diagram



BAIL06CCM674FVA

BAIL06CCM674FVA 1

Global Positioning System (GPS) control unit - Electronic schema

| | |
|-------------------------------|-----|
| MAXXUM 110 Multicontroller EP | INT |
| MAXXUM 115 Multicontroller EP | INT |
| MAXXUM 120 Multicontroller EP | INT |
| MAXXUM 125 Multicontroller EP | INT |
| MAXXUM 130 Multicontroller EP | INT |
| MAXXUM 140 Multicontroller EP | INT |
| MAXXUM CVT 110 | INT |
| MAXXUM CVT 120 | INT |
| MAXXUM CVT 130 | INT |

Component Identification


| | |
|------------|---|
| 1. | Autoguidance Module (NAV) |
| 2. | Crank Isolate Relay |
| 3. | Manual Override Pressure Sensor |
| 4. | Steering Angle Sensor |
| 5. | Diagnostic Connector |
| 6. | GPS (Global Positioning System) Receiver |
| 7. | Select Switch |
| 8. | Steering Solenoids Isolation Relays |
| 9. | Steering Solenoids |
| 10. | Sensor Ground |
| 11. | Chassis Ground |
| 12. | Power Ground |

Centre LCD

The information displayed in the centre LCD (4), will vary depending on tractor specification. Use the CAL/SEL switch or Enhanced Keypad (where fitted) to toggle between the displays.


The following information may be displayed in the centre LCD.

1. Rear wheel slip (with radar option only)
2. Power Take Off speed (front or rear)
3. 3-point hitch position (front or rear)





BRE1435B 19








When operating the ground drive power take off (GPtO) the display may be used to monitor the letters "GPtO". Depress the CAL/SEL button or Enhanced Keypad (where fitted), to show the GPtO is ON (where fitted).



BRE1741A 21

| Symbol on display | Indicator light | Warning light | Acoustic warning | Cause | Signal |
|---|-----------------|---|------------------|--|--|
|  | - |  flashes 4 s / illuminates | - | Hydraulic pressure for brake force amplification too low: This warning is displayed if the engine is turned off and the pressure is < 15 bar (217.5 psi) . | + 12 V *S-008 (*S-008 switch, exhaust brake) |

Transmission

| Symbol on display | Indicator light | Warning light | Acoustic warning | Cause | Signal |
|---|-----------------|---------------|------------------|---|------------------------------------|
|  | - | - | Action required | Transmission oil too cold. Heat transmission oil. | CAN message from TCM |
|  | - | - | Action required | Driver's seat switch was disengaged for more than 5 s and driver attempts to select a direction of travel. Press clutch pedal once. | CAN message from TCM |
| N | - | - | Action required | Direction of travel selected. Request to shift into Neutral. | CAN message from TCM |
|  | - | - | - | With the PTO switched off, a smaller speed was switched to a higher speed, or from "N" to "1000", "1000E". (Symbol and switching procedure is activated when PTO is switched on). (Only with ESPTO) | CAN message from TCM |
|  | - | - | - | With the PTO switched off, a higher speed was switched to a lower speed, or from "N" to "540E", "540".((Symbol and switching procedure is activated when PTO is switched on). (Only with ESPTO) | CAN message from TCM |
|  | - | - | - | With the PTO switched off, any speed was switched to "N". (Only with ESPTO) | CAN message from TCM |
|  | - | - | - | This symbol shows that the switching procedure was successful. (Only with ESPTO) | CAN message from TCM |
|  | - | - | - | Impermissible switching procedure. With the PTO switched on, an attempt was made to select another speed or "N". (Only with ESPTO) | CAN message from TCM |

Electrical systems - FAULT CODES

| Message | Description | Controller |
|---------|---|------------|
| 3123 | PTO Twist Sensor - Not Calibrated | EDC |
| 3123 | PTO Twist Sensor - Not Calibrated | EDC |
| 3131 | Grid Heater Always Switched On | EDC |
| 3145 | Terminal 15 - No Signal | EDC |
| 3145 | Terminal 15 - No Signal | EDC |
| 3146 | Water detected in fuel | EDC |
| 3154 | Grid Heater Relay - Short Circuit To Battery | EDC |
| 3155 | Grid Heater Relay - Short Circuit To Ground | EDC |
| 3156 | Grid Heater Relay - No Load | EDC |
| 3157 | ECM Not Detected On CAN Bus | EDC |
| 3158 | Engine anti-tamper - security check failed | EDC |
| 3160 | Fan Actuator - Short Circuit to Battery | EDC |
| 3161 | Fan Actuator - Short Circuit to Ground | EDC |
| 3162 | Fan Actuator - Open Load | EDC |
| 3163 | Fan Actuator - No Load | EDC |
| 3166 | Fuel Filter Heater Relay - Short Circuit To Battery | EDC |
| 3167 | Fuel Filter Heater Relay - Short Circuit To Ground | EDC |
| 3168 | Fuel Filter Heater Relay - Open Load | EDC |
| 3169 | Fuel Filter Heater Relay - Signal Not Plausible | EDC |
| 3179 | Time-out Of CAN Message BC2EDC2 | EDC |
| 3180 | Time-out of CAN Message VM2EDC | EDC |
| 3182 | Timeout Of CAN Message RxCCVS | EDC |
| 3183 | Timeout of CAN message TSC1-VR (when active) | EDC |
| 3184 | Timeout of CAN message TSC1-VR (when inactive) | EDC |
| 3250 | Dataset - Variant Defect | EDC |
| 3251 | Dataset - Requested Variant Could Not Be Set | EDC |
| 3253 | ADC Monitoring - Reference Voltage Too Low | EDC |
| 3254 | ADC Monitoring - Reference Voltage Too High | EDC |
| 3255 | ADC Monitoring Test Impulse Error | EDC |
| 3256 | ADC Monitoring Queue Error | EDC |
| 3258 | High side power - short circuit to battery | EDC |
| 3259 | High side power - short circuit to ground | EDC |
| 3260 | Low side power - open load | EDC |
| 3261 | Low side power - short circuit to battery or excess temperature | EDC |
| 3262 | Low side power - short circuit to ground | EDC |
| 3267 | Main relay 3 - short circuit to battery | EDC |
| 3268 | Main relay 3 - short circuit to ground | EDC |
| 3278 | Engine Controller Supply Voltage Too High | EDC |
| 3279 | Engine Controller Internal Supply Voltage Too Low | EDC |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL