



# Service Manual

MC/FC

## Chassis, Mast & Options

EP16K            ETB6A-00011-up

EP18K            ETB6A-50001-up

EP20KC          ETB7A-00011-up

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Serial Number Locations

Mast number


Chassis number

Nameplate



208072

## Electrical Components in Console Box



- 1 Key switch
- 2 Lighting switch

## Maintenance Precautions



The FC model contains a microcomputer. The following are precautions to be observed in performing any maintenance on the FC model.

- (1) When removing the controller cover, make proper provisions to keep out water.
- (2) After using the controller setting switch, check to make sure the control system is in keeping with the truck specifications.

**NOTE**

Improper setting of the system will result in inability to lower the forks in an incremental manner. (See "How to Set Controller.")


- (3) Before performing repairs that require welding, be sure to disconnect the battery plug and the controller from the system connectors.
- (4) When handling the controller by hand, never touch its electrical terminals, or your body charge will rupture some of the electronic elements in the internal controller circuits.



## Troubleshooting

### 1. Preparatory steps

- (1) The system receives supply power when the battery connector is connected, the key switch is turned to the ON position, and the emergency switch is turned OFF. The finger-tip control becomes operable after the seat switch closes (when operator is seated).
- (2) Before deciding to replace a blown fuse, make sure that the harness connectors in the power line are all in sound condition, free of any sign of short-circuit.
- (3) Use the test-use connector (special tool) for checking the connector-to-connector lines for continuity and for reading the voltage across two terminals and the ohmic resistance of a line.
- (4) When coupling or uncoupling a connector, make sure that the key switch is turned OFF and the battery connector is disconnected. Never try to forcibly insert or pull off the connector, or its pins will suffer damage. When connecting a connector, be sure to insert half portion into its self-locking position.
- (5) Before starting troubleshooting work, check the items in the table below.



5. Troubleshooting guide for solenoid control valves

Trouble symptom	Possible cause	Remedy
The pump discharge pressure will not build up	<ol style="list-style-type: none"> <li>1. Sticky plunger in proportioning solenoid of reducing valve, or sticky shuttle in reducing valve</li> <li>2. Open in lead wire or in solenoid coil</li> <li>3. Input current to solenoid too small</li> <li>4. Unload valve stuck open</li> <li>5. Spool stuck in flow-divider valve</li> </ol>	<p>Disassemble and clean by washing. If the plunger is sticky, replace the solenoid. Repair or replace.</p> <p>Check to make sure that solenoid is drawing specified maximum input current.</p> <ul style="list-style-type: none"> <li>• Check unload solenoid for action.</li> <li>• Check unload valve for action.</li> </ul> <p>Disassemble and clean by washing.</p>
Sticky spool	Sticky plunger in proportioning solenoid of reducing valve, or sticky shuttle in reducing valve.	Disassemble and clean by washing. If plunger is sticky, replace solenoid.

## POWER TRAIN

- After installing the parking brake cable, be sure to adjust.

(Refer to BRAKE SYSTEM section.)

- Pour oil into the transfer cases:


Remove oil level plug (1).

Remove oil inlet plug (2).

Pour appropriate oil in the oil inlet. Make sure the oil level reaches the level plug location.

Unit: liter (U.S. gal)

	Left transfer	Right transfer
Oil quantity	1.09 (0.29)	1.86 (0.49)



- Bleeding hydraulic oil line and inspecting oil level

Operate the tilt cylinders in the forward and backward directions to bleed the tilt cylinders. Operate the lift cylinders in the vertical directions to fill the cylinders with oil.

Lower the lift cylinders to the lowest position, and check the oil level gauge. If the oil level is low, add oil to the specified level.

- Checking steering oil line

Operate the steering wheel to make sure that it operates smoothly.

**Suggestions for Reassembly**

1. Inspect the mounting surfaces of cover 1 and main case 11 for dents and burrs, and clean the surfaces.
2. To install oil seal 4, use a jig. Tap the jig to fit the oil seal evenly.
3. To install retainer 7, install o-ring seal in the retainer and push the chamfered face (bore) of retainer toward the hub flange as shown.
4. Tighten nut 9. Rotate the wheel hub a few turns tapping with a plastic hammer. Then check the preload of taper roller bearings 2 and 3.

When tightening the nut, insert vinyl tubes on three symmetrical locations relative to the hub bolt and use a hub holding tool.

Hub holding tool: To be fabricated at service location

**NOTE**




Cut a vinyl tube with an inside diameter of 14 mm (0.55 in.) into pieces of 25 mm (1 in.) in length, and use these vinyl tube pieces to protect the screw sections when using the spring scale for measurement.

**Preload**

Tangential force on hub bolt	59 to 88 N (6 to 9 kgf) [13.3 to 19.8 lbf]
------------------------------	--

5. After checking preload, stake one side of nut 9 with a dull punch to secure the nut in place. Make sure the groove is flattened completely and the flattened area measures more than 4 mm (0.16 in.) in diameter.
6. When installing cover 1 sub-assembly on main case 11, apply a thin coat of liquid gasket (Three bond #1104) on the mounting surfaces. Tighten bolt 18 to the specified torque.

Bolt tightening torque	108 ± 10 N·m (11.0 ± 1.0 kgf·m) [79.6 ± 7.2 lbf·ft]
------------------------	---



**Sequence**



- |                        |                                     |
|------------------------|-------------------------------------|
| 1 Cap                  | 14 Stopper bolt, Lock nut           |
| 2 Nut (outer)          | 15 King pin                         |
| 3 Lock washer          | 16 Shim                             |
| 4 Nut (inner)          | 17 Thrust bearing                   |
| 5 Bearing (inner race) | 18 Knuckle                          |
|                        | 19 Oil seal                         |
|                        | 20 Needle bearing                   |
|                        | 21 Oil seal                         |
|                        | 22 Needle bearing                   |
|                        | 23 Ring, Spherical bearing          |
|                        | 24 Bolt, Spring washer              |
|                        | 25 Pipe, Elbow, O-ring              |
|                        | 26 Elbow, O-ring                    |
|                        | 27 Bolt, Spacer, spring washer, Nut |
|                        | 28 Steering cylinder                |

Remove parts 6 through 8 as an assembly.

- 6 Hub
- 7 Oil seal
- 8 Bearings (outer race)
- 9 Retainer and Bearing (inner) as a unit.
- 10 Bolt, Spring washer, Plain washer, Spacer, Tie rod pin, Grease nipple
- 11 Dust seal, Retainer
- 12 Dust seal, Retainer (cylinder side)
- 13 Tie rod

**Suggestions for Disassembly**


1. Removing retainer and inner bearing 9. Use puller to remove the retainer and inner bearing from the knuckle.
2. Do not remove the taper roller bearings (outer race) 8 that are pressed into hub 6 if acceptable.
3. Inspect the rings and bearings 23, and do not remove unless it is necessary.
4. Keep removed shims 16 in a packed condition (as assembled). This facilitates the determination of the optimum shim thickness at reassembly.




4. Procedure for installing piston seal

(Piston seal consists of inner seal and outer seal)

- (1) Grip the inner piston seal lightly by hand five or six times to soften the seal before installation.
- (2) Place the piston rod in a vice. Use care not to damage the rod when holding it. Slightly apply oil on the inner piston seal. Insert one side of the seal into the fitting groove of the piston, and insert the other side.
- (3) After installing the inner piston seal, install the outer piston seal.




5. Assemble wiper seal and U-seal as shown.




6. Align marks on the cylinder head to marks on the cylinder tube. Tighten nuts 13.

Tightening torque for nuts	$21 \pm 2 \text{ N}\cdot\text{m}$ $(2.1 \pm 0.2 \text{ kgf}\cdot\text{m})$ $[15.5 \pm 1.5 \text{ lbf}\cdot\text{ft}]$
----------------------------	---



Brake Pedal Assembly



- |                 |                   |
|-----------------|-------------------|
| 1 Pedal bracket | 5 Master cylinder |
| 2 Brake pedal   | 6 Adjustment bolt |
| 3 Brake link    | 7 Brake switch    |
| 4 Return spring |                   |

The brake pedal assembly is mounted on the left side of the frame.

The adjustment bolt is used to set the brake pedal height.

The installation length of the brake switch is pre-adjusted. When the pedal is pressed, the switch activates and controls the operating speed of the drive motor.

Brake fluid is supplied to the master cylinder from the reservoir tank located under the left side of the dashboard.


A : Standard value    B : Repair or service limit  
Unit : mm (in.)

Item		Truck Models	1 ton class	2 ton class
Master cylinder	Cylinder body inside diameter 1	A	19.05 <sup>+0.052</sup> / <sub>0</sub> (0.7500 <sup>+0.00205</sup> / <sub>0</sub> )	
	Piston outside diameter 2	A	19.05 <sup>-0.020</sup> / <sub>-0.053</sub> (0.7500 <sup>-0.0079</sup> / <sub>-0.00209</sub> )	
	Clearance between cylinder and piston	A	0.020 to 0.105 (0.00079 to 0.00413)	
		B	0.2 (0.08)	
	Primary cup lip-side outside diameter 3	A	20 <sup>0</sup> / <sub>-0.3</sub> (0.79 <sup>0</sup> / <sub>-0.012</sub> )	
		B	(Replace once a year.)	
	Secondary cup lip-side outside diameter 4	A	20.2 ± 0.2 (0.795 ± 0.008)	
		B	(Replace once a year.)	
	Return spring free-movement length 5	A	46.8 (1.843)	
		B	(Replace once a year.)	
211082				

## Suggestions for Disassembly


### (1) Retaining ring removal

Remove the ring from the housing by prying the end of the ring out of the groove. Do not damage the machined surface.



### (2) Seal gland bushing removal

Position the control spool and control sleeve assembly so that the pin is even with the center of the assembly. Remove the bushing.




### (3) Control spool and sleeve removal

Remove the control spool and sleeve assembly from the housing by pulling it toward the end of the housing opposite to the flange. Remove the pin from the assembly.

#### NOTE

To prevent damage to the housing, slowly pull out the assembly while twisting.




### (4) Control spool and sleeve disassembly

#### NOTE


Before removing the spool from the sleeve, put a mark across the spool and sleeve so that the spool can be installed in the same position.

Pull the control spool from the sleeve enough to permit removal of the centering springs. Remove the centering springs. Remove the spool from the sleeve by pulling it toward the rear end of the sleeve while turning slowly.




# HYDRAULIC SYSTEM

<b>Specifications</b> .....	8 – 1
<b>Finger-tip Control Type (FC model)</b> .....	8 – 3
Description .....	8 – 4
Hydraulic Line .....	8 – 4
Solenoid Control Valve .....	8 – 5
Inlet Section .....	8 – 6
Lift Section .....	8 – 10
Tilt Section .....	8 – 16
Attachment Section .....	8 – 20
Main Relief Valve .....	8 – 24
Lift and Tilt Cylinders .....	8 – 25
Flow Regulator Valve .....	8 – 26
Down Safety Valve .....	8 – 26
<b>Removal and Installation</b> .....	8 – 27
Hydraulic Pump .....	8 – 27
Solenoid Control Valve .....	8 – 28
Lift Cylinders .....	8 – 29
Simplex Mast .....	8 – 29
Duplex and Triplex Masts .....	8 – 32
Tilt Cylinders .....	8 – 35
Suction Strainer and Return Filter .....	8 – 36
<b>Disassembly and Reassembly</b> .....	8 – 37
Solenoid Control Valve .....	8 – 37
Lift Cylinders .....	8 – 56
Tilt Cylinders .....	8 – 62
Flow Regulator Valve .....	8 – 65



**No. 3 (attachment) Spool Switching**


When the section No. 3 spool moves to the right, negative pressure at port A3 is applied to chamber (d). Due to pressure difference from chamber (e), inlet spool 1 positions itself at a location where it is balanced.



## Lift Cylinders

### Procedures and Suggestions for Removal and Installation

#### Simplex Mast



207768


#### Sequence

- |                              |                      |   |
|------------------------------|----------------------|---|
| 1 Nuts                       | 4 Hose guard         | 7 Cylinder clamp,<br>Cushion, Collar, Shims |
| 2 Fork, Lift bracket         | 5 High-pressure hose | 8 Lift cylinder, Bracket                    |
| 3 Return (low-pressure) hose | 6 Set bolt, Shims    |   |

#### Suggestions for Removal

##### 1. Lift bracket removal

- (1) Tilt the mast forward, and lower the inner mast to the bottom. Slacken the lift chains, and remove the nuts from the anchor bolts.
- (2) Tilt the mast back to vertical position. Raise the inner mast until the lift bracket becomes free. Then, back the truck away from the lift bracket and fork assembly.



204873A

## Suggestions for Disassembly

### Spool

- (1) Loosen plug 1 (27 Hex) by rotating two to three turns. Dismount orifice plug 2 (27 Hex) from inlet housing. Spring 3 can be removed together with the plug.
- (2) Slowly pull out spool 4 assembly by holding it at the spring guide section.
- (3) Remove cap screw 5 (5 Hex), and remove spring 6 and valve 7 from spool 4.

### Main Relief Valve

Refer to the “Main Relief Valve Setting Procedures” on page 8-54.

### Pilot Relief Valve

Loosen plug 8 (19 Hex), then remove it together with spring 9 and pilot poppet 10 from inlet housing.

#### NOTE

Do not loosen adjuster kit 11 (17 Hex) unless it is necessary, as loosening the adjuster kit changes relief pressure.


### Inspection After Disassembly

- (1) Check the springs for fatigue.
- (2) Check the sliding surfaces of the piston and valve for damage.

**Shut-off Valve**

**Sequence**

- 1 Poppet
- 2 O-ring
- 3 O-ring
- 4 Plug
- 5 Nut
- 6 Set screw



**Suggestions for Reassembly**

- (1) Install O-ring 2 on poppet 1, and insert the poppet into plug 4.
- (2) Install O-ring 3 on the valve housing.
- (3) Install plug 4 on the valve housing.
- (4) Install set screw 6 (4 Hex) in plug 4 and tighten.

Unit: N·m (kgf·m) [lbf·ft]

Tightening torque	10 to 12 (1 to 1.2) [7.2 to 8.7]
-------------------	--

- (5) Screw nut 5 (12 Hex). While holding set screw 6 (4 Hex) with a wrench to prevent it from turning, tighten the nut.

Unit: N·m (kgf·m) [lbf·ft]


Tightening torque	10 to 12 (1 to 1.2) [7.2 to 8.7]
-------------------	--



**Be sure to tighten the set screw. If the set screw is not tightened, the valve cannot hold the neutral position, thus leading to hazardous situations.**

Reassembly

\*: Parts contained in seal kit



000825B

Sequence

- |  |  |
|--|--|
| <ul style="list-style-type: none"> <li>1 Piston rod, Piston<br/>Install parts 2 through 6 to part 1.</li> <li>2 Check valve</li> <li>3 Washer</li> <li>4 Snap ring</li> <li>5 Piston seal</li> <li>6 Piston guide ring</li> <li>7 Cylinder tube</li> </ul> | <ul style="list-style-type: none"> <li>8 Cylinder head assembly<br/>Install parts 9 through 11 to part 8.</li> <li>9 Seal</li> <li>10 Backup ring</li> <li>11 Wiper ring</li> <li>12 Backup ring, O-ring</li> <li>13 O-ring</li> <li>14 Washer, Screw</li> </ul> |
|--|--|

Suggestions for Reassembly

1. Use all parts in the seal kit to replace removed parts.
2. After installing seal kit parts, apply hydraulic oil before assembling the cylinder tube and piston rod.
3. Fill the space between the cylinder tube and piston rod with the specified amount of hydraulic oil before installing the cylinder head.

4. Tighten the cylinder head to the specified torque.

Cylinder head tightening torque	300 to 350 N·m (30.6 to 35.7 kgf·m) [221.3 to 258.1 lbf·ft]
---------------------------------	---

5. Tighten the screw to specified torque.


Plug tightening torque	3.92 N·m (0.4 kgf·m) [2.9 lbf·ft]
------------------------	---

Amount of hydraulic oil	75 cc (4.58 cu. in.)
-------------------------	-------------------------

## Lift Cylinders and Tilt Cylinders

### (1) Adjustment of mast tilt angle

- (a) Adjust the air pressure of the tires, and place the vehicle on level ground.
- (b) Tilt the masts backward to the maximum position.
- (c) Measure the backward tilt angles of both right and left tilt cylinders.
- (d) To adjust, loosen the socket tightening bolt, turn the tilt cylinder rod, and adjust the cylinder stroke until the right and left tilt cylinders are tilted at the same angle.



**NOTE**


The forward tilt angle of the masts is automatically set when the backward tilt angle is adjusted.

Forward tilt – Backward tilt (STD)	6° – 7°
------------------------------------	---------

### (2) Adjustment of right and left lift cylinder strokes


- (a) Gently raise the inner masts, and observe the right and left piston rod stopping conditions when they reach the maximum lift position.
- (b) If the upper parts of the inner masts shake at the moment of stopping, make adjustment with shims.

Improper adjustment causes the inner mast to slant slightly when the mast is stopped, and also causes the lift cylinder with a longer cylinder stroke to shake when the lift cylinder is stopped.



### Adjustment method


- (1) Raise the inner masts, and place wood blocks under the inner masts. Lower the masts until the inner masts contact the wood blocks.



## **Mechanical Control Type (MC Model)**

For the component descriptions other than control valve, refer to the Finger-tip Control Type (FC model).

# Hydraulic Circuit Diagram (MC)



208137

A: Standard value

Unit: mm (in.)

Items	Truck Models		1 ton class	2 ton class
	Lift cylinders (Duplex mast second cylinders)	[Piston] Inside diameter of cylinder tube 1	A	45 (1.77)
Diameter of piston rod 2		A	32 (1.26)	
Tightening torque for holder 3 N·m (kgf·m) [lbf·ft]		A	170 to 240 (17.3 to 24.5) [125 to 175]	
Holder thread diameter 3		A	M52 × 2	
Bleed screw tightening torque 4 N·m (kgf·m) [lbf·ft]		A	4.5 to 5.0 (0.46 to 0.51) [3.33 to 3.69]	

The diagram shows a cross-section of a hydraulic lift cylinder. Callout 1 points to the inner diameter of the cylinder tube. Callout 2 points to the diameter of the piston rod. Callout 3 points to the holder thread diameter. Callout 4 points to the bleed screw tightening torque.

000825C

## 2. Removing lift cylinder high pressure hoses


Lower the mast to the bottom position, disconnect the hoses at the flow regulator valve.

## 3. Removing tilt cylinders


- (1) Hitch a sling to the mast. Using two eye-bolts and a sling as shown, support the mast with a hoist.



Be sure to use a hoist with enough capacity to support the mast assembly.



- (2) Remove the tilt socket pins, and separate the masts from the tilt cylinders.
- (3) Turn the key switch to ON and pull back the tilt lever to contract the tilt cylinder rods.
- (4) Turn the key switch to OFF and disconnect the high-pressure hose from tilt cylinders.




## 4. Removing mast support bearing caps

- (1) Mark the bearing caps to ensure the correct reassembling before removing them.
- (2) Remove the cap bolts and lift off the mast assembly. Lay it down flat on a level floor.

### NOTE

Lay the mast assembly on the floor so that you have enough space to disassemble the parts.



**Preparation**


With the lift bracket side facing up, place the mast horizontally on wood blocks. Use a wood block as a wedge to prevent the inner and middle masts from sliding.

**Suggestions for Disassembly**

**1. Removing first lift cylinder 3**


- (1) Remove retaining bolts from the first lift cylinder.
- (2) Hitch slings on first lift cylinder 3, and gently remove the cylinder.

Use two slings. Wind or tie slings securely to prevent from slipping.




**2. Removing main rollers 12 and mast strips 11**

- (1) Remove clamp bolts from the second lift cylinders.
- (2) Remove bolts from the upper rod sections of the second lift cylinders, and place the cylinders on the outer mast.
- (3) Check the number of shims and the shim thickness at the rod end sections.
- (4) Lower the inner mast, then remove main rollers 12, mast strips and shims 11.



**3. Removing inner mast 14**

Using slings, lift and remove inner mast 14, steering it to pass over the roller shaft sections of outer mast 19.



**Inspection after Disassembly**


Follow the inspection procedure described in the dual-stage panoramic mast (simplex mast).

**Triple-stage full free panoramic mast  
(Triplex Mast)**




**Turn the main key to the (OFF) position before making the inspection or adjustment of lift chains, anchor bolts and nuts. Place blocks below the forks when they are lifted.**


1. Inspection of Chain Tension
  - (1) On the level ground, place the mast vertical, and lower the forks to the ground. Check the lift cylinders are fully retracted.
  - (2) Raise the forks approx. 100 mm (3.9 in.) from the ground.
  - (3) Turn the key to ○ (OFF) position.
  - (4) Place blocks approx. 90 mm (3.5 in.) high below the forks.
  - (5) Push the chains at the middle point between the chain wheel and chain fixed end on the lift bracket. Check the right and left chains for even tightness. Adjust the primary and secondary chains, totally four chains.
  
2. Adjustment of right and left chain balance
  - (1) Displace the blocks below the forks.  
Turn the key to I (ON) position.
  - (2) Lower the forks to the ground and tilt forward until the tips contact with ground.  
The chains are slackened to facilitate the adjustment.
  - (3) Turn the key to ○ (OFF) position.
  - (4) Fix anchor bolts on the lift bracket (primary chains) and under the inner masts (secondary chains).
  - (5) Turn the double nut (upper) ③ on the lift cylinder to adjust the chain tension.  
When the secondary chains are replaced, adjust their tension relatively tight to reduce the risk of the interference with piping and pulleys.
  - (6) Turn the key to I (ON) position, and place the mast vertical again.
  - (7) Repeat the procedure 1. (2) through (5) to confirm the chain tension.
  
3. Tightening of nuts after the adjustment
  - (1) Hold the anchor bolt on the lift cylinder at two flats with a wrench so as not to twist the chain, then tighten the upper nut ② to the specified torque.
  - (2) Hold the double nut (upper) ③ with a wrench and tighten the double nut (lower) ① to the specified torque.
  
4. When the lift cylinders are fully extended or retracted, check the protrusion of each lift bracket main roller to be 40 % of the roller diameter or less.



207635



102708



207636

- After adjusting the tilt angle, tighten the socket bolts to the specified torque.


Tightening torque for tilt cylinder socket bolt	127 to 152 N·m (13 to 15.5 kgf·m) [94 to 112 lbt·ft]
---	--

### Lift Cylinder Stroke Adjustment

- Gently raise the inner masts, and observe the right and left piston rod stopping conditions when they reach the maximum lift position.


- If the upper parts of the inner masts shake at the moment of stopping, make adjustment with shims.

Improper adjustment causes the inner mast to slant slightly when the mast is stopped, and also causes the lift cylinder with a longer cylinder stroke to shake when the lift cylinder is stopped.




- Adjusting method

- Raise the inner masts, and place wood blocks under the inner masts. Lower the masts until the inner masts contact the wood blocks.
- Loosen the stopper bolt located at the upper part of the lift cylinder that stopped first. Lower the piston rod, and insert a shim at the upper piston rod end.
- Raise the piston rod, then tighten the lift cylinder stopper bolt. Remove the wood blocks from under the inner masts.
- Lower the inner masts gently, and check to see if the piston rods move smoothly until the inner masts reach the lowest position.



### Bleeding lift cylinders

When air and oil remaining inside the air chamber of the rod and inside the rod chamber between the tubes are compressed, they open the check valve and flow out of the cylinder. Therefore, there is no need to bleed the lift cylinders.



Inspection/Maintenance Location and Item		Pre-operation Inspection	Periodic Inspection Interval				Remarks Service Standard
			Every Month or 200 Hours	Every 3 Months or 600 Hours	Every 6 Months or 1200 Hours	Every 12 Months or 2400 Hours	
Chains and chain wheels	Length of lift chains (20 links)	○	○	○	○	○	Allowed lift chain stretch: 1 ton class: 327 mm (12.87 in.) 2 ton class: 392 mm (15.43 in.)
	Chain deformation, damage, lubrication and rusting		○	○	○	○	
	Chain bushing coupling, bolt deformation and damage		○	○	○	○	
	Chain wheel deformation and damage					○	
	Chain wheel bearing rattle		○	○	○	○	
Attachments	Attachment abnormality and mounting conditions	○	○	○	○	○	
Hydraulic system							
Cylinders	Looseness, deformation and damage of rods, rod bolts and rod ends					○	
	Cylinder operating condition	○	○	○	○	○	
	Drift lowering and forward tilting distances				○	○	Drift lowering distance: 50 mm (1.97 in.)/15 min Drift forward tilting distance: 22 mm (0.87 in.)/15 min
	Cylinder oil leaks and damage	○	○	○	○	○	
	Wear and damage of piston and cylinder shaft bearings					○	
Oil pump	Oil leaks, abnormal noise, wear in drive unit, and mounting looseness	○	○	○	○	○	
Hydraulic tank	Oil level and contamination	○	○	○	○	⊗	N level: 13.1 liter (3.5 U.S. gal) H level: 16.7 liter (4.4 U.S. gal)
	Filter clogging				⊗	⊗	
Operation levers	Linkage looseness		○	○	○	○	
	Lever functions		○	○	○	○	
Control valves	Oil leaks	○	○	○	○	○	
	Safety valves	○	○	○	○	○	
	Release pressure measurement					○	18142 $^{+490}_0$ kPa (185 $^{+5}_0$ kgf/cm <sup>2</sup> ) [2632 $^{+71}_0$ psi]





CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Chassis and Mast Model Identification



## Accelerator Control




### Adjustment procedure

- (1) Disconnect the battery plug.
- (2) Fix the stopper bolt to 30 to 32 mm (1.18 to 1.26 in.) from the floor to the upper face of bolt.
- (3) Adjust the mounting angle of the position meter using the adjusting screw so the switch inside the position meter turns on when the accelerator pedal is depressed 1.5 to 2.6 mm (0.06 to 0.10 in.).

Make sure the inside switch ON by continuity between two arrow terminals using a tester.

- (4) Enter Self-diagnostics (page 3-16) cycle to the Accelerator Test (page 3-21). The display should read OFF and Speed 0 without the accelerator depressed. The display should change to ON before the speed changes from 0 to 1. If not then readjust accelerator switch.
- (5) Make sure when the accelerator is fully depressed the display reads Speed 16. If not readjust the stop bolt.




1. Setting switches


The controller has a total of 16 setting switches.

**NOTE**

Use a screwdriver to move each switch. The switch is made of resin; be careful not to damage the switch head in setting.





(a) Switch setting pattern (Black dot indicates switch head.)



(b) Example of setting


Truck: EP16K  
No. of stages: 3 V  
Mast: 4G15A (2-stage panoramic)



205053A

(4) Case 3: Controller's LED (red) will not go ON.

Troubleshooting Procedure




## Outline

### Main controller

The main controller is the heart of the lift truck operating system.

The logic card contains judgment-making functions, and is equipped with a battery discharge indicator and a malfunction diagnostic function.

The main controller is used to operate the drive motors, pump motor.



206793A

### Logic card


The logic card is a printed circuit board located on the main controller panel. Most of the circuits on the board are used to control input and output voltages to and from the microprocessor.

### Microprocessor (MPU)

The software in the microprocessor controls the drive system, pump motor and central vehicle monitor system (CVMS).

### Selector Switches


They are used for setting the BDI and section of some options.



206794


### Auto Regeneration Characteristic

Armature Current Table



207528

Shunt Current Table



207529

Self-diagnosis

Step	Diagnosed item	Operation	Check item	Normal condition		Abnormal condition	
				Monitor display	Operation	Monitor display	Operation
0	Power line voltage	Turn the key switch ON.	Turn the line contactor ON, and check the power line voltage.	1	The line contactor operates instantaneously for reset.	dd	
1	Seat switch	Turn the seat switch ON.	Check the input: OFF→ON→ON	2		1	
2	Forward/reverse lever switch	Shift the lever: N→R→N→F	Check that the input status changes according to the lever position.	3		2	
3	Parking brake switch	Engage and disengage the parking brake.	Check the input: OFF→ON→ON	4		3	
4	Foot brake switch	Press and release the foot brake.	Check the input: OFF→ON→ON	5		4	
5	Accelerator sensor	Operate the accelerator pedal. RUN→DIAG		Indicators flash to indicate a value between 0 and 15 according to the amount of pedal depression. 6	The line contactor closes.	Indication other than that at left 5	
6	Battery voltage	(Automatic)	Check the voltage: 48 V	7		6	
7	Lift switch	Pull and return the lift lever.	Chopper: Check the 2-stage switch input. Contactor: Check the switch input.	8		7	
8	Tilt switch	Pull and return the tilt lever.	Check the input: OFF→ON→ON	9		8	
9	Attach 1 switch	Pull and return the attach 1 lever.	Check the input: OFF→ON→ON	10		9	
10	Attach 2 switch	Pull and return the attach 2 lever.	Check the input: OFF→ON→ON	Flashing 0		10	
11	Hydraulic pump speed check	Pull any hydraulic lever. →RUN		Pump speed indication flashes according to the lever operation. 12		Indication other than that at left	
12	Line contactor	→DIAG		12	The contactor closes.	Indication other than that at left	The contactor opens.
		→RUN		13	The contactor opens.		The contactor closes.
13	Regeneration contactor	→DIAG		13	The contactor closes.	Indication other than that at left	The contactor opens.
		→RUN		14	The contactor opens.		The contactor closes.
14	Pump contactor	→DIAG		14	The contactor closes.	Indication other than that at left	The contactor opens.
		→RUN		done	The contactor opens.		The contactor closes.

Logic Voltage Checks CH2

Logic Terminal	Function	*Normal Voltage	Activated Voltage	Test Procedures
(P3) 39	L&R ARMATURE VOLTAGE	Low	5 to 20 V	Low: Line contactor opens 5 to 20 V: Line contactor closes (Forward/reverse lever in neutral, accelerator pedal OFF)
40	PUMP Tr. VOLTAGE	Low	B+	Low: Line contactor opens B+: Line contactor closes (no pump motor operation)
41	R. Tr. VOLTAGE	Low	5 to 20 V	Low: Line contactor opens 5 to 20 V: Line contactor closes (Forward/reverse lever in neutral, accelerator pedal OFF)
42	L. Tr. VOLTAGE	Low	5 to 20 V	Low: Line contactor opens 5 to 20 V: Line contactor closes (Forward/reverse lever in neutral, accelerator pedal OFF)
43	CONT THERRMO SENSOR	0 to 5 V	0 to 5 V	Controller Temperature
44	GND	0 V	0 V	signal GND
45	R.ARMATURE CURRENT	0 to 0.3 V	0 to 4.2 V	R. ARM Current: Activated by drive motor ON
46	R.ARMATURE CURRENT RTN	0 V	0 V	R. Armature Current Return
47	L.ARMATURE CURRENT	0 to 0.3 V	0 to 4.2 V	L. ARM Current: Activated by drive motor ON
48	L.ARMATURE CURRENT RTN	0 V	0 V	L. Armature Current Return
49	PUMP CURRENT	0 to 0.3 V	0 to 4.2 V	Pump Current: Activated by pump motor ON
50	PUMP CURRENT RTN	0 V	0 V	Pump Current Return
51	15 V	15 V	15 V	15 V = key SW ON, 0 V = key SW OFF
52	15 V	15 V	15 V	15 V = key SW ON, 0 V = key SW OFF
53	15 V	15 V	15 V	15 V = key SW ON, 0 V = key SW OFF
54	EMPTY			
55	PUMP CONTACTOR	B1+	33 to 39 V	B1+: Contactor opens, 33 to 39 V: Contactor closes
56	REGEN CONTACTOR	B1+	33 to 39 V	B1+: Contactor opens, 33 to 39 V: Contactor closes
57	LINE CONTACTOR	B1+	33 to 39 V	B1+: Contactor opens, 33 to 39 V: Contactor closes
58	SPARE			
59	48 VE	B+	B1+	0 V = key SW OFF, B1+ = key SW ON
60	48 VE	B+	B1+	0 V = key SW OFF, B1+ = key SW ON
61	48 VE	B+	B1+	0 V = key SW OFF, B1+ = key SW ON
62	48 VE	B+	B1+	0 V = key SW OFF, B1+ = key SW ON
63	GND	0 V	0 V	signal GND
64	GND	0 V	0 V	signal GND

- Replacement procedure



**Disconnect the battery plug before approaching the controller.**

- Turn the key switch off.
- Disconnect the battery plug.
- Remove the logic card.
- Remove the busbar and other parts, then remove the diode.
- Clean contact surface ①, and place a silicone sheet under the diode.
- Install the diode, and tighten mounting bolts to the following torque.
- Connect the busbar and other parts.

Diode	Tightening torque
D1R, D1L, D1P, D2	$4.5 \pm 0.5 \text{ N}\cdot\text{m}$ $(0.45 \pm 0.05 \text{ kgf}\cdot\text{m})$ $[3.25 \pm 0.36 \text{ lbf}\cdot\text{ft}]$

**(10) Drive board**



- On-vehicle test




**Disconnect the battery plug before approaching the controller.**

**Inspection before test**


- Inspect head capacitors.
- Inspect diodes D1R, D1L, D1P and D2.
- Inspect IGBTs T1D and T2D.
- Inspect current sensors.
- Check continuity between drive board CN1 and logic card.




- (7) Disconnect the harness from the black connector of the drive board assembly. Loosen four screws (M3×6) with washers from the drive board assembly.



- (8) Loosen three screws (M6×14) with washers from bracket C, then remove bracket C.



- (9) Loosen the screw (M6×14) that connects cable B (16A50-03602) to bus plate A.



## Standard resistance-temperature relationships

	Temperature °C	Lower limit kΩ	Standard value kΩ	Upper limit kΩ
<b>Voltage</b>	-20.0	427.4	487.4	555.3
	-19.0	403.6	459.6	523.0
	-18.0	381.2	433.6	492.8
	-17.0	360.2	409.3	464.6
	-16.0	340.6	386.5	438.1
	-15.0	322.1	365.0	413.4
	-14.0	304.7	344.9	390.1
	-13.0	288.4	326.1	368.4
	-12.0	273.0	308.4	348.0
	-11.0	258.6	291.7	328.8
	-10.0	245.0	276.1	310.8
	-9.0	232.2	261.4	293.9
	-8.0	220.2	247.5	278.0
	-7.0	208.8	234.5	263.1
	-6.0	198.1	222.2	249.1
	-5.0	188.0	210.7	235.9
	-4.0	178.5	199.8	233.5
	-3.0	169.6	189.6	211.8
	-2.0	161.1	179.9	200.8
	-1.0	153.1	170.8	190.4
<b>4.8 V</b>	0.0	145.6	162.2	180.6
	1.0	138.4	154.1	171.4
	2.0	131.6	146.4	162.6
	3.0	125.2	139.1	154.4
<b>4.74 V</b>	4.0	119.2	132.3	146.6
	5.0	113.5	125.8	139.3
	6.0	108.0	119.7	132.4
	7.0	102.9	113.9	125.9
	8.0	98.07	108.4	119.7
<b>4.68 V</b>	9.0	93.48	103.2	113.9
	10.0	89.14	98.32	108.4
	11.0	85.02	93.68	103.1
	12.0	81.11	89.29	98.21
	13.0	77.41	85.13	93.55
<b>4.60 V</b>	14.0	73.89	81.19	89.13
	15.0	70.56	77.45	84.95
	16.0	67.40	73.91	80.98
	17.0	64.39	70.55	77.23
	18.0	61.54	67.36	73.67
<b>4.50 V</b>	19.0	58.83	64.34	70.29
	20.0	56.26	61.47	67.09

$$R (100^{\circ}\text{C}) = 3.3 \text{ k}\Omega \pm 3\%$$


$$B (0/100) = 3970 \text{ K} \pm 2\%$$

## TROUBLESHOOTING FOR CONTROL CIRCUITS


Right Drive Motor, Overheating .....	4 – 1
Left Drive Motor, Overheating .....	4 – 2
Pump Motor, Overheating .....	4 – 3
Controller, Overheating .....	4 – 4
Right Drive Motor, Worn Brushes .....	4 – 5
Left Drive Motor, Worn Brushes .....	4 – 6
Pump Motor, Worn Brushes .....	4 – 7
Brake Oil, Low Level .....	4 – 8
Right Drive Motor, Faulty Armature Circuit .....	4 – 9
Right Drive Motor, Transistor Wire Breakage .....	4 – 10
Right Drive Motor, Shorted Transistor .....	4 – 11
Right Drive Motor, Faulty Transistor Drive .....	4 – 12
Right Drive Motor, Faulty Current Sensor .....	4 – 13
Right Drive Motor, Armature Over-current .....	4 – 14
Right Drive Motor, Stall Timer .....	4 – 15
Right Drive Motor, Faulty Field Circuit .....	4 – 16
Right Drive Motor, Faulty Field Drive .....	4 – 17
Right Drive Motor, Field Over-current .....	4 – 18
Left Drive Motor, Faulty Armature Circuit .....	4 – 19
Left Drive Motor, Transistor Wire Breakage .....	4 – 20
Left Drive Motor, Shorted Transistor .....	4 – 21
Left Drive Motor, Faulty Transistor Drive .....	4 – 22
Left Drive Motor, Faulty Current Sensor .....	4 – 23
Left Drive Motor, Armature Over-current .....	4 – 24
Left Drive Motor, Stall Timer .....	4 – 25
Left Drive Motor, Faulty Field Circuit .....	4 – 26
Left Drive Motor, Faulty Field Drive .....	4 – 27
Left Drive Motor, Field Over-current .....	4 – 28
Pump Motor, Faulty Circuit .....	4 – 29
Pump Motor, Transistor Wire Breakage .....	4 – 30
Pump Motor, Shorted Transistor .....	4 – 31
Pump Motor, Faulty Transistor Drive .....	4 – 32
Pump Motor, Faulty Current Sensor .....	4 – 33
Pump Motor, Armature Over-current .....	4 – 34
Line Contactor, Abnormality .....	4 – 35

**Problem: Right Drive Motor, Faulty Armature Circuit**

Indication: "10" display. Vehicle operation (drive and pump motors) disabled.



When T1R IGBT, D1R diode, D2 diode and head capacitor are normal, consult your lift truck manufacturer because the Drive Board, H Bridge Card and CS1 current sensor may be abnormal.



207699

**Problem: Left Drive Motor, Faulty Armature Circuit**

Indication: "20" display. Vehicle operation (drive and pump motors) disabled.

(1) Situation  
Indication: "20" display. Vehicle operation disabled.

(2) Cause  
Faulty left motor armature circuit, faulty line contactor, faulty regeneration contactor, faulty D1L diode, faulty D2 diode, faulty left motor armature wiring, faulty head capacitor, faulty T1L IGBT, faulty CS2 current sensor, faulty wiring in other parts, faulty logic card, faulty drive board, faulty H bridge card.

(3) Inspection  
Disconnect battery plug. Inspect line and regeneration contactor tips for wire breakage and melting. Make sure each contactor tips moves freely.

No broken or shorted wire Broken or shorted wire

(4) Inspect left motor armature wiring for wire breakage and shorting.

No broken or shorted wire Broken or shorted wire

(15) Correct or replace faulty components (regeneration contactor, line contactor).

(5) Check T1L IGBT, D1L diode, D2 diode and head capacitor for abnormality.

Acceptable Unacceptable

(14) Correct or replace left motor, or correct or replace wiring.

(6) Test drive board.

Acceptable Unacceptable

(13) Replace faulty components (T1L, D1L, D2, head capacitor).

(7) Test H bridge card.

Acceptable Unacceptable

(12) Replace drive board.

(8) Check CS2 current sensor for abnormality.

Acceptable Unacceptable



(11) Replace H bridge card.

(9) Replace logic card.

(10) Replace CS2 current sensor.



**Problem: Pump Motor, Faulty Circuit**

Indication: "30" display. Vehicle operation (drive and pump motors) disabled.



**Problem: Right Diode, Abnormality**

Indication: "44" display. Vehicle operation disabled.



207708

**Problem: AC Lever, Abnormality**

Indication: "54" display. Faulty operation circuit. Related function disabled.

**(1) Situation**


Indication: "54" display. Related function disabled.

**(2) Cause**

Faulty operating lever, faulty lever wiring (wire breakage, shorting), faulty AC controller.

**(3) Inspection**

Conduct inspection according to troubleshooting for AC controller.




207717

**Problem: AC Controller Lever, Faulty Setting**


Indication: "H5" display. Faulty operating lever setting. All functions disabled.

<p>(1) Situation Indication: "H5" display. All functions disabled.</p>
<p>(2) Cause Operating lever not in proper neutral position, faulty wiring (wire breakage, shorting) of lever, faulty AC controller.</p>
<p>(3) Inspection Conduct inspection according to troubleshooting for AC controller.</p>



207717

## 7. Removing brake components




206824

- (1) Loosen the parking brake lever, and remove parking brake cable assemblies (i) (L.H.) and (ii) (R.H.).

Disconnect the parking brake cables at the calipers, and keep the cables together on the frame near the center brake.

- (2) Position an oil receiving pan, and disconnect brake fluid tube (iii) at the master cylinder.
- (3) Disconnect brake pipes (iv, v) (L.H., R.H.) at the master cylinder. Disconnect the branch brake hoses (L.H., R.H.) from the brake pipes.
- (4) Remove brake pedal assembly (vi).

Pump Motor



The hydraulic pump which supplies oil to the hydraulic system is driven by a series-wound self-ventilating type direct current (DC) motor.

With (+) and (-) cables connected to A1 and to S2 respectively, the motor rotates clockwise as viewed from the output shaft.

Field coils are fastened to the inside of the motor frame. The motor coils are covered with heat resistive insulation.

The armature consists of a shaft, cores, windings and a commutator and is supported with a sealed single row ball bearing at each end.


Removal of the brush cover provides easy access to the brushes and commutator for inspection.

The motor has four brushes, each being held by one brush holder. The brush springs evenly press the brushes against the commutator, compensating for brush wear.


The motor is cooled by a fan mounted on the armature shaft and rotates with the shaft.

The motor is provided with a brush wear sensor and a thermal sensor which turn on warning lamps when brush wear and undue heating are detected, respectively.


The motor is activated when the key switch is turned to ON, the seat is depressed to close the seat switch and a lift, tilt or auxiliary lever is moved. The motor speed is variable according to the amount of movement of the lever used.



Pump motor



208090



206910

**Sequence**

- |                            |                     |             |
|----------------------------|---------------------|-------------|
| 1 Cover                    | 5 Commutator        | 9 Armature  |
| *2 Brushes with spring set | 6 Brush holder      | 10 Stator   |
| 3 Fan                      | 7 Gasket            | *11 Bearing |
| 4 Connection plate         | 8 Drive end bracket | *12 Bearing |

**Start by:**

- (1) Before disassembly, prepare parts indicated by an asterisk (\*) above.
- (2) Place a work table under the crane.
- (3) Arrange the following tools.  
Tester, spring scale, wires, eye bolt (for lifting armature), wrenches (inch size), gear puller, calipers, installer, sand paper (#600)


# TRANSFER UNITS

Specifications .....	7 – 1
Structure and Functions .....	7 – 2
Procedures and Key Points for Disassembly and Reassembly.....	7 – 4
Disassembly .....	7 – 4
Inspection after Disassembly .....	7 – 5
Reassembly .....	7 – 6
Service Data .....	7 – 8

# REAR AXLE

Structure .....	8 – 1
Rear Axle .....	8 – 1
Steering Cylinder .....	8 – 2
Procedures and Key Point for Removal and Installation .....	8 – 3
Rear Wheels .....	8 – 3
Rear Axle Assembly .....	8 – 4
Procedures and Key Point for Disassembly and Reassembly .....	8 – 6
Rear Axle Assembly .....	8 – 6
Disassembly .....	8 – 6
Reassembly .....	8 – 8
1. Installing Steering Cylinder and Hydraulic Pipe .....	8 – 8
2. Assembling Knuckle and King Pin .....	8 – 9
3. Assembling Rear Axle Hub .....	8 – 12
Steering Cylinder .....	8 – 14
Disassembly .....	8 – 14
Reassembly .....	8 – 16
Adjustment .....	8 – 18
Adjusting of Minimum Turning Radius .....	8 – 18
Troubleshooting .....	8 – 19
Service Data .....	8 – 20

2. Assembling Knuckle and King Pin



208152

**Sequence**


Assemble parts, knuckle 1 through boot 8, and insert this sub-assembly into the rear axle housing.

- |                                     |   |
|-------------------------------------|---|
| 1 Knuckle (with bearing outer race) | 10 Shims  |
| 2 Spherical bearing                 | 11 King pin plate                               |
| 3 Ring                              | 12 Bolt, Spring washer                          |
| 4 O-ring                            | 13 Cap  |
| 5 Bearing (inner race)              | 14 Retainer, Dust seal (knuckle side)           |
| 6 Oil seal                          | 15 Tie rod                                      |
| 7 Retainer and cover as a unit      | 16 Pin (knuckle side)                           |
| 8 Boot                              | 17 Retainer, Dust seal (steering cylinder side) |
| 9 King pin and O-ring               | 18 Pin (cylinder side)                          |
|                                     | 19 Spacer, Plain washer, Lock washer, Bolt      |
|                                     | 20 Grease nipple                                |

## Troubleshooting

Heavy steering wheel operation	<ul style="list-style-type: none"> <li>— Insufficient grease in rear axle or steering parts</li> <li>— Faulty steering system</li> </ul>	<ul style="list-style-type: none"> <li>— Supply grease.</li> <li>— Refer to STEERING SYSTEM, troubleshooting section.</li> </ul>
Slow return of steering wheel	<ul style="list-style-type: none"> <li>— Over-tightening of steering system or rear axle parts</li> </ul>	<ul style="list-style-type: none"> <li>— Retighten to the specified torque.</li> </ul>
Steering wheel prone to move to one side	<ul style="list-style-type: none"> <li>— Gap in external diameters between right and left tires</li> </ul>	<ul style="list-style-type: none"> <li>— Replace with genuine tires.</li> </ul>
Shudder of steering wheel	<ul style="list-style-type: none"> <li>— Wear or breakage of taper roller bearing</li> <li>— Faulty steering system</li> </ul>	<ul style="list-style-type: none"> <li>— Replace the bearing.</li> <li>— Refer to STEERING SYSTEM, and inspect or repair.</li> </ul>
Uneven or early wear of rear tires	<ul style="list-style-type: none"> <li>— Misalignment of wheels</li> <li>— Different tire types for right and left wheels</li> </ul>	<ul style="list-style-type: none"> <li>— Realign wheels.</li> <li>— Replace with genuine tires.</li> </ul>

## Parking Brake Lever



208138

- |              |           |
|--------------|-----------|
| 1 Lever body | 5 Stopper |
| 2 Gear       | 6 Spring  |
| 3 Pawl       | 7 Hook    |
| 4 Grip       | 8 Pin     |

The parking brake lever is mounted on the left side of the dashboard.

When the grip is pulled, the parking brake cable activates the pad assembly of the caliper to clamp the brake disc and apply stopping force.

Notch 3 engages with gear 2 to retain the lever in position. To release the parking brake, pull the grip and press stopper 5. This disengages the gear from the notch, and the lever can be returned to the original position.

The maximum lever stroke is 50 degrees. There are a total of 10 gear teeth. Adjust the parking brake so that the brake activates and applies force when the third or fourth tooth of gear 2 engages with the pawl.


Unit: N (kgf) [lbf]

Grip operating effort	294 (30) [66]
-----------------------	---------------

# STEERING SYSTEM

Specifications .....	10 – 1
Structure and Functions .....	10 – 2
General .....	10 – 2
Steering Control Valve .....	10 – 3
Procedures and Key Points for Removal and Installation .....	10 – 4
Steering Column Assembly .....	10 – 4
Steering Control Valve .....	10 – 6
Disassembly .....	10 – 6
Inspection .....	10 – 8
Reassembly .....	10 – 9
Hydraulic Circuit .....	10 – 14
Troubleshooting .....	10 – 15
Service Data .....	10 – 16

## Reassembly



### Sequence

- |  |  |
|--|--|
| 1 Long housing   | 7 Thrust needle, Race bearings                       |
| 2 Check valve, Check ball retainer, Ball, O-ring, Check seat and Set screw | 8 Seal gland bushing, Oil seal, Dust seal and O-ring |
| 3 Control sleeve   | 9 Retaining ring                                     |
| 4 Control spool  | 10 Drive shaft, Spacer plate and O-ring              |
| 5 Centering springs  | 11 "Gerotor" set, O-ring                             |
| 6 Pin  | 12 End cap, O-ring, Spacer and Bolts                 |

### Start by :

- (a) Replace worn or defective parts.
- (b) Wash all metal parts and blow dry.
- (c) Replace O-rings and seals.
- (d) Apply grease to O-rings and other sealing parts.


## Mast Systems

This manual applies to the following vehicle models (names).

Model \ Mast Types	Dual-stage Panoramic Mast System	Dual-stage Full Free Panoramic Mast System	Triple-stage Full Free Panoramic Mast System
EP16K	2G15A □□	2H15A □□	2J15A □□
EP18K			
EP20KC	1G20A	1H20A	1J20A

NOTE □□ : Maximum fork lift height [118 in. (30 : 3000 mm)]


### Mast Type Code Stamping Position



### Mast Types

Code	Mast Type
G	Dual-stage panoramic masts Simplex mast
H	Dual-stage full free panoramic masts Duplex mast
J	Triple-stage full free panoramic masts Triplex mast

### Explanation of Mast Type Code




**Installation**

To install, follow the removal sequence in reverse, and service as follows.

1. Procedure for installing mast support bushings 7 and caps 6.
  - (1) Apply grease to the inner surfaces of caps and mast support bushings.
  - (2) Install mast support bushings 7 and caps 6, making sure that the sides with larger chamfered area face toward the center of the vehicle.
  - (3) Be sure to tighten the support tightening bolts securely.


	1-ton class	2-ton class
Bolt tightening torque	74 N·m (7.5 kgf·m) [54 lbf·ft]	178 N·m (18.2 kgf·m) [132 lbf·ft]



2. Adjust the chain tensions.  
(Refer to the Inspection and adjustment section.)

Tighten the nuts to the specified torque.

	Tightening Trque
Upper nut ②	57 N·m (5.8 kgf·m) [42.0 lbf·ft]
Double nut (lower) ①	98 N·m (10.0 kgf·m) [72.3 lbf·ft]



3. Bleeding lift cylinders.
 

In the dual-stage full free panoramic mast, only the second lift cylinders are provided with air bleeding valves.

The other lift cylinder does not require air bleeding since it is an internal drain type cylinder.
4. After proper operation is confirmed, check the oil level.

**NOTE**


The lift bracket disassembly procedure is the same as for the dual-stage panoramic mast.

**Preparation**

With the lift bracket side facing up, place the mast horizontally on wood blocks. Place a wood block as a wedge to prevent the inner and middle masts from sliding.


**Suggestions**

1. Removing first lift cylinder 4
  - (1) Remove retaining bolts from the first lift cylinder.
  - (2) Hitch slings on lift cylinder 4, and gently remove the cylinder.  
Use two slings. Wind or tie slings securely to prevent slipping.




2. Removing inner mast and main rollers
 

Lower inner mast 12 until the main rollers can be removed. Remove main rollers 10, 11 and mast strips 9.




3. Removing inner mast
 

Using slings, lift and remove the inner mast 12, steering it clear of the roller shaft sections of the middle mast.



- (4) Insert a bar between the outer and inner masts on the indicator side, and push the inner mast to the opposite side.
- (5) Read the indicator.


Clearance J	0.1 to 0.5 mm (0.004 to 0.020 in.)
-------------	---------------------------------------



- (6) If the clearance J is out of specification, adjust by shims.

**NOTE**



Refer to Main Roller Shim Replacement.



3. Lateral clearance adjustment on outer mast main rollers

- (1) Raise the mast to the top.
- (2) Set a dial indicator on the outer mast with its contact point rested on the inner mast.
- (3) Go over to the opposite side of the mast, and push the outer mast against the inner mast with a bar. Set the indicator to zero.
- (4) Insert a bar between the outer and inner mast, and push the inner mast to the opposite side.
- (5) Read the indicator.

Clearance K	0.1 to 0.5 mm (0.004 to 0.020 in.)
-------------	---------------------------------------



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL