

**FG70 FG75
FG85 FG105
SERIES B**

MOTOR GRADERS

SERVICE MANUAL SET

73160217

CUT ON LINE & INSERT IN BINDER TAB

**FG70 FG75 FG85 FG105
SERIES B**

SERVICE MANUAL SET CONSISTS OF

73160219	SERVICE MANUAL TEXT
73160218	INDEX CARD
73155591	2 INCH BINDER
73160587	CLARK 24000 TRANSMISSION SERVICE MANUAL
73160588	CLARK 28000 TRANSMISSION SERVICE MANUAL

**73160586 ZF WG200 TRANSMISSION SERVICE MANUAL IS NOT INCLUDED
IN THE SET BUT CAN BE PURCHASED SEPARATELY**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SAFETY RULES

Always before leaving the operator's seat and after making certain all people are clear of the machine, slowly lower the attachments or tools flat to the ground in a positive ground support position. Move any multi purpose tool to positive closed position. Return the controls to hold. Place transmission control in neutral and move engine controls to off position. Engage all control locks, set parking brake, and open and lock the master (key, if so equipped) switch. Consult Operation and Maintenance Instruction Manual.

Always follow the shut down instructions as outlined in the Operation and Maintenance Instruction Manual.

MAINTENANCE

Do not perform any work on equipment that is not authorized. Follow the Maintenance or Service Manual procedures.

Machine should not be serviced with anyone in the operator's seat unless they are qualified to operate the machine and are assisting in the servicing.

Shut off engine and disengage the Power Take Off lever if so equipped before attempting adjustments or service.

Always turn the master switch (key switch if so equipped) to the OFF position before cleaning, repairing, or servicing and when parking machine to forestall unintended or unauthorized starting.

Disconnect batteries and TAG all controls according to local or national requirements to warn that work is in progress. Block the machine and all attachments that must be raised per local or national requirements.

Never lubricate, service or adjust a machine with the engine running, except as called for in the Operation and Maintenance Instruction Manual. Do not wear loose clothing or jewelry near moving parts.

Do not run engine when refueling and use care if engine is hot due to the increased possibility of a fire if fuel is spilled.

Do not smoke or permit any open flame or spark near when refueling, or handling highly flammable materials.

Always place the fuel nozzle against the side of the filler opening before starting and during fuel flow. To reduce the chance of a static electricity spark, keep contact until after fuel flow is shut off.

Do not adjust engine fuel pump when the machine is in motion.

Never attempt to check or adjust fan belts when engine is running.

When making equipment checks that require running of the engine, have an operator in the operator's seat at all times with the mechanic in sight. Place the transmission in neutral and set the brakes and lock. **KEEP HANDS AND CLOTHING AWAY FROM MOVING PARTS.**

Avoid running engine with open unprotected air inlets. If such running is unavoidable for service reasons, place protective screens over all inlet openings before servicing engine.

Do not place head, body, limbs, feet, fingers, or hands near rotating fan or belts. Be especially alert around a pusher fan.

Keep head, body, limbs, feet, fingers, or hands away from bucket, blade or ripper when in raised position.

If movement of an attachment by means of machine's hydraulic system or winches is required for service or maintenance, do not raise or lower attachments from any position other than when seated in the operator's seat. Before starting machine or moving attachments or tools, set brakes, sound horn and call for an all clear. Raise attachments slowly.

Never place head, body, limbs, feet, fingers, or hands into an exposed portion between uncontrolled or unguarded scissor points of machine without first providing secure blocking.

Never align holes with fingers or hands - Use the proper aligning tool.

Disconnect batteries before working on electrical system or repair work of any kind.

Check for fuel or battery electrolyte leaks before starting service or maintenance work. Eliminate leaks before proceeding.

BATTERY GAS IS HIGHLY FLAMMABLE. Leave battery box open to improve ventilation when charging batteries. Never check charge by placing metal objects across the posts. Keep sparks or open flame away from batteries. Do not smoke near battery to guard against the possibility of an accidental explosion.

Do not charge batteries in a closed area. Provide proper ventilation to guard against an accidental explosion from an accumulation of explosive gases given off in the charging process.

Be sure to connect the booster cables to the proper terminals (+ to +) and (- to -) at both ends. Avoid shorting clamps. Follow the Operation and Maintenance Instruction Manual procedure.

Due to the presence of flammable fluid, never check or fill fuel tanks, storage batteries or use starter fluid near lighted smoking materials or open flame or sparks.

Rust inhibitors are volatile and flammable. Prepare parts in well ventilated place. Keep open flame away - **DO NOT SMOKE.** Store containers in a cool well ventilated place secured against unauthorized personnel.

Do not use an open flame as a light source to look for leaks or for inspection anywhere on the machine.

DO NOT pile oily or greasy rags - they are a fire hazard. Store in a closed metal container.

SECTION 1 ENGINE RELATED COMPONENTS

TABLE OF CONTENTS


TOPIC	TITLE	PAGE
1.1	GENERAL DESCRIPTION	1-1
1.2	REPAIR PROCEDURES.....	1-2
1.2.1	Removal and Installation.....	1-2
1.2.2	Muffler	1-13
1.2.3	Air Cleaner	1-14
1.2.4	Belts.....	1-14
1.2.4.1	Fan Belts, FG70, 70A only	1-14
1.2.4.8	Fan Belts, all others	1-15
1.2.4.14	Alternator Belts	1-15
1.2.5	Fuel Tank.....	1-17
1.2.6	Throttle Linkage and Fuel Shut-off.....	1-19
1.2.7	Radiator	1-19
1.2.8	Cold Weather Start Aid (Special Equipment).....	1-22
1.3	SPECIFICATIONS	1-24
1.3.1	Torques.....	1-24
1.3.2	Throttle Linkage Adjustment	1-26
1.3.3	Fan Belts and Tightener.....	1-28
1.3.4	Fan Drive Bearing Preload and Torque.....	1-29
1.3.5	Fan Belt Tightener.....	1-30

1.2.1 ENGINE REMOVAL

1.2.1.28

Disconnect electric cable and tube from transmission valve.


T-95032



1.2.1.29

Disconnect drive shaft.



T-95034



1.2.1.30

Disconnect transmission oil temperature gauge and parking brake.

T-101229



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

1.2. ENGINE ACCESSORIES REMOVAL

1.2.6 THROTTLE LINKAGE and FUEL SHUT-OFF

1.2.6.1

Should the throttle linkage and fuel shut-off ever need to be removed or replaced, it would be for one of four reasons: The fuel pump or engine must be removed, the levers and linkage at the fuel pump are damaged, the push-pull cables are corroded or damaged, or the cab is to be removed. Refer to Section 8 for Cab Removal. Refer to Engine Removal for disconnecting the throttle linkage. Refer to Specifications for torques and adjustments.

1.2.7 RADIATOR

1.2.7.1


Shut off master electrical switch.



WARNING

Always turn the master switch to the off position before cleaning, repairing, servicing or parking the machine to prevent injury.


T-95508



1.2.7.2

Drain the radiator coolant by means of a fitting located on the end of the transmission heat exchanger.


T-95446



1.2.7.3

Remove the top and side access covers from the radiator shell.

T-95462





1.3 SPECIFICATIONS

1.3.4 FAN DRIVE BEARING PRELOAD & TORQUE

Torque nut to 16.2 daNm (120 lbs. ft.) minimum. Continue to torque to align cotter pin hole with slot in nut.

	mm	inch
Bearing I.D.		
Bearing O.D.		
Shaft O.D.	35.0114-35.0215	1.3784-1.3788
Housing I.D.	71.9988-72.0242	2.8346-2.8356



T-101227

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

2.2 REMOVAL & INSTALLATION

2.2.21

Install a suitable lifting device to support radiator guard.



WARNING

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.

2.2.22

Remove radiator guard.


T-95717



2.2.23

Disconnect hoses and tube from hydraulic pump.

T-95027



2.2.24

Disconnect hoses from ground drive pump.

T-95028



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

2.3 SPECIFICATIONS

2.3.5 TORQUE SPECIFICATIONS FOR MODEL FG70, FG70A

	daNm	ft. lbs.
Dipstick bracket to flywheel housing capscrew	8.7	64
Dipstick clamp to bracket	10.2	75
Engine mount to engine capscrews	8.7	64
Engine to frame center bolt	100	737
Engine to frame mount capscrews	30	220
Muffler stand to engine capscrew	12.7	94
Muffler to adapter stand bolts	3.0	22
Transmission mount to transmission capscrews	36.6	270
Transmission to frame center bolt	100	737
Transmission to frame mount capscrews	30	220
Fan drive mounting capscrews	10.2	75
Steering & brake pump mounting capscrews	10.2	75
Implement pump mounting capscrews	10.2	75
Steering pump to brake pump mounting capscrews	6.5	50
Transmission to flywheel housing capscrews	6.5	50
Torque converter ring gear capscrews	3.3	24
Transmission shift lever pivot bolts	10.2	75
Transmission shift lever pivot bracket capscrews	4.1	30
Transmission shift tower mounting capscrews	10.2	75
Transmission shift cable adjustment bracket	4.1	30
Shift cable to control lever jam nuts	1.2	8.8
Control assembly to shift tower capscrews	2.4	17.7
Shift tower, access cover hinge screws	1.2	8.8
Parking brake lever support mounting capscrews	12.6	93
Parking brake lever to support mounting capscrews	5.1	37.6
Parking brake linkage pivot pin (at support) capscrew	5.1	37.6
Parking brake linkage cable clamp (at support) capscrew	1.4	10.3
Parking brake linkage pivot bracket (at transmission) mounting capscrew	7.8	57.5
Transmission oil cooler mounting capscrew & nut	4.1	30
Tubes from radiator to transmission oil cooler capscrew	4.1	30

TESTING

T-86002

3.3 NoSPIN TEST


3.3.1

Use a jack or hoist of sufficient capacity to raise the rear axle off the floor. Tires must be completely free of drag.




WARNING

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.



LEFT WHEEL




3.3.2

Start the test by simultaneously rotating a wheel on each tandem in a forward direction as far as possible. Both should stop after a few inches of movement.


3.3.3

With the right wheel held firmly forward against the stop, rotate the left wheel rearward. The left wheel should overrun, and you may hear a clicking or indexing noise. The wheel will not disengage unless the right wheel is held firmly.



3.3.4

Rotate both wheels rearward as far as possible. Again both wheels should turn only a few inches.




3.4 REPAIR PROCEDURES

3.4.3.11

Tie shims together for reassembly purposes.

T-91827



3.4.3.12


Lift the bull gear from the housing using adequate lifting facilities. Bull gear weighs 100 kg (220 lbs.).



WARNING

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.


T-91828



3.4.3.13

The bull gear bearings should not be removed unless the bearing is failed. Removing the bearing will destroy the bearing. If working on an articulated machine, see the next six steps for rebuild. If not, then go to 3.4.3.20.

T-91829



3.4.3.14


A new NoSPIN differential should not be taken apart prior to installation.

3.4 REPAIR PROCEDURES

3.4.3.51

Measure the gap between the end cap and the housing. Make a shim pack to this measurement and install it between the end cap and the housing.


T-91839



3.4.3.52

Re-measure the ring gear shaft rolling torque to insure that the rolling torque remains the same. If the rolling torque changes, then the previous three steps must be repeated.


T-91840



3.4.3.53

Measure the distance from the pinion gear face to the carrier flange. Record this measurement. These are the dimensions needed to set the pinion depth. Dimension A^1 is given in the specification section. Dimension A^2 is etched on the ring gear as MD. Dimension A^3 was just measured. To find the correct shim pack, add A^2 and A^3 and subtract from A^1 . The remainder is the shim pack.

T-86143



3.4.3.54

$$S = (A^2 + A^3) - A^1$$

$$S = 4.301 + 7.606 - 11.757$$

$$S = 0.150 \text{ inch}$$

S = Shim pack thickness

$$S = (A^2 + A^3) - A^1$$

$$S = 4.301 + 7.606 - 11.757$$

$$S = 0.150 \text{ in}$$

3.4 REPAIR PROCEDURES

3.4.4.4

Apply blocks under tandem case. Lower machine onto blocks. Repeat the same procedure for the other side. Disconnect electrical power. Be sure blocking does not interfere with oil draining.



WARNING

When supporting machine component must be removed or installed and jacks are used, be sure the support of the jack at the machine and on the ground are appropriate to the load applied. Transfer the load to authorized blocking or jack stands immediately. Do not work on or under the machine or its components while supported only on a jack or other lifting device, according to local or national requirements.

3.4.4.5

If the wheel and hub are to be pulled together, remove the brake caliper. See section 3.4.5.

3.4.4.6

Set brakes and disconnect electrical power.

3.4.4.7


Pull wheel from shaft. Use slings around the tire as shown to lift the tire and wheel. Repeat procedure for front tandem wheel.




WARNING

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.


T-86002




T-95115



T-86004



T-86008



3.4 REPAIR PROCEDURES

3.4.4.44


Loop the chain over the drive sprocket. Connect the two ends of the chain with the master link. Keep the master link in position by installing the **special cotter pins**. The chain may need to be pried over to get the master link through the chain ends.

T-91876



WARNING


Use proper tools to bring holes into alignment. "Do not use fingers or hands."



3.4.4.45

Heat the bearing to 121°C (250°F) and install the bearing onto the rear axle. Hold the bearing in place with the snap ring.


T-86057



3.4.4.46

Install Permatex to the cover and axle. Pack bearing in grease 70604026.


T-86059



3.4.4.47

Install the bearing cover onto the case. Tighten capscrews to specified torque. Use guide studs and puller capscrews to draw the cover over the bearing.

T-86060



Section 3.6.3 REBUILD PROCEDURES FOR ARTICULATED AXLE

Item	Rolling torque	Nm	in lb
1	Pinion shaft bearings	2.35-4.5	20-40
2	Ring gear shaft bearings	1.17-3.52	10-30
	Radius of shaft at gear teeth for figuring rolling torque is 64.2mm (2.529in)		
	Backlash	mm	in
3	Backlash tolerance	.028-.05	.007-.012
	Torques	daNm	ft lb
A	Ring gear cap capscrews	12.2-13.6	90-100
B	Pinion cartridge to center housing capscrew	12.2-13.6	90-100
C	Extension housing to center housing capscrews	36.6-40.7	270-300
D	Extension housing to bearing retainer capscrews	12.2-13.6	90-100
E	Pinion cover bolts	12.2-13.6	90-100
F	Backplate to housing capscrews	12.2-13.6	90-100
G	NoSpin Differential case bolts		
	Wheel to shaft nut	30.2-33.2	223-245
	Axle support to pinion cover capscrews	44.1-42.5	
	Axle support to top capscrews	40.8-44.9	
	Axle support to bottom capscrews	5.04	
	Shim thickness	mm	in
J	Extension housing to center housing bearing preload	.01-.02	.004-.008
K	Extension housing bearing preload	.01-.02	.004-.008
	Dimensions	mm	in
	Differential case capscrews	8.4-9.2	62-68
A'	Distance from mounting surface to bore center line	298.63	11.757
L	Pinion shaft O. D.	66.70-66.71	2.6260-2.6265
	Bearing cone I. D.	66.67-66.69	2.6250-2.6255
M	Bearing carrier I.D.	122.19-122.21	4.8105-4.8115
	Bearing cup O. D.	122.24-122.26	4.8125-4.8135
N	Pinion shaft O. D.	77.81-77.83	3.0635-3.0640
	Bearing cone I. D.	77.79-77.81	3.0625-3.0635
O	Bearing carrier I. D.	136.47-136.50	5.3730-5.3740
	Bearing cup O. D.	136.52-136.55	5.3750-5.3760
P	Bearing bore I. D.	135.76-135.78	5.3447-5.3457
	Bearing cup O. D.	135.76-135.78	5.3447-5.3457
Q	Shaft O. D.	65.11-65.13	2.5635-2.5640
	Bearing cone I. D.	65.09-65.10	2.5625-2.5630
R	Extension housing I. D.	196.77-196.82	7.747-7.749
	Bearing cup O. D.	196.85-196.88	7.750-7.751
R'	Extension housing I. D.	180.90-180.95	7.122-7.124
	Bearing Cup O. D.	180.97-181.00	7.125-7.126
S	Gear flange O. D.	133.41-133.44	5.2525-5.2535
	Bearing cone I. D.	133.35-133.38	5.250-5.251
S'	Axle shaft O. D.	104.84-104.86	4.127-4.128
	Bearing cone I. D.	104.78-104.80	4.125-4.126
T	Extension housing I. D.	206.35-206.40	8.124-8.126
	Bearing cup O. D.	206.38-206.40	8.125-8.126
U	Axle shaft O. D.	114.34-114.36	4.502-4.503
	Bearing cone I. D.	114.30-114.33	4.500-4.501
V	NoSpin Differential		
W	Apply 70699262 to external threads		


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

3.9 REPAIR PROCEDURES

3.9.1.17

Remove wheel lean knuckle.

T-91543



3.9.1.18

Remove seals from wheel lean knuckle.


T-91559



3.9.1.19

Remove seals and needle roller bearing from the front axle.

T-91544



3.9.1.20

Remove bearing from wheel lean arm.

T-91545



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

3.10.3 FRONT WHEEL LEAN

ITEM	NAME	mm	in
A	Cylinder pivot bearing I. D.	50.762 - 50.787	1.9885 - 1.9995
	Bearing O. D.	50.787 - 50.800	1.9995 - 2.0000
	Pivot Pin O. D.	31.763 - 31.788	1.2505 - 1.2515
	Bearing I. D.	31.737 - 31.750	1.2495 - 1.2500
B	Cylinder rod I. D.	50.762 - 50.787	1.9985 - 1.9995
	Bearing O. D.	50.787 - 50.800	1.9995 - 2.0000
C	Front wheel lean link bearing bore I.D.	50.762 - 50.787	1.9985 - 1.9995
	Bearing O. D.	50.787 - 50.800	1.9995 - 2.0000

PROCEDURE


- D Tighten nut to 54.2 - 67 daNm (400 -500 ft lbs), then increase torque to align holes for the cotter pin.

4.4 COMPONENT REBUILD

4.4.1.1.5

Remove mount capscrews as well as U-bolt holding the pump on the engine.

T-95275



4.4.1.2 Brake Pump Removal FG105

4.4.1.2.1

Turn off electrical master switch.

T-95508



WARNING

Always turn the master switch to the off position before cleaning, repairing, servicing or parking the machine to prevent injury.



4.4.1.2.2

Drain implement tank.

T-95515



4.4.1.2.2

Remove side panels on radiator wrap around.

T-95518



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

4.4 COMPONENT REBUILD

4.4.2.3.9

Be sure end cap is fitted into booster housing and seal is not rolled.

T-95206



4.4.2.3.10

Install the valve rod and reaction piston assembly in the hollow end of the power piston. Insert the reaction piston end in the power piston first.

T-95148



4.4.2.3.11

Screw the input plug and push rod assembly into the power piston and hand tighten. Gently clamp the input plug flats in the jaws of a vise and firmly hand tighten the power piston and plug until seated. Do not use tools to tighten. Push boot onto booster housing.

T-95210



4.4.2.3.12

Lubricate and install the two oval face seals in the grooves of the electric motor pump assembly.

T-95214



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

5.1 GENERAL DESCRIPTION

FG70 AND 75B IMPLEMENT SCHEMATIC

The schematic includes the implement hydraulic and steering systems. These systems all utilize a common reservoir (29). Therefore, the systems use a common specified oil.

There are three pumps supplying the two systems. They are all gear type pumps. One pump (15a) supplies the steering system and the circle turn circuit. Two pumps (13a & 13b) supply the two valve banks one for left bank, one for right bank, both of these pumps also supply the circle turn circuit when no other functions are used.

The steering circuit consists of the following: pump (15a) orbitrol type control valve (24) cross relief valves and anticavitation valves (26) and cylinders (27). The cross reliefs function both as steering main reliefs and circuit reliefs. A relief valve (22) teed out of the steering pump circuit is the circle turn relief.

When a steering function is made the steering control valve is activated. The valve directs oil to the internal gear flow control meter. (The rate at which the meter is turned determines the flow to the cylinders). Therefore, whatever amount of flow not required for steering

continues on to the circle turn circuit. Return oil from the cylinders is directed by the steering valve back to the reservoir.

During the steering function when forces high enough are encountered, and the pressure build up equals the setting of the cross relief valves, the valve open and protect the steering system. When the cross relief opens, it exhausts oil to the opposite side anticavitation valve and to tank to prevent cavitation in the opposite ends of the cylinders.

When the steering valve is in neutral the cross relief valves function the same as described above. In this case they become circuit reliefs.

The implement system consists of the two pumps (13a) and (13b), implement control spool valves (12 & 14), over center valves (1), dual check valves (3), dual operation solenoid valves (6), circuit relief valves, main relief valves, and load check valves.

One of the pumps supplies the left valve bank. The other pump supplies the right valve bank.

Left Stack Top to Bottom
Circuit
Circle shift
Moldboard pitch
Moldboard lateral shift
Ripper
Left moldboard lift

Components
Spool, dual over center valve, cylinder
Spool, solenoid, check valve, cylinder
Spool, solenoid, cylinder
Spool, dual over center valve, cylinder
Spool, dual over center valve, cylinder

Right Stack Top to Bottom
Circuit
Scarifier lift
Articulation
Wheel lean
Saddle lock
Right moldboard lift

Components
Spool, dual over center, cylinder
Spool, solenoid, dual check valve, cylinders
Spool, solenoid, dual check valve, cylinder
Spool, relief valves, cylinders
Spool, dual over center, cylinder

5.4 COMPONENT REMOVAL

5.4.2.5

Remove mount capscrews and remove pump.

T-95309



5.4.3 Implement Control Valve Removal and Installation

5.4.3.1

Drain the implement tank and turn off the electrical master switch.



WARNING

Always turn the master switch to the off position before cleaning, repairing, servicing or parking the machine to prevent injury.


T-95006



5.4.3.2

Remove cover from the control valve.


T-95346



5.4.3.3

Disconnect the control linkages from the spools.

T-95353




5.4 COMPONENT REMOVAL

5.4.9 Moldboard Lateral Shift Cylinder Removal & Installation

T-91682

5.4.9.1

Position moldboard upon the ground.




5.4.9.2

Turn off master switch and drain the implement tank.

T-95006

WARNING

Always turn the master switch to the off position before cleaning, repairing, servicing or parking the machine to prevent injury.



5.4.9.3

Remove the cylinders end caps, keeping shims in position. Force the piston rod into the cylinder.


T-95154



5.4.9.4

Remove cylinder hoses.


T-95155



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


5.6 SPECIFICATIONS

5.6.3 Dual Check Valve



5.6 SPECIFICATIONS

5.6.13 Scarifier Lift Cylinder



Torque (lubricated)	daNm	ft.lbs.
Rod Nut	115-129	850-950
Head	190-203	1400-1500
Dimensions	mm	in
Cylinder I.D.	104.1-104.4	4.100-4.110
Piston I.D.	35.05-35.10	1.380-1.382
Rod O.D.	50.72-50.80	1.997-2.000
Rod O.D.	34.89-34.92	1.374-1.375
Head I.D.	50.85-50.90	2.002-2.004

5.6 SPECIFICATIONS


5.8 TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	TOOLS REQUIRED	TEST	SOLUTION
Cylinder moves while control valve is in neutral	Over-center valve (or cylinder lock valve) not sealing properly		Disconnect line between over-center valve and control valve with blade in the air. Blade should remain in position.	If blade drifts, rebuild or replace the over-center valve (or cylinder lock valve).
	Oil leakage around cylinder piston seal.			Replace all the piston seals of the affected cylinder.
Cylinder moves due to gravity load while control valve is in neutral.	Control valve spool is stuck open or not fully stroking.		Check to make sure spool travel is not limited due to external interference or make sure linkage is adjusted to insure proper stroke of the spool.	Check affected spool in control valve for scoring or scratches. Spool may be repaired with some light "dressing", otherwise, it must be replaced.
	The signal check is not working properly	Two pressure gauges 75300110	Check the differential pressure between the signal port and the work port of the affected valve. Operate the questionable function while "dead-heading" another function. If a differential of over 1.4 bar (20 psi) is produced at any time, the signal is not working.	Examine the signal check for sticking and check the o-rings on the orifice plug in the valve end plate.
	In the moldboard lift circuit, the circuit relief is not working properly.		Check the differential pressure between the signal port and the work port of the affected valve. Operate the questionable function while "dead-heading" another function. If a differential of over 1.4 bar (20 psi) is produced at any time, the signal is not working.	In the moldboard lift circuits, if the differential is normal but full system pressure cannot be produced, replace the circuit relief and/or defective o-rings.
	In the moldboard lift circuit, over-center valve malfunction.		Disconnect line between over-center valve and control valve with blade in the air. Blade should remain in position.	If blade drifts, rebuild or replace the over-center valve (or cylinder lock valve).

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

FG85 FG105 SPECIFICATIONS

5.12.2 Valve Section (FG85-95)



T-073

	daNm	ft. lbs.
A	0.81-1.35	6-10
B	0.4-0.67	3-5
C	2.44-3.0	18-22
D	1.08-1.35	8-10
E	1.08-1.35	8-10

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

SECTION 6 REBUILD PROCEDURES


6.1

6.2 ARTICULATION JOINT

6.2.1

The hitch used consists of tapered roller bearings. The hitch allows a total of 50 degrees articulation.

T-95899



6.2.2

Support the two main frames on jack stands during rebuild.

WARNING

Do not work under or near unblocked or unsupported linkage, parts or machine.


6.2.3

Clean bearing bores.

WARNING

Never use gasoline solvent or other flammable fluids to clean element. Use authorized commercial, non-flammable, non-toxic solvents.


T-95403



6.2.4

Measure the bearing height of the outer races plus the height of the spacer. Record these dimensions. Keep the bearing pieces matched. Repeat the measurement for the other hitch bearing.

T-95402




SECTION 6 REBUILD PROCEDURES

6.3.4.13

Rebuild is the reverse of disassembly except for preloading the worm bearings. See section 6.6.3.4 for specifications.


T-95894



6.3.4.14

The shaft weld assembly must have an end shake. Check Section 6.6.3.4 for specifications.

T-95896




6.4 SCARIFIER REMOVAL

6.4.1

Lower scarifier teeth to the ground. Shut off engine.


T-95361



6.4.2

Remove pin locks and push pin from scarifier and mount.


T-95363



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

SECTION 6 REBUILD PROCEDURES

6.6.5 RIPPER



T-85961

Dimensions	mm	inch
A. Support bore I.D.	70.100-70.174	2.7598-2.7627
B. Strut bore I.D.	60.000-60.046	2.3622-2.3640
C. Frame bore I.D.	50.080-50.180	1.9716-1.9756
D. Bushing O.D.	60.07-60.10	2.365-2.366
Bushing I.D.	50.195-50.265	1.9761-1.9789
E. Pin O.D.	59.954-60.000	2.3604-2.3622
F. Pin O.D.	49.961-50.000	1.9669-1.9685

Torque	daNm	ft.lbs.
See section 0 for individual bolt torques per size of bolt.		




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

FG75, 85 ALPHABETICAL INDEX

DESCRIPTION	ITEM	DESCRIPTION	ITEM
AIR CLEANER SWITCH	16	HEAD LIGHT	46
ALTERNATOR	15	HORN	47
ARTICULATION SWITCH	113	HORN SWITCH	82
		HOUR METER	80
BACKUP ALARM	1	HYDRAULIC FILTER PRESSURE SWITCH	10
BATTERIES, CABLES & MASTER SWITCH	7		
BEACON LIGHT	52	IGNITION SWITCH	76
BEACON LIGHT SWITCH	69		
BRAKE LIGHT SWITCH	97	LEFT ARTICULATION SOLENOID VALVE	114
BRAKE MAIN PRESSURE SWITCH	98	LEFT DOOR WIPER MOTOR	61
BRAKE MOTOR RELAY	65	LEFT DOOR WIPER SWITCH	73
BRAKE PEDAL SWITCH	99	LEFT LIFT FLOAT SOLENOID VALVE	44
BRAKE PRESSURE SWITCH	23	LEFT LIFT FLOAT SWITCH	86
BRAKE RELAY	24	LEFT TURN SIGNAL INDICATOR	42
BUZZER	29	LIGHT SWITCH	81
CAB FLOOD LIGHT	53	NEUTRAL LOCK SWITCH	110
CAB FLOOD LIGHT SWITCH	70		
CAB HEATER FANS	63	OUTPUT SPEED SENSOR	117
CAB HEATER SWITCH	75		
CIRCUIT BREAKER	31	PARKING BRAKE INDICATOR	25
CIRCUIT BREAKER	32	PARKING BRAKE SWITCH	106
CIRCUIT BREAKER	112	PRESSURE SWITCH	33
CIRCUIT BREAKER (BRAKE)	100		
CONVERTER TEMPERATURE GAUGE	90	REAR DEFROSTER FAN	51
CONVERTER TEMPERATURE SENDING UNIT	94	REAR DEFROSTER SWITCH	68
COOLANT LEVEL SENSOR	6	REAR WASHER PUMP	58
COOLANT TEMPERATURE SENDING UNIT	92	REAR WIPER MOTOR	50
		REAR WIPER SWITCH	67
DATA MONITOR	26	REVERSE DECLUTCH RELAY	105
DECLUTCH INDICATOR LIGHT	108	RIGHT ARTICULATION SOLENOID VALVE	115
DECLUTCH SWITCH	109	RIGHT DOOR WIPER MOTOR	62
DOME LIGHT	49	RIGHT DOOR WIPER SWITCH	74
DOOR WASHER PUMP (RIGHT & LEFT)	60	RIGHT LIFT FLOAT SOLENOID VALVE	56
DOZER FLOAT SOLENOID VALVE	48	RIGHT LIFT FLOAT SWITCH	87
DOZER FLOAT SWITCH	85	RIGHT TURN SIGNAL INDICATOR	43
EMERGENCY BRAKE MOTOR	64	SADDLE LOCK PIN CONTROL SOLENOID	57
EMERGENCY STEERING INDICATOR	38	SADDLE LOCK PIN SWITCH	79
EMERGENCY STEERING SOLENOID VALVE	36	START PROTECT RELAY	12
EMERGENCY STEERING TEST SWITCH	39	STARTER	14
ENGINE COOLANT TEMPERATURE SENSOR	18	STARTER RELAY	13
ENGINE OIL LEVEL SENSOR	19	STARTING AID FUZE	83
ENGINE OIL PRESSURE GAUGE	89	STARTING AID SWITCH	84
ENGINE OIL PRESSURE SENDING UNIT	93	STARTING AID VALVE	96
ENGINE OIL PRESSURE SWITCH	17	STOP & TAIL LIGHT	4
ENGINE TEMPERATURE GAUGE	88		
		TRANSMISSION CONTROL VALVE	103
FORWARD DECLUTCH RELAY	107	TRANSMISSION CONTROL VALVE	116
FRONT & REAR FLOOD LIGHT	5	TRANSMISSION MAIN PRESSURE SWITCH	9
FRONT DEFROSTER FAN	55	TRANSMISSION OIL PRESSURE SENDING UNIT	95
FRONT DEFROSTER SWITCH	72	TRANSMISSION PRESSURE GAUGE	91
FRONT FLOOD LIGHT	45	TRANSMISSION SHIFT CONTROL	120
FRONT WASHER PUMP	59	TRANSMISSION TEMPERATURE SWITCH	8
FRONT WIPER MOTOR	54	TURBINE SPEED SENSOR	104
FRONT WIPER SWITCH	71	TURN SIGNAL FLASHER	35
FUEL LEVEL SENSOR	22	TURN SIGNAL LIGHT (LEFT FRONT & REAR)	3
FUSE BOX	77	TURN SIGNAL LIGHT (RIGHT FRONT & REAR)	2
FUSE BOX	78	TURN SIGNAL SWITCH	37
GEAR SELECTOR	111	VOLTMETER	66

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


6 COOLANT LEVEL SENSOR



T-0937


WIRE

- 0 To frame ground
- 31C To data monitor (26) plug A position 5



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


16 AIR CLEANER SWITCH



T-01171


WIRE

36A To data monitor (26) plug B, position 12
0 To frame ground



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


26 DATA MONITOR



T-01172


WIRE

- 33A To brake relay (34), position D
- 36A To air cleaner switch (16)
- 30 To fuse box (78) 4 amp fuse, position 4, to hour meter (80), + position
- 36H To hydraulic filter pressure switch (10)
- 31P To engine oil pressure switch (17), to hour meter (80), - position
- 34 To alternator (15), position D+
- 31T To engine coolant temperature sensor (18)
- 31B To buzzer (29) + position
- 32T To transmission temperature switch (8)
- 31G To buzzer (29), - position
- 0 To frame ground
- 12 To fuse box (78) 4 amp fuse, position 2 & 3, also ignition switch (76) "ACC" position
- 36 To fuel level sensor (22)
- 36R To fuel level sensor (22)
- 21 To ignition switch (76), "ST" position
- 31C To coolant level sensor (6)
- 31L To engine oil level sensor (19)
- 32MP To transmission main pressure switch (9)



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

36 EMERGENCY STEERING SOLENOID VALVE



T-01166

WIRE

- 37 To emergency steering test switch (39)
- 0 To pressure switch (33), to frame ground

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

46 HEAD LIGHT




T-0221

WIRE

41 To light switch (81), position "HL"


56 RIGHT LIFT FLOAT SOLENOID VALVE



WIRE


- 83 To right lift float switch (87)
- 0 To ground

T-01176



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


66 VOLTMETER



T-0240



WIRE

- 13 To engine oil pressure gauge (89), engine temperature gauge (88) and ignition switch (76) "IGN" position
- 0 To engine oil pressure gauge (89), engine temperature gauge (88) to panel ground



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


76 IGNITION SWITCH



T-0156


WIRE

- 1 To starter (14); also to fuse box (77) 15 amp fuse, position 4
- 1A To fuse box (78) 15 amp fuse, position 7, 10 & 11
- 12 To data monitor (26) plug B, position 1; also fuse box (78) 4 amp fuse, position 2 & 3, 15 amp fuse, position 6 and fuse box (77) 15 amp fuse, position 5, 8, 9 & 12
- 13 To instrument panel gauges (66, 88, 89, 90 & 91); also to fuse box (77) 5 amp fuse, position 1
- 21 To data monitor (26) plug A, position 6
- None To fuse (83), to starting aid switch (84)



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

86 LEFT LIFT FLOAT SWITCH




T-0204

WIRE

- 80 To dozer float switch (85)
- 82 To left lift float control solenoid (44)


96 STARTING AID VALVE



T-0247

- WIRE
28 To starting aid switch (84)
0 To ground


106 PARKING BRAKE SWITCH



T-0250


WIRE

- 25 To forward declutch relay (107), position A
- 1TA To wire1T, to fuse box (77) 10 amp fuse, position 2



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

116 TRANSMISSION CONTROL VALVE



T-01186


WIRE

- M1 To shift control (120) 7 terminal connector, position 1
- M2 To shift control (120) 7 terminal connector, position 2
- M3 To shift control (120) 7 terminal connector, position 3
- M4 To shift control (120) 7 terminal connector, position 4
- M5 To shift control (120) 7 terminal connector, position 5
- 0T To frame ground

COMPONENT REMOVAL

8.2.2.3

The access panel can be removed to gain access to the front of the engine and to the steering relief valve.



8.2.2.4

Height adjustment can be made by raising or lowering the seat on the pedestal.



8.2.3 Vent Fan

8.2.3.1

Remove capscrews holding vent panel to the cab roof.
Turn off master switch.



WARNING

Always turn the master switch to the off position before cleaning, repairing, servicing or parking the machine to prevent injury.

8.2.3.2

Disconnect fan.

TABLE OF CONTENTS

HOW THE UNITS OPERATE

SECTIONAL VIEWS AND PARTS IDENTIFICATION

Basic Design	Fig. A
Converter and Transmission Case Group	Fig. B
Converter Group	Fig. C
Six Speed Gear and Clutch Group	Fig. D
Clutch Group	Fig. E
Control Valve Assembly	Fig. F
Charging Pump and Regulating Valve Group	Fig. G
External Plumbing and Pressure Check Points	Fig. H
Assembly Instructions	Fig. I
HR24000 Typical Cross Section	Fig. J
DISASSEMBLY OF TRANSMISSION	1
CLUTCH DISASSEMBLY	16
REASSEMBLY OF TRANSMISSION	48
CLEANING AND INSPECTION	65
SERVICING MACHINE AFTER TRANSMISSION OVERHAUL	66
TOWING OR PUSH STARTING	66
SPECIFICATIONS AND SERVICE DATA	67
LUBRICATION	67
TROUBLE SHOOTING GUIDE	68
CLUTCH AND GEAR ARRANGEMENT	69
POWER FLOW	70
ELECTRIC SOLENOID CONTROL	73
CONTROL WIRING DIAGRAM	74
DRIVE PLATE INSTALLATION	75
TRANSMISSION TO ENGINE INSTALLATION PROCEDURE	76

NOTE: Metric Dimensions Shown in Brackets [].

CLUTCH AND GEAR GROUP

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Forward Shaft Pilot Bearing	1	65	Front Output Flange	1
2	Spring Retainer Ring	1	66	Front Bearing Cap Oil Seal	1
3	Spring Retainer	1	67	Front Bearing Cap	1
4	Piston Return Spring - Belleville Washer	7	68	Bearing Cap Shim	AR
5	Piston Return Spring Spacer	1	69	Front Bearing Cap "O" Ring	1
6	Forward Shaft, Drum & Plug Assembly	1	70	Front Bearing Cup	1
7	Piston Ring Expander Spring	3	71	Front Bearing Cone	1
8	Forward Shaft Piston Ring	3	72	Forward Shaft Gear	1
9	Piston Ring Sleeve Retaining Ring	1	73	Gear Retaining Ring	1
10	Piston Ring Sleeve	1	74	1st & 2nd Clutch Shaft Front Bearing	1
11	Forward Shaft Rear Bearing	1	75	Front Bearing Spacer	1
12	Reverse Shaft Piston Ring	3	76	1st & 2nd Clutch Gear Bearing	1
13	Front Bearing Retaining Ring	1	77	Bearing Locating Ring	1
14	Front Bearing Snap Ring	1	78	Bearing Spacer	1
15	Reverse Shaft Front Bearing	1	79	1st & 2nd Clutch Gear	1
16	Front Bearing Retaining Ring	1	80	Baffle Ring	1
17	Clutch Driven Gear Bearing Assembly	1	81	Bearing Locating Ring	1
18	Reverse Clutch Gear & Hub Assembly	1	82	1st & 2nd Clutch Gear Bearing	1
19	Baffle Ring	1	83	Belleville Washer Retainer	1
20	Spring Retaining Snap Ring	1	84	Spring Retainer Ring	1
21	Spring Retainer	1	85	Belleville Washer	7
22	Piston Return Spring - Belleville Washer	7	86	Belleville Washer Spacer	1
23	Piston Return Spring Spacer	1	87	1st & 2nd Clutch Drum & Bleed Valve Assembly	1
24	Reverse and 3rd & 4th Clutch Drum and Plug Assembly	1	88	Bearing to Shaft Spacer	1
25	Piston Return Spring	1	89	Clutch Shaft Rear Bearing	1
26	Spring Retainer	1	90	Bearing Retainer Ring	1
27	Spring Retainer Snap Ring	1	91	1st & 2nd Shaft Piston Ring	1
28	3rd & 4th Clutch Shaft Pilot Bearing	1	92	Bearing Cap Gasket	1
29	Retainer Locating Ring	1	93	Bearing Cap "O" Ring	1
30	Retaining Ring Retainer	1	94	Bearing Cap Plug	1
31	Clutch Disc Hub Retaining Ring	1	95	Rear Bearing Cap	1
32	Baffle Ring	1	96	Bearing Cap Screw Lockwasher	4
33	Clutch Disc Hub	1	97	Bearing Cap Screw	4
34	Piston Return Spring	1	98	Idler Shaft Front Bearing	1
35	Spring Retainer	1	99	Idler Shaft	1
36	Spring Retainer Ring	1	100	Idler Shaft Rear Bearing	1
37	5th & 6th Clutch Shaft Pilot Bearing	1	101	Idler Shaft Rear Bearing Lock Ball	1
38	Retainer Snap Ring	1	102	Rear Bearing Locating Ring	1
39	Retaining Ring Retainer	1	103	Pump Drive Sleeve	1
40	Clutch Disc Hub Retaining Ring	1	104	Idler Shaft Nut	1
41	Baffle Ring	1	105	Idler Gear Spacer	1
42	Clutch Disc Hub	1	106	Idler Shaft Gear	1
43	Spring Retainer Ring	1	107	Idler Shaft Gear	1
44	Spring Retainer	1	108	Idler Shaft Bearing Cap Gasket	1
45	Piston Return Spring - Belleville Washer	7	109	Idler Shaft Bearing Cap	1
46	Piston Return Spring Spacer	1	110	Idler Shaft Bearing Cap Screw Lockwasher	4
47	Forward High and 5th & 6th Clutch Drum & Plug Assembly	1	111	Idler Shaft Bearing Cap Screw	4
48	Forward High Shaft Piston Ring	3	112	Output Shaft	1
49	Front Bearing Retaining Ring	1	113	Output Gear Spacer	1
50	Front Bearing Snap Ring	1	114	Output Shaft Gear	1
51	Forward High Shaft Front Bearing	1	115	Rear Bearing Cone	1
52	Front Bearing Retaining Ring	1	116	Rear Bearing Cup	1
53	Clutch Driven Gear Bearing	1	117	Rear Bearing Cap "O" Ring	1
54	Clutch Gear Bearing Retaining Ring	1	118	Rear Bearing Cap "O" Ring	1
55	Clutch Driven Gear Bearing Spacer	1	119	Rear Bearing Cap	1
56	Forward High Clutch Gear & Hub Assembly	1	120	Rear Bearing Cap Screw Lockwasher	3
57	Oil Baffle Ring	1	121	Rear Bearing Cap Screw	3
58	Clutch Gear Bearing Retaining Ring	1	122	Rear Bearing Cap Oil Seal	1
59	Clutch Driven Gear Bearing	1	123	Rear Output Flange	1
60	Front Bearing Cap Screw Lockwasher	4	124	Flange "O" Ring	1
61	Front Bearing Cap Screw	4	125	Flange Washer	1
62	Flange Nut	1	126	Flange Nut	1
63	Flange Washer	1	127	Rear Bearing Cap Screw	1
64	Flange "O" Ring	1	128	Rear Bearing Cap Screw Lockwasher	1

- ▲ 1 Assemble oil filter and tighten 20 to 25 Lbs.Ft. [27,2-33,8 N·m]
- ▲ 2 Teflon seals must be sized prior to ass'y.
- ▲ 3 Must be loose internal fit bearing with a No. 3 etched on the bearing.
- ▲ 4 10-outer steel plates, 10-inner friction plates. Alternately assemble, starting with outer steel plate.
- ▲ 5 6-outer steel plates, 6-inner friction plates. Alternately assemble, starting with outer steel plate.
- ▲ 6 12-outer steel plates, 12-inner friction plates. Alternately assemble, starting with outer steel plate.
- ▲ 7 Tighten 200 to 250 Lbs.Ft [271,2-338,9 N·m]
- ▲ 8 Special bearing loading notches opposite snap ring.
- ▲ 9 Bend lock tabs after tightening cap screws to proper torque.
- ▲ 10 Tighten oil screen assy 10 to 15 Lbs.Ft. [13,6-20,3 N·m]
- ▲ 11 Low, Forward and Reverse Clutch Springs - Concave side of first Belleville spring to be placed against clutch piston. Remaining six springs of each clutch to be stacked alternately reversed as shown.



- ▲ 12 Shim output shaft bearings to produce 6 to 8 Lbs. in. [0,68-0,90 N·m] pre load.
- ▲ 13 Clean mounting surfaces and tapped holes with solvent. Dry thoroughly, being certain tapped holes are dry and clean. See text for proper installation.
- ▲ 14 Tighten 200-250 Lbs. Ft. [271,2-338,9 N·m] and stake nut securely into shaft notch.
- ▲ 15 Stator support screw assembly: (View "S")
 1. Clean stator support mounting surface and tapped holes with solvent. Dry thoroughly, being certain tapped holes are clean and dry.
 2. Install 6 special stator support screws. Tighten screws 12 to 16 Lbs. Ft. [16,3-21,6 N·m] torque. See Caution.

Notes

All lead in chamfers for oil seals, piston rings, and "O" rings must be smooth and free from burrs. inspect at assembly.

Lubricate all piston ring grooves and "O" rings with oil before assembly.


Apply a thin coating of grease between seal lips on lip type seals prior to assembly.

Apply a very light coat of Permatex No. 2 to O.D. of all oil seals and bore plugs before assy.

Apply a light coat of Loctite No. 92 to all plug threads.

Apply a light coat of Permatex No. 2 to all thru hole stud threads.


After assembly of parts using Loctite or Permatex, there must not be any free or excess material which might enter the oil circuit.



VIEW "T"
REVERSE IDLER



1ST
(Low)




Enlarged view of stator support piston ring & expander

Note:
Expander gap to be approx. 180° from ring hook joint to aid assembly.



Caution:

Assembly of stator support to converter housing must be completed within a 15 minute period from start of screw installation. The special screw is to be used for one installation only. If screw is removed for any reason, it must be replaced. The Loctite left in the holes must be removed with the proper tap and cleaned with solvent. Dry hole thoroughly and use a new screw for reinstallation.



VIEW "S"

Grade 5

Torque Specification for Lubricated or Plated Screw Threads

Grade 8

NOM. SIZE	FINE THREAD		COARSE THREAD		FINE THREAD		COARSE THREAD	
	LB-FT	[N·m]	LB-FT	[N·m]	LB-FT	[N·m]	LB-FT	[N·m]
.2500	9 - 11	[12,3 - 14,9]	8 - 10	[10,9 - 13,5]	11 - 13	[15,0 - 17,6]	9 - 11	[12,3 - 14,9]
.3125	16 - 20	[21,7 - 27,1]	12 - 16	[16,3 - 21,6]	28 - 32	[36,0 - 43,3]	26 - 30	[35,3 - 40,6]
.3750	26 - 29	[35,3 - 39,3]	23 - 25	[31,2 - 33,8]	37 - 41	[50,2 - 55,5]	33 - 36	[44,8 - 48,8]
.4375	41 - 45	[55,6 - 61,0]	37 - 41	[50,2 - 55,5]	58 - 64	[78,7 - 86,7]	52 - 57	[70,6 - 77,2]
.5000	64 - 70	[86,9 - 94,9]	57 - 63	[77,3 - 85,4]	90 - 99	[122,1 - 134,2]	80 - 88	[108,5 - 119,3]
.5625	91 - 100	[123,4 - 135,5]	82 - 90	[111,2 - 122,0]	128 - 141	[173,6 - 191,1]	115 - 127	[156,0 - 172,2]
.6250	128 - 141	[173,5 - 191,2]	113 - 124	[153,2 - 169,1]	180 - 198	[224,0 - 268,5]	159 - 175	[215,6 - 237,3]
.7500	223 - 245	[302,3 - 332,2]	200 - 220	[271,2 - 298,3]	315 - 347	[427,1 - 470,5]	282 - 310	[382,3 - 420,3]

FIGURE I




Figure 35
Remove brake shoe return spring.




Figure 38
Remove brake backing plate attaching bolts and washers.




Figure 36
Remove brake shoe and lining.




Figure 39
Remove backing plate.




Figure 37
Remove brake actuator lever.




Figure 40
Remove output shaft rear bearing cap bolts and washers.



Figure 94
Remove end plate retainer ring.




Figure 97
Remove clutch inner bearing.




Figure 95
Remove end plate.



Figure 98
Remove piston return spring (belleville washer) retainer ring retainer.



Figure 96
Remove inner and outer clutch discs.



Figure 99
Remove return spring retainer ring.




Figure 154

Install one steel disc.



Figure 157

Install end plate retainer ring.



Figure 155

Install one friction disc. Alternate steel and friction discs until the proper amount of discs are installed. First disc next to the piston is steel, last disc installed is friction.



Figure 158

Install clutch gear inner taper bearing, small diameter of taper up.



Figure 156

Install clutch disc end plate.



Figure 159

Position taper bearing spacer on shaft.



Figure 213

Remove end plate.



Figure 216

Remove piston return springs. (Belleville washers)



Figure 214

Remove inner and outer clutch discs.



Figure 217

Remove piston spacer.




Figure 215

Compress piston return springs (Belleville washers).
Remove return spring retainer ring and ring retainer.




Figure 218

Remove clutch piston.

See cleaning and inspection page.




Figure 272

Position pump drive idler gear and bearing on idler gear stub shaft.




Figure 275

Install idler gear inner taper bearing on shaft with large diameter of taper down.




Figure 273

Install idler gear to stub shaft retainer ring.




Figure 276

Position bearing spacer on shaft.




Figure 274

Install idler shaft spacer.



Figure 277

Position idler gear on bearing with hub of gear up.




Figure 329

Install impeller and hub assembly using caution as not to damage the oil baffle oil seal. **NOTE:** Use extreme caution as not to cut, break or unhook the oil sealing ring on the support.




Figure 332

Install reaction member retainer ring. Proceed to Figure 337.

FREEWHEEL REASSEMBLY

NOTE: The freewheel assembly cannot be serviced. If the freewheel is damaged it must be replaced as an assembly.




Figure 330

Position impeller hub bearing spacer on stator support.




Figure 333

Install outer race and sprag assembly in reaction member. **NOTE:** Undercut shoulder of race must go toward the rear of the reaction member.




Figure 331

For a fixed reaction member, install reaction member with thick side of blades out.

For freewheel reaction member see Figure 333.




Figure 334

Install outer race to reaction member retainer ring.


SPECIFICATIONS AND SERVICE DATA—POWER SHIFT TRANSMISSION AND TORQUE CONVERTER

<p>CONVERTER OUT PRESSURE</p> <p>CONTROLS</p> <p>CLUTCH TYPE</p> <p>CLUTCH INNER DISC</p> <p>CLUTCH OUTER DISC</p>	<p>Converter outlet oil temp. 180° - 200° F. [82.3° - 93.3° C].</p> <p>Transmission in NEUTRAL.</p> <p>Operating specifications:</p> <p>25 P.S.I. [172.4 kPa] minimum pressure at 2000 R.P.M. engine speed AND a maximum of 70 P.S.I. [482.6 kPa] outlet pressure with engine operating at no-load governed speed.</p> <p>Forward and Reverse — Manual</p> <p>Speed Selection — Manual</p> <p>Multiple discs, hydraulically actuated, spring released, automatic wear compensation and no adjustment. All clutches oil cooled and lubricated.</p> <p>Friction.</p> <p>Steel.</p>	<p>OIL FILTRATION</p> <p>Full flow oil filter safety by-pass, also strainer screen in sump at bottom of transmission case.</p> <p>CLUTCH PRESSURE</p> <p>240 - 280 psi [1654,8 - 1930,5 kPa] --- With parking brake set (see note), oil temperature 180° - 200° F. [82,2° - 93,3° C], engine at idle (400 to 600 RPM), shift thru direction and speed clutches. All clutch pressure must be equal within 5 psi. [34,5 kPa]. If clutch pressure varies in any one clutch more than 5 psi. [34,5 kPa] repair clutch.</p> <p>NOTE: Never use service brakes while making clutch pressure checks. Units having brake actuated declutching in forward and/or reverse will not give a true reading.</p> <p>ALWAYS USE PARKING BRAKE WHEN MAKING CLUTCH PRESSURE CHECKS.</p>
---	--	--

LUBRICATION

RECOMMENDED LUBRICANTS FOR CLARK POWER SHIFTED TRANSMISSION AND TORQUE CONVERTERS

<p>TYPE OF OIL</p> <p>CAPACITY</p> <p>CHECK PERIOD</p> <p>NORMAL * DRAIN PERIOD</p>	<p>See Lube Chart.</p> <p>Consult Operator's Manual on applicable machine model for system capacity. Torque Converter, Transmission and allied hydraulic system must be considered as a whole to determine capacity.</p> <p>Check oil level DAILY with engine running at 500-600 RPM and oil at 180° to 200° F. [82, 2 - 93, 3° C]. Maintain oil level to FULL mark.</p> <p>Every 500 hours, change oil filter element.</p> <p>Every 1000 hours, drain and refill system as follows: Drain with oil at 150° to 200° F. [65, 6 - 93, 3° C].</p> <p>NOTE: It is recommended that filter elements be changed after 50 and 100 hours of operation on new and rebuilt or repaired units.</p> <p>(a) Drain transmission and remove sump screen. Clean screen thoroughly and replace, using new gaskets.</p> <p>(b) Drain oil filters, remove and discard filter elements. Clean filter shells and install new elements.</p> <p>(c) Refill transmission to LOW mark.</p> <p>(d) Run engine at 500-600 RPM to prime converter and lines.</p> <p>(e) Recheck level with engine running at 500 - 600 RPM and add oil to bring level to LOW mark. When oil temperature is hot (180-200° F.) [82,2-93,3° C] make final oil level check. BRING OIL LEVEL TO FULL MARK.</p>
---	---



NOTES: Temperature ranges "2" and "3" may be used to lower ambient temperatures when sump preheaters are used. Temperature range "4" should be used only in ambient temperature range shown.

MODULATED SHIFT TRANSMISSIONS: H125, H200, H500, H600, 18000, 24000, 28000, 32000 & 34000 series transmissions with modulated shift use only C-3 or temperature range 3 items (a) & (b) *Dexron or *Dexron II D. **SEE CAUTION BELOW.** 3000, 4000, 5000, 6000, 8000 & 16000 series transmissions with modulated shift use only C-3 or temperature range 3 items (a) only *Dexron. Do **NOT** use *Dexron II D. **SEE CAUTION BELOW.**

CAUTION: *Dexron II D is not compatible with graphitic clutch plate friction material UNLESS IT MEETS THE APPROVED C-3 SPECIFICATIONS. *Dexron II D cannot be used in the 3000, 4000, 5000, 6000, 8000 or 18000 series power shift transmissions, or the HR28000, HR32000 & HR34000 series having converter lock-up, or the C270 series converter having lock-up UNLESS IT MEETS THE APPROVED C-3 SPECIFICATIONS.

Any deviation from this chart must have written approval from the application department of the Clark Components International Engineering and Marketing Department.

*** Normal drain periods and filter change intervals are for average environmental and duty-cycle conditions. Severe or sustained high operating temperatures or very dusty atmospheric conditions will cause accelerated deterioration and contamination. For extreme conditions judgment must be used to determine the required change intervals.**

FOREWORD

This manual has been prepared to provide the customer and the maintenance personnel with information and instructions on the maintenance and repair of the **CLARK-HURTH COMPONENTS** product.

Extreme care has been exercised in the design, selection of materials and manufacturing of these units. The slight outlay in personal attention and cost required to provide regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated will be reimbursed many times in low cost operation and trouble free service.

In order to become familiar with the various parts of the product, its principle of operation, trouble shooting and adjustments, it is urged that the mechanic study the instructions in this manual carefully and use it as a reference when performing maintenance and repair operations.

Whenever repair or replacement of component parts is required, only **Clark-Hurth Components**-approved parts as listed in the applicable parts manual should be used. Use of "will-fit" or non-approved parts may endanger proper operation and performance of the equipment. **Clark-Hurth Components** does not warrant repair or replacement parts, nor failures resulting from the use of parts which are not supplied by or approved by **Clark-Hurth Components**. **IMPORTANT: Always furnish the Distributor with the serial and model number when ordering parts.**

HR 28000 CONVERTER AND TRANSMISSION CASE GROUP

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY.
1	Suction Tube Assembly	1	46	Converter Housing to Transmission Case Gasket	1
2	Pipe Plug	1	47	Suction Line Tube Clip Rivet	1
3	Pipe Plug	1	48	Converter Housing to Transmission Case Dowel Pin	2
4	Converter Housing and Tube Assembly	1	49	Low Speed Clutch Pressure Tube	1
5	Tube Sleeve	1	50	Transmission Case to Converter Housing Screw Lockwasher	10
6	Tube Sleeve	1	51	Transmission Case to Converter Housing Screw	10
7	Converter Housing Sleeve	1	52	Transmission Case Assembly	1
8	Converter Housing Sleeve Lock	1	53	Transmission Case to Rear Cover Dowel Pin	2
9	Converter Housing Sleeve Screw Lockwasher	1	54	Transmission Case to Rear Cover Gasket	1
10	Converter Housing Sleeve Screw	1	55	Transmission Case Rear Cover	1
11	Converter Housing Sleeve Screw	1	56	Rear Cover to Case Screw Lockwasher	13
12	Converter Housing Sleeve Screw Lockwasher	1	57	Rear Cover to Case Screw	13
13	Converter Housing Sleeve Lock	1	58	Rear Cover Pipe Plug	1
14	Converter Housing Sleeve	1	59	Rear Cover to Transmission Case Stud Nut	2
15	Breather	1	60	Rear Cover to Transmission Case Lockwasher	2
16	Street Ell	1	61	Clutch Pressure Tube "O" Ring	1
17	Tube Sleeve	3	62	Tube Sleeve	1
18	Breather Reducing Bushing	1	63	Transmission Case to Rear Cover Stud	2
19	Pipe Plug	1	64	Drain Plug	1
20	Converter Housing to Transmission Housing Screw Lockwasher	4	65	Oil Level Plug	2
21	Converter Housing to Transmission Housing Screw	4	66	Screen Assembly Gasket	1
22	Converter Housing to Transmission Housing Lockwasher	4	67	Screen Assembly	1
23	Converter Housing to Transmission Housing Screw	4	68	Suction Tube Assembly	1
24	Lube Tube Retaining Screw	1	69	Suction Tube Clip Washer	1
25	Lube Tube Retaining Screw Lockwasher	1	70	Suction Tube Clip	1
26	Valve Oil Supply Tube	1	71	Pipe Plug	1
27	3rd Speed Tube "O" Ring	1	72	Suction Tube "O" Ring	1
28	3rd Speed Tube Assembly	1	73	Suction Tube Retainer Washer	1
29	Tube Clip	1	74	Suction Tube Retainer Washer Screw	2
30	Tube Clip Screw Lockwasher	1	75	Oil Distributor Retainer Ring	1
31	Tube Clip Screw	1	76	Oil Distributor Lock Ball	1
32	Lube Tube Assembly	1	77	Oil Distributor	1
33	Lube Tube Retainer Screw Lockwasher	1	78	Oil Distributor Retainer Ring	1
34	Lube Tube Retainer Screw	1	79	4th Clutch Lube Tube	1
35	Reverse Tube "O" Ring	1	80	Tube Sleeve	1
36	Reverse Tube Assembly	1	81	Clutch Pressure Tube "O" Ring	1
37	Tube Clip	1	82	Tube Sleeve	1
38	Tube Clip Screw Lockwasher	1	83	4th Speed Pressure Tube	1
39	Tube Clip Screw	1	84	4th Speed Pressure Tube "O" Ring	1
40	Suction Tube "O" Ring	1	85	Control Valve Mounting Plate	1
41	Suction Tube Spacer Ring	1	86	Remote Valve Plate Screw	9
42	Suction Tube Retainer Lockwasher	1	87	Remote Valve Plate Screw Lockwasher	9
43	Suction Tube Retainer Screw	1	88	Control Valve Mounting Plate Plug	1
44	Tube Sleeve	1	89	Valve Cover Plate	1
45	Clutch Pressure Tube "O" Ring	1			

AXLE DISCONNECT

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Disconnect Housing Capscrew	4	8	Disconnect Shaft	1
2	Disconnect Housing Capscrew		9	Detent Ball	1
	Lockwasher	4	10	Detent Spring	1
3	Disconnect Housing	1	11	Shift Rail	1
4	Disconnect Housing Plug	1	12	Shift Rail Oil Seal	1
5	Shift Hub	1	13	Bearing Retainer Ring	1
6	Shift Fork	1	14	Bearing	1
7	Shift Fork Lockscrew	1	15	Bearing Retainer Ring	1

MECHANICAL PARKING BRAKE

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Backing Plate Assembly.....	1	8	Return Spring	2
2	Actuating Lever	1	9	Brake Shoe (see item 3).....	
3	Brake Shoe and Lining	2	10	Brake Lining	2
4	Brake Flange	1	11	Rivet	20
5	Brake Drum	1	12	Backing Plate Screw	4
6	Brake Drum to Flange Screw Lockwasher	6	13	Backing Plate Screw Lockwasher	4
7	Brake Drum to Flange Screw	6			




Figure 47

Remove low clutch rear bearing retaining ring.
NOTE: See page 33 for disassembly of low clutch utilizing a rear double taper bearing (helical gears).




Figure 48

Remove low clutch rear bearing.




Figure 49

Remove idler shaft and 4th speed clutch from housing.
NOTE: Do not lose rear bearing lock bail.




Figure 50

Remove low speed drive gear retainer ring and drive gear.




Figure 51

Remove reverse and 3rd clutch assembly.




Figure 52

Remove 2nd gear retaining ring.




Figure 101

Install low clutch shaft front bearing inner race with large diameter of race down.

4th Speed Clutch Reassembly




Figure 102

Install piston, piston return spring and inner and outer discs as explained in Fig. 81 through Fig. 86.

Install 4th speed gear inner bearing. **NOTE:** Bearing Part Number must go down. See Figure 104-A.



Figure 103

Install bearing spacer between inner and outer 4th speed gear bearings.

Install 4th speed gear into clutch drum. Align splines on clutch gear with internal teeth of friction discs. Tap gear into position. Do not force this operation. Gear splines must be in full position with internal teeth of all friction discs.




Figure 104

Install 4th speed gear outer bearing. **NOTE:** Bearing Part Number must go up. See Figure 104-A. It is recommended a rubber band be used to hold outer bearing rollers in position when installing bearing.




Figure 104-A




Figure 105

Install front bearing locating ring.




Figure 106

Install front bearing and bearing retainer ring.




Figure 161

Align holes in impeller cover with holes in impeller. Install bolts and washers and tighten to specified torque.




Figure 162

Locate detent balls and springs in control valve. Position new gasket. Secure valve with bolts and washers. Tighten to specified torque.



Figure 163

Install pump drive sleeves




Figure 164

Position new gasket and "O" rings on pressure regulator valve. Install valve on studs.




Figure 165

With new valve body to pump gasket in position insert pump drive shaft through valve body. Use caution as not to damage valve body oil seal. It may be necessary to turn impeller one way or the other to align pump shaft with drive sleeves.




Figure 166

Install new "O" ring in filter adaptor housing. Install filter element and housing. Tighten filter housing 20 to 25 ft. lbs. torque. [27,2 - 33,8 N.m.]



Figure G

Install bearing cup.



Figure J

Install bolts and block gears. Torque bolts to specifications and lock wire together.




Figure H

Install outer taper bearing. **NOTE:** Heat bearing in hot oil bath prior to installation.




Figure K

Install low clutch shaft sealing ring.



Figure I

Install retainer plate, inner diameter chamfer toward bearing.




Figure 11
Install input shaft into front bearing.




Figure 14
Install cover to case bolts. Tighten to specified torque.




Figure 12
Forward clutch front bearing locating ring.



Figure 15
Install front cover plug.




Figure 13
Support front cover with a chain fall. Spread forward clutch front bearing retaining ring. Position front cover to transmission case. Tap cover into place using caution as not to damage any of the clutch shaft piston rings.



Figure 16
Install companion flange, flange "O" ring, washer and nut. Tighten standard slotted nut or elastic stop nut to specified torque. (See elastic stop nut torque chart.)

CONVERTER SECTION WITH FREEWHEEL REACTION MEMBER

Item	Description	Qty.	Item	Description	Qty.
1	Bearing Support Screw	2	36	Drive Gear	1
2	Lockwasher	2	37	Woodruff Key	1
3	Drive Gear Snap Ring	1	38	Gear Retaining Ring	1
4	Drive Gear Bearing	1	39	Detent Spring	2
5	Drive Gear Bearing Support	1	40	Detent Ball	2
6	Drive Gear	1	41	Valve to Converter Gasket	1
7	Snap Ring (internal) —See item 8	1	42	Control Valve Assembly	1
8	Pump Drive Sleeve Assembly — Inc. items 7 and 9	1	43	Valve to Converter Housing Washer	9
9	Snap Ring (external) — See item 8	1	44	Valve to Converter Housing Screw	9
10	Valve Body to Converter Housing Gasket	1	45	Hub to Impeller Screw	8
11	Valve Body O-Ring	1	46	Hub to Impeller Screw Washer	8
12	Valve Body O-Ring	1	47	Impeller Hub Bearing	1
13	Valve Body O-Ring	1	48	Impeller Hub	1
14	Regulator Valve, Charging Pump & Filter Assy	1	49	Impeller Hub O-Ring	1
15	Impeller Hub Gear	1	50	Impeller	1
16	Impeller Hub Gear Snap Ring	1	51	Oil Baffle Retainer Ring	1
17	Piston Ring	1	52	Oil Baffle	1
18	Stator Support Screw	3	53	Oil Baffle Seal Ring	1
19	Stator Support Screw	3	54	Impeller to Drive Disc O-Ring	1
20	Stator Support & Sleeve Assembly	1	55	Snap Ring	1
21	Turbine Shaft Piston Ring	1	56	Turbine	1
22	Turbine Shaft	1	57	Turbine Ring	1
23	Piston Ring	1	58	Snap Ring	1
24	Turbine Shaft Bearing	1	59	Thrust Washer Snap Ring	1
25	Converter Housing & Tube Assembly	1	60	Thrust Washer	1
26	Turbine Shaft Gear	1	61	Reaction Member Snap Ring	1
27	Turbine Shaft Gear Snap Ring	1	62	Reaction Member	1
28	Piston Ring	2	63	Bearing Spacer	1
29	Turbine Shaft Piston Ring Race	1	64	Bearing	2
30	Tachometer Drive Tube Nut	1	65	Outer Race	1
31	Drive Shaft Oil Seal	1	66	Sprag Assembly	1
32	Drive Shaft Front Bearing	1	67	Snap Ring	1
33	Drive Shaft	1	68	Bearing Washer Snap Ring	1
34	Drive Shaft Rear Bearing	1	69	Bearing Washer	1
35	Bearing Retaining Ring	1	70	Bearing Snap Ring	1




Figure 32
Install sprag assembly retainer ring. Note drag strips at top.



Figure 33
Press free-wheel race assembly into reaction member and secure with retainer ring.

DISASSEMBLY OF LOCK-UP COVER




Figure 34
Remove end plate to lock-up cover bolts.




Figure 35
Remove end plate and clutch disc.





Figure 36
Remove piston and outer drive disc.



List of special Tools



Order-No. 5871 162 102

**Supplement to the WORKSHOP MANUAL
WG-180/WG-200 (ref. Order-No. 5871 162 002)**





ZAHNRADFABRIK PASSAU GmbH
Donaustr. 25 - 71
D- 94 034 Passau

73160586




6 WG 180



Pressure control



WANDLERSICHERHEITVENTIL
CONV. SAFETY VALVE
CONV. SOUPAPE DE SURETE



20.710




20.750 20.760

20.740


20.730

20.260

WANDLDRUCKHALTEVENTIL
CONV. PRESS. VALVE
CONV. SOUPAPE. PRESS



5870 801 003



5870 221 500



5870 221 501

220 V 110V

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL