


FR10 FR12 FR15

WHEEL LOADER



**IMPLEMENT HYDRAULICS
AND POWER STEERING**

Service manual

Form 73142921 English

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SAFETY RULES

In lifting and handling heavy parts, slings must be of adequate strength for the purpose intended and must be in good condition.

Handle all parts with extreme care. Keep hands and fingers from between parts. Wear authorized protective equipment such as safety glasses, heavy gloves, safety shoes.

When using compressed air for cleaning parts use safety glasses with side shields or goggles. Limit the pressure to 207 kPa (30psi) according to local or national requirements.

Wear welders protective equipment such as dark safety glasses, helmets, protective clothing, gloves and safety shoes when welding or burning. Wear dark safety glasses near welding. **DO NOT LOOK AT ARC WITHOUT PROPER EYE PROTECTION.**

Wear proper protective equipment such as safety goggles or safety glasses with side shields, hard hat, safety shoes, heavy gloves when metal or other particles are apt to fly or fall.

Use only grounded auxiliary power source for heaters, chargers, pumps and similar equipment to reduce the hazards of electrical shock.

Keep maintenance area CLEAN and DRY. Remove water or oil slicks immediately.

Remove sharp edges and burrs from reworked parts.

Be sure all mechanics tools are in good condition. **DO NOT** use tools with mushroomed heads. Always wear safety glasses with side shields.

Do not strike hardened steel parts with anything other than a soft iron or non-ferrous hammer.

GENERAL DESCRIPTION

- | | |
|------------------------------|------------------------------|
| 1. Boom cylinders | 15. Main relief valve piston |
| 2. Bucket cylinders | 16. Spring |
| 3. One-way check valves | 17. Relief piston |
| 4. Anti-cavitation valve | 18. Spring |
| 5. Boom Spool | 19. Implement pump (section) |
| 6. Regenerative check valve | 20. Steering pump (section) |
| 7. Backdragging relief valve | 21. Oil tank |
| 8. Relief piston | 22. Main priority valve |
| 9. Sump return check valve | 23. One way check valve |
| 10. Bucket spool | 23a. One way check valve |
| 10a. Relief piston | 24. Steering control valve |
| 11. Dozing relief valve | 25. Gerotor (metering valve) |
| 12. Check valves | 26. Cross-over valves |
| 13. Special equipment spool | 27. Steering cylinders |
| 14. Check valves | 28. Cushion valve |

1.3.10 EMERGENCY STEERING CONTROL (Fig. 1-3) Special Equipment

NOTE: The conditions under which emergency steering will automatically become effective are:

- . Engine off
- . Machine moving
- . Steering wheel turning

The ground drive pump (29) draws oil from the reservoir (21) through the check valve block (30); the purpose of the block is to allow emergency steering in either a forward or backward direction.

Oil from the pump (29) flows through the block to the secondary priority valve (31) and to the pressure switch and warning light (32); the switch is activated (closed) by pressurized oil to turn on the warning light (if the ignition switch is on.).

Oil flows through the secondary priority valve (31), opens the check valve (23a) and flows to the steering control valve (24); a portion of the oil flows through a small check valve (in the control valve) and flows back to the secondary priority valve (to hold it in position for directing oil to the steering valve). The main flow goes to the gerotor (meter) valve (25) which directs the oil to the cross-over valves (26) cushion valve (28) and steering cylinders (27). Refer to paragraph 1.3.7 and 1.3.8 for an explanation of cross-over and cushion valves.

When normal steering is taking place, engine running, the main pump flow is blocked from the secondary priority valve (31) by a one-way check valve (23A). But, the oil can flow to the right end of valve (31) pushing the valve to the left, opening emergency pump flow to sump; this, of course lowers the pressure in the emergency system and the warning light goes out.

TROUBLESHOOTING AND TESTING THE HYDRAULIC SYSTEMS

=====

⚠ WARNING Observe all start up and shut down procedures and WARNINGS listed in the Operation and Maintenance Instruction Manual.

Start the engine and set it at mid-throttle. Allow the temperature of the hydraulic oil to reach approximately 71–82°C (160–180°F).

With the flow meter load valve open, place the boom control lever to the "raise" position. No pressure will register on the flow meter, only oil flow volume. Volume should be:

FR10, 12 -- 106–119 L/MIN (28–31.4 gpm)
FR15 ----- 162–182 L/MIN (43–48 gpm)

Record the volume indicated.

NOTE: Since there is no resistance to oil flow through the meter, and considerable resistance through the boom cylinders, all oil will flow through the meter at this time. Thus, the boom will not "raise" until a load is applied with the flow meter load valve.

IMPORTANT: When performing the following tests and adjustments, never hold the flow meter load valve in the engaged position for more than 10 seconds at a time. In this condition, the hydraulic pump is working against main relief valve pressure. This will cause the hydraulic oil to overheat and may damage hydraulic system components.

With boom control lever in the "lower" position, gradually apply a load (with the flow meter load valve) and record oil flow volume at each of the following pressure points (in chart).

bar	34.5	68.9	103.4
kg/cm ²	35.1	70.3	105.4
psi	500	1000	1500

Boom
"lower"

Boom
"raise"

Bucket
"retract"

Bucket
"dump"

Repeat this procedure with the boom control lever in the "raise" position, and record the results. Make certain that engine speed remains constant for each test.

NOTE: Refer to paragraph 4.6.2 for boom circuit test analysis.

With the bucket control lever in the "retract" position, gradually apply a load with the flow meter load valve and record oil flow at each (charted) pressure point. Repeat this procedure with the bucket control lever in the "dump" position, and record the results. Make certain that engine speed remains constant for each test.

IMPLEMENT AND STEERING PUMPS

5.4 IMPLEMENT/STEERING PUMP DISASSEMBLY/ASSEMBLY NOTES (FR10,12)




FIG.5-4 IMPLEMENT/STEERING PUMP (FR10,12)

T-70664

- | | | |
|------------------------|-----------------------|-----------------------|
| 1. End cover oil seal | 14. Pocket seal | 26. Rear gear housing |
| 2. Front end cover | 15. Roller bearing | 27. O-ring |
| 3. Seal ring, bronze | 16. Seal ring, bronze | 28. Wear plate |
| 4. Set screw | 17. Bearing carrier | 29. Pocket seal |
| 5. Roller bearing | 18. Seal ring, bronze | 30. Roller bearing |
| 6. Wear plate | 19. Connecting shaft | 31. Seal ring, bronze |
| 7. Pocket seal | 20. Roller bearing | 32. Rear end cover |
| 8. Drive shaft assy. | 21. Wear plate | 33. Washer |
| 9. Driven gear | 22. Pocket seal | 34. Pump stud |
| 10. O-ring | 23. Drive gear | 35. Nut |
| 11. Front gear housing | 24. Driven gear | 36. Pipe plug |
| 12. O-ring | 25. O-ring | 37. Gasket |
| 13. Wear plate | | |

SERVICE NOTES:

- A. Mark all housing sections and when re-assembling use matching components, so the parts will fit in the original positions.
- B. Use extreme care when removing wear plates from blind bores – do not force or pry on the plates.
- C. When rebuilding pump, replace all seals, wear plates, isolation plates and o-rings.
- D. Maximum allowable gear track depth in gear housings is 0.38 mm (.015"). Nominal depth is 0.20 mm (.008"). If housings are worn 0.38 mm (.015") replace housings and bushings.

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

IMPLEMENT AND STEERING VALVES

MEMO

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

HYDRAULIC CYLINDER REPAIR




FIG. 7-1 LOOSENING CYLINDER T-76501

stand. After boom is fully supported, move the control levers to each position several times to relieve hydraulic pressure. Turn master electrical switch to the "OFF" position.

IMPORTANT: If for some reason your hoist is not capable of raising the boom and bucket weight (and only one lift cylinder has failed) disconnect and block the failed cylinder hoses at the upper manifold. To block the hoses, use the same o-ring and flange connections, and steel plates (in place of the connecting hose). The one good cylinder is capable of lifting the boom and bucket.

=====

⚠ WARNING - Do not work under the boom unless it is additionally supported.

7.1.2 With spanner wrench, loosen cylinder head assembly unit, similar to Fig. 7-1, whether it is a complete or partial tear down. Block up or brace cylinder to keep from damaging the cylinder or pinching hoses when pulling pin on rod end. After rod end is loose, finish unscrewing cylinder head assembly, Fig. 7-2 (12).

7.1.3 Pull piston rod assembly (6) from cylinder tube (1). Clamp the piston rod assembly in a soft jaw vise. Remove rod nut and slide all parts from the piston rod.

7.1.4 Remove the capscrews and lock washers that secure end plate (15) to cylinder head (12). Remove rod wiper (16) from end plate.

7.1.5 Remove rod packing set (13) from the bore in cylinder head (12). Remove o-ring (10) and back-up ring (11) from the cylinder head.

7.1.6 Remove Teflon seal ring (8) rubber seal ring (7) and wear ring (5) from piston (6).

7.1.7 Replacing piston rod bushing. Weld two or three beads across the inner surface of bushing. These welds will shrink the bushing so they may be driven out. Press new bushing into place so ends are flush with face of equal distance on each side.

7.2 ASSEMBLY OF CYLINDERS

7.2.1 Fig. 7-2. Clean the bore in end plate (15) and press a new rod wiper (16) into the end plate with the sealing lip facing out.

7.2.2 Clean the bore in cylinder head (12). Insert rod packing set (13). Place the four shims (14) and end plate (15) into position on the cylinder head. Install the end plate capscrews and lockwashers and tighten hand tight only.

NOTE: FR10,12,15 steering cylinder rod packing is not adjustable. The seals and wear rings must be replaced if leakage occurs. Dump and lift rod packing is adjustable.

7.2.3 Install back-up ring (11) and o-ring (10) over the threaded end of the cylinder head. Make certain they are firmly seated in their groove.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL