



DEATHACE 
HONDA



SERVICE MANUAL

2008
CBR1000RR

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

LUBRICATION SYSTEM SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT
Engine oil capacity	After draining	2.8 liters (3.0 US qt, 2.5 Imp qt)	-
	After oil filter change	3.0 liters (3.2 US qt, 2.6 Imp qt)	-
	After disassembly	3.7 liters (3.9 US qt, 3.3 Imp qt)	-
Recommended engine oil		Pro Honda GN4 4-stroke oil (U.S.A. and Canada) or equivalent motor oil API service classification: SG or Higher JASO T 903 standard: MA Viscosity: SAE 10W-30	-
Oil pressure at EOP switch		590 kPa (6.0 kgf/cm ² , 86 psi) at 6,000 rpm/(80°C/176°F)	-
Oil pump	Tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.15 – 0.21 (0.006 – 0.008)	0.35 (0.014)
	Side clearance	0.04 – 0.09 (0.002 – 0.004)	0.17 (0.007)

FUEL SYSTEM (PGM-FI) SPECIFICATIONS

ITEM		SPECIFICATIONS
Throttle body identification number	Except California type	GQ23C
	California type	GQ23B
Idle speed		1,200 ± 100 rpm
Throttle grip freeplay		2 – 5 mm (1/16 – 3/16 in)
IAT sensor resistance (at 20°C/68°F)		1 – 4 kΩ
Fuel injector resistance (at 20°C /68°F)	Primary injector	11 – 13 Ω
	Secondary injector	11 – 13 Ω
PAIR control solenoid valve resistance (at 20°C/68°F)		23 – 27 Ω
IDC solenoid valve resistance (at 20°C/68°F)		28 – 32 Ω
CKP sensor peak voltage (at 20°C/68°F)		0.7 V minimum
Fuel pressure at idle		343 kPa (3.5 kgf/cm ² , 50 psi)
Fuel pump flow (at 12 V)		167 cm ³ (5.6 US oz, 5.9 Imp oz) minimum/10 seconds

COOLING SYSTEM SPECIFICATIONS

ITEM		SPECIFICATIONS
Coolant capacity	Radiator and engine	3.0 liters (3.2 US qt, 2.6 Imp qt)
	Reserve tank	0.34 liter (0.36 US qt, 0.30 Imp qt)
Radiator cap relief pressure		108 – 137 kPa (1.1 – 1.4 kgf/cm ² , 16 – 20 psi)
Thermostat	Begin to open	80 – 84°C (176 – 183°F)
	Fully open	95°C (203°F)
	Valve lift	8 mm (0.3 in) minimum
Recommended antifreeze		Pro Honda HP Coolant or an equivalent high quality ethylene glycol antifreeze containing silicate free corrosion inhibitors
Standard coolant concentration		1:1 (mixture with distilled water)

HYDRAULIC BRAKE

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Reserve tank stopper plate screw	2	4	1.2 (0.1, 0.9)	Apply silicone grease to the sliding surface.
Front brake lever pivot bolt	1	6	1.0 (0.1, 0.7)	
Front brake lever pivot nut	1	6	6.0 (0.6, 4.4)	ALOC bolt; replace with a new one.
Front brake light switch screw	1	4	1.2 (0.1, 0.9)	
Front master cylinder holder bolt	2	6	12 (1.2, 9)	
Front brake caliper mounting bolt	4	10	45 (4.6, 33)	
Front brake reserve tank stay bolt	1	6	12 (1.2, 9)	
Rear master cylinder push rod lock nut	1	8	18 (1.8, 13)	
Rear master cylinder mounting nut	2	6	10 (1.0, 7)	
Front brake caliper pad pin	4	10	15 (1.5, 11)	
Rear brake caliper pad pin	1	10	18 (1.8, 13)	
Brake hose oil bolt	5	10	34 (3.5, 25)	
Front brake hose clamp nut	1	6	10 (1.0, 7)	
Front brake hose 3-way joint bolt	1	6	10 (1.0, 7)	
Front brake caliper bleed valve	2	8	8.0 (0.8, 5.9)	
Rear brake caliper bleed valve	1	8	6.0 (0.6, 4.4)	
Rear brake hose clamp bolt	1	5	4.2 (0.4, 3.1)	
Heat guard mounting screw	2	5	4.2 (0.4, 3.1)	

ELECTRIC STARTER

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Starter motor terminal nut	1	6	12 (1.2, 9)	ALOC bolt; replace with a new one.
Starter motor setting bolt	2	5	4.0 (0.4, 3.0)	
Negative brush mounting screw	1	5	3.7 (0.4, 2.7)	


LIGHTS/METERS/SWITCHES

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
EOP switch	1	PT 1/8	12 (1.2, 9)	Apply sealant to the threads.
EOP switch wire terminal bolt	1	4	2.0 (0.2, 1.5)	Replace with a new one.
Neutral switch	1	10	12 (1.2, 9)	
Combination meter screw	8	5	1.0 (0.1, 0.7)	
Ignition switch mounting bolt	2	8	26 (2.7, 19)	
Sidestand switch mounting bolt	1	6	10 (1.0, 7)	
Right handlebar switch housing screw	2	4	0.9 (0.09, 0.7)	ALOC screw; replace with a new one.
Clutch switch mounting screw	1	3	0.6 (0.06, 0.4)	
Combination meter stay mounting bolt	2	8	32 (3.3, 24)	


OTHERS

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
Sidestand pivot bolt	1	10	10 (1.0, 7)	
Sidestand pivot nut	1	10	29 (3.0, 21)	
Sidestand spring hook bolt	1	8	21.5 (2.2, 16)	
Gearshift pedal pivot bolt	1	8	22 (2.2, 16)	

EXCEPT CALIFORNIA TYPE:



CALIFORNIA TYPE:



EMISSION CONTROL SYSTEMS

EXHAUST EMISSION REQUIREMENT

The U.S. Environmental Protection Agency (EPA), California Air Resources Board (CARB) and Transport Canada require manufacturers to certify that their motorcycles comply with applicable emissions standards during their useful life, when operated and maintained according to the instructions provided.

NOISE EMISSION REQUIREMENT

The EPA also requires that motorcycles built after January 1, 1983 comply with applicable noise emission standards for one year or 3,730 miles (6,000 km) after the time of sale to the ultimate purchaser, when operated and maintained according to the instructions provided.

WARRANTY COMPLIANCE

Compliance with the terms of the Distributor's Limited Warranty for Honda Motorcycle Emission Control Systems is necessary in order to keep the emissions system warranty in effect.


SOURCE OF EMISSIONS

The combustion process produces carbon monoxide (CO), oxides of nitrogen (NO_x) and hydrocarbons (HC). Control of carbon monoxide, oxides of nitrogen and hydrocarbons is very important because, under certain conditions, they react to form photochemical smog when subject to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda Motor Co., Ltd. utilizes various system (page 1-38) to reduce carbon monoxide, oxides of nitrogen and hydrocarbons.

CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the air cleaner housing and throttle body.




TECHNICAL FEATURES


CLUTCH MECHANISM

OPERATION

When the clutch lever is released, the engine power is transmitted from the crankshaft to mainshaft as follows:



When the clutch lever is applied, the pressure plate is lifted off from the clutch discs and the engine power is cut from the crankshaft to mainshaft.




UPPER INNER COVER

REMOVAL/INSTALLATION

Remove the trim clips.

Release the groove from the rubber tab and remove the upper inner cover.

Be careful not to damage the tabs. Installation is in the reverse order of removal.



LOWER COWL

REMOVAL/INSTALLATION

Release the hoses from the lower cowl.

Be careful not to damage the tabs and grooves. Remove the screws and special screws.

Release the front side grooves from the middle cowl tabs.

Slide the lower cowl rearward and remove the lower cowl downward.


Remove the special nuts from the stays.

Installation is in the reverse order of removal.

TORQUE:

Lower cowl mounting screw:
1.5 N·m (0.2 kgf·m, 1.1 lbf·ft)

Lower cowl mounting special screw:
10 N·m (1.0 kgf·m, 7 lbf·ft)



REAR FENDER A

REMOVAL/INSTALLATION

Remove the nuts, bolts and number plate bracket.


Remove the nuts and reflectors from the number plate bracket.

Remove the special screws.

Remove the nut, reflector, collar and rear fender A.

Installation is in the reverse order of removal.

- Align the reflector tab with the license light stay hole.



REAR FENDER B


REMOVAL/INSTALLATION

Remove the following:


- Rear seat cowl (page 3-8)
- Fuel tank (page 6-51)
- Battery (page 17-6)
- Regulator/rectifier (page 17-9)
- Starter relay switch (page 19-14)
- EGCA (page 6-79)

Disconnect the brake/tail light 3P (Natural) and sub harness 4P (Black) connectors.


Remove the fuse/relay box from the rear fender B.



INSTALLATION




Install a new gasket and the muffler to the exhaust pipe.




FUEL LINE

FUEL TANK LIFTING


Remove the top shelter (page 3-7).
 Release the fuel tank drain hose.



Remove the fuel tank mounting bolts and collars.




California type: Disconnect the fuel tank breather hose at hose joint.



Except California type: Lift the fuel tank front end and disconnect the fuel tank breather hose.

California type: Lift the fuel tank front end.




Record the clearance for each valve for reference in shim selection if adjustment is required.

Check the valve clearance for the No.2 and No.4 cylinder intake valves using feeler gauge.

VALVE CLEARANCE:

IN: 0.16 ± 0.03 mm (0.006 ± 0.001 in)



Turn the crankshaft clockwise 1/2 turn (180°).




Record the clearance for each valve for reference in shim selection if adjustment is required.

Check the valve clearance for the No.1 and No.3 cylinder exhaust valves using a feeler gauge.

VALVE CLEARANCE:

EX: 0.30 ± 0.03 mm (0.012 ± 0.001 in)



ADJUSTMENT

NOTE:


Use genuine Honda parts shims specific to this model for replacement. In case of wrong shims usage, the intake valve titanium surface may be damaged.

It is not necessary to remove the cam sprocket from the camshaft except when replacing the camshaft and/or cam sprocket.

Remove the camshafts (page 9-9).

Remove the valve lifters and shims.

- The shim may stick to the inside of the valve lifter. Do not allow the shims to fall into the crankcase.
- Mark all valve lifters and shims to ensure correct reassembly in their original locations.
- The valve lifter can be easily removed with a valve lapping tool or magnet.
- The shims can be easily removed with a tweezers or magnet.



Remove the muffler (page 3-24).



Loosen the lock nut and adjust the EGCA cable length with the ECV closed position.

- Keep the EGCA cable straight when adjust the cable length.
- Check the length of the EGCA cable with the ECV closed position while pulling the EGCA cable.

STANDARD LENGTH: 49 – 52 mm (1.9 – 2.0 in)

Tighten the EGCA cable lock nut to the specified torque.



TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)



Connect the EGCA cable to the EGCA pulley.

Turn the EGCA pulley counterclockwise to the specified angle as shown.

Installation is in the reverse order of removal.



SIDESTAND

Check the sidestand spring for damage or loss of tension.

Check the sidestand for movement and lubricate the sidestand pivot if necessary.

TORQUE:



Sidestand pivot bolt: 10 N·m (1.0 kgf·m, 7 lbf·ft)

Sidestand pivot nut: 29 N·m (3.0 kgf·m, 21 lbf·ft)

Check the sidestand ignition cut-off system:

- Sit astride the motorcycle and raise the sidestand.
- Start the engine with the transmission in neutral, then, with the clutch lever fully squeezed, shift the transmission into gear.
- Move the sidestand full down.
- The engine should stop as the sidestand is lowered.

If there is a problem with the system, check the sidestand switch (page 20-20).



SUSPENSION

FRONT SUSPENSION INSPECTION

Check the action of the forks by operating the front brakes and compressing the front suspension several times.

Check the entire assembly for signs of leaks, damage or loose fasteners.

Loose, worn or damaged suspension parts impair motorcycles stability and control.

Replace damaged components that cannot be repaired.

Tighten all nuts and bolts.

For fork service (page 14-22).



OIL PRESSURE INSPECTION

If the oil pressure indicator remains on while the engine is running, check the indicator system (page 20-14) before checking the oil pressure.

Remove the EOP switch (page 20-14).

Install the oil pressure gauge attachment to the switch base.

Connect the oil pressure gauge to the oil pressure gauge attachment.

TOOLS:

Oil pressure gauge set

07506-3000001 or equivalent commercially available

Oil pressure gauge attachment

07406-0030000 or equivalent commercially available

Check the engine oil level (page 4-17).


Warm the engine to normal operating temperature (approximately 80°C/176°F) and increase the engine speed to 6,000 min⁻¹ (rpm) and read the oil pressure.

Standard:

590 kPa (6.0 kgf/cm², 86 psi) at 6000 rpm/ (80°C/176°F)

Stop the engine and remove the tools.

Install the EOP switch (page 20-14).



OIL PUMP



REMOVAL

Drain the engine oil (page 4-18).

Remove the exhaust pipe (page 3-31).


Remove the screws and lower cowl stays.

Remove the bolts and oil pan.




COMPONENT LOCATION	6-2	THROTTLE BODY	6-58
SERVICE INFORMATION	6-3	PRIMARY INJECTOR.....	6-63
PGM-FI SYMPTOM TROUBLESHOOTING	6-7	ENGINE IDLE SPEED.....	6-66
PGM-FI SYSTEM LOCATION	6-8	IACV	6-66
PGM-FI SYSTEM DIAGRAM	6-9	KNOCK SENSOR	6-68
CONNECTOR LOCATION	6-10	MAP SENSOR.....	6-69
PGM-FI TROUBLESHOOTING INFORMATION	6-12	IAT SENSOR	6-70
DTC INDEX.....	6-15	ECT SENSOR	6-70
DTC TROUBLESHOOTING.....	6-17	CMP SENSOR	6-71
MIL CIRCUIT TROUBLESHOOTING	6-40	BANK ANGLE SENSOR	6-71
FUEL LINE INSPECTION	6-41	ENGINE STOP RELAY	6-73
FUEL PUMP UNIT.....	6-47	ECM.....	6-74
FUEL PUMP RELAY	6-50	SECONDARY AIR SUPPLY SYSTEM	6-77
FUEL TANK	6-51	EGCA	6-79
AIR CLEANER HOUSING	6-52	INTAKE AIR DUCT CONTROL	6-81
SECONDARY INJECTOR.....	6-55	EVAP PURGE CONTROL SOLENOID VALVE/ CANISTER (CALIFORNIA TYPE).....	6-83

NOTE: Remove the air cleaner housing (page 6-52).



NOTE: Remove the seat (page 3-6).



3. ECT Sensor Resistance Inspection


Measure the resistance at the ECT sensor terminals.

Connection: Blue/yellow – Gray/black
Standard: 2.3 – 2.6 kΩ (20°C/68°F)
 (Sensor side terminals)

Is the resistance within 2.3 – 2.6 kΩ?

YES – Replace the ECM with a known good one, and recheck.

NO – Faulty ECT sensor



4. ECT Sensor Output Line Short Circuit Inspection

Turn the ignition switch OFF.


Check for continuity between the ECT sensor 3P (Gray) connector at the wire side and ground.

Connection: Blue/yellow – Ground

Is there continuity?

YES – Short circuit in Blue/yellow wire

NO – Replace the ECM with a known good one, and recheck.



DTC 7-2 (ECT SENSOR HIGH VOLTAGE)

- Before starting the inspection, check for loose or poor contact on the ECT sensor 3P (Gray) connector and ECM 33P connectors, then recheck the DTC.

1. ECT Sensor System Inspection

Turn the ignition switch ON and engine stop switch "O".

Check the ECT sensor with the HDS.

Is about 5 V indicated?

YES – GO TO STEP 2.

NO – Intermittent failure

2. ECT Sensor Inspection

Turn the ignition switch OFF.

Disconnect the ECT sensor 3P (Gray) connector. Connect the ECT sensor 3P (Gray) connector terminals with a jumper wire.

Connection: Blue/yellow – Gray/black


Turn the ignition switch ON and engine stop switch "O".

Check the ECT sensor with the HDS.

Is about 0 V indicated?

YES – Inspect the ECT sensor (page 20-13).

NO – GO TO STEP 3.



3. CMP Sensor Input Voltage Inspection


Measure the voltage at the wire side.

Connection: Yellow/red (+) – Gray/black (-)

Is the voltage within 4.75 – 5.25 V?

YES – Faulty CMP sensor

NO – • Open circuit in Yellow/red wire
• Open circuit in Gray/black wire



4. CMP Sensor signal line open Circuit Inspection

Turn the ignition switch OFF.
Disconnect the ECM 33P (Gray) connector.


Check for continuity at the Gray wire between the CMP sensor 3P (Blue) connector and ECM 33P (Gray) connector.

Connection: B33 – Gray

Is there continuity?

YES – Replace the ECM with a known good one, and recheck.

NO – Open circuit in Gray wire



DTC 19-1 (CKP SENSOR)

- Before starting the inspection, check for loose or poor contact on the CKP sensor 2P (Red) connector and ECM 33P connectors, then recheck the DTC.

1. CKP Sensor Peak Voltage Inspection

Turn the ignition switch OFF.
Disconnect the CKP sensor 2P (Red) connector.

Turn the ignition switch ON.
Crank the engine and measure the CKP sensor peak voltage at the CKP sensor 2P (Red) connector.

Connection: Yellow (+) – White/yellow (-)
(Sensor side terminals)

TOOL:


IgnitionMate peak voltage tester MTP07-0286 (U.S.A. only) or 07HGJ-0020100 (Not available in U.S.A.)
Peak voltage adaptor

with commercially available digital multimeter (impedance 10 MΩ/DCV minimum)

Is the voltage more than 0.7 V (20°C/68°F)?

YES – GO TO STEP 2.

NO – Faulty CKP sensor




FUEL LINE INSPECTION

QUICK CONNECT FITTING LOCATION

The quick connect fittings are located as shown.


NOTE:

The quick connect fitting cover is only installed on the fuel pump side joint. The rubber caps are installed in the other quick connect fittings.



FUEL PRESSURE RELIEVING/QUICK CONNECT FITTING REMOVAL

- Before disconnecting the fuel hose, relieve pressure from the system as follows.
 1. Turn the ignition switch OFF.
Lift and support the fuel tank (page 4-5).
Remove the quick connect fitting cover (fuel pump side only).
 2. Disconnect the fuel pump 2P (Brown) connector.
 3. Start the engine, and let it idle until the engine stalls.
 4. Turn the ignition switch OFF.
 5. Disconnect the battery negative (-) cable (page 17-6).




FUEL TANK

REMOVAL

Relieve the fuel pressure (page 6-41) and disconnect the quick connect fitting from the fuel tank.

Disconnect the fuel reserve sensor 2P (Black) connector.


EXCEPT CALIFORNIA TYPE SHOWN:
QUICK CONNECT FITTING




2P (BLACK) CONNECTOR


Remove the support, fuel tank pivot bolts, collars and fuel tank.

For fuel pump unit removal (page 6-48).




INSTALLATION





PAINTED WHITE


THROTTLE BODY VACUUM HOSE ROUTING (CALIFORNIA TYPE)



CMP SENSOR

REMOVAL/INSTALLATION

- Remove the air cleaner housing (page 6-52).
- Disconnect the CMP sensor 3P (Blue) connector.
- Remove the bolt, CMP sensor and O-ring from the cylinder head cover.
- Apply oil to a new O-ring and install it onto the CMP sensor.
- Install the CMP sensor on to the cylinder head.
- Tighten the bolt securely.
- Connect the CMP sensor 3P (Blue) connector.
- Install the air cleaner housing (page 6-54).




BANK ANGLE SENSOR

REMOVAL/INSTALLATION

- Remove the upper cowl (page 3-13).
- Remove the vacuum chamber.



- Remove the screws and vacuum chamber stay.
- Remove the bank angle sensor 3P (Black) connector from the stay.




- Disconnect the bank angle sensor 3P (Black) connector.

- Remove the screws, washers and bank angle sensor from the front cowl.

Installation is in the reverse order of removal.

TORQUE:

- Bank angle sensor mounting screw:**
1.1 N·m (0.1 kgf·m, 0.8 lbf·ft)



Measure the resistance between the EGCA 6P (Black) connector terminals.

Connection: Yellow/red – Green


Standard: 3.5 – 6.5 kΩ

Connection: Brown – Green


Standard: 0 – 5 kΩ

If the resistance is out of range, replace the EGCA.

6P CONNECTOR
(EGCA side/male terminals)



6P CONNECTOR
(EGCA side/male terminals)



INTAKE AIR DUCT CONTROL

INTAKE AIR DUCT VALVE DIAPHRAGM

INSPECTION


Remove the intake air duct from the middle cowl (page 3-11).

Disconnect the vacuum hose from the diaphragm.

Connect a vacuum pump to the diaphragm and apply specified vacuum.

SPECIFIED VACUUM: 250 mm Hg (9.8 in Hg)

The vacuum should hold and the air duct valve should remain open.




IDC SOLENOID VALVE

Check that the air should flow (A) to (B), only when the 12 V battery is connected to the IDC solenoid valve terminal.

Connection: White terminal (+) – Yellow terminal (-)

2P CONNECTOR
(IDC solenoid valve side/male terminals)



COOLING SYSTEM

RADIATOR CAP/SYSTEM PRESSURE INSPECTION

Remove the radiator cap (page 7-5).

Before installing the cap in the tester, wet the sealing surfaces.

Pressure test the radiator cap. Replace the radiator cap if it does not hold pressure, or if relief pressure is too high or too low. It must hold specified pressure for at least 6 seconds.

RADIATOR CAP RELIEF PRESSURE:


108 – 137 kPa (1.1 – 1.4 kgf/cm², 16 – 20 psi)

Pressure the radiator, engine and hoses, and check for leaks.

NOTICE

Excessive pressure can damage the cooling system components. Do not exceed 137 kPa (1.4 kgf/cm², 20 psi).

Repair or replace components if the system will not hold specified pressure for at least 6 seconds.



COOLANT REPLACEMENT

PREPARATION


- The effectiveness of coolant decreases with the accumulation of rust or if there is a change in the mixing proportion during usage. Therefore, for best performance change the coolant regularly as specified in the maintenance schedule.
- Mix only distilled, low mineral water with the antifreeze.

RECOMMENDED ANTIFREEZE:

Pro Honda HP Coolant or an equivalent high quality ethylene glycol antifreeze containing silicate free corrosion inhibitors


RECOMMENDED MIXTURE:

1:1 (mixture with distilled water)



COOLING SYSTEM


ASSEMBLY



Left fan motor


Install the left fan motor onto the shroud and tighten the screws to the specified torque.

TORQUE: 2.7 N·m (0.3 kgf·m, 2.0 lbf·ft)



ENGINE REMOVAL/INSTALLATION

COMPONENT LOCATION



ENGINE REMOVAL/INSTALLATION

Correctly route the wires (page 1-20).

Install the battery negative (-) cable and tighten the bolt securely.


Connect the stator motor cable and tighten the nut to the specified torque.

TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)


Install the drive sprocket with its marks facing out.

Install the washer and drive sprocket bolt, then tighten the bolt to the specified torque.

TORQUE: 54 N·m (5.5 kgf·m, 40 lbf·ft)



Connect the water hoses to the thermostat housing securely.



Connect the knock sensor 3P (Blue) and ECT sensor 3P (Gray) connectors.



Connect the sidestand switch 2P (Black) connector.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

CYLINDER HEAD/VALVES

Remove the cylinder head cover bolts and washers.




Remove the cylinder head cover from the cylinder head.




CYLINDER HEAD COVER DISASSEMBLY

Remove the cylinder head cover packing.
Remove the bolts and breather plate.



Remove the bolts and PAIR check valve cover.



CYLINDER HEAD/VALVES

VALVE SPRING

Measure the free length of the inner and outer valve springs.

SERVICE LIMITS:


IN: Inner: 34.5 mm (1.36 in)

Outer: 38.2 mm (1.50 in)


EX: 38.9 mm (1.53 in)

Replace the springs if they are shorter than the service limits.

IN:




EX:



CAM CHAIN TENSIONER/CAM CHAIN GUIDE

Inspect the cam chain tensioner A and cam chain guide A for excessive wear or damage, replace them if necessary.


CAM CHAIN TENSIONER A



CAM CHAIN GUIDE A


Inspect the cam chain tensioner B for excessive wear or damage, replace it if necessary.

CAM CHAIN TENSIONER B




CYLINDER HEAD/VALVES

Check that the cylinder stud bolt height from the bolt head to cylinder gasket surface is within specification.



Install the cylinder head onto the cylinder block while aligning the cam chain tensioner A and B as shown.




CYLINDER HEAD/VALVES

Install and tighten the bolts securely.

Remove the tensioner stopper.


Install a new sealing washer and tighten the sealing bolt securely.

Remove the support and close the fuel tank (page 4-7).




CLUTCH/STARTER CLUTCH/GEARSHIFT LINKAGE


Remove the clutch outer guide and needle bearing.




Remove the clutch outer.



Remove the starter reduction gear from the crankcase.




Be careful not to drop the parts into the oil pan. Remove the bolt and oil pump drive chain guide.




CLUTCH/STARTER CLUTCH/GEARSHIFT LINKAGE

Loosely install the setting bolts (M6 x 35) as shown.




Install the clutch disc assembly by aligning its tabs of outside clutch disc A into the clutch outer shallow slots.

Remove the setting bolts.




Install the spring seat.




CLUTCH/STARTER CLUTCH/GEARSHIFT LINKAGE

Install the thrust washer and gearshift spindle into the crankcase while aligning the spring ends with the stopper pin.



Apply locking agent to the setting plate bolt threads (page 1-18).
Install the setting plate and tighten the bolt to the specified torque.


TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)



Install the gearshift arm to the gearshift spindle, aligning the arm slit with the punch mark on the gearshift spindle.
Install and tighten the pinch bolt.


Install the following:

- Clutch (page 10-17)
- Right crankcase cover (page 10-30)



RIGHT CRANKCASE COVER INSTALLATION

Install the four dowel pins.




ALTERNATOR

The alternator cover (stator) is magnetically attracted to the flywheel, be careful during installation.

Install the alternator cover and bolts.

Tighten the bolts in a crisscross pattern in two or three steps securely.



Connect the CKP sensor 2P (Red) connector.



Connect the alternator 3P (Black) connector.

Install the following:

- Drive sprocket cover (page 4-28)
- Left middle cowl (page 3-10)
- Fuel tank (page 6-51)

After installation, add the recommended engine oil to the specified level.

Check the engine oil level (page 4-17).



CRANKCASE/TRANSMISSION/BALANCER

Check the mainshaft and countershaft for abnormal wear or damage.

Measure the mainshaft O.D. at the M5 gear.

SERVICE LIMIT: 27.957 mm (1.1007 in)

Measure the countershaft O.D. at the C2 gear.


SERVICE LIMIT: 29.960 mm (1.1795 in)

Calculate the gear bushing-to-shaft clearance.

SERVICE LIMITS:

M5: 0.06 mm (0.002 in)

C2: 0.06 mm (0.002 in)



Countershaft bearing


Turn the outer race of countershaft bearing with your finger.

The bearing should turn smoothly and quietly.

Also check that the bearing inner race fits tightly on the countershaft.

Replace the countershaft, collar, and bearing as an assembly, if the race does not turn smoothly, quietly, or if the inner race fits loosely on the countershaft.

- The countershaft bearing cannot be replaced. If the countershaft bearing is faulty, replace the countershaft as an assembly.



Mainshaft bearing


Temporarily install the right mainshaft bearing onto the mainshaft.

Turn the outer race of the left mainshaft bearing with your finger.

The bearing should turn smoothly and quietly.

Also check that the inner race of the bearing fits tightly on the mainshaft.

Replace the bearing if the inner race does not turn smoothly, quietly, or if the inner race fits loosely on the mainshaft.




Turn the inner race of the left mainshaft bearing with your finger.

The bearing should turn smoothly and quietly.


Also check that the outer race of the bearing fits tightly in the crankcase.

Replace the bearing if the inner race does not turn smoothly, quietly, or if the outer race fits loosely in the crankcase.




CRANKCASE/TRANSMISSION/BALANCER

Apply oil to a new O-ring and install it to the balancer shaft groove.




INSTALLATION


Install the balancer weight into the lower crankcase.
Install the balancer shaft.



Turn the balancer shaft and position the punch mark on the shaft facing down.




Install the balancer shaft holder.
Install the balancer holder bolt and balancer holder pinch bolt.
Install a new sealing washer and sealing bolt.
Assemble the crankcase halves (page 12-22).
Adjust the backlash (page 12-21).



CRANKSHAFT/PISTON/CYLINDER

Remove the bolts, oil jet pipes and O-rings from the upper crankcase.

Clean the oil jet pipes in solvent thoroughly.




INSPECTION

Support the crankshaft at both end journals.
Set a dial gauge on the center main journal of the crankshaft.
Rotate the crankshaft two revolutions and read the runout.

SERVICE LIMIT: 0.05 mm (0.002 in)


Check the primary drive gear and balancer drive gear teeth for abnormal wear or damage.



Always replace the O-rings when the oil jet pipes are removed.

Inspect the oil jet pipes for clogs, bending or damage.

Replace them if necessary.




CRANKSHAFT/PISTON/CYLINDER

PISTON DISASSEMBLY


Be careful not to damage the piston ring by spreading the ends too far.

Spread each piston ring ends and remove them by lifting up at a point opposite the gap.



Never use a wire brush; it will scratch the groove.

Clean carbon deposits from the piston ring grooves with a ring that will be discarded.



PISTON INSPECTION

Inspect the piston rings for free movement by rotating them in their grooves. The rings should be able to move freely without catching.

Push the ring until the outer surface of the piston ring is nearly flush with the piston and measure the ring-to-ring groove clearance.

SERVICE LIMITS:

Top: 0.120 mm (0.0050 in)

Second: 0.075 mm (0.0030 in)



Push the rings into the cylinder with the top of the piston to be sure they are squarely positioned in the cylinder.


Insert the piston ring squarely into the top of the cylinder and measure the ring end gap.













SERVICE LIMITS:

Top: 0.52 mm (0.020 in)

Second: 0.74 mm (0.029 in)

Oil (side rail): 1.00 mm (0.040 in)




<p>Fork damper holder 07YMB-MCF0101</p>  <p>or 07YMB-MCFA100 (U.S.A. only)</p>	<p>Spring collar holder 070MF-MBZC110</p>  <p>NOTE: This tool is a part of fork damper install set (P/N 070MF-MBZC100) (Not available in U.S.A.)</p>	<p>Damper rod holder 070MF-MBZC120</p>  <p>NOTE: This tool is a part of fork damper install set (P/N 070MF-MBZC100) (Not available in U.S.A.) or 070MF-MBZA120</p>
<p>Stopper plate 070MF-MBZC130</p>  <p>NOTE: This tool is a part of fork damper install set (P/N 070MF-MBZC100) (Not available in U.S.A.)</p>	<p>Test probe 07ZAJ-RDJA110</p> 	<p>HDS pocket tester TDS3557-0112-01 (U.S.A. only)</p> 
<p>Main bearing driver attachment 07946-ME90200</p> 	<p>Fork seal driver weight 07947-KA50100</p> 	<p>Oil seal driver 07965-MA60000</p> 
<p>Installer shaft 07VMF-KZ30200</p> 	<p>Installer attachment (2 required) 07VMF-MAT0200</p> 	<p>Remover attachment 07AMF-MELA200 (U.S.A. only)</p> 

Install the right handlebar switch housing by aligning its locating pin with the hole in the handlebar.

Tighten the forward screw first, then the rear screw to the specified torque.

TORQUE: 0.9 N·m (0.09 kgf·m, 0.7 lbf·ft)




Install the master cylinder by aligning the end of the master cylinder with the punch mark on the handlebar.

Install the master cylinder holder with its "UP" mark facing up.

Tighten the upper bolt first, then the lower bolt.


TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)

Connect the front brake switch wire connectors.



Install the right handlebar weight and tighten a new screw to the specified torque.

TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)




HANDLEBAR WEIGHT REPLACEMENT

Remove the left grip and throttle pipe from the handlebar.

Straighten the weight retainer tab by the screwdriver or punch.

Temporarily install the handlebar weight and screw, then remove the inner weight by turning the handlebar weight.

Apply lubricant spray through the tab locking hole to the rubber for easy removal.




Hold the axle holder in a vise with soft jaws or a shop towel.
 Hold the fork damper with the special tool, then remove the fork socket bolt and sealing washer.


TOOL:

Fork damper holder

**07YMB-MCF0101 or
 07YMB-MCFA100
 (U.S.A. only)**




Remove the fork damper assembly from the fork slider.




Remove the dust seal.

*Do not scratch the
 fork tube sliding
 surface.*


Remove the oil seal stopper ring.



Pull the fork tube out until you feel resistance from the slider bushing. Then move it in and out, tapping the bushing lightly until the fork tube separates from the fork slider.
 The slider bushing will be forced out by the fork tube bushing.



Straighten the lock washer tabs.
Remove the lock nut and lock washer.




Remove the steering stem adjusting nut using the special tool.

TOOL:
Steering stem socket **07HMA-MR70100**



Remove the following:

- Dust seal
- Upper bearing inner race
- Upper bearing
- Steering stem
- Lower bearing



BEARING REPLACEMENT


Always replace the bearings and races as a set.

Replace the races using the special tools as described in the following procedure.

Except U.S.A.:

TOOLS: (Not available in U.S.A.)

- (1) Driver attachment (2 required) **07NMF-MT70120**
- (2) Driver shaft assembly **07946-KM90301**
- (3) Bearing remover **07NMF-MT70110**
- (4) Assembly base **07946-KM90600**



SERVICE INFORMATION

GENERAL

- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- After the rear wheel installation, check the brake operation by applying the brake pedal.
- The shock absorber contains nitrogen under high pressure. Do not allow fire or heat near the shock absorber.
- Before disposal of the shock absorber, release the nitrogen (page 15-17).
- When servicing the rear wheel and suspension, support the motorcycle using a safety stand or hoist.
- Use only tires marked "TUBELESS" and tubeless valves on rim marked "TUBELESS TIRE APPLICATION".
- Use genuine Honda replacement bolts and nuts for all suspension pivot and mounting point.
- For brake system information (page 16-4).

SPECIFICATIONS


Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		–	2.0 (0.08)
Cold tire pressure	Driver only	290 kPa (2.90 kgf/cm ² , 42 psi)	–
	Driver and passenger	290 kPa (2.90 kgf/cm ² , 42 psi)	–
Axle runout		–	0.2 (0.01)
Wheel rim runout	Radial	–	2.0 (0.08)
	Axial	–	2.0 (0.08)
Wheel balance weight		–	60 g (2.1 oz) max.
Drive chain	Size/link	DID	DID50VA11-116YB
		RK	RK50HFOZ6-116LJFZ
	Slack	25 – 35 (1.0 – 1.4 in)	
Shock absorber	Spring pre-load adjuster standard position		Position 4
	Rebound damping adjuster initial setting		2-1/4 turns out from full hard
	Compression damping adjuster initial setting		2 turns out from full hard

TORQUE VALUES

Rear brake disc bolt	42 N·m (4.3 kgf·m, 31 lbf·ft)	ALOC bolt; replace with a new one.
Driven sprocket nut	64 N·m (6.5 kgf·m, 47 lbf·ft)	U-nut
Rear axle nut	113 N·m (11.5 kgf·m, 83 lbf·ft)	U-nut
Shock absorber mounting nut	44 N·m (4.5 kgf·m, 32 lbf·ft)	U-nut
Shock link nut	44 N·m (4.5 kgf·m, 32 lbf·ft)	U-nut
Shock arm-to-swingarm nut	44 N·m (4.5 kgf·m, 32 lbf·ft)	U-nut
Drive chain slider bolt	9.0 N·m (0.9 kgf·m, 6.6 lbf·ft)	ALOC bolt; replace with a new one.
Drive chain case bolt	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Swingarm pivot nut	113 N·m (11.5 kgf·m, 83 lbf·ft)	U-nut
Rear brake hose clamp screw	4.2 N·m (0.4 kgf·m, 3.1 lbf·ft)	

Install the adjusting plate, washer and rear axle nut.
Adjust the drive chain slack (page 4-26).



SUSPENSION LINKAGE

REMOVAL


Remove the muffler (page 3-24).

Support the motorcycle using a hoist or equivalent, and raise the rear wheel off the ground.

Support the rear wheel securely.


Remove the following:

- Bolts/nuts
- Shock link
- Shock arms



SHOCK LINK BEARING REPLACEMENT

Remove the pivot collar and dust seals.




Press the needle bearings out of the shock link using the special tools.


TOOLS:

- Driver**
- Attachment, 22 x 24 mm**
- Pilot, 17 mm**
- Attachment, 30 mm I.D.**


- 07949-3710001**
- 07746-0010800**
- 07746-0040400**
- 07746-0030300**




ASSEMBLY



Apply molybdenum disulfide grease to new dust seal lips.
Install the distance collar, dust seals and pivot collars to the swingarm.



Apply molybdenum disulfide grease to new dust seal lips, then install the dust seals and collar into the swingarm.




HYDRAULIC BRAKE

Front: Perform air bleeding for the other side bleed valve.
Fill each reserve tank to the upper level with DOT 4 brake fluid from a sealed container.
Reinstall the diaphragm and set plate.


Front: Install the reserve tank cap, stopper plate and tighten the screw to the specified torque.

TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)



Rear: Install the reserve tank cap, stopper plate and tighten the screw to the specified torque.

TORQUE: 1.2 N·m (0.1 kgf·m, 0.9 lbf·ft)




BRAKE PAD/DISC

FRONT BRAKE PAD REPLACEMENT

While servicing the front and rear brake calipers, do not let them hang from the brake hose.

Loosen the pad pins.
Remove the caliper mounting bolts and brake caliper.

Discard the brake caliper mounting bolts.



Check the brake fluid level in the brake master cylinder reserve tank, as this operation causes the level to rise.

Push the caliper pistons all the way in to allow installation of new brake pads.



HYDRAULIC BRAKE

REAR MASTER CYLINDER

NOTICE

Spilled fluid can damage painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

REMOVAL

Drain the rear brake hydraulic system (page 16-6).


Remove the brake hose oil bolt, sealing washers and brake hose eyelet joint.



Support the muffler securely.


Remove the muffler mounting nut and bolt.

Remove the bolts and right main step bracket assembly from the frame.



Be careful not to damage the EGCA cable.


Release the EGCA cable from the cable guide.



HYDRAULIC BRAKE

Be careful not to damage the piston sliding surface.

Push the dust seals and piston seals in and lift them out.
Clean the seal grooves with clean brake fluid.



INSPECTION


Check the caliper cylinder for scoring or other damage.

Measure the caliper cylinder I.D.

SERVICE LIMITS:

Cylinder A: 32.130 mm (1.2650 in)

Cylinder B: 30.330 mm (1.1941 in)




Check the caliper pistons for scratches, scoring or other damage.

Measure the O.D. of each caliper piston.

SERVICE LIMITS:

Piston A: 31.967 mm (1.2585 in)

Piston B: 30.167 mm (1.1877 in)



TROUBLESHOOTING

BATTERY IS DAMAGED OR WEAK

1. BATTERY TEST

Remove the battery (page 17-6).

Check the battery condition using the recommended battery tester.

Recommended battery tester: BM210 or BATTERY MATE or equivalent

Is the battery in good condition?

NO – Faulty battery

YES – GO TO STEP 2.

2. CURRENT LEAKAGE TEST

Install the battery (page 17-6).

Check the battery current leakage test (page 17-7).

Is the current leakage below 2.0 mA?

YES – GO TO STEP 4.

NO – GO TO STEP 3.

3. CURRENT LEAKAGE TEST WITHOUT REGULATOR/RECTIFIER CONNECTED

Disconnect the regulator/rectifier connector and recheck the battery current leakage.

Is the current leakage below 2.0 mA?

YES – Faulty regulator/rectifier

NO – • Shorted wire harness
• Faulty ignition switch

4. ALTERNATOR CHARGING COIL INSPECTION

Check the alternator charging coil (page 17-8).

Is the alternator charging coil resistance within 0.1 – 1.0 Ω (20°C/68°F)?

NO – Faulty charging coil

YES – GO TO STEP 5.

5. CHARGING VOLTAGE INSPECTION

Measure and record the battery voltage using a digital multimeter (page 17-6).

Start the engine.

Measure the charging voltage (page 17-7).

Compare the measurement to result of the following calculation.

Standard:

Measured BV < Measured CV < 15.5 V

- BV = Battery Voltage (page 17-6)
- CV = Charging Voltage (page 17-7)

Is the measured charging voltage within the standard voltage?

YES – Faulty battery

NO – GO TO STEP 6.

6. REGULATOR/RECTIFIER SYSTEM INSPECTION

Check the voltage and resistance at the regulator/rectifier connector (page 17-8).

Are the results of checked voltage and resistance correct?

YES – Faulty regulator/rectifier

NO – • Open circuit in related wire
• Loose or poor contacts of related terminal

IGNITION SYSTEM

Disconnect the direct ignition coil 2P (White) connector.


Turn the ignition switch ON and engine stop switch "O".

Measure the initial voltage.

Connection: Black/white (+) – Ground (-)

Standard: Battery voltage

2P CONNECTOR
(Wire side/female terminals)



CKP SENSOR PEAK VOLTAGE

- Check all system connections before inspection. If the system is disconnected, incorrect peak voltage might be measured.
- Check cylinder compression and check that the spark plugs are installed correctly.

Lift and support the fuel tank (page 4-5).

Disconnect the ECM 33P (Gray) connector from the ECM.



Connect the peak voltage tester or peak voltage adaptor probes to the connector terminal of the wire side.

TOOLS:

IgnitionMate peak voltage tester MTP07-0286

(U.S.A. only) or

Peak voltage adaptor 07HGJ-0020100
(Not available in U.S.A.)

with commercially available digital multimeter
(impedance 10 M Ω /DCV minimum)

Test probe 07ZAJ-RDJA110

Connection: B22 (+) – Ground (-)


Crank the engine and read the peak voltage.

PEAK VOLTAGE: 0.7 V minimum

If the peak voltage measured at ECM connector is abnormal, measure the peak voltage at the CKP sensor connector.

33P (GRAY) CONNECTOR
(Wire side/female terminals)

Yellow
(B22)




ELECTRIC STARTER

Check for continuity between positive brushes (terminal bolt side) and rear cover.


There should be no continuity.

Check for continuity between positive and negative brushes.

There should be no continuity.




Remove the screw and negative brushes.




Remove the terminal nut.



Remove the washer, insulator, terminal stopper and O-ring.



SYSTEM LOCATION



LIGHTS/METERS/SWITCHES


Apply oil to the O-ring and install it to the VS sensor.
Install the VS sensor to the crankcase.



Tighten the VS sensor mounting bolt securely and connect the VS sensor 3P (Blue) connector.

California type: Install the EVAP purge control solenoid valve (page 6-84).

Remove the support and close the fuel tank (page 4-7).




TACHOMETER

SYSTEM INSPECTION

- Check for loose or poor contact terminals at the combination meter 20P (Gray) and sub harness 20P (Black) connectors.

Turn the ignition switch ON, check that the tachometer needle moves to full scale and then returns to zero.

If the needle does not show initial function, check the combination meter power input line (page 20-8).




HORN

INSPECTION

Remove the upper cowl (page 3-13).

Connect a 12 V battery to the horn terminal directly. The horn is normal if it sounds when the 12 V battery is connected across the horn terminals.




REMOVAL/INSTALLATION

Remove the upper cowl (page 3-13).

Remove the bolt and horn.

Installation is in the reverse order of removal.

Correctly route the wire (page 1-20).



TURN SIGNAL RELAY

INSPECTION

1. Related Circuit Inspection

Support the upper cowl securely.

Remove the upper cowl (page 3-13) with sub harness 20P (Black) and 8P (Black) connectors connected.


Check the following:

- Burned bulb or non-specified wattage
- Blown fuse (MAIN 30 A, STOP/HORN 10 A)
- Ignition switch (page 20-16) and turn signal switch (page 20-18) function
- Loose connector

Are the above items in good condition?

NO - Replace or repair the failed part(s).

YES - GO TO STEP 2.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL