

Introduction

This service manual describes the service procedures for and technical feature of the VFR400R.

This Model Specific Manual includes every service procedure that is of a specific nature to this particular model. Basic service procedures that are common to other Honda Motorcycles/Motor Scooters/ATVs are covered in the Common Service Manual. This Model Specific Service Manual should be used together with the Common Service Manual in order to provide complete service information on all aspects of this motorcycle.

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Section 1 and 3 apply to the whole motorcycle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections.

While Section 4 through 19 describe parts of the motorcycle, grouped according to locations.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections describe the service procedure through system illustration. Refer to the next page for details on how to use this manual.

If you are not familiar with this motorcycle, read Technical Feature in section 20.

If you don't know the source of the trouble, go to section 21 TROUBLESHOOTING.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

HONDA MOTOR CO., LTD.
SERVICE PUBLICATION OFFICE

Contents

	General Information	1
	Frame/Body Panels/Exhaust System	2
	Maintenance	3
Engine and Drive Train	Lubrication System	4
	Cooling System	5
	Fuel System	6
	Engine Removal/Installation	7
	Cylinder Head/Valves	8
	Clutch	9
	Gearshift Linkage	10
	Crankshaft/Piston/Transmission	11
Chassis	Front Wheel/Suspension/Steering	12
	Rear Wheel/Suspension	13
	Brake System	14
Electrical	Charging System/Alternator	15
	Ignition System	16
	Electric Starter/Starter Clutch	17
	Lights/Meters/Switches	18
	Wiring Diagram	19
	Technical Feature	20
	Troubleshooting	21
	Index	22

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Unit: mm (in)


Cylinder Head Item	Standard	Service Limit
Cylinder compression	1,274 ± 196 kPa (13.0 ± 2.0 kg/cm ² , 185 ± 28 psi)/400 min ⁻¹ (rpm)	—
Cylinder compression difference	40 mmHg (1.6 inHg)	—
Valve clearance IN EX	0.12–0.18 (0.005–0.007) 0.21–0.27 (0.008–0.011)	— —
Cylinder head warpage	—	0.10 (0.004)
Com lobe height ① IN EX	32.717–32.957 (1.2882–1.2975) 32.428–32.668 (1.2767–1.2861)	32.67 (1.286) 32.38 (1.275)
Camshaft runout	—	0.03 (0.001)
Camshaft oil clearance A B	0.040–0.082 (0.0016–0.0032) —	0.092 (0.0036) —
		
Camshaft journal O.D. A B	27.939–27.960 (1.1000–1.1008) —	27.93 (1.010) —
Camshaft holder I.D. A B	28.000–28.021 (1.1024–1.1032) —	28.03 (1.104) —
Valve stem O.D. IN	4.475–4.490 (0.1762–0.1788)	4.47 (0.176)
EX	4.465–4.480 (0.1758–0.1764)	0.46 (0.1756)
Valve guide I.D. IN	4.500–4.512 (0.1772–0.1776)	4.56 (0.180)
EX	4.500–4.512 (0.1772–0.1776)	4.56 (0.180)
Stem-to-guide clearance IN	0.010–0.037 (0.0004–0.0015)	0.09 (0.004)
EX	0.020–0.047 (0.0008–0.0019)	0.12 (0.005)
Valve guide projection above cylinder head IN (h)	10 (0.4)	—
EX (h)	10 (0.4)	—
 <p data-bbox="271 1179 670 1354"> Before guide installation: 1. Chill the valve guide in the freezer section of a refrigerator for about an hour. 2. Heat the cylinder head to 100–150°C (212–300°F) </p>		
Valve seat width IN	1.70–2.30 (0.067–0.091)	—
EX	1.70–2.30 (0.067–0.091)	—
Valve spring free length IN	—	—
EX	—	—
Inner IN	31.4 (1.24)	30.2 (1.19)
Inner EX	31.4 (1.24)	30.2 (1.19)
Outer IN	34.4 (1.35)	33.2 (1.31)
Outer EX	34.4 (1.35)	33.2 (1.31)
Rocker arm I.D. IN	8.500–8.515 (0.3346–0.3352)	8.53 (0.336)
EX	8.500–8.515 (0.3346–0.3352)	8.53 (0.336)
Rocker arm shaft O.D. IN	8.466–8.484 (0.3333–0.3340)	8.46 (0.333)
EX	8.466–8.484 (0.3333–0.3340)	8.46 (0.333)
Rocker arm-to-rocker arm shaft clearance	—	—
Valve lifter O.D.	—	—
Valve lifter bore I.D.	—	—
Hydraulic tappet adjuster assist spring free length	—	—
Hydraulic tappet adjuster compression stroke with kerosene	—	—

Tools

- The newly designed tools are indicated with * mark in the list.

Description	Tool Number	Application	Section
Compression gauge attachment, 8 mm Oil pressure gauge attachment Oil filter wrench Spark plug wrench, 8 mm	*07KME-MR80100 07510-4220100 07HAA-PJ70100 *07KMA-MR80200	Cylinder compression measurement Engine oil pressure measurement Oil filter replacement Spark plug removal/installation	3
Lock nut wrench	07HMA-MR70200	Engine removal/installation	7
Valve spring compressor attachment Valve guide driver Valve guide reamer, 4.5 mm Valve seat cutter, 24 mm (45° IN) Valve seat cutter, 22 mm (45° EX) Valve flat cutter, 21.5 mm (32° IN) Valve flat cutter, 21.5 mm (32° EX) Valve interior cutter, 22 mm (60° IN/EX) Cutter holder, 4.5 mm	07959-KM30101 07HMD-ML00100 07HMH-ML00101 07780-0010600 07780-0010701 07780-0012500 07780-0012800 07780-0014202 07781-0010600	Cylinder head disassembly/assembly Valve guide replacement Valve guide reaming Valve seat refacing	8
Lock nut wrench, 26 × 30 mm Extension bar Gear holder	07716-0020203 07716-0020500 07724-0010100	Clutch disassembly/assembly Primary drive gear removal/installation	9
Fork seal driver Fork seal driver attachment Lock nut wrench, 39 × 41 mm Steering stem socket Steering stem driver attachment Inner driver C Driver attachment B (2 pcs. required) Driver assembly shaft Bearing remover B Assembly base	07947-KA50100 07947-KF00100 07GMA-KS40100 07HMA-MR70100 07HMD-MR70100 07746-0030100 07946-KM90200 07946-KM90300 07946-KM90500 07946-KM90600	Fork oil seal installation Steering stem nut removal/installation Steering bearing adjustment nut tightening Steering bearing lower inner race installation Steering bearing outer race removal/installation	12
Driver Attachment, 42 × 47 mm Attachment, 62 × 68 mm Pilot, 40 mm Shock absorber compressor attachment Shock absorber compressor Bushing driver B Pivot adjust wrench Driver shaft Attachment, 37 × 40 mm Pilot, 20 mm Bearing remover set - Remover handle - Bearing remover - Sliding weight Needle bearing remover Driver shaft Pilot, 28 mm	07749-0010000 07746-0010300 07746-0010500 07746-0040900 07959-MB10000 07GME-0010000 07HMF-MM90200 07908-4690001 07946-MJ00100 07746-0010200 07746-0040500 07936-3710001 07936-3710100 07936-3710600 07741-0010201 07HMC-MR70100 07946-MJ00100 07746-0041100	Bearing installation Bearing holder needle bearing replacement Shock absorber disassembly/assembly Shock absorber upper mounting bushing replacement Swingarm pivot bolt removal/installation Right swingarm pivot bearing installation Right swingarm pivot bearing removal Left swingarm pivot bearing replacement	13

Side Fairing Removal/Installation



CAUTION

- Be careful not to damage the tabs.
- Make sure that the clip nut for the tapping screw is installed properly. If it is missing, install it securely with the threaded side facing down.

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Quick screw	4	
(2)	Screw	2	
(3)	Tapping screw	2	
(4)	Left side fairing	1	
(5)	Right side fairing	1	

CAUTION

- Turn the ignition switch OFF and disconnect the battery negative cable from the battery terminal.
- Be careful not to bind the wire harness when installing the sub-frame.
- Route the wire harness, cable, etc. (page 1-21).

Requisite Service

- Seat cowling removal/installation (page 2-2)
- Fuel tank removal/installation (page 2-5)
- Battery removal/installation (page 15-4)

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Spark plug cap/primary wire connector	2/2	
(2)	Regulator/rectifier connector	1	
(3)	Turn signal relay connector	1	
(4)	Spark unit wire connector	2	
(5)	Rear turn signal wire connector	4	
(6)	License light wire connector	2	
(7)	Fuse box	1	
(8)	Right grab rail	1	
(9)	Shock absorber reservoir/bracket	1	
(10)	Rear brake reservoir	1	CAUTION Keep the reservoir level to prevent air from entering the system.
(11)	Radiator reserve tank	1	
(12)	Muffler mounting bolt/nut	1/2	
(13)	Sub-frame mounting bolt	4	NOTE Remove the main wire harness from the clamp.
(14)	Rear fender bolt	1	


Maintenance

Carefully slide the rocker arm back to the original position. Make sure that the shim contacting surface of the rocker arm is positioned in the center of the shim and the shim is completely seated.


CAUTION

- Be careful not to bound the shim out when sliding the rocker arm.

Turn the crankshaft clockwise several times. Recheck the valve clearance.



Apply Honda bond A or equivalent to the gasket groove in the cylinder head cover. Install the cover gasket with the "IN" mark facing toward the intake side.




Install the cylinder head cover with the "IN" mark facing toward the intake side.

Install the cover bolt washers with the "UP" mark facing up. Install the cover bolts and tighten them.

Torque: 10 N·m (1.0 kg-m, 7 ft-lb)

Install the removed parts in the reverse order of removal.




Carburetor Synchronization

NOTE

- Refer to section 2 of Common Service Manual for carburetor synchronization procedure.
- Synchronize the carburetor with the engine at normal operating temperature, transmission in neutral and motorcycle supported upright.

Disconnect the vacuum tube from the No. 3 cylinder intake manifold, apply vacuum to the auto fuel valve and pinch the tube with a clip.

Remove the plugs from the No. 1, 2 and 4 cylinder intake manifold and install the vacuum gauge adaptors.



5. Cooling System

Service Information	5-1	Water Pump Disassembly/Assembly	5-5
Troubleshooting	5-1	Radiator Removal/Installation	5-6
System Flow Pattern	5-2	Radiator Disassembly/Assembly	5-8
Coolant Draining	5-3		
Thermostat Removal/Installation	5-4		

Service Information

▲ WARNING

- Wait until the engine is cool before slowly removing the radiator cap. Removing the cap while the engine is hot and the coolant is under pressure may cause serious scalding.
- Radiator coolant is toxic. Keep it away from eyes, mouth, skin and clothes.
 - If any coolant gets in your eyes, rinse them with water and consult a doctor immediately.
 - If any coolant is swallowed, induce vomiting, gargle and consult a physician immediately.
 - If any coolant gets on your skin or clothes, rinse thoroughly with plenty of water.
- KEEP OUT OF REACH OF CHILDREN.

- Add coolant at the reserve tank. Do not remove the radiator cap except to refill or drain the system.
- All cooling system service can be made with the engine in the frame.
- Avoid spilling coolant on painted surfaces.
- After servicing the system, check for leaks with a cooling system tester.
- Refer to section 18 for fan motor switch and thermo sensor inspections.

Troubleshooting

Engine Temperature Too High

- Faulty radiator cap.
- Insufficient coolant.
- Passages blocked in radiator, hoses, or water jacket.
- Air in system.
- Faulty water pump.
- Thermostat stuck closed.
- Faulty temperature gauge or thermo sensor.
- Faulty cooling fan motor.
- Faulty fan motor switch.
- Fan shroud installed improperly.

Engine Temperature Too Low

- Faulty temperature gauge or gauge sensor.
- Thermostat stuck open.
- Faulty cooling fan motor switch (see section 18).

Coolant Leaks

- Faulty pump mechanical seal.
- Deteriorated O-rings.
- Faulty radiator cap.
- Damaged or deteriorated gasket.
- Loose hose connection or clamp.
- Damaged or deteriorated hoses.

Troubleshooting

Engine Won't Start

- No fuel to carburetors
 - fuel strainer clogged
 - fuel tube clogged
 - faulty fuel valve
 - float level misadjusted
 - fuel tank cap breather hole clogged
- Too much fuel getting to the engine
 - air cleaner clogged
 - flooded carburetors
- Intake air leak
- Fuel contaminated/deteriorated
- Slow circuit or bystarter circuit clogged
- Ignition malfunction

Engine Stalls, Hard to Start, Rough Idling

- Fuel line restricted
- Ignition malfunction
- Fuel mixture too lean/rich
- Fuel contaminated/deteriorated
- Intake air leak
- Idle speed misadjusted
- Pilot screw misadjusted
- Slow circuit or bystarter circuit clogged
- Float level misadjusted
- Fuel tank breather tube clogged

Afterburn on Deceleration

- Lean mixture in slow circuit

Backfiring or Misfiring During Acceleration

- Ignition system faulty
- Fuel mixture too lean

Poor Performance (driveability) and Poor Fuel Economy

- Fuel system clogged
- Ignition malfunction

Lean Mixture

- Fuel jets clogged
- Float valve faulty
- Float level too low
- Fuel line restricted
- Carburetor air vent hole (or tube) clogged
- Intake air leak
- Vacuum piston faulty
- Throttle valve faulty


Rich Mixture

- Bystarter valve in ON position
- Float valve faulty
- Float level too high
- Air jets clogged
- Air cleaner element contaminated
- Flooded carburetors


Carburetor Combination



: O-RING, COTTER PIN




- (A) THRUST WASHER
- (B) PLASTIC SPRING WASHER
- (C) PLASTIC THRUST WASHER
- (D) COTTER PIN



Tighten the mounting bolt and the adjusting bolt by using a hex wrench.

TORQUE: 11 N·m (1.1 kg-m, 8 ft-lb)



Install the lock nut. Hold the mounting bolt and tighten the lock nut by using the lock nut wrench.

TORQUE: 55 N·m (5.5 kg-m, 40 ft-lb)


5 TOOL

LOCK NUT WRENCH

07HMA-MR70200

Tighten the mounting nut on the other side.

TORQUE: 40 N·m (4.0 kg-m, 29 ft-lb)



Cam Gear Case Installation

NOTE

- The cam gear case is marked with F or R on the flange. Install the gear case marked F on the front cylinder and the case marked R on the rear cylinder.
- When the identification mark is not clear, the gear case can be identified by the sub gear of the second gear. With the sub gear toward you:
 - for front cylinder: the sub gear is off to the left side from the main gear.
 - for rear cylinder: the sub gear is off to the right side from the main gear.

Push the gear case dowel pins fully into the cylinder head.

NOTE

- The second gear and the crankshaft timing gear do not engage properly when the dowel pins are not pushed into the full.

Check the I.D. mark on the gear case and install the case on the designate cylinder head.

Check for the proper engagement of the timing gear and the seconds gear in the following procedures.

Lightly move the third gear back and forth with the gear case lightly pushed down. The engagement is correct if the flange of the gear case is pushed by the timing gear and raised off the cylinder head slightly.

Remove the gear case and reinstall it if necessary.

Tighten the four gear case mounting bolts fully with your fingers.

Install and loosely tighten the gear case set bolt and the copper washer.

NOTE

- When tightening the set bolt, take care not to damage the gear case threads and the bolt threads.





Tighten the gear case mounting bolts of the dowel pin side to the specified torque.

TORQUE: 36 N·m (3.6 kg-m, 26 ft-lb)

Then tighten the remaining mounting bolts.

Tighten the gear case set bolt.

TORQUE: 12 N·m (1.2 kg-m, 9 ft-lb)



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

NOTE

- To loosen the clutch center lock nut, straighten the locking tabs with care not to damage them, then; Move the shift lever to the 6th speed and operate the rear brake.
When the engine is dismounted from the frame, move the shift lever to the 6th speed and hold the drive sprocket with a universal holder or equivalent.
- Loosen the oil pump driven sprocket bolt with the clutch assembly installed before removing the bolt. Note that the bolt threads are coated with the thread locking agent.
- Note the connection and installation direction of the lifter rod once it is removed. Special alignment is required at the left lifter cam connecting section (page 10-2).

Requisite Service

- Right crankcase cover removal/installation (page 9-2).
- Starter clutch removal (page 17-2).

Procedure	Q'ty	Remarks
Removal Order		
(1) Snap ring	1	NOTE • When removing the oil pump driven sprocket bolt, loosen it first with the clutch outer installed.
(2) Clutch lifter plate	1	NOTE • Remove the bearing only on replacement.
(3) Lifter guide	1	NOTE • Remove the stopper ring only on replacement.
(4) Lifter rod	1	NOTE • Do not depress the clutch lever with the rod removed.
(5) Clutch center lock nut	1	NOTE • Straighten the locking tabs first (page 9-3)
(6) Lock washer	1	
(7) Clutch spring set plate	1	
(8) Diaphragm spring	3	NOTE • Replace the three springs as a set.
(9) Pressure plate	1	NOTE • Remove the stopper ring only on replacement.
(10) Thrust washer	1	
(11) Clutch disc	10	NOTE • Disc contact surface of the two end plates is black.
(12) Clutch plate	9	
(13) Clutch center B	1	
(14) One-way clutch assembly	1	NOTE • Do not disassemble unnecessarily.
(15) Thrust washer	1	
(16) Clutch center A	1	
(17) Clutch outer	1	
(18) Oil pump driven sprocket bolt	1	
(19) Oil pump driven sprocket	1	
(20) Oil pump drive chain/sprocket	1/1	NOTE • Remove the oil pump drive chain and sprocket together.
(21) Clutch outer guide	1	

NOTE

- When installing the water pump, check the water pump shaft and oil pump shaft connection.

Requisite Service

- Oil pan installation (page 4-4).
- Drive sprocket cover installation (page 10-2).
- Water pump installation (page 5-5).
- Clutch installation (page 9-6).
- Lower fairing installation (page 2-4).

Procedure	Q'ty	Remarks
Removal Order		
(1) Shift drum/bearing	1/1	
(2) Shift fork	3	NOTE • Install the left shift fork on the C6 gear, center shift fork on the M3/M4 gear, and the right shift fork on the C5 gear respectively with the marks facing right (page 11-4).
(3) Shift fork shaft	1	NOTE • Apply engine oil and push in from the right side.
(4) Stopper washer/bolt	1/1	
(5) Gearshift Linkage Shift drum pin	1	NOTE • Install the shift drum pin on the shift drum.
(6) Shift drum center	1	CAUTION • Install by aligning the shift drum pin with the longhole in the drum center.
(7) Shift drum center bolt	1	
(8) Doel pin	2	
(9) Shift drum set plate	1	
(10) Spacer collar	1	
(11) Stopper arm assembly/spring	1/1	NOTE • Loosely tighten the two set bolts and install the roller on the drum center with the spring hook set on the arm and the reverse side set on the crankcase. Remove the set bolts.
(12) Thrust washer	1	
(13) Guide plate/drum shifter assembly	1/1	NOTE • Assemble the shifter body, plunger, spring, and reatched pawl with the shifter plate. Pushing the pawl with your fingers, install the assembled plate on the shift drum center.
(14) Bolt	2	
(15) Shift collar	1	
(16) Thrust washer	1	
(17) Gearshift spindle/spring	1/1	NOTE • Install by aligning the long hole with the shifter collar and the two return springs with the stud pins on the case.
(18) Gasket	1	
(19) Dowel pin	1	
(20) Gearshift linkage cover	1	NOTE • Install with care not to damage the dust seal.
(21) Gearshift linkage cover bolt	5	
(22) Gearshift spindle joint/gearshift spindle joint bolt	1	NOTE • Align the punch mark with the one on the shift arm and install on the spindle.


Bearing Selection

Main Bearing

Record the crankcase I.D. code.

NOTE


- A or B stamped on the No.4 journal of the upper crankcase is the I.D. code of the journal. The code letters, from left to right, indicate each journal I.D. respectively. (Refer to the drawing to the right.)



Record the crankshaft main journal O.D. code (or measure the main journal O.D.).

NOTE

- 1 or 2 stamped on the crank weight is the main journal O.D. code. (Refer to the drawing to the right.)




Determine the bearing I.D. code by referring to the case I.D. code and the main journal code.

		Main journal O.D. code	
		1	2
		29.994–30.002mm (1.1809–1.1812in)	30.002–30.010mm (1.1812–1.1815in)
Case I.D. code	A	33.000–33.008mm (1.2992–1.2995in)	C (Yellow)
	B	33.008–33.016mm (1.2995–1.2998in)	B (Green)
			A (Brown)

- A (Brown): 1.498–1.502 mm (0.0590–0.0591 in)
- B (Green): 1.494–1.498 mm (0.0588–0.0590 in)
- C (Yellow): 1.490–1.494 mm (0.0587–0.0588 in)

Thickness of the bearing metal can be identified by the color code.




Connecting Rod Bearing

Record the connecting rod I.D. code number.

NOTE

- 1 or 2 stamped on the connecting rod is the connecting rod I.D. code number. (Refer to the drawing to the right.)



▲ WARNING

- A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.
- Inhaled asbestos fibers have been found to cause respiratory disease and cancer. Never use an air hose or dry brush to clean brake assemblies.

NOTE

- Install the front wheel with the arrow mark (stamped on the right side) facing to the normal rotating direction.
- Do not depress the brake lever when the caliper is removed, or it will be difficult to refit the disc between the brake pads.

Requisite Service

- Raise the wheel off the ground by placing a jack or other support under the engine.

Procedure		Q'ty	Remarks
Removal Order			
(1)	Caliper mounting bolt	4	CAUTION • Do not hang the caliper by the brake hose. Loosen the bolts. Loosen the bolts. Disassembly/assembly (page 12-8)
(2)	Front caliper assembly	2	
(3)	Right axle pinch bolt	2	
(4)	Axle bolt	1	
(5)	Left axle pinch bolt	2	
(6)	Axle shaft	1	
(7)	Front wheel assembly	1	
(8)	Side collar	2	
Installation Order			
(8)	Side collar	2	NOTE • Right side collar is longer than the left side collar. • Apply grease to the dust seal lips before installing.
(7)	Front wheel assembly	1	
(6)	Axle shaft	1	NOTE • Apply thin coat of grease.
(4)	Axle bolt	1	
(5)	Left axle pinch bolt	2	NOTE • Tighten after tightening the axle bolt.
(3)	Right axle pinch bolt	2	
(2)	Front caliper assembly	2	CAUTION • Be careful not to damage the pads.
(1)	Caliper mounting bolt	4	

NOTE

- Check the steering bearing preload after installing.

Requisite Service

- Fork installation (page 12-10)
- Front wheel installation (page 12-6)

Procedure		Q'ty	Remarks
Installation Order			
(1)	Upper bearing outer race	1	Use the driver attachment B (07946-KM90200), driver assembly shaft (07946-KM90300), bearing remover B (07946-KM90500) and base (07946-KM90600).
(2)	Lower bearing outer race	1	
(3)	Lower dust seal	1	Use the stem driver attachment (07HMD-MR70100) and inner driver C (07746-0030100).
(4)	Lower bearing inner race	1	
(5)	Lower bearing	1	Use the steering stem socket (07HMD-MR70100). Bend down the two tabs into the adjustment nut grooves. Hand tighten, align the grooves with the lock washer tabs and bend up the tabs into the grooves.
(6)	Steering stem	1	
(7)	Upper bearing	1	
(8)	Upper bearing inner race	1	
(9)	Upper dust seal	1	
(10)	Steering bearing adjustment nut	1	
(11)	Lock washer	1	
(12)	Lock nut	1	
(13)	Top bridge	1	
(14)	Steering stem nut	1	
(15)	Steering stem nut cap	1	Connect the horn wires.
(16)	Horn	1	
(17)	Brake hose clamp	1	

Rear Wheel/Suspension

Rear Suspension Bolt Removal


Raise the rear wheel off the ground and support the motorcycle securely.

Remove the seat cowling.


Remove the shock link-to frame bolt.

NOTE

- Loosen the nut first then remove the bolt for easy removal.




Remove the shock absorber upper mounting bolt while supporting the rear wheel by hand.




Loosen the shock absorber lower mounting nut. Raise the wheel further by hand and remove the shock absorber lower mounting bolt.

NOTE

- Be careful not to damage the exhaust pipe while servicing.



Remove the screw and the lower portion of the drive chain slider from the swingarm. Remove the shock arm-to-swingarm bolt.




Pivot Bearing Replacement

Removal


Remove the snap ring.
Remove the ball bearing from the right swingarm pivot.

S TOOL
Bearing remover set 07936-3710001



Drive the needle bearing out of the left swingarm pivot.


S TOOL
Needle bearing remover 07HMC-MR70100
Driver shaft 07946-MJ00100



Installation

Apply molybdenum disulfide grease to a new needle bearing. Carefully press the needle bearing into the left swingarm pivot 4 mm (0.16 in) from the edge of the swingarm, measuring with the vernier caliper.


S TOOL
Driver 07749-0010000
Attachment, 37 x 40 mm 07746-0010200
Pilot, 28 mm 07746-0041100



Drive ball bearings into the right swingarm pivot one by one with the marked side facing out until they bottom.

S TOOL
Driver 07749-0010000
Attachment, 37 x 40 mm 07746-0010200
Pilot, 20 mm 07746-0040500


Install the snap ring




Rear Brake Caliper Disassembly/Assembly



: O-ring, seal and sealing washer



Alternator Removal/Installation



NOTE



• The engine oil will spill out when the left crankcase cover is removed. Place a clean oil pan under the engine to catch the oil and add the recommended oil to the specified level after installing the cover.

Requisite Service

- Lower fairing removal/installation (page 2-4)


Procedure	Q'ty	Remarks
Removal Order		Installation is in the reverse order of removal.
(1) Alternator wire connector	1	Disconnect the connector.
(2) Left crankcase cover bolt	6	
(3) Left crankcase cover	1	
(4) Wire clamp/bolt	1/1	
(5) Flywheel bolt/washer	1/1	Hold the flywheel with the universal holder (07725-0030000) and remove the bolt. Use the rotor puller (07733-0020001).
(6) Flywheel	1	
(7) Stator mounting bolt	4	
(8) Stator	1	

System Location



If the fan motor does not start:


1. Disconnect the fan motor switch connector from the switch and ground it with a jumper wire.
2. Turn the ignition switch ON, and check the fan motor.
 - If the motor turns, the fan motor switch is faulty or switch connector is loose or poorly connected.
 - If the motor does not turn, check for voltage between the connector and ground.
 - If the battery voltage exists, the fan motor is faulty.
 - If no voltage, the wire harness has an open circuit.



When installing a new fan motor switch, apply sealant to the threads and tighten it to the specified torque.

Torque: 18 N·m (1.8 kg-m, 13 ft-lb)


Connect the fanmotor switch connector.
Install the lower fairing (page 2-4).



Coolant Temperature Gauge Inspection

Remove the lower fairing (page 2-4) and the fuel tank (page 2-5).

Disconnect the thermosensor wire connector from the sensor and ground it with a jumper wire.



Turn the ignition switch ON and check the coolant temperature gauge. Disconnect the thermosensor wire from the ground immediately when the gauge needle moves fully to H.


CAUTION

- Do not ground the thermosensor wire longer than 5 seconds to prevent damage to the gauge.

If the needle does not move to H, check the wire harness between the switch and gauge.

If the wire harness is normal, replace the coolant temperature gauge.

Install the removed parts in the reverse order of removal.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL