

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications(R450LC-7A)	1-9
Group 2 Specifications(R500LC-7A)	1-29

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-22
Group 3 Swing Device	2-47
Group 4 Travel Device	2-58
Group 5 RCV Lever	2-65
Group 6 RCV Pedal	2-72

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit	3-1
Group 2 Main Circuit	3-2
Group 3 Pilot Circuit	3-5
Group 4 Single Operation	3-13
Group 5 Combined Operation	3-23

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location	4-1
Group 2 Electrical Circuit	4-3
Group 3 Electrical Component Specification	4-20
Group 4 Connectors	4-28

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline	5-1
Group 2 Mode Selection System	5-3
Group 3 Automatic Deceleration System	5-6
Group 4 Power Boost System	5-7
Group 5 Travel Speed Control System	5-8
Group 6 Automatic Warming Up Function	5-9
Group 7 Engine Overheat Prevention Function	5-10
Group 8 Anti-Restart System	5-11

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


SECTION 1 GENERAL



Group 1 Safety Hints	1-1
Group 2 Specifications	1-9

2. SPECIFICATIONS

1) ROBEX 450LC-7A










4507A2SP02

Description		Unit	Specification
Operating weight		kg(lb)	45200(99650)
Bucket capacity(SAE heaped), standard		m ³ (yd ³)	2.15(2.81)
Overall length	A	mm(ft-in)	12000(39' 4")
Overall width, with 600mm shoe	B		3340(10'11")
Overall height	C		3600(11'10")
Superstructure width	D		2980(9' 9")
Overall height of cab	E		3250(10' 8")
Ground clearance of counterweight	F		1340(4' 5")
Engine cover height	G		2792(9' 2")
Minimum ground clearance	H		555(1'10")
Rear-end distance	I		3665(12' 0")
Rear-end swing radius	I'		3720(12' 2")
Distance between tumbler	J		4470(14' 8")
Undercarriage length	K		5462(17'11")
Undercarriage width	L		3340(10'11")
Track gauge	M		2740(8'12")
Track shoe width, standard	N		600(24")
Travel speed(Low/high)			km/hr(mph)
Swing speed		rpm	9.0
Gradeability		Degree(%)	35(70)
Ground pressure(600mm shoe)		kgf/cm ² (psi)	0.78(11.09)


6. BUCKET SELECTION GUIDE


1) GENERAL BUCKET


						
1.38m ³ SAE heaped bucket	1.65m ³ SAE heaped bucket	1.84m ³ SAE heaped bucket	※ 2.15m ³ SAE heaped bucket	2.56m ³ SAE heaped bucket	2.79m ³ SAE heaped bucket	3.03m ³ SAE heaped bucket

Capacity		Width		Weight	Recommendation							
SAE heaped	CECE heaped	Without side cutter	With side cutter		7.06m (23' 2") boom					6.55m(21' 5") boom	9.00m(29' 6") boom	
					2.4m arm (7' 10")	2.9m arm (9' 6")	3.38m arm (11' 1")	4.0m arm (13' 1")	4.5m arm (14' 9")	2.4m arm (7' 10")	5.85m arm (19' 2")	
1.38m ³ (1.80yd ³)	1.20m ³ (1.57yd ³)	1100mm (43.3")	1250mm (49.2")	1360kg (3000lb)								
1.65m ³ (2.16yd ³)	1.44m ³ (1.88yd ³)	1350mm (53.1")	1500mm (59.1")	1550kg (3420lb)								
1.84m ³ (2.41yd ³)	1.60m ³ (2.09yd ³)	1420mm (55.9")	1570mm (61.8")	1590kg (3510lb)								
※ 2.15m ³ (2.81yd ³)	1.85m ³ (2.40yd ³)	1610mm (63.4")	1760mm (69.3")	1740kg (3840lb)								
2.56m ³ (3.35yd ³)	2.20m ³ (2.90yd ³)	1870mm (73.6")	2020mm (79.5")	1970kg (4340lb)								
2.79m ³ (3.65yd ³)	2.40m ³ (3.14yd ³)	2020mm (79.5")	2170mm (85.4")	2100kg (4630lb)								
3.03m ³ (3.96yd ³)	2.60m ³ (3.40yd ³)	2170mm (85.4")	2320mm (91.3")	2140kg (4720lb)								

※ : Standard bucket


 Applicable for materials with density of 2000kgf/m³ (3370lbf/yd³) or less

 Applicable for materials with density of 1600kgf/m³ (2700lbf/yd³) or less

 Applicable for materials with density of 1100kgf/m³ (1850lbf/yd³) or less

2. SPECIFICATIONS















· 7.06m(23' 2") BOOM, 3.38m(11' 1") ARM

















5007A2SP02

Description		Unit	Specification
Operating weight		kg(lb)	48800(107580)
Bucket capacity(SAE heaped), standard		m ³ (yd ³)	2.15(2.81)
Overall length	A	mm(ft-in)	12030(39' 6")
Overall width, with 600mm shoe (Transport position/Working position)	B		2990/3540(9'10"/11'7")
Overall height	C		3850(12' 8")
Superstructure width	D		2980(9' 9")
Overall height of cab	E		3390(11' 2")
Ground clearance of counterweight	F		1500(4'11")
Engine cover height	G		3015(9'11")
Minimum ground clearance	H		770(2' 6")
Rear-end distance	I		3665(12' 0")
Rear-end swing radius	I'		3720(12' 2")
Distance between tumbler	J		4470(14' 8")
Undercarriage length	K		5460(17'11")
Undercarriage width (Transport position/Working position)	L		2980/3540(9' 9"/11' 7")
Track gauge (Transport position/Working position)	M		2380/2940(7'10"/ 9' 8")
Track shoe width, standard	N		600(24")
Travel speed(Low/high)			km/hr(mph)
Swing speed		rpm	9.0
Gradeability		Degree(%)	35(70)
Ground pressure(600mm shoe)		kgf/cm ² (psi)	0.84(11.94)

6) 7.06m(23' 2") boom, 4.50m(14' 9") arm equipped with 2.15m³(SAE heaped) bucket, 600mm (24") triple grouser shoe and 10,200kg(22,490lb) counterweight.

Load point height		Load radius												At max. reach		
		3.0m(10.0ft)		4.5m(15.0ft)		6.0m(20.0ft)		7.5m(25.0ft)		9.0m(30.0ft)		10.5m(35.0ft)		Capacity		Reach
																kg
7.5m (25.0ft)	kg lb									*6730 *14840	*6730 *14840			*6590 *14530	4990 11000	11.18 (36.7)
6.0m (20.0ft)	kg lb									*7500 *16530	*7500 *16530	*4930 *10870	*4930 *10870	*6620 *14590	4370 9630	11.76 (38.6)
4.5m (15.0ft)	kg lb							*9110 *20080	*9110 *20080	*8110 *17880	7320 16140	*6660 *14680	5390 11880	*6690 *14750	3990 8800	12.11 (39.7)
3.0m (10.0ft)	kg lb			*17640 *38890	*17640 *38890	*12870 *28370	*12870 *28370	*10360 *22840	9600 21160	*8840 *19490	6980 15390	*7820 *17240	5200 11460	6490 14310	3790 8360	12.25 (40.2)
1.5m (5.0ft)	kg lb			*21200 *46740	20380 44930	*14860 *32760	12910 28460	*11540 *25440	9040 19930	*9530 *21010	6640 14640	*8180 *18030	5000 11020	6450 14220	3740 8250	12.18 (40.0)
Ground Line	kg lb	*14310 *31550	*14310 *31550	*22980 *50660	19250 42440	*16190 *35690	12200 26900	*12400 *27340	8580 18920	*10040 *22130	6360 14020	8190 18060	4840 10670	6640 14640	3840 8470	11.91 (39.1)
-1.5m (-5.0ft)	kg lb	*17750 *39130	*17750 *39130	*23160 *51060	18780 41400	*16670 *36750	11780 25970	*12770 *28150	8290 18280	*10210 *22510	6170 13600	*7850 *17310	4740 10450	7110 15670	4140 9130	11.41 (37.4)
-3.0m (-10.0ft)	kg lb	*22170 *48880	*22170 *48880	*22090 *48700	18710 41250	*16250 *35830	11640 25660	*12510 *27580	8160 17990	*9840 *21690	6100 13450			*7120 *15700	4710 10380	10.65 (34.9)
-4.5m (-15.0ft)	kg lb	*27780 *61240	*27780 *61240	*19780 *43610	18920 41710	*14820 *32670	11710 25820	*11360 *25040	8210 18100	*8500 *18740	6190 13650			*6890 *15190	5790 12760	9.56 (31.4)
-6.0m (-20.0ft)	kg lb	*21610 *47640	*21610 *47640	*15870 *34990	*15870 *34990	*11960 *26370	*11960 *26370	*8670 *19110	8500 18740					*6000 *13230	*6000 *13230	7.98 (26.2)

7) 9.00m(29' 6") boom, 5.85m(19' 2") arm equipped with 1.65m³(SAE heaped) bucket, 600mm (24") triple grouser shoe and 10,700kg(23,590lb) counterweight.

Load point height		Load radius												At max. reach		
		3.0m(10.0ft)		5.0m(15.0ft)		7.0m(25.0ft)		9.0m(30.0ft)		11.0m(35.0ft)		13.0m(45.0ft)		Capacity		Reach
																kg
10.0m (35.0ft)	kg lb													*4350 *9590	3530 7780	13.66 (44.8)
8.0m (25.0ft)	kg lb									*4910 *10820	*4910 *10820	*2810 *6190	*2810 *6190	*4290 *9460	2860 6310	14.63 (48.0)
6.0m (20.0ft)	kg lb									*5320 *11730	*5320 *11730	*4370 *9630	3650 8050	*4290 *9460	2450 5400	15.25 (50.0)
4.0m (15.0ft)	kg lb					*9040 *19930	*9040 *19930	*7050 *15540	*7050 *15540	*5880 *12960	4990 11000	*5110 *11270	3450 7610	4200 9260	2200 4850	15.57 (51.1)
2.0m (-5.0ft)	kg lb			*16870 *37190	16620 36640	*10900 *24030	9970 21980	*8070 *17790	6630 14620	*6460 *14240	4600 10140	*5410 *11930	3230 7120	4080 8990	2100 4630	15.60 (51.2)
Ground Line	kg lb			*17270 *38070	15020 33110	*12210 *26920	9020 19890	*8880 *19580	6060 13360	*6930 *15280	4250 9370	5550 12240	3030 6680	4140 9130	2110 4650	15.35 (50.4)
-2.0m (-5.0ft)	kg lb	*11700 *25790	*11700 *25790	*18210 *40150	14440 31830	*12720 *28040	8480 18700	*9290 *20480	5680 12520	*7160 *15790	4010 8840	5400 11900	2890 6370	4390 9680	2270 5000	14.80 (48.6)
-4.0m (-15.0ft)	kg lb	*15000 *33070	*15000 *33070	*17860 *39370	14390 31720	*12450 *27450	8290 18280	*9180 *20240	5500 12130	*7000 *15430	3890 8580	*4190 *9240	2870 6330	*4530 *9990	2620 5780	13.91 (45.6)
-6.0m (-20.0ft)	kg lb	*18860 *41580	*18860 *41580	*15810 *34860	14660 32320	*11330 *24980	8360 18430	*8400 *18520	5530 12190	*6190 *13650	3940 8690			*4380 *9660	3290 7250	12.61 (41.4)
-8.0m (-25.0ft)	kg lb	*17900 *39460	*17900 *39460	*12440 *27430	*12440 *27430	*9090 *20040	8680 19140	*6540 *14420	5780 12740					*3820 *8420	*3820 *8420	10.72 (35.2)

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device	2-1
Group 2 Main Control Valve	2-22
Group 3 Swing Device	2-47
Group 4 Travel Deviceb	2-58
Group 5 RCV Lever	2-65
Group 6 RCV Pedal	2-72

2) REGULATOR


Regulator consists of the negative flow control, total horse power control and power shift control function.

(1) Negative flow control

By changing the pilot pressure P_i , the pump tilting angle (delivery flow) is regulated arbitrarily, as shown in the figure.

This regulator is of the negative flow control in which the delivery flow Q decreases as the pilot pressure P_i rises.

With this mechanism, when the pilot pressure corresponding to the flow required for the work is commanded, the pump discharges the required flow only, and so it does not consume the power uselessly.




(4) Adjustment of maximum and minimum flows

① Adjustment of maximum flow


Adjust it by loosening the hexagon nut(808) and by tightening(or loosening) the set screw(954).

The maximum flow only is adjusted without changing other control characteristics.

Speed	Adjustment of max flow	
	Tightening amount of adjusting screw (954)	Flow change amount
(min ⁻¹)	(Turn)	(l /min)
1900	+1/4	-7.6



2-19(1)




② Adjustment of minimum flow


Adjust it by loosening the hexagon nut(808) and by tightening(or loosening) the hexagonal socket head set screw (953). Similarly to the adjustment of the maximum flow, other characteristics are not changed.

However, remember that, if tightened too much, the required horsepower during the maximum delivery pressure(or during relieving) may increase.

Speed	Adjustment of min flow	
	Tightening amount of adjusting screw (953)	Flow change amount
(min ⁻¹)	(Turn)	(l /min)
1900	+1/4	+7.6




2-19(2)



3) BOOM SPOOL


(1) Neutral

This valve is providing the anti-drift valve on the cylinder bottom side of boom 1 section. In neutral, the poppet(AD1) is seated by the pressure of spring chamber(AD5) because the oil from the port A7 is connection with spring chamber(AD5) via passage(AD2), spool(AD3) and passage(AD4).



45071MC06

- ② When the straight travel spool is operated, the oil discharged from port P1 flows into RH travel section through the neutral passage(L1) and also flows into LH travel section via the neutral passage(R1) and passage(②). The oil discharged from port P2 flows into the parallel passage(L3) via passage(①).
- ③ In case the load pressure of the section except travel is higher than that of the RH travel section, the partial oil of discharged from port P2 pushes open the poppet(S6-2) and flows together into the passage(S6-1) through the orifice at the edge of poppet. The travel(LH, RH) is operated by the discharged oil from port P1 and the other actuators are operated by the discharged oil from port P2. Thus, when travel and front attachment functions are operated simultaneously, keeps the straight travel.



2. FUNCTION

1) ROTARY PART

When high pressurized oil enters a cylinder through port(a), which is the inlet of balance plate(1), hydraulic pressure acting on the piston causes axial force F. The pressure force F works via the piston(2) upon the return plate(3) which acts upon the swash plate(4) via an hydrostatic bearing. Force F1 perpendicular to swash plate(4) and force F2 perpendicular to cylinder center.

Being transferred to the cylinder block(5) through piston, force F2 causes rotational moment at surroundings of cylinder.

Since cylinder block has 9 equidistantly arrayed pistons, rotational torque is transmitted to cylinder shaft in order by several pistons connected to the inlet port of high pressurized oil. When the direction of oil flow is reversed, rotational direction of cylinder is also reversed. Output torque is given by the equation.

$$T = \frac{p \times q}{2\pi}, q = Z \cdot A \cdot \text{PCD} \cdot \tan\theta, F1 = \frac{F}{\cos\theta}, F2 = F \tan\theta, S = \text{PCD} \times \tan\theta$$

Where p : Effective difference of pressure(kgf/cm²)

q : Displacement(cc/rev)


T : Output torque(kgf · cm)

Z : Piston number(9EA)

A : Piston area(cm²)


θ : Tilting angle of swash plate(degree)

S : Piston stroke(cm)



TRAVEL MOTOR(2/2)


• Control part



450A8TO03

- | | | | | | |
|----|-------------------|----|-----------------|----|------------------------|
| 1 | Port plate | 18 | O-ring | 35 | Locking screw |
| 2 | Position piston | 19 | Throttle pin | 36 | O-ring |
| 3 | Position turnnion | 20 | Valve | 37 | O-ring |
| 4 | Control bushing | 21 | Poppet valve | 38 | Brake off pin |
| 5 | Control piston | 22 | Pressure spring | 39 | Ball |
| 6 | Pressure spring | 23 | Seat poppet | 40 | Locking screw |
| 7 | Locking screw | 24 | Poppet valve | 41 | Brake off pin |
| 8 | Throttle screw | 25 | Pressure spring | 42 | Locking screw |
| 9 | Throttle screw | 26 | Locking screw | 43 | Pressure control valve |
| 10 | Brake valve | 27 | O-ring | 44 | Locking screw |
| 11 | Brake piston | 28 | Locking screw | 45 | Control piston |
| 12 | Locking screw | 29 | Valve screw | 46 | Control bushing |
| 13 | Pressure spring | 30 | Bushing | 47 | Pressure spring |
| 14 | Washer | 31 | Socket screw | 48 | O-ring |
| 15 | Throttle screw | 32 | Socket screw | 49 | Shim |
| 16 | Throttle screw | 33 | Cylinder pin | 50 | Relief pressure valve |
| 17 | Throttle pin | 34 | Locking screw | 51 | Cap |

(1) Case where handle is in neutral position



25032RL03

The force of the spring(7) that determines the output pressure of the pilot valve is not applied to the spool(5). Therefore, the spool is pushed up by the spring(10) to the position of port(1, 3) in the operation explanation drawing. Then, since the output port is connected to tank port T only, the output port pressure becomes equal to tank pressure.


GROUP 2 MAIN CIRCUIT

The main hydraulic circuit consists of suction circuit, delivery circuit, return circuit and drain circuit.

The hydraulic system consists of one main pump, one control valve, one swing motor, four cylinders and two travel motors.

The swash plate type variable displacement tandem axial piston pump is used as the main pump and is driven by the engine at ratio 1.0 of engine speed.

1. SUCTION AND DELIVERY CIRCUIT



3-02 (210-7)


The pumps receive oil from the hydraulic tank through a suction filter. The discharged oil from the pump flows into the control valve and goes out the tank ports.

The oil discharged from the main pump flows to the actuators through the control valve.

The control valve controls the hydraulic functions.

The return oil from the actuators flows to the hydraulic tank through the control valve and the oil cooler.

7. BOOM PRIORITY SYSTEM



45073HC08


When carrying out the combined operation of swing and boom or arm, the boom or arm speed can be lowered than operating speed of swing. When the heavy duty working mode in work mode is selected on the cluster, swing reducing solenoid valve actuates automatically.

The oil from pilot pump flows into the solenoid valve through the line filter.

6pcb pressure from solenoid valve change the swing select spool and decreases the oil flow rate to the swing section by orifice.

This is called the boom priority system.

TRAVEL CIRCUIT OPERATION



3-20 (210-7)

Valves are provided on travel motors to offer the following functions.

1) CHECK VALVE

Stopping the motor, this valve sucks the oil from lower pressure passage for prevention the negative pressure and the cavitation of the motor.


2) COUNTER BALANCE VALVE

When stopping the motor of slope descending, this valve to prevent the motor over run.

3) OVERLOAD RELIEF VALVE


Relief valve limit the circuit pressure below 345kgf/cm^2 to prevent high pressure generated at a time of stopping the machine. Stopping the motor, this valve sucks the oil from lower pressure passage for preventing the negative pressure and the cavitation of the motor.







POWER CIRCUIT











4507A4EL05









WIPER AND WASHER CIRCUIT




Part name	Symbol	Specifications	Check
Start relay	 <p>CR-23</p>	24V 300A	※ Check contact Normal : 0.94 Ω (For terminal 1-2)
Blower motor		24V 9.5A	※ Check resistance Normal : 2.5 Ω (For terminal 1-2)
Aircon resistor		-	※ Check resistance Normal : 1.12 Ω (For terminal 4-2) 2.07 Ω (For terminal 2-3) 3.17 Ω (For terminal 3-1)
Duct sensor		1°C OFF 4°C ON	※ Check resistance Normal : 0 Ω (For terminal 1-2), the atmosphere temp : Over 4°C
Door switch	 <p>CS-1 CS-20 CS-53</p>	24V 2W	※ Check resistance Normal : About 5M Ω
Switch (Power max, one touch decal, horn, breaker)	 <p>CS-5 CS-19 CS-26 CS-29</p>	24V 6A	※ Check resistance Normal : ∞ Ω

4) CN TYPE CONNECTOR

No. of pin	Receptacle connector(Female)	Plug connector(Male)
1	 <p style="text-align: center;">S810-001202</p>	 <p style="text-align: center;">S810-101202</p>
2	 <p style="text-align: center;">S810-002202</p>	 <p style="text-align: center;">S810-102202</p>
3	 <p style="text-align: center;">S810-003202</p>	 <p style="text-align: center;">S810-103202</p>
4	 <p style="text-align: center;">S810-004202</p>	 <p style="text-align: center;">S810-104202</p>

No. of pin	Receptacle connector(Female)	Plug connector(Male)
6	 <p style="text-align: center;">S816-006002</p>	 <p style="text-align: center;">S816-106002</p>
8	 <p style="text-align: center;">S816-008002</p>	 <p style="text-align: center;">S816-108002</p>
10	 <p style="text-align: center;">S816-010002</p>	 <p style="text-align: center;">S816-110002</p>
12	 <p style="text-align: center;">S816-012002</p>	 <p style="text-align: center;">S816-112002</p>

GROUP 5 TRAVEL SPEED CONTROL SYSTEM



45075MS07

Travel speed can be switched manually by pressing the travel speed switch on the cluster.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation
Lo	OFF	Turtle	Low speed, high driving torque in the travel motor
Hi	ON	Rabbit	High speed, low driving torque in the travel motor

※ Default : Turtle(Lo)

Fault code No.	Reason	Effect(only when fault code is active)
288	The machine vehicle electronic control unit (VECU) detected a fault with its remote throttle.	The engine will not respond to the remote throttle.
293	High voltage detected at the machine temperature sensor signal pin of the 31-pin machine connector.	No engine protection for machine temperature.
294	Low voltage detected at the machine temperature sensor signal pin of the 31-pin machine connector.	No engine protection for machine temperature.
295	An error in the ambient air pressure sensor signal was detected by the ECM.	Engine is derated to no air setting.
297	High voltage detected at the machine pressure sensor signal pin of the 31-pin machine connector.	No engine protection for machine pressure.
298	Low voltage detected at the machine pressure sensor signal pin of the 31-pin machine connector.	No engine protection for machine pressure.
299	Engine shutdown by device other than key switch before proper engine cool down resulting in filtered load factor above maximum shutdown threshold.	No action taken by the ECM.
311	Current detected at No.1 injector when voltage is turned off.	Current to injector is shut off.
312	Current detected at No.5 injector when voltage is turned off.	Current to injector is shut off.
313	Current detected at No.3 injector when the voltage is turned off	Current to injector is shut off.
314	Current detected at No 6 injector when the voltage is turned off.	Current to injector is shut off.
315	Current detected at No.2 injector when the voltage is turned off.	Current to injector is shut off.
319	Real time clock lost power.	None on performance. Data in the ECM will not have accurate time and date information.
321	Current detected at No.4 injector when the voltage is turned on.	Current to injector is shut off.
322	No current detected at No.1 injector when the voltage is turned on.	Current to injector is shut off.
323	No current detected at No.5 injector when the voltage is turned on.	Current to injector is shut off.
324	No current detected at No.3 injector when the voltage is turned on.	Current to injector is shut off.
325	No current detected at No.6 injector when the voltage is turned on.	Current to injector is shut off.
331	No current detected at No.2 injector when the voltage is turned on.	Current to injector is shut off.
332	No current detected at No.4 injector when the voltage is turned on.	Current to injector is shut off.
341	Severe loss of data from the ECM.	Possible no noticeable performance effects OR engine dying OR hard starting. Fault information, trip information and maintenance monitor data may be inaccurate.
343	Internal ECM error.	Possible none on performance or severe derate.
349	A frequency greater than calibrated threshold was detected at the tail shaft governor signal pin of the 31-pin machine connector.	Calibration dependent power and speed derate.
352	Low voltage detected on the ECM voltage supply line to some sensors (VSEN 1 supply).	Engine is derated to no air setting.

2) CLUSTER CHECK PROCEDURE

(1) Start key : ON

- ① Check monitor initial 5 seconds
 - a. All lamps light up.
 - b. Buzzer sound.
- ② Check monitor after 5 seconds : Indicate cluster version and machine condition
 - a. Cluster program version : CL : 2.0 Indicates program version 2.0 for 2 seconds.
 - b. Tachometer : 0rpm
 - c. Fuel gauge : All light up below appropriate level
 - d. Hydraulic temperature : All light up below appropriate level
 - e. Engine coolant temperature gauge : All light up below appropriate level
 - f. Warning lamp
 - ※ During start key **ON** the engine oil pressure lamp and battery charging lamp go on, but it is not abnormal.
 - ※ When engine coolant temperature below 30°C, the warming up lamp lights up.
- ③ Indicating lamp state
 - a. Work mode selection : General work
 - b. Power mode selection : S mode
 - c. User mode selection : No LED ON
 - d. Auto decel LED : ON
 - e. Travel speed pilot lamp : Low(Turtle)

(2) Start of engine

- ① Check machine condition
 - a. Tachometer indicates at present rpm
 - b. Gauge and warning lamp : Indicate at present condition.
 - ※ When normal condition : All warning lamp OFF
 - c. Work mode selection : General work
 - d. Power mode selection : S mode
 - e. User mode selection : No LED ON
 - f. Auto decel LED : ON
 - g. Travel speed pilot lamp : Low(Turtle)
- ② When warming up operation
 - a. Warming up lamp : ON
 - b. 10 seconds after engine started, engine speed increases to 1000 rpm(Auto decel LED : ON)
 - ※ Others same as above ①.
- ③ When abnormal condition
 - a. The lamp lights up and the buzzer sounds.
 - b. If **BUZZER STOP** switch is pressed, buzzer sound is canceled but the lamp light up until normal condition.

2) DESCRIPTION OF MONITORING DISPLAY

Group	Display	Name	Description
Group 0	1850 rpm	Engine speed	It displays current engine speed detected by engine speed sensor from 500 to 3000rpm. Range : 500~3000rpm by 10rpm
	TIME 12 : 30	Time	It displays current time(12 is hour and 30 is minute) Range : Hour(1~12), minute(00~59)
	EP : 10bar	Power shift pressure of EPPR valve	It shows that pump power shift pressure of EPPR valve being controlled by the CPU controller is 10bar. Range : 00~50bar by 1bar
	45 : C5.1	Model and CPU program version	It shows that machine model(R450/500LC-7A) and the program version of the CPU controller is 5.1. Version display range : 0.0~9.9 by 0.1
	P1 : 100bar (Option)	Front pump pressure	It displays front pump pressure of 100bar which is detected by pressure sensor. Range : 000~500bar by 10bar
	P2 : 200bar (Option)	Rear pump pressure	It displays rear pump pressure of 200bar which is detected by pressure sensor. Range : 000~500bar by 10bar
	P3 : 30bar (Option)	Pilot pump pressure	It displays pilot pump pressure of 30bar which is detected by pressure sensor. Range : 00~50bar by 1bar
Group 1	b: 24.8V	Battery voltage	It shows that battery power of 24.8V is supplied into CPU controller. Range : 00.0~48.0V by 0.1V
	Po : 2.5V	Potentiometer voltage	It shows that throttle command signal voltage is 2.5V. Range : 0.0~5.0V by 0.1V
	dL : 3.8V	Accel dial voltage	It shows that accel dial signal voltage is 3.8V. Range : 0.0~5.0V by 0.1V
	Hd : 50° C	Hydraulic oil temperature	It shows that hydraulic oil temperature detected by temperature sensor is 50°C. Range : 0~150°C by 1°C
	Ct : 85° C	Coolant temperature	It shows that coolant oil temperature received from ECM is 50°C. Range : 0~150°C by 1°C
	AP : 100	Ambient pressure	It shows that ambient pressure recived from ECM is 120kpa Range : 0~125kpa by 1kpa

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

b. Protocol type 2

- If there are more than 2 error codes, each one can be displayed by pressing or switch respectively.
- 3 error codes (①SPN200200, ②FMI06, ③SPN6789, ④FMI04, ⑤345) display.




③ Maintenance




④ Setting

a. Time set



b. System lock - Reserved

5) TRAVEL ACTION IS POWERLESS(Travel only)




6) MACHINE RUNS RECKLESSLY ON A SLOPE




3. BATTERY CHARGING WARNING LAMP LIGHTS UP(Starting switch : ON)

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.



Check voltage



YES	20 ~ 32V
NO	0V



45076ES01

13. WHEN STARTING SWITCH ON DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and master switch ON.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.




2) TEST PROCEDURE

(1) **Test 6** : Check voltage at CN-51(1) and ground.

- ① Prepare 1 piece of thin sharp pin, steel or copper.
- ② Starting key ON.
- ③ Insert prepared pin to rear side of connectors : One pin to (1) of CN-51.
- ④ Check voltage as figure.

(2) **Test 7** : Check voltage at CN-51(13) and ground.

- ① Prepare 1 piece of thin sharp pin, steel or copper
- ② Starting key ON.
- ③ Insert prepared pin to rear side of connectors : One pin to (13) of CN-51
- ④ Check voltage as figure.




4) TRACK REVOLUTION SPEED

(1) Measure the track revolution cycle time with the track raised off ground.

(2) Preparation

- ① Adjust the tension of both side tracks to be equal.
- ② On the track to be measured, mark one shoe with chalk.
- ③ Swing the upperstructure 90° and lower the bucket to raise the track off ground. Keep the boom-arm angle between 90 to 110° as shown. Place blocks under machine frame.
- ④ Keep the hydraulic oil temperature at $50 \pm 5^\circ\text{C}$.



21077MS06

(3) Measurement

- ① Select the following switch positions.
 - Travel mode switch : 1 or 2 speed
 - Mode selector : H mode
 - Auto decel switch : OFF
- ② Operate the travel control lever of the raised track in full forward and reverse.
- ③ Rotate 1 turn, then measure time taken for next 3 revolutions.
- ④ Raise the other side of machine and repeat the procedure.
- ⑤ Repeat steps ③ and ④ three times and calculate the average values.

(4) Evaluation

The revolution cycle time of each track should meet the following specifications.

Unit : Seconds / 3 revolutions

Model	Travel speed	Standard	Maximum allowable
R450LC-7A	1 Speed	39.9 ± 2.0	49.9
	2 Speed	24.8 ± 2.0	31
R500LC-7A	1 Speed	38.5 ± 2.0	48
	2 Speed	24.0 ± 2.0	30


13) PILOT PRIMARY PRESSURE

(1) Preparation

- ① Stop the engine.
- ② Remove the top cover of the hydraulic tank oil supply port with a wrench.
- ③ Loosen and remove plug on the pilot pump delivery port and connect pressure gauge.
- ④ Start the engine and check for oil leakage from the port.
- ⑤ Keep the hydraulic oil temperature at $50 \pm 5^{\circ}\text{C}$.

(2) Measurement

- ① Select the following switch positions.
 - Engine speed : Decel rpm(1000)



50077MS01




(3) Evaluation

The average measured pressure should meet the following specifications:

Unit : kgf / cm^2

Model	Engine speed	Standard	Allowable limits	Remarks
R450LC-7A R500LC-7A	Decel rpm(1000)	35 ± 5	-	

6. TURNING JOINT


Part name		Maintenance standards	Remedy
Body, Stem	Sliding surface with sealing sections.	Plating worn or peeled due to seizure or contamination.	Replace
	Sliding surface between body and stem other than sealing section.	• Worn abnormality or damaged more than 0.1mm (0.0039in) in depth due to seizure contamination.	Replace
		• Damaged more than 0.1mm(0.0039in) in depth.	Smooth with oilstone.
	Sliding surface with thrust plate.	• Worn more than 0.5mm(0.02in) or abnormality.	Replace
• Worn less than 0.5mm(0.02in).		Smooth	
• Damage due to seizure or contamination remediable within wear limit (0.5mm)(0.02in).		Smooth	
Cover	Sliding surface with thrust plate.	• Worn more than 0.5mm(0.02in) or abnormality.	Replace
		• Worn less than 0.5mm(0.02in).	Smooth
		• Damage due to seizure or contamination remediable within wear limit (0.5mm)(0.02in).	Replace
Seal set	-	<ul style="list-style-type: none"> • Extruded excessively from seal groove square ring. 	Replace
	-	<ul style="list-style-type: none"> • Slipper ring 1.5mm(0.059in) narrower than seal groove, or narrower than back ring. 	Replace
	-	<ul style="list-style-type: none"> • Worn more than 0.5mm(0.02in) ~ 1.5mm(MAX.) (0.059in) 	Replace

2. INSTALL WORK

- 1) Tighten all bolts and nuts(Sleeve nuts) to the specified torque.
- 2) Install the hoses without twisting or interference.
- 3) Replace all gaskets, O-rings, cotter pins, and lock plates with new parts.
- 4) Bend the cotter pin or lock plate securely.
- 5) When coating with adhesive, clean the part and remove all oil and grease, then coat the threaded portion with 2-3 drops of adhesive.
- 6) When coating with gasket sealant, clean the surface and remove all oil and grease, check that there is no dirt or damage, then coat uniformly with gasket sealant.
- 7) Clean all parts, and correct any damage, dents, burrs, or rust.
- 8) Coat rotating parts and sliding parts with engine oil.
- 9) When press fitting parts, coat the surface with antifriction compound(LM-P).
- 10)After installing snap rings, check that the snap ring is fitted securely in the ring groove(Check that the snap ring moves in the direction of rotation).
- 11)When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect securely.
- 12)When using eyebolts, check that there is no deformation or deterioration, and screw them in fully.
- 13)When tightening split flanges, tighten uniformly in turn to prevent excessive tightening on one side.
- 14)When operating the hydraulic cylinders for the first time after repairing and reassembling the hydraulic cylinders, pumps, or other hydraulic equipment or piping, always bleed the air from the hydraulic cylinders as follows:
 - (1) Start the engine and run at low idling.
 - (2) Operate the control lever and actuate the hydraulic cylinder 4-5 times, stopping 100mm before the end of the stroke.
 - (3) Next, operate the piston rod to the end of its stroke to relieve the circuit. (The air bleed valve is actuated to bleed the air.)
 - (4) After completing this operation, raise the engine speed to the normal operating condition.
 - ※ If the hydraulic cylinder has been replaced, carry out this procedure before assembling the rod to the work equipment.
 - ※ Carry out the same operation on machines that have been in storage for a long time after completion of repairs.

3) DISASSEMBLY

- (1) Select place suitable to disassembling.
 - ※ Select clean place.
 - ※ Spread rubber sheet, cloth or so on on overhaul workbench top to prevent parts from being damaged.
- (2) Remove dust, rust, etc, from pump surfaces with cleaning oil or so on.
- (3) Remove drain port plug(468) and let oil out of pump casing(Front and rear pump).
- (4) Remove hexagon socket head bolts(412, 413) and remove regulator.





- (5) Loosen hexagon socket head bolts(401) which tighten swash plate support(251), pump casing(271) and valve cover(F, 311).
 - ※ If gear pump and so on are fitted to rear face of pump, remove them before starting this work.
- (6) Loosen hexagon socket head bolts(402) which tighten swash plate support(251), pump casing(271) and valve cover(R, 312).


6) TOOLS AND TIGHTENING TORQUE

(1) Tools

The tools necessary to disassemble/reassemble the pump are shown in the follow list.

Tool name & size		Part name			
Name	B	Hexagon socket head bolt	PT plug (PT thread)	PO plug (PF thread)	Hexagon socket head setscrew
Allen wrench 	4	M 5	BP-1/16	-	M 8
	5	M 6	BP-1/8	-	M10
	6	M 8	BP-1/4	PO-1/4	M12, M14
Double ring spanner, socket wrench, double(Single) open end spanner 	-	Hexagon head bolt	Hexagon nut	VP plug (PF thread)	
	6	M 8	M 8	-	
Adjustable angle wrench		Small size, Max 36mm			
Screw driver		Minus type screw driver, Medium size, 2 sets			
Hammer		Plastic hammer, 1 set			
Pliers		For snap ring, TSR-160			
Steel bar		4 × 100mm			
Torque wrench		Capable of tightening with the specified torques			
Pincers		-			
Bolt		M4, Length : 50mm			

2. STRUCTURE(1/3)



20	Spool assy	50	Relief valve assy	62	Plug assy
21	Spring seat	51	Plug assy	65	Bolt
22	Spring	52	Poppet	69	Poppet
23	Plug	53	Spring	72	Relief valve kit
24	Spool assy	54	Plug	73	Relief valve kit
25	Spring	55	O-ring	76	O-ring
26	O-ring	58	Plug assy	77	O-ring
27	Plug	59	Plug assy	78	O-ring
29	Spring	60	Plug assy	79	O-ring
30	Poppet	61	Plug assy	86	Socket head bolt
49	Relief valve kit				

45078MC04

3) ASSEMBLY


(1) General comments

- ① In this assembly section, explanation only is shown.
For further understanding, please refer to the figures and photographs shown in the previous disassembly section.
- ② Figure in () shown after the part name in the explanation refers to the reference identity number shown on the construction figure shown in the spares section.
- ③ **Cautions in assembling seal**
 - a. Pay close attention to keeping all seals free from handling damage and inspect carefully for damage before using them.
 - b. Apply clean grease or hydraulic oil to the seal so as to ensure it is fully lubricated before assembly.
 - c. Do not stretch seals so much as to deform them permanently.
 - d. In fitting O-rings, pay close attention not to roll them into their final position in addition, a twisted O-ring cannot easily untwist itself naturally and could thereby cause inadequate sealing and thereby both internal and external oil leakage.
 - e. Tighten fitting bolts for all sections with a torque wrench adjusted to the respective tightening torque as shown on the cross section drawings of the spares section.


(2) Main spool

- ① Apply loctite to thread of spools(3, 4, 6, 7, 9, 10, 11) and assemble spring seat, spring and spool end. Assemble spool end to spool after fixing spool with a vise attached wood.
※ Be careful not to applying loctite too much.
· Tightening torque : 2.4 ~ 2.6 kgf · m(17.4 ~ 18.8lbf · ft)
Fit O-ring into housing and assemble spools(3, 4, 6, 7, 9, 10, 11) into housing.
Assemble lock cap on housing and tighten hex socket bolt.
· Tightening torque : 11 ± 0.5 kgf · m(79.7 ± 3.7 lbf · ft)
- ② Insert poppet, spring into spool(5) and then apply loctite to thread of spool.
Fit O-ring and backup ring on the plug and then tighten plug.
Assemble spring seat, spring, and spool end and then assemble spool end sub assy to spool after fixing spool with a vise attached wood.
· Tightening torque : 2.4 ~ 2.6 kgf · m(17.4 ~ 18.8lbf · ft)
Fit O-ring into housing and assemble spool(5) into housing.
Assemble lock cap on housing and tighten hex socket bolt.
· Tightening torque : 11 ± 0.5 kgf · m(79.7 ± 3.7 lbf · ft)
- ③ Insert poppet, spring into spool(8) and then apply loctite to thread for spool.
Fit O-ring and backup ring on the plug and then tighten plug.
Assemble spring seat, spring, and spool end and then assemble spool end sub assy to spool after fixing spool with a vise attached wood.
· Tightening torque : 2.4 ~ 2.6 kgf · m(17.4 ~ 18.8lbf · ft)
Fit O-ring into housing and assemble spool(8) into housing.
Assemble lock cap on housing and tighten hex socket bolt.
· Tightening torque : 11 ± 0.5 kgf · m(79.7 ± 3.7 lbf · ft)
- ④ Assemble short cap on housing and tighten hex socket bolt.
· Tightening torque : 11 ± 0.5 kgf · m(79.7 ± 3.7 lbf · ft)


(4) Tack O-ring(471) to the casing(301).




(5) Reassemble the front cover(304) to the casing(301).
※ Apply grease to the rib of oil seal to avoid damage to the rib.




(6) Install the snap ring(437) to the casing (301).




(7) Insert the shoe plate(124) with the casing (301) position horizontally.




- (12) Remove drive shaft(2) with roller bearing(7) and oil seal(6) assembled.
Remove knock pin(12) from the casing(1).




- (13) Remove roller bearing(7) and oil seal(6)
from the drive shaft(2).
※ Do not reuse oil seal(6) once removed.



- (14) Using the bearing disassembly tool,
remove roller bearing(5).




- (15) Remove plugs(29, 30) from the casing(1).




(2) Seal kit and component groups

① Attention

Observe the following notices when carrying out repair work at hydraulic aggregates!




② Close all ports of the hydraulic aggregates.




③ Replace all seals.

Use only original spare parts.



④ Check all seal and sliding surfaces for wear.

Rework of sealing area for example with abrasive paper can damage surface.




4) ASSEMBLY


(1) General precautions

- ① Reassemble in a work area that is clean and free from dust and grit.
- ② Handle parts with bare hands to keep them free of liny contaminates.
- ③ Repair or replace the damaged parts.
Each parts must be free of burrs its corners.
- ④ Do not reuse O-rings, oil seal and floating seal that were removed in disassembly.
Provide the new parts.
- ⑤ Wash all parts thoroughly in a suitable solvent.
Dry thoroughly with compressed air.
Do not use the cloths.
- ⑥ When reassembling oil motor components of motor, be sure to coat the sliding parts of the motor and valve with fresh hydraulic oil. (NAS class 9 or above)
- ⑦ Use a torque wrench to tighten bolts and plugs, to the torque specified as follows.


(12) Remove the O-rings(24,25) and the backup rings(23, 26) from their grooves in the flanged hub(17).




(13) Turn the gearbox around, unscrew and remove the 2 plugs(2) and the 2 washers (1) from the end cover(4).




(14) Unscrew and remove the 16 socket head screws(3).




(15) By means of a puller remove the end cover(4).




(21) Insert the 1st stage sun gear(7).




(22) Fit the O-ring(5) into its groove in the end cover(4).




(23) Place the end cover(4) on the gearbox housing(15).
Apply LOCTITE type 243 on the 16 socket head screws(3), and tighten them by a torque wrench at a torque of 19.4kgf · m (140lbf · ft).



(24) Place the 2 washer(1) in their groves and tighten the 2 plugs at a torque of 6.1~8.2kgf · m(44.1~59.3lbf · ft).




(7) Remove plate(15).




(8) When return spring(10) is weak in force, plug(11) stays in casing because of sliding resistance of O-ring.

- ※ Take it out with minus screwdriver. Take it out, utilizing external periphery groove of plug and paying attention not to damage it by partial loading.
- ※ During taking out, plug may jump up due to return spring(10) force. Pay attention to this.




(9) Remove reducing valve subassembly and return spring(10) out of casing.

- ※ Record relative position of reducing valve subassembly and return springs.




(10) Loosen hexagon socket head plug(2) with hexagon socket screw key.



2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE





R210TJT2

- | | | | | | |
|---|----------------|----|--------------|----|----------------|
| 1 | Hub | 6 | Shim | 11 | Plug |
| 2 | Shaft assembly | 7 | Slipper seal | 12 | Plug |
| 3 | Cover | 8 | O-ring | 13 | Retaining ring |
| 4 | Spacer | 9 | O-ring | 14 | Hexagon bolt |
| 5 | Shim | 10 | O-ring | 15 | Spring washer |

2. DISASSEMBLY AND ASSEMBLY

1) STRUCTURE

(1) Bucket cylinder(R450LC-7A)



470078BK01


1	Tube assembly	11	O-ring	21	Lock nut
2	Rod assembly	12	Back up ring	22	Hexagon socket head bolt
3	Gland	13	Cushion ring	23	Pin bushing
4	DD2 bushing	14	Piston	24	Dust seal
5	Snap ring	15	O-ring	25	Band assembly
6	Rod seal	16	Back up ring	26	Pipe assembly
7	Back up ring	17	Piston seal	27	Pipe assembly
8	Buffer ring	18	Wear ring	28	O-ring
9	Dust wiper	19	Dust ring	29	Hexagon socket head bolt
10	Snap ring	20	Lock washer	30	Grease nipple

3) ASSEMBLY

(1) Assemble cylinder head assembly

※ Check for scratches or rough surfaces if found smooth with an oil stone.


- ① Coat the inner face of gland(3) with hydraulic oil.



- ② Coat dust wiper(9) with grease and fit dust wiper(9) to the bottom of the hole of dust seal.

At this time, press a pad metal to the metal ring of dust seal.


- ③ Fit snap ring(10) to the stop face.



- ④ Fit back up ring(7), rod seal(6) and buffer ring(8) to corresponding grooves, in that order.


※ Coat each packing with hydraulic oil before fitting it.

※ Insert the backup ring until one side of it is inserted into groove.



※ Rod seal(6) has its own fitting direction. Therefore, confirm it before fitting them.

※ Fitting rod seal(6) upside down may damage its lip. Therefore check the correct direction that is shown in fig.




(3) Assembly

- ※ Before assembly, clean the parts.
- ※ Coat the sliding surfaces of all parts with oil.


① Cool up bushing(2) fully by some dry ice and press it into shell(1).

Do not press it at the normal temperature, or not knock in with a hammer even after the cooling.




② Coat O-ring(4) with grease thinly, and install it to shaft(3).


③ Insert shaft(3) into bracket(6) and drive in the spring pin(7).



④ Install seal(5) to shell(1) and bracket(6).



⑤ Install shaft(3) to shell(1).



SECTION 9 COMPONENT MOUNTING TORQUE

Group 1 Introduction Guide	9-1
Group 2 Engine System	9-2
Group 3 Electric System	9-4
Group 4 Hydraulic System	9-6
Group 5 Undercarriage	9-9
Group 6 Structure	9-10
Group 7 Work Equipment	9-14

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL