

**en**

**Service manual**

Wheel loader

**Document ID**

**Order number:** 12242502  
**Issued:** 2021-01-26  
**Version:** 04  
**Author:** LBH / Technical Documentation Department

**Product ID**

**Manufacturer:** Liebherr-Werk Bischofshofen GmbH  
**Valid for:** L 508-1817

**Contact**

Liebherr-Werk Bischofshofen GmbH  
Dr. Hans Liebherr-Straße 4  
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

030.3.12	Lubrication grease <i>L508-1817;</i>	030-20
030.3.12.1	Liebherr recommendation	030-20
030.3.12.2	Minimum quality requirement	030-21
030.4	Maintenance tasks	030-22
030.4.1	Safety precautions <i>L508-1817;</i>	030-22
030.4.2	Preparatory tasks for maintenance	030-22
030.4.2.1	Maintenance positions <i>L508-1817;</i>	030-23
030.4.2.2	Opening the service hatches <i>L508-1817;</i>	030-24
030.4.2.3	Turning off battery main switch <i>L508-1817;</i>	030-25
030.4.3	Overall machine	030-26
030.4.3.1	Checking machine is in proper condition <i>L508-1817;</i>	030-26
030.4.3.2	Removing loose parts, dirt, ice and snow from machine <i>L508-1817;</i>	030-28
030.4.3.3	Cleaning machine <i>L508-1817;</i>	030-28
030.4.3.4	Replacing VCI capsules <i>L508-1817;</i>	030-31
030.4.3.5	Operating fluid analysis: General specifications <i>L508-1817;</i>	030-33
030.4.3.6	Operating fluid analysis: filling out sample information form <i>L508-1817;</i>	030-36
030.4.3.7	Fuel and operating fluid analysis: scope of analysis <i>L508-1817;</i>	030-42
030.4.3.8	Analysis of lubricants and fuels <i>L508-1817;</i>	030-46
030.4.4	Drive group	030-52
030.4.4.1	Checking diesel engine oil level <i>L508-1817;</i>	030-52
030.4.4.2	Diesel engine: changing diesel engine oil <i>L508-1817;</i>	030-54
030.4.4.3	Diesel engine: changing oil filter <i>L508-1817;</i>	030-56
030.4.4.4	Diesel engine: checking V-belt <i>L508-1817;</i>	030-58
030.4.4.5	Diesel engine: changing V-belt <i>L508-1817;</i>	030-60

	160.3.2.2	Blower <i>L508-1817;</i>	160-21
160.4	Air conditioning		160-23
160.4.1	Basic function of the air conditioning unit <i>L508-1817;</i>		160-23
160.4.2	Air conditioning compressor <i>L508-1817;</i>		160-24
160.4.3	Condenser <i>L508-1817;</i>		160-29
160.4.4	Dryer <i>L508-1817;</i>		160-29
160.4.5	Air conditioning pressure switch <i>L508-1817;</i>		160-30
<b>170</b>	<b>Lubrication system</b>		170-1
170.1	Liebherr automatic central lubrication system		170-2
170.1.1	Automatic central lubrication system: overview <i>L508-1817;</i>		170-2
170.1.2	Central lubrication pump EP-1 <i>L508-1817;</i>		170-6
170.1.3	Progressive distributor MX-F <i>L508-1817;</i>		170-9
<b>200</b>	<b>Diagnosis</b>		200-1
200.1	Malfunctions		200-2
200.1.1	Warning symbols		200-2
200.1.2	Service codes: indication on display		200-2
200.1.3	Display service code table		200-4
200.2	Troubleshooting		200-6
200.2.1	Replacing fuses		200-6
	200.2.1.1	Fuses on the fuse board in the cab	200-6
	200.2.1.2	Fuses in the battery compartment	200-8
	200.2.1.3	Plug-in fuses for LiDAT	200-9

### 010.1.3.4 Operator

#### Responsibility

Operator is responsible for following:

- Read the operator's manual.
- Read included documentation:
  - Operator's manuals for components
  - Operator's manuals from third party manufacturers
  - Additional instructions
- Wear personal protective equipment.
- Operate machine as intended.
- Avoid working methods that can endanger safety.
- Adhere to safety regulations at place of use.
- Maintain visual contact or voice contact with spotter.
- During operation, do not allow any other persons on machine.
- Report all changes to machine that affect safety to operating company.
- If it is no longer possible to work safely, stop operating the machine immediately.
- Only perform retrofittings of machine after consultation with manufacturer.
- Use original Liebherr spare parts wherever possible.

#### Requirement

The operator has following qualification and skills:

- Has completed the legally specified minimum age.
- Is physically and mentally capable of operating the machine safely.
  - Satisfactory eyesight
  - Satisfactory hearing ability
  - Quick reactions
  - Is able to estimate distance, height and gaps.
- Has the necessary authorisation for operation of machine.
- The operator has the necessary education (theoretical and practical) for the following:
  - Handling the machine type
  - Attaching
  - Spotting
  - Handling fire extinguishing equipment
- Knows all means of escape in an emergency.
- Is not under any physical or mental impairment that limits one of the prescribed requirements.
- Is not under the influence of alcohol.
- Is not under the influence of drugs.

### 010.1.3.5 Maintenance staff

#### Responsibility

The maintenance staff are responsible for the following:

- Read the operator's manual.
- Read included documentation:
  - Operator's manuals for components
  - Operator's manuals from third party manufacturers
  - Additional instructions
- Maintain machine for safe and reliable function.
- Execute all maintenance tasks specified for maintenance staff in the maintenance and inspection schedule.

## Injuries

### Incorrect protection

- If there is a danger of falling objects: Exclusively use machines with suitable falling object protective structures.
- If there is a danger of objects penetrating the operator's cab: Exclusively use machines with suitable falling object protective structures.
- If machine is used in toxic environment: Insert filters approved for the use in air conditioning.
- If machine is used in dust-intensive environment: Insert filters approved for the use in air conditioning.

### Incorrect refuelling

- Do not touch fuels with your skin.
- Do not inhale fuel vapours.

### Incorrect maintenance

- Make sure there is nobody in the danger area.
- Park machine and secure to prevent rolling or driving away.
- Park machine on level, firm ground.
- Park machine with lowered working attachment.
- When searching for leaks in the hydraulic system wear protective gloves.
- Exclusively search for leaks in the hydraulic system with cardboard or similar material.
- Hydraulic system must be depressurised before work can be carried out on it.
- Repairs to hydraulic hoses and hose lines are carried out by authorised specialist staff only.
- Lay and install hydraulic hoses and hose lines professionally.
- Do not weld or solder accumulators.
- Do not perform mechanical work on accumulators.
- Make sure that the permanent labelling of the accumulators (operating data) is kept visible.
- Be especially careful when removing or inserting bolts and pins as this can cause serious injury.
- Make sure that machine is supported in a proper and secure manner.

## Crushing injuries

### Unexpected movements of machine

- Make sure there is nobody in the danger area.
- Park machine and secure to prevent rolling or driving away.
- Do not work under working attachment unless it is supported or resting on ground.

### Unintentional closing of service access points

- Ensure that the service access points cannot close unintentionally.

### Incorrect lifting tackle

- Exclusively use undamaged lifting accessories.
- Ensure that the load and tensile capacity of the lifting tackle is sufficient.

Designation	ID no.	Use	Remark
Valve insert remover	11834779	All wheel loaders	For changing valve inserts in filling port of air conditioning hoses.
Vacuum pump	7027552	All wheel loaders	For evacuating the air conditioning system
4-valve test fitting	7027558	All wheel loaders	For testing, evacuating and filling the air conditioning system
Filling hose, blue 1500 mm	7027553	All wheel loaders	For the test fitting
Filling hose, yellow 1500 mm	7027554	All wheel loaders	For the test fitting
Filling hose, red 1500 mm	7027555	All wheel loaders	For the test fitting
Car coupling 253a	7027556	All wheel loaders	For the test fitting
Car coupling 254a	7027557	All wheel loaders	For the test fitting

Tab. 13: Special tools for air conditioning system

### 010.2.11 Special tools for cab glazing

Description	ID no.	Use	Remarks
Toolbox complete with suction cups	10021147	All wheel loaders	For removing and installing bonded panes

Tab. 14: Special tools for cab glazing

### 010.2.12 Special tools for the central lubrication system

Designation	ID number	Use	Remark
Liebherr filling press	10009239	All wheel loaders with Liebherr central lubrication system	For quickly filling the reservoir
Filling press	10333342	All wheel loaders with Liebherr central lubrication system	For quickly filling the reservoir
Liebherr filling port	7029283	All wheel loaders with Liebherr central lubrication system	For quickly filling the reservoir

LBH12242502/04/211-20210126\_072043/en

## 010.4 Preservation guidelines

### 010.4.1 General information

All parts of a construction machine are exposed to corrosion when out of use. Corrosion can be compared to wear. However, the effects can be much more serious than mechanical wear and can significantly reduce the service life of the parts. This means the machines and their components must be preserved according to certain guidelines when out of use.

Generally these guidelines are based on the following time-scales:

- Out of service for an unknown period of time
- Putting the machine out of service
  - Out of service for up to 2 months
  - Out of service for up to 12 months
  - Out of service for longer than 12 months
- Putting back into service

The required measures are also scaled according to the time periods. The preservation measures are not strictly standardized, and are to be shortened or lengthened depending on necessity (e.g. because of environmental conditions).

Such conditions are, for example:

- The machine's location (e.g. in unprotected open space, in closed space, with roof, temperature-controlled environment)
- The type of climate (e.g. extreme temperatures, storage near the sea or the coast, etc.)

### 010.4.2 Machine out of service for an unknown period of time

If the machine is out of use for a lengthy period without preservation, it must be **put back into service at intervals of no more than 14 days** in order to prevent increased corrosion and the resulting damage.

- All oil levels must be checked before putting into service and filled up where necessary.
- Carry out all the prescribed daily maintenance work every day before putting into service. Carry out all the additional maintenance work subject to time limits as per the inspection plan and the additional diesel engine operator's manual by the specified intervals at the latest.
- Put machine back into service according to operating instructions and operate until the diesel engine and hydraulics system have reached the prescribed operating temperature in the hydraulic tank and in the coolant circulation.
- Activate all the functions of the travel and working hydraulics and of the other hydraulic components, and operate alternately for approx. 20 minutes in total. Hydraulic cylinders must each be extended and retracted over their full stroke length.
- When switching off the machine, retract all the hydraulic cylinders completely if possible, and fill up the fuel tank. If the surface is soft, put the machine on wooden blocks or similar, and secure against rolling.
- Check batteries and, if necessary, remove and recharge. Check electronic contact points and grease with terminal grease if needed.

	Designation	Unit	Value
	Bucket capacity as per ISO 7546 <sup>C)</sup>	m <sup>3</sup>	1.0
	Bucket width	mm	2100
	Specific material weight	t/m <sup>3</sup>	1.8
A	Dumping height at maximum lifting height and 42° tilt out angle	mm	2640
B	Dump height	mm	3000
C	Maximum bucket base height	mm	3180
D	Maximum bucket pivot point height	mm	3370
E	Maximum bucket upper edge height	mm	4260
F	Reach at maximum lifting height and 42° tilt out angle	mm	810
F max.	Maximum reach at 42° tilt out angle	mm	1600
G	Digging depth	mm	57
H	Height above operator's cab	mm	2460
I	Height above exhaust	mm	1810
J	Ground clearance	mm	325
K	Wheelbase	mm	2150
L	Overall length	mm	5515
	Turning radius over bucket outer edge (transport position)	mm	4465
	Breakout force (SAE)	kN	56
	Tipping load when straight	kg	4400
	Tipping load when articulated (ISO 14397-1)	kg	3850
	Operating weight	kg	5600

Tab. 20: Complete machine with loading bucket

- A) Z-bar kinematics including quick coupler  
 B) Welded tooth holder with plug-in teeth  
 C) In practice, the bucket capacity can be around 10% greater than as calculated using the ISO 7546 standard. This depends on the type of material.

## 020.1.2 Working attachment: 4 in 1 bucket

Valid for: L508-1817;

Values stated refer to machine:

- With 340/80R18 tyres
- Including all lubricants
- With a full fuel tank
- With ROPS/FOPS cab and operator
- On level and stable ground



### Note

Tyres and working attachments affect operating mass and tip load.

- ▶ Note tyre and working attachment specifications.
- ▶ See separate operator's manual for more information.

Description	Unit	Value
Stroke length	mm	380
Weight	kg	51.2
Tightening torque of piston rod bearing	Nm	800
Tightening torque of piston	Nm	400
Tightening torque of piston nut	Nm	200

LBH12242502/04/211-20210126\_072043/en

## 020.12 Steel parts of the basic machine

### 020.12.1 Ballast weight

*Valid for: L508-1817;*

Description	Unit	Value
Ballast weight	kg	987

030.4.12.3	Engine bonnet: lubricating moving parts with penetrating oil <i>L508-1817;</i>	030-128
030.4.12.4	Service hatches: cleaning and maintaining seals <i>L508-1817;</i>	030-128
030.4.13	Working attachment	030-129
030.4.13.1	Lubricating the lift arms and working attachment <i>L508-1817;</i>	030-129
030.4.13.2	Checking lift arm bucket bearing bushings <i>L508-1817;</i>	030-130
030.4.13.3	Checking lift arm bucket stops <i>L508-1817;</i>	030-131
030.4.13.4	Quick coupler: checking function <i>L508-1817;</i>	030-132
030.4.14	Operator's cab, heating and air conditioning	030-133
030.4.14.1	Cleaning operator's cab air filter <i>L508-1817;</i>	030-133
030.4.14.2	Changing operator's cab air filter <i>L508-1817;</i>	030-133
030.4.14.3	Safety belt: checking condition and function <i>L508-1817;</i>	030-134
030.4.14.4	Windscreen washer system: testing <i>L508-1817;</i>	030-135
030.4.14.5	Windscreen washer system: filling windscreen washer fluid <i>L508-1817;</i>	030-135
030.4.14.6	Operator's cab: lubricating locking mechanism and cylinder with penetrating oil <i>L508-1817;</i>	030-136
030.4.14.7	Operator's cab: cleaning and maintaining seals <i>L508-1817;</i>	030-137
030.4.14.8	Air conditioning: checking V-belt <i>L508-1817;</i>	030-138
030.4.14.9	Air conditioning: changing V-belt <i>L508-1817;</i>	030-140
030.4.14.10	Air conditioning: draining condensate <i>L508-1817;</i>	030-142
030.4.14.11	Heating and air conditioning unit: Testing function <i>L508-1817;</i>	030-143
030.4.15	Lubrication system	030-144
030.4.15.1	Central lubrication system: checking level in grease reservoir <i>L508-1817;</i>	030-144

### 030.3.3 Converting hydraulic system from mineral oils to biodegradable hydraulic fluids

For operation of Liebherr earth moving machines with biodegradable hydraulic fluids, we recommend **Liebherr Hydraulic Plus**.

In the case of a machine equipped with biodegradable hydraulic fluid at the factory, a corresponding information label is attached.

#### Procedure for later conversion

---

#### NOTICE

Non-approved oil!  
Damage to the hydraulic system.

- ▶ Only use oil that meets the Liebherr specifications.
  - ▶ Do not mix different oils.
- 
- ▶ In case of subsequent conversion of machine to a biodegradable hydraulic fluid, contact Liebherr customer service!
  - ▶ Request **instructions** and **conversion guidelines** from Liebherr and observe them!

### 030.3.4 Diesel fuels

*Valid for: L508-1817;*

#### 030.3.4.1 Minimum quality requirement

Approved diesel fuels	As per DIN EN 590, ASTM D 975 1-D / 2-D
	Emission stage V
Maximum sulphur content	10 ppm
Minimum cetane number	45
Lubricity at 60 °C (HFRR)	Maximum 460 µm

*Tab. 27: Minimum quality requirement*

Do not mix diesel fuel with additives.

#### 030.3.4.2 Operating temperatures of diesel fuels

Approved diesel fuels according to DIN EN 590	Cloud point	Ambient temperature
Class standard	-7 °C	to -10 °C
Arctic class 0	-10 °C	to -13 °C
Arctic class 1	-16 °C	to -20 °C

*Tab. 28: Operating temperatures of diesel fuels*

**CAUTION**

Engine hood falling shut  
Injury.

- ▶ Only open the engine hood when the gas-filled springs function properly.

**To open engine bonnet:**

- ▶ Open the lock with the ignition key.
- ▶ Open the engine hood **2** with the handle **1**.
  - ▷ The engine hood **2** is held in this position by gas-filled springs.

**Troubleshooting**

If the gas-filled spring does not hold the hood open:

- ▶ Contact Liebherr customer service.

**To close engine bonnet:**

- ▶ Close the engine hood **2** with the handle **1**.
- ▶ Close the lock with the ignition key.

**030.4.2.3 Turning off battery main switch**

*Valid for: L508-1817;*

Battery main switch is located on left side of engine compartment.

**For certain maintenance tasks, battery main switch must first be turned off.**

Find out from descriptions of relevant maintenance tasks whether battery main switch must be turned on or off.

Turn on battery main switch after completing these maintenance tasks.

**NOTICE**

Voltage fluctuations!  
Damage to the electrical system.

- ▶ Never turn off the battery main switch when the engine is running.

2 Locking screw

4 Sample container

**Note**

Contaminated fuel sample!  
Incorrect analysis result.

- ▶ Clean hand pump 3 only with clean cloth.
- ▶ Ensure that sampling hose 1 is new.
- ▶ Clean sampling point before opening.


- 
- ▶ Screw in new sampling container 4 immediately after removing cover in hand pump 3.
  - ▶ Shorten new sampling hose 1 to suitable length.
  - ▶ Guide sampling hose 1 through hand pump 3 into sampling container 4.
  - ▶ Screw locking screw 2 closed.
    - ▷ Sampling hose 1 is clamped air tight in hand pump 3.

**Preparing sample container for shipping**

- ▶ Fill out sample information form ([For more information see: Operating fluid analysis: filling out sample information form, page 030-36](#)).
- ▶ Glue barcode of sample information form to sample container.
- ▶ Separate sample receipt from sample information form and keep it safe.
- ▶ Insert sample information form into outer opening of plastic bag.
- ▶ Place sample container into plastic bag.
- ▶ Close plastic bag.
- ▶ Enter sender data on front of plastic bag.
- ▶ Enter details of sampling area on plastic bag.
- ▶ Apply postage to shipping bag.
  - ▷ Sample container is ready for shipment.

**Note**




The operating fluid analysis is performed by Oelcheck GmbH.

Cover colour	Appearance		Wear	Additives	Contamination	PQ index	Viscosity 40 °C	Viscosity 100 °C	Viscosity index	Oxidation	IR index	Water with IR	Water according to K. F.	Neutralisation number	Optical particle counting
	Appearance	Wear													
	X	X	X	X	X	X	X	X	X	X	X		X	X	X

Tab. 59: Scope of analysis of transmission oils



## Transmission

### Transmission oils

Cover colour	Appearance		Wear	Additives	Contamination	PQ index	Viscosity 40 °C	Viscosity 100 °C	Viscosity index	Oxidation	IR index	Water with IR	Water according to K. F.	Neutralisation number	Optical particle counting
	Appearance	Wear													
	X	X	X	X	X	X	X	X	X	X	X	X			
	X	X	X	X	X	X	X	X	X	X	X		X		
	X	X	X	X	X	X	X	X	X	X	X		X	X	X

Tab. 60: Scope of analysis of transmission oils

### Pump distributor gear oils

Cover colour	Appearance		Wear	Additives	Contamination	PQ index	Viscosity 40 °C	Viscosity 100 °C	Viscosity index	Oxidation	IR index	Water with IR	Water according to K. F.	Neutralisation number	Optical particle counting
	Appearance	Wear													
	X	X	X	X	X	X	X	X	X	X	X	X			
	X	X	X	X	X	X	X	X	X	X	X		X		

LBH12242502/04/211-20210126\_072043/en

## Draining oil




Fig. 113: Draining oil

- 1 Drain valve  
2 Drain hose

3 Cover

- ▶ Unscrew cover 3.
  - ▷ Crankshaft housing is ventilated. Flow of engine oil is thereby accelerated.
- ▶ Place collecting pan under diesel engine.



### CAUTION

Hot fluids!  
Burns.

- ▶ Avoid skin contact with fluids.

Drain valve 1 is on underside of diesel engine.

- ▶ Screw drain hose 2 onto drain valve 1.
  - ▷ Open drain valve. Engine oil drains out.
- ▶ Unscrew drain hose 2.
- ▶ Change oil filter. (For more information see: [Diesel engine: changing oil filter, page 030-56](#))

## Topping up oil

### NOTICE

Non-approved oil!  
Damage.

- ▶ Only use oil that meets the Liebherr specifications.




Fig. 125: Removing DPF, exposing valves

- |   |                                 |   |                              |
|---|---------------------------------|---|------------------------------|
| 1 | Diesel particulate filter (DPF) | 4 | Screws on input module (3x)  |
| 2 | Valve cover                     | 5 | Screws on output module (3x) |
| 3 | Screws on exhaust manifold (4x) |   |                              |

- ▶ Replace seal on the exhaust manifold.
- ▶ Position screws on the exhaust manifold **3**.
- ▶ Position screws on the input module **4**.
- ▶ Position screws on the output module **5**.
- ▶ Tighten screws on the exhaust manifold **3** to a tightening torque of  $49 \pm 4.9$  Nm.
- ▶ Tighten screws on the output module **5** to a tightening torque of  $49 \pm 4.9$  Nm.
- ▶ Tighten screws on the input module **4** to a tightening torque of  $49 \pm 4.9$  Nm.
- ▶ Connect the electrical cables on the diesel particulate filter **1**.
- ▶ Start diesel engine and let it run for 3 minutes at medium idling speed.



#### WARNING

Rotating parts!  
Risk of injury.

- ▶ Do not touch rotating parts of the engine.



#### WARNING

Hot components!  
Risk of injury.

- ▶ Do not touch components of the exhaust system and the engine.
- ▶ Check that valve cover and valve cover seal do not leak.
- ▶ Turn off diesel engine.

g2048734

## Installing the main element




Fig. 136: Installing the main element

- |   |                      |   |                |
|---|----------------------|---|----------------|
| 1 | Dust discharge valve | 4 | Main element   |
| 2 | Service cover        | 5 | Safety element |
| 3 | Fixing clips         | 6 | Filter housing |

- ▶ Lightly oil the sealing face of the main element 4.
- ▶ Install the main element 4.
- ▶ Put the clean service cover 2, with the dust discharge valve 1 facing down, on the filter housing 6.
- ▶ Close the fixing clips 3.



### Note

If *air filter contamination* symbol lights up again a few operating hours after main element has been cleaned:

- ▶ Change main element.



### Note

If *air filter contamination* symbol remains lit after main element has been changed:

- ▶ Change safety element.

### 030.4.4.14 Changing the safety element of the air filter system

Valid for: L508-1817;

#### NOTICE

Always carry out maintenance correctly.  
Damage to the engine.

- ▶ Do not clean the safety element.
- ▶ Only replace the safety element.

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.




Fig. 147: Sending data to Yanmar server

- 1    Checkbox
- 2    Data record
- 3    "Send" function
- 4    "OK" function

- ▶ Select Checkbox 1 for data record 2 of corresponding diesel engine.
- ▶ Select "Send" function 3.
  - ▷ Data is sent to Yanmar server.
- ▶ Select "OK" function 4.
  - ▷ Sending data to Yanmar server is completed.

## 030.4.5 Cooling system

### 030.4.5.1 Checking coolant level in cooling system

Valid for: L508-1817;

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.

#### Checking coolant level




Fig. 148: Checking the coolant level

- 1    Equalising reservoir cap
- 2    Equalising reservoir
- 3    Maximum coolant level
- 4    Minimum coolant level

- ▶ Check coolant level in equalising reservoir 2.
  - ▷ The coolant level must be between the maximum 3 and minimum 4.

LBH12242502/04/211-20210126\_072043/en

**NOTICE**

Incorrect cleaning!  
Damage to diesel engine.

- ▶ When cleaning with engine bonnet open, close opening to air filter system so is it watertight.

**NOTICE**

Incorrect cleaning!  
Damage to the cooling system.

- ▶ Do not use hard objects or excessive water pressure.




Fig. 157: Cleaning cooling system

- |   |             |   |                         |
|---|-------------|---|-------------------------|
| 1 | Cooler unit | 3 | Condenser unit (option) |
| 2 | Fuel cooler |   |                         |

- ▶ Clean cooler units 1, fuel cooler 2 and condenser unit 3 with a high-pressure cleaner or compressed air.

#### 030.4.5.4 Cooling system: changing coolant

Valid for: L508-1817;

Make sure the following preconditions are met:

- Machine is cold.
- Machine is in maintenance position 1.
- Service access is open.

Make sure that following tools are ready:

- Drain hose
- Receptacle (12 l)

Make sure that following consumables are ready:

- Coolant as specified in table. (For more information see: 030.2.2 Fuel and operating fluid filling quantity, page 030-13)

**Note**

Information on coolant specification:

- ▶ See "Lubricants and fuels: Diesel engine coolants". (For more information see: 030.3.7 Coolant, page 030-17)

- ▶ Mount guard **5** with fastening bolts **4**.
- ▶ Top up oil.

### Topping up oil




Fig. 167: Topping up oil

- |  |   |
|--|---|
| <p><b>1</b> Breather filter with filler strainer</p> <p><b>2</b> Plug connection</p> | <p><b>MIN</b> Minimum oil level</p> <p><b>MAX</b> Maximum oil level</p> |
|--|---|

#### NOTICE

Contamination in hydraulic oil!  
Damage to hydraulics.

- ▶ Always top up oil through filler strainer into hydraulic tank.

- ▶ Fill oil through filler strainer **1** into hydraulic tank up to maximum oil level **MAX**.
- ▶ Screw on breather filter **1** and tighten it.
- ▶ Start diesel engine.
- ▶ At medium engine speed, operate all functions of working hydraulics to their furthest extent.
  - ▷ Oil is circulated.
- ▶ Put machine in maintenance position 1.
- ▶ Unscrew bleeder filter **1**.
- ▶ Fill oil through filler strainer **1** into hydraulic tank until oil level is between minimum **MIN** and maximum **MAX**.
- ▶ Screw on breather filter **1** and tighten it.
- ▶ Pull out plug connection **2** and keep it in a safe place.
  - ▷ Breather filter **1** is protected from accidental opening.




Fig. 178: Changing the travel direction switch

1 Rocker

2 Seal

---

#### NOTICE

Thin seal!  
Damage to the seal.

▶ Do not put in the screwdriver more than 5 mm.

- 
- ▶ Insert tip of a small screwdriver between rocker **1** and travel direction switch below the central axis.
  - ▶ Prise out rocker.
  - ▶ Check seal **2** for damage.

If seal is damaged:

- ▶ Replace travel direction switch.
- ▶ Fit a new rocker on the travel direction switch.

#### Changing push button covering (option)

Make sure the following preconditions are met:

- Machine is in maintenance position 1.




Fig. 188: Checking drive shafts

- 1 Universal joint (2x)
- 2 Extension

► Check drive shaft for play in universal joints 1 and extension 2.



**Note**

There may not be any play at all in universal joints and extension.

If there is play in a universal joint 1 or extension 2:

► Replace drive shaft.

**030.4.11.5 Tyres: checking tyre pressure**

Valid for: L508-1817;

Make sure the following preconditions are met:

- Machine is in maintenance position 1.
- You have the recommended tyre pressures from the manufacturer or dealer at hand.




Fig. 189: Tyres: checking tyre pressure

LBH/12242502/04/211-20210126\_072043/en




Fig. 200: Safety belt: checking condition and function

- |   |       |   |               |
|---|-------|---|---------------|
| 1 | Strap | 3 | Unlock button |
| 2 | Lug   | 4 | Belt lock     |

- ▶ Check operator's seat safety belt for proper function and damage.
- ▶ Replace damaged parts.

#### 030.4.14.4 Windscreen washer system: testing

Valid for: L508-1817;

Make sure that following requirements are fulfilled:

- The machine is parked in a safe place.
- The electrical system of the machine is switched on.

**To check the front windscreen washer system:**

- ▶ Activate the windscreen washer system using the steering column switch.
  - ▷ Washer fluid is squirted onto the front windscreen.
  - ▷ The windscreen wiper is switched on.

**To check rear windscreen washer system:**


- ▶ Activate the windscreen washer system using the switch.
  - ▷ Washer fluid is sprayed onto the rear windscreen.
  - ▷ The windscreen wiper is switched on.

#### 030.4.14.5 Windscreen washer system: filling windscreen washer fluid

Valid for: L508-1817;

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 1.
- Service access is open.



G2061003

Fig. 211: Central lubrication system: checking level in grease reservoir

- |   |                                   |   |                                 |
|---|-----------------------------------|---|---------------------------------|
| 1 | Central lubrication system button | 4 | Filling coupling (fast filling) |
| 2 | Grease reservoir                  | 5 | Fast filling pump               |
| 3 | Grease fitting                    |   |                                 |

- ▶ Visually check the level in the grease reservoir 2.
  - ▷ It must be within the minimum and maximum lubricant levels.



#### Note

Mixing of lubricant greases!  
Malfunction in central lubrication system.

- ▶ Ensure proper miscibility of lubricant greases.
- ▶ If necessary, contact **Liebherr Lubricant Hotline**.

#### NOTICE

Dirty grease reservoir!  
Damage to the central lubrication system.

- ▶ Pay attention to cleanliness when filling the grease reservoir.

To fill grease reservoir:

- ▶ Fill grease reservoir via grease fitting 3.

or

for rapid filling, connect the fast filling pump 5 to the filling coupling 4.

### 030.4.15.2 Central lubrication system: checking pipes, hoses and lubrication points for leaks and damage.

Valid for: L508-1817;

This equipment is optional.

Make sure the following preconditions are met:

- Machine is in maintenance position 2.




Fig. 216: Connect the SMARTASSIST-Direct diagnostics software to the diesel engine.

- |   |                                  |   |                     |
|---|----------------------------------|---|---------------------|
| 1 | ECU Access tab                   | 4 | Engine function     |
| 2 | Diagnostics (Execution) function | 5 | ECU Search function |
| 3 | Data Rate function               | 6 | Start function      |

- ▶ Select the ECU Access tab 1.
- ▶ Select the Diagnostics (Execution) function 2.
- ▶ For the Data Rate function 3 select a connection speed of 250k.
- ▶ Select the Engine function 4.
- ▶ Select the ECU Search function 5.
  - ▷ A connection is made to the engine control unit (ECU).
- ▶ Select the Start function 6.
  - ▷ The "Diagnostics" screen opens.




Fig. 217: "Diagnostics" screen

- |   |                        |   |                    |
|---|------------------------|---|--------------------|
| 1 | ECU DATA SAVE function | 2 | Main Menu function |
|---|------------------------|---|--------------------|

- ▶ Select the ECU DATA SAVE function 1.
  - ▷ Data is loaded by the engine and saved internally in the SMARTASSIST-Direct diagnostic software.
- ▶ Select the Main Menu function 2.
  - ▷ The "Main Menu" screen opens.

LBH/12242502/04/211-20210126\_072043/en




Fig. 233: Transferring setting data of old engine control unit

- |   |                            |   |   |
|---|----------------------------|---|---|
| 1 | Write (PC to ECU) function | 4 | Setting data of old engine control unit |
| 2 | Old ECU data function      | 5 | Next function                           |
| 3 | Next function              |   |   |

- ▶ Select Write (PC to ECU) function 1.
- ▶ Select Old ECU data function 2.
- ▶ Select Next function 3.
- ▶ Select setting data of old engine control unit 4.
- ▶ Select Next function 5.




Fig. 234: Transferring setting data of old engine control unit

- |   |               |   |              |
|---|---------------|---|--------------|
| 1 | Next function | 3 | Password     |
| 2 | User number   | 4 | Set function |

- ▶ Select Next function 1.

For security reasons, transmission of setting data must be confirmed by entering password 3.

- ▶ Enter password 3.
- ▶ Select Set function 4.
  - ▷ Setting data is transferred.

LBH12242502/04/211-20210126\_072043/en

- ▶ Check the routing of the hydraulic line, correct if necessary.

If the condition deteriorates:

- ▶ Replace the hydraulic lines.

#### **Moist surfaces, no visible oil leak**

Moist spots can be seen on the surface. An oil leak or oil drops are not visible. As long as you do not observe an obvious oil leak, it is classified as minor damage.



*Fig. 242: Moist surfaces, no visible oil leak*

- ▶ Document the damage and observe whether the condition deteriorates.

If the condition deteriorates:

- ▶ Replace the hydraulic lines.

#### **Medium damage to the hydraulic lines**

##### **Cracks or cuts up to the steel fabric or steel fabric exposed due to damage to the outer jacket**

The damage to the outer jacket (such as cracks, cuts or abrasions) through which the steel fabric is exposed is classified as medium damage if the steel fabric is undamaged. Damage to the steel fabric is classified as severe damage.

- ▶ Connect a pressure gauge (600 bar) to high pressure test connection **MH** on travel pump.
- ▶ Start diesel engine.

**DANGER**

Unintentional movement of the machine!  
Fatal injury.

- ▶ Make sure there is nobody in danger area.
- ▶ Be ready to brake.

- ▶ Select forward travel direction.
- ▶ Carefully increase diesel engine speed until travel high pressure **MH** is exactly 400 bar.
- ▶ Check that diesel engine speed matches specified value.

Description	Unit	Value
Engine speed at high pressure of 400 bar	rpm	1650 $\pm 100$

If required value is not reached:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Adjust eccentric adjusting screw **1**.

**Note**

Position of control lens **5** is adjusted with cam **2** of eccentric adjusting screw **1**.

- ▶ Check position of cam **2** using monitoring groove **4**.

- ▶ Repeat check and adjustment until required value is reached.

If required value is reached:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Disconnect pressure gauge from high pressure test connection **MH**.

### 030.6.6.5 Travel pump: high pressure relief valves

Valid for: L508-1817;

**Note**

Opening pressure of high pressure relief valves is above opening pressure of pressure cut-off.

- ▶ Before testing, set pressure cut-off to a higher value. (For more information see: [Preparations, page 030-186](#))

Make sure that following requirements are fulfilled:

- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.
- Machine is in blocked condition.
- Service access is open.

Make sure that following tools are ready:

- Laptop with Sculi diagnostic software
- Pressure gauge (600 bar)

To save the setting:

- ▶ Press the button for 1 second in save mode:
  - ▷ The setting is saved.

**After setting the service hours:**

- ▶ Attach the rubber sleeve **2**.
- ▶ Mount the display.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 2.8 Oil pump




Fig. 265: Oil pump

- |   |                      |   |               |
|---|----------------------|---|---------------|
| 1 | Drive gear           | 4 | Internal gear |
| 2 | Outer gear rim       | 5 | Cover plate   |
| 3 | Transmission housing |   |               |

Oil pump is situated in front transmission housing 3. It is driven by same transmission as camshaft and fuel injection pump.

Oil pump is an internal gear pump. Oil flows between internal gear 4 and outer gear rim 2. Teeth of internal gear mesh with those of outer gear rim. This displaces oil and builds up pressure.

### 040.1.4.3 Vacuum switch for air filter

Valid for: L508-1817;

#### 1.1 Layout




Fig. 276: Vacuum switch for air filter with symbol

- |   |                                 |   |        |
|---|---------------------------------|---|--------|
| 1 | Air filter                      | 3 | Symbol |
| 2 | Vacuum switch for air filter B4 |   |        |

Air filter vacuum switch 2 is fitted on air filter 1.

#### 2.1 Function



Air filter vacuum switch 2 monitors pressure behind air filter 1 and is an N/O contact. It triggers air filter contamination symbol in display when filters are dirty (excessive vacuum detected).

When there is neutral pressure, vacuum switch is open and closes when vacuum reaches 54 mbar.

### 040.1.5 Exhaust system

## 050.2 Cooler

### 050.2.1 Water cooler

Valid for: L508-1817;

#### 1 Layout




Fig. 293: Water cooler

- |   |                                 |   |              |
|---|---------------------------------|---|--------------|
| 1 | Water cooler                    | 4 | Thermostat   |
| 2 | Cooler cover                    | 5 | Coolant pump |
| 3 | Equalising reservoir connection |   |              |

The water cooler 1 is integrated in the cooler mount.

A serpentine pipe runs through the water cooler to which the cooler fins are attached. The surface of the pipe is thereby increased and the cooling output accordingly improved.

The cooler cover 2 and the equalising reservoir 3 are located at the highest point.

#### 2 Function

##### 2.1 Basic function

When the coolant temperature reaches 71 °C, the thermostat 4 opens. When the coolant temperature reaches 85 °C, the thermostat is completely opened. The hot coolant flows through the water cooler 1.

The fan draws ambient air in through the water cooler. The cooler fins transfer the heat from the coolant into the air.

The water pump 5 draws in the cooled coolant once more.

### 2.2 Priority valve




Fig. 302: Priority valve with steering not actuated / priority valve with steering actuated

- |   |                                    |   |                                    |   |                         |
|---|------------------------------------|---|------------------------------------|---|-------------------------|
| 1 | Oil supply for control valve block | 3 | Load sensing signal from servostat | 5 | Connection to gear pump |
| 2 | Priority valve                     | 4 | Oil supply to servostat            |   |                         |

Priority valve 2 distributes oil supplied by gear pump 5 to following systems:

- Steering system
- Working hydraulics

The oil supply for the steering system has priority.

If working hydraulics and steering system are not actuated, readjusting spring sets priority valve 2 so that oil from gear pump 5 flows to servostat 4. If pressure in steering system exceeds spring force of readjusting spring, this pressure pushes priority valve 2 back against spring force of spring. As a result, oil flows to control block 1. However, once pressure in steering system drops below spring force of readjusting spring, priority valve 2 opens again to steering system. For this reason, there is always a standby pressure at servostat 4. Due to this standby pressure, steering movement begins immediately when servostat is actuated.

When the servostat 4 is actuated, it generates a load sensing signal 3. This load sensing signal 3 moves priority valve 2 so that pressure in steering system corresponds to that of load sensing signal 3.

Oil that is not needed by steering system is directed by priority valve 2 to control block 1 and therefore working hydraulics.

LBH12242502/04/211-20210126\_072043/en

sah02518

Feeder valves **2** prevent cavitation during rapid working movements by allowing oil to flow from tank side **2** to consumer **1** via feeder valves **3**. Cavitation occurs, for example when quickly lowering lift arms with a full bucket, because lift arms are lowered by their own weight.

### 2.6 Working hydraulics lockout




Fig. 315: Working hydraulics lockout activated / working hydraulics lockout deactivated (example: spool for tilt cylinder)

1 Pin

2 Spool valve

BMK	Function
S2a.X103	Retaining magnet for working hydraulics lockout (tilt cylinder)

Tab. 96: Equipment codes

Spool for tilt cylinder and spool for lift cylinder are equipped with an electromechanical working hydraulics lockout. If working hydraulics lockout is activated, retaining magnets S2a.X103 and S2a.X102 are de-energised. As a result, compression springs push pins **1** in recess in spools **2**, blocking them mechanically.

3rd function is not secured.

### 2.7 3rd function, 4th function

3rd function is actuated by additional control lever.

If control lever lock function is activated, spool for 3rd function of retaining magnets for control lever lock S2a.X104 is kept in front position.

Since control block is not expandable, 4th function can exclusively be realised via comfort control option. (For more information see: 060.6.1 4. Function with comfort control – overview, page 060-32)

LBH12242502/04/211-20210126\_072043/en

<b>15</b> Steel tank	<b>39</b> Diesel engine	<b>61</b> Lift cylinder
<b>16</b> Sight glass for hydraulic oil level	<b>40</b> Check valve	<b>62</b> Tilt cylinder
<b>17</b> Hydraulic oil drain valve	<b>41</b> Pilot control hydro accumulator	<b>63</b> Quick coupler for 3rd function (2x)
<b>18</b> Replenishing pump suction port	<b>45</b> <b>Control block for 3rd function with electrohydraulic pilot control</b>	<b>64</b> Open solenoid valve for quick coupler
<b>19</b> Travel pump leak oil	<b>46</b> Primary pressure relief valve	<b>65</b> Quick coupler locking hydraulic cylinder

Name	Test point
PA	Working hydraulics high pressure

Tab. 104: Test points

BMK	Function	BMK	Function	BMK	Function
<b>B8</b>	Hydraulic oil temperature sensor	<b>Y20</b>	Solenoid for ride control	<b>Y203 a</b>	Proportional solenoid for 3rd function B1
<b>S2a.X 102</b>	Retaining magnet for working hydraulics lockout (lift cylinder)	<b>Y53</b>	Solenoid for opening quick coupler		
<b>S2a.X 103</b>	Retaining magnet for working hydraulics lockout (tilt cylinder)	<b>Y203</b>	Proportional solenoid for 3rd function A1		

Tab. 105: Equipment codes

If 3rd function has electrohydraulic pilot control, spool for 3rd function **48** is moved with oil from replenishing pump **36**.

## 060.5.2 Control block for 3rd function with electrohydraulic pilot control

Valid for: L508-1817;

This equipment is optional.

<b>5</b>	Inlet valve 0.03 bar	<b>20</b>	Return flow from inching valve	<b>42</b>	Throttle for setting flow rate
<b>6</b>	Filler strainer 800 µm	<b>21</b>	Return flow from servostat	<b>43</b>	Throttle
<b>7</b>	<b>Return suction filter</b>	<b>25</b>	<b>Working pump</b>	<b>44</b>	Solenoid valve for regulated flow rate
<b>8</b>	Temperature valve	<b>26</b>	Gear pump	<b>45</b>	Pressure relief valve for setting delivery pressure
<b>9</b>	Throttle	<b>27</b>	Priority valve	<b>46</b>	Control block
<b>10</b>	Filter element 10 µm	<b>28</b>	Throttle 1	<b>50</b>	<b>Double check valve</b>
<b>11</b>	Strainer for replenishing pump	<b>29</b>	Throttle 2	<b>51</b>	Check valve 8.0 bar
<b>12</b>	Preload valve 0.5 bar	<b>30</b>	Load sensing signal from servostat	<b>52</b>	Check valve 0.5 bar
<b>13</b>	Feeder valve	<b>31</b>	Oil supply to servostat	<b>53</b>	Quick coupling for oil supply with rear accessory kit
<b>14</b>	Bypass valve 2.5 bar	<b>35</b>	Travel pump	<b>54</b>	Quick coupling for return flow with rear accessory kit
<b>15</b>	Steel tank	<b>36</b>	Diesel engine		

Name	Test point
PA	Working hydraulics high pressure

Tab. 113: Test points

BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	Y230	Solenoid for regulated flow rate

Tab. 114: Equipment codes

Regulated flow rate option limits oil flow to rear accessory kit to a pre-set value. Flow rate and pressure are independent of diesel engine speed. This ensures a constant ejection during operation of a spreader.

Working pump **25** draws oil from hydraulic tank **1** and pumps it to valve block for regulated flow rate **40**.

If regulated flow rate function is not activated, solenoid valve for regulated flow rate **44** is de-energised. As a result, priority valve **41** to hydraulic tank **1** is relieved. Delivery pressure moves priority valve **41** against spring force of readjusting spring. Majority of oil flows to control block **46**. For connection for rear accessory kit **53**, a greatly throttled quantity of oil now flows. Since oil primarily flows to control block **46** due to low resistance, at connection for rear accessory kit **53**, pressure is hardly present and preloaded check valve 8.0 bar **51** separates oil supply for rear accessory kit.

If regulated flow rate function is , solenoid valve for regulated flow rate **44** is energised. As a result, priority valve **41** regulates oil current to rear accessory kit **53** to set value.

Check valve 0.5 bar **52** is installed, since when connecting attachment on quick coupling **53**, a small amount of oil must escape from line, so that locking of quick coupling **53** can be opened.

- Travel motor (For more information see: 070.3.1 Travel motor, page 070-20)
- Inching valve (For more information see: Inching valve, page 100-12)
- Hydraulic oil cooler (For more information see: 050.2.2 Hydraulic oil cooler, page 050-5)

**2 Function**

**2.1 Basic function**




Fig. 338: Diagram of travel hydraulics (forward travel direction)

- |                                 |  |   |
|---------------------------------|--|---|
| <b>1 Hydraulic tank</b>         | <b>20</b> Return flow from stabilization module (option) | <b>42</b> Swivel restrictor 0.8 mm            |
| <b>2 Breather filter</b>        | <b>21</b> Return flow from servostat                     | <b>43</b> Diesel engine                       |
| <b>3</b> Fine filter            | <b>25</b> Travel pump                                    | <b>45</b> Travel motor                        |
| <b>4</b> Outlet valve 0.35 bar  | <b>26</b> Replenishing pump                              | <b>46</b> Axial piston rotary group           |
| <b>5</b> Inlet valve 0.03 bar   | <b>27</b> Towing bypass valve                            | <b>47</b> Check valve                         |
| <b>6</b> Filler strainer 800 µm | <b>28</b> Shuttle valve                                  | <b>48</b> Check valve                         |
| <b>7</b> Return suction filter  | <b>29</b> Pressure cut-off valve                         | <b>49</b> Travel direction solenoid valve     |
| <b>8</b> Temperature valve      | <b>30</b> Swivel restrictor 1.6 mm                       | <b>50</b> Solenoid valve for 1st travel range |
| <b>9</b> Throttle               | <b>31</b> Control valve                                  | <b>51</b> Spool                               |

See next page for continuation of the image legend

LBH12242502/04/211-20210126\_072043/en

### 2.3 Replenishing pressure relief valve




Fig. 347: Replenishing pressure relief valve

- |   |                                    |   |                                |
|---|------------------------------------|---|--------------------------------|
| 1 | Replenishing pressure relief valve | 3 | Connection to pump housing     |
| 2 | Compression spring                 | 4 | Oil from the replenishing pump |

Replenishing pressure relief valve 1 performs following tasks:

- Limiting replenishing pressure
- Draining excess oil from the replenishing pump 4 into the pump housing 3 of travel pump

With the diesel engine running, the oil flows continuously via the replenishing pressure relief valve 1 into the pump housing 3 of travel pump and from there into the hydraulic tank. This cools the travel pump.

### 2.4 Variable displacement pump




Fig. 348: Variable displacement pump (forward travel direction)

- |   |                    |   |                 |
|---|--------------------|---|-----------------|
| 1 | Drive shaft        | 7 | Piston          |
| 2 | Swivel plate       | 8 | Sliding bushing |
| 3 | Positioning piston | 9 | Glide shoe      |

See next page for continuation of the image legend

LBH12242502/04/211-20210126\_072043/en

- 9 Oil supply from travel pump  
(forward travel direction high pressure)

Name	Test point
M1	Travel motor servo pressure

Tab. 136: Test points

BMK	Function	BMK	Function
Y6	Travel range 1 solenoid	Y26	Travel direction solenoid (travel motor)

Tab. 137: Equipment codes

**2 Function**




Fig. 357: Travel motor: hydraulic diagram (diesel engine is running)

- 1 Travel motor
- 2 Axial piston rotary group
- 3 Check valve
- 4 Check valve
- 5 Travel direction solenoid valve
- 6 Solenoid valve for 1st travel range
- 7 Spool
- 8 Throttle check valve
- 9 Positioning piston
- 10 Discharge valve
- 11 Orifice 1.4 mm
- 12 Pressure relief valve
- 13 Oil supply from travel pump (reverse travel direction high pressure)
- 14 Leak oil from travel pump
- 15 Leak oil to hydraulic oil cooler
- 16 Control pressure from travel pump
- 17 Oil supply from travel pump (forward travel direction high pressure)

Name	Test point
M1	Travel motor servo pressure

Tab. 138: Test points

LBH/12242502/04/211-20210126\_072043/en

# 080 Hydraulic components

## Contents

080.1	Hydraulic system – overview <i>L508-1817;</i>	080-2
080.2	Hydraulic tank	080-4
080.2.1	Overview of hydraulic tank <i>L508-1817;</i>	080-4
080.2.2	Return suction filter <i>L508-1817;</i>	080-6
080.2.3	Breather filter <i>L508-1817;</i>	080-12

### 2.4 Bypass valve




Fig. 372: Bypass valve

- |   |                      |   |                          |
|---|----------------------|---|--------------------------|
| 1 | Filter element 10 µm | 3 | Bypass valve             |
| 2 | Filter housing       | 4 | Connection to steel tank |

Bypass valve 3 protects system from excessive pressure.

If not enough hydraulic oil passes through filter element because oil is cold or filter element 1 is clogged, some of oil flows unfiltered via bypass valve 3 directly into steel tank 4. This prevents hydraulic components being damaged.

### 2.5 Temperature valve




Fig. 373: Temperature valve with cold hydraulic oil / temperature valve with hot hydraulic oil.

- |   |  |   |                                    |   |              |
|---|--|---|------------------------------------|---|--------------|
| 1 | Leak oil from travel pump and travel motor         | 4 | Bypass channel (closed at one end) | 7 | Valve sleeve |
| 2 | Compression spring                                 | 5 | Connection to filter housing       | 8 | Pin          |
| 3 | Bypass channel with restrictor (closed at one end) | 6 | Temperature element                |   |              |

Leak oil connections from travel pump and travel motor 1 are connected with hydraulic oil cooler and, via temperature valve, return-suction filter.

LBH/12242502/04/211-20210126\_072043/en

## 2.2 Secondary pressure relief valves

Secondary pressure relief valves **12** and **13** protect steering system from excessive pressure caused by pressure peaks and external force.

## 2.3 Feeder valves

The feeder valves **10** and **11** protect the steering cylinders from cavitation.

## 2.4 LS pressure relief valve

LS pressure relief valve **14** protects steering system from excessive pressure by limiting load sensing pressure **19** of steering system. If pump pressure **18** exceeds maximum permitted value, it pushes priority valve in control valve block against (limited) load sensing pressure of steering system **19**. Priority valve then directs some of the oil to the control block, which drains surplus oil to hydraulic tank.

## 2.5 Emergency steering function




Fig. 382: Emergency steering function: hydraulic diagram (steering to left)

- |  |   |
|--|---|
| <b>1</b> Servostat   | <b>8</b> Chamber isolation for steering right (emergency steering function) |
| <b>2</b> Valve spool   | <b>9</b> Check valve  |
| <b>3</b> Emergency steering feeder valve                                   | <b>10</b> Return flow to return suction filter                              |
| <b>4</b> Metering pump   | <b>11</b> Oil supply from working pump                                      |
| <b>5</b> Check valve   | <b>12</b> Connection for steering to the right                              |
| <b>6</b> Chamber isolation for steering left (emergency steering function) | <b>13</b> Connection for steering to left                                   |
| <b>7</b> Check valve   |   |

Servostat **1** includes an emergency steering function. If the oil supply from the working pump fails **11** it allows a limited range of steering movements.

## 2.2 Adjuster




Fig. 391: Adjuster when turning clockwise (top view)

- |   |                                       |    |   |
|---|---------------------------------------|----|---|
| 1 | Right brake shoe                      | 7  | Adjuster lever for anticlockwise rotation |
| 2 | Threaded pin for left brake shoe      | 8  | Threaded pin for right brake shoe         |
| 3 | Adjuster lever for clockwise rotation | 9  | Left brake shoe                           |
| 4 | Recess for adjuster                   | 10 | Adjuster disc                             |
| 5 | Adjuster pivot point                  | 11 | Clasp                                     |
| 6 | Adjuster tube                         | 12 | Compression spring                        |

Adjuster prevents gap from exceeding 0.5 mm.

If brake drum is turning clockwise during braking, right brake shoe 1 is pushed against adjuster.

If brake drum is turning anticlockwise during braking, left brake shoe 9 is pushed against adjuster.

Brake shoe 9 pushes against adjuster and thus moves adjuster tube 6 towards compression spring 12. Adjuster disc 10 moves along with adjuster tube 6. Adjuster disc 10 thus presses against recess in adjuster lever 4 and turns lever around pivot point 5.

At same time, clasp 11 pushes end of adjuster lever 3 against teeth on adjuster tube 6.

Distance adjuster tube 6 moves while braking depends on brake lining gap. Of adjuster tube 6 move too far because gap is too big, adjuster lever 3 moves so far that end of it jumps on one more tooth.

If brake is then released, compression spring 12 pushes adjuster tube 6 back to its initial position. Adjuster lever 3 also moves back to its initial position. Adjuster lever 3 turns on adjuster tube 6, thus unscrewing two threaded pins 2 and 8.

BMK	Function	BMK	Function
F01	Main fuse	Mp5a	Grounding point
F02	Fuse for starter	Mp6	Grounding point
F03	Fuse for pre-heat system	X44	Diagnostic plug for engine
F07a	Hazard warning system fuse	Y2	Forward travel direction solenoid valve
F200	Engine terminal 30 fuse	Y3	Reverse travel direction solenoid valve
F201	Exhaust gas recirculation fuse	Y6	Travel range 1 solenoid valve
G2a	Battery	Y26	Travel motor direction solenoid valve
H40	Warning buzzer	Y53	Quick coupler solenoid valve

Tab. 158: Component designations

### 2.1 Other electrical components




Fig. 404: Other electrical components

BMK	Function	BMK	Function
B5	Parking brake switch	S2a.X102	Retaining magnet for working hydraulics lockout (lift cylinder)
B12	Brake light pressure switch	S2a.X103	Retaining magnet for working hydraulics lockout (tilt cylinder)
R5	Accelerator pedal angle sensor	S2a.X104	Retaining magnet for control lever lock (option)
S2	Control lever		

Tab. 159: Component designations

LBH/12242502/04/211-20210126\_072043/en

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-E1.X3.S_a *	=H	+H	OPTION FRONT SECTION SOCKET	=K	+K	FUSE LIGHTING LEFT	/21.B4
-E1.X4	=B	+B1	CONNECTOR REVERSING HEADLIGHT RIGHT	=K	+K	FUSE LIGHTING RIGHT	/21.B5
-E1.X5	=B	+B1	CONNECTOR REVERSING HEADLIGHT RIGHT	=K	+K	FUSE LIGHTING RIGHT	/21.B5
-E2	=K	+K3	INTERIOR ILLUMINATION	=K	+K	FUSE LIGHTING LEFT	/21.B4
-E2.X1	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	=K	+K	FUSE LIGHTING RIGHT	/21.B5
-E2.X2	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	=K	+K	FUSE LIGHTING LEFT	/21.B4
-E2.X3	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	=K	+K	FUSE RADIO SEAT COMPRESSOR 12V SOCKET	/25.C2
-E3	=V	+V1	DRIVING HEADLIGHT FRONT LEFT	=K	+K	FUSE REAR WINDOW HEATER	/26.C1
-E3.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT FRONT LEFT	=B	+B1	FUSE T. 30 FUSE BOARD	/12.E2
-E4	=V	+V1	DRIVING HEADLIGHT FRONT RIGHT	=B	+B1	CONNECTION FUSE BOX	/12.E2
-E4.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT FRONT RIGHT	=B	+B1	FUSE DIESEL ENGINE ACTIVE	/12.E2
-E5	=B	+B2	REVERSING HEADLIGHT LEFT	=B	+B1	CONNECTOR FUSE DIESEL ENGINE ACTIVE	/12.E2
-E5.X1	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	=B	+B1	FUSE PRE-HEAT SYSTEM	/12.E3
-E5.X2	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	=B	+B1	CONNECTOR FUSE PRE-HEAT SYSTEM	/12.E3
-E5.X3	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	=B	+B1	OPTION FUSE TELEMATICS SYSTEM	/12.E3
-E5.X3.B	=H	+H	CONNECTOR REVERSING HEADLIGHT	=B	+B1	CONNECTOR FUSE OPTION TELEMATICS SYSTEM	/12.E3
-E5.X3.B_a *	=H	+H	OPTION FRONT SECTION SOCKET	=B	+B2	FUSE HAZARD WARNING SYSTEM	/18.C1
-E5.X3.S_a *	=H	+H	OPTION FRONT SECTION SOCKET	=K	+K	FUSE PARKING BRAKE	/30.F2
-E5.X4	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	=K	+K	FUSES REAR WINDOW HEATER	/26.C6
-E5.X4.B	=H	+H	CONNECTOR REVERSING HEADLIGHT	=K	+K	FUSE SWITCH LIGHTING	/17.C5
-E5.X5	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	=K	+K	FUSE REGULATED FLOW RATE	/54.A1
-E10	=K	+K3	WORKING HEADLIGHT FRONT LEFT	=K	+K	FUSE DPF REGENERATION	/31.D1
-E10.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT LEFT	=K	+K	FUSE SENSORS	/17.D3
-E11	=K	+K3	WORKING HEADLIGHT FRONT LEFT	=K	+K4	FUSE TERMINAL 15	/34.D2
-E11.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT LEFT	=K	+K	FUSE STARTER	/29.B3
-E12	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	=K	+K	FUSE RESERVE T. 15	/33.D3
-E12.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	=K	+K	FUSE WINDSCREEN WIPER REAR	/19.B4
-E13	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	=K	+K	FUSE HEATING AND AIR CONDITIONING SYSTEM	/27.E7
-E13.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	=K	+K	FUSE WINDSCREEN WIPER FRONT HORN	/19.B3
-E141 *	=H	+H1	LICENCE PLATE LIGHT RIGHT	=K	+K	FUSE PARKING LIGHT	/21.E2
-E141.X *	=H	+H1	CONNECTOR LICENCE PLATE LIGHT RIGHT	=K	+K	FUSE CENTRAL LUBRICATION SYSTEM	/58.B4
-E141r *	=H	+H1	LICENCE PLATE LIGHT LEFT	=K	+K	RESERVE FUSE	/33.D5
-E141r.X *	=H	+H1	CONNECTOR LICENCE PLATE LIGHT LEFT	=K	+K	FUSE OPTION PIPE BREAK PROTECTION OPERATOR'S CAB FAN	/58.B5
-E701	=K	+K4	DPF REGENERATION	=K	+K	FUSE BEACON STEERING COLUMN SWITCH	/19.B3
-E701.X	=K	+K4	CONNECTOR DPF REGENERATION	=K	+K	FUSE CENTRAL CONTROL UNIT	/39.A3
-F1	=K	+K	FUSE QUICK COUPLER	=K	+K	FUSE DRIVING HEADLIGHT T. 15	/21.E2

BMK	SYSTEM	LOCATION	FUNCTION	PAGE
-E1.X3.S_a *	=H	+H	OPTION FRONT SECTION SOCKET	/55.B3
-E1.X4	=B	+B1	CONNECTOR REVERSING HEADLIGHT RIGHT	/21.E3
-E1.X5	=B	+B1	CONNECTOR REVERSING HEADLIGHT RIGHT	/21.E3
-E2	=K	+K3	INTERIOR ILLUMINATION	/20.D8
-E2.X1	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	/20.D8
-E2.X2	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	/20.E8
-E2.X3	=K	+K3	CONNECTOR INTERIOR ILLUMINATION	/20.E8
-E3	=V	+V1	DRIVING HEADLIGHT FRONT LEFT	/21.E4
-E3.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT FRONT LEFT	/21.E4
-E4	=V	+V1	DRIVING HEADLIGHT FRONT RIGHT	/21.E5
-E4.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT FRONT RIGHT	/21.E5
-E5	=B	+B2	REVERSING HEADLIGHT LEFT	/21.E6
-E5.X1	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	/21.E6
-E5.X2	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	/21.E6
-E5.X3	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	/21.E6
-E5.X3.B	=H	+H	CONNECTOR REVERSING HEADLIGHT	/21.D6
-E5.X3.B_a *	=H	+H	OPTION FRONT SECTION SOCKET	/55.D3
-E5.X3.S_a *	=H	+H	OPTION FRONT SECTION SOCKET	/55.D3
-E5.X4	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	/21.E6
-E5.X4.B	=H	+H	CONNECTOR REVERSING HEADLIGHT	/21.E6
-E5.X5	=B	+B2	CONNECTOR REVERSING HEADLIGHT LEFT	/21.E6
-E10	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/20.D1
-E10.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/20.D1
-E11	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/20.D2
-E11.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/20.D2
-E12	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/20.D7
-E12.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/20.D7
-E13	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/20.D7
-E13.X	=K	+K3	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/20.D7
-E141 *	=H	+H1	LICENCE PLATE LIGHT RIGHT	/21.E7
-E141.X *	=H	+H1	CONNECTOR LICENCE PLATE LIGHT RIGHT	/21.E7
-E141r *	=H	+H1	LICENCE PLATE LIGHT LEFT	/21.E7
-E141r.X *	=H	+H1	CONNECTOR LICENCE PLATE LIGHT LEFT	/21.E7
-E701	=K	+K4	DPF REGENERATION	/31.E4
-E701.X	=K	+K4	CONNECTOR DPF REGENERATION	/31.D4
-F1	=K	+K	FUSE QUICK COUPLER	/29.D8


12829112


ITEM CODE DRAWING INDEX 001

Kompaktlader\_EU\_LUSA 1817 00090 01 00

PROJECT DRAWING NUMBER

ISO 17016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	LIDOS Gerät	SERIAL NUMBER	XXXXX	BMK-INDEX	E-SCHEMA	PAGE	5	OF
								
						CREATION DATE 10.09.2019 10:44		




MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH


CONTROL LEVER  
E-SCHEMA

# RADIO OPERATOR'S SEAT 12V SOCKET



MACHINE TYPE	SERIAL NUMBER	PAGE	OF
LIDOS Gerät	XXXXX	25	8
RADIO OPERATOR'S SEAT 12V SOCKET E-SCHEMA		CREATION DATE	10.09.2019 10:44





12829112  
 001  
 Kompaktlader\_EU\_USA  
 1817 0090 01 00  
 1817 0090 01 00  
 001  
 DRAWING INDEX  
 ITEM CODE  
 PROJECT  
 DRAWING NUMBER

ISO 19018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
 FACTORY LBH


INTERFACE CONNECTOR DIESEL ENGINE X36  
 E-SCHEMA

PAGE 45 OF  
 CREATION DATE 10.09.2019 10:44

1 2 3 4 5 6 7 8

A B C D E F

# OPTION FRONT SECTION SOCKET



MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

OPTION FRONT SECTION SOCKET  
E-SCHEMA







PAGE 55 OF 8  
CREATION DATE 10.09.2019 10:44











PROJECT Kompaktlader\_EU\_USA 1817 00090 01 00  
DRAWING NUMBER 12829112  
ITEM CODE 001  
DRAWING INDEX

ISO 19018: The reproduction is prohibited, distribution and utilisation of this document, All rights reserved in the case of patent, utility model or design registration.

1 2 3 4 5 6 7 8

**SWITCH AND BUTTON ASSIGNMENT**

OPTION	OPTION	OPTION	OPTION	OPTION	OPTION	OPTION	OPTION
S216  9514846 6905595	S45a  6002120 6905592	S205  6905201 6905595	S230  7363088 6905360	S202  6905524 6905592	S9  6000848 6905592	FLASHING LIGHT	CENTRAL LUBRICATION SYSTEM

S700  11651378	S20  6002144 6905592	S19  6905663 6905662	S23  6905320 6905360	S13  6000847 6905598	S58  11100189 6905597		
S4  6000846 6905589	S6  10801495 6905591	S7  6000844 6905592	S8  6000843 6905592				

MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

SWITCH AND BUTTON ASSIGNMENT  
E-SCHEMA

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

### 2.1 Battery




Fig. 414: Battery and fuse holder

- |   |              |   |                 |
|---|--------------|---|-----------------|
| 1 | Battery      | 4 | Electrical lead |
| 2 | Threaded pin | 5 | Insulating nut  |
| 3 | Fuse insert  | 6 | Fuse carrier    |

Battery 1 consists of six cells, each with 2 volts.

The battery is connected to the electrical lines through the fuse holder 6. Electric lines are secured to fuse holder with insulating nuts 5 (tightening torque 10 Nm).

Insulating nut 5 fastens electrical cable via a threaded pin 2 to fuse. At same time, insulating nut separates electrical cable from threaded pin. This separation is necessary, as otherwise, function of fuse is disabled.



**Note**

Insulating nut ensures that electrical cable is separated from threaded pin. Without this separation, electrical cable would be directly connected to positive terminal of battery. Fuse would be bypassed and therefore useless.

- ▶ Always fasten electrical cables to the fuse carrier with the appropriate insulating nuts.
- ▶ Check the insulating nuts for damage and replace them if necessary.

Charge levels				
Acid density at 27 °C	Charge level	Battery voltage	Voltage per cell	Remark
1.28 to 1.26	100%	over 12.60	over 2.10	Battery OK
1.25 to 1.24	75%	12.54 to 12.40	2.10 to 2.07	
1.24 to 1.18	50%	12.40 to 12.18	2.07 to 2.03	Charge battery
1.18 >	25%	12.18 >	2.03 >	Battery not OK

Tab. 168: Table of charge levels

The acid density should be about the same in all 6 cells. If it is much lower in one of the cells, there is probably a short circuit.

When the diesel engine is running, the batteries are charged by the alternator.

LBH/12242502/04/211-20210126\_072043/en

## 2.4 Wheel hub




Fig. 418: Wheel hub: sectional view

- |   |                   |    |                            |
|---|-------------------|----|----------------------------|
| 1 | Axle casing       | 7  | Planetary gear             |
| 2 | Axial face seal   | 8  | Planetary carrier          |
| 3 | Hub               | 9  | Washer for bearing preload |
| 4 | Snap ring         | 10 | Half shaft with sun gear   |
| 5 | Ring gear carrier | 11 | Sliding washer             |
| 6 | Ring gear         | 12 | Oil drain plug             |

There is a planetary gear in wheel hub. Through planetary gear speed is reduced and torque is increased.

Sun gear on half shaft **10** drives three planetary pinions **7**. Planetary pinions **7** rest against ring gear **6**. This causes planetary carrier **8** and hub **3** to rotate.

Ring gear **6** is connected to axle casing **1** via ring gear carrier **5** and accordingly does not rotate.

## 2.5 Drum brake

Drum brake is service brake and parking brake. (For more information see: [100.2.1 Drum brake, page 100-5](#))

Bucket bearing **3** is also sealed against dirt.

## 2 Function

Advantages of Z kinematics:

- Very high torque in loading position, therefore very high breakout force.
- Tilted-out bucket goes into loading position when lowered.
- Fewer moving parts, so requires less maintenance.
- Low weight, therefore high tipping load.

Drawbacks of Z kinematics:

- Low torque at upper lift arm position. Heavy working attachments (such as a timber grabber) can pull out tilt cylinder or prevent equipment from being tilted in again.
- No parallel movement. Bucket tilts out slightly when lifting.

## 160.1 Overview of operator's cab, heating and air conditioning unit

Valid for: L508-1817;

### 1 Layout




Fig. 429: Operator's cab

- |    |  |    |   |
|----|--|----|---|
| 1  | Steering wheel   | 11 | Control lever (S2)  |
| 2  | Steering-column switch (S3)                                | 12 | Display (A10)   |
| 3  | Heating, ventilation and air conditioning nozzles (option) | 13 | 12V socket  |
| 4  | Inching brake pedal  | 14 | Manual inching (R1a) (Option)                                   |
| 5  | Parking brake  | 15 | Heating, ventilation and air conditioning control unit (option) |
| 6  | Storage compartment  | 16 | Starting switch (S1)  |
| 7  | Speaker (B11)  | 17 | Additional control lever (option)                               |
| 8  | Operator's seat  | 18 | Switch panel  |
| 9  | Interior mirror  | 19 | Adjustable arm rest   |
| 10 | Accelerator pedal (R5)                                     |    |   |

### 2.1 Basic function

The operator's cab is mounted on a flexible bearing on the rear section.

The operator's cab is equipped with warm water heating. Optionally, air conditioning can be also installed.

Entry to operator's cab is via cab access and door on left.

If there is a malfunction with the angle encoder, the engine control unit assumes an equivalent voltage. The engine runs at lower idling speed.

## 2.2 Plug assignment

Pin	Function	Pin	Function
A	Sensor 1 output voltage	D	Sensor 2 power supply
B	Sensor 1 earth	E	Sensor 2 earth
C	Sensor 1 power supply	F	Sensor 2 output voltage

Tab. 180: Pin assignment table

## 160.4 Air conditioning

### 160.4.1 Basic function of the air conditioning unit

Valid for: L508-1817;

#### 1 Layout




Fig. 465: Refrigerant circuit

- |   |                                      |    |   |
|---|--------------------------------------|----|---|
| 1 | Air conditioning compressor          | 8  | Evaporator                                |
| 2 | Magnetic coupling                    | 9  | Blower                                    |
| 3 | Condenser                            | 10 | Expansion valve                           |
| 4 | Fan                                  | A  | Liquid/gaseous refrigerant, high pressure |
| 5 | Air conditioning pressure switch B27 | B  | Liquid refrigerant, high pressure         |
| 6 | Dryer                                | C  | Liquid/gaseous refrigerant, low pressure  |
| 7 | Sight glass (optional)               | D  | Gaseous refrigerant, low pressure         |

#### 2 Basic function

The air conditioning compressor **1** takes in the warm gaseous refrigerant and compresses it. Compression heats up the refrigerant.

The generated heat is dissipated in the condenser **3**. Cooling down in condenser causes refrigerant to condense and become liquid.

The refrigerant flows from the condenser to the dryer **6**. Any water residue is removed in dryer to protect expansion valve **10** and evaporator **8** from icing up. The refrigerant flows from the dryer into the expansion valve.

The expansion valve sprays the liquid, pressurised refrigerant into the evaporator.

The refrigerant expands. The expansion reduces the pressure energy in the refrigerant and quickly cools the evaporator.

# 170 Lubrication system

## Contents

170.1	Liebherr automatic central lubrication system	170-2
170.1.1	Automatic central lubrication system: overview <i>L508-1817;</i>	170-2
170.1.2	Central lubrication pump EP-1 <i>L508-1817;</i>	170-6
170.1.3	Progressive distributor MX-F <i>L508-1817;</i>	170-9

After the piston **III** is moved, the lubricant flows to the left side of the piston **I** (piston position **C**). The piston **I** moves to the right and presses the lubricant out of the right pressure chamber of the piston to outlet **4**.

Then the pistons **II** and **III** pump the lubricant to the outlets **5** and **6**.

After the piston **III** moves, the lubricant flows back to the right side of the piston **I** (piston position **A**) and a new cycle of the progressive distributor starts. This function is repeated for as long as lubricant is pumped to the progressive distributor.

### 2.1.1 Effects of malfunctions

Malfunctions can occur in the network of lubrication lines or in the distributor.

Malfunctions include:

- Blocked lubrication lines
- Twisted split bushings

These malfunctions interrupt the flow of lubricant. This blocks the distributor.

When the distributor is blocked, lubricant escapes via the pressure relief valve of the central lubrication pump.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL