

en

Service manual

Wheel loader

Document ID

Order number: 11835199
Issued: 01-2020
Version: 19
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 566-1484

Contact

Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

020.13.2	Air conditioning pressure switch <i>L566-1484;</i>	020-43
020.14	Lubrication system	020-44
020.14.1	Central lubrication system (Liebherr) <i>L566-1484;</i>	020-44
020.14.1.1	Central lubrication pump	020-44
020.14.1.2	Progressive distributor	020-44
020.14.2	Progressive distributor <i>L566-1484;</i>	020-45
020.14.2.1	MX-F	020-45
020.14.2.2	MX-F 25	020-45
020.14.2.3	MX-F 45	020-46
020.14.2.4	MX-F 75	020-46
020.14.2.5	MX-F105	020-46
020.14.3	Progressive distributor SXE-2 <i>L566-1484;</i>	020-46
020.14.3.1	SXE-2 / MX-F	020-46
020.14.3.2	SXE-2 100	020-46
020.14.3.3	SXE-2 150	020-47
020.14.3.4	SXE-2 220	020-47
020.14.3.5	SXE-2 400	020-47
020.14.3.6	SXE-2 760	020-47

030	Maintenance	030-1
030.1	Maintenance and inspection schedule	030-11
030.2	Filling quantities and lubrication chart	030-16
030.2.1	Recommended lubricants <i>L566-1484;</i>	030-16
030.2.2	Recommended operating fluids <i>L566-1484;</i>	030-17
030.3	Lubricants and fuels	030-18
030.3.1	General information on lubricants and fuels	030-18
030.3.1.1	General questions	030-18
030.3.1.2	Safety data sheets	030-18
030.3.1.3	Technical data sheets	030-18
030.3.1.4	Specific Liebherr standards	030-18
030.3.2	General information on changing lubricants and fuels	030-18

	030.6.10.5	Transmission control unit (TCU): Software update <i>L566-1484;</i>	030-262
030.6.11	Axles and drive shafts		030-265
	030.6.11.1	Tyres: setting radius <i>L566-1484;</i>	030-265
030.6.12	Working attachment		030-266
	030.6.12.1	Valve block for quick coupler (option): Pressure reducing valve <i>L566-1484;</i>	030-266
	030.6.12.2	Parameters for lift arm geometry <i>L566-1484;</i>	030-267
	030.6.12.3	Working attachment: automatic return of 3rd function <i>L566-1484;</i>	030-269
030.6.13	Operator's cab, heating and air conditioning		030-269
	030.6.13.1	Checking the pressure and temperature conditions of the air conditioning unit <i>L566-1484;</i>	030-269
	030.6.13.2	Calibrating the display (Display4) <i>L566-1484;</i>	030-270
	030.6.13.3	Formatting the display and reinstalling the software (Display4) <i>L566-1484;</i>	030-272
030.6.14	Options		030-273
	030.6.14.1	Checking the LiDAT connection status <i>L566-1484;</i>	030-273
	030.6.14.2	LiDAT: activating data transmission manually <i>L566-1484;</i>	030-275
	030.6.14.3	Skyview 360°: calibration <i>L566-1484;</i>	030-277
	030.6.14.4	Personnel detection: transmitting configuration files <i>L566-1484;</i>	030-284
040	Drive group		040-1
	040.1	Engine	040-3
	040.1.2	Electrical components of diesel engine <i>L566-1484;</i>	040-7
	040.1.3	Sensors on diesel engine <i>L566-1484;</i>	040-11
	040.1.4	Ambient temperature sensor <i>L566-1484;</i>	040-22
	040.1.5	Fuel system	040-24
	040.1.5.2	Fuel level sensor <i>L566-1484;</i>	040-28

010 Introduction

Contents

010.1	Safety instructions	010-4
010.1.1	Information on these instructions	010-4
010.1.1.1	Representation of warning messages	010-4
010.1.1.2	Graphic symbols in these instructions	010-4
010.1.2	Intended use	010-5
010.1.2.1	Laws, rules, guidelines and safety regulations	010-5
010.1.2.2	Intended use	010-5
010.1.2.3	Foreseeable misuse	010-6
010.1.2.4	Operating conditions	010-6
010.1.2.5	Disposal	010-7
010.1.3	Description of staff	010-7
010.1.3.1	Personal protective equipment	010-7
010.1.3.2	Requirements for staff	010-8
010.1.3.3	Operating company	010-8
010.1.3.4	Operator	010-9
010.1.3.5	Maintenance staff	010-9
010.1.3.6	Refrigeration technician	010-10
010.1.3.7	Slinger	010-11
010.1.3.8	Spotter	010-12
010.1.4	Protective devices on the machine	010-12
010.1.4.1	Operator's cab	010-12
010.1.4.2	Roll over protective structure (ROPS)	010-13
010.1.4.3	Falling object protective structures (FOPS)	010-13
010.1.5	Emergency equipment on the machine	010-13
010.1.5.1	Emergency exit (standard)	010-13
010.1.5.2	Fire extinguisher (option)	010-14
010.1.6	Safe operation	010-14

- Is able to estimate distance, height and gaps.
- The refrigeration technician has completed training that complies with the country-specific laws, standards and guidelines.
- The refrigeration technician has following skills:
 - Is able to assess work correctly.
 - Is able to recognise dangers.
 - Is able to take safety measures.
- Has knowledge and experience of the relevant field of activity.
- Knows the relevant national standards.
- Has the necessary authorisation for maintenance and repair of machine.
- Knows the machine and the hazards.
- Knows all procedures and precautions for maintenance.
- Has knowledge of handling special tools for maintenance and repair.
- Is not under any physical or mental impairment that limits one of the prescribed requirements.
- Is not under the influence of alcohol.
- Is not under the influence of drugs.

010.1.3.7 Slinger

Responsibility

Slinger is responsible for following:

- Wear personal protective equipment.
- Choose correct and undamaged slinging gear.
- Correctly attach slinging gear to load or lifting accessory.
- Correctly remove slinging gear from load or lifting accessory.
- Grant approval for movement or accompaniment.

Requirement

The slinger has following qualification and skills:

- Has completed the legally specified minimum age.
- Physically and mentally capable of slinging loads:
 - Satisfactory eyesight
 - Satisfactory hearing ability
 - Quick reactions
 - Is able to estimate distance, height and gaps.
- The slinger has following skills:
 - Is able to estimate mass distribution and load distribution.
 - Is able to operate radio units.
 - Is able to give clear instructions on radio units.
 - Is able to guide a load.
- Has the necessary authorisation for attaching loads.
- The slinger has the necessary education (theoretical and practical) for the following:
 - Selecting the suitable slinging gear
 - Attaching slinging gear
 - Securing to prevent unintended disengaging of slinging gear
 - Avoiding damage to slinging gear
 - Spotting
 - Applying all necessary signal signs
- Is not under any physical or mental impairment that limits one of the prescribed requirements.
- Is not under the influence of alcohol.
- Is not under the influence of drugs.

Environmental pollution

- When working in following areas, adhere to laws, regulations and rules applicable at place of use:
 - Areas at risk of water (for example bodies of water)
 - Sound-sensitive areas
 - Emission-sensitive areas

010.1.7 Safe maintenance

010.1.7.1 Spare parts

Danger to life

Incorrect spare parts

- Use original spare parts.
- Make sure that the spare parts meet the technical requirements specified by the manufacturer.
- After replacing parts, tighten loosened screw connections with prescribed tightening torque.
- Find prescribed tightening torque in supplied documentation.
- If the tightening torque is not prescribed by the supplied documentation: Find prescribed tightening torque in Liebherr factory standard.
- If the tightening torque is not prescribed by the Liebherr factory standard: Find tightening torque in valid DIN standard, EN standard or ISO standard.

010.1.7.2 Heavy parts

Danger to life

Incorrect handling




- Exclusively use machine for load-lifting with sufficient loading capacity.
- Exclusively use suitable and functioning lifting accessories with sufficient loading capacity.
- Make sure there are no persons underneath raised loads.
- Exclusively task qualified and experienced persons with the attaching of loads.
- Exclusively task qualified and experienced persons with the directing of operators.
- Make sure that the spotter can be seen by the operator.
- Make sure that spotter and operator are in voice contact if necessary.

Injury

Incorrect protective equipment




- Put on gloves when handling wire ropes.

010.2.5 Special tools for lift cylinders with industrial lift arms

Designation	Item code	Remark	Fig.
Mounting sleeve 150 mm	9998622	For fitting the seals	
Expansion sleeve 150 mm	9110410	For fitting the seals	
Piston wrench 90 mm	9600418	For fitting the piston	



Tab. 9: Special tools for lift cylinders with industrial lift arms

010.2.6 Special tools for tilt cylinders with industrial lift arms

Designation	Item code	Remark	Fig.
Mounting sleeve 170 mm	9107931	For fitting the seals	
Expansion sleeve 170 mm	9110412	For fitting the seals	
Piston wrench 110 mm	9600928	For fitting the piston	

Tab. 10: Special tools for tilt cylinders with industrial lift arms

LBH/11835189/19/21+20191218_090358/en

Metric standard threads and fine threads	Metric standard threads and fine threads
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fIZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fIZnnc-480h-L valid \geq M6)	All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)
 <p>g2025329</p> <p>1: Zinc flake coated</p>	 <p>g2025333</p> <p>1: Black oxide, phosphated, blued 2: Thick passivation 3: Yellow chromate coated 4: Galvanised Fe//ZnNi(12)5//Cn//T2</p>

Tab. 22: Bolt types

Metric standard threads and fine threads				Metric standard threads and fine threads			
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fIZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fIZnnc-480h-L valid \geq M6)				All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)			
Minimum total coefficient of friction $\mu_G = 0.09$				Minimum total coefficient of friction $\mu_G = 0.11$			
Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm	Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm
				M 4	8.8	4.5	2.9
					10.9	6.6	4.3
					12.9	7.7	5.0
				M 5	8.8	7.3	5.7
					10.9	10.7	8.4
					12.9	12.5	9.8
M 6	8.8	10.6	8.6*	M 6	8.8	10.3	9.9
	10.9	15.5	12.6*		10.9	15.2	14.5
	12.9	18.2	14.7*		12.9	17.7	16.9

LBH/11835199/19/21+20191218_090358/en

010.4.4.2 After being out of service for 12 months

Put the machine into serve as described in the section on recommissioning after 2 months out of service.

The following measures must also be carried out:

- Extract an oil probe from the hydraulic oil and send it in for analysis.
- Carry out planned maintenance and inspection tasks on the machine before putting back into service.
- Mechanically activate the external exhaust return on the diesel engine and the engine brake flap and check for clearance.
- Clean corrosion inhibitor wax from machine and components with steam from a high-pressure cleaner (min. 120 °C) and with 5% cleaning agent (e.g. petroleum). (Careful on walk-on surfaces: there is a danger of slipping on wax remains.)
- Check the diesel engine's V-ripped belt and change if necessary.
- To carry out a test run of the diesel engine: increase the engine speed gradually to up to $\frac{3}{4}$ of the upper idle speed, until the operating temperature is reached.
- Check oil pressure display immediately after starting the diesel engine.

010.4.4.3 After being out of service for longer than 12 months

Put the machine into serve as described in the section on recommissioning after 12 months out of service.

- **After a machine has been out of service for longer than 12 months, the diesel engine manufacturer's customer service must be contacted.**
- Remove all covers and seals used for the preservation measures.
- Turn the diesel engine several full turns by hand (use flywheel cranking device – see special tools).
- Start the engine and bring up to operating temperature.
- After the engine has been brought to operating temperature, change all lubrication and operating fluids as well as the filters.
- Check the whole machine for proper functioning and inspect for leaks.

Carry out any additionally required temporary maintenance work.

Designation	Unit	Value	
Turning radius over bucket outer edge	mm	7410	7440
Breakout force (SAE)	kN	200	185
Tipping load when straight	kg	17100	16650
Tipping load when fully articulated (ISO 14397-1)	kg	15000	14550
Operating weight	kg	24800	24950

Tab. 26: Complete machine with loading bucket (industrial lift arms)

- A) Industrial lift arms with parallel guidance including quick coupler
- B) Earth bucket with short, straight base for quick coupler
- C) Welded tooth holder with plug-in teeth
- D) In practice, the bucket capacity can be around 10% greater than as calculated using the ISO 7546 standard. The bucket filling level depends on the type of material.

020.1.3 Working attachment: light material bucket

Valid for: L566-1484;

Values stated refer to machine:

- In standard version
- With 26.5R25 L3 tyres (For more information see: 020.10.7 Tyres, page 020-37)
- Including all lubricants
- With a full fuel tank
- With ROPS/FOPS cab and operator
- On level and stable ground



Note

Tyres and working attachments affect operating weight and tipping load.

► Note the information about the tyres and working attachment.




Fig. 81: Working attachment: light material bucket

020.4 Working hydraulics

020.4.1 Working pump

Valid for: L566-1484;

Description	Unit	Value
Type		Axial piston pump with swash plate variable displacement
Type		A11VO130LRS
Direction of rotation		Anticlockwise
Maximum displacement per turn	cm ³	130
Maximum displacement	l/min	300
Weight	kg	75

020.4.2 Control valve block for Z kinematics

Valid for: L566-1484;

Description	Unit	Value
Type		M6-1441-30/2M6-22 W
Maximum flow rate for lifting function (per outlet)	l/min	280
Maximum flow rate for lowering function (per outlet)	l/min	200
Maximum flow rate for tilt-in function	l/min	200
Maximum flow rate for tilt-out function	l/min	180
Maximum flow rate for 3rd function A3 (optional)	l/min	170
Maximum flow rate for 3rd function B3 (optional)	l/min	300
Maximum flow rate for 4th function A4 (optional)	l/min	170
Maximum flow rate for 4th function B4 (optional)	l/min	300
Weight (excluding additional spool valve)	kg	59

LBH/11835189/19/21+20191218_090358/en

020.7.5 Brake accumulator pressure sensor B19

Valid for: L566-1484;

Description	Unit	Value
Measuring range	bar	0 to 600
Signal output	mA	4 to 20
Supply voltage	VDC	8 – 30
Rated temperature range	°C	-25 to +85
Tightening torque	Nm	20

020.7.6 Parking brake hydro accumulator

Valid for: L566-1484;

Description	Unit	Value
Volume	l	0.32
Nitrogen filling pressure at 20 °C	bar	80 ^{+2/-1}
Weight	kg	1.3

020.10.7.2 Tyres for timber work

Size and tread code		Change in operating weight	Width across tyres	Change in height	Tyre pressure		
					FA ^{A)}	RA ^{B)}	p - max. ^{C)}
		kg	mm	mm	bar	bar	bar
Bridgestone 26.5R25 VJT	L3	+160	2970	+14	4.80	3.50	5.00
Bridgestone 26.5R25 VLTS	L4	+420	2970	+44	4.80	3.20	5.00
Bridgestone 26.5R25 VSDL	L5	+1290	2970	+57	4.80	3.20	6.50
Bridgestone 26.5R25 VSdT	L5	+1038	2970	+50	4.80	3.20	6.50
Bridgestone 26.5R25 VSMS	L5	+1599	2960	+70	4.80	3.50	6.50
Bridgestone 26.5R25 VSNT	L4	+576	2960	+47	4.80	3.20	6.50
Bridgestone 750/65R25 VTS	L3	+194	3070	-39	4.80	3.50	5.00
Continental 26.5R25 EM-Master	L4	+528	2930	+48	5.00	3.80	6.50
Goodyear 26.5R25 GP-4D	L4	+436	2980	+26	4.80	3.50	5.00
Goodyear 26.5R25 RL-4K	L4	+776	2990	+63	4.80	3.50	6.50
Goodyear 26.5R25 RL-5K	L5	+1244	2990	+63	4.80	3.50	6.50
Goodyear 26.5R25 RL-5S	L5	+1460	2990	+63	4.80	3.50	6.50
Goodyear 26.5R25 RT-3B	L3	+324	2980	+26	4.80	3.50	6.50
Goodyear 26.5R25 RT-5D	L5	+1008	2990	+63	4.80	3.50	6.50
Goodyear 26.5R25 TL-3A+	L3	+348	2980	+30	4.80	3.50	6.50
Goodyear 750/65R25 TL-3A+	L3	+148	3100	-26	4.80	3.50	5.00
Michelin 26.5R25 XHA2	L3	0	2960	0	4.00	2.50	5.50
Michelin 26.5R25 XLD D2A	L5	+696	2970	+38	4.00	2.50	5.50
Michelin 26.5R25 XMINE PRO	L5	+1188	3010	+58	4.20	2.80	7.00
Michelin 26.5R25 XKA	L3	+464	3000	+11	4.00	2.50	6.50
Michelin 26.5R25 XTXL	L4	+488	2970	+23	5.00	3.50	8.00
Michelin 750/65R25 XLD65	L3T	-8	3060	-57	4.20	2.50	5.50

Tab. 32: Tyres for timber work

- A) Recommended tyre pressure for cold tyres on the front axle
 B) Recommended tyre pressure for cold tyres on the rear axle
 C) Maximum tyre pressure

020.10.7.3 Special tyres

Enter the specifications in the tables below as follows:

- **By the machine operator:** If the machine is retrofitted by the machine operator

030 Maintenance

Contents

030.1	Maintenance and inspection schedule	030-11
030.2	Filling quantities and lubrication chart	030-16
030.2.1	Recommended lubricants <i>L566-1484;</i>	030-16
030.2.2	Recommended operating fluids <i>L566-1484;</i>	030-17
030.3	Lubricants and fuels	030-18
030.3.1	General information on lubricants and fuels	030-18
030.3.1.1	General questions	030-18
030.3.1.2	Safety data sheets	030-18
030.3.1.3	Technical data sheets	030-18
030.3.1.4	Specific Liebherr standards	030-18
030.3.2	General information on changing lubricants and fuels	030-18
030.3.3	Converting hydraulic system from mineral oils to biodegradable hydraulic fluids	030-19
030.3.4	Diesel fuels <i>L566-1484;</i>	030-19
030.3.5	Diesel fuels for diesel engines without emission-type approval <i>L566-1484;</i>	030-20
030.3.6	Diesel exhaust fluid <i>L566-1484;</i>	030-21
030.3.7	Engine oils <i>L566-1484;</i>	030-21
030.3.8	Engine oils for diesel engines without emission-type approval <i>L566-1484;</i>	030-22
030.3.9	Refrigerant <i>L566-1484;</i>	030-24
030.3.10	Coolant <i>L566-1484;</i>	030-24
030.3.11	Hydraulic oil <i>L566-1484;</i>	030-25
030.3.12	Splitter box oil <i>L566-1484;</i>	030-26

030.1 Maintenance and inspection schedule

General information

Shorten maintenance intervals depending on conditions of use, for example:

- Dust-intensive use
- Oil quality
- Fuel quality


Ensure that lubricants, liquids and replaced parts are disposed of safely and in an environmentally friendly manner. Comply with applicable country-specific guidelines and applicable laws in country of use.

Service packs in spare parts catalogue contain spare parts required for maintenance activities.


The following abbreviations are used in this section:

- h = operating hours

Various symbols (solid or empty circles, boxes and stars) are used to indicate the maintenance tasks, which fall into two main types.

 <p style="text-align: right; margin-top: 5px;">G2010460</p>	<p>The symbols have the following meanings:</p> <p>Table with solid circle, box or star</p> <p>Responsibility for carrying out the maintenance work lies with the machine operator or his maintenance staff. Maintenance interval: every 10, 50 and 500 service hours (h), and at unscheduled times.</p>
---	---

Tab. 34: Machine operator

 <p style="text-align: right; margin-top: 5px;">G2010467</p>	<p>The symbols have the following meanings:</p> <p>Table with empty circle, box or star, or service hours (h)</p> <p>The maintenance and inspection work must be performed or supervised by authorised engineers from Liebherr or its authorised dealers. Maintenance interval: on delivery and every 1000, 2000, 3000 service hours (h), and at unscheduled times.</p>
---	--

Tab. 35: Authorised specialist staff

You will find a list of the spare parts needed for maintenance and inspection work in the service package of the spare parts list.

LBH/11835199/19/211-20191218_090358/en

030.3.6 Diesel exhaust fluid

Valid for: L566-1484;

030.3.6.1 Liebherr recommendation

Designation
AdBlue® in Europe
DEF (Diesel exhaust fluid) in the USA
AUS 32 (aqueous urea solution)

Tab. 44: Liebherr recommendation

030.3.6.2 Minimum quality requirement

Specification
DIN 70 070
ISO 22241
LH-00-UREA

Tab. 45: Minimum quality requirement

030.3.7 Engine oils

Valid for: L566-1484;

030.3.7.1 Liebherr recommendation

Ambient temperature	Designation
-30 °C to 35 °C	Liebherr engine oil 5W-30
-30 °C to 35 °C	Liebherr engine oil 5W-30 low ash

Tab. 46: Recommendation for engine oils

For machines with a diesel particulate filter, the low ash engine oil must be used.

030.3.7.2 Other approved engine oils

Ambient temperature	Designation
-20 °C to 45 °C	Liebherr engine oil 10W-40
-20 °C to 45 °C	Liebherr engine oil 10W-40 low ash

Tab. 47: Other approved engine oils

For machines with a diesel particulate filter, the low ash engine oil must be used.

- ▶ Push the button **1** to position **A** and hold it.
 - ▷ The engine bonnet **2** opens.
 - ▷ The mechanism holds the engine bonnet in position.

Troubleshooting

If the mechanism does not hold the engine bonnet in position:

- ▶ Contact Liebherr customer service.

To close the engine bonnet:

- ▶ Push the button **1** to position **B** and hold it.
 - ▷ The engine bonnet **2** closes.



Note

The engine bonnet encounters an obstruction when opening or closing and is stopped due to overload.

The engine bonnet can only be opened or closed in the opposite direction to the overload.

- ▶ Press button **1**.
- ▶ Remove obstruction.

Manual emergency operation of the engine bonnet

NOTICE

Overload!

Damage to the drive system.

- ▶ Turn off the battery main switch.
- ▶ Only carry out emergency actuation manually.




Fig. 95: Manual emergency operation of the engine bonnet

- | | |
|---------------------|------------------------------------|
| 1 Drive gear | 3 Battery compartment cover |
| 2 Screw plug | |

- ▶ Remove the battery compartment cover **3**.
 - ▷ This provides access to the emergency actuation mechanism.
- ▶ Unscrew the screw plug **2**.
- ▶ Turn the drive gear **1** by hand with an Allen key.
 - ▷ The engine bonnet opens.




Fig. 102: Cleaning the front windscreen of the cab

- | | | | |
|---|------------------|---|-----------------|
| 1 | Front windscreen | 3 | Footplate |
| 2 | Handrail | 4 | Exterior mirror |

- ▶ Fold in the exterior mirror 4 towards the cab door.
- ▶ Access to the windscreen: use the footplate 3 and handrail 2.
- ▶ Use commercial glass cleaner.
- ▶ Use lint-free cleaning cloths.

030.4.3.4 Changing the VCI-capsules

Valid for: L566-1484;

Make sure that following requirements are met:

- Machine is in maintenance position 1.

Make sure following material is ready:

- 5 VCI-capsules of type VC1-1 (item code: 8145869).
- A sticker for noting that they have been changed (enclosed with the VCI-capsules).

Changing the VCI-capsule in the back of the switches




Fig. 103: Changing the VCI-capsule in the back of the switches

- | | | | |
|---|-------------|---|--------------|
| 1 | VCI-capsule | 2 | Switch cover |
|---|-------------|---|--------------|




Fig. 111: Sampling point on the axles

- | | | | |
|---|---------------|---|--------------|
| 1 | Hand pump | 3 | Filling plug |
| 2 | Sampling hose | | |

- ▶ Start diesel engine and drive machine for 3 minutes at 15 km/h.
 - ▷ The oil is circulated.
- ▶ Put machine in maintenance position 2.



CAUTION

Hot, pressurised fluid!
Injury.

- ▶ Carefully unscrew filling plug.
-
- ▶ Carefully unscrew filling plug 3.
 - ▶ Insert the sampling hose 2 to 5 cm below the oil level.
 - ▶ Fill the sample container using the hand pump 1.
 - ▶ Close the filling plug again.

Hydraulic system

Take oil sample from hydraulic system: ([For more information see: Hydraulic tank: analysing the oil, page 030-108](#))

030.4.4 Drive group

030.4.4.1 Checking diesel engine oil level

Valid for: L566-1484;

There are two ways to check the oil level:

- Checking the oil level on the display
- Checking the oil level on the dipstick

Troubleshooting

If you find any damage to the electrical system of the engine:

- ▶ Do not start the engine.
- ▶ Repair the damage or replace the parts.

030.4.4.7 Checking diesel engine valve clearance

Valid for: L566-1484;

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.

Make sure that one of following tools is ready:

- Engine cranking device (item code: 10116805) (recommended)
- Engine cranking device (item code: 0524045)


Attaching engine cranking device

Fig. 121: Attaching engine cranking device

1 Engine cranking device (item code: 0524045)

2 Engine cranking device (item code: 10116805)

**Note**

The engine cranking device (item code: 10116805) is recommended because the torsional vibration damper is easier to access than the flywheel housing.

- ▶ Attach a cranking device to the diesel engine.

Checking and adjusting the valve clearance

Cylinder numbering and crankshaft direction of rotation:

- Cylinder 1 is on the flywheel side.
- The diesel engine turns anticlockwise as seen towards the flywheel.
- The outlet valves of the cylinder are on the flywheel end.

- ▶ Remove valve cover.

- Service access is open.
- Diesel engine has cooled down.

Make sure that following tool is ready.

- Receptacle



WARNING

Highly flammable consumables!
Beware of burns.

- ▶ Avoid naked lights and fire.




Fig. 130: Bleeding fuel system

1 Hand pump in *PUMP* position

2 Hand pump in *RUN* position



CAUTION

Pressurised fluids that are irritants to the skin!
Risk of injury.

- ▶ Wear safety gloves and goggles.
- ▶ Put hand pump in *PUMP* position 1.
- ▶ Operate hand pump until you feel strong resistance.
- ▶ Put hand pump in *RUN* position 2.
- ▶ Start diesel engine.

Troubleshooting

If machine will not start after approx. 20 sec.:

- ▶ Wait one minute and repeat starting process.

Once you have repeated this three times:

- ▶ Repeat bleeding process.

Splitter box: Draining the oil




Fig. 141: Splitter box: Draining the oil

- | | | | |
|---|--------------|---|-------------|
| 1 | Engine | 3 | Drain valve |
| 2 | Splitter box | 4 | Drain hose |

- ▶ Pull the dipstick out of the splitter box 2.
 - ▷ This allows the oil to flow out more easily.

The drain valve 3 is on the underside of the splitter box.

- ▶ Unscrew the cap from the drain valve.
- ▶ Screw the drain hose 4 onto the drain valve.
- ▶ Drain off the oil into the receptacle.
- ▶ Unscrew the drain hose.
- ▶ Unscrew the cap of the drain valve.
- ▶ Put in the dipstick.

030.4.5 Cooling system


030.4.5.1 Cooling system: Checking the coolant level

Valid for: L566-1484;

Checking the coolant level

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- The engine has cooled down.



G32007482

Fig. 150: Checking the coolant level

1 Equalising reservoir sight glass

- ▶ Check the coolant level in the equalizing reservoir through the sight glass 1.

If the sight glass 1 is not completely filled with coolant:

- ▶ Top up the coolant. (For more information see: [Filling coolant, page 030-91](#))

Filling coolant

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- The engine has cooled down.

Draining coolant




Fig. 158: Draining the coolant

- | | | | |
|----------|------------------------------|----------|-------------|
| 1 | Cap | 3 | Drain valve |
| 2 | Coolant equalising reservoir | | |

- ▶ Carefully open the cap **1** of the coolant equalizing reservoir **2**.
- ▶ Place a receptacle under machine.
- ▶ Unscrew the cap from the drain valve **3**.
- ▶ Screw the drain hose onto the drain valve **3**.
 - ▷ Coolant flows out.
- ▶ Completely drain the coolant into the receptacle.
- ▶ Unscrew the drain hose from the drain valve **3**.
- ▶ Screw the cap onto the drain valve **3**.



Fig. 168: Draining oil from the hydraulic tank

6 Hydraulic tank drain valve

- ▶ Unscrew the cap of the hydraulic tank drain valve **6**.
- ▶ Screw the drain hose onto the hydraulic tank drain valve **6**.
 - ▷ Oil drains off.
- ▶ Drain off all the oil into the receptacle.
- ▶ Unscrew the drain hose from the hydraulic tank drain valve **6**.
- ▶ Screw the cap onto the hydraulic tank drain valve **6**.
- ▶ Top up the oil.

Topping up the oil




Fig. 169: Topping up the oil

- ▶ Lift out the filter insert and turn it by 90°.
- ▶ Put down the filter insert.
 - ▷ The return filter is in the filling position.



Note

When filling using the filling position, the oil flows through the 100 µm strainer fabric.

- ▶ Fill the oil through the return filter until the oil level is between the minimum and maximum.

**WARNING**

Inadvertently engaging the parking brake!
Crushing injuries.

- ▶ Keep people out of the operator's cab.
 - ▶ Make sure that the main switch cannot be operated.
-
- ▶ Force the variable **QRPBValve** to the maximum value **65535**.
 - ▷ The parking brake opens.
 - ▶ Unscrew the protective cap.
 - ▶ Unscrew the counter nut **8**.
 - ▶ Loosen the adjusting screw **7** by three to four turns.
 - ▶ Push back the thrust pin **6** with a screwdriver.
 - ▶ Remove the cotter pin **3** and pull out the guide pin **4**.
 - ▶ Remove both brake shoes **1**.
 - ▶ Put on the new brake shoes.
 - ▶ If the brake shoes do not stick to the solenoids **5**: clean the solenoids **5**.
 - ▶ Pit in the guide pin **4** and insert the cotter pin **3**.
 - ▶ Adjust the gap. (For more information see: [Adjusting the gap, page 030-121](#))


Adjusting the gap

Fig. 181: Adjusting the gap

- | | |
|---------------------|--------------------------|
| 1 Brake shoe | 4 Adjusting screw |
| 2 Brake disc | 5 Counter nut |
| 3 Thrust pin | s2 Gap |

- ▶ Start the diesel engine and let it run for 30 seconds at low idling speed.
 - ▷ The parking brake hydro accumulator is filled.
 - ▷ The parking brake can be operated when the diesel engine is off.
- ▶ Turn off the diesel engine.
- ▶ Switch on the ignition.




Fig. 211: Checking the lift arm bucket bearing bushings

1 Bucket bearing (2x) 2 Bucket bearing bushing (2x)

- ▶ Raise the lift arms so far that the bucket can be fully tilted out.
- ▶ Tilt the bucket out.
- ▶ Tilt the bucket in and out with short, fast movements.
- ▶ When doing so, listen out for noises and play in the bucket bearing bushes 2.

If there are noises or play in the bucket bearing bushes 2:

- ▶ Check the lubrication of the bucket bearing bushes 2.
- ▶ Replace the bucket bearing bushes 2.

030.4.13.4 Checking the lift arm bucket stops

Valid for: L566-1484;



Note

This maintenance item is only for Z kinematics.

Make sure that the following requirements are fulfilled:

- The machine is secured against rolling away.

Checking the bucket stops with direct attachment




Fig. 212: Checking the bucket stops with direct attachment

1 Bucket stop (2x) 2 Linkage stop

- ▶ Check the condition and function of the driver's safety belt.
- ▶ Replace damaged parts.

030.4.14.4 Testing the windscreen washer system

Valid for: L566-1484;

Make sure that following requirements are met:

- The machine is parked in a safe place.
- The electrical system of the machine is switched on.

To check the front windscreen washer system:

- ▶ Activate windscreen washer system.
 - ▷ Windscreen washer fluid is sprayed onto the front windscreen.
 - ▷ The wiper is switched on.

To check the rear windscreen washer system:

- ▶ Activate windscreen washer system.
 - ▷ Windscreen washer fluid is sprayed onto the rear window.
 - ▷ The wiper is switched on.

030.4.14.5 Windscreen washer system: Topping up windscreen washer fluid

Valid for: L566-1484;

The reservoir is fitted below the left cab access.

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.




Fig. 222: Windscreen washer system: Topping up windscreen washer fluid

1 Cover

The filling quantity is approximately 3.5 l.

- ▶ Open cap **1** on the reservoir.

3. Hydraulic adjustment procedures									
Test / adjustment	1000 h	2000 h	Unit	Required value	Measured	Adjusted	Adjusting point	Test point	Figure
Industrial lift arms control valve block (option): secondary pressure relief valves ⓘ									
Opening pressure for tilting out		o	bar	225 ^{±5}			4	PA	<p>sep01824</p>
Opening pressure for tilting in ^{A)}		o	bar	425 ^{±5}			5	PA	
Opening pressure for lifting ^{A)}		o	bar	425 ^{±5}			6	PA	
Opening pressure for 3rd function A3 (option)		o	bar	255 ^{±5}			7	PA	
Opening pressure for 3rd function B3 (option)		o	bar	255 ^{±5}			8	PA	
Opening pressure for 4th function A4 (option)		o	bar	255 ^{±5}			9	PA	
Opening pressure for 4th function B4 (option)		o	bar	255 ^{±5}			10	PA	
Industrial lift arms control valve block (option): primary pressure relief valve ⓘ									
Opening pressure ^{B)}		o	bar	390 ^{±5}			11	PA	<p>sep01827</p>
Industrial lift arms control valve block (option): LS-pressure cut-off ⓘ									
High pressure at full load		o	bar	380 ^{±5}			12	PA	
Stabilisation module cut-out function ⓘ									
Cut-out pressure when charging		o	bar	120 ^{+60/-10}				MX	
Steering system									
Steering pump: LS-pressure cut-off valve ⓘ									
High pressure at full load		o	bar	210 ^{±5}			13	PL/	<p>sep01826</p>
Steering pump: flow regulator (differential pressure)									
Up to software version 020: ⓘ									
From software version 024: ⓘ									
Differential pressure ΔP at low idling speed	◇	o	bar	23 ^{±1}			14	PL/ LSL	
Brake system									
Brake accumulator pressure sensor B19: deviation ⓘ									
Deviation between pressure gauge and sensor	o	o	bar	<5			15	M3	

LBH/11835199/19/211+20191218_090358/en



Fig. 233: "Snapshot" function

- ▶ Select the "Snapshot" function.



Note

The name of the service file contains information that is important for automatic processing of the data.

- ▶ Do not change the file name.

- ▶ Save the file.

030.6.4 Cooling system

030.6.4.1 Fan speed proportional solenoid valve

Valid for: L566-1484;



Note

Fan speed proportional solenoid valve does not normally need to be adjusted.

- ▶ Exclusively check and adjust fan speed proportional solenoid valve if performance of cooling system is insufficient, for troubleshooting or if fan motor or parts of it have been replaced.

Make sure that following requirements are met:

- Cooling system is cleaned.
- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.
- Service access is open.

Make sure that following tools are ready:

- Laptop with Sculi diagnostic software
- Pressure gauge (250 bar)




Fig. 234: Fan speed proportional solenoid valve

PK Cooling system high pressure test connection

- ▶ Unforce the variable **QREHLiftValveUp**.
- ▶ Repeat the process for the lowering function with the variable **QREHLiftValveDn**. Enter the value you read in the variable **CREHLiftDnCurrMoveBegin**.
- ▶ Repeat the process for the tilt-in function with the variable **QREHBucketValveUp**. Enter the value you read in the variable **CREHBucketUpCurrMoveBegin**.
- ▶ Repeat the process for the tilt-out function with the variable **QREHBucketValveDn**. Enter the value you read in the variable **CREHBucketDnCurrMoveBegin**.

Once all the functions have been calibrated:

- ▶ Turn off the diesel engine.

Manual calibration of proportional solenoids for 3rd and 4th functions (option)



Note

Calibration of the 3rd and 4th functions is not necessary for normal operation.

- ▶ Exclusively calibrate 3rd and 4th functions if there are problems actuating the working attachment.

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The working attachment is attached.
- The machine is in the maintenance position for adjustment procedures.

Make sure that the following tools are ready:

- Laptop with Sculi diagnostic software
- ▶ Start the diesel engine.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ In the variables editor, select the **Working hydraulics** folder.
- ▶ Select the **Calibrate angle proportional solenoids** sub-folder.
 - ▷ The variable **QRCntrlCirc3a** shows the current at the proportional solenoid for 3rd function A3.
 - ▷ The variable **QRCntrlCirc3b** shows the current at the proportional solenoid for 3rd function B3.
 - ▷ The variable **QRCntrlCirc4a** shows the current at the proportional solenoid for 4th function A4.
 - ▷ The variable **QRCntrlCirc4b** shows the current at the proportional solenoid for 4th function B4.
- ▶ Make sure that the parking brake is activated.
- ▶ Raise the lift arms half way.
- ▶ Tilt the bucket half way in.
- ▶ Click the variable **QRCntrlCirc3a** and press the *space bar*.
 - ▷ The line is coloured pink.
 - ▷ The variable is forced. A gradual approach towards the required value is possible.

If a required value is not reached:

- ▶ Set bucket down on ground on its teeth or cutting edge.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Turn adjusting screw of corresponding secondary pressure relief valve.



Note

To adjust secondary pressure relief valves:

- ▶ Turn adjusting screw clockwise to increase high pressure.
- ▶ Turn adjusting screw anticlockwise to reduce high pressure.

- ▶ Repeat check and adjustment until required value is reached.

When all required values are reached:

- ▶ Set bucket down on ground on its teeth or cutting edge.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Turn adjusting screw on primary pressure relief valve **9** by exactly one turn anticlockwise.
- ▶ Turn adjusting screw on LS-pressure cut-off valve **8** by exactly one turn anticlockwise.
- ▶ Check and adjust primary pressure relief valve. (For more information see: [Z-bar kinematics control valve block: primary pressure relief valve, page 030-201](#))
- ▶ Check and adjust the LS pressure cut-off valve. (For more information see: [Z-bar kinematics control valve block: LS-pressure cut-off, page 030-203](#))

030.6.5.9 Z-bar kinematics control valve block: primary pressure relief valve

Valid for: L566-1484;



Note

Opening pressure of primary pressure relief valve is above opening pressure of LS-pressure cut-off.

- ▶ Before testing, set LS-pressure cut-off to a higher value.

Make sure that following requirements are met:

- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.
- Service access is open.

Make sure that following tools are ready:

- Pressure gauge (600 bar)

Description	Unit	Value
Hydro accumulator charge pressure MX	bar	120 ^{+60/} -10

If the value is not correct:

- ▶ Set the bucket down on the ground on its teeth or cutting edge.
- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Check the stabilisation module for damage.

If the value is correct:

- ▶ Set the bucket down on the ground on its teeth or cutting edge.
- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Disconnect the pressure gauge from the hydro accumulator charge pressure test connection **MX**.

030.6.5.15 Ride control hydro accumulator nitrogen filling

Valid for: L566-1484;

Make sure that following requirements are met:

- Machine is in maintenance position for adjustment procedures.

Make sure that following tools are ready:

- Testing and filling device for hydro accumulator




Fig. 249: Ride control hydro accumulator nitrogen filling

- | | | | | | |
|---|------------|---|--------------|---|-------------------------------------|
| 1 | Screw plug | 2 | Relief valve | 3 | Ride control hydro accumulator (3x) |
|---|------------|---|--------------|---|-------------------------------------|



WARNING

Descending lift arms!
Injury.

- ▶ Make sure that the full weight of the lift arms rests on the ground.
-
- ▶ Unscrew plug 1.
 - ▶ Unscrew relief valve 2 by two turns.
 - ▷ Hydraulic pressure in hydro accumulators 3 is relieved into hydraulic tank.
 - ▷ Hydro accumulators can be checked while installed.

**WARNING**

Accidental steering movements!
Injury.

- ▶ Make sure that articulation lock is engaged.
-
- ▶ With joystick steering deactivated and within 8 seconds, move **joystick** all the way left and right.
 - ▶ Wait until the variable **MXJSEmergVlvPosAdjStart** returns to **0**.
 - ▷ Calibration is completed.
 - ▶ Turn off diesel engine.
 - ▶ Disengage articulation lock (for further information see: operator's manual).

Automatic calibration of proportional solenoids for main spool valve and emergency spool valve

**Note**

Before calibration of proportional solenoids of emergency spool valve, calibrate position sensor of main spool valve!

- ▶ Make sure that the articulation lock is disengaged.
- ▶ Start diesel engine.
- ▶ Move lift arms into transport position.
- ▶ Fold up left armrest and then fold back down.
 - ▷ Joystick steering is deactivated.

**WARNING**

Automatic machine movements!
Injury.

- ▶ Make sure there is nobody in hazard zone around machine.
-
- ▶ Set variable **MXJSSteerValveAdjMvBg** to **1**.
 - ▷ Calibration takes place automatically.
 - ▷ The machine automatically performs from minimal steering movements.
 - ▷ The calibration can be cancelled by steering with the steering joystick or starting up.
 - ▶ Wait until the variable **MXJSSteerValveAdjMvBg** returns to **0**.
 - ▷ Calibration is completed.

030.6.7.4 Steering pump: LS pressure cut-off valve

Valid for: L566-1484;

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The machine is in the maintenance position for adjustment procedures.
- The service access is open.

Make sure that the following tools are ready:

- Pressure gauge (600 bar)

- ▶ In the variables editor, select the **Brake system** folder.
 - ▷ The variable **PRSIMBrakePressure** shows the brake accumulator pressure.
- ▶ Check how far the value of the **MDDrPmPressHV** variable deviates from the value displayed by the high pressure gauge **M3**.

Description	Unit	Value
Maximum deviation	bar	5

If the deviation is too great:

- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Inspect the brake accumulator pressure sensor **1** for damage and replace if necessary.
- ▶ Repeat the test.

If the deviation is within the permitted range:

- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Disconnect the pressure gauge from the brake accumulator pressure test connection **M3**.

030.6.8.2 Compact brake valve hydro accumulator charging function

Valid for: L566-1484;

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The machine is in the maintenance position for adjustment procedures.

Make sure that the following tools are ready:

- Pressure gauge (250 bar)




Fig. 265: Compact brake valve hydro accumulator charging function

1 Pilot valve

M3 Service brake accumulator pressure test connection

- ▶ Connect a pressure gauge (250 bar) to the brake accumulator pressure test connection **M3** on the compact brake valve.
- ▶ Start the diesel engine.
- ▶ Wait 10 seconds.
 - ▷ The hydro accumulators for the service brake are full.

Troubleshooting

If the software update is not successfully completed:

- ▶ Switch off ignition and wait until all LEDs go out.
 - ▶ Switch on ignition. Software update is started again.
-

Troubleshooting

If after the software update, the functions do not operate correctly:

- ▶ Create a service file.
 - ▶ Set **MXMDMachineInit** variable to **1**.
 - ▶ Wait until the value is reset to **0** automatically.
 - ▶ Switch off ignition and wait until all LEDs go out.
 - ▶ Switch on ignition.
 - ▶ Recheck functions.
-

Troubleshooting

If the service code 0x8500A39D is displayed after the software update:

- ▶ Switch off ignition and wait until all LEDs go out.
 - ▶ Switch on ignition.
- If a service code continues to be displayed even after turning ignition off and then again several times:
- ▶ Create a service file.
 - ▶ Contact technical customer service at manufacturer factory.
-

030.6.9.3 Setting the IP addresses of the central control unit (Master4)

Valid for: L566-1484;

The IP addresses of the Ethernet interface may be lost due to a flat back-up battery or an error in the central control unit (Master4).

If this occurs, the IP addresses must be reset via the Terminal Plugin function with the Sculi diagnostic software.

Establishing the RS-232 connection with the machine

To be able to set the IP addresses, an RS-232 connection needs to be established between the central control unit and the notebook.

On machines with an RS-232 diagnostic plug:

- ▶ Use an RS-232 diagnostic data cable (ID number: 10035410) to connect the notebook with the central control unit.

On machines without an RS-232 diagnostic plug:

- ▶ Use an adapter cable (ID number: 6905860) to connect the notebook via the COM 4 port with the central control unit.

Setting the IP addresses

- ▶ Switch on the ignition.
- ▶ Start the Sculi diagnostic software.

- | | | | |
|---|--|---|--|
| 2 | Serial number of connected modules | 6 | Indicates whether the module is used |
| 3 | CAN line connecting the module to the central control unit | 7 | Indicates whether the module is active |
| 4 | Module identification | 8 | Drop-down window |

The serial number 2 indicates the module. The serial number 2 is on the identification plate of the module.

- ▶ Select module editor “function” 1.
- ▶ Select module and open drop-down window 8.
- ▶ Select address and confirm with Enter key.

Checking system information of CAN modules

The CAN module addresses are checked using the Sculi diagnostic software.

You can check following settings:

- Address
- **Active** status
- **Timeout** status
- Serial number of module
- Item code of module




Fig. 287: Checking system information of CAN modules

- | | | | |
|---|-------------------------------|---|------------------------------------|
| 1 | “System information” function | 4 | Serial number and item code |
| 2 | Module | 5 | “Save system information” function |
| 3 | Module status | | |

- ▶ Turn on starting switch.
- ▶ Start Sculi diagnostic software and connect it to machine.

LBH/11835199/19/211+20191218_090358/en

se000492

Reversing test is subdivided into a test with a short shifting delay and a test with a long shifting delay. Both tests must be carried out.

Preparing the memory card

Make sure that following tools are ready:

- A formatted flash card (item code: 10223095)
- A flash card reader (item code: 11000491)

The following files must be saved uncompressed on a formatted memory card:

- The file [autoexec.frc](#)
- The file [sampleXPower001.smp](#)
- The file [canalyser.SMP](#)

Files for recording data are provided as a compressed file ([testing_files.exe](#)) in Liebherr service documentation.

File storage location: Liebherr Service Documentation -> Wheel loader -> Machine software -> XPower_TCU_ID_11837049 -> Diagnosis -> [testing_files.exe](#)

- ▶ Unpack file [testing_files.exe](#).
 - ▷ The files for recording the data are then available.
- ▶ Copy the files for recording the data to a formatted memory card.
- ▶ Insert the memory card with the files for recording the data in the memory card slot CF2.

Preparing for the reversing test

Make sure that following requirements are fulfilled:

- Machine is at operating temperature.
- Machine is in maintenance position 1.
- Machine software is correctly configured (type, serial number, etc.).
- The service calibration has been carried out.
- Automatic hydrostat calibration has been carried out.
- Automatic clutch calibration has been carried out.
- There is a flat, straight stretch of roadway available for the test.
- ▶ Start diesel engine.
- ▶ Connect Sculi diagnostic software to Machine.
- ▶ In the variables editor, select the [Transmission](#) folder.
- ▶ Select the subfolder [Reversing Diagnosis](#).
 - ▷ The variables necessary for the test are displayed.
- ▶ Set the value of the variable [MXTDTransmRevDiagStart](#) to 1.
 - ▷ The machine is in testing mode.
 - ▷ Data is recorded on the memory card in memory card slot CF2.
 - ▷ The diesel engine speed is limited.
 - ▷ The terminal speed is limited to around 8 km/h.

Carrying out the reversing test with short shift delay

In this test, the reversing sequence is initiated as soon as the terminal speed is reached.

During the test, the accelerator pedal is fully depressed the whole time.

- ▶ Select forward travel direction.
- ▶ Accelerate the machine to the terminal speed.

▷ The display starts up in setting mode.



Fig. 303: Display with Touch Panel button


▶ Press touch panel button.



Fig. 304: Display with enter button

▶ Press enter button.


LBH/11835/19/211-2019/12/18_090358/en



g2060358

Fig. 320: Loading design data

- 1 "Perform Calibration" tab
- 2 "File" tab
- 3 "Load Design" function
- ▶ Select "Perform Calibration" tab 1.
- ▶ Select "File" tab 2.
- ▶ Select "Load Design" function 3.
- ▶ Select prepared folder "Designs".
- ▶ Select and open machine-specific design data.
 - ▷ Design data are loaded.



g2060366

Fig. 321: Starting calibration

- 1 "Start" function
- 2 "Next Camera" function
- ▶ Select "Start" function 1.

LBH/11835199/19/21+20191218_090358/en

040.1 Engine

Valid for: L566-1484;




Fig. 333: Diesel engine overview

- | | | | |
|----|-----------------------------|----|--------------------|
| 1 | Torsional vibration damper | 11 | Bleeder line |
| 2 | Water pump | 12 | Charge air line |
| 3 | Tensioning device | 13 | Turbocharger |
| 4 | Alternator | 14 | Starter |
| 5 | Air conditioning compressor | 15 | Exhaust pipe |
| 6 | Oil filter | 16 | Wastegate valve |
| 7 | Dipstick | 17 | Exhaust port |
| 8 | Heating flange | 18 | Thermostat housing |
| 9 | Air intake pipe | 19 | Coolant manifold |
| 10 | Valve cover | | |

Pin	Function
1	Ground
2	Output signal (0.5 to 4.5 V)
3	Power supply (5 V)

Tab. 116: Plug assignment

Oil pressure	Output voltage
0.0 bar/g	0.5 V
2.5 bar/g	1.5 V
5.0 bar/g	2.5 V
7.5 bar/g	3.5 V
10 bar/g	4.5 V

Tab. 117: Output voltage

1.2.1 Measured values for diagnostics

Supply line diagnostics			
Check	Preconditions	Measurement	Required value
Sensor power supply	Ignition ON	Measure voltage between pins 1 and 3 on line.	5 ^{±0.2} V
	Diesel engine OFF		
	Plug connection disconnected		
Short circuit between individual lines	Ignition OFF	Measure resistance between pins 1, 2, and 3 on line.	More than 10 kΩ
	Plug connection disconnected		
Lines shorted to earth	Ignition OFF	Measure resistance from pin 2 and pin 3 to earth.	More than 10 kΩ
	Plug connection disconnected		

Tab. 118: Supply line diagnostics

Sensor diagnostics			
Check	Preconditions	Measurement	Required value
Short circuit between individual pins on sensor	Ignition OFF	Measure resistance between pins 1, 2, and 3 on sensor.	More than 10 kΩ
	Plug connection disconnected		
Output signal voltage with ignition ON	Ignition ON	Measure voltage between pins 1 and 2.	0.5 ^{±0.2} V
	Diesel engine OFF		
Output signal voltage when idling	Ignition ON	Measure voltage between pins 1 and 2.	Voltage at lower idling speed: 2 ^{±0.2} V
	Diesel engine ON		

Tab. 119: Sensor diagnostics

2.2 Characteristic




Fig. 348: Characteristic

°C Ambient temperature

kΩ Sensor resistance

As the temperature increases, the sensor resistance decreases.

Substitute values	
Air humidity	50 %

Tab. 142

040.1.7 Exhaust system

040.1.7.1 Overview of exhaust gas treatment system

Valid for: L566-1484;




Fig. 358: Overview of exhaust gas treatment system

- | | |
|------------------|-------------------------------|
| 1 Diesel engine | 3 SCR catalytic converter |
| 2 Mixing section | 4 Diesel exhaust fluid nozzle |

2.1 Basic function

The statutory emissions standards (stage IV, Tier 4f) are fulfilled using a pure SCR strategy.

The diesel engine management system is set so that high combustion temperatures can be reached. This reduces the particulate emissions of the diesel engine. This means that a diesel particulate filter is not required in order to meet the emissions standards.

A diesel particulate filter is only necessary if stipulated by national or regional laws. In this case, the exhaust system comes with an SCR catalytic converter with diesel particulate filter (SCR-F).

High combustion temperatures have the drawback that NO_x emissions are higher. NO_x are nitrogen oxides, the output of which is regulated by emissions standards.

To reduce NO_x emissions, an SCR system is used.

1.2 NH₃ sensor



Fig. 370: NH₃ sensor

1 NH₃ sensor

2 NH₃ sensor controller B783

The NH₃ sensor 1 measures the ammonia content in the exhaust at the outlet of the SCR catalytic converter.

If the NH₃ sensor fails, a substitute value of 0 ppm is assumed. A power reduction is activated.

1.3 Differential pressure sensor




Fig. 371: Differential pressure sensor

1 Differential pressure sensor B722

The differential pressure sensor B722 1 is only installed in machines with diesel particulate filter (DPF).

The differential pressure sensor is used to calculate the soot load of the diesel particulate filter. The soot load is calculated from the pressure difference between the input of the DPF and the output of the DPF.

The differential pressure sensor outputs a voltage signal between 0.5 V and 4.5 V. This corresponds to a measuring range of 0 bar to 0.3 bar.

040.2 Clutch

Valid for: L566-1484;

The clutch is an elastic torsion absorber and vibration damper installed between the flywheel on the engine and the splitter box.




Fig. 382: Position of the clutch

1 Torsion absorber

2 Flywheel

Name	Test point
PK	Cooling system high pressure

Tab. 145: Test points

BMK	Function
Y13	Fan speed proportional solenoid

Tab. 146: Equipment codes

The cooling system hydraulics consist of the following components:

- Hydraulic tank (For more information see: 080.3.1 Overview of hydraulic tank, page 080-8)
- Collector pipe
- Fan pump (For more information see: 050.2.2 Fan pump, page 050-8)
- Fan motor with fan (For more information see: 050.2.3 Fan motor, page 050-9)

2 Function

2.1 Basic function




Fig. 388: Diagram of cooling system hydraulics (diesel engine is running)

- | | | |
|-----------------------------|---|--|
| 1 Hydraulic tank | 13 Hydraulic tank drain valve | 25 In-line filter 80 µm |
| 2 Return filter | 14 Emergency steering pump suction port | 30 Fan motor |
| 3 Main filter element 10 µm | 15 Working pump suction port drain valve | 31 Gear motor |
| 4 Bypass valve 2.5 bar | 16 Working pump suction port | 32 Fan speed proportional solenoid valve |
| 5 Strainer mesh 100 µm | 17 Steering pump suction port | 33 Secondary piston |
| 6 Breather filter | 18 Return flow from compact brake valve and pilot control | 34 Throttle |
| 7 Fine filter | 19 Leak oil from steering pump and working pump | 35 Primary piston |
| 8 Outlet valve 0.65 bar | 20 Return flow from control valve block | 36 Return flow from servostat |
| 9 Inlet valve 0.03 bar | 21 Diesel engine | 40 Collector pipe |

See next page for continuation of the image legend

LBH/11835199/19/21+20191218_090358/en

2 Function




Fig. 397: Hydraulic oil temperature sensor: Wiring diagram and characteristic

T Temperature in °C

R Resistance in kilohms

Temperature	Resistance	Temperature	Resistance
-20 °C	895 Ω	60 °C	1355 Ω
0 °C	1000 Ω	80 °C	1485 Ω
20 °C	1110 Ω	100 °C	1620 Ω
40 °C	1230 Ω	120 °C	1760 Ω

Tab. 160: Relationship of temperature to resistance

The central control unit measures the resistance R of the hydraulic oil temperature sensor and calculates the hydraulic oil temperature T from it.

As the temperature T increases, so does the sensor resistance R (PTC characteristic). The increase is approximately linear.

LBH/11835199/19/211-20191218_090358/en

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Name	Test point	Name	Test point	Name	Test point
MP	Working pump return pressure	MV	Servo pressure	PA A)	Working pump high pressure

Tab. 167: Test points

A) Test point on control valve block

BMK	Function	BMK	Function	BMK	Function
Y14	Solenoid for servo pressure	Y31a	Proportional solenoid for tilting out	Y32a	Proportional solenoid for lowering
Y20	Solenoid for ride control	Y31b	Proportional solenoid for tilting in	Y32b	Proportional solenoid for lifting

Tab. 168: Equipment codes




Fig. 404: Working hydraulics for Z-bar kinematics (lifting function actuated) (from rear right)

- | | | |
|-------------------------|---|--|
| 1 Hydraulic tank | 11 Oil supply from hydro accumulator for 1st brake circuit | 23 Hydro accumulator block |
| 2 Return filter | 12 Pilot control hydro accumulator | 24 Ride control hydro accumulator |

See next page for continuation of the image legend

LBH/11835199/19/211-20191218_090358/en

sah01801c

- | | |
|---|---|
| 3 Oil supply for control valve block | 8 Adjusting screw for Q_{min} |
| 4 Leak oil to leak oil strainer | 9 Suction port from hydraulic tank |
| 5 Load sensing signal from control valve block | 10 Power regulator |

Name	Test point	Name	Test point
MP	Working pump return pressure	PA	Working pump high pressure

Tab. 175: Test points

Working pump is attached together with steering pump on splitter box (tandem arrangement).

Working pump is an axial piston variable displacement pump for open circuit.




Fig. 408: Sectional view of working pump

- | | | |
|--|------------------------------|---------------------------|
| 1 Drive shaft | 10 Throttle | 19 Piston |
| 2 Roller bearing | 11 Positioning piston | 20 Sliding bushing |
| 3 Swivel plate | 12 Roller bearing | 21 Return plate |
| 4 Adjusting pin | 13 Throttle | 22 Glide shoe |
| 5 Adjusting screw for Q_{min} | 14 Return piston | 23 Return ball |
| 6 Compression spring | 15 Control plate | 24 Cup springs |

See next page for continuation of the image legend

LBH/11835199/19/211+20191218_090358/en

sah01817

- | | | |
|---|--|--|
| 10 Control valve block section for 4th function (option) | 22 Return flow to pilot control valve block | 34 Connection of 3rd function B3 (option) |
| 11 Secondary pressure relief valve for 4th function A4 | 23 Pressure relief valve | 35 Connection of 4th function A4 (option) |
| 12 End section | 24 Release valve | 36 Connection of 4th function B4 (option) |

Name	Test point	Name	Test point
LSA	Load sensing signal for working pump	PA	Working pump high pressure
MT	Servo pressure for tilt-out function		

Tab. 180: Test points

BMK	Function	BMK	Function	BMK	Function
Y31a	Proportional solenoid for tilting out	Y32b	Proportional solenoid for lifting	Y34a	Proportional solenoid for 4th function A4 (option)
Y31b	Proportional solenoid for tilting in	Y33a	Proportional solenoid for 3rd function A3 (option)	Y34b	Proportional solenoid for 4th function B4 (option)
Y32a	Proportional solenoid for lowering	Y33b	Proportional solenoid for 3rd function B3 (option)		

Tab. 181: Equipment codes

The control valve block is installed behind the maintenance cover.

2 Function




Fig. 420: Hydraulic diagram of control valve block for industrial lift arms (diesel engine running)

LBH/11835199/19/21+20191218_090358/en

sah01815

For charging, oil flows from lifting cylinder piston side **11** via non-return valve in ride control valve spool **2** to ride control hydro accumulators **13**. Once maximum charge pressure (shut-off pressure) is reached, pressure in ride control hydro accumulators **13** pushes ride control valve spool **2** against force of return spring, thereby disconnecting lifting cylinder piston side **11** from hydro accumulators **13**.

If maximum charge pressure is exceeded, pressure moves ride control valve spool **2** one position further. This allows oil to flow out of ride control hydro accumulators **13** back to hydraulic tank **12**.

2.3 Ride control activated

To activate ride control, central control unit energises ride control solenoid valve **7**. That pressurises ride control valve spool **2** via release valve **6**.

Pressure pushes ride control valve spool **2** against force of return spring. Ride control valve spool **2** thus connects lifting cylinder piston side **11** to ride control hydro accumulators **13** and lifting cylinder ring side **10** to hydraulic tank **12**.

2.4 Release valve

If pressure in ride control hydro accumulators **13** is higher than on lifting cylinder piston side **11**, there is a perceptible jolt when ride control is activated. Release valve **6** prevents that jolt.

For that purpose, lifting cylinder piston side **11** pressure acts on release valve **6**. If ride control solenoid valve **7** is energised, pressure from ride control accumulators **13** is applied to other side of release valve **6**. If that pressure is higher than pressure on lifting cylinder piston side **11** and spring force, release valve **6** connects ride control hydro accumulators **13** to hydraulic tank **12**.

Only when pressure in ride control hydro accumulators **13** has dropped sufficiently does release valve **6** pass oil through to ride control valve spool **2**.

12	Preload valve for 2nd tank duct	45	Throttle check valve	76	Throttle
13	Tilt cylinder spool valve	46	Throttle 1.2 mm	77	Throttle
14	Throttle 1.0 mm	47	Throttle 0.6 mm	78	Right lift cylinder
15	Strainer	50	Pipe break protection valve block (tilt cylinder)	80	Stabilization module
16	Strainer	51	Throttle check valve	81	Ride control valve spool
17	Throttle 1.0 mm	52	Pipe break protection valve	82	Throttle 2.0 mm
18	Tilt cylinder pressure balance	53	Check valve	83	Throttle 0.3 mm
19	Replenishing valve for tilting out	54	Safety valve	84	Throttle 0.6 mm
20	Secondary pressure relief valve for tilting out	55	Fine strainer	85	Release valve
21	Secondary pressure relief valve for tilting in	56	Throttle	86	Ride control solenoid valve
22	Lift cylinder spool valve	57	Throttle	87	Hydro accumulator relief valve
23	Throttle 0.8 mm	58	Tilt cylinder	88	Safety valve
24	Strainer	59	Ride control release solenoid valve	89	Hydro accumulator block
25	Strainer	60	Pipe-break protection valve block (left lift cylinder)	90	Ride control hydro accumulator
26	Throttle 0.8 mm	61	Throttle check valve	91	Ride control hydro accumulator
27	Lift cylinder pressure balance	62	Pipe break protection valve	92	Ride control hydro accumulator
28	Feeder valve for lowering	63	Check valve		
29	Feeder valve for lowering	64	Safety valve		

Name	Test point	Name	Test point	Name	Test point
LSA	Load sensing signal for working pump	MV	Servo pressure	PA	Working pump high pressure
MT	Servo pressure for tilt-out function	MX	Ride control hydro accumulator charge pressure	X	Venting connection (3x)

Tab. 205: Test points

BMK	Function	BMK	Function	BMK	Function
B90	Pressure sensor for weighing device (piston side) (from serial number 54428)	Y20	Solenoid for ride control	Y32a	Proportional solenoid for lowering
B91	Pressure sensor for weighing device (ring side) (from serial number 54428)	Y31a	Proportional solenoid for tilting out	Y32b	Proportional solenoid for lifting
Y14	Solenoid for servo pressure	Y31b	Proportional solenoid for tilting in	Y200	Solenoid for release of ride control (option)

Tab. 206: Equipment codes

If a pipe breaks, pipe break protection system prevents lift arms from falling and bucket from tipping in an uncontrolled manner. Depending on the hydraulic cylinder and lift arm type, the pipe break protection system disconnects the piston side or the ring side from the control valve block.

Name	Test point	Name	Test point	Name	Test point
MK2	Clutch 2 shift pressure (K2)	MSy	System pressure	PL1	High pressure for steering pump or emergency steering pump
MKR	Clutch shift pressure for reverse travel direction (KR)	MT	Servo pressure for tilt-out function		

Tab. 212: Test points

- A) Test point on working pump
 B) Test point on control valve block

BMK	Function	BMK	Function	BMK	Function
B3	Emergency steering pressure switch	M8	Electric motor for emergency steering pump	Y14	Solenoid for servo pressure
B3a	Emergency steering check pressure switch	R1	Inching function angle sensor	Y20	Solenoid for ride control
B8	Hydraulic oil temperature sensor	Y1	Proportional solenoid for clutch 2 (K2)	Y31a	Proportional solenoid for tilting out
B12	Brake light pressure switch	Y2	Proportional solenoid for forward travel direction clutch (KV)	Y31b	Proportional solenoid for tilting in
B19	Brake accumulator pressure sensor	Y3	Proportional solenoid for 1st optional connection	Y32a	Proportional solenoid for lowering
B80	Pressure sensor for duct AB	Y4	Proportional solenoid for reverse travel direction clutch (KR)	Y32b	Proportional solenoid for lifting
B81	Pressure sensor for duct A	Y5	Proportional solenoid for clutch 1 (K1)	Y33a	Proportional solenoid for 3rd function A3
B85	Filter bypass switch	Y6	Proportional solenoid for 2nd optional connection	Y33b	Proportional solenoid for 3rd function B3
B86	Gear oil temperature sensor	Y7	Proportional solenoid for position control	Y53	Solenoid for opening quick coupler
B90	Pressure sensor for weighing device (piston side) (from serial number 54428)	Y10	Parking brake solenoid	Y53a	Quick coupler load sensing signal solenoid
B91	Pressure sensor for weighing device (ring side) (from serial number 54428)	Y13	Fan speed proportional solenoid		

Tab. 213: Equipment codes

090 Steering system

Contents

090.1	Steering system overview <i>L566-1484/0-50692;</i>	090-3
090.2	Steering system overview <i>L566-1484/50693-;</i>	090-8
090.3	Steering pump <i>L566-1484;</i>	090-13
090.4	Servostat <i>L566-1484;</i>	090-19
090.5	Steering cylinder	090-22
090.5.1	Steering cylinder <i>L566-1484;</i>	090-22
090.5.2	Steering stabilisation valve block <i>L566-1484/0-50692;</i>	090-25
090.5.3	Steering stabilisation valve block <i>L566-1484/50693-;</i>	090-26
090.6	Emergency steering	090-28
090.6.1	Emergency steering overview <i>L566-1484;</i>	090-28
090.6.2	Emergency steering pump <i>L566-1484;</i>	090-30
090.6.3	Emergency steering electronics	090-32
	090.6.3.1 Overview of electrical controls of emergency steering system <i>L566-1484;</i>	090-32
	090.6.3.2 Emergency steering pressure switch <i>L566-1484;</i>	090-36
	090.6.3.3 Emergency steering check pressure switch <i>L566-1484;</i>	090-37
090.7	Joystick steering	090-39
090.7.1	Overview of joystick steering <i>L566-1484/0-50692;</i>	090-39
090.7.2	Overview of joystick steering <i>L566-1484/50693-54742;</i>	090-46
090.7.3	Overview of joystick steering <i>L566-1484/54743-;</i>	090-52

2 Function




Fig. 455: Hydraulic diagram of the steering system (steering to the left)

- | | | |
|--|--|--|
| 1 Hydraulic tank | 24 Throttle | 50 Servostat |
| 2 Return filter | 25 LS-pressure cut-off | 51 Valve spool |
| 3 Main filter element 10 µm | 26 Flow regulator | 52 Metering pump |
| 4 Bypass valve 2.5 bar | 27 Throttle | 53 Secondary pressure relief valve for steering to left |
| 5 Strainer mesh 100 µm | 28 Fan pump and brake pump suction port | 54 Secondary pressure relief valve for steering to right |
| 6 Breather filter | 29 Working pump suction port drain valve | 55 Feeder valve for steering to left |
| 7 Fine filter | 30 Working pump | 56 Feeder valve for steering to the right |
| 8 Outlet valve 0.65 bar | 31 Diesel engine | 60 Steering stabilization valve block |
| 9 Inlet valve 0.03 bar | 32 Oil supply for control valve block | 61 Replenishing valve for steering stabilization 0.5 bar |
| 10 Leak oil strainer 100 µm | 35 Emergency steering pump | 62 Replenishing valve for steering stabilization 0.5 bar |
| 11 Steel tank | 36 Gear pump | 63 Steering damper hydro accumulator |
| 12 Sight glass for hydraulic oil level | 37 Pressure relief valve | 64 Throttle check valve 2.0 mm |
| 13 Hydraulic tank drain valve | 40 Valve block for steering system | 65 Steering damper hydro accumulator |
| 14 Fan motor leak oil | 41 Check valve | 66 Throttle check valve 2.0 mm |

See next page for continuation of the image legend

LBH/11835199/19/21+20191218_090358/en

fast the wheel is turned. Metering pump **3** acts like a gear pump and delivers oil to steering cylinders every time steering wheel is turned.

Servostat also generates a load sensing signal **9** which regulates steering pump.

2.2 Secondary pressure relief valves

Secondary pressure relief valves protect steering system from excessive pressure caused by pressure peaks and external force.

2.3 Feeder valves

Replenishing valves protect steering cylinders from cavitation.

2.4 Flow booster




Fig. 468: Servostat: flow amplification

- | | | | |
|----------|------------------------------------|----------|--|
| Q | Flow rate in % | A | Flow rate via metering pump |
| U | Turns of steering wheel per minute | B | Flow rate directly to steering cylinders |

Valve spool consists of a inner spool and an outer spool. Both spools are held in position by centring springs.

At less than ten turns of steering wheel per minute, inner spool and outer spool turn together and deliver oil to metering pump.

At more than ten turns of steering wheel per minute, valve spools shift against each other due to greater resistance. This causes valve spools to release additional openings through which oil flows past metering pump directly to steering cylinders. This boosts flow rate by up to 60%.

2 Function

2.1 Basic function




Fig. 480: Hydraulic diagram of emergency steering pump (pump active)

- | | | | |
|----------|--------------------------------|----------|----------------------------------|
| 1 | Emergency steering pump | 4 | Suction port from hydraulic tank |
| 2 | Gear pump | 5 | Oil supply to servostat |
| 3 | Pressure relief valve | | |

BMK	Function
M8	Electric motor for emergency steering pump

Tab. 236: Equipment codes

Emergency steering pump 1 supplies steering system with oil for a short time if steering fails. To do so,, emergency steering pump 1 draws oil from hydraulic tank 4 and pumps it through steering system valve block to servostat 5.

If no oil is taken while emergency steering pump 1 is in operation, oil circulates via pressure relief valve 3 inside emergency steering pump 1.

Emergency steering pump 1 is powered by batteries.

2.2 Pump capacity and current consumption




Fig. 481: Emergency steering pump capacity and current consumption

- | | | | |
|----------|--------------------------------|-----------|----------------------|
| Q | Flow rate in litres per minute | Δp | Pump pressure in bar |
| I | Current consumption in amps | | |

Pump pressure Δp = output pressure - input pressure (tank pressure)




Fig. 490: Joystick steering system (steering to left) (from rear right)

- | | | | | | |
|----|--------------------------------------|----|--|----|---|
| 1 | Hydraulic tank | 11 | Collector pipe | 21 | Return flow to control valve block (housing preheating) |
| 2 | Return filter | 12 | Joystick steering control valve block | 22 | Working pump suction port drain valve |
| 3 | Breather filter | 13 | Return flow to leak oil strainer (via pilot control valve block) | 23 | Hydraulic tank drain valve |
| 4 | Return flow from control valve block | 14 | Return flow from compact brake valve (housing preheating) | 24 | Fan motor leak oil |
| 5 | Fan pump and brake pump suction port | 15 | Servostat | 25 | Return flow from compact brake valve and pilot control |
| 6 | Emergency steering pump | 16 | Steering stabilisation valve block | 26 | Shuttle valve |
| 7 | Steering pump | 17 | Throttle check valve 2.0 mm (only with joystick steering) | 27 | Orifice 0.8 mm |
| 8 | Working pump | 18 | Steering damper hydro accumulator | 28 | Orifice 0.8 mm |
| 9 | Valve block for steering system | 19 | Left steering cylinder with stroke limit damping | 29 | Pressure relief valve for stroke limit damping |
| 10 | Hydraulic oil cooler | 20 | Right steering cylinder with stroke limit damping | 30 | Pressure relief valve for stroke limit damping |

sle01835b

LBH11835189/19/21+20191218_090358/en

1	Hydraulic tank	30	Working pump	62	Return line from fan motor
2	Return filter	31	Diesel engine	65	Collector pipe
3	Main filter element 10 µm	32	Oil supply for control valve block	66	Preload valve for steering cylinder replenishing function 5 bar
4	Bypass valve 2.5 bar	35	Emergency steering pump	67	Bypass valve for hydraulic oil cooler 1.5 bar
5	Strainer mesh 100 µm	36	Gear pump	68	Hydraulic oil cooler
6	Breather filter	37	Pressure relief valve	70	Servostat
7	Fine filter	40	Valve block for steering system	71	Valve spool
8	Outlet valve 0.65 bar	41	Check valve	72	Metering pump
9	Inlet valve 0.03 bar	42	Check valve	73	Secondary pressure relief valve for steering to left
10	Leak oil strainer 100 µm	45	Joystick steering control valve block	74	Secondary pressure relief valve for steering to right
11	Steel tank	46	Shuttle valve	75	Feeder valve for steering to left
12	Sight glass for hydraulic oil level	47	Servo oil strainer for main spool valve	76	Feeder valve for steering to the right
13	Hydraulic tank drain valve	48	Servo pressure reducing valve for main spool valve	80	Steering stabilisation valve block
14	Fan motor leak oil	49	Servo oil strainer for emergency spool valve	81	Replenishing valve for steering stabilisation 0.5 bar
15	Return flow from compact brake valve and pilot control	50	Servo pressure reducing valve for emergency spool valve	82	Replenishing valve for steering stabilisation 0.5 bar
16	Return flow from control valve block	51	Check valve	83	Steering damper hydro accumulator
20	Steering pump	52	Main spool valve	84	Throttle check valve 2.0 mm
21	Axial piston rotary group	53	Cut-off valve for main spool valve	85	Steering damper hydro accumulator
22	Return piston	54	Solenoid valve for safety circuit	86	Throttle check valve 2.0 mm
23	Positioning piston	55	Control block section for emergency steering function	87	Left steering cylinder with stroke limit damping
24	Throttle	56	Emergency spool valve	88	Pressure relief valve for stroke limit damping
25	LS-pressure cut-off	57	Return flow to leak oil strainer (via pilot control valve block)	89	Right steering cylinder with stroke limit damping
26	Flow regulator	58	Shuttle valve	90	Pressure relief valve for stroke limit damping
27	Throttle	59	Orifice 0.8 mm	91	Return flow to control valve block (housing preheating)
28	Fan pump and brake pump suction port	60	Orifice 0.8 mm		
29	Working pump suction port drain valve	61	Return flow from compact brake valve (housing preheating)		

Name	Test point	Name	Test point	Name	Test point
M A2	Servo pressure for steering to the left (emergency spool valve)	M DMV1	Pressure to servo pressure reducing valve for main spool valve	PL/	Steering pump high pressure

flow from the steering pump **15** to the steering cylinders. In addition, a load-sensing signal **23** is generated that is fed back to the steering pump.

2.3 Steering in emergency steering mode

Joystick steering in emergency mode fundamentally functions in the same way as in normal mode. However, the safety circuit solenoid valve **10** is not energised. As a result, the emergency spool valve **13** is supplied with pilot control oil. At the same time, the main spool valve shut-off valve **9** disconnects the main spool valve **8** from the steering cylinders. That makes sure that emergency steering function still functions even if the main spool valve **8** jams.

The emergency spool valve is supplied with pilot control oil by its own pressure reducing valve **6**.

2.4 Improved response of the main spool valve

Control oil constantly flows through the external line on the joystick steering control valve block **1** when the main spool valve **8** is activated, and then passed through the orifice **20** or **21** to the hydraulic **16** tank. This improves the response of main spool valve **8**.

2.5 Variable *CXJSValveBlockGen2*

Variable *CXJSValveBlockGen2* must be set to **0**.

090.7.5 Joystick steering control block

Valid for: L566-1484/54743-;

Version: generation 2




Fig. 504: Joystick steering function in emergency mode


- | | | |
|--|--|--------------------------------|
| 1 Joystick steering control block | 3 Main spool valve | 5 Emergency spool valve |
| 2 Solenoid valve for safety circuit | 4 Control block section for emergency steering function | |

BMK	Function	BMK	Function	BMK	Function
A15	Central control unit (Master4)	B71	Emergency spool valve position sensor	Y72	Proportional solenoid for steering to left (emergency spool valve)

LBH/11835199/19/21+20191218_090358/en

G2065237

1.1 Layout



G2072475

Fig. 510: Electronic control unit for joystick steering

1 Left armrest

1 Joystick steering control valve block

BMK	Function	BMK	Function	BMK	Function
A4b	Joystick steering relay board	B67	Articulation angle sensor	Y70	Proportional solenoid for steering to left (main spool valve)
A15	Central control unit (Master4)	B70	Main spool valve position sensor	Y71	Proportional solenoid for steering to left (spool valve for emergency steering function)
A17b	Output module A17b	B71	Emergency spool valve position sensor	Y72	Proportional solenoid for steering to left (emergency spool valve)
A29	Joystick module	S71	Joystick steering switch	Y73	Proportional solenoid for steering to right (emergency spool valve)
A29a	Joystick electronics	S72	Joystick steering switch (armrest)	Y74	Solenoid valve for safety circuit

Tab. 274: Equipment codes

Joystick module **A29** and electronics of joystick **A29a** communicate via an SPI bus.

Joystick module **A29** also receives signals from following components:

- Joystick steering switch **S71**
- Joystick steering switch (armrest) **S72**
- Articulation angle sensor **B67**

Joystick module **A29** forwards these signals via CAN lines 2 and 3 to central control unit **A15**.

LBH/11835199/19/211+20191218_090358/en

At same time, oil flows through connecting ducts **8** and **12** to readjusting springs. When oil pressure in brake circuits is high enough, oil pressure and return springs push pressure regulating pistons back against pressure regulating spring **14**. Connection to hydro accumulators is interrupted again. This maintains a steady braking pressure in brake circuits as long as pedal position remains unchanged.

If inching brake pedal **1** is pushed down further, oil pressure also increases in brake circuits and higher oil pressure is required to push pressure regulator pistons back against pressure regulator spring **14**.

2.6 Parking brake

When parking brake solenoid valve Y10 is energised, oil flows from parking brake hydro accumulator to disc brake. Parking brake disengages.

2.7 Brake light pressure switch

Pressure switch for brake light B12 in 2nd brake circuit switches on brake light at a brake pressure of 5 ± 0.5 bar.

2.7.1 Brake accumulator pressure sensor

Brake accumulator pressure sensor B19 measures pressure in hydro accumulator of service brake and sends this to central control unit. If pressure falls below a set value, *brake accumulator pressure too low* symbol appears in display.

In service brake, brake pressure constantly increases up to cut-out pressure and then slowly and steadily falls back to cut-in pressure. If value that central control unit receives from brake accumulator pressure sensor is not plausible or not constant for a certain time, central control unit detects a faulty sensor and generates a service code.

110.2 Overview of electrical system

Valid for: L566-1484/54428-;

Operating voltage of machine is 24 V. Batteries (2 x 12 V) are connected in series.

Two batteries are installed in left ballast weight.

Following illustrations and tables contain components of electrical system (except for diesel engine).

1 Layout




Fig. 537: Machine view from left

Position	Function	Position	Function
A4	Fuse and relay board	G1	Battery
A15	Central control unit	G2	Battery
A30	LiDAT module	K04	Heater flange relay
A16a	Input module A16a	K11	Emergency steering pump relay
A16b	Input module A16b	K15.H	Relay for electric battery main switch
A17a	Output module A17a	M4	Windscreen washer pump
A17b	Output module A17b	M9	Rear screen washer pump
B3	Emergency steering pressure switch	M13	Condenser fan (top)
B12	Brake light pressure switch	M13a	Condenser fan (bottom)
B19	Brake accumulator charge pressure sensor	S15	Battery main switch
B27	Air conditioning pressure switch	S224	Engine bonnet button
B710	Water sensor for Separ filter	X60a	Diesel engine diagnostic plug


LBH/11835189/19/211-20191218_090358/en

12418288
ITEM CODE
DRAWING INDEX
105

Stufe 4 GG_23.11.18 E_Hauptschalter
PROJECT
1333 9010 01 00
DRAWING NUMBER

1333 9010 01 00
DRAWING NUMBER

ISO 15071/5: The reproduction, distribution and utilization of this document or its contents in any form or by any means without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility, model or design registration.



MACHINE TYPE
LIDOS UNIT

SERIAL NUMBER
XXXXX

IGNITION LOCK ; BATTERIES ; GENERATOR ;
E PLAN

STEP 4 FACELIFT DOWN Snr.: 54427; L5661/1332 STEP 4 FACELIFT DOWN Snr.: 54430; L5661/1464 STEP 4 FACELIFT DOWN Snr.: 54472
STEP 4 FACELIFT DOWN Snr.: 54428; L5761/1333 STEP 4 FACELIFT DOWN Snr.: 54431; L5661/1334 STEP 4 FACELIFT DOWN Snr.: 54472

PAGE 24 OF 26.04.2019 10:08
CREATION DATE

12418288

ITEM CODE

Stufe 4 GG_23.11.18 E_Hauptschalter

1333 90100 01 00

DRAWING NUMBER

Violations require compensation. All rights reserved in the case of patent, utility, model or design registration. The reproduction, distribution and utilization of this document or its contents to others without express authorization is prohibited.

MACHINE TYPE

LIDOS UNIT


SERIAL NUMBER

XXXXX

WINDSCREEN WASHER FRONT ; HOOTER ; HORN OPERATION
E PLAN






PAGE 34 OF

CREATION DATE 26.04.2019 10:08





1 2 3 4 5 6 7 8

A B C D E F



DIAGNOSIS TRANSMISSION

EXTENSION PRESSURE SWITCH





MACHINE TYPE
LIDOS UNIT

SERIAL NUMBER
XXXXX

LIEBHERR
 FACTORY LBH

ELECTRICAL HOOD OPENING
 E PLAN

1 2 3 4 5 6 7 8



SWITCH BUMPER AT REAR



LIDEC2

Ident Nr.: LH-ECU-LIDEC2

Modul Nr.:
Modulname:

Pin	vom 1		vom 2		EA	SHEET	ADDRESS	Pin	vom 1		vom 2		PLUG	Pin
	ADDRESS	EA	ADDRESS	EA					ADDRESS	EA	ADDRESS	EA		
1	A700.VCC-G1	5V	DIFFERENTIAL PRESSURE [H5V]	MACHINE-SIDE A	X1	1	A700.DD_L-G1	Kaltstartemp	MACHINE-SIDE B	X2	1			
2	A700.ABV-G1	Signal	DIFFERENTIAL PRESSURE [Sig]	MACHINE-SIDE A	X1	2	A700.DI_KL15	CLAMP 15	MACHINE-SIDE B	X2	2			
3	A700.KL_31_PWR	GND	DIFFERENTIAL PRESSURE [GND]	MACHINE-SIDE A	X1	3	A700.KL_31_PWR	CLAMP 31 elektr. (PS2_GND) [GND]	MACHINE-SIDE B	X2	3			
4	A700.CAN-G2L	Low	CAN-BUS-Interface 2 [Low]	MACHINE-SIDE A	X1	4	A700.KL30_ELEK	CLAMP 30 elektr. / PS2	MACHINE-SIDE B	X2	4			
5	A700.VCC-G1	5V	AR PRESSURE SENSOR 1 [H5V]	MACHINE-SIDE A	X1	5	A700.DD_L-G2	Fehlfunktion im EMERGENCY OPERATION	MACHINE-SIDE B	X2	5			
6	A700.ABV-G2	Signal	AR PRESSURE SENSOR 1 [Sig]	MACHINE-SIDE A	X1	6	A700.KL_31_PWR	ACCELERATOR ENCODER 1 [GND]	MACHINE-SIDE B	X2	6			
7	A700.KL_31_PWR	GND	AR PRESSURE SENSOR 1 [GND]	MACHINE-SIDE A	X1	7	A700.UAH-G1	ACCELERATOR ENCODER 1 [Sig]	MACHINE-SIDE B	X2	7			
8	A700.CAN-G2L	Low	CAN-BUS-Interface 2 [Low]	MACHINE-SIDE A	X1	8	A700.UBAT-G1	ACCELERATOR ENCODER 1 [UBATT]	MACHINE-SIDE B	X2	8			
9	A700.VCC-G2	5V	DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE [H5V]	MACHINE-SIDE A	X1	9	A700.DD_L-G3	SCR CONTROL COOLING WATER HEATING	MACHINE-SIDE B	X2	9			
10	A700.ABV-G3	Signal	DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE [Sig]	MACHINE-SIDE A	X1	10	A700.KL_31_PWR	ACCELERATOR ENCODER 2 [GND]	MACHINE-SIDE B	X2	10			
11	A700.KL_31_PWR	GND	DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE [GND]	MACHINE-SIDE A	X1	11	A700.UAH-G2	ACCELERATOR ENCODER 2 [Sig]	MACHINE-SIDE B	X2	11			
12	A700.CAN-G2T	Term.	CAN-BUS-Interface 2 [Term.]	MACHINE-SIDE A	X1	12	A700.UBAT-G2	ACCELERATOR ENCODER 2 [UBATT]	MACHINE-SIDE B	X2	12			
13	A700.VCC-G2	5V	SCR Differenzdrucksensor 1 [H5V]	MACHINE-SIDE A	X1	13	A700.DD_L-G4	SCR Supply MODULE/ENGINE (Bosch)	MACHINE-SIDE B	X2	13			
14	A700.ABV-G4	Signal	SCR Differenzdrucksensor 1 [Sig]	MACHINE-SIDE A	X1	14	A700.KL_31_PWR	SCR AIR PRESSURE SENSOR (Alcoa) #	MACHINE-SIDE B	X2	14			
15	A700.KL_31_PWR	GND	SCR Differenzdrucksensor 1 [GND]	MACHINE-SIDE A	X1	15	A700.ABV-G5	SCR AIR PRESSURE SENSOR (Alcoa) #	MACHINE-SIDE B	X2	15			
16	A700.CAN-G2H	High	CAN-BUS-Interface 2 [High]	MACHINE-SIDE A	X1	16	A700.VCC-G3	SCR AIR PRESSURE SENSOR (Alcoa) #	MACHINE-SIDE B	X2	16			
17	A700.UBAT-G4	UBATT	AIR FILTER VACUUM SWITCH 1 [UBATT]	MACHINE-SIDE A	X1	17	A700.DD-G1	HEATER FLANGE RELAY 1	MACHINE-SIDE B	X2	17			
18	A700.ABV-G4	Signal	AIR FILTER VACUUM SWITCH 1 [Sig]	MACHINE-SIDE A	X1	18	A700.KL_31_PWR	AirBlue-PRESSURE (Denoxo)	MACHINE-SIDE B	X2	18			
19	A700.KL_31_PWR	GND	RESERVE [GND] [GND]	MACHINE-SIDE A	X1	19	A700.ABV-G6	AirBlue-PRESSURE (Denoxo)	MACHINE-SIDE B	X2	19			
20	A700.CAN-G2H	High	CAN-BUS-Interface 2 [High]	MACHINE-SIDE A	X1	20	A700.VCC-G3	AirBlue-PRESSURE (Denoxo)	MACHINE-SIDE B	X2	20			
21	A700.KL_31_PWR	GND	RESERVE [GND] [GND]	MACHINE-SIDE A	X1	21	A700.DD-G2	HEATER FLANGE RELAY 2	MACHINE-SIDE B	X2	21			
22	A700.DK-G1	Signal	MASTERSLAVE REQUEST [Sig]	MACHINE-SIDE A	X1	22	A700.DD-G6	RESERVE (DO-G6)	MACHINE-SIDE B	X2	22			
23	A700.KL_31_PWR	GND	SCR TEMPERATURE SENSOR 1 [GND]	MACHINE-SIDE A	X1	23	A700.DH-G3	Notizenzahl REQUEST [Sig]	MACHINE-SIDE B	X2	23			
24	A700.TH-G1	Signal	SCR TEMPERATURE SENSOR 1 [Sig]	MACHINE-SIDE A	X1	24	A700.DH-G2	RELAY REQUEST (KLS04) [Sig]	MACHINE-SIDE B	X2	24			
25	A700.PWM_F-G1-B	A	SCR Airblue PUMP [A]	MACHINE-SIDE A	X1	25	A700.DD-G5	RELAY ENGINE Smart Komponente	MACHINE-SIDE B	X2	25			
26	A700.KL_31_PWR	GND	AirBlue LEVEL (Wema) [S]	MACHINE-SIDE A	X1	26	A700.DH-G6	NO-Hall REQUEST (LWE) [Sig]	MACHINE-SIDE B	X2	26			
27	A700.KL_31_PWR	GND	SCR TEMPERATURE SENSOR 2 [GND]	MACHINE-SIDE A	X1	27	A700.DH-G5	Profisanktionung [Sig]	MACHINE-SIDE B	X2	27			
28	A700.TG-G2	Signal	SCR TEMPERATURE SENSOR 2 [Sig]	MACHINE-SIDE A	X1	28	A700.DH-G4	Erkennung Aukler OPERATION (LWE) [Sig]	MACHINE-SIDE B	X2	28			
29	A700.PWM_F-G1-B	B	SCR Airblue PUMP [B]	MACHINE-SIDE A	X1	29	A700.KL_31_PWR	RESERVE [GND] [GND]	MACHINE-SIDE B	X2	29			
30	A700.KL_31_PWR	GND	AirBlue LEVEL (Wema) [G]	MACHINE-SIDE A	X1	30	A700.LSB-G1-GND	LSB-Interface [GND]	MACHINE-SIDE B	X2	30			
31	A700.KL_31_PWR	GND	SCR TEMPERATURE SENSOR 3 [GND]	MACHINE-SIDE A	X1	31	A700.LSB-G1-LSB	LSB-Interface [LSB]	MACHINE-SIDE B	X2	31			
32	A700.TH-G3	Signal	SCR TEMPERATURE SENSOR 3 [Sig]	MACHINE-SIDE A	X1	32	A700.LSB-G1-V	LSB-Interface	MACHINE-SIDE B	X2	32			
33	A700.KL_31_PWR	GND	RESERVE [GND] [GND]	MACHINE-SIDE A	X1	33	A700.DD_L-G5	SCR CONTROL ELECTRICAL HEATING 1	MACHINE-SIDE B	X2	33			
34	A700.KL_31_PWR	GND	Maintenance [GND]	MACHINE-SIDE A	X1	34	A700.RS232-G1-GND	RS232-BUS-Interface [GND]	MACHINE-SIDE B	X2	34			
35	A700.KL_31_PWR	GND	HYDRAULIC OIL TEMPERATURE SENSOR [GND]	MACHINE-SIDE A	X1	35	A700.RS232-G1-TxD	RS232-BUS-Interface [TxD]	MACHINE-SIDE B	X2	35			
36	A700.TH-G4	Signal	HYDRAULIC OIL TEMPERATURE SENSOR [Sig]	MACHINE-SIDE A	X1	36	A700.RS232-G1-RxD	RS232-BUS-Interface [RxD]	MACHINE-SIDE B	X2	36			
37	A700.DK-G1-SUP	Supply	Maintenance [Supply]	MACHINE-SIDE A	X1	37	A700.KL_31_PWR	RESERVE [GND] [GND]	MACHINE-SIDE B	X2	37			
38	A700.DK-G1-HO	Supply	Maintenance [Sig]	MACHINE-SIDE A	X1	38	A700.AB3V-G2	HEATER FLANGE RELAY 1 [Sig]	MACHINE-SIDE B	X2	38			
39	A700.KL_31_PWR	GND	SLEW ANGLE [GND]	MACHINE-SIDE A	X1	39	A700.CAN-G-H	CAN-BUS-Interface 1 [High]	MACHINE-SIDE B	X2	39			
40	A700.TH-G5	Signal	SLEW ANGLE [Sig]	MACHINE-SIDE A	X1	40	A700.CAN-G-H	CAN-BUS-Interface 1 [High]	MACHINE-SIDE B	X2	40			
41	A700.DOC-G3	UBATT	HEATING	MACHINE-SIDE A	X1	41	A700.DD_L-G6	SCR CONTROL ELECTRICAL HEATING 2	MACHINE-SIDE B	X2	41			
42	A700.UBAT-G5	GND	AIR FILTER VACUUM SWITCH 2 [UBATT]	MACHINE-SIDE A	X1	42	A700.AB3V-G3	HEATER FLANGE RELAY 2 [Sig]	MACHINE-SIDE B	X2	42			
43	A700.KL_31_PWR	GND	WATER in FUEL SENSOR 1 [GND]	MACHINE-SIDE A	X1	43	A700.CAN-G-L	CAN-BUS-Interface 1 [Low]	MACHINE-SIDE B	X2	43			
44	A700.TH-G6	Signal	WATER in FUEL SENSOR 1 [Sig]	MACHINE-SIDE A	X1	44	A700.CAN-G1-L	CAN-BUS-Interface 1 [Low]	MACHINE-SIDE B	X2	44			
45	A700.DOC-G4	Signal	VENTILATION FLAP	MACHINE-SIDE A	X1	45	A700.KL_31_PWR	RESERVE [GND] [GND]	MACHINE-SIDE B	X2	45			
46	A700.AB3V-G5	Signal	AIR FILTER VACUUM SWITCH 2 [Sig]	MACHINE-SIDE A	X1	46	A700.UBAT-G3	COOLANT LEVEL SWITCH [UBATT]	MACHINE-SIDE B	X2	46			
47	A700.KL_31_PWR	GND	Batterietemperatursensor [GND]	MACHINE-SIDE A	X1	47	A700.CAN-G3-T	CAN-BUS-Interface 3 [Term.]	MACHINE-SIDE B	X2	47			
48	A700.TH-G7	Signal	Batterietemperatursensor [Sig]	MACHINE-SIDE A	X1	48	A700.CAN-G1-T	CAN-BUS-Interface 3 [Term.]	MACHINE-SIDE B	X2	48			
49	A700.KL_31_PWR	GND	RESERVE [GND] [GND]	MACHINE-SIDE A	X1	49	A700.DD_L-G7	SCR CONTROL ELECTRICAL HEATING 3	MACHINE-SIDE B	X2	49			
50	A700.PWM_H-G1H	Plus	SCR Reversing Valve (Bosch) [H]	MACHINE-SIDE A	X1	50	A700.AB3V-G1	COOLANT LEVEL SWITCH [Sig]	MACHINE-SIDE B	X2	50			
51	A700.KL_31_PWR	GND	WATER CIRCULATION TEMPERATURE SENSOR [GND]	MACHINE-SIDE A	X1	51	A700.CAN-G3-L	CAN-BUS-Interface 3 [Low]	MACHINE-SIDE B	X2	51			
52	A700.TH-G8	Signal	DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE [Sig]	MACHINE-SIDE A	X1	52	A700.CAN-G3-L	CAN-BUS-Interface 3 [Low]	MACHINE-SIDE B	X2	52			
53	A700.PWM_H-G1H	Minus	SCR Reversing Valve (Bosch) [H]	MACHINE-SIDE A	X1	53	A700.KL_31_PWR	RESERVE [GND] [GND]	MACHINE-SIDE B	X2	53			
54	A700.KL_31_PWR	GND	AirBlue TEMPERATURE (Wema) [G]	MACHINE-SIDE A	X1	54	A700.NC	EMPTY	MACHINE-SIDE B	X2	54			
55	A700.TH-G9	Signal	AirBlue TEMPERATURE (Wema) [S]	MACHINE-SIDE A	X1	55	A700.CAN-G3-H	CAN-BUS-Interface 3 [High]	MACHINE-SIDE B	X2	55			
56	A700.KL_31_PWR	GND	AirBlue TEMPERATURE (Wema) [S]	MACHINE-SIDE A	X1	56	A700.CAN-G3-H	CAN-BUS-Interface 3 [High]	MACHINE-SIDE B	X2	56			
57	A700.KL_31_PWR	GND	Kühlmittel-CONTROL 1 [GND]	MACHINE-SIDE A	X1	57	A700.KL_31_PWR	CLAMP 31Power (PS1_GND) [GND]	MACHINE-SIDE B	X2	57			
58	A700.KL_31_PWR	GND	Kühlmittel-CONTROL 2 [GND]	MACHINE-SIDE A	X1	58	A700.KL_31_PWR	CLAMP 31Power (PS1_GND) [GND]	MACHINE-SIDE B	X2	58			
59	A700.KL_31_PWR	GND	AIR CHANGE OVER VALVE [GND]	MACHINE-SIDE A	X1	59	A700.KL_31_PWR	CLAMP 31Power (PS1_GND) [GND]	MACHINE-SIDE B	X2	59			
60	A700.PWM_CFB-G	Signal	Kühlmittel-CONTROL 1	MACHINE-SIDE A	X1	60	A700.KL_31_PWR	CLAMP 30Power / PSI	MACHINE-SIDE B	X2	60			
61	A700.PWM_CFB-G2	Signal	Kühlmittel-CONTROL 2	MACHINE-SIDE A	X1	61	A700.KL_31_PWR	CLAMP 30Power / PSI	MACHINE-SIDE B	X2	61			
62	A700.PWM_CFB-G3	Signal	AIR CHANGE OVER VALVE	MACHINE-SIDE A	X1	62	A700.KL_31_PWR	CLAMP 30Power / PSI	MACHINE-SIDE B	X2	62			

13015175: The reproduction, distribution and utilization of this document in any form or by any means, without express authorization is prohibited.
Violations require compensation. All rights reserved in the case of patent, utility, model or design registration.


MACHINE TYPE
LIDOS UNIT

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OPTION BACK-UP ALARM ACOUSTIC
E PLAN


PAGE **84** OF
CREATION DATE **26.04.2019 10:08**



A B C D E F
8 7 6 5 4 3 2 1

PROJECT: Stufe 4 GG_23.11.18 E_Hauptschalter
 ITEM CODE: 12418288
 DRAWING NUMBER: 1333 90100 01 00
 DRAWING INDEX: 105

Violations require compensation. All rights reserved in the case of patent, utility, model or design registration.
 L3S (S18)S: The reproduction, distribution and utilization of this document or its contents to others without express authorization is prohibited.



PROJECT: Stufe 4 GG_23.11.18 E_Hauptschalter
 ITEM CODE: 12418288
 DRAWING NUMBER: 1333 90100 01 00
 DRAWING INDEX: 105

Violations require compression. All rights reserved in the case of patent, utility, model or design registration.
 The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited.

MACHINE TYPE
LIDOS UNIT


SERIAL NUMBER
XXXXX

LIEBHERR
 FACTORY LBH


OPTION LH WEIGHING DEVICE; AIR FILTER VACUUM SWITCH G1
 E PLAN

PAGE 114 OF

CREATION DATE 26.04.2019 10:08



Grid coordinates: 1, 2, 3, 4, 5, 6, 7, 8 (horizontal); A, B, C, D, E, F (vertical)



12418288
ITEM CODE

105
DRAWING INDEX

PROJECT
Stufe 4 6G_23.11.18 E_Hauptschalter
1333 901001 00
DRAWING NUMBER

1333 901001 00
DRAWING NUMBER

1501616: The reproduction, distribution and utilization of this document or its contents to others without express authorization is prohibited.
Violations require compensation. All rights reserved in the case of patent, utility, model or design registration.

MACHINE TYPE
LIDOS UNIT


SERIAL NUMBER
XXXXX

VERSION 1 MULTILEVER CONTROL F-N-R + 3 PUSH-BUTTON SWITCH
E PLAN

TO SERIAL NUMBER.....

PAGE 134 OF
CREATION DATE 26.04.2019 10:08

CXMH1 Module=0



1 2 3 4 5 6 7 8

A B C D E F

12418288
105

ITEM CODE DRAWING INDEX

PROJECT **Stufe 4 GG_23.11.18 E_Hauptschalter**
1333 90100 01 00

DRAWING NUMBER

1501816: The reproduction, distribution and utilization of this document or its contents in any form or by any means without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility, model or design registration.

MACHINE TYPE
LIDOS UNIT

SERIAL NUMBER
XXXXX











LIEBHERR
FACTORY LBH

VERSION 2 LOG HANDLER VAN-R +3 PUSH-BUTTON SWITCH
E PLAN







PAGE 144 OF

CREATION DATE 26.04.2019 10:08

1 2 3 4 5 6 7 8



1 2 3 4 5 6 7 8



RSO 16016. The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

REPLACEMENT FOR MARKED DATE 25.07.2016 12:14


0
CHECKED Immbua0
TECHNICAL REFEREE

Imbova0
A3
FACTORY LMB

DESIGNATION
ELECTRICAL WIRING DIAGRAM

DESCRIPTION
BOOST AIR TEMPERATURE SENSOR, COOLANT TEMPERATURE SENSOR, FUEL TEMPERATURE SENSOR

ARTICLE CODE 10139857
DRAWING NUMBER 96 002 9307 90
INDEX 003
SYSTEM =M
LOCATION FROM 13 TO 19
+M




se/00356

Fig. 545: Plug connections on the central control unit (Master4)

- | | | | |
|---|--------------------------------|----|---------------------------------------|
| 1 | PWR.X plug for power supply | 6 | Central control unit housing |
| 2 | CAN.X plug for CAN connections | 7 | Connector COM1.X |
| 3 | LAN 1 plug (diagnostics) | 8 | Connector COM2.X |
| 4 | LAN 2 connector | 9 | Connector COM3.X |
| 5 | LAN 3 connector | 10 | Plug COM4.X for diagnostics via RS232 |


Plug assignment



se/00358

Fig. 546: PWR.X plug

- | | | | |
|---|----------------|---|---------------|
| 1 | Earth (ground) | 4 | Not assigned |
| 2 | Terminal 15 | 5 | Housing earth |
| 3 | Not assigned | 6 | Terminal 30 |



se/00356

Fig. 547: CAN.X plug

- | | | | |
|---|-----------|---|------------|
| 1 | CAN 4 low | 5 | CAN 1 high |
| 2 | CAN 3 low | 6 | CAN 2 high |
| 3 | CAN 2 low | 7 | CAN 3 high |
| 4 | CAN 1 low | 8 | CAN 4 high |

LBH/11835199/19/211+20191218_090358/en

2.3 Output module addresses

Module	Address	Function
Output module	SFTY	Safety function
	OD04	Digital outputs
	OA16	Analogue power outputs
	IF02	Frequency measurement inputs

Tab. 311: Output module addresses

The CAN modules are addressed using the Sculi diagnostic software.

The following components are powered directly by the battery:

- Main fuse F01 (100 A)
- Heating flange fuse F02 (100 A)
- Emergency steering pump fuse F03 (200 A)
- Generator G3
- Starter M1

2.2 Batteries




Fig. 568: Battery

1 Battery

2 Anti-ignition cap

The battery consists of six cells, each with 2 volts. These are connected in series and can produce an operating voltage of 12 volts.

The battery 1 has a central gas release and is equipped with a return safety pilot 2.

The free ducts must be sealed with dummy plugs.

Charge levels				
Acid density at 27 °C	Charge level	Battery voltage	Voltage per cell	Remark
1.28 to 1.26	100%	over 12.60	over 2.10	Battery OK
1.25 to 1.24	75%	12.54 to 12.40	2.10 to 2.07	
1.24 to 1.18	50%	12.40 to 12.18	2.07 to 2.03	Charge battery
1.18 >	25%	12.18 >	2.03 >	Battery not OK

Tab. 316: Table of charge levels

If the machine is not started for 4 weeks, there is a risk of sulphate formation and storage deterioration on the battery. During longer standstill periods, the charge level must be regularly checked and the battery must be re-charged if necessary.

If the charge level falls below 50%, there is a risk of permanent damage to the battery.

2.3 Self-discharge of the battery

Even if the battery is not connected to any consumers, after a certain time it will be flat. This phenomenon is called self-discharge and is caused by chemical processes in the battery. The rate of self-discharge depends on the temperature, the acid-to-weight ratio and the battery technology.

- | | | | | | |
|---|---------------------------------------|----|---------------------------------------|----|-----------------|
| 5 | Auxiliary power take-off 2 (not used) | 12 | Parking brake | 19 | Gear oil filter |
| 6 | Hydrostat oil filter | 13 | Duct plate | 20 | Vent valve |
| 7 | Transmission valve block | 14 | Auxiliary power take-off 1 (not used) | | |

Name	Test point	Name	Test point	Name	Test point
MK1	Clutch 1 shift pressure (K1) A)	MKV	Clutch shift pressure for forward travel direction (KV) A)	MSy	System pressure A)
MK2	Clutch 2 shift pressure (K2) A)	MO1	Switching pressure for 1st optional connection B)		
MKR	Clutch shift pressure for reverse travel direction (KR) A)	MO2	Switching pressure for 2nd optional connection B)		

Tab. 321: Test points

A) Thread M10x1; tightening torque 6 Nm

B) Thread M12x1.5; tightening torque 35 Nm

BMK	Function	BMK	Function	BMK	Function
A25	Transmission control unit TCU	Y1	Proportional solenoid for clutch 2 (K2)	Y5	Proportional solenoid for clutch 1 (K1)
B84	Speed sensor for reverse travel direction clutch	Y2	Proportional solenoid for forward travel direction clutch (KV)	Y6	Proportional solenoid for 2nd optional connection
B85	Filter bypass switch	Y3	Proportional solenoid for 1st optional connection		
B86	Gear oil temperature sensor	Y4	Proportional solenoid for reverse travel direction clutch (KR)		

Tab. 322: Equipment codes

2.3.4 Change from clutch K1 to clutch K2




Fig. 581: Change from clutch K1 to clutch K2

Name	Description	Name	Description	Name	Description
A	Duct A	ZS2	Sun gear 2	Z9	Gearwheel 9
B	Duct B	ZP1	Planetary gear 1	KV	Forward travel direction clutch
T1	Rotary group 1	ZP2	Planetary gear 2	KR	Reverse travel direction clutch
T2	Rotary group 2	ZH	Ring gear	K1	Clutch 1
W1	Shaft 1	Z6	Gearwheel 6	K2	Clutch 2
W2	Shaft 2	Z7	Gearwheel 7		
ZS1	Sun gear 1	Z8	Gearwheel 8		

Tab. 331: Key

At around 10 km/h the double yoke reaches its end position, with the rotary group T1 (pump) at the maximum angle of 44°. At the same time, the rotary group T2 (motor) is at the minimum angle of 0°, which means it does not displace any oil and therefore no longer transmits any power. The shaft W2 is thus driven 100% mechanically. This also drives rotary group T2 and changes its function from motor to pump. The rotary group T1 becomes a motor.

At the same time, the clutch K1 is opened and the clutch K2 is closed.

LBH/11835199/19/211-20191218_090358/en

- | | |
|--|---|
| <p>6 Secondary spool for forward travel direction clutch (KV)</p> <p>7 Proportional solenoid valve for 1st optional connection</p> <p>8 Secondary spool valve for 1st optional connection</p> <p>9 Proportional solenoid valve for reverse travel direction clutch (KR)</p> <p>10 Secondary spool for reverse travel direction clutch (KR)</p> <p>11 Proportional solenoid valve for clutch 1 (K1)</p> <p>12 Secondary spool for clutch 1 (K1)</p> <p>13 Proportional solenoid valve for 2nd optional connection</p> | <p>19 Port for forward travel direction clutch (KV)</p> <p>20 Port for 1st optional connection</p> <p>21 Port for reverse travel direction clutch (KR)</p> <p>22 Port for clutch 1 (K1)</p> <p>23 Port for 2nd optional connection</p> <p>24 Bearing lubrication for rotary groups, rotary group 2 shaft and planetary gear assembly</p> <p>25 Return line to transmission housing</p> |
|--|---|

BMK	Function	BMK	Function	BMK	Function
Y1	Proportional solenoid for clutch 2 (K2)	Y3	Proportional solenoid for 1st optional connection	Y5	Proportional solenoid for clutch 1 (K1)
Y2	Proportional solenoid for forward travel direction clutch (KV)	Y4	Proportional solenoid for reverse travel direction clutch (KR)	Y6	Proportional solenoid for 2nd optional connection

Tab. 336: Equipment codes

Clutches are shifted by means of transmission control valve block.

2.2 Main pressure valve

Main pressure valve **15** regulates oil flow from gear pump **16** to bearing lubrication **25** so that in front of main pressure valve **15**, a pressure of 20 bar accumulates. This pressure shifts clutches.

2.3 Pressure reducing valve

Pressure reducing valve **2** reduces pressure of control oil for secondary spool valve to 9 bar.

2.4 Proportional solenoid valves and secondary spool valve

To shift clutches, transmission control unit energises corresponding proportional solenoid valve. Proportional solenoid valve then directs control oil to secondary spool valve and to a valve and opens it. Secondary spool valve directs oil to clutch and closes it.

120.3.5 Engine speed sensor

Valid for: L566-1484;

1.1 Layout




Fig. 597: Speed sensor

BMK	Function
B82	Speed sensor for sun gear 2
B83	Output speed sensor
B84	Speed sensor for reverse travel direction clutch

Tab. 346: Equipment codes

The speed sensors are installed in the transmission housing.

The speed sensors are two-pole Hall sensors.

2.1 Function

NOTICE

Hall element is damaged by resistance measurement!
Damage to speed sensor.

- ▶ Do not carry out any resistance measurements on the speed sensor.

The speed sensors detect speed and direction of rotation.

When the brake is released, the oil flows back out of the pressure chamber 2. The return spring 4 pushes the brake piston 3 back to the initial position and the brake discs 5 separate from each other. The planetary carrier 7 can turn freely again.

2.4 Lubrication

The axle is filled with oil to the bottom of the filling plug. The individual components are lubricated by dipping into the oil with each rotation.

130.1.2 Rear axle

Valid for: L566-1484;

1 Layout




Fig. 605: Rear axle (from front left)

- | | | | |
|---|---|----|--|
| 1 | Central housing with self-locking differential | 7 | Transmission drive flange |
| 2 | Left trumpet arm | 8 | Right wheel hub with planetary gear and wet disc brake (2nd brake circuit) |
| 3 | Vent valve | 9 | Right wheel hub |
| 4 | Left wheel hub | 10 | Vent valve |
| 5 | Left wheel hub with planetary gear and wet disc brake (2nd brake circuit) | 11 | Right trumpet arm |
| 6 | Oil from the compact brake valve (2nd brake circuit) | | |

The rear axle is bolted to the rear section.

The self-locking differential is integrated in the central housing. The wheel hubs contain the den service brake for the 2nd brake circuit. The service brake is a wet disc brake.

2.1.3 Closing the quick coupler


To close the quick coupler, only the quick coupler load sensing signal solenoid valve 4 is energised.

The quick coupler opening solenoid valve 2 applies pressure to the piston side of the quick coupler hydraulic locking cylinder 9. Also, the quick coupler load sensing signal solenoid valve 3 sends a load sensing signal 8 via the control valve block to the working pump.

150.3.2.2 Overview of quick coupler hydraulics

Valid for: L566-1484/45467-51139;

1 Layout



shg01824

Fig. 619: Overview of the quick coupler hydraulics (from front left)

- | | | | |
|---|--|---|--|
| 1 | Valve block for quick coupler | 4 | Load sensing signal for working pump (via control valve block) |
| 2 | Oil supply from working pump (via control valve block) | 5 | Hydraulic cylinder for locking quick coupler |
| 3 | Return flow to control valve block | 6 | Preload valve 15 bar |

Name	Test point
MS	Quick coupler closing pressure

Tab. 360: Test points

BMK	Function	BMK	Function
Y53	Solenoid for opening quick coupler	Y53a	Quick coupler load sensing signal solenoid

Tab. 361: Equipment codes

The quick coupler hydraulics consist of the following components:

- Valve block for quick coupler (For more information see: [Valve block for quick coupler, page 150-13](#))
- Hydraulic cylinder for locking quick coupler

LBH/11835189/19/21+20191218_090358/en

160 Operator's cab, heating and air conditioning

Contents

160.1	Overview of operator's cab, heating and air conditioning unit <i>L566-1484;</i>	160-3
160.2	Display and control elements	160-5
160.2.1	Electrical components in the control panel	160-5
160.2.1.1	Control unit <i>L566-1484;</i>	160-5
160.2.2	Touch screen display <i>L566-1484;</i>	160-7
160.2.3	Control lever <i>L566-1484;</i>	160-8
160.2.4	Accelerator pedal <i>L566-1484;</i>	160-10
160.3	Heating, ventilation, air conditioning	160-12
160.3.1	Heating, ventilation, air conditioning: General overview <i>L566-1484;</i>	160-12
160.3.2	Heating and air conditioning unit	160-17
160.3.2.1	Heating and air conditioning unit <i>L566-1484;</i>	160-18
160.3.2.2	Blower <i>L566-1484;</i>	160-22
160.3.3	Air conditioning controller <i>L566-1484;</i>	160-23
160.4	Air conditioning	160-26
160.4.1	Basic function of the air conditioning unit <i>L566-1484;</i>	160-26
160.4.2	Air conditioning compressor <i>L566-1484;</i>	160-27
160.4.3	Condenser <i>L566-1484;</i>	160-29
160.4.4	Dryer <i>L566-1484;</i>	160-30

2.2 Function of the angle sensor




Fig. 635: Current signal characteristics

x Operating area in degrees (angle) **y** Output current in mA

The angle sensor R5 emits two mixed current signals.

When not active, the output for signal 1 is around 18 mA. When not active, the output for signal 2 is around 6 mA. The two signals add up to 24 mA in every position of the accelerator pedal.

For safety reasons, both signals are monitored by the central control unit. This prevents unwanted speed increases caused by a malfunctioning angle sensor.

If the signals deviate or if the angle sensor fails, the engine is reduced to idling speed. At the same time, a service code appears in the display.

If the accelerator pedal is replaced, it has to be calibrated. ([For more information see: Pedals: calibration, page 030-178](#))

2.3 Plug assignment

Pin	Function	Pin	Function
A	Sensor 1 current signal	D	Sensor 2 supply voltage
B	Sensor 1 earth	E	Sensor 2 earth
C	Sensor 1 supply voltage	F	Sensor 2 current signal

Tab. 376: Pin assignment table

2.4 Characteristic of anti-icing sensor




Fig. 643: Characteristic of anti-icing sensor

The anti-icing sensor **B38** is an NTC resistor. As temperature increases, electrical resistance drops.

2.5 Expansion valve




Fig. 644: Expansion valve

- | | | | |
|---|--|----|-----------------------------|
| 1 | Refrigerant from dryer | 7 | Flange fastening |
| 2 | Housing | 8 | Refrigerant from compressor |
| 3 | Refrigerant to air conditioning compressor | 9 | Valve body |
| 4 | Membrane | 10 | Flange fastening |
| 5 | Thermostatic sensor | 11 | Refrigerant to compressor |
| 6 | Restrictor | 12 | Regulator valve |

LBH/11835199/19/211-20191218_090358/en

g20074/5

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL