

en

Service manual

Wheel loader

Document ID

Order number: 12252623
Issued: 2020-03-26
Version: 03
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 556-1757

Contact

Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

020.14	Lubrication system	020-42
020.14.1	Central lubrication system (Liebherr) <i>L556-1757;</i>	020-42
020.14.1.1	Central lubrication pump	020-42
020.14.1.2	Progressive distributor	020-42
020.14.2	Progressive distributor <i>L556-1757;</i>	020-43
020.14.2.1	MX-F	020-43
020.14.2.2	MX-F 25	020-43
020.14.2.3	MX-F 45	020-44
020.14.2.4	MX-F 75	020-44
020.14.2.5	MX-F105	020-44
020.14.3	Progressive distributor SXE-2 <i>L556-1757;</i>	020-44
020.14.3.1	SXE-2 / MX-F	020-44
020.14.3.2	SXE-2 100	020-44
020.14.3.3	SXE-2 150	020-45
020.14.3.4	SXE-2 220	020-45
020.14.3.5	SXE-2 400	020-45
020.14.3.6	SXE-2 760	020-45
030	Maintenance	030-1
030.1	Maintenance and inspection schedule	030-11
030.2	Filling quantities and lubrication chart	030-16
030.2.1	Lubricant filling quantity <i>L556-1757;</i>	030-16
030.2.2	Fuel and operating fluid filling quantity <i>L556-1757;</i>	030-16
030.3	Lubricants and fuels	030-17
030.3.1	General information on lubricants and fuels	030-17
030.3.1.1	General questions	030-17
030.3.1.2	Safety data sheets	030-17
030.3.1.3	Technical data sheets	030-17
030.3.1.4	Specific Liebherr standards	030-17
030.3.2	General information on changing lubricants and fuels	030-17
030.3.3	Converting hydraulic system from mineral oils to biodegradable hydraulic fluids	030-18

	030.6.12.2	Parameters for lift arm geometry <i>L556-1757;</i>	030-257
	030.6.12.3	Working attachment: automatic return of 3rd function <i>L556-1757;</i>	030-258
030.6.13	Operator's cab, heating and air conditioning		030-259
	030.6.13.1	Checking the pressure and temperature conditions of the air conditioning unit <i>L556-1757;</i>	030-259
030.6.14	Options		030-260
	030.6.14.1	LiDAT: connecting to LiDAT module <i>L556-1757;</i>	030-260
	030.6.14.2	LiDAT: software update for LiDAT module <i>L556-1757;</i>	030-262
	030.6.14.3	LiDAT: creating report and snapshot <i>L556-1757;</i>	030-264
	030.6.14.4	Liebherr weighing device with Truck Payload Assist: calibration <i>L556-1757;</i>	030-268
	030.6.14.5	Skyview 360°: calibration <i>L556-1757;</i>	030-268
	030.6.14.6	Personnel detection: transmitting configuration files <i>L556-1757;</i>	030-275
	030.6.14.7	Tyre pressure monitoring: changing and program- ming pressure sensor <i>L556-1757;</i>	030-279
040	Drive group		040-1
	040.1	Engine	040-3
	040.1.1	Diesel engine overview <i>L556-1757;</i>	040-3
	040.1.2	Electrical components of diesel engine <i>L556-1757;</i>	040-7
	040.1.3	Ambient temperature sensor <i>L556-1757;</i>	040-10
	040.1.5	Fuel system	040-16
	040.1.5.2	Fuel level sensor <i>L556-1757;</i>	040-19
	040.1.5.3	Separ fuel pre-filter <i>L556-1757;</i>	040-21
	040.1.6	Air filter system	040-21
	040.1.6.1	Air filter <i>L556-1757;</i>	040-22
	040.1.6.2	Vacuum switch <i>L556-1757;</i>	040-23

010 Introduction

Contents

010.1	Safety instructions	010-4
010.1.1	Information on these instructions	010-4
010.1.1.1	Representation of warning messages	010-4
010.1.1.2	Graphic symbols in these instructions	010-4
010.1.2	Intended use	010-5
010.1.2.1	Laws, rules, guidelines and safety regulations	010-5
010.1.2.2	Intended use	010-5
010.1.2.3	Foreseeable misuse	010-6
010.1.2.4	Operating conditions	010-6
010.1.2.5	Disposal	010-7
010.1.3	Description of staff	010-7
010.1.3.1	Personal protective equipment	010-7
010.1.3.2	Requirements for staff	010-8
010.1.3.3	Operating company	010-8
010.1.3.4	Operator	010-9
010.1.3.5	Maintenance staff	010-9
010.1.3.6	Refrigeration technician	010-10
010.1.3.7	Slinger	010-11
010.1.3.8	Spotter	010-12
010.1.4	Protective devices on the machine	010-12
010.1.4.1	Operator's cab	010-12
010.1.4.2	Roll over protective structure (ROPS)	010-13
010.1.4.3	Falling object protective structures (FOPS)	010-13
010.1.5	Emergency equipment on the machine	010-13
010.1.5.1	Emergency exit (standard)	010-13
010.1.5.2	Fire extinguisher (option)	010-14
010.1.6	Safe operation	010-14

- Is able to estimate distance, height and gaps.
- The refrigeration technician has completed training that complies with the country-specific laws, standards and guidelines.
- The refrigeration technician has following skills:
 - Is able to assess work correctly.
 - Is able to recognise dangers.
 - Is able to take safety measures.
- Has knowledge and experience of the relevant field of activity.
- Knows the relevant national standards.
- Has the necessary authorisation for maintenance and repair of machine.
- Knows the machine and the hazards.
- Knows all procedures and precautions for maintenance.
- Has knowledge of handling special tools for maintenance and repair.
- Is not under any physical or mental impairment that limits one of the prescribed requirements.
- Is not under the influence of alcohol.
- Is not under the influence of drugs.

010.1.3.7 Slinger

Responsibility

Slinger is responsible for following:

- Wear personal protective equipment.
- Choose correct and undamaged slinging gear.
- Correctly attach slinging gear to load or lifting accessory.
- Correctly remove slinging gear from load or lifting accessory.
- Grant approval for movement or accompaniment.

Requirement

The slinger has following qualification and skills:

- Has completed the legally specified minimum age.
- Physically and mentally capable of slinging loads:
 - Satisfactory eyesight
 - Satisfactory hearing ability
 - Quick reactions
 - Is able to estimate distance, height and gaps.
- The slinger has following skills:
 - Is able to estimate mass distribution and load distribution.
 - Is able to operate radio units.
 - Is able to give clear instructions on radio units.
 - Is able to guide a load.
- Has the necessary authorisation for attaching loads.
- The slinger has the necessary education (theoretical and practical) for the following:
 - Selecting the suitable slinging gear
 - Attaching slinging gear
 - Securing to prevent unintended disengaging of slinging gear
 - Avoiding damage to slinging gear
 - Spotting
 - Applying all necessary signal signs
- Is not under any physical or mental impairment that limits one of the prescribed requirements.
- Is not under the influence of alcohol.
- Is not under the influence of drugs.

Environmental pollution

- When working in following areas, adhere to laws, regulations and rules applicable at place of use:
 - Areas at risk of water (for example bodies of water)
 - Sound-sensitive areas
 - Emission-sensitive areas

010.1.7 Safe maintenance

010.1.7.1 Spare parts

Danger to life

Incorrect spare parts

- Use original spare parts.
- Make sure that the spare parts meet the technical requirements specified by the manufacturer.
- After replacing parts, tighten loosened screw connections with prescribed tightening torque.
- Find prescribed tightening torque in supplied documentation.
- If the tightening torque is not prescribed by the supplied documentation: Find prescribed tightening torque in Liebherr factory standard.
- If the tightening torque is not prescribed by the Liebherr factory standard: Find tightening torque in valid DIN standard, EN standard or ISO standard.

010.1.7.2 Heavy parts

Danger to life

Incorrect handling





- Exclusively use machine for load-lifting with sufficient loading capacity.
- Exclusively use suitable and functioning lifting accessories with sufficient loading capacity.
- Make sure there are no persons underneath raised loads.
- Exclusively task qualified and experienced persons with the attaching of loads.
- Exclusively task qualified and experienced persons with the directing of operators.
- Make sure that the spotter can be seen by the operator.
- Make sure that spotter and operator are in voice contact if necessary.

Injury

Incorrect protective equipment


- Put on gloves when handling wire ropes.

010.2.6 Special tools for tilt cylinders with industrial lift arms

Designation	Item code	Remark	Fig.
Mounting sleeve 150 mm	998622	For fitting the seals	
Expansion sleeve 150 mm	9110410	For fitting the seals	
Piston wrench 100/14 mm	8007366	For fitting the piston	
Piston nut wrench 80/90 mm	9921124	For fitting the piston nut	

Tab. 9: Special tools for tilt cylinders with industrial lift arms

010.2.7 Special tools for steering wheel

Designation	Item code	Remark	Fig.
Extractor for steering wheel	10430204	For steering wheel removal	

Tab. 10: Special tools for steering wheel

Metric standard threads and fine threads				Metric standard threads and fine threads			
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fZnnc-480h-L valid \geq M6)				All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)			
Minimum total coefficient of friction $\mu_G = 0.09$				Minimum total coefficient of friction $\mu_G = 0.11$			
Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm	Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm
M 7	8.8	15.3	13.9*	M 7	8.8	15.0	16.1
	10.9	22.5	20.4*		10.9	22.0	23.6
	12.9	26	23.9*		12.9	26	28
M 8	8.8	19.3	20.6*	M 8	8.8	18.9	23.8
	10.9	28	30*		10.9	28	35
	12.9	33	35*		12.9	32	41
M 8 x 1	8.8	21.0	21.7*	M 8 x 1	8.8	20.5	25
	10.9	31	32*		10.9	30	37
	12.9	36	37*		12.9	35	43
M 9 x 1	8.8	27	31*	M 9 x 1	8.8	27	36
	10.9	40	46*		10.9	39	53
	12.9	47	53*		12.9	46	62
M 10	8.8	31	40	M 10	8.8	30	47
	10.9	45	59		10.9	44	68
	12.9	53	69		12.9	52	80
M 10 x 1	8.8	35	44	M 10 x 1	8.8	34	51
	10.9	51	64		10.9	50	75
	12.9	60	75		12.9	59	88
M 10 x 1.25	8.8	33	42	M 10 x 1.25	8.8	32	49
	10.9	48	62		10.9	47	72
	12.9	56	72		12.9	55	84
M 12	8.8	45	69	M 12	8.8	44	80
	10.9	66	102		10.9	64	118
	12.9	77	119		12.9	75	140
M 12 x 1.25	8.8	50	74	M 12 x 1.25	8.8	49	86
	10.9	73	109		10.9	71	125
	12.9	85	125		12.9	84	150
M 12 x 1.5	8.8	47	72	M 12 x 1.5	8.8	46	83
	10.9	69	105		10.9	68	122
	12.9	81	123		12.9	79	145

LBH/12252623/03/211-20200326_151754/en

010.5 Preservation guidelines for the SCR system

010.5.1 Putting out of service for longer than 2 months

The SCR system can be put out of service for more than 2 months under the following conditions:

- To prevent urea crystals from accumulating, the SCR system must be checked for leaks and damage.
- Electric or hydraulic connections must not be disconnected.

010.5.2 Starting up after being out of service for longer than 2 months

Before starting up after being out of service for more than 2 months, the following tasks must be carried out:

- Check the SCR system for visible damage.
- Check the electrical and hydraulic lines of the SCR system for damage.
- Check the electrical and hydraulic connections of the SCR system for damage.
- Check the quality of the diesel exhaust fluid (item code for analysis kit: 11698484). If the quality of the diesel exhaust fluid no longer meets the specifications, it must be drained.
- Before operating the diesel exhaust fluid pump, the diesel exhaust fluid tank must be filled to the maximum.

Once the above tasks have been carried out, the function of the SCR system must be tested.

This test is done using the LIDIA engine diagnostic software. The test must be carried out with the engine running.

Test the following functions of the SCR system with the engine running:

- Test the air circuit.
- Test the diesel exhaust fluid circuit.
- Test the blowing out function.

Once these tests have been carried out and no faults have been found, the SCR system can be started up.

	Designation	Unit	Value		
	Tipping load when fully articulated (ISO 14397-1)	kg	12400	10300	10100
	Operating weight	kg	19500	19700	19750

Tab. 25: Complete machine with loading bucket (industrial lift arms)

- A) Industrial lift arms with parallel guidance including quick coupler
- B) Earth bucket with short, straight base for quick coupler
- C) Welded tooth holder with plug-in teeth
- D) High lift
- E) In practice, the bucket capacity can be around 10% greater than as calculated using the ISO 7546 standard. The bucket filling level depends on the type of material.

020.1.3 Working attachment: light material bucket

Valid for: L556-1757;

Values stated refer to machine:

- In standard version
- With 23.5R25 L3 tyres
- Including all lubricants
- With a full fuel tank
- With ROPS/FOPS cab and operator
- On level and stable ground



Note

Tyres and working attachment affect operating mass and tip load.

► Note information about tyres and working attachment.




Fig. 79: Working attachment: light material bucket

	Designation	Unit	Value			
	Hydraulic quick coupler		Yes	Yes	Yes	Yes
	Load geometry		A)	A)	A)	A)

LBH/12252623/03/211-20200326_151754/en

G32004221

020.4 Working hydraulics

020.4.1 Working pump

Valid for: L556-1757;

Description	Unit	Value
Type		Axial piston pump with swash plate variable displacement
Type		A11VO95LRS
Direction of rotation		Anticlockwise
Maximum displacement per turn	cm ³	95
Maximum displacement	l/min	244
Weight	kg	21

020.4.2 Control valve block for Z kinematics

Valid for: L556-1757;

Description	Unit	Value
Type		M6-1477-30/2M6-22 W
Maximum flow rate for lifting function (per outlet)	l/min	280
Maximum flow rate for lowering function (per outlet)	l/min	180
Maximum flow rate for tilt-in function	l/min	200
Maximum flow rate for tilt-out function	l/min	180
Maximum flow rate for 3rd function A3 (optional)	l/min	170
Maximum flow rate for 3rd function B3 (optional)	l/min	300
Maximum flow rate for 4th function A4 (optional)	l/min	170
Maximum flow rate for 4th function B4 (optional)	l/min	300
Weight (excluding supplementary control valve)	kg	59

LBH12252623/03/211-20200326_151754/en

020.7.5 Brake accumulator pressure sensor B19

Valid for: L556-1757;

Description	Unit	Value
Measuring range	bar	0 to 600
Signal output	mA	4 to 20
Supply voltage	VDC	8 – 30
Rated temperature range	°C	-25 to +85
Tightening torque	Nm	20

020.7.6 Parking brake hydro accumulator

Valid for: L556-1757;

Description	Unit	Value
Volume	l	0.32
Nitrogen filling pressure at 20 °C	bar	80 ^{+2/-1}
Weight	kg	1.3

020.11 Steel parts of the basic machine

020.11.1 Ballast weights

Valid for: L556-1757;

020.11.1.1 Standard (Z kinematics)

Description	Unit	Value
Right ballast weight	kg	550
Left ballast weight	kg	550
Bolt tightening torque	Nm	850
Design:		Steel and concrete

020.11.1.2 Foam-filled tyres or tracks

Description	Unit	Value
Right ballast weight	kg	320
Left ballast weight	kg	320
Bolt tightening torque	Nm	850
Design:		Steel body

020.11.1.3 Industrial lift arms and timber grabber

Description	Unit	Value
Right ballast weight	kg	850
Left ballast weight	kg	850
Bolt tightening torque	Nm	850
Design:		Steel and concrete

030.4.4.8	Diesel engine: changing oil separator filter cartridge <i>L556-1757;</i>	030-61
030.4.4.9	Diesel engine: Changing the heating flange <i>L556-1757;</i>	030-62
030.4.4.10	Fuel tank: Draining off condensate and sediment <i>L556-1757;</i>	030-62
030.4.4.11	Fuel pre-filter: Draining off condensate <i>L556-1757;</i>	030-63
030.4.4.12	Changing fuel pre-filter cartridge <i>L556-1757;</i>	030-64
030.4.4.13	Changing fuel fine filter element <i>L556-1757;</i>	030-67
030.4.4.14	Diesel exhaust fluid tank: checking ventilation <i>L556-1757;</i>	030-70
030.4.4.15	Air filter system: Cleaning the service cover and dust discharge valve <i>L556-1757;</i>	030-71
030.4.4.16	Cleaning or changing the main element of the air filter system <i>L556-1757;</i>	030-72
030.4.4.17	Air filter system: Changing the safety element <i>L556-1757;</i>	030-75
030.4.4.18	Dust protection for alternator (option): cleaning or replacing filter element <i>L556-1757;</i>	030-76
030.4.4.19	Splitter box: Checking the oil level <i>L556-1757;</i>	030-79
030.4.4.20	Splitter box: Changing the oil <i>L556-1757;</i>	030-80
030.4.4.21	Checking that the diesel engine intake and exhaust system is in good condition and not loose or leaking <i>L556-1757;</i>	030-82
030.4.4.22	Checking the diesel engine for leaks, contamination and damage <i>L556-1757;</i>	030-84
030.4.4.23	Diesel engine: checking profile clamps <i>L556-1757;</i>	030-85
030.4.4.24	Diesel particulate filter: Cleaning filter module <i>L556-1757;</i>	030-87
030.4.4.25	Changing the compressed air dryer <i>L556-1757;</i>	030-90
030.4.4.26	Checking compressed air system <i>L556-1757;</i>	030-91
030.4.5	Cooling system	030-92
030.4.5.1	Cooling system: Checking the coolant level <i>L556-1757;</i>	030-92

Customer:..... Machine type:..... Serial no.:..... Operating hours:..... Date:.....

Maintenance / inspection after service hours							Tasks to be performed				
On handover	All 8-10 h	All 50 h	All 500 h	All 1000 h	All 2000 h	Other intervals	Additional labelling	By maintenance staff	By authorised specialist staff	Confirm tasks	See page
						○	+	■ Once-only activity ● Repeat interval † If necessary ✱ Annually before the winter	□ Once-only activity ○ Repeat interval ✧ If necessary		
						○	+	Air filter system: Clean the safety element (after replacing the main element three times, or every year at the latest).			030-75
							+	Dust protection for alternator (option): clean or replace filter element.			030-76
□	●	●	○	○				Splitter box: Check the oil level.			030-79
			○	○				Splitter box: Change the oil.			030-80
		■	○	○				Check that the diesel engine intake and exhaust system is in good condition and not loose or leaking.			030-82
	●	●	○	○				Check the diesel engine for leaks, contamination and damage.			030-84
□			○	○				Diesel engine: check profile clamps.			030-85
						○5000 h		Clean the diesel particulate filter module.			030-87
						○		Change the compressed air dryer.			030-90
						○		Check the compressed air system.			030-91
Cooling system											
	●	●	●	○	○			Cooling system: Check the coolant level.			030-92
						○	✱	Coolant: checking antifreeze and corrosion protection agent concentration.			030-93
							+	Clean the cooling system.			030-100
						○6000 h		Change coolant in cooling system (at least every 4 years).			030-101
Hydraulic components											
□	●	●	●	○	○			Hydraulic tank: Check the oil level.			030-104
				○	○			Drain off condensate and sediment from the hydraulic tank.			030-106
				○	○			Change the return filter insert in the hydraulic tank.			030-107
				○				Change the hydraulic tank breather filter.			030-108
							✧	Hydraulic tank: analyse the oil (For more information see: Oil analysis, page 030-23)			030-109
							✧	Change the oil in the hydraulic tank (For more information see: Oil change, page 030-23)			030-110
Steering system											
□	●	●	●	○	○			Steering: Check the function.			030-114
□		●	●	○	○			Steering cylinders: Lubricate the bearings.			030-114

LBH/12252623/03/211-20200326_151754/en

Ambient temperature	Designation
From -25 °C to 45 °C	Liebherr Hydraulic Plus

Tab. 49: Recommendation for hydraulic oils

030.3.9.2 Minimum quality requirement

Specification
EMT LH-00-Minimum-HYE

Tab. 50: Minimum quality requirement

When using hydraulic oils from other manufacturers, information on oil change intervals must be obtained from manufacturer or supplier.

030.3.9.3 Oil analysis

	Hydraulic oil	Interval
Normal use (oil analysis optional)	Mineral oil	
	Liebherr Hydraulic HVI	First after 1000 h, then every 1000 h, at least once a year
Bio use (oil analysis prescribed)	Biodegradable	
	Liebherr Hydraulic Plus	First after 1000 h, then every 1000 h, at least once a year

Tab. 51: Oil analysis


030.3.9.4 Oil change

Hydraulic oil	Without oil analysis	With oil analysis ³²⁾
Mineral oil		
Liebherr Hydraulic HVI	Every 3000 h	Every 6000 h
Biodegradable		
Liebherr Hydraulic Plus	Every 4000 h	Every 8000 h

Tab. 52: Oil change

³¹⁾ PAO = polyalphaolefin

³²⁾ If the result of the oil analysis is positive, the oil can continue being used. If the result of the oil analysis is negative, the oil must be changed.



G2012974

Fig. 91: Service cover in the left of the cab access

- | | | | |
|---|---------------|---|-------------------|
| 1 | Service cover | 3 | Locking mechanism |
| 2 | Cotter pin | | |

To open the service cover:

- ▶ Remove cotter pin 2.
- ▶ Open lock 3.
- ▶ Open service cover 1.

NOTICE

Service cover open!
Risk of damage to the machine.

- ▶ Before starting up the machine: Close the service cover and secure it with the cotter pin.
-

To close the service cover:

- ▶ Close service cover 1.
- ▶ Close lock 3 and secure it with the cotter pin 2.

030.4.2.3 Turning off the battery main switch

Valid for: L556-1757;

For certain maintenance jobs, the battery main switch must first be turned off.

Read the descriptions of the maintenance tasks to find out whether the battery main switch must be turned on or off.

Turn on the battery main switch after completing these maintenance tasks.

Make sure that following requirements are met:

- Diesel engine is switched off.

Quantity	Description	Item code
1	1 m test line	7002437
1	Hand pump with sampling hose	8145666

Tab. 64: Tools required

Oil analysis kits

Liebherr recommends having the oil analyses carried out by Oelcheck.

Oelcheck offers various methods of analysis for a wide range of components and units. Liebherr has chosen two methods analysis that are specially adapted to the particular requirements of our systems and components.

	Green lid: petroleum, coolant	Yellow lid: bio oil
Single analysis kit	8145660	7026 817
6-sample analysis kit	7018 368	7026 088
12-sample analysis kit	7018 369	

Tab. 65: Available analysis kits

The analysis kits with the green lid can be used for hydraulic systems filled with mineral oil, diesel engines, transmission and lubricating grease.

The analysis kits with the yellow lid may only be used for bio hydraulic oils. The difference in the scope of the analysis is that the water content of all bio oils has to be tested using the comparatively expensive Karl Fischer method. However, this test method is essential for a precise diagnosis of bio oils.

If other test laboratories are used, the oil analyses must at least include the following data:

Test methods	Measured items
Atomic emission spectroscopy (AES)	Metal debris, additives, contaminants, iron, chrome, tin, aluminium, nickel, copper, lead, molybdenum, silver, silicon, potassium, magnesium, boron, zinc, phosphorus, barium
Infrared spectroscopy (FT-IR)	Oil condition and pollution, oil oxidation, glycol, water, nitration, fuel, soot
Viscosity	Test at 40 °C and 100 °C, viscosity index, note on lubricity and mixing
Analex PQ index	Magnetic abrasion (information on quantity of magnetisable iron debris in oil > 5 µm)

Tab. 66: Test methods

Sending oil samples

- ▶ Label the sample container with the barcode (the red laboratory number on the sample information form).
 - ▷ This ensures that the form with the sample information is allocated to the correct sample.
- ▶ Carefully complete sample information form.

Diesel engine: draining oil




Fig. 107: Changing oil

1 Filler pipe
2 Dipstick

3 Drain hose
4 Drain valve



CAUTION

Hot fluids!
Burns.

▶ Avoid skin contact with fluids.

- ▶ Open filler pipe 1.
 - ▷ Oil drains faster.
- ▶ Unscrew sealing cap on drain valve 4 on bottom of oil pan.
- ▶ Screw drain hose 3 onto drain valve.
 - ▷ Oil drains off.
- ▶ Drain off oil into receptacle.
- ▶ Unscrew drain hose.
- ▶ Unscrew cap of drain valve.




Fig. 117: Fuel tank: Draining off condensate and sediment

- 1 Drain valve
2 Cap
3 Drain hose

- ▶ Place a receptacle under the fuel tank.
- ▶ Unscrew the cap 2 of the drain valve 1.
- ▶ Screw the drain hose 3 onto the drain valve 1.
 - ▷ Condensate and sediment drain off.
- ▶ Drain the condensation and sediment into a suitable receptacle until clean fuel begins to flow.
- ▶ Unscrew the drain hose 3.
- ▶ Screw the cap 2 onto the drain valve 1 and tighten it.

030.4.4.11 Fuel pre-filter: Draining off condensate

Valid for: L556-1757;

When the water level probe in the fuel pre-filter is activated (the service code is displayed), the water collector tank must be drained.

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- You have a suitable receptacle ready.
- The engine has cooled down.



WARNING

Highly flammable consumables!
Beware of burns.

- ▶ Avoid naked lights and fire.

Removing the main element




Fig. 126: Removing the main element

- | | | | |
|---|----------------------|---|----------------|
| 1 | Dust discharge valve | 4 | Main element |
| 2 | Service cover | 5 | Safety element |
| 3 | Fixing clips | 6 | Filter housing |

NOTICE

Always carry out maintenance correctly.
Damage to the engine.

- ▶ Always replace damaged filter elements.

- ▶ Release the fixing clips 3 on the service cover 2.
- ▶ Take off the service cover 2.
- ▶ Remove the main element 4 and check it for damage before cleaning it.


If the main element is damaged:

- ▶ Change the damaged filter element.

If the main element is not damaged:

- ▶ Clean the main element.

Checking the intake system



G2063059

Fig. 139: Checking the intake system


- | | | | |
|---|------------------|---|-----------------|
| 1 | Air intake hose | 4 | Air intake pipe |
| 2 | Air filter house | 5 | Heater flange |
| 3 | Screw | | |

- ▶ Check that air intake hose 1 is not damaged and is firmly seated.
- ▶ Check air intake hose 1 for cracks and porosity.
- ▶ Check that fastening clips on air intake hose 1 fit tightly.
- ▶ Check that air filter housing 2 is not damaged and is firmly seated.
- ▶ Check that air intake pipe 4 is not damaged and screws 3 are tight.

If you find any damage:

- ▶ Do not operate diesel engine.
- ▶ Have damaged components replaced by Liebherr customer service.

Checking the exhaust system




G2063096

Fig. 140: Checking the exhaust system

- | | | | |
|---|--------------|---|------------------|
| 1 | Exhaust pipe | 5 | Exhaust manifold |
| 2 | Exhaust port | 6 | Screw |

See next page for continuation of the image legend

LBH/12252623/03/211-20200326_151754/en



G2007484

Fig. 148: Checking the coolant level

- | | |
|----------------------------------|-------------------------------|
| <p>1 Filler neck
2 Cover</p> | <p>3 Equalising reservoir</p> |
|----------------------------------|-------------------------------|



CAUTION

Hot, pressurised liquid!
Beware of burns.

- ▶ Let the engine cool down.
- ▶ Carefully open the cap 2 of the equalising reservoir 3.

NOTICE

Non-approved coolant!
Damage to the engine and cooling system.

- ▶ Only use coolant that meets the Liebherr specifications.
- ▶ Do not mix coolants with and without silicates.
- ▶ Top up coolant to the bottom of the filler neck 1. (For more information see: [030.3.8 Coolant, page 030-22](#))
- ▶ Close the cover 2.


030.4.5.2 Coolant: checking anti-freeze and corrosion protection agent concentration

Valid for: L556-1757;

Checking antifreeze and corrosion inhibitor concentration

The machine is delivered factory-filled with antifreeze and corrosion inhibitor.

Filling coolant



G2007484

Fig. 156: Filling coolant

- 1 Filler pipe
2 Cap
3 Coolant equalising reservoir

- ▶ Top up coolant to the bottom of the filler neck 1 in the coolant equalising reservoir 3.
- ▶ Close the cap 2 of the coolant equalizing reservoir 3.
- ▶ Start diesel engine.
- ▶ Set heating to maximum temperature and blower speed.
- ▶ Run machine for five minutes at upper diesel engine speed.
 - ▷ Coolant is circulated.
- ▶ Turn off diesel engine.
- ▶ Wait until diesel engine has cooled down.



CAUTION

Hot, pressurised liquid!
Beware of burns.

- ▶ Let the engine cool down.
-
- ▶ Carefully open cap 2 of coolant equalizing reservoir 3.
 - ▶ Check that the coolant level is up to the bottom of the filler pipe 1.
 - ▶ If the coolant level is too low: Top up coolant to the bottom of the filler pipe 1 in the coolant equalising reservoir 3.
 - ▶ Close the cap 2 of the coolant equalizing reservoir 3.

Adjusting the gap




Fig. 178: Adjusting the gap

1	Brake shoe	5	Adjusting screw
2	Brake disc	6	Adjusting screw
3	Thrust pin	7	Lock nut
4	Counter nut	s2	Gap

- ▶ Start the diesel engine and let it run for 30 seconds at low idling speed.
 - ▷ The parking brake hydro accumulator is filled.
 - ▷ The parking brake can be operated when the diesel engine is off.
- ▶ Turn off the diesel engine.
- ▶ Switch on the ignition.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ In the variables editor, select the **Brake system** folder.



WARNING

Beware of machine rolling away!
Accidents.

- ▶ Make sure the machine is parked on level ground.
- ▶ Use chocks to secure the machine against rolling away.



WARNING

Inadvertently engaging the parking brake!
Crushing injuries.

- ▶ Make sure no-one can enter the operator's cab.
 - ▶ Make sure that the main switch cannot be operated.
-
- ▶ Force the variable **QRPBValve** to the maximum value **65535**.
 - ▷ The parking brake opens.
 - ▶ Unscrew the protective cap.

Troubleshooting

If leakages are detected on the transmission:

- ▶ Contact Liebherr customer service.
-

Checking the oil level when the gear oil is at operating temperature

Make sure that the following requirements are fulfilled:

- The machine is level.
- The gear oil can be seen in the sight glass.




Fig. 188: Checking the oil level when the gear oil is at operating temperature

- | | | | |
|---|-----------------|---|-----------|
| 1 | Transmission | 3 | HOT range |
| 2 | Oil sight glass | | |

- ▶ Put machine into service and operate until the gear oil temperature reaches 60 °C.
- ▶ Let the machine run at idling speed for 2 minutes.
- ▶ Engage parking brake.
- ▶ Engage the articulation lock.
- ▶ Check the oil level in the oil sight glass 2.
 - ▷ The oil level must be in the HOT range 3.

If the oil level is below the HOT range 3:

- ▶ Turn off the diesel engine.
- ▶ Top up the oil. (For more information see: [Topping up the oil, page 030-134](#))
- ▶ Release the articulation lock.

Troubleshooting

If the oil level is above the HOT range or if leakages are detected on the transmission:

- ▶ Contact Liebherr customer service.
-

Extension: checking articulation play




Fig. 197: Extension: checking articulation play

- | | | | |
|---|-------------------|---|------------------|
| 1 | Gauge | 5 | Protective cover |
| 2 | Dial gauge holder | 6 | Weld seam |
| 3 | Drive shaft tube | X | Extension length |
| 4 | Weld seam | | |

- ▶ Remove drive shaft (for more information, see removal and installation instructions).
- ▶ Using forks, place drive shaft on a firm, level surface.
- ▶ Pull drive shaft out to length **X** = 45 mm.
- ▶ Secure dial gauge holder **2** next to weld seam **4** on drive shaft tube **3**.
- ▶ Place dial gauge **1** next to weld seam **6** on protective cover **5** and set to 0.
- ▶ Lift drive shaft at centre of gravity.
 - ▷ Dial gauge **1** shows articulation play.
- ▶ Check that the articulation play is below the maximum.

Description	Unit	Value
Maximum articulation play	mm	0.17

If required value is not reached:

- ▶ Replace drive shaft.

030.4.11.3 Checking the tyre pressure

Valid for: L556-1757;

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- You have the recommended tyre pressures from the manufacturer or dealer at hand.

- ▶ Check the condition and function of the driver's safety belt.
- ▶ Replace damaged parts.

030.4.14.4 Testing the windscreen washer system

Valid for: L556-1757;

Make sure that following requirements are met:

- The machine is parked in a safe place.
- The electrical system of the machine is switched on.

To check the front windscreen washer system:

- ▶ Activate windscreen washer system.
 - ▷ Windscreen washer fluid is sprayed onto the front windscreen.
 - ▷ The wiper is switched on.

To check the rear windscreen washer system:

- ▶ Activate windscreen washer system.
 - ▷ Windscreen washer fluid is sprayed onto the rear window.
 - ▷ The wiper is switched on.

030.4.14.5 Windscreen washer system: filling windscreen washer fluid

Valid for: L556-1757;

The reservoir is fitted below the left cab access.

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 1.
- Service access is open.




Fig. 220: Windscreen washer system: filling windscreen washer fluid

1 Cover

The filling quantity is approximately 3.5 l.

- ▶ Open cover **1** on the reservoir.
- ▶ Top up with standard windscreen washer fluid as necessary.

3. Hydraulic adjustment procedures										
Test / adjustment	1000 h	2000 h	Unit	Required value	Measured	Adjusted	Adjusting point	Test point	Figure	
Industrial lift arms control valve block (option): LS-pressure cut-off ⓘ										
High pressure at full load		○	bar	380 ^{±5}			12	PA		
Stabilisation module cut-out function ⓘ										
Cut-out pressure when charging		○	bar	120 ^{+60/-10}				MX		
Steering system										
Steering pump: LS-pressure cut-off valve ⓘ										
High pressure at full load		○	bar	210 ^{±5}			13	PL		
Steering pump: flow regulator (differential pressure) ⓘ										
Differential pressure ΔP at low idling speed	◇	○	bar	23 ^{±1}			14	PL/ LSL		
Brake system										
Brake accumulator pressure sensor B19: deviation ⓘ										
Deviation between pressure gauge and sensor	○	○	bar	<5			15	M3		
Compact brake valve hydro accumulator charging function ⓘ										
Cut-in pressure	○	○	bar	175 ^{±10}			16	M3		
Cut-out pressure	○	○	bar	210 ^{±10}			16	M3		
Service brake pressure ⓘ										
Brake pressure in 1st brake circuit (front axle)	○	○	bar	95 ^{±5}			17	M4		
Brake pressure in 2nd brake circuit (rear axle)	○	○	bar	95 ^{±5}			17	M5		
Service brake hydro accumulator capacity ⓘ										
Residual pressure in 1st brake circuit (front axle) hydro accumulators after braking 9 times, starting at 165 bar	○	○	bar	>80				M4		
Residual pressure in 2nd brake circuit (rear axle) hydro accumulators after braking 9 times, starting at 165 bar	○	○	bar	>80				M5		

LBH/12252623/03/211-20200326_151754/en

- ▶ Select the "Snapshot" function.

**Note**

The name of the service file contains information that is important for automatic processing of the data.

- ▶ Do not change the file name.

- ▶ Save the file.

030.6.4 Cooling system

030.6.4.1 Fan speed proportional solenoid valve

Valid for: L556-1757;

**Note**

Fan speed proportional solenoid valve does not normally need to be adjusted.

- ▶ Exclusively check and adjust fan speed proportional solenoid valve if performance of cooling system is insufficient, for troubleshooting or if fan motor or parts of it have been replaced.

Make sure that following requirements are met:

- Cooling system is cleaned.
- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.
- Service mode is activated.
- Service access is open.

Make sure that following tools are ready:

- Laptop with Sculi diagnostic software
- Pressure gauge (250 bar)




Fig. 232: Fan speed proportional solenoid valve

PK Cooling system high pressure test connection

Preparations

NOTICE

Pressure peak when automatically switching on the reversible fan drive!
Damage to the fan motor.

- ▶ Make sure the reversible fan drive is deactivated.

Manual calibration of proportional solenoids for 3rd and 4th functions (option)



Note

Calibration of the 3rd and 4th functions is not necessary for normal operation.

- ▶ Exclusively calibrate 3rd and 4th functions if there are problems actuating the working attachment.

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The working attachment is attached.
- The machine is in the maintenance position for adjustment procedures.

Make sure that the following tools are ready:

- Laptop with Sculi diagnostic software
- ▶ Start the diesel engine.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ In the variables editor, select the **Working hydraulics** folder.
- ▶ Select the **Calibrate angle proportional solenoids** sub-folder.
 - ▷ The variable **QRNtrlCirc3a** shows the current at the proportional solenoid for 3rd function A3.
 - ▷ The variable **QRNtrlCirc3b** shows the current at the proportional solenoid for 3rd function B3.
 - ▷ The variable **QRNtrlCirc4a** shows the current at the proportional solenoid for 4th function A4.
 - ▷ The variable **QRNtrlCirc4b** shows the current at the proportional solenoid for 4th function B4.
- ▶ Make sure that the parking brake is activated.
- ▶ Raise the lift arms half way.
- ▶ Tilt the bucket half way in.
- ▶ Click the variable **QRNtrlCirc3a** and press the *space bar*.
 - ▷ The line is coloured pink.
 - ▷ The variable is forced. A gradual approach towards the required value is possible.



Note

To gradually approach the required value:

- ▶ Cursor *up/down*: last digit of the value +/- 1
 - ▶ Cursor *left/right*: last digit of the value +/- 5
 - ▶ Page *up/down*: last digit of the value +/- 10
-
- ▶ Increase the value of the variable **QRNtrlCirc3a** until you notice a slight movement of the corresponding working attachment.
 - ▶ When the movement starts, read the variable **QRNtrlCirc3a**.
 - ▶ Enter the value you read in the variable **CRCC3aCurrMoveBegin**.
 - ▶ Unforce the variable **QRNtrlCirc3a**.
 - ▶ Repeat the process for 3rd function B3 with the variable **QRNtrlCirc3b**. Enter the value you read in the variable **CRCC3bCurrMoveBegin**.




Fig. 241: Z-bar kinematics control valve block: primary pressure relief valve

- 1 LS-pressure cut-off PA Working pump high pressure test connection
 2 Primary pressure relief valve

Preparations

- ▶ Connect a pressure gauge (600 bar) to high pressure test connection **PA** on control valve block.
- ▶ Turn adjusting screw on LS-pressure cut-off valve **1** by exactly one turn clockwise.
 - ▷ Opening pressure of LS-pressure cut-off valve is above opening pressure of primary pressure relief valve.

Checking and adjusting

- ▶ Starting diesel engine
- ▶ Raise lift arms as far as they will go.
- ▶ Fully activate lifting function at low idling speed.
- ▶ While doing so, check whether high pressure **PA** corresponds to specified value.

Description	Unit	Value
High pressure PA	bar	380 ±5

If required value is not reached:

- ▶ Set bucket down on ground on its teeth or cutting edge.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Turn adjusting screw of primary pressure relief valve **2**.

- ▶ Check and top up nitrogen filling of ride control hydro accumulators 3. (For more information see: [Hydro accumulator: checking and topping up nitrogen filling, page 030-213](#))
- ▶ Tighten relief valve 2 with tightening torque 3.5 Nm.
- ▶ Tighten screw plug 1 to a tightening torque of 7 Nm.

030.6.6 Hydraulic components

030.6.6.1 Hydro accumulator: checking and topping up nitrogen filling

Valid for: L556-1757;

Make sure that following tools are ready:

- Testing and filling device for hydro accumulator
- Leak spray




Fig. 248: Hydro accumulator: checking and topping up nitrogen filling

- | | |
|--|----------------------------------|
| 1 Oil side of hydraulic accumulator | 8 Drain valve |
| 2 Oil filling on nitrogen side (option) | 9 Nitrogen cylinder |
| 3 Nitrogen side of hydraulic accumulator | 10 Pressure reducer |
| 4 Screw plug | 11 Cylinder pressure gauge |
| 5 Testing and filling device | 12 Outlet pressure gauge |
| 6 Filling pressure gauge | 13 Pressure reducer outlet valve |
| 7 Handwheel for screw plug | 14 Pressure control valve |

- ▶ Permanently connect hydro accumulator with hydraulic tank or atmosphere (for example, via relief valve).

If oil side of hydro accumulator cannot be permanently connected with hydraulic tank or atmosphere:

- ▶ Depressurise and remove hydro accumulator.
- ▶ Unscrew protective cap of hydro accumulator.
- ▶ Place hydro accumulator so that screw plug 4 points up.
 - ▷ Oil filling on nitrogen side 2 does not flow out.

Manual calibration of position sensor of emergency spool valve



Note

Before calibration of position sensor of emergency spool valve, calibrate position sensor of main spool valve!

- ▶ Engage articulation lock (for further information see: operator's manual). If necessary, deactivate service mode and then reactivate it.
- ▶ Fold up left armrest and then fold back down.
 - ▷ Joystick steering is deactivated.
- ▶ Set variable **MXJSEmergVlvPosAdjStart** to **1**.
 - ▷ Calibration function is active for 8 seconds.



WARNING

Accidental steering movements!
Injury.

- ▶ Make sure that articulation lock is engaged.
- ▶ With joystick steering deactivated and within 8 seconds, move **joystick** all the way left and right.
- ▶ Wait until the variable **MXJSEmergVlvPosAdjStart** returns to **0**.
 - ▷ Calibration is completed.
- ▶ Disengage articulation lock (for further information see: operator's manual).

Automatic calibration of proportional solenoids for main spool valve and emergency spool valve



Note

Before calibration of proportional solenoids of emergency spool valve, calibrate position sensor of main spool valve!

- ▶ Make sure that the articulation lock is disengaged.
- ▶ Start diesel engine.
- ▶ Move lift arms into transport position.
- ▶ Fold up left armrest.
 - ▷ Joystick steering is deactivated.



WARNING

Automatic machine movements!
Injury.

- ▶ Make sure there is nobody in danger area around machine.
- ▶ Set variable **MXJSSteerValveAdjMvBg** to **1**.
 - ▷ Calibration takes place automatically.
 - ▷ The machine automatically performs from minimal steering movements.
 - ▷ The calibration can be cancelled by steering with the steering joystick or starting up.
- ▶ Wait until the variable **MXJSSteerValveAdjMvBg** returns to **0**.




Fig. 263: Service brake pressure

1 Stop bolt

M5 Brake pressure test connection for 2nd brake circuit

M4 Brake pressure test connection for 1st brake circuit

- ▶ Connect a pressure gauge (250 bar) to the 1st brake circuit pressure test connection **M4** on the front axle.
- ▶ Connect a pressure gauge (250 bar) to the 2nd brake circuit pressure test connection **M5** on the compact brake valve.
- ▶ Start the diesel engine.
- ▶ Press the compact brake valve down as far as it will go and hold it there.
- ▶ Check that the brake pressure in both brake circuits has the required value.

Description	Unit	Value
Brake pressure in 1st brake circuit M4 (front axle)	bar	95 \pm 5
Brake pressure in 2nd brake circuit M5 (rear axle)	bar	95 \pm 5

If the required values are not reached:

- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Adjust the stop screw **1**.
- ▶ Repeat the procedure and adjustment until the required values are attained.

If the required values are reached:

- ▶ Turn off the diesel engine and take out the ignition key.
- ▶ Disconnect the pressure gauge from the 1st brake circuit pressure test connection **M4**.
- ▶ Disconnect the pressure gauge from the 2nd brake circuit pressure test connection **M5**.

030.6.8.4 Service brake hydro accumulator capacity

Valid for: L556-1757;

Make sure that following requirements are met:

- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.




Fig. 278: Connection settings

- | | | | |
|---|-------------------|---|----------------------|
| 1 | “AutoIP” checkbox | 3 | “OK” function |
| 2 | IP address | 4 | “Speichern” function |

- ▶ Make sure that “AutoIP” checkbox 1 is selected.
- ▶ Make sure that IP address 2 is set: 169.254.0.50
- ▶ Select “OK” function 3.
- ▶ Select “Speichern” function 4.
 - ▷ Connection settings are checked.

Creating “Master 5 Ethernet” address




Fig. 279: Creating “Master 5 Ethernet” address

- | | | | |
|---|----------------------------------|---|--|
| 1 | “New” function | 4 | Designation of new address |
| 2 | “PME1 address book” address book | 5 | Connection “Master-5 (Master 5Plugin)” |
| 3 | “New address” function | 6 | “Edit” function |

- ▶ Run Sculi diagnostic software.
- ▶ Select “New” function 1.
- ▶ Select “PME1 address book” address book 2.
- ▶ Select “New address” function 3.
- ▶ Name new address book: Master5 – Ethernet
- ▶ Select “Master-5 (Master 5Plugin)” connection 5.

Service code	Cause	Remedy
50CA (1st attempt)	The gear oil temperature fell below the minimum during the calibration. The parking brake was opened during the calibration. A function was activated during the calibration. Faulty hydrostat calibration.	Make sure that all requirements are fulfilled: Start calibration again. Do not operate any functions during calibration.
50CA (2nd attempt)	Faulty hydrostat calibration.	Contact technical customer service department.

Tab. 86: Service code table

If no service code appears:

- ▶ Calibration was successful. Turn off the engine and wait until the central control unit has shut down.
 - ▷ Calibration data is sent to the central control unit.



Note

Calibration is not completed until the engine is turned off and the central control unit is completely shut down!

- ▶ Calibrate the clutch.

Automatic clutch calibration

- ▶ Start diesel engine.
- ▶ Set the variable ***MXTCUStartClutchCalibRev*** to **1**.
 - ▷ The calibration is carried out automatically (duration up to 15 minutes).
 - ▷ The *calibration active* symbol field **1** in the display lights up.



Note

If the calibration does not start (symbol field *calibration active* is not lit):

- ▶ Perform basis calibration. (For more information see: [Gearbox: basic calibration, page 030-249](#))
- ▶ Wait until the variable ***MXTCUStartClutchCalibRev*** returns to **0**.
 - ▷ Calibration is completed.
 - ▷ The *calibration completed* symbol field **2** in the display lights up.

If a service code appears:

- ▶ Calibration has failed. Turn off the engine and wait until the central control unit has shut down.
- ▶ Proceed as specified in the service code table.

Service code	Cause	Remedy
50D5	Gear oil temperature too low. Parking brake released.	Make sure that all requirements are fulfilled: Start calibration again.




Fig. 295: Checking software version of SCULi diagnostic software

- 1 "Help" function
- 2 "Check for update" function

- ▶ Select "Help" 1 function.
- ▶ Select "Check for update" function 2 and perform software update of diagnostic software if necessary.

Updating software of LiDAT module

- ▶ Make sure that the latest software version of the SCULi diagnostic software is installed.
- ▶ Connect to the LiDAT module. (For more information see: [LiDAT: connecting to LiDAT module, page 030-260](#))




Fig. 296: Software update

- 1 Current software version
- 2 "Software update" function

The current software version can be found at the position 1.

- ▶ Select "Software update" function 2.

LBH/12252623/03/211-20200326_151754/en

g2078118

040.1 Engine

040.1.1 Diesel engine overview

Valid for: L556-1757;




Fig. 324: Diesel engine overview

1	Torsional vibration damper	10	Crankcase bleeding line
2	Water pump	11	Bleeder line
3	Tensioning device	12	Compressor
4	Alternator	13	Turbocharger
5	Air conditioning compressor	14	Starter
6	Oil filter	15	Exhaust pipe
7	Dipstick	16	Exhaust port
8	Heating flange	17	Thermostat housing
9	Air intake pipe	18	Coolant from radiator

After heatsink **5**, engine oil continues to flow to oil filters.

At low ambient temperatures, the viscosity of the engine oil changes. The engine oil gets thicker. This increases the pressure in the lubrication system. The bypass valve for oil cooler **4** opens starting from a pressure of 3 bar. As a result, the engine oil does not flow through the heatsink **5**. The cooling effect is eliminated, the operating temperature of engine oil is reached faster.

Specifications of bypass valve for oil cooler

Opening pressure	3 bar
------------------	-------

Tab. 95: Specifications of bypass valve for oil cooler

1.3 Cold start valve




Fig. 335: Cold start valve

1 Cold start valve

A Adjustment dimension

At low ambient temperatures, the viscosity of the engine oil changes. The engine oil gets thicker. This can cause pressure peaks in the lubrication circuit when the diesel engine starts.

The cold start valve **1** protects the lubrication circuit from excess oil pressure. If the oil pressure exceeds the set value, engine oil will be drained via the cold start valve **1** into the oil pan. The pressure drops.

Specifications for cold start valve

Opening pressure	9 bar
Adjustment dimension A	13 ± 0.5 mm

Tab. 96: Specifications for cold start valve

040.1.6.2 Vacuum switch

Valid for: L556-1757;

1.1 Layout




Fig. 345: Layout of vacuum switch

The vacuum switch 2 is fitted on the air filter 1.

2.1 Function

The vacuum switch 2 monitors the pressure ratio between the turbocharger and air filter 1.


When the filters are dirty (excessive vacuum detected), the switch triggers the air filter contamination symbol field in the display unit.

When there is neutral pressure, the vacuum switch is closed and opens when the vacuum reaches 50 mbar. If there is already an interruption with the ignition ON, this is recognised as a fault (cable rupture). If the vacuum switch opens during operation or the line is interrupted, this signifies the air filter is contaminated.

040.1.7 Exhaust system

040.1.7.2 Exhaust gas treatment (stage IV / tier 4f): overview

Valid for: L556-1757;



g2073448

Fig. 353: Overview of exhaust gas treatment system

- | | | | |
|---|-------------------------|---|-----------------------------|
| 1 | Input module | 4 | Diesel exhaust fluid nozzle |
| 2 | SCR catalytic converter | 5 | Mixing section |
| 3 | Output module | | |

2.1 Basic function

The statutory emissions standards (stage IV, Tier 4f) are fulfilled using a pure SCR strategy.

The engine management system is set so that high combustion temperatures can be reached. This reduces the particulate emissions of the engine. This means that a diesel particulate filter is not required in order to meet the missions standards.

High combustion temperatures have the drawback that NO_x emissions are higher. NO_x are nitrogen oxides, the output of which is regulated by emissions standards.

To reduce NO_x emissions, an SCR system is used.

1.2 NH₃ sensor



Fig. 365: NH₃ sensor

1 NH₃ sensor

2 NH₃ sensor controller B783

The NH₃ sensor 1 measures the ammonia content in the exhaust at the outlet of the SCR catalytic converter.

If the NH₃ sensor fails, a substitute value of 0 ppm is assumed. A power reduction is activated.

1.3 Differential pressure sensor




Fig. 366: Differential pressure sensor

1 Differential pressure sensor B722

The differential pressure sensor B722 1 is only installed in machines with diesel particulate filter (DPF).

The differential pressure sensor is used to calculate the soot load of the diesel particulate filter. The soot load is calculated from the pressure difference between the input of the DPF and the output of the DPF.

The differential pressure sensor outputs a voltage signal between 0.5 V and 4.5 V. This corresponds to a measuring range of 0 bar to 0.3 bar.

040.1.8 Compressed air system

050 Cooling system

Contents

050.1	Cooling system: General overview <i>L556-1757;</i>	050-2
050.2	Cooling system hydraulics	050-3
050.2.1	Overview of cooling system hydraulics <i>L556-1757;</i>	050-4
050.2.2	Fan pump <i>L556-1757;</i>	050-8
050.2.3	Fan motor <i>L556-1757;</i>	050-9
050.3	Cooling system electronics	050-13
050.3.1	Overview of electrical controls of cooling system <i>L556-1757;</i>	050-13
050.3.2	Hydraulic oil temperature sensor <i>L556-1757;</i>	050-16
050.4	Cooler	050-18
050.4.1	Cooler unit <i>L556-1757;</i>	050-18
050.5	Reversible fan drive	050-19
050.5.1	Overview of reversible fan drive <i>L556-1757;</i>	050-19
050.5.2	Fan reversal valve block <i>L556-1757;</i>	050-21

- 4 Secondary piston
- 5 Throttle
- 9 Return flow to collector pipe

BMK	Function
Y13	Fan speed proportional solenoid

Tab. 110: Equipment codes

The fan motor drives the fan blade.

2.2 Fan speed proportional solenoid valve




Fig. 384: Fan speed proportional solenoid valve de-energised / fan speed proportional solenoid valve energised

- 1 Compression spring for secondary piston
- 2 Stay
- 3 Secondary piston
- 4 Pressure chamber
- 5 Compression spring for primary piston
- 6 Primary piston
- 7 Oil supply via fan pump

BMK	Function
Y13	Fan speed proportional solenoid

Tab. 111: Equipment codes

Fan speed proportional solenoid valve regulates fan speed by directing oil past gear motor. The more oil that flows through bypass, the lower output speed.

Central control unit energises fan speed proportional solenoid Y13. Resulting magnetic force pushes stay 2 against spring force of compression spring 1. This opens secondary piston 3 and allows hydraulic oil to flow out of pressure chamber 4. Pressure of fan pump 7 can then move primary piston 6 and some of

LBH/12252623/03/211-20200326_151754/en

050.5.2 Fan reversal valve block

Valid for: L556-1757;

1 Layout




Fig. 390: Fan reversal valve block (from front left and from rear right)

- | | |
|--|--|
| <p>1 Fan reversal valve block</p> <p>2 Check valve</p> <p>3 Solenoid valve for fan reversal</p> <p>4 Oil supply via fan pump</p> | <p>5 Return flow to collector pipe</p> <p>6 Connection for fan motor (high pressure when fan reversal deactivated)</p> <p>7 Connection for fan motor (high pressure when fan reversal activated)</p> |
|--|--|

BMK	Function	BMK	Function
Y13	Fan speed proportional solenoid	Y50	Fan reversal solenoid

Tab. 120: Equipment codes

The fan reversal valve block is mounted on the right-hand side of the vehicle in the rear section below the cooler unit.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2 Function




Fig. 395: Diagram of Z-bar kinematics working hydraulics (lift function actuated)

- | | | |
|------------------------------------|---|---|
| 1 Hydraulic tank | 39 Oil supply from hydro accumulator for 1st brake circuit | 80 End section |
| 2 Return filter | 40 Compact brake valve return flow | 81 Orifice 1.0 mm |
| 3 Main filter element 10 µm | 45 Control block for Z-bar kinematics | 82 Return flow from compact brake valve (control valve block housing preheating) |
| 4 Bypass valve 2.5 bar | 46 Primary pressure relief valve | 83 Return flow of stroke limit damping pressure relief valves |
| 5 Strainer mesh 100 µm | 47 Preload valve for 2nd tank duct | 85 Anti-drift valve |
| 6 Breather filter | 48 Tilt cylinder spool valve | 86 Seat valve |
| 7 Fine filter | 49 Throttle 1.0 mm | 87 Release valve |
| 8 Outlet valve 0.65 bar | 50 Strainer | 88 Pressure relief valve |
| 9 Inlet valve 0.03 bar | 51 Strainer | 90 Throttle check valve |
| 10 Leak oil strainer 100 µm | 52 Throttle 1.0 mm | 91 Throttle 1.2 mm |
| 11 Steel tank | 53 Tilt cylinder pressure balance | 92 Throttle 0.6 mm |

See next page for continuation of the image legend

LBH/12252623/03/211-20200326_151754/en

2 Function

2.1 Basic function




Fig. 400: Hydraulic diagram of the working pump (diesel engine is running)

- | | |
|------------------------------------|--|
| 1 Working pump | 8 Power regulator |
| 2 Axial piston rotary group | 9 Dummy piston |
| 3 Return piston | 10 Flow regulator |
| 4 Throttle | 11 Oil supply for control valve block |
| 5 Positioning piston | 12 Load sensing signal from control valve block |
| 6 Throttle | 13 Leak oil to leak oil strainer |
| 7 Regulating lever | 14 Suction port from hydraulic tank |

Name	Test point	Name	Test point
MP	Working pump return pressure	PA	Working pump high pressure

Tab. 135: Test points

Working pump draws up oil from hydraulic tank **14** and pumps it to control valve block **11**.

Displacement of working pump depends on engine speed and swivel plate angle. Working pump is regulated via load sensing signal from control valve block **12**.

LBH/12252623/03/211-20200326_151754/en

- | | | |
|---|---|---|
| 1 Control block | 24 LS-pressure cut-off | 52 Release valve |
| 2 Primary pressure relief valve | 25 Control valve block section for 3rd function (option) | 53 Pressure relief valve |
| 3 Preload valve for 2nd tank duct | 26 Spool valve for 3rd function (option) | 55 Throttle check valve |
| 4 Tilt cylinder spool valve | 27 Throttle 1.0 mm | 56 Throttle 1.2 mm |
| 5 Throttle 1.0 mm | 28 Strainer | 57 Throttle 0.6 mm |
| 6 Strainer | 29 Strainer | 60 Return flow from return filter |
| 7 Strainer | 30 Throttle 1.0 mm | 61 Oil supply from working pump |
| 8 Throttle 1.0 mm | 31 Pressure balance for 3rd function | 62 Connection to ring side of tilt cylinder |
| 9 Tilt cylinder pressure balance | 32 Secondary pressure relief valve for 3rd function A3 | 63 Connection to piston side of tilt cylinder |
| 10 Replenishing valve for tilting out | 33 Secondary pressure relief valve for 3rd function B3 | 64 Connection to stabilisation module (ring side of lift cylinder) |
| 11 Secondary pressure relief valve for tilting out | 35 Control valve block section for 4th function (option) | 65 Load sensing signal for working pump |
| 12 Secondary pressure relief valve for tilting in | 36 Spool valve for 4th function (option) | 66 Connection for 3rd function A3 |
| 13 Lift cylinder spool valve | 37 Throttle 1.0 mm | 67 Connection for 3rd function B3 |
| 14 Throttle 0.8 mm | 38 Strainer | 68 Connection for 4th function A4 |
| 15 Strainer | 39 Strainer | 69 Connection for 4th function B4 |
| 16 Strainer | 40 Throttle 1.0 mm | 70 Return flow from stabilisation module |
| 17 Throttle 0.8 mm | 41 Pressure balance for 4th function | 71 Return flow from compact brake valve (control valve block housing preheating) |
| 18 Lift cylinder pressure balance | 42 Secondary pressure relief valve for 4th function A4 | 72 Return flow of stroke limit damping pressure relief valves |
| 19 Feeder valve for lowering | 43 Secondary pressure relief valve for 4th function B4 | 73 Connection to piston side of lift cylinder |
| 20 Feeder valve for lowering | 45 End section | 74 Connection to ring side of lift cylinder |
| 21 Secondary pressure relief valve for lifting | 46 Orifice 1.0 mm | 75 Control oil from pilot control valve block |
| 22 Strainer | 50 Anti-drift valve | 76 Return flow to pilot control valve block |
| 23 Flow regulating valve | 51 Seat valve | |

Name	Test point	Name	Test point
LSA	Load sensing signal for working pump	PA	Working pump high pressure
MT	Servo pressure for tilt-out function		

Tab. 139: Test points

BMK	Function	BMK	Function	BMK	Function
Y31a	Proportional solenoid for tilting out	Y32b	Proportional solenoid for lifting	Y34a	Proportional solenoid for 4th function A4 (option)

LBH/12252623/03/211-20200326_151754/en

060.6 Pilot control

060.6.1 Pilot control valve block

Valid for: L556-1757;

1 Layout




Fig. 411: Pilot control valve block (from front left)

- | | | | |
|---|---|---|--|
| 1 | Servo pressure relief valve | 4 | Return flow from control valve block |
| 2 | Control oil to control valve block | 5 | Return flow to leak oil strainer |
| 3 | Oil supply from hydro accumulator for service brake (1st brake circuit) | 6 | Port for pilot control hydro accumulator |

Name	Test point
MV	Servo pressure

Tab. 146: Test points

BMK	Function
Y14	Solenoid for servo pressure

Tab. 147: Equipment codes

Pilot control valve block is installed on left side of vehicle, under operator's cab.

060.8 Electronics of the working hydraulics

060.8.1 Overview of electrical controls the working hydraulics

Valid for: L556-1757;

1 Layout




Fig. 418: Overview of electrical controls the working hydraulics

1 Lift arms

2 Control block

BMK	Function	BMK	Function
A15	Central control unit	Y32a	Proportional solenoid for lowering
A17a	Output module A17a	Y32b	Proportional solenoid for lifting
A26	CAN module for control lever	Y33a	Proportional solenoid for 3rd function A3
B60	Angle sensor for bucket position	Y33b	Proportional solenoid for 3rd function B3
B61	Angle sensor for lift arm position	Y34a	Proportional solenoid for 4th function A4
Y31a	Proportional solenoid for tilting out	Y34b	Proportional solenoid for 4th function B3
Y31b	Proportional solenoid for tilting in		

Tab. 160: Equipment codes

LBH/12252623/03/211-20200326_151754/en

Valve block for pipe break protection is mounted directly on hydraulic cylinder to be protected.

2 Function




Fig. 426: Valve block for pipe break protection: hydraulic diagram

- | | | | |
|----------|--|-----------|--|
| 1 | Valve block for pipe break protection | 8 | Throttle |
| 2 | Throttle check valve | 9 | Return flow to leak oil strainer |
| 3 | Pipe break protection valve | 10 | Oil supply through control valve block |
| 4 | Check valve | 11 | Servo pressure from control valve block |
| 5 | Safety valve | 12 | Connection to other valve block for pipe break protection (lift cylinder only) |
| 6 | Fine strainer | 13 | Connection for hydraulic cylinder |
| 7 | Throttle | | |

Name	Test point
X	Venting connection

Tab. 168: Test points

When lifting lift arms or tilting bucket, oil flows from control valve block **10** via pipe break protection valve **3** and check valve **4** to hydraulic cylinder **13**.

When lowering lift arms or tilting out bucket pipe break protection valve **3** is opened with servo pressure **11** of corresponding function.

To guarantee pressure protection, safety valve **5** opens at a pressure of 300 bar at hydraulic cylinder **13** connection. Pipe break protection valve **3** opens and connects hydraulic cylinder **6** to secondary pressure relief valve for corresponding function in control valve block **10**.

060.9.3 Ride control release solenoid valve

Valid for: L556-1757;

1 Layout


Ride control release solenoid valve is installed in front section next to control valve block.

LBH/12252623/03/211-20200326_151754/en

080.2.3 Return filter

Valid for: L556-1757;

1 Layout



sh101809


Fig. 433: Return filter

- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Filter cover 2 Filter bracket 3 Filter housing 4 Strainer mesh 100 µm | <ul style="list-style-type: none"> 5 Return flow from control valve block 6 Return flow from hydraulic oil cooler 7 Steel tank |
|--|---|

Return filter is integrated in steel tank.

2 Function

2.1 Basic function



sh101810

Fig. 434: Return filter: hydraulic diagram

- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Return filter 2 Main filter element 10 µm 3 Bypass valve 2.5 bar 4 Strainer mesh 100 µm | <ul style="list-style-type: none"> 5 Return flow from hydraulic oil cooler 6 Return flow from control valve block 7 Steel tank |
|--|---|

LBH/12252623/03/211-20200326_151754/en

15 Return flow from compact brake valve and pilot control	42 Check valve	67 Left steering cylinder with stroke limit damping
16 Return flow from control valve block	43 Return line from fan motor	68 Pressure relief valve for stroke limit damping
20 Steering pump	45 Collector pipe	69 Right steering cylinder with stroke limit damping
21 Axial piston rotary group	46 Preload valve for steering cylinder replenishing function 5 bar	70 Pressure relief valve for stroke limit damping
22 Return piston	47 Bypass valve for hydraulic oil cooler 1.5 bar	71 Return flow from pressure relief valves to control valve block
23 Positioning piston	48 Hydraulic oil cooler	

Name	Test point	Name	Test point	Name	Test point
LSL	Load sensing signal for steering pump (option)	PL/	Steering pump high pressure	PL1	High pressure for steering pump or emergency steering pump

Tab. 178: Test points

BMK	Function	BMK	Function
B3	Emergency steering pressure switch	B8	Hydraulic oil temperature sensor
B3a	Emergency steering check pressure switch	M8	Electric motor for emergency steering pump

Tab. 179: Equipment codes

The steering system is an open circuit. This means that after leaving the consumer, the oil flows to the hydraulic tank rather than directly back to the working pump.

The steering pump **20** draws oil from the hydraulic tank **1** and pumps it through the steering system valve block **40** to the servostat **50**.

The servostat **50** delivers a measured quantity of oil to the steering cylinders with every turn of the steering wheel. The servostat **50** also generates a load sensing signal which is used to regulate the steering pump **20**.

The steering pump has stroke limit damping that prevents hard stops at the limit position. In addition, the steering stabilisation valve block **60** prevents cavitation in the steering cylinders and damps jerky steering movements and external effects when the vehicle is moving.

The oil returning from the steering cylinders flows through the collector pipe **45** and the hydraulic oil cooler **48** back to the hydraulic tank **1**.

The electric emergency steering pump **35** supplies the steering system with oil for a short time if the steering pump **20** fails.

Hydro accumulator for steering damping **63** and **65** with integrated throttle check valve improve steering behaviour.

090.4 Steering cylinder

090.4.1 Steering cylinder

Valid for: L556-1757;

1 Layout




Fig. 456: Steering cylinder (from front left and from front right)

- | | | | |
|---|------------------------------|---|---|
| 1 | Ring-side cylinder bearing | 5 | Cylinder extension port |
| 2 | Piston rod | 6 | Cylinder retraction port |
| 3 | Piston chamber | 7 | Return flow from pressure relief valve to control valve block |
| 4 | Piston-side cylinder bearing | 8 | Pressure relief valve for stroke limit damping |

The steering cylinder is equipped with stroke limit damping on the piston side.

090.5.3 Emergency steering electronics

090.5.3.1 Overview of electrical controls of emergency steering system

Valid for: L556-1757;

1.1 Layout




Fig. 469: Overview of electrical controls of emergency steering system

- | | | | |
|---|--|---|-------------------------|
| 1 | Emergency steering active symbol field | 3 | Emergency steering key |
| 2 | Emergency steering CHECK failed symbol field | 4 | Emergency steering pump |

BMK	Function	BMK	Function	BMK	Function
A4	Fuse and relay board	A17a	Output module A17a	K16	Emergency steering relay
A11	Control unit	B3	Emergency steering pressure switch	M8	Electric motor for emergency steering pump
A13	Display	B3a	Emergency steering check pressure switch	S19	On-road travel switch
A15	Central control unit	K11	Emergency steering pump power relay		
A16a	Input module A16a	K14	Emergency steering pump control relay		

Tab. 189: Equipment codes

LBH/12252623/03/211-20200326_151754/en

sle01849

6	Breather filter	40	Valve block for steering system	76	Preload valve for steering cylinder replenishing function 5 bar
7	Fine filter	41	Check valve	77	Bypass valve for hydraulic oil cooler 1.5 bar
8	Outlet valve 0.65 bar	42	Check valve	78	Hydraulic oil cooler
9	Inlet valve 0.03 bar	45	Joystick steering control block	80	Servostat
10	Leak oil strainer 100 µm	46	Servo oil strainer for main spool valve	81	Valve spool
11	Steel tank	47	Pressure reducing valve for main spool valve	82	Metering pump
12	Sight glass for hydraulic oil level	48	Servo oil strainer for emergency spool valve	83	Secondary pressure relief valve for steering to left
13	Hydraulic tank drain valve	49	Pressure reducing valve for emergency spool valve	84	Secondary pressure relief valve for steering to right
14	Fan motor leak oil	50	Shuttle valve 1	85	Feeder valve for steering to left
15	Return flow from compact brake valve and pilot control	51	Shuttle valve 2	86	Feeder valve for steering to the right
16	Return flow from control valve block	52	Check valve	90	Steering stabilisation valve block
20	Steering pump	53	Solenoid valve for safety circuit	91	Replenishing valve for steering stabilisation 0.5 bar
21	Axial piston rotary group	54	Proportional solenoid valve for steering left (main spool valve)	92	Replenishing valve for steering stabilisation 0.5 bar
22	Return piston	55	Throttle check valve	93	Steering damper hydro accumulator
23	Positioning piston	56	Orifice 0.7 mm	94	Throttle check valve 2.0 mm
24	Throttle	57	Proportional solenoid valve for steering right (main spool valve)	95	Steering damper hydro accumulator
25	LS-pressure cut-off	58	Throttle check valve	96	Throttle check valve 2.0 mm
26	Flow regulator	59	Orifice 0.7 mm	97	Left steering cylinder with stroke limit damping
27	Throttle	60	Main spool valve	98	Pressure relief valve for stroke limit damping
28	Fan pump and brake pump suction port	61	Cut-off valve for main spool valve	99	Right steering cylinder with stroke limit damping
29	Working pump suction port drain valve	65	Control block section for emergency steering function	100	Pressure relief valve for stroke limit damping
30	Working pump	66	Emergency spool valve	101	Return flow to control valve block (housing preheating)

Name	Test point	Name	Test point	Name	Test point
M A1	Servo pressure for steering to left (main spool valve)	M B2	Servo pressure for steering to right (emergency spool valve)	PL1	High pressure for steering pump or emergency steering pump
M B1	Servo pressure for steering to right (main spool valve)	LSL	Load sensing signal for steering pump		

LBH/12252623/03/211-20200326_151754/en

Name	Test point	Name	Test point
M B1	Servo pressure for steering to the right (main spool valve) ^{A)}	M B2	Servo pressure for steering to the right (emergency spool valve) ^{A)}

Tab. 200: Test points

A) Thread M10x1

BMK	Function	BMK	Function	BMK	Function
B70	Main spool valve position sensor	Y71	Proportional solenoid for steering to the left (spool valve for emergency steering function)	Y74	Solenoid for safety circuit
B71	Emergency spool valve position sensor	Y72	Proportional solenoid for steering to the left (emergency spool valve)		
Y70	Proportional solenoid for steering to the left (main spool valve)	Y73	Proportional solenoid for steering to the right (emergency spool valve)		

Tab. 201: Equipment codes

The joystick steering control valve block is supplied with oil by the steering pump **28** and directs that oil to the steering cylinders when the vehicle is steered. The spools are electro-hydraulically actuated.

2.2 Steering in normal mode operation

When joystick steering is activated, the safety circuit solenoid valve **9** is energised. As a result, exclusively the main spool valve **16** is supplied with pilot control oil. That pressure is generated from the steering pump **28** delivery pressure by the main spool valve pressure reducing valve **3**.

When steering to the left or right the relevant proportional solenoid valve is energised. The proportional solenoid valve continues reducing the servo pressure, depending on the current, and directs the servo oil to the main spool valve **16**. As a result, the pilot control fluid pushes the main spool valve **16** against the force of return springs. The ports thus opened by the main spool valve **16** allow the oil to flow from the steering pump **28** to the steering cylinders. In addition, a load-sensing signal **29** is generated that is fed back to the steering pump.

2.3 Steering in emergency steering mode

Joystick steering in emergency mode fundamentally functions in the same way as in normal mode. However, the safety circuit solenoid valve **9** is not energised. As a result, the emergency spool valve **21** is supplied with pilot control oil. At the same time, the main spool valve shut-off valve **17** disconnects the main spool valve **16** from the steering cylinders. That makes sure that emergency steering function still functions even if the main spool valve **16** jams.

The emergency spool valve is supplied with pilot control oil by its own pressure reducing valve **5**.

090.7 2in1 steering

090.7.1 2in1 steering: total overview

Valid for: L556-1757;

This equipment is optional.

1 Layout

2in1 steering consists of following components:

- Hydraulic tank (For more information see: 080.2.1 Overview of hydraulic tank, page 080-5)
- Steering pump (For more information see: 090.2 Steering pump, page 090-8)
- Servostat for 2in1 steering (For more information see: 090.7.2 Servostat for 2in1 steering, page 090-59)
- Solenoid valve for 2in1 steering
- Steering cylinder (For more information see: 090.4.1 Steering cylinder, page 090-17)
- Steering stabilisation valve block (For more information see: 090.4.2 Steering stabilisation valve block, page 090-20)
- Emergency steering
- Hydraulic oil cooler

100.2 Service brake and parking brake

100.2.1 Brake pump

Valid for: L556-1757;

1 Layout




Fig. 492: Brake pump (from front left and from front right)

- | | | | |
|---|----------------------------------|---|------------------------------------|
| 1 | Fan pump | 3 | Oil supply for compact brake valve |
| 2 | Suction port from hydraulic tank | | |

Brake pump is installed together with fan pump on left of vehicle on auxiliary drive of diesel engine.

2 Function




Fig. 493: Hydraulic diagram of brake pump

- | | | | |
|---|------------|---|------------------------------------|
| 1 | Fan pump | 3 | Suction port from hydraulic tank |
| 2 | Brake pump | 4 | Oil supply for compact brake valve |

Brake pump draws up oil from hydraulic tank through a suction port it shares with fan pump and pumps it to compact brake valve.

Brake pump supplies oil via compact brake valve to following systems:

- Service brake
- Parking brake
- Pilot control (via hydro accumulator for 1st brake circuit)
- Control valve block housing preheating (with surplus oil from brake system)
- Joystick steering control valve block housing preheating (with surplus oil from brake system) (option)





Fig. 501: Sectional view of the parking brake

- | | | | |
|----|--------------------------|----|----------------------|
| 1 | Ball for anti-twist lock | 13 | Brake shoe |
| 2 | Adjusting screw | 14 | Brake disc |
| 3 | Counter nut | 15 | Brake calliper |
| 4 | Cup spring | 16 | Solenoid |
| 5 | Snap ring | 17 | Fastening bolt |
| 6 | Brake piston | 18 | Transmission housing |
| 7 | Seal ring | 19 | Lock nut |
| 8 | Pressure chamber | 20 | Lining spring |
| 9 | Seal ring | 21 | Adjusting screw |
| 10 | Anti-dust membrane | 22 | Bleeder screw |
| 11 | Thrust pin | 23 | Cover |
| 12 | Solenoid | | |

LBH/12252623/03/211-20200326_151754/en



PROJECT GG_4_EVO 1333 90100 02 00 DRAWING NUMBER 12466553 000 DRAWING INDEX

ISO 16016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

BMK	SYSTEM	LOCATION	FUNCTION	PAGE	BMK	SYSTEM	LOCATION	FUNCTION	PAGE
-F4	=K	+K	ADDITIONAL CONTROLLER	/124.A2	-F17	=A4a	+B	FUSE CENTRAL LUBRICATION SYSTEM	/64.A2
-F5	=A4a	+B	FUSE SWITCH PARKING BRAKE	/48.F2	-F18	=A4	+K2	FUSE SOLENOID VALVES LogHandler	/25.E8
-F5	=A4b	+K2	FUSE ADDITIONAL CONTROLLER	/98.A5	-F18.	=A4a	+B1	FUSE PARKING BRAKE; TILT OUT; TILT IN; LIFT	/46.A2
-F5	=K	+K	ADDITIONAL CONTROLLER	/124.A4	-F19	=A4	+K	FUSE CENTRAL CONTROL UNIT MASTERS-PREMIUM	/48.A6
-F6	=A4	+K2	FUSE ACTIVATION DIESEL PARTICULATE FILTER	/106.A8	-F19	=A4a	+B1	FUSE EMERGENCY STEERING PUMP, FAN DRIVE, REVERSIBLE	/46.A6
-F6	=A4b	+K2	RESERVE FUSE	/95.A5	-F20	=A4	+K	FUSE REVERSING ALARM	/84.B5
-F6.	=A4a	+B	RESERVE	/54.A3	-F20.	=A4a	+B	DIESEL EXHAUST FLUID TANK	/55.A5
-F7	=A4	+K	FUSE SWITCH LIGHTING	/35.A6	-F21	=A4	+K	FUSE BEACON	/83.A4
-F7	=A4b	+K2	RESERVE FUSE	/95.A7	-F21.	=A4a	+B	FUSE EXHAUST THROTTLE VALVE	/56.A1
-F7.	=A4a	+B	FUSE SCR CATALYTIC CONVERTER INLET NOX SENSOR	/54.A5	-F22	=A4	+K	FUSE ADDITIONAL CONTROLLER OUTPUT MODULE 1	/88.A4
-F8	=A4	+K	FUSE CONDENSER FAN	/59.C8	-F22	=A4a	+B	FUSE ENGINE OIL PRESSURE	/56.A3
-F8	=A4a	+B	FUSE SCR CATALYTIC CONVERTER OUTLET NOX SENSOR	/54.A6	-F23	=A4	+K	FUSE ADDITIONAL CONTROLLER INPUT MODULE 1	/88.A2
-F9	=A4	+K2	FUSE BUTTON-OPERATED HORN	/33.A2	-F23.	=A4a	+B	FUSE HAZARD WARNING SYSTEM	/30.F2
-F9	=A4b	+K2	FUSE LOGIC UNIT EMERGENCY STEERING CIRCUIT JOYSTICK STEERING	/92.A3	-F24	=A4	+K	FUEL LEVEL SENSOR	/47.A2
-F9.	=A4a	+B	FUSE NH3 SENSOR	/55.A2	-F24.	=A4a	+B1	FUSE TRANSMISSION	/43.A4
-F01	=A4a	+B1	FUSE T. 30 FUSE BOARD	/24.D6	-F25	=A4	+K	FUSE HEATING AND AIR CONDITIONING SYSTEM	/58.A4
-F02	=A4a	+B1	FUSE HEATER FLANGE	/24.D7	-F25.	=A4a	+B	DIESEL EXHAUST FLUID LINE PREHEATER	/51.A4
-F03	=A4a	+B1	FUSE EMERGENCY STEERING PUMP	/24.D6	-F26.	=A4a	+B	SOLENOID VALVE; AIR SUPPLY, SCR SYSTEM	/51.A6
-F10	=A4	+K2	FUSE ANGLE SENSORS	/41.A4	-F27	=A4a	+B	FUSE EMERGENCY STEERING CIRCUIT JOYSTICK STEERING T. 15b	/92.F2
-F10	=A4b	+K2	FUSE EMERGENCY SPOOL VALVE POSITION SENSOR	/93.A8	-F28	=A4	+K	FUSE ADDITIONAL CONTROLLER OUTPUT MODULE 1	/88.A6
-F11	=A4	+K2	FUSE LIDAT MODULE	/62.A1	-F28a.W	=K2.RH	+K	FUSE PREPARATION WEIGHING DEVICE	/110.B5
-F11	=A4b	+K2	FUSE ARTICULATED JOINT ANGLE SENSOR	/93.A1	-F28b.W	=K2.R.H	+K	FUSE PREPARATION WEIGHING DEVICE	/110.B6
-F11.	=A4a	+B	FUSE HEATING CIRCUIT WATER VALVE	/51.A1	-F29	=A4	+K	FUSE ADDITIONAL CONTROLLER OUTPUT MODULE 1	/88.A7
-F12	=A4	+K	FUSE WINDSCREEN WASHER SYSTEM FRONT; HORN	/33.B4	-F30	=A4	+K	FUSE ADDITIONAL CONTROLLER OUTPUT MODULE 1	/88.A8
-F12	=A4b	+K2	FUSE JOYSTICK STEERING	/94.A8	-F31	=A4	+K	FUSE WINDSCREEN WASHER SYSTEM REAR	/34.A1
-F12	=B	+B	FUSE EMERGENCY ACTUATION OF PARKING BRAKE	/103.A1	-F31A	=A4	+K2	FUSE WORKING HEADLIGHT FRONT	/31.B3
-F13	=A4	+K	FUSE CONDENSER FAN	/59.C2	-F31B	=A4	+K2	FUSE WORKING HEADLIGHT FRONT	/31.B5
-F13	=A4b	+K2	FUSE STEERING WHEEL ANGLE SENSOR	/94.A5	-F32	=A4	+K	FUSE DISPLAY REVERSING CAMERA	/39.A1
-F13	=K	+K2	FUSE DISPLAY 2	/159.A2	-F32A	=A4	+K2	FUSE WORKING HEADLIGHT REAR	/32.B3
-F14	=K	+K2	FUSE KEYPAD 2	/128.A4	-F32B	=A4	+K2	FUSE WORKING HEADLIGHT REAR	/32.B5
-F14.	=A4a	+B	FUSE ENGINE CONTROL UNIT	/49.A1	-F33	=A4	+K	FUSE BRAKE LIGHT	/29.C2
-F15	=A4	+K	FUSE SWITCH ROAD TRAVEL	/26.F1	-F34	=A4	+K	FUSE IMMOBILISER	/39.A5
-F15.	=A4a	+B1	FUSE REVERSING SIGNAL	/46.A8	-F35	=A4	+K	FUSE MULTI-LEVER CONTROL	/135.A1
-F16	=A4	+K	FUSE ADDITIONAL CONTROLLER INPUT MODULE 1	/88.A3	-F36	=A4	+K	FUSE CONTROL LEVER CAN MODULE	/40.A2
-F16.	=A4a	+B1	FUSE WORKING HYDRAULICS LOCKOUT; LOWER; 3RD FUNCTION	/46.A5	-F37	=A4	+K	FUSE CONTROL UNIT; TRANSMISSION DIAGNOSTIC PLUG	/43.A1
-F17	=A4	+K	FUSE ADDITIONAL CONTROLLER OUTPUT MODULE 1	/88.A5	-F38	=A4	+K	FUSE REAR WINDOW HEATER MIRROR HEATER	/35.A5

BMK	SYSTEM	LOCATION	FUNCTION	LOCATION	SYSTEM	FUNCTION	PAGE
-X.LAN1	=K	+K2	CONNECTOR REVERSING ALARM BUTTON	+K2	=K	CONNECTOR ETHERNET MASTERS5-PREMIUM	/48.C7
-X.LAN1.X60b	=K	+K2	CONNECTOR REVERSING ALARM BUTTON	+K2	=K	CONNECTOR ETHERNET MASTERS6-PREMIUM	/48.C7
-X.S19b.B	=K	+K	CONNECTOR PREPARATION WEIGHING DEVICE	+K	=K	CONNECTOR ROAD TRAVEL	/26.C3
-X.S19b.S	=K	+K	CONNECTOR PREPARATION WEIGHING DEVICE	+K	=K	CONNECTOR ROAD TRAVEL	/26.B3
-X.Splice.Can #H	#H	+H	CONNECTOR DOOR CONTACT SWITCH	+H	#H	SPLICE	/55.F4
-X.Splice.Can #H#	#H#	+H	CONNECTOR DOOR CONTACT SWITCH	+H	#H	SPLICE	/55.F3
-X.Splice.Can #H	#H	+H	DOOR CONTACT SWITCHRECEIVING UNIT / CONTROL UNIT	+H	#H	SPLICE	/54.F6
-X.Splice.Can #H	#H	+H	CONTACT PINS; RECEIVING UNIT / CONTROL UNIT	+H	#H	SPLICE	/54.F8
-X.Splice.CAN #H	#H	+H	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+H	#H	SPLICE	/55.F4
-X.Splice.CAN #H	#H	+H	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+H	#H	SPLICE	/55.F3
-X.Splice.CAN #H	#H	+H	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	+H	#H	SPLICE	/54.F6
-X.Splice.CAN #H	#H	+H	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	+H	#H	SPLICE	/54.F8
-X.KI.30	=K	+K2	CONNECTOR WORKING BASKET SHUTDOWN	+K2	=K	CONNECTION T. 30	/86.A1
-XC	=F	+F3	CONNECTOR WORKING BASKET SHUTDOWN	+F3	=F	CONNECTOR TRANSMISSION	/43.B8
-XC2.B	=H	+H3	CONNECTOR COMPACT MODULE 1	+H3	=H	CONNECTOR CAN	/87.B5
-XC2.B*	=H	+H	CONNECTOR COMPACT MODULE 1	+H	=H	CONNECTOR CAN TERMINATOR	/40.D5
-XC2.B.	=H	+H3	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+H3	=H	CONNECTOR CAN	/87.E1
-XC2.S	=H	+H	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+H	=H	CONNECTOR COMPACT MODULE 1	/118.E7
-XC2.S.	=H	+H	CONNECTOR 24V SOCKET	+H	=H	CONNECTOR CAN	/87.D5
-XC2.S..	=H	+H3	CONNECTOR 24V SOCKET	+H3	=H	CONNECTOR CAN	/87.B2
-XC2a.	=K	+K	FRONT SECTION SOCKET RIGHT	+K	=K	CONNECTOR COMPACT MODULE 1	/118.B7
-XC2b.	=K	+K	FRONT SECTION SOCKET	+K	=K	CONNECTOR CAN CONNECTION	/91.B4
-XC.END2	=H	+H	CONNECTOR WIRELESS DEVICE	+H	=H	CONNECTOR CAN CONNECTION	/91.E4
-XD	=F	+F3	RADIO MUTE SWITCH RADIO COMFORT	+F3	=F	CAN TERMINATOR	/40.D5
-XDW	=K	+K	SPLICE	+K	=K	CONNECTOR TRANSMISSION	/43.D8
-XMSP1	=H	+H2a	CONNECTOR CAB FLOOR	+H2a	=H	DIAGNOSTIC PLUG AUXILIARY HEATER	/104.A4
-XMSP1	=H	+H2b	CONNECTOR CAB FLOOR	+H2b	=H	REAR SECTION GROUNDING POINT	/24.E7
-XMSP1	=H	+H2c	CONNECTOR CAB FLOOR	+H2c	=H	REAR SECTION GROUNDING POINT	/29.F8
-XMSP1	=H	+H2	CONNECTOR LIGHTING CONTROL	+H2	=H	REAR SECTION GROUNDING POINT	/29.E3
-XMSP1.Z11	=H	+H	DIAGNOSTIC PLUG, SKYVIEW 360°	+H	=H	REAR SECTION GROUNDING POINT	/24.D2
-XMSP1.ZO1	=H	+H	CONTROL ELECTRONICS, SKYVIEW 360°	+H	=H	GROUND INPUT MODULE	/88.F2
-XMSP4	=B	+Bb	DIAGNOSTIC PLUG, SKYVIEW 360°	+Bb	=B	GROUND OUTPUT MODULE	/88.F4
-XMSP4	=B	+Bc	DIAGNOSTIC PLUG, SKYVIEW 360°	+Bc	=B	GROUNDING POINT	/51.B5
-XMSP4	=B	+B1a	CONNECTOR PERSONNEL DETECTION	+Bc	=B	OPERATOR'S CAB GROUNDING POINT	/63.C4
-XMSP4.1	=H	+H	CONNECTOR PERSONNEL DETECTION	+B1a	=B	GROUNDING POINT	/45.C4
	=H	+H	CONNECTOR ENGINE CONTROL UNIT	+H	=H	REAR SECTION GROUNDING POINT	/24.E1

BMK	SYSTEM	LOCATION	FUNCTION	LOCATION	SYSTEM	FUNCTION	PAGE
-X106.B	=K	+K2	CONNECTOR REVERSING ALARM BUTTON	+K2	=K	CONNECTOR REVERSING ALARM BUTTON	/84.B1
-X106.S	=K	+K2	CONNECTOR REVERSING ALARM BUTTON	+K2	=K	CONNECTOR REVERSING ALARM BUTTON	/84.B1
-X111.B	=K	+K	CONNECTOR PREPARATION WEIGHING DEVICE	+K	=K	CONNECTOR PREPARATION WEIGHING DEVICE	/110.D5
-X111.S	=K	+K	CONNECTOR PREPARATION WEIGHING DEVICE	+K	=K	CONNECTOR PREPARATION WEIGHING DEVICE	/110.E5
-X115.B	=K	+K	CONNECTOR DOOR CONTACT SWITCH	+K	=K	CONNECTOR DOOR CONTACT SWITCH	/113.D1
-X115.B.X	=K	+K	CONNECTOR DOOR CONTACT SWITCH	+K	=K	CONNECTOR DOOR CONTACT SWITCH	/113.D1
-X117.F	=K	+K	DOOR CONTACT SWITCHRECEIVING UNIT / CONTROL UNIT	+K	=K	DOOR CONTACT SWITCHRECEIVING UNIT / CONTROL UNIT	/113.E2
-X118.S	=K	+K	CONTACT PINS; RECEIVING UNIT / CONTROL UNIT	+K	=K	CONTACT PINS; RECEIVING UNIT / CONTROL UNIT	/113.E3
-X200.B	=K	+K3	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+K3	=K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	/85.B1
-X200.S	=K	+K3	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+K3	=K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	/85.B1
-X201.B	=K	+K	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	+K	=K	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	/113.B1
-X201.S	=K	+K	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	+K	=K	INTERFACE CONNECTOR ELECTRIC DOOR OPENING	/113.B1
-X213.B	=V	+V	CONNECTOR WORKING BASKET SHUTDOWN	+V	=V	CONNECTOR WORKING BASKET SHUTDOWN	/119.B5
-X213.S	=V	+V	CONNECTOR WORKING BASKET SHUTDOWN	+V	=V	CONNECTOR WORKING BASKET SHUTDOWN	/119.C5
-X214.B	=K	+K	CONNECTOR COMPACT MODULE 1	+K	=K	CONNECTOR COMPACT MODULE 1	/118.C2
-X214.S	=K	+K	CONNECTOR COMPACT MODULE 1	+K	=K	CONNECTOR COMPACT MODULE 1	/118.B2
-X219.B	=K	+K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+K	=K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	/85.A5
-X219.S	=K	+K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	+K	=K	CONNECTOR EXTERIOR MIRROR ADJUSTMENT	/85.A5
-X255.B	=K	+K	CONNECTOR 24V SOCKET	+K	=K	CONNECTOR 24V SOCKET	/86.D8
-X255.S	=K	+K	CONNECTOR 24V SOCKET	+K	=K	CONNECTOR 24V SOCKET	/86.D8
-X321a	=V	+V	FRONT SECTION SOCKET RIGHT	+V	=V	FRONT SECTION SOCKET RIGHT	/116.D2
-X321b	=V	+V	FRONT SECTION SOCKET	+V	=V	FRONT SECTION SOCKET	/116.D8
-X325	=K	+K3	CONNECTOR WIRELESS DEVICE	+K3	=K	CONNECTOR WIRELESS DEVICE	/106.F3
-X326	=K	+K3	RADIO MUTE SWITCH RADIO COMFORT	+K3	=K	RADIO MUTE SWITCH RADIO COMFORT	/36.C6
-X500	=H	+H	SPLICE	+H	=H	SPLICE	/86.F2
-X500.B	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/86.D1
-X500.S	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/86.D2
-X501.B	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/86.D5
-X501.S	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/86.D5
-X502	=K	+K	CONNECTOR LIGHTING CONTROL	+K	=K	CONNECTOR LIGHTING CONTROL	/111.C4
-X503	=K	+K	DIAGNOSTIC PLUG, SKYVIEW 360°	+K	=K	DIAGNOSTIC PLUG, SKYVIEW 360°	/120.C2
-X504	=K	+K	CONTROL ELECTRONICS, SKYVIEW 360°	+K	=K	CONTROL ELECTRONICS, SKYVIEW 360°	/120.C4
-X504.a	=K	+K	DIAGNOSTIC PLUG, SKYVIEW 360°	+K	=K	DIAGNOSTIC PLUG, SKYVIEW 360°	/120.B8
-X615	=K	+K	CONNECTOR PERSONNEL DETECTION	+K	=K	CONNECTOR PERSONNEL DETECTION	/121.D3
-X616	=H	+H	CONNECTOR PERSONNEL DETECTION	+H	=H	CONNECTOR PERSONNEL DETECTION	/121.C1
-X710	=M	+M	CONNECTOR ENGINE CONTROL UNIT	+M	=M	CONNECTOR ENGINE CONTROL UNIT	/56.D1

12466553
ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT
ISO 19016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	SERIAL NUMBER	BMK-INDEX	PAGE	OF
LIDOS Gerät	XXXXX	ELECTRICAL SCHEMATIC;	21	
			CREATION DATE	08.10.2019 15:49

12466553
ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

WORKING HEADLIGHT FRONT
ELECTRICAL SCHEMATIC;

PAGE 31 OF

CREATION DATE 09.10.2019 15:49



1 2 3 4 5 6 7 8

1 2 3 4 5 6 7 8





12466553

ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 9010 02 00

DRAWING NUMBER

PROJECT
ISO 18018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

WORKING HYDRAULICS LOCKOUT, RIDE CONTROL, ANGLE SENSORS
ELECTRICAL SCHEMATIC;

PAGE 41 OF
CREATION DATE 08.10.2019 15:49

12466553


ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 15018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

1 2 3 4 5 6 7 8



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

DIESEL EXHAUST FLUID TANK COOLANT SOLENOID VALVE DIESEL EXHAUST FLUID LINE PREHEATER
ELECTRICAL SCHEMATIC;

PAGE 51 OF

08.10.2019 15:49

1 2 3 4 5 6 7 8

12466553
ITEM CODE
000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER
1333 90100 02 00

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

1 2 3 4 5 6 7 8

A

B

C

D

E

F



=K +K2		-A30		Modul Nr.:		Modulname:		ITU_GRUNDGERAT			
Phys. Adr.	Blatt	EA	Beschreibung	Stecker	Pin	Phys. Adr.	Blatt	EA	Beschreibung	Stecker	Pin
A30.1					1	A30.25					25
A30.2					2	A30.26					26
A30.3					3	A30.27	/62.E2				27
A30.4					4	A30.28			POWER SUPPLY	T. 30	28
A30.5	/62.F4		DCD		5	A30.29					29
A30.6	/62.F3		DTR		6	A30.30					30
A30.7					7	A30.31					31
A30.8	/62.F6		GROUND		8	A30.32					32
A30.9					9	A30.33	/62.F5		TXT		33
A30.10					10	A30.34	/62.F7		CTS		34
A30.11					11	A30.35					35
A30.12					12	A30.36					36
A30.13					13	A30.37					37
A30.14					14	A30.38					38
A30.15					15	A30.39					39
A30.16					16	A30.40					40
A30.17					17	A30.41					41
A30.18					18	A30.42	/62.E2		GROUND		42
A30.19	/62.F5		RXD		19						
A30.20	/62.F8		RTS		20						
A30.21					21						
A30.22					22						
A30.23					23						
A30.24					24						

MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX



OVERVIEW LIDAT
ELECTRICAL SCHEMATIC;

PAGE 71 OF

CREATION DATE 09.10.2019 15:49

1 2 3 4 5 6 7 8

12466553
ITEM CODE

000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 15016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OPTION WORKING HEADLIGHT REAR
ELECTRICAL SCHEMATIC;

PAGE 81 OF

CREATION DATE 09.10.2019 15:49



1 2 3 4 5 6 7 8

A B C D E F

12466553
ITEM CODE

000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 18018: The reproduction is prohibited, distribution and utilization of its contents to others without express authorization and liability of its contents to others without registration.

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX

LIEBHERR
FACTORY LBH

OPTION JOYSTICK STEERING CAN MODULE
ELECTRICAL SCHEMATIC;

PAGE 91 OF


CREATION DATE

08.10.2019 15:49



CAN 2

CAN 3



X1 GREY

X3 BLACK

1 2 3 4 5 6 7 8

A

B

C

D

E

F

12466553

ITEM CODE

DRAWING INDEX

000

GG_4_EVO

1333 9010 02 00

DRAWING NUMBER

PROJECT

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX

LIEBHERR
FACTORY LBH

OPTION AUTOMATIC DELAYED ENGINE STOP
ELECTRICAL SCHEMATIC;

PAGE 101

OF

CREATION DATE

09.10.2019 15:49

8

8

7

7

6

6

5

5

4

4

3


3

2

2

1

1




ISO 18016. The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

12466553
ITEM CODE
000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 19016: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations reserved in the case of patent, utility model or design registration.



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OPTION LIGHTING CONTROL
ELECTRICAL SCHEMATIC;

PAGE 111

OF

CREATION DATE


09.10.2019 15:49

12466553
ITEM CODE
000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT

ISO 15016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX



LIEBHERR
FACTORY LBH

OPTION BLAXTAIR REVERSING ALARM
ELECTRICAL SCHEMATIC;

PAGE 121 OF

CREATION DATE 09.10.2019 15:49

1 2 3 4 5 6 7 8



KEYPAD 3

PROJECT GG_4_EVO 1333 90100 02 00
 ITEM CODE 12466553
 DRAWING INDEX 000

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

ADDRESS	TYPE	PAGE	DESCRIPTION	CONNECTOR	PIN
A38.1	=K +K4 -A38	/128.B8	CAN LOW	X	1
A38.2		/128.B7	CAN HIGH	X	2
A38.3			CAN TERMINATOR	X	3
A38.4			GROUND	X	4
A38.5	/127.E5		S3_IN S4_IN	X	5
A38.6			INPUT INPUT	X	6
A38.7			CAN LOW	X	7
A38.8			CAN HIGH	X	8
A38.9	/128.D5		GROUND	X	9
A38.10	/128.D5		POWER SUPPLY	X	10
A38.11	/127.E6		S3_OUT S4_OUT	X	11
A38.12			OUTPUT OUTPUT	X	12

MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

PAGE 131 OF
 CREATION DATE 09.10.2019 15:49

KEYPAD 3 ELECTRICAL SCHEMATIC;

12466553
ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT
GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

ISO 19018. The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.


MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

VERSION 1 MULTI-LEVER CONTROL KEYPAD 12 3
ELECTRICAL SCHEMATIC;

PAGE 141 OF
CREATION DATE 09.10.2019 15:49



1 2 3 4 5 6 7 8

A B C D E F

1 2 3 4 5 6 7 8

PROJECT GG_4_EVO
 DRAWING NUMBER 1333 9010 02 00
 ITEM CODE 12466553
 DRAWING INDEX 000

ISO 19018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.





MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
 FACTORY LBH

VERSION 2 LogHandler KEYPAD 12
 ELECTRICAL SCHEMATIC;

PAGE 151 OF
 CREATION DATE 09.10.2019 15:49



MOTOR_SPL
TYPE

TABLE OF CONTENTS

ALTERNATOR	/8
BMK-INDEX	/15
CHARGE AIR TEMPERATURE & PRESSURE	/10
COMPRESSOR FOR AIR CONDITIONER	/8
COOLANT TEMPERATURE SENSOR	/11
ELECTRICAL WIRING DIAGRAM	/1
ENGINE CONTROL UNIT ECU3-SD	/7
ENGINE OVERVIEW	/6
EXHAUST FLAP	/9
EXHAUST GAS RECIRCULATION	/9
FUEL PRESSURE SENSOR	/10
FUEL TEMPERATURE SENSOR	/11
HEAT FLANGE WITH GROUND	/9
HIGH-PRESSURE PUMP VCV / PCV	/13
INSTALLATION PLACE ELECTRIC COMPONENTS	/4
INSTALLATION PLACE ELECTRIC COMPONENTS 3A DERIVAT	/5
INTERCOOLER TEMPERATURE SENSOR	/11
KEY TO SYMBOLS	/3
MODIFICATION SHEET	/3
NOZZLE CYL. 1-4	/14
OIL PRESSURE SENSOR	/10
PHASE SENSOR	/12
RAIL PRESSURE SENSOR	/13
SPEED SENSOR 1	/12
STARTER	/8
TERMINATING RESISTOR 120 Ohm	/9

PROJECT: 11392209

ISO 16016: The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of a patent, utility model or design.


REPLACEMENT FOR MARKED
0
DATE 06.02.2018 08:23
CHECKED
CONFIDENTIAL TECHNICAL REFEREE

LIEBHERR
A3
FACTORY LMB



DESIGNATION
ELECTRICAL WIRING DIAGRAM

DESCRIPTION
TABLE OF CONTENTS


ARTICLE CODE 11392206
DRAWING NUMBER 96 007 9309 90
INDEX 001
SYSTEM =M
SHEET 2 FROM 15
LOCATION +M
DATE 06.02.2018 08:23



SPEED SENSOR



PHASE SENSOR



REPLACEMENT FOR MARKED DATE CHECKED CONFIDENTIAL	Imbbap1 06.02.2018 08:23 Imbbua0 TECHNICAL REFEREE
--	--

LIEBHERR
FACTORY LMB
A3

DESIGNATION
ELECTRICAL WIRING DIAGRAM

DESCRIPTION
SPEED SENSOR 1, PHASE SENSOR

ARTICLE CODE	11392206	SYSTEM	=M	LOCATION	+M
DRAWING NUMBER	96 007 9309 90	INDEX	001	SHEET 12	FROM 15
<small>IMBBLOC 11392206 IMBBLOC 11392206 IMBBLOC 11392206</small>					

2 Function

2.1 Basic function

The input modules are part of the control system and are linked to the central control unit via a CAN bus interface. The measurements from sensors are read and evaluated by the input modules. (For more information see: [Input modules](#), page 110-17)

The output modules are part of the control system and are linked to the central control unit via a CAN bus interface. The central control unit can specify the current from the analogue outputs via the CAN bus. The module regulates what currents are required from the outputs. The output module actuates solenoid valves, proportional valves and relays, for example. (For more information see: [Output modules](#), page 110-18)

The tightening torque for the plug connections on the modules is 3 Nm.

2.2 Addresses of the input and output modules

Component	CAN line	Address	Setting when replaced	Status in the system
Input module A16a	1	45 (53, 81)	No	Mandatory
Input module A16b (optional)	2	47 (55, 83)	Yes	Optional
Input module A16L (LogHandler)	2	45 (53, 81)	Yes	Optional
Input module A16M (multi-lever control)	2	48 (56, 84)	Yes	Optional
Output module A17a	1	22 (14, 6, 50)	Yes	Mandatory
Output module A17b (optional)	2	21 (13, 5, 19)	No	Optional

Tab. 232: Module addresses



The CAN addresses can be called up in Sculi diagnostic software using *INFO* button.

For more information see the section on addressing the compact modules. (For more information see: [Addressing CAN module and checking system information](#), page 030-245)

Connections						Remark
IN			OUT			
X	Y	Z	15	87	87a	
1	0	0	1	1	1	Malfunction. Starting switch defective, external voltage or fuses for terminal 30 defective. Check fuses for terminal 30. Check starting switch. Check external voltage.
1	0	1	1	1	1	Malfunction. Starting switch defective or external voltage. Check starting switch. Check external voltage.
1	1	0	1	1	1	Malfunction. Starting switch defective, external voltage or fuses for terminal 30 defective. Check fuses for terminal 30. Check starting switch. Check external voltage.
1	1	1	1	1	1	Malfunction. Starting switch defective or external voltage. Check starting switch. Check external voltage.

Tab. 238: Diagnosis

1.3 Fuse board A4a




Fig. 524: Fuse board A4a

- | | | | |
|---|--|----|-----------------------------------|
| 1 | Battery main switch S15 | 7 | Distributor rail |
| 2 | Diesel exhaust fluid line indicator light E700 | 8 | 100A fuse for heating flange |
| 3 | Fuse board A4a | 9 | 100A main fuse |
| 4 | Socket for fuse test | 10 | Power supply from the batteries |
| 5 | Relay K01 | 11 | 200A emergency steering pump fuse |
| 6 | Relay K700 | | |

LBH/12252623/03/211-20200326_151754/en

g2010986

2	Temperature valve for gear oil cooler bypass	8	Transmission valve block	14	Gear oil filter
3	Oil from the gear oil cooler	9	Sight glass for gear oil level	15	Duct plate
4	Hydrostat module	10	Parking brake	16	Auxiliary power take-off 1 (not used)
5	Flange for driving diesel engine	11	Brake disc for parking brake	17	Gear pump
6	Auxiliary power take-off 2 (not used)	12	Gear oil filling tube	18	Vent valve

Name	Test point	Name	Test point	Name	Test point
MK1	Clutch 1 shift pressure (K1) A)	MKV	Clutch shift pressure for forward travel direction (KV) A)	MSy	System pressure A)
MK2	Clutch 2 shift pressure (K2) A)	MO1	Switching pressure for 1st optional connection B)		
MKR	Clutch shift pressure for reverse travel direction (KR) A)	MO2	Switching pressure for 2nd optional connection B)		

Tab. 244: Test points

A) Thread M10x1; tightening torque 6 Nm

B) Thread M12x1.5; tightening torque 35 Nm

BMK	Function	BMK	Function	BMK	Function
A25	Transmission control unit TCU	Y1	Proportional solenoid for clutch 2 (K2)	Y5	Proportional solenoid for clutch 1 (K1)
B84	Speed sensor for reverse travel direction clutch	Y2	Proportional solenoid for forward travel direction clutch (KV)	Y6	Proportional solenoid for 2nd optional connection
B85	Filter bypass switch	Y3	Proportional solenoid for 1st optional connection		
B86	Gear oil temperature sensor	Y4	Proportional solenoid for reverse travel direction clutch (KR)		

Tab. 245: Equipment codes

The planetary gears **ZP1** now rest on the sun gear **ZS1** and transmit the power via the planetary gears **ZP2** to the sun gear **ZS2** and the clutch **K2** to the output.

2.3.5 Machine continuing to accelerate (clutch K2 closed)




Fig. 539: Machine continuing to accelerate (clutch K2 closed)

Name	Description	Name	Description	Name	Description
A	Duct A	ZS2	Sun gear 2	Z9	Gearwheel 9
B	Duct B	ZP1	Planetary gear 1	KV	Forward travel direction clutch
T1	Rotary group 1	ZP2	Planetary gear 2	KR	Reverse travel direction clutch
T2	Rotary group 2	ZH	Ring gear	K1	Clutch 1
W1	Shaft 1	Z6	Gearwheel 6	K2	Clutch 2
W2	Shaft 2	Z7	Gearwheel 7		
ZS1	Sun gear 1	Z8	Gearwheel 8		

Tab. 255: Key

If the machine continues to accelerate, the double yoke begins to swivel back. As a result, the pump T2 starts delivering oil to the motor T1. The motor T1 drives the shaft W1 and thus transmits power hydraulically again as well as mechanically.

LBH/12252623/03/211-20200326_151754/en

120.2.4 Hydrostat module

Valid for: L556-1757;

1 Layout




Fig. 545: Hydrostat module (from front left)

- | | | | |
|---|--|----|--|
| 1 | Double yoke | 8 | Adjusting arm |
| 2 | Rotary group 1 | 9 | Servo cylinder (extend rotary group 2) |
| 3 | Discharge valve with pressure reducing valve 11 bar | 10 | Connection from rotary group 1 to transmission |
| 4 | Dummy piston | 11 | Upper swivel bearing for double yoke with rotary bushing |
| 5 | Servo cylinder (extend rotary group 1) | 12 | Oil supply from gear pump (via gear oil filter and hydrostat oil filter) |
| 6 | Lower swivel bearing for double yoke with rotary bushing | 13 | Rotary group 1 bearing lubrication |
| 7 | Connection from rotary group 2 to transmission | 14 | Rotary group 2 bearing lubrication |

120.3.6 Temperature sensor

Valid for: L556-1757;

1.1 Layout




Fig. 555: Temperature sensor

BMK	Function
B86	Gear oil temperature sensor

Tab. 270: Equipment codes

The temperature sensor is screwed into the transmission housing.

2.1 Function

The temperature sensor detects the gear oil temperature.

120.3.7 Proportional solenoid for position control

Valid for: L556-1757;

1.1 Layout




Fig. 556: Proportional solenoid for position control

1 Actuation pin

LBH/12252623/03/211-20200326_151754/en

130.2 Cardan shafts

130.2.1 Drive shaft between diesel engine and transmission

Valid for: L556-1757;

1 Layout




Fig. 563: Drive shaft between diesel engine and transmission

1	Universal joint	4	Transmission
2	Extension	5	Front axle
3	Diesel engine	6	Rear axle

2 Function

The drive shaft connects the output of the diesel engine 3 to the input of the transmission 4.

2.2 Removal and installation

The drive shaft is balanced. When disassembling the extension, it must therefore be ensured that the two drive shaft halves can be reassembled in the original position. The two drive shaft halves must not be installed twisted with respect to one another.

The universal joints must not be bent to stop position.

- Manual emergency operation may only be carried out by hand, not with an electric screwdriver. Emergency operation with an electric screwdriver can damage the linear motor. Emergency operation may not be carried out with more than 65 revolutions per minute.

2.4 Linear motor: Troubleshooting

Malfunction	Cause	Remedy
The motor does not make any noise or the piston rod does not move.	No power supply for driving the linear motor.	Check the fuse. Check the power supply. Check the wiring.
	No signal from the <i>engine hood</i> bitter.	Check the fuse. Check the power supply. Check the wiring. Check the <i>engine hood</i> button .
The linear motor switches off due to overload.	The engine hood is obstructed.	Check the hinge mechanism of the engine hood.
	Damage to the linear motor cylinder.	Check the cylinder of the linear motor. Try extending and retracting the drive with no load.
The electric motor is running but the cylinder does not move.	Damaged gear system or spindle.	Replace the linear motor.
The cylinder extends too slowly. The cylinder extends in jolts.	Too much resistance from the engine hood.	Check the hinge mechanism of the engine hood.
	Insufficient power supply. Voltage drop on the line.	Check the power supply. Check the wiring.

Tab. 274: Linear motor: Troubleshooting

150.3.2.2 Valve block for quick coupler

Valid for: L556-1757;

1 Layout




Fig. 577: Valve block for quick coupler (from front left and from rear right)

- | | | | |
|---|--|---|--|
| 1 | Pressure reducing valve for quick coupler | 4 | Return flow to control valve block |
| 2 | Load sensing signal for working pump (via control valve block) | 5 | Connection to hydraulic cylinder ring side |
| 3 | Oil supply from working pump (via control valve block) | 6 | Connection to hydraulic cylinder piston side |

Name	Test point
MS	Quick coupler closing pressure

Tab. 283: Test points

BMK	Function	BMK	Function
Y53	Solenoid for opening quick coupler	Y53a	Quick coupler load sensing signal solenoid

Tab. 284: Equipment codes

Quick coupler valve block is installed in front section to left of control valve block.

LBH/12252623/03/211-20200326_151754/en


2 Function

Fig. 584: Function of the control lever

- | | | | |
|---|----------------------------------|---|---|
| 1 | Control lever handle | 6 | Stop socket |
| 2 | Universal joint | 7 | Angle sensor for the tilt function |
| 3 | CAN module for control lever A26 | 8 | Angle sensor for the lifting and lowering functions |
| 4 | Universal joint | 9 | Return springs |
| 5 | Handle holder | | |

The control lever consists of the handle **1**, the universal joint **4** and the CAN module **3**.

The handle of the control lever contains the travel direction switch and the buttons for additional functions.

The signals from the travel direction switch and the additional function buttons are read by the CAN module of the control lever.

The handle of the control lever is screwed onto the universal joint.

The angle sensors for the tilt function **7** and the angle sensors for the lifting and lowering functions **8** are attached to the axles of the universal joint. These sensors measure the inclination of the control lever.

The universal joint has an action point in all four directions (additional spring force). If this action point is exceeded for more than 0.3 seconds, the kick-out function in that direction is activated.

The control lever CAN module reads and evaluates the signals from the angle sensors, the travel direction switch and the buttons.

This data is sent via a CAN line to the central control unit.

The control lever does not need to be calibrated.

1	Outside temperature sensor B39	12	Cooling/heating mixer flap
2	Blower	13	Mixer plate
3	Anti-icing sensor B38	14	Outlet temperature sensor B41
4	Evaporator	15	Outlet hood
5	Refrigerant forward flow	16	Servo motor for head/front level M17
6	Condensate trap	17	Cable harness outlet
7	Expansion valve	18	Servo motor for mixer flap M18
8	Refrigerant return flow	19	Air conditioning controller A21
9	Heat exchanger	20	Inside temperature sensor B40
10	Coolant forward flow	21	Servo motor for recirculated air/fresh air flap M14
11	Coolant return flow		

The heating and air conditioning unit is installed on the right on the operator's cab.

2.1 Function

The outside temperature sensor **1** measures the temperature of the fresh air drawn in from outside.

The anti-icing sensor **3** measures the temperature on the evaporator. The evaporator temperature is measured to prevent the evaporator from icing up. If the temperature falls below $-1\text{ }^{\circ}\text{C}$, the compressor coupling is switched off.

The outlet temperature sensor **14** measures the temperature in the mixing chamber. The temperature in the mixing chamber corresponds to the outlet temperature into the operator's cab.

The blower **2** draws in fresh air from outside. The fresh air drawn in is pumped through the condenser and if necessary the heat exchanger via the air pipes into the operator's cab.

The accumulated condensate is collected in the trap **6**. The collected condensate is then discharged via a hose on the bottom of the heating and air conditioning unit.

Refrigerant is evaporated in evaporator **4**. This extracts heat from the surroundings and the evaporator is cooled.

The expansion valve **7** injects refrigerant into the evaporator.

Hot coolant from the diesel engine passes through the heat exchanger **9**. This warms up the heat exchanger. If air is passed through the heat exchanger, it is heated up. The hot air is directed into the operator's cab. This heats the operator's cab.

The cooling/heating mixer flap **12** regulates cooling and heating. In heating mode, the air passes through the heat exchanger. In cooling mode, the path through the heat exchanger is shut off. The air passes directly from the evaporator to the mixing chamber.

The servo motor for the head/front-level flap **16** controls the distribution of air between the head area and the front area.

The servo motor for the mixer flap **18** controls the position of the flap to switch between heating and cooling.

The air conditioning controller **19** processes data from the sensors and controls the servo motors.

The cab air temperature sensor **20** measures the temperature in the operator's cab.

The servo motor for the fresh air flap **21** controls the amount of fresh air in the air drawn in.

160.4.3 Condenser

Valid for: L556-1757;

1 Layout




Fig. 600: Condenser unit components

1	Line to dryer	5	Condenser fan M13
2	Line from air conditioning compressor	6	Connecting line
3	Condenser	7	Dryer
4	Condenser fan M13a	8	Air conditioning pressure switch B27

The condenser is part of the cooling system.

2 Function

When the air conditioning compressor compresses the refrigerant, the refrigerant is heated up.

The forced-ventilated condenser cools the refrigerant. This turns the gaseous refrigerant into liquid.

The liquid refrigerant passes through the connecting line 6 to the dryer 7.

Cooling takes place through the air that is drawn in through the condenser by the condenser fans M13 5 and M13a 4.

When the air conditioning unit is switched on, both condenser fans run at half speed.

2.5 Liebherr automatic central lubrication system: industrial lift arms diagram




Fig. 608: Diagram of the central lubrication system with overview of lubrication points (Z kinematics)

- | | | |
|--------------------------------|---------------------------------------|----------------------------|
| 1 Central lubrication pump | 4 Secondary progressive distributor 2 | 7 High pressure hose (NW6) |
| 2 Main progressive distributor | 5 Secondary progressive distributor 3 | 8 Polyamide pipe |
| 3 Pulse generator | 6 High pressure hose (NW4) | |

LBH/12252623/03/211-20200326_151754/en

The flow rate depends on the piston diameter. Each progressive distributor requires at least three pumping elements to work properly.

The distributors must always be installed in a horizontal position.




Fig. 620: Progressive distributor

- | | |
|--|--|
| 1 Grease intake | 5 Basic end element |
| 2 Outlets to lubrication points and distributors | 6 Basic middle element |
| 3 Metering elements | 7 Outlets to lubrication points and distributors |
| 4 Dummy element | 8 Basic initial element |

The progressive distributor consists of a number of distributor plates connected together by tie rods with washers and nuts. The metering elements are fastened to the basic elements with hex socket screws. The individual elements are sealed with O-rings.

2 Function

2.1 Basic function




Fig. 621: Piston settings for the progressive distributor SXE-2

- | | | | |
|-------|------------------|-----|------------------------|
| A-C | Piston positions | 1-6 | Grease channel outlets |
| I-III | Piston | | |

LBH/12252623/03/211-20200326_151754/en

The LiDAT module is equipped with an internal rechargeable battery 1. The battery is charged using the battery voltage when terminal 30 is activated (battery main switch ON).

The charge status of the battery is monitored internally. If the battery is fully charged or damaged, the charging process is stopped.

1.5 Status display with indicator lamp (LED)













Fig. 629: Status display with indicator lamp (LED)

1 Indicator lamp (LED)

Indicator lamp (LED) 1 signals operating status of LiDAT module.

Colour	Code	Status
 Green	Flashes, 1 second on, 1 second off	OK, application runs on terminal 30.
 Green	Flashes, 1 second on, 10 second off	OK, application runs on internal rechargeable battery (optional).
 Green	Steady light	Starts or shuts down.
 White	Steady light	Application is restored or an update is performed.
 Yellow	Steady light	There are non-critical errors.
 Yellow	Flashes, 1 second on, 1 second off	No W-LAN reception (optional).
 Red	Flashes, 1 second on, 1 second off	Critical error
 Blue	Flashes, 1 second on, 1 second off	No GNSS reception.
 Magenta	Flashes, 1 second on, 1 second off	No GSM reception.

Tab. 299: Status display with indicator lamp (LED)

LBH/12252623/03/211-20200326_151754/en

2.2 Remote control




Fig. 647: Remote control

- | | | | |
|---|---------------|---|------------------------|
| 1 | Lock button | 3 | Unlock and open button |
| 2 | Unlock button | | |

Remote control sends encrypted signals to receiving unit and control unit.

Remote control is powered by a replaceable button battery inside case.

Remote control and receiving unit and control unit are programmed at factory before delivery. Programming is performed using a programming code. Programming code is enclosed on a label of remote control on delivery.

If a remote control is defective or lost, a new remote control can be requested from factory. Programming is performed using corresponding programming code.

If programming code is lost, a new programming code must be requested. If a new programming code is needed, remote control and receiving unit and control unit must be reprogrammed.

Silo operation consists of following components:

- Tilt sensor for silo operation
- Angle sensors for bucket position and lift arm position (For more information see: [060.8.2 Working hydraulics angle sensors, page 060-51](#))
- Pressure sensors for lift cylinder piston side (For more information see: [060.8.3 Pressure sensors for lift cylinders and tilt cylinders, page 060-53](#))
- Central control unit
- Transmission (For more information see: [120.1 Overview of transmission, page 120-2](#))
- Diesel engine

2 Function

2.1 Basic function

During silo operation, diesel engine and transmission increase the output torque (power boost). This means more power is available for pushing. To do this, the machine must operate with a certain load uphill in engine braking mode (for example, when moving the silo).

The silo operation reduces the service life of the drive components.

2.2 Activation and deactivation

Silo operation is automatically activated and deactivated by the central control unit. The power boost is gradually adjusted according to the following factors.

Power boost	0% to 100% (linear)	100%
Travel speed	9 km/h to 6 km/h	less than 6 km/h
Pressure on the lifting cylinder piston side	230 bar to 150 bar	less than 150 bar
Angle of inclination around the transverse axis	4° to 8°	8°
Bucket angle starting from saved loading position	25° to 20° tilted in	less than 20° tilted in
Lift cylinder position	60% to 50%	less than 50%

Tab. 307: Parameters for silo operation

The travel speed is sent by the transmission control unit **A25** to the central control unit **A15**.

The pressure on the lifting cylinder piston side is detected by pressure sensor for the lift cylinder piston side **B90**.

The inclination angle is detected by the tilt sensor **B95** and sent via the CAN line **CAN 5** to the central control unit.

The lift arm position is detected by the angle sensors for the bucket position **B60** and lift arm position **B61**.

The central control unit **A15** transmits the appropriate commands to the engine control unit **A700** and transmission control unit **A25**.

2.3 Activation

Install the current transmission software and set the variable **CXTorqueBoosterOn** to **1**.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL