

**en**

**Service manual**

Wheel loader

**Document ID**

**Order number:** 12252628  
**Issued:** 12-2019  
**Version:** 01  
**Author:** LBH / Technical Documentation Department

**Product ID**

**Manufacturer:** Liebherr-Werk Bischofshofen GmbH  
**Valid for:** L 586-1761

**Contact**

Liebherr-Werk Bischofshofen GmbH  
Dr. Hans Liebherr-Straße 4  
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	020.14.3.4	SXE-2 220	020-37
	020.14.3.5	SXE-2 400	020-37
	020.14.3.6	SXE-2 760	020-37
<b>030</b>	<b>Maintenance</b>		<b>030-1</b>
030.1	Maintenance and inspection schedule		030-10
030.2	Filling quantities and lubrication chart		030-15
030.2.1	Lubricant filling quantity <i>L586-1761</i> ;		030-15
030.2.2	Fuel and operating fluid filling quantity <i>L586-1761</i> ;		030-15
030.3	Lubricants and fuels		030-16
030.3.1	General information on lubricants and fuels		030-16
	030.3.1.1	General questions	030-16
	030.3.1.2	Safety data sheets	030-16
	030.3.1.3	Technical data sheets	030-16
	030.3.1.4	Specific Liebherr standards	030-16
030.3.2	General information on changing lubricants and fuels		030-16
030.3.3	Converting hydraulic system from mineral oils to biodegradable hydraulic fluids		030-17
030.3.4	Diesel fuels <i>L586-1761</i> ;		030-17
	030.3.4.1	Minimum quality requirement	030-17
	030.3.4.2	Operating temperatures of diesel fuels	030-18
	030.3.4.3	Minimum quality requirement	030-18
030.3.5	Diesel exhaust fluid <i>L586-1761</i> ;		030-18
	030.3.5.1	Liebherr recommendation	030-18
	030.3.5.2	Minimum quality requirement	030-18
030.3.6	Engine oils <i>L586-1761</i> ;		030-19
	030.3.6.1	Liebherr recommendation	030-19
	030.3.6.2	Minimum quality requirement	030-19
	030.3.6.3	Changing intervals	030-19
	030.3.6.4	Complicating factors	030-20
030.3.7	Refrigerant <i>L586-1761</i> ;		030-20
030.3.8	Coolant <i>L586-1761</i> ;		030-21

	040.1.7.4	Sampling module <i>L586-1761;</i>	040-41
	040.1.7.5	Exhaust treatment sensors <i>L586-1761;</i>	040-42
040.1.8	Compressed air system		040-43
	040.1.8.1	Overview of the compressed air system <i>L586-1761;</i>	040-44
	040.1.8.2	Compressor <i>L586-1761;</i>	040-46
	040.1.8.3	Air dryer <i>L586-1761;</i>	040-47
	040.1.8.4	SCR system air supply valve <i>L586-1761;</i>	040-48
040.2	Clutch <i>L586-1761;</i>		040-49
040.3	Splitter box <i>L586-1761;</i>		040-51
<b>050</b>	<b>Cooling system</b>		<b>050-1</b>
050.1	Cooling system: General overview <i>L586-1761;</i>		050-2
050.2	Cooling system hydraulics		050-3
	050.2.1	Overview of cooling system hydraulics <i>L586-1761;</i>	050-4
	050.2.2	Fan pump <i>L586-1761;</i>	050-8
	050.2.3	Fan motor <i>L586-1761;</i>	050-9
050.3	Cooling system electronics		050-13
	050.3.1	Overview of electrical controls of cooling system <i>L586-1761;</i>	050-13
	050.3.2	Hydraulic oil temperature sensor <i>L586-1761;</i>	050-16
050.4	Cooler		050-18
	050.4.1	Cooler unit <i>L586-1761;</i>	050-18
050.5	Reversible fan drive		050-19
	050.5.1	Overview of reversible fan drive <i>L586-1761;</i>	050-19
	050.5.2	Fan reversal valve block <i>L586-1761;</i>	050-21

	010.3.1.3	Modifications and descriptions	010-38
	010.3.1.4	Tightening torques	010-38
	010.3.2	Liebherr standards for assembly instructions and tightening torques	010-44
010.4		Preservation guidelines	010-45
	010.4.1	General information	010-45
	010.4.2	Machine out of service for an unknown period of time	010-45
	010.4.3	Putting the machine out of service	010-46
	010.4.3.1	Out of service for up to 2 months	010-46
	010.4.3.2	Out of service for up to 12 months	010-47
	010.4.3.3	Out of service for longer than 12 months	010-48
	010.4.4	Putting back into service	010-48
	010.4.4.1	After being out of service for 2 months	010-48
	010.4.4.2	After being out of service for 12 months	010-49
	010.4.4.3	After being out of service for longer than 12 months	010-49
010.5		Preservation guidelines for the SCR system	010-50
	010.5.1	Putting out of service for longer than 2 months	010-50
	010.5.2	Starting up after being out of service for longer than 2 months	010-50

### 010.1.4.2 Roll over protective structure (ROPS)

#### Danger to life

##### Damaged falling object protective structures

- Do not put machine into service with damaged falling object protective structures.
- Do not put machine into service with deformed falling object protective structures.
- Do not use falling object protective structures with structural changes.
- Do not use repaired falling object protective structures.
- Do not perform welding on falling object protective structures.
- Do not cut or saw falling object protective structures.
- Do not drill falling object protective structures.

##### Exceeding of total weight

- Make sure that total weight of machine (see identification plate) is not exceeded.
- Make sure that the machine does not exceed the total weight with heavy working tools.
- Make sure that the machine does not exceed the total weight after changing the working attachment.
- Make sure that the machine does not exceed the total weight with add-ons or after retrofitting.

### 010.1.4.3 Falling object protective structures (FOPS)

#### Danger to life

##### Damaged falling object protective structures

- Do not put machine into service with damaged falling object protective structures.
- Do not put machine into service with deformed falling object protective structures.
- Do not use falling object protective structures with structural changes.
- Do not use repaired falling object protective structures.
- Do not perform welding on falling object protective structures.
- Do not cut or saw falling object protective structures.
- Do not drill falling object protective structures.

### 010.1.5 Emergency equipment on the machine

#### 010.1.5.1 Emergency exit (standard)






#### Danger to life

##### Incorrect labelling

- Make sure that all information signs are present.
- Make sure that all information signs are legible.


## 010.2 Special tools for maintenance and repair work

### 010.2.1 Special tools, general

Designation	Item code	Remark	Fig.
Refractometer	11830573	For checking acid density of batteries, antifreeze concentration in coolant and diesel exhaust fluid	
24 volt vacuum pump	7408148	For preventing loss of oil when working on hydraulic system	
Testing and filling device for hydro accumulators, with case	8460226	For testing and filling hydro accumulators	
Pressure gauge (40 bar), class 1.0	7361288	For testing hydraulic pressure	
Pressure gauge (250 bar), class 1.0	7361285	For testing hydraulic pressure	


LBH/12252628/01/211-2019/12/18\_155739/en

### 010.2.10 Special tools for front axle

Designation	Item code	Remark	Fig.
Positioning tool	12244602	For mounting the bevel gear shaft seal ring	




Tab. 13: Special tools for front axle

### 010.2.11 Special tools for rear axle

Designation	Item code	Remark	Fig.
Positioning tool	12244602	For mounting bevel gear shaft seal ring	

Tab. 14: Special tools for rear axle

### 010.2.12 Special tools for the air conditioning system

Designation	Item code	Remarks	Fig
Valve insert remover	11834779	For changing valve inserts in the filling port of air conditioning hoses.	
Valve insert in air conditioning hose filling port	11834778	For replacing defective valve inserts. Set of 10	
Vacuum pump	7027552	For evacuating the air conditioning system	

LBH/12252628/01/211-2019/12/18\_155739/en

Metric standard threads and fine threads				Metric standard threads and fine threads			
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fIZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fIZnnc-480h-L valid $\geq$ M6 )				All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)			
Minimum total coefficient of friction $\mu_G = 0.09$				Minimum total coefficient of friction $\mu_G = 0.11$			
Thread	Strength class	Assembly prestressing forces $F_M$ in kN	Tightening torques $M_A$ in Nm	Thread	Strength class	Assembly prestressing forces $F_M$ in kN	Tightening torques $M_A$ in Nm
M 33	8.8	370	1550	M 33	8.8	370	1800
	10.9	550	2250		10.9	540	2600
	12.9	640	2600		12.9	630	3100
M 33 x 1.5	8.8	430	1650	M 33 x 1.5	8.8	420	1950
	10.9	630	2450		10.9	620	2900
	12.9	740	2800		12.9	730	3400
M 33 x 2	8.8	420	1600	M 33 x 2	8.8	410	1900
	10.9	610	2400		10.9	600	2800
	12.9	720	2800		12.9	700	3300
M 36	8.8	440	1950	M 36	8.8	430	2300
	10.9	650	2900		10.9	630	3400
	12.9	760	3400		12.9	740	3900
M 36 x 1.5	8.8	520	2150	M 36 x 1.5	8.8	510	2600
	10.9	760	3200		10.9	750	3800
	12.9	890	3700		12.9	870	4400
M 36 x 3	8.8	470	2050	M 36 x 3	8.8	460	2400
	10.9	690	3000		10.9	680	3500
	12.9	810	3500		12.9	790	4100
M 39	8.8	530	2500	M 39	8.8	520	3000
	10.9	770	3700		10.9	760	4400
	12.9	910	4400		12.9	890	5100
M 39 x 1.5	8.8	610	2800	M 39 x 1.5	8.8	600	3300
	10.9	900	4000		10.9	880	4800
	12.9	1050	4700		12.9	1030	5600
M 39 x 3	8.8	560	2600	M 39 x 3	8.8	550	3100
	10.9	820	3900		10.9	810	4500
	12.9	960	4500		12.9	940	5300

Tab. 21: Bolt prestressing forces and tightening torques

\*The tightening torques for fIZn bolts <M10 are non-binding because no fixed friction coefficient window is defined in the LH10215295 standard. According to the

020.8.1	Central control unit (Master5-Premium) <i>L586-1761;</i>	020-23
020.8.2	Input module <i>L586-1761;</i>	020-23
020.8.3	Output module <i>L586-1761;</i>	020-23
020.8.4	Battery <i>L586-1761;</i>	020-24
020.8.5	Voltage transformer <i>L586-1761;</i>	020-24
020.8.6	Reversing camera <i>L586-1761;</i>	020-24
020.9	Gearbox	020-25
020.9.1	Transmission <i>L586-1761;</i>	020-25
020.9.2	Filter bypass switch B85 <i>L586-1761;</i>	020-25
020.9.3	Proportional solenoid for gear shifting Y1, Y2, Y3, Y4, Y5, Y6 <i>L586-1761;</i>	020-25
020.9.4	Pressure sensor B80, B81 <i>L586-1761;</i>	020-26
020.9.5	Speed sensor B82, B83, B84 <i>L586-1761;</i>	020-26
020.9.6	Transmission oil temperature sensor B86 <i>L586-1761;</i>	020-26
020.9.7	Proportional solenoid for position control Y7 <i>L586-1761;</i>	020-27
020.10	Axles and drive shafts	020-28
020.10.1	Front axle <i>L586-1761;</i>	020-28
020.10.2	Rear axle <i>L586-1761;</i>	020-28
020.10.3	Drive shaft between diesel engine and transmission <i>L586-1761;</i>	020-28
020.10.4	Drive shaft between transmission and front axle <i>L586-1761;</i>	020-29
020.10.5	Cardan shaft between transmission and rear axle <i>L586-1761;</i>	020-29
020.10.6	Tyres <i>L586-1761;</i>	020-29
	020.10.6.2 Special tyres	020-30
020.11	Steel parts of the basic machine	020-31
020.11.1	Ballast weights <i>L586-1761;</i>	020-31

## 020.3 Cooling system

### 020.3.1 Fan pump

Valid for: L586-1761;

Description	Unit	Value
Type		External gear pump
Displacement per turn	cm <sup>3</sup>	14
Direction of rotation		Anticlockwise

### 020.3.2 Fan motor

Valid for: L586-1761;

Description	Unit	Value
Type		External gear motor
Displacement per turn	cm <sup>3</sup>	22.5
Direction of rotation		Anticlockwise
Pressure relief	bar	220
Weight	kg	6.68

### 020.3.3 Hydraulic oil temperature sensor B8

Valid for: L586-1761;

Description	Unit	Value
Minimum temperature	°C	-30
Maximum temperature	°C	130
Resistance at 20 °C	Ω	1000
Connecting thread	mm	M14x1.5
Tightening torque	Nm	30

## 020.8 Electrical system

### 020.8.1 Central control unit (Master5-Premium)

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP65
Power supply (logic unit)	VDC	7.0 – 36.0
Rated voltage	VDC	24
Operating temperature	°C	-40 to +60
Weight	kg	2

### 020.8.2 Input module

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP6K9K
Power supply (logic unit)		See sticker on module
Rated voltage	VDC	24
Operating temperature	°C	-40 to +85
Operation at ambient air pressure	mbar	500 to 1100
Weight	kg	1.77
Module connector tightening torque	Nm	3

### 020.8.3 Output module

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP6K9K
Power supply (logic unit)		See sticker on module
Rated voltage	VDC	24
Operating temperature	°C	-40 to +85
Operation at ambient air pressure	mbar	500 to 1100
Weight	kg	1.77
Module connector tightening torque	Nm	3

## 020.13 Operator's cab, heating and air conditioning

Valid for: L586-1761;

### 020.13.1.1 Air conditioning compressor

Description	Unit	Value
Manufacturer		Sanden
Refrigerant oil (PAG oil)		ZXL 100 PG

### 020.13.2 Air conditioning pressure switch

Valid for: L586-1761;

Description	Unit	Value
Low pressure OFF	bar	2 <sup>±0.2</sup>
Low pressure ON	bar	2.1 <sup>±0.3</sup>
High pressure OFF	bar	27 <sup>±2</sup>
High pressure ON	bar	20 <sup>±3</sup>
Increase fan speed OFF	bar	14 <sup>±1.2</sup>
Increase fan speed ON	bar	17 <sup>±1.2</sup>

	030.4.9.3	Control lever: Change the travel direction switch rocker and cap. <i>L586-1761;</i>	030-125
	030.4.9.4	Personnel detection: cleaning sensor <i>L586-1761;</i>	030-127
030.4.10	Gearbox		030-128
	030.4.10.1	Transmission: checking the oil level <i>L586-1761;</i>	030-128
	030.4.10.2	Changing gear oil and gear oil filter <i>L586-1761;</i>	030-131
	030.4.10.3	Change the transmission hydrostat oil filter. <i>L586-1761;</i>	030-134
030.4.11	Axles and drive shafts		030-135
	030.4.11.1	Axles Changing the oil <i>L586-1761;</i>	030-135
	030.4.11.2	Checking drive shafts <i>L586-1761;</i>	030-137
	030.4.11.3	Checking the tyre pressure <i>L586-1761;</i>	030-139
	030.4.11.4	Checking the wheel tightness <i>L586-1761;</i>	030-141
030.4.12	Steel parts of the basic machine		030-141
	030.4.12.1	Cooler hood: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-141
	030.4.12.2	Engine hood: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-142
	030.4.12.3	Right cab access: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-143
	030.4.12.4	Service hatches: Cleaning and maintaining the seals <i>L586-1761;</i>	030-143
030.4.13	Working attachment		030-144
	030.4.13.1	Lift arms: Checking the bucket bearing seals <i>L586-1761;</i>	030-144
	030.4.13.2	Checking the lift arm bucket bearing bushings <i>L586-1761;</i>	030-145
	030.4.13.3	Checking the lift arm bucket stops <i>L586-1761;</i>	030-146
	030.4.13.4	Bucket: Check the teeth or undercut blade for wear and replace if necessary <i>L586-1761;</i>	030-147
	030.4.13.5	Lubricate and test the bearings on the quick coupler. <i>L586-1761;</i>	030-150

## 030.2 Filling quantities and lubrication chart

### Specifications in the quantity column:

- The values stated for the filling quantities in the table are only guidelines.
- The dipstick and level markings are always mandatory.
- Each time the oil is replaced or topped up, check the level in the unit in question.

Valid for: L586-1761;

### 030.2.1 Lubricant filling quantity

Valid for: L586-1761;

Designation	Quantity
Diesel engine (with filter change)	42 l
Hydraulic system: system content	210 l
Hydraulic system: tank capacity (exchange amount)	95 l
Splitter box	1.2 l
Transmission	55 l
Front axle	60 l
Rear axle	60 l

Tab. 30: Lubricant filling quantity

### 030.2.2 Fuel and operating fluid filling quantity

Valid for: L586-1761;

Designation	Quantity
Fuel tank	500 l
Diesel exhaust fluid tank	67.5 l
Cooling system (system content)	73 l
Windscreen washer system	5.3 l
Air conditioning refrigerant	1.25 <sup>+0.02</sup> kg
CO <sub>2</sub> equivalent	1.79 t
Refrigerant oil for air conditioning compressor	210 cm <sup>3</sup>

Tab. 31: Fuel and operating fluid filling quantity

### 030.3.14 Windscreen washer fluid

*Valid for: L586-1761;*

#### 030.3.14.1 Liebherr recommendation

Liebherr recommends standard windscreen washer fluid with anti-freeze.

#### 030.3.14.2 Minimum quality requirement

Use mixture of water and denatured alcohol.

### 030.3.15 Refrigerant oil for air conditioning compressor

*Valid for: L586-1761;*

#### 030.3.15.1 Liebherr recommendation

Designation
ZXL 100 PG (PAG Oil)

*Tab. 56: Liebherr recommendation*

Position	Component	Check
3	Working attachment	Check working attachment for loose bolts, damage and wear.
4	Diesel exhaust fluid tank	Check SCR system for leaks and damage.
5	Underside of engine compartment	Open cover plates on underside of diesel engine. Check underside of engine compartment for damage, loose bolts and leaks.
6	Underside of wheel loader	Check underside of wheel loader for loose bolts, leaks and damage. Check transmission for leaks and damage.
7	Cab access	Check fluid level in windscreen washer tank and central lubrication system (option).
8	Cooling system	Check cooling system for loose bolts, leaks and damage.
9	Diesel engine	Check SCR system for loose bolts and clips. Check SCR system for damage. Check SCR system for leaks.
10	Operator's cab	Check mirrors and other visual aids for damage. Check indicators and control elements for damage. Check service codes. Check function of installed cameras (reversing camera etc.).
11	Wheel wedges	Check chock for damage. Check function of chock.

Tab. 58: Checking machine is in proper condition

### 030.4.3.2 Removing loose parts, dirt, ice and snow from machine

Valid for: L586-1761;

Make sure the following requirements are met:

- Machine is in maintenance position 1.



#### Note

Ensure safe machine operation.


- ▶ Remove any loose parts, coarse dirt, mud, ice, snow etc.
- ▶ Carefully clean machine with a high-pressure cleaner.
  - ▷ (For more information see: [Cleaning machine, page 030-35](#))

### 030.4.3.3 Cleaning machine

Valid for: L586-1761;

Thoroughly clean the machine of all dirt and deposits in the following situations:

- After completing each job
- Before maintenance work
- Before repairs



G2005553

Fig. 97: Sampling point on the splitter box

- |   |               |   |               |
|---|---------------|---|---------------|
| 1 | Splitter box  | 3 | Sampling hose |
| 2 | Dipstick tube | 4 | Hand pump     |

- ▶ Start the engine and wait 3 minutes.
  - ▷ The oil is circulated.
- ▶ Put machine in maintenance position 1.



#### WARNING

Hot components!  
Risk of injury.

- ▶ Do not touch components of the exhaust system and the engine.

- ▶ Take out dipstick.
- ▶ Insert the sampling hose 3 to 5 cm below the oil level.
- ▶ Fill the sample container using the hand pump 4.
- ▶ Remove the sampling hose.
- ▶ Put the dipstick back in again.

#### Coolant circuit

The coolant sample is taken from the coolant equalising reservoir using a hand pump.

▷ Engine oil pressure symbol must not light up.

▶ Turn off diesel engine.



### WARNING

Hot components!  
Injury.

▶ Do not touch components of exhaust system and diesel engine.

▶ Check that oil filter is leak-tight.

▶ After 2 or 3 minutes, check whether oil level on dipstick is between **MIN** and **MAX** markings.

If the oil level is not between the **MIN** and **MAX** markings:

▶ Correct oil level.

## 030.4.4.4 Checking diesel engine belt drive

Valid for: L586-1761;

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- The diesel engine and exhaust system have cooled down.




Fig. 107: Checking diesel engine belt drive

- |                 |                     |
|-----------------|---------------------|
| 1 Pulleys       | 3 Deflector roller  |
| 2 V-ribbed-belt | 4 Tensioning device |

Following damage could occur on V-ribbed belt:

- Broken ribs
- Lumps of rubber on belt
- Accumulated dirt or grit
- Ribs coming loose from belt
- Cracks across back
- Cracks across several ribs

▶ Check V-ribbed belt 2 for damage.

- ▶ Install new fuel pre-filter **6**.
- ▶ Check the seal **4** and replace it if necessary.
- ▶ Check that cover **2** is clean, put it on again and tighten screws **3** crosswise and evenly.
- ▶ Close drain valve **7**.
- ▶ Tighten the bleeder screw **1** with a torque of 6 Nm.
- ▶ Put hand pump in the *RUN* position **9**.
- ▶ Bleed the fuel system.

### Bleeding fuel system

Bleeding fuel system is necessary after:

- Changing fuel filter
- Emptying fuel tank

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.

Make sure that following tool is ready.

- Receptacle



#### WARNING

Highly flammable consumables!  
Beware of burns.

- ▶ Avoid naked lights and fire.




Fig. 117: Bleeding fuel system

- 1** Hand pump in the *PUMP* position    **2** Hand pump in the *RUN* position

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- The engine has cooled down.
- Suitable protective equipment is used.




Fig. 127: Air filter: Changing the safety element

- |   |                      |   |                |
|---|----------------------|---|----------------|
| 1 | Dust discharge valve | 4 | Main element   |
| 2 | Service cover        | 5 | Safety element |
| 3 | Fixing clips         | 6 | Filter housing |

- ▶ Release the fixing clips 3 on the service cover 2.
- ▶ Take off the service cover 2.
- ▶ Remove the main element 4.
- ▶ Clean the service cover 2 and the filter housing 6 with a clean cloth.
- ▶ Remove the safety element 5.
- ▶ Lightly oil the sealing faces of the new safety element 5 and the main element 4.
- ▶ Install the new safety element 5 and the main element 4.
- ▶ Put the service cover 2, with the dust discharge valve 1 facing down, on the filter housing 6.
- ▶ Close the fixing clips 3.

#### 030.4.4.18 Splitter box: Checking the oil level

Valid for: L586-1761;

The dipstick and the oil filler pipe are located in the engine compartment beside the air filter. Access is from above the engine on the left-hand side.

#### Checking the oil level

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- The machine is level.




Fig. 136: Changing filter module

- |   |                            |   |                     |
|---|----------------------------|---|---------------------|
| 1 | Profile clip               | 5 | Hinge strap bracket |
| 2 | Bolt clamp                 | 6 | Profile clip        |
| 3 | Differential pressure line | 7 | Filter module       |
| 4 | Output module              | 8 | Profile clip        |

- ▶ Secure filter module 7 against falling down with a securing element (wooden block, sling, support).
- ▶ Release profile clip 1.
- ▶ Release bolt clamp 2.
- ▶ Release differential pressure line 3.
- ▶ Release hinge strap bracket 5.
- ▶ Release profile clip 6.
- ▶ Remove output module 4.
- ▶ Release profile clip 8.
- ▶ Take out filter module 7.

### Installing filter module

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Diesel engine has cooled down.
- Service access is open.

Make sure that following components are ready:

- New or cleaned filter module.
- New seals and profile clips.



#### Note

- ▶ Replace profile clips and seals with new parts after each release.

## Checking the corrosion inhibitor concentration

In exceptional circumstances, the machine can be filled with corrosion inhibitor without antifreeze.



### Note

Corrosion inhibitor without antifreeze may only be used in exceptional cases.

- ▶ Only use corrosion inhibitor without anti-freeze when no approved antifreeze and corrosion agent is available and the ambient temperature is above freezing all year round.
- ▶ If in doubt, contact the technical customer service department.

Make sure that following requirements are met:

- Machine is cold.
- Machine is in maintenance position 1.
- Service access is open.

Make sure that following tools are ready:

- Refractometer with Brix scale
- Drain hose
- Receptacle




Fig. 144: Checking the corrosion inhibitor concentration

- |   |                      |   |             |
|---|----------------------|---|-------------|
| 1 | Cap                  | 3 | Drain valve |
| 2 | Equalising reservoir |   |             |



### CAUTION

Hot, pressurised liquid!  
Beware of burns.

- ▶ Let the engine cool down.
- ▶ Open the cap 1 of the equalising reservoir 2.

### Checking the corrosion inhibitor concentration



- The machine is parked on level ground.

Make sure that the following tools are ready:

- Feeler gauge
- Laptop with Sculi diagnostic software
- Torque wrench

## Preparations




Fig. 167: Using chocks to secure the machine against rolling away

### 1 Chock

- ▶ Start the diesel engine.
- ▶ Turn the steering wheel far left as it will go.
  - ▷ The parking brake is now accessible.
- ▶ Lay the bucket flat on the ground.
- ▶ Turn off the diesel engine.
- ▶ Use chocks **1** to secure the machine against rolling away.

## Checking the wear on the brake linings




Fig. 168: Checking the wear on the brake linings

- |                       |                                         |
|-----------------------|-----------------------------------------|
| <b>1</b> Brake shoe   | <b>3</b> Brake disc                     |
| <b>2</b> Brake lining | <b>s1</b> Thickness of the brake lining |

## Checking the charge level

- ▶ Check the charge level with a refractometer.

Charge levels				
Acid density at 27 °C (kg/l)	Charge level	Battery voltage	Voltage per cell	Remark
1.28 to 1.26	100%	Over 12.60	Over 2.10	Battery OK
1.25 to 1.24	75%	12.54 to 12.40	2.10 to 2.07	
1.24 to 1.18	50%	12.40 to 12.18	2.07 to 2.03	Charge the battery
1.18 >	25%	12.18 >	2.03 >	Battery not OK

Tab. 64: Table of charge levels

If the acid density is below 1.24 kg/l:

- ▶ Charge the batteries.

If the acid density is below 1.18 kg/l:

- ▶ Replace the batteries.

### 030.4.9.3 Control lever: Change the travel direction switch rocker and cap.

Valid for: L586-1761;

#### Changing the travel direction rocker switch



#### Note

If joystick steering is installed, the rocker that is used most often must be changed.

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.





Fig. 176: Changing the travel direction rocker switch

1 Rocker

2 Seal





G32002215

Fig. 198: Lift arms: Checking the bucket bearing seals

- |   |                      |   |                     |
|---|----------------------|---|---------------------|
| 1 | Bucket bearing plate | 4 | Dirt guard          |
| 2 | Bucket arm           | B | Bucket bearing seal |
| 3 | Sealing lips         |   |                     |

- ▶ Clean the bucket bearing seal **B** using a steam jet cleaner.
- ▶ Visually check whether the sealing lips **3** touch the sides of the bucket arm **2** and bucket bearing plate **1**.

**Replace the bucket bearing seals if:**

- The bucket bearing seal **B** is damaged
- The sealing lips **3** do not touch the bucket bearing plate **1**
- The sealing lips **3** do not touch the bucket arm **2**



**Note**

Replace the bucket bearing seals!

- ▶ Contact Liebherr customer service.


### 030.4.13.2 Checking the lift arm bucket bearing bushings

Valid for: L586-1761;

Make sure that the following requirements are fulfilled:

- The machine is secured against rolling away.

## Changing the recirculated air filter



G2002727

Fig. 208: Cleaning the recirculated air filter

- |   |                  |   |                         |
|---|------------------|---|-------------------------|
| 1 | Filter cartridge | 3 | Recirculated air filter |
| 2 | Pre-filter       | 4 | Screw                   |

- ▶ Undo the screw 4.
  - ▷ The filter cartridge 1 is unlocked.
- ▶ Move the filter cartridge 1 forward and take it out.
- ▶ Take the pre-filter 2 out of the filter cartridge 1 and dispose of it.
- ▶ Take out the recirculated air filter 3 and dispose of it.
- ▶ Put in a new recirculated air filter 3.
- ▶ Put a new pre-filter 2 into the filter cartridge 1 and fit them.
- ▶ Tighten the screw 4.
  - ▷ The filter cartridge 1 is locked.

### 030.4.14.3 Safety belt: Checking the condition and function

Valid for: L586-1761;

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.







Fig. 209: Safety belt: Checking the condition and function

- |   |       |   |               |
|---|-------|---|---------------|
| 1 | Strap | 3 | Unlock button |
| 2 | Lug   | 4 | Belt lock     |

2. Calibrations									
Test / adjustment	1000 h	2000 h	Unit	Required value	Measured	Adjusted	Adjusting point	Test point	Figure
<b>Drive group</b>									
<b>Pedals: calibration</b> ⓘ									
Manual calibration of accelerator pedal		○				■	🔧		
Manual calibration of inching function		○				■	🔧		

Tab. 69: Calibrations

3. Hydraulic adjustment procedures									
Test / adjustment	1000 h	2000 h	Unit	Required value	Measured	Adjusted	Adjusting point	Test point	Figure
<b>Cooling system</b>									
<b>Fan speed proportional solenoid valve</b> ⓘ									
Maximum operating pressure	◇	◇	bar	100 <sup>±10</sup>	■	■	🔧	PK	
Pressure relief when proportional solenoid fails	◇	◇	bar	220 <sup>±20</sup>	■	■		PK	
<b>Working hydraulics</b>									
<b>Pilot control valve block: pressure reducing valve</b> ⓘ									
Servo pressure	○	○	bar	33 <sup>±2</sup>	■	■	1	MV	
<b>Working pump: adjusting screw for Q<sub>min</sub> (standby pressure)</b> ⓘ									
High pressure at low idling speed	◇	◇	bar	34 <sup>±2</sup>	■	■	2	PA	
<b>Working pump flow regulator (differential pressure)</b> ⓘ									
Differential pressure ΔP at 1500 min <sup>-1</sup> diesel engine speed and float position	◇	◇	bar	23 <sup>±2</sup>	■	■	3	PA/LSA	
<b>Working pump: power regulator</b> ⓘ									
Start of regulation	◇	◇	bar	180 <sup>±10</sup>	■	■	4	PA/MP	

LBH/12252628/01/211-2019/12/18\_155739/en

### 030.6.3.2 Reading the diesel engine service files

Valid for: L586-1761;

Service files are data that is required for diagnosing diesel engine problems and for handling warranty claims.

The service file of the Liebherr diesel engine is saved in HTML format. The file name must not be changed.

After replacing an diesel engine component, the diesel engine service file must be sent to the following e-mail address:

[lbh.maschinenfeedback@liebherr.com](mailto:lbh.maschinenfeedback@liebherr.com)

Only the serial number of the machine must be included in the subject line of the e-mail.

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.

Make sure that the following tools are ready:

- Diagnostic cable (CAN-Fox) (item code: 11482727)
- LiDIA USB dongle (item code: 11494535)
- ▶ Connect the LiDIA diagnostics software with the diesel engine.



Fig. 219: "Diagnosis" function

- ▶ Select "Diagnosis" function.
  - ▷ The diagnostics software looks for an ECU to connect to.



Fig. 220: Engine control unit

- ▶ Select the engine control unit.
- ▶ The diagnostics software connects to the engine control unit.



Fig. 221: "Snapshot" function

- ▶ Start the diesel engine.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ In the variables editor, select the **Working hydraulics** folder.
- ▶ Select the **Calibrate angle proportional solenoids** sub-folder.
  - ▷ The variable **QREHLiftValveUp** shows the current at the proportional solenoid for lifting.
  - ▷ The variable **QREHLiftValveDn** shows the current at the proportional solenoid for lowering.
  - ▷ The variable **QREHLiftBucketValveUp** shows the current at the proportional solenoid for tilting in.
  - ▷ The variable **QREHLiftBucketValveDn** shows the current at the proportional solenoid for tilting out.
- ▶ Make sure that the parking brake is activated.
- ▶ Raise the lift arms half way.
- ▶ Tilt the bucket half way in.
- ▶ Click the variable **QREHLiftValveUp** and press the *space bar*.
  - ▷ The line is coloured pink.
  - ▷ The variable is forced. A gradual approach towards the required value is possible.




---

**Note**

To gradually approach the required value:

- ▶ Cursor *up/down*: last digit of the value +/- 1
  - ▶ Cursor *left/right*: last digit of the value +/- 5
  - ▶ Page *up/down*: last digit of the value +/- 10
- 

- ▶ Increase the value of the variable **QREHLiftValveUp** until you notice a slight movement of the lifting function.
- ▶ When the movement starts, read the variable **QREHLiftValveUp**.
- ▶ Enter the value you read in the variable **CREHLiftUpCurrMoveBegin**.
- ▶ Unforce the variable **QREHLiftValveUp**.
- ▶ Repeat the process for the lowering function with the variable **QREHLiftValveDn**. Enter the value you read in the variable **CREHLiftDnCurrMoveBegin**.
- ▶ Repeat the process for the tilt-in function with the variable **QREHBucketValveUp**. Enter the value you read in the variable **CREHBucketUpCurrMoveBegin**.
- ▶ Repeat the process for the tilt-out function with the variable **QREHBucketValveDn**. Enter the value you read in the variable **CREHBucketDnCurrMoveBegin**.

Once all the functions have been calibrated:

- ▶ Turn off the diesel engine.

**NOTICE**

There is no secondary pressure relief valve for lowering function.  
Irreparable damage to working pump.

- ▶ Do not activate lowering function as far as it will go.

- ▶ At low idling speed, activate in succession lifting, tilting out and tilting in functions, as well as optional additional functions, as far as they will go and then operate fully.
- ▶ While doing so, check whether high pressure **PA** corresponds to specified value.

Description	Unit	Value
High pressure <b>PA</b> during tilt out <b>1</b> function	bar	400 $\pm 5$
High pressure <b>PA</b> during tilt in <b>2</b> function	bar	400 $\pm 5$
High pressure <b>PA</b> during lifting <b>3</b> (main spool valve)	bar	400 $\pm 5$
High pressure <b>PA</b> during lifting <b>4</b> (additional spool valve)	bar	400 $\pm 5$
High pressure <b>PA</b> for additional function A3 (option)	bar	255 $\pm 5$
High pressure <b>PA</b> for additional function B4 (option)	bar	255 $\pm 5$

If a required value is not reached:

- ▶ Set bucket down on ground on its teeth or cutting edge.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Turn adjusting screw of corresponding secondary pressure relief valve.

**Note**

To adjust secondary pressure relief valves:

- ▶ Turn adjusting screw clockwise to increase high pressure.
- ▶ Turn adjusting screw anticlockwise to reduce high pressure.

**Note**

High pressure during lifting:

Function has two secondary pressure relief valves (main spool valve and additional spool valve). The pressure gauge always shows value of secondary pressure relief valve with lower setting.

- ▶ If there is a deviation from specified value, adjust both secondary pressure relief valves alternately until required value is reached.

- ▶ Repeat check and adjustment until required value is reached.

When all required values are reached:

- ▶ Set bucket down on ground on its teeth or cutting edge.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Turn adjusting screw on primary pressure relief valve **6** by exactly one turn anticlockwise.

- ▶ Document the damage and observe whether the condition deteriorates.

If the condition deteriorates:

- ▶ Replace hydraulic lines immediately.

If the condition does not deteriorate:

- ▶ Replace the hydraulic line within the next 250 operating hours.

### Moist surfaces, slight oil leak visible

Moist spots can be seen on the surface. Slight oil leak or small oil drops are visible. As long as you do not observe a severe oil leak, it is classified as medium damage.



Fig. 239: Moist surfaces, slight oil leak visible

- ▶ Document the damage and observe whether the condition deteriorates.

If the condition deteriorates:

- ▶ Replace hydraulic lines immediately.

If the condition does not deteriorate:

- ▶ Replace the hydraulic line within the next 250 operating hours.

### Severe damage to the hydraulic lines



#### **DANGER**

Hydraulic oil discharged under high pressure!  
Fatal injury.

- ▶ Do not operate the machine.

### Visible oil leak

Oil leaks from the hydraulic line. Leaking oil is classified as severe damage.

### 030.6.7.7 Steering pump: flow regulator (differential pressure)

Valid for: L586-1761;

Make sure the following preconditions are met:

- Hydraulic oil is at operating temperature.
- Machine is in maintenance position for adjustment procedures.
- Service mode is activated.
- Service access is open.

Make sure that following tools are ready:

- Differential pressure measuring set (60 bar)  
or two pressure gauges (40 bar)




Fig. 245: Steering pump: flow regulator (differential pressure)

**1** Flow regulator

**PL** Steering pump high pressure  
test connection

**LSL** Steering pump load sensing  
signal test connection

#### NOTICE

High pressure of steering pump above maximum pressure of pressure gauges!  
Irreparable damage to the pressure gauges.

▶ Do not operate steering.

▶ Connect a differential pressure measuring device or pressure gauge to load sensing signal test connection **LSL** on steering pump.

▶ Connect a differential pressure measuring device or pressure gauge to high pressure test connection **PL** on steering pump.

▶ Start diesel engine.

▶ Allow diesel engine to run at low idling speed.

## MSB Online Tool

The screenshot shows the MSB Online Tool interface. At the top, there are two buttons: "Request MSB" (labeled 1) and "Download MSB". Below the buttons is a table with the following data:

Machine Class	Type Series	Sales Type	Specific Type
Wheelloader	Large_size	L550	1214
Wheelloader	Large_size	CL1812	1717
Wheelloader	Large_size	L556	1332
Wheelloader	Large_size	CL1914	1748
Wheelloader	Large_size	L566	1484
Wheelloader	Large_size	L576	1333
Wheelloader	Large_size	L580	1464
Wheelloader	Large_size	L580 LogHandler	1414
Wheelloader	Large_size	L586	1815
Wheelloader	Large_size	L586	1334

Below the table is a pagination bar showing "1 - 10 of 10" and "Items per page: 10". To the right of the table is a form with the following fields:

- Machine Class: Wheelloader (labeled 2)
- Machine Type Series: Large\_size (labeled 2)
- Machine Sales Type: L550
- Machine Specific Type: 1214
- Software Index: 004
- Serial Number: (labeled 4)
- Generate MSB! (labeled 5)

Fig. 254: Creating MSB file

- |   |                        |   |                              |
|---|------------------------|---|------------------------------|
| 1 | "Request MSB" function | 4 | Machine serial number        |
| 2 | Type of machine        | 5 | "Generate MSB file" function |
| 3 | List of machine types  |   |                              |

- ▶ Select "Request MSB" function 1.
- ▶ Select type of machine 2.
  - ▷ A list displays the selectable machine types.
- ▶ Select machine type from the list of machine types 3.

**Note**

The MSB file is machine-specific.

The entered serial number must correspond to the serial number of machine.

- ▶ Enter machine serial number 4.
- ▶ Select "Generate MSB file" function 5.
  - ▷ MSB file is generated.
  - ▷ An e-mail informs the user when the generation of the MSB file is completed.

Overview of CAN addresses (valid for Master5 software item code 12467218)		
Address	CAN module	CAN line
IR02 (84)	Resistance measurement inputs, input module A16M	2
IA16 (46)	Analogue universal outputs, input module (optional)	2
IF02 (54)	Frequency measurement inputs, input module (optional)	2
IR02 (82)	Resistance measurement inputs, input module (optional)	2
OA16 (21)	Analogue universal outputs, output module A17a	2
OD04 (13)	Digital outputs, output module A17a	2
SFTY (5)	Safety function, output module A17a	2
IF02 (49)	Frequency measurement inputs, output module A17a	2
TA21 (97)	Control unit	3
CC01 (106)	Air conditioning controller	3
JD (63)	Module for joystick steering	3
JA08 (64)		3
IMMO (107)	Immobilizer	3

Tab. 78: Addressing CAN modules

- ▶ Switch on ignition.
- ▶ Start the Sculi diagnostic software and connect it to the machine.




Fig. 271: Module editor in Sculi

- |          |                                                            |          |                                        |
|----------|------------------------------------------------------------|----------|----------------------------------------|
| <b>1</b> | “Module editor ”function                                   | <b>5</b> | Set address of the module              |
| <b>2</b> | Serial number of connected modules                         | <b>6</b> | Indicates whether the module is used   |
| <b>3</b> | CAN line connecting the module to the central control unit | <b>7</b> | Indicates whether the module is active |
| <b>4</b> | Module identification                                      | <b>8</b> | Drop-down window                       |

LBH/12252628/01/211-20191218\_155739/en

g/2009921




Fig. 276:

- 1** Pressure reducing valve for quick coupler      **MS** Quick coupler closing pressure test connection
- ▶ Connect a pressure gauge (600 bar) to the quick coupler closing pressure test connection **MS** on the quick coupler valve block.
  - ▶ Start diesel engine.
  - ▶ At lower idling speed, push *quick coupler* button to position **B** and hold it there.
  - ▶ When doing so, check whether the quick coupler closing pressure **MS** corresponds to the required value.

Description	Unit	Value
Quick coupler closing pressure <b>MS</b>	bar	250 $\pm 10$

If the required value is not reached:

- ▶ Turn off the engine and take out the ignition key.
- ▶ Turn the adjusting screw of the pressure reducing valve **1**.

**Note**

To adjust the pressure reducing valve:

- ▶ Turning the adjusting screw clockwise increases the pressure.
- ▶ Turning the adjusting screw anticlockwise reduces the pressure.

- ▶ Repeat the check and adjustment until the required value is reached.

If the required value is reached:

- ▶ Turn off the engine and take out the ignition key.
- ▶ Remove the pressure gauge from the quick coupler closing pressure test connection **MS**.

### 030.6.12.2 Parameters for lift arm geometry

Valid for: L586-1761;

Make sure that following tools are ready:

- Laptop with Sculi diagnostic software




Fig. 291: Completing calibration

- 1 "Finished" function
  - 2 "Apply" function
  - 3 "OK" function
- ▶ Select "Finished" function 1.
  - ▶ Select "Apply" function 2.
  - ▶ Select "OK" function 3.



Fig. 292: Transmitting calibration to control electronics Skyview 360°

- 1 "Save" function
  - 2 "Yes" function
  - 3 "OK" function
- ▶ Select "Save" function 1.
  - ▶ Save camera data.
  - ▶ Select "Yes" function 2.
  - ▶ Select "OK" function 3.
    - ▷ Data are transmitted to control electronics for Skyview 360°.

If data were successfully transferred:

- ▶ Check for correct representation of camera image on display for Skyview 360°.
- ▶ Start Powerbroker.
  - ▷ Settings for IP address are reset.

### 030.6.14.2 Personnel detection: transmitting configuration files

Valid for: L586-1761;

If personnel detection control electronics are renewed or replaced, correct configuration files must be transferred to new control electronics.

Configuration files consist of two individual files and are machine-group specific.

Configuration files are transferred to the personnel detection control electronics using a commercially available USB stick.

Software LiPDS\_ConfigTool is used for transmitting configuration files to USB stick.

#### Preparatory tasks

Configuration files and software for transferring configuration files are available via Liebherr service documentation.

File path: General – Personnel detection

					Description
D	93	6	A7	XX	Diesel engine type designation
					20 Without emission-type approval
					23 Emission stage: tier 3 – stage IIIA With exhaust gas recirculation
					24 Emission stage: tier 4f – stage IV Exhaust treatment system: SCR system
					25 Emission stage: stage V Exhaust treatment system: SCR system and diesel particulate filter

Tab. 85: Description of the type designation

### 2.3 Cooling

Cooling is performed by a thermostatically controlled fluid cooler and a coolant pump. Each cylinder unit is supplied individually by distribution channels cast in the crankcase.

The pistons are cooled by a cooling channel from the lubricating oil circuit of the diesel engine.

### 2.4 Electronic diesel control

The electronic diesel control (EDC) regulates the engine speed and start of injection. The EDC consists primarily of sensors, the injection system and engine control unit.

Equipment on the diesel engine and vehicle side is connected to the engine control unit using wiring harnesses.

### 2.5 Power reductions

#### 2.5.1 Power reduction for excessive coolant temperature




Fig. 300: Power reduction for excessive coolant temperature

% Engine torque in per cent

°C Coolant temperature in degrees Celsius

LBH/12252628/01/211-20191218\_155739/en

g20004218

### 1.5 Crankcase bleeding line




Fig. 311: Crankcase bleeding line

- |   |                                   |    |                                            |
|---|-----------------------------------|----|--------------------------------------------|
| 1 | Turbocharger                      | 7  | Entry from crankcase gas                   |
| 2 | Crankcase gas from diesel engine  | 8  | Pressure control valve                     |
| 3 | Filtered air from filter          | 9  | Outflow from crankcase gas                 |
| 4 | Filter housing                    | 10 | Flow through filter from inside to outside |
| 5 | Line to oil pan                   | 11 | Discharge to oil pan                       |
| 6 | Bypass valve from fibre separator |    |                                            |

During combustion, an overpressure is generated in the crankcase. During combustion, a portion of the combustion gases flows from the combustion chamber over the area between the piston or piston rings and cylinder into the crankcase. If these blow-by gases are not removed, the pressure in the crankcase increases greatly depending on the speed. This has a negative impact on the lubrication and sealing system of the diesel engine. The diesel engine would leak.

Crankcase ventilation reduces this overpressure.

Due to the negative pressure from the turbocharger 1, the crankcase gas from the diesel engine 2 is extracted via the filter. The engine oil is separated in the filter element and flows over the discharge 11 and the line 5 back to the oil pan.

The line to the oil pan 5 has a check valve. This ensures that no gases can flow from the lubrication side into the crankcase ventilation.

The filter cartridge of the crankcase ventilation must be replaced regularly. See maintenance and inspection schedule.

During passive regeneration, the DOC increases the amount of NO<sub>2</sub> in the exhaust gas. As a result, soot particles are burned in the DPF starting from 260 °C.

During the active regeneration, fuel (HC) is injected into the exhaust line. This triggers an exothermal reaction in the DOC. The exhaust temperature rises up to 540 °C.

### 2.2 Layout of the exhaust gas treatment system




Fig. 321: Layout of the exhaust gas treatment system

1	Coolant from the diesel engine	10	Exhaust throttle valve M715	19	SCR catalytic converter
2	SCR system air supply valve	11	Exhaust from diesel engine	20	Slip catalyst
3	Diesel exhaust fluid tank	12	NO <sub>x</sub> sensor at DOC intake B726	21	Differential pressure sensor B722
4	Solenoid valve for coolant to diesel exhaust fluid tank Y770	13	Temperature sensor at DOC inlet B723	22	Temperature sensor at outlet of SCR catalytic converter B772
5	Solenoid valve for coolant to metering unit Y774	14	Diesel oxidation catalyst (DOC)	23	NH <sub>3</sub> sensor B783
6	Heated diesel exhaust fluid line from diesel exhaust fluid tank	15	Temperature sensor at intake of SCR catalytic converter B771	24	NO <sub>x</sub> sensor at outlet of the SCR catalytic converter B727
7	Metering unit	16	Diesel exhaust fluid nozzle	25	Engine control unit (ECU)
8	Coolant to the diesel engine	17	Mixing section		
9	Heated diesel exhaust fluid line from metering unit	18	Filter module (SCRFilter)		

The air supply valve of the SCR system 2 provides compressed air.

The metering unit 7 removes diesel exhaust fluid from diesel exhaust fluid tank 3. The metering unit 7 regulates the amount of diesel exhaust fluid and compressed air supply to be injected into the SCR system.

LBH/12252628/01/211-20191218\_155739/en

To prevent the diesel exhaust fluid crystallising in the pipes or the diesel exhaust fluid nozzle when the diesel engine is not running, these components are blown out with compressed air when the diesel engine is shut down.

### 2.3 How the exhaust gas treatment system works




Fig. 329: How the exhaust gas treatment system works

1 Exhaust from diesel engine	6 Slip catalyst
2 NO <sub>x</sub> sensor in front of the SCR catalytic converter B726	7 NO <sub>x</sub> sensor behind the SCR catalytic converter B727
3 Diesel exhaust fluid nozzle	8 Exhaust gas after treatment
4 Mixing section	9 Temperature sensor at outlet of SCR catalytic converter B772
5 SCR catalytic converter	10 NH <sub>3</sub> sensor B783

The exhaust gas is treated using selective catalytic reduction (SCR).

Diesel exhaust fluid is injected into the exhaust from the diesel engine 1. This mixture flows into the mixing section. The exhaust and the urea solution are thoroughly mixed in the mixing section.

At sufficiently high exhaust temperatures (around 170 °C), chemical reactions commence. The diesel exhaust fluid is converted to ammonia (NH<sub>3</sub>) and carbon dioxide (CO<sub>2</sub>).

The ammonia (NH<sub>3</sub>) thus created reacts in the SCR catalytic converter 5 at sufficiently high temperatures with the nitrogen oxide (NO<sub>x</sub>) in the exhaust gas. NO<sub>x</sub> and NH<sub>3</sub> are converted to N<sub>2</sub> and H<sub>2</sub>O.

The slip catalyst 7 converts excess ammonia back to nitrogen (N<sub>2</sub>) and water (H<sub>2</sub>O). This prevents unpleasant smells from excess ammonia.

The NH<sub>3</sub> sensor 11 measures the ammonia content in the exhaust gas.

## 2.1 Function




Fig. 342: Diagram of the compressed air system

- |   |                            |   |                             |
|---|----------------------------|---|-----------------------------|
| 1 | Compressor                 | 6 | Regeneration accumulator    |
| 2 | Cooling line               | 7 | SCR system air supply valve |
| 3 | Air dryer                  | 8 | Metering unit               |
| 4 | Silencer                   | 9 | Diesel exhaust fluid nozzle |
| 5 | Compressed air accumulator |   |                             |

The compressor **1** draws in air through the air filter of the diesel engine. The air is compressed and goes through the cooling line **2** to the air dryer **3**.

The cooling line **2** passes through the cooler mount. This cooled the compressed air. The compressed air continues on to the air dryer **3**.

The air dryer **3** removes moisture from the compressed air using a granulate filter. The dehumidified air carries on to the compressed air accumulator **5**.

If the pressure in the air dryer **3** rises above 10 bar, the connection to the compressed air accumulator is interrupted. At the same time, the drain valve is opened. Air from the regeneration accumulator **6** then blows the moisture out of the granulate filter. This humid air escapes through the silencer **4** to the outside. ([For more information see: Air dryer, page 040-47](#))

The SCR system air supply valve **7** allows air to come from the compressed air accumulator **5**.

The SCR system air supply valve **7** acts as a switching valve and a pressure reducing valve. The pressure is reduced to 2.2 bar. If necessary, compressed air is released to the metering unit **8**. ([For more information see: SCR system air supply valve, page 040-48](#))

The compressed air continues through the metering unit **8** to the diesel exhaust fluid nozzle **9**.

In the nozzle **9**, compressed air and diesel exhaust fluid are mixed and injected into the exhaust treatment system.

## 050.2 Cooling system hydraulics

LBH/12252628/01/211-2019/12/18\_155739/en

## 050.3 Cooling system electronics

### 050.3.1 Overview of electrical controls of cooling system

Valid for: L586-1761;

#### 1 Layout




Fig. 359: Overview of electrical controls of cooling system

- |                                |                |
|--------------------------------|----------------|
| 1 Diesel engine                | 3 Fan motor    |
| 2 Suction line of working pump | 4 Transmission |

BMK	Function	BMK	Function
A15	Central control unit	B8	Hydraulic oil temperature sensor
A16a	Input module A16a	B86	Gear oil temperature sensor
A17a	Output module A17a	B707	Temperature sensor for charge air
A25	Transmission control unit (TCU)	B708	Temperature sensor for coolant
A700	Engine control unit (ECU)	Y13	Fan speed proportional solenoid

Tab. 107: Equipment codes

#### 2 Function

##### 2.1 Basic function

Fan speed is controlled by central control unit.

LBH/12252628/01/211-2019/12/18\_155739/en

# 060 Working hydraulics

## Contents

060.1	Overview of Z-bar kinematics working hydraulics <i>L586-1761;</i>	060-2
060.2	Working pump <i>L586-1761;</i>	060-7
060.3	Control block for Z-bar kinematics <i>L586-1761;</i>	060-15
060.4	Pilot control	060-24
060.4.1	Pilot control valve block <i>L586-1761;</i>	060-24
060.5	Ride control	060-26
060.5.1	Overview of ride control system <i>L586-1761;</i>	060-26
060.5.2	Stabilisation module <i>L586-1761;</i>	060-29
060.5.3	Electric ride control unit <i>L586-1761;</i>	060-31
060.6	Electronics of the working hydraulics	060-33
060.6.1	Overview of electrical controls the working hydraulics <i>L586-1761;</i>	060-33
060.6.2	Working hydraulics angle sensors <i>L586-1761;</i>	060-35
060.7	Pipe break protection	060-38
060.7.1	Pipe break protection: overview <i>L586-1761;</i>	060-38
060.7.2	Pipe break protection valve block (lift cylinder) <i>L586-1761;</i>	060-41
060.7.3	Pipe break protection valve block (tilt cylinder) <i>L586-1761;</i>	060-43
060.7.4	Ride control release solenoid valve <i>L586-1761;</i>	060-44

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 2.2 Swivel plate angle




Fig. 372: Swivel plate angle

- |   |                                |   |                                |
|---|--------------------------------|---|--------------------------------|
| 1 | Adjusting screw for $Q_{\max}$ | 4 | Positioning piston             |
| 2 | Axial piston rotary group      | 5 | Adjusting screw for $Q_{\min}$ |
| 3 | Return piston                  | 6 | Swivel plate                   |

Positioning piston **4** moves axial piston rotary group **2** to a greater swivel plate angle. Operating pressure of working pump acts on positioning piston **4**. At a greater angle, working pump delivers more oil. Maximum angle can be set using adjusting screw for  $Q_{\max}$  **1**.

Return piston **3** moves axial piston rotary group **2** back to a smaller swivel plate angle. Return force is controlled by flow regulator. At a smaller angle, working pump delivers less oil. Minimum angle can be set using adjusting screw for  $Q_{\min}$  **5**.

Because effective surface of return piston **3** is greater than that of positioning piston **4** rotary group moves to a smaller angle when operating pressure acts on both of them.

BMK	Function	BMK	Function
Y31b	Proportional solenoid for tilting in	Y32b	Proportional solenoid for lifting

Tab. 129: Equipment codes

Control valve block **1** is supplied with fluid by working pump **66** and directs it to consumers. Spools are electro-hydraulically actuated.

Pilot control pressure reducing valve **75** supplies control valve block **1** with pilot control fluid for that purpose. When working attachment is actuated, proportional solenoid valves for individual functions are energised. Proportional solenoid valves reduce servo pressure once more, depending on current, and direct servo oil to spool valves. Servo oil pushes spools against force of readjusting springs. Oil flows from working pump **66** to consumers via openings that spools have accordingly released.

## 2.2 Pressure balance flow distribution independent of load pressure (LUDV)

Pressure balances have two functions:

- Generating a load-sensing signal **65** that is used to regulate working pump.
- Distributing flow volume between consumers.

When a function is activated, entire oil flow for consumer flows through relevant pressure balance. In process, pressure compensator generates a load-sensing signal **65** that is fed back to working pump.

This load-sensing signal affects not only working pump but also other pressure balances in control valve block. Load-sensing pressure of system **65** acts against working pressure at each pressure compensator. Therefore, load sensing pressure can partially close pressure balance against force of working pressure and restrict oil flow to consumer. Flow volume is distributed to consumers as required.

## 2.3 Spool valves for lifting cylinder: oil supply for lifting cylinder

Due to their large volume, lift cylinders require a large quantity of oil. Accordingly, lift cylinders are supplied with oil via two spool valves: main spool valve **13** and additional spool valve **46**. During lifting or lowering main spool **13** is actuated. From there control oil flows to additional spool **46**. Both spools have an own pressure balance and an own secondary pressure relief valve.

Furthermore, both spool valves have a pressure balance bypass: if lifting and tilt in functions are actuated simultaneously, lifting function is heavily restricted by LUDV system. Oil is diverted past pressure balances via check valve in pressure balance bypass in spools for lift cylinders and flows directly to hoist cylinder piston side. This makes lifting function relatively faster when multiple movements are performed simultaneously.

## 2.4 Spool valves for lift cylinders: float position

In float position function, lift cylinder ring side is connected to lift cylinder piston side and hydraulic tank **67**. As a result, lifting arms are resting under their own weight and can move freely up and down.

The lift cylinder main spool **13** has a fourth position for float position function. If control lever is pushed forwards beyond point of resistance, current applied to proportional solenoid valve for lowering **Y32a** is increased to a level at which main spool **13** is moved into this fourth position.

charge pressure (cut-out pressure) is reached, pressure in ride control hydro accumulators pushes ride control valve spool 2 against spring force of readjusting spring, thereby disconnecting lifting cylinder piston side 7 from hydro accumulators.

If maximum charge pressure is exceeded, pressure moves ride control valve spool 2 one position further. That allows oil to flow out of ride control hydro accumulators back to hydraulic tank 9.

### 2.3 Ride control activated

To activate ride control, central control unit energises ride control solenoid valve 4. That pressurises ride control valve spool 2.

Pressure pushes ride control valve spool 2 against force of return spring. The ride control valve spool 2 thus connects lift cylinder piston side 7 to ride control hydro accumulators and lift cylinder ring side 8 to hydraulic tank 9.

## 060.5.3 Electric ride control unit

Valid for: L586-1761;

### 1 Layout




Fig. 384: Electric ride control unit

- 1 Ride control key
- 2 Lift arms
- 3 Transmission
- 4 Stabilization module

BMK	Function	BMK	Function
A11	Control unit	A26	CAN module for control lever
A15	Central control unit	B60	Angle sensor for bucket position

LBH/12252628/01/211-20191218\_155739/en

sah02021

BMK	Function	BMK	Function	BMK	Function
Y14	Solenoid for servo pressure	Y31b	Proportional solenoid for tilting in	Y200	Solenoid for release of ride control (option)

Tab. 145: Equipment codes

If a pipe breaks, pipe break protection system prevents lift arms from falling and bucket from tipping in an uncontrolled manner. To do this, pipe break protection system separates piston side from control valve block.

## 2.2 Pipe break protection for ride control

Because pipe break protection system cuts off lift cylinder piston side when working hydraulics are actuated, pipe break protection must be opened to operate ride control. Solenoid for release of ride control **Y200** together with solenoid for ride control are energized for this purpose **Y20**. The ride control release solenoid valve **60** then opens pilot control valves **76** and **86** with pressure from pilot control valve block 1.

### 2.2.1 Variable for pipe break protection

If a pipe break protection is installed, variable **CXEHLFDGeoCondition** must be set to **0**. As a result, operating mode "Ride control activated with working attachment tilted in" is deactivated (for more information see: operator's manual).

This is necessary because with active ride control, pipe break protection is unlocked. With operating mode "Ride control activated with working attachment tilted in", ride control can also be activated with stationary machine when a person is present under lift arms.

## 060.7.2 Pipe break protection valve block (lift cylinder)

Valid for: L586-1761;

### 1 Layout




Fig. 391: Pipe break protection valve block (lift cylinder)

- |                                                |                                    |
|------------------------------------------------|------------------------------------|
| 1 Safety valve and pipe break protection valve | 5 Return flow to leak oil strainer |
|------------------------------------------------|------------------------------------|

See next page for continuation of the image legend

<b>BMK</b>	<b>Function</b>	<b>BMK</b>	<b>Function</b>	<b>BMK</b>	<b>Function</b>
<b>B3</b>	Emergency steering pressure switch	<b>B91</b>	Pressure sensor for weighing device (ring side)	<b>Y10</b>	Parking brake solenoid
<b>B3a</b>	Emergency steering check pressure switch	<b>M8</b>	Electric motor for emergency steering pump	<b>Y13</b>	Fan speed proportional solenoid
<b>B8</b>	Hydraulic oil temperature sensor	<b>R1</b>	Inching function angle sensor	<b>Y14</b>	Solenoid for servo pressure
<b>B12</b>	Brake light pressure switch	<b>Y1</b>	Proportional solenoid for clutch 2 (K2)	<b>Y20</b>	Solenoid for ride control
<b>B19</b>	Brake accumulator pressure sensor	<b>Y2</b>	Proportional solenoid for forward travel direction clutch (KV)	<b>Y31a</b>	Proportional solenoid for tilting out
<b>B80</b>	Pressure sensor for duct AB	<b>Y3</b>	Proportional solenoid for optional connection	<b>Y31b</b>	Proportional solenoid for tilting in
<b>B81</b>	Pressure sensor for duct A	<b>Y4</b>	Proportional solenoid for reverse travel direction clutch (KR)	<b>Y32a</b>	Proportional solenoid for lowering
<b>B85</b>	Filter bypass switch	<b>Y5</b>	Proportional solenoid for clutch 1 (K1)	<b>Y32b</b>	Proportional solenoid for lifting
<b>B86</b>	Gear oil temperature sensor	<b>Y6</b>	Proportional solenoid for clutch 3 (K3)	<b>Y33a</b>	Proportional solenoid for additional function A4
<b>B90</b>	Pressure sensor for weighing device (piston side)	<b>Y7</b>	Proportional solenoid for position control	<b>Y33b</b>	Proportional solenoid for additional function B4

Tab. 151: Equipment codes

# 090 Steering system

## Contents

090.1	Steering system overview <i>L586-1761;</i>	090-3
090.2	Steering pump <i>L586-1761;</i>	090-7
090.3	Servostat <i>L586-1761;</i>	090-13
090.4	Steering cylinder	090-16
090.4.1	Steering cylinder <i>L586-1761;</i>	090-16
090.4.2	Steering stabilisation valve block <i>L586-1761;</i>	090-17
090.4.3	Valve block for steering stabilisation (without steering wheel steering) <i>L586-1761;</i>	090-18
090.5	Emergency steering	090-21
090.5.1	Emergency steering overview <i>L586-1761;</i>	090-21
090.5.2	Emergency steering pump <i>L586-1761;</i>	090-23
090.5.3	Emergency steering electronics	090-24
090.5.3.1	Overview of electrical controls of emergency steering system <i>L586-1761;</i>	090-25
090.5.3.2	Emergency steering pressure switch <i>L586-1761;</i>	090-30
090.5.3.3	Emergency steering check pressure switch <i>L586-1761;</i>	090-31
090.6	Joystick steering	090-33
090.6.1	Joystick steering: overview (combined with steering wheel steering) <i>L586-1761;</i>	090-33
090.6.2	Joystick steering: overview (without steering wheel steering) <i>L586-1761;</i>	090-37
090.6.3	Joystick steering control valve block <i>L586-1761;</i>	090-40

### 2.2 Swivel plate angle




Fig. 415: Swivel plate angle

- |                                    |                             |
|------------------------------------|-----------------------------|
| <b>1</b> Swivel plate              | <b>3</b> Positioning piston |
| <b>2</b> Axial piston rotary group | <b>4</b> Return piston      |

Positioning piston **3** moves axial piston rotary group **2** to a greater swivel plate angle. Operating pressure of steering pump acts on positioning piston **3**. At a greater angle, steering pump delivers more oil.

Return piston **4** moves axial piston rotary group **2** back to a smaller swivel plate angle. Return force is controlled by flow regulator. At a smaller angle, steering pump delivers less oil.

Because effective surface of return piston **4** is greater than that of positioning piston **3** rotary group moves to a smaller angle when operating pressure acts on both of them.

### 2.3 Flow regulator




Fig. 416: Consumers not requesting oil / consumers requesting oil

- |                                             |                                                |                                           |
|---------------------------------------------|------------------------------------------------|-------------------------------------------|
| <b>1</b> Flow regulator                     | <b>4</b> LS-pressure cut-off                   | <b>7</b> Connection to operating pressure |
| <b>2</b> Regulating spring                  | <b>5</b> Connection to pump housing (leak oil) |                                           |
| <b>3</b> Load sensing signal from servostat | <b>6</b> Connection to return piston           |                                           |

LBH/12252628/01/211-20191218\_155739/en

## 090.5 Emergency steering

### 090.5.1 Emergency steering overview

Valid for: L586-1761;

#### 1 Layout

Emergency steering system consists of following components:

- Hydraulic tank (For more information see: 080.2.1 Overview of hydraulic tank, page 080-6)
- Emergency steering pump (For more information see: 090.5.2 Emergency steering pump, page 090-23)
- Valve block for steering system
- Electrical controls

#### 2 Function




Fig. 430: Emergency steering: hydraulic diagram (emergency steering active)

- |   |                                       |   |                                 |
|---|---------------------------------------|---|---------------------------------|
| 1 | Hydraulic tank                        | 7 | Gear pump                       |
| 2 | Return flow from hydraulic oil cooler | 8 | Pressure relief valve           |
| 3 | Steering pump                         | 9 | Valve block for steering system |

See next page for continuation of the image legend

### 090.5.3.3 Emergency steering check pressure switch

Valid for: L586-1761;

#### 1 Layout




Fig. 438: Emergency steering check pressure switch: sectional view

1	Throttle	5	Electronics
2	Pressure chamber	6	3-pin plug connection
3	Metal surface	7	Service brake hydro accumulator
4	Thin-film sensor		

The emergency steering check pressure switch B3a is mounted on the emergency steering pump.

The emergency steering check pressure switch is normally open.

#### 2 Function

##### 2.1 Basic function

The oil flows via the throttle 1 to the pressure chamber 2. Pressure peaks are absorbed by the throttle 1.

The curvature of the metal surface 3 causes the resistance of the thin-film sensor 4 to change. When a specific resistance is reached, the electronics 5 close the electrical contact.

##### 2.2 Monitoring emergency steering pump pressure




Fig. 439: Pressure switch for emergency steering check: equivalent diagram and symbol field Emergency steering CHECK failed

The emergency steering check pressure switch B3a monitors the emergency steering pump pressure.

After starting diesel engine, the emergency steering system tests itself. The emergency steering pump is activated for a few seconds and the *emergency steering CHECK failed* symbol field lights up in the display. If the emergency steering pump generates enough pressure, the electronics in the emergency steering check pressure switch close the contact and the central control unit registers that the emer-

1 Layout




Fig. 442: Control valve block for joystick steering (from front left)

- |   |                                      |    |                                                           |    |                                                       |
|---|--------------------------------------|----|-----------------------------------------------------------|----|-------------------------------------------------------|
| 1 | Return flow to collector pipe        | 6  | Return flow from compact brake valve (housing preheating) | 11 | Pressure reducing valve for emergency spool valve     |
| 2 | Throttle check valve                 | 7  | Connection for steering to left                           | 12 | Control block section for emergency steering function |
| 3 | Throttle check valve                 | 8  | Return flow to collector pipe                             | 13 | Check valve                                           |
| 4 | Oil supply from steering pump        | 9  | Cut-off valve for main spool valve                        | 14 | Pressure reducing valve for main spool valve          |
| 5 | Connection for steering to the right | 10 | Joystick steering control valve block                     |    |                                                       |

Name	Test point	Name	Test point
M B1	Servo pressure for steering to the right (main spool valve) <sup>A)</sup>	M B2	Servo pressure for steering to the right (emergency spool valve) <sup>A)</sup>
M A2	Servo pressure for steering to the left (emergency spool valve) <sup>A)</sup>		

Tab. 172: Test points

LBH/12252628/01/211-2019/12/18\_155739/en

sle0184-3a

BMK	Function	BMK	Function	BMK	Function
<b>A29</b>	Joystick module	<b>S72</b>	Joystick steering switch (armrest)	<b>Y74</b>	Solenoid valve for safety circuit
<b>A29a</b>	Joystick electronics	<b>Y70</b>	Proportional solenoid for steering to left (main spool valve)		
<b>B70</b>	Main spool valve position sensor	<b>Y71</b>	Proportional solenoid for steering to left (spool valve for emergency steering function)		

Tab. 180: Equipment codes

In emergency mode, joystick steering is directly controlled via joystick module **A29**.

Safety circuit solenoid valve **Y74** is not energised. Control takes place using emergency spool valve **7**. Oil flow through main spool valve **5** is cut off.

Proportional control solenoid for steering to right (emergency spool valve) **Y72** and proportional control solenoid for steering to left (emergency spool valve) **Y73** are directly energised by joystick module **A29**.

Emergency spool valve position sensor **B71** monitors position of emergency spool valve **7**. This signal is received by joystick module **A29**.

### 2.3 Failure of position control

Central control unit monitors position control of joystick. In event of a fault, central control unit switches off power supply for position control. As a result, joystick no longer adjusts its position to articulation angle. However, steering function itself is still fully available.

### 2.4 Function of joystick steering relay board A4b




Fig. 448: Function of joystick steering relay board A4b

- 8 Leak oil from steering pump and working pump
- 16 Hydro accumulator for service brake (1st brake circuit)
- 24 Front axle with service brake for 1st brake circuit

Name	Test point	Name	Test point	Name	Test point
M3	Service brake accumulator pressure	M4	Brake pressure in 1st brake circuit (front axle)	M5	Brake pressure in 2nd brake circuit (rear axle)

Tab. 186: Test points

BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	B19	Brake accumulator pressure sensor
B12	Brake light pressure switch	R1	Inching function angle sensor

Tab. 187: Equipment codes




Fig. 454: Brake system (parking brake activated) (from rear right)

- 1 Hydraulic tank
- 2 Return filter
- 3 Breather filter
- 4 Return flow from control valve block
- 5 Return flow from hydraulic oil cooler
- 7 Hydraulic tank drain valve
- 13 Fan motor oil supply
- 14 Brake pump
- 15 Hydro accumulator for service brake (2nd brake circuit)
- 16 Hydro accumulator for service brake (1st brake circuit)
- 17 Hydro accumulator for service brake (2nd brake circuit)
- 18 Hydro accumulator for service brake (1st brake circuit)
- 22 Compact brake valve
- 23 Parking brake
- 24 Front axle with service brake for 1st brake circuit
- 25 Emergency steering pump suction port
- 26 Steering pump suction port
- 27 Return flow from pilot control

See next page for continuation of the image legend

LBH/12252628/01/211-20191218\_155739/en

sbr02001b

### 2.3.1 Hydro accumulators are fully charged

When hydro accumulators are charged up to cut-out pressure, system pressure pushes piston **3** and pilot valve **10** against regulating spring **1**.

Pilot valve **10** separates accumulator charge valve **8** from system pressure and connects it to return line to leak oil strainer **11**. This means oil from brake pump **12** pushes accumulator charge valve **8** against compression spring **9**. The oil from brake pump **12** flows to collector pipe **13**.

### 2.3.2 Hydro accumulators are being charged

Via piston **3**, brake system pressure acts on pilot valve **10**. If system pressure drops to cut-in pressure, regulating spring **1** pushes pilot valve **10** against system pressure.

Pilot valve **10** connects accumulator charge valve **8** to system pressure. This results in accumulator charge valve **8** being closed by system pressure and compression spring **9**.

Oil from brake pump **12** flows via inverted shuttle valve **4** and parking brake check valve **7** to hydro accumulator.

### 2.4 Inching function

Inching function angle sensor R1 is connected to inching brake pedal. In first two thirds of pedal movement, only inching function is operated.

Inching function angle sensor R1 is a two-channel sensor. It issues two mixed current signals between 6 mA and 18 mA.

When inching, central control unit reduces target speed and tractive force. Machine is slowed down by engine braking effect.

2.2 Grounding points




Fig. 470: Grounding points

Position	BMK	Installation location
1	XMSP6, XMSP6a, XMSP6b, XMSP6i, XMSP6Ja, XMSP6.1, XMSP6.2	In left of operator's cab on rear wall.
2	XMSP7a, XMSP7b	In front left of operator's cab under roof liner.
3	XMSP1, XMSP1a, XMSP1b	On front left of rear section.
4	XMSP4a, XMSP4b, XMSP4c, XMSP4.2	On rear left of rear section.
5	MP_4.3, MP_5	On rear right of rear section.

Tab. 198: Grounding points

LBH/12252628/01/211-2019/12/18\_155739/en

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-A17.a.X1	H	+H3	CONNECTOR OUTPUT MODULE 1	=K	+K4	CONNECTOR KEYPAD 2	/128.C8
-A17b	H	+H3	OUTPUT MODULE A17b	=K	+K4	KEYPAD 3	/131.C4
-A17b.X1	H	+H3	CONNECTOR ADDITIONAL CONTROLLER OUTPUT MODULE 1	=K	+K	KEYPAD 3	/143.E8
-A17c	H	+H3	OUTPUT MODULE: A17c	=K	+K	CONNECTOR KEYPAD 3	/141.D5
-A17c.X1	H	+H3	CONNECTOR COMPACT MODULE 1	=K	+K4	CONNECTOR KEYPAD 3	/128.B8
-A21	K	+K4	HEATING AND AIR CONDITIONING SYSTEM	=K	+K2	IMMOBILISER	/133.C5
-A21.X1	K	+K4	CONNECTOR HEATING AND AIR CONDITIONING SYSTEM	=K	+K2	IMMOBILISER	/144.C5
-A25	F	+F3	TRANSMISSION	=K	+K2	CONNECTOR IMMOBILISER	/144.E4
-A25.X1	F	+F3	CONNECTOR TRANSMISSION	=K	+K2	CONNECTOR IMMOBILISER	/133.E4
-A26	K	+K4	CONTROL LEVER CAN MODULE	=K	+K	CONNECTOR DISPLAY TYRE PRESSURE SENSOR	/123.E6
-A26*	K	+K4	LogHandler CONTROL LEVER CAN MODULE	=K	+K	CONNECTOR DISPLAY TYRE PRESSURE SENSOR	/123.E6
-A26*.X	K	+K4	CONNECTOR LogHandler CONTROL LEVER CAN MODULE	=K	+K	CONNECTOR DISPLAY TYRE PRESSURE SENSOR	/123.E7
-A26.X	K	+K4	CONNECTOR CONTROL LEVER CAN MODULE	=K	+K	RECEIVING UNIT / CONTROL UNIT	/113.D5
-A29	K	+K6	CENTRAL CONTROL UNIT JOYSTICK STEERING	=K	+K	CONNECTOR RECEIVING UNIT / CONTROL UNIT	/113.E5
-A29.X1	K	+K6	CONNECTOR CENTRAL CONTROL UNIT JOYSTICK STEERING	=M	+M	ENGINE CONTROL UNIT	/73.A1
-A29.X3	K	+K6	CONNECTOR CENTRAL CONTROL UNIT JOYSTICK STEERING	=M	+M	CONNECTOR ENGINE CONTROL UNIT	/49.E2
-A29a	K	+K	JOYSTICK STEERING	=M	+M	CONNECTOR ENGINE CONTROL UNIT	/53.A8
-A30	K	+K2	LIDAT MODULE	=M	+M	SOLENOID VALVE: AIR SUPPLY, SCR SYSTEM	/51.D7
-A30.X	K	+K	CONNECTOR LIDAT MODULE	=M	+M	CONNECTOR SOLENOID VALVE: AIR SUPPLY, SCR SYSTEM	/51.D7
-A30.X1	K	+K2	CONNECTOR LIDAT MODULE	=H	+H	DIESEL EXHAUST FLUID PUMP	/53.D1
-A30a.X	K	+K2	CONNECTOR CLAAS DIAGNOSIS	=H	+H	CONNECTOR DIESEL EXHAUST FLUID PUMP	/53.D1
-A35	K	+K2	ADDITIONAL CONTROLLER	=H	+H	AIR CHANGEOVER VALVE	/53.D3
-A35.X	K	+K2	CONNECTOR ADDITIONAL CONTROLLER	=H	+H	CONNECTOR AIR CHANGEOVER VALVE	/53.D3
-A36	K	+K4	KEYPAD 1	=H	+H	AIR PRESSURE SENSOR	/53.D5
-A36.L	K	+K	KEYPAD 1 LogHandler	=H	+H	CONNECTOR AIR PRESSURE SENSOR	/53.D5
-A36.L.X	K	+K	CONNECTOR KEYPAD 1 LogHandler	=H	+H	DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE SENSOR	/53.D7
-A36.M	K	+K	KEYPAD 1	=H	+H	CONNECTOR DIESEL EXHAUST FLUID PRESSURE AND TEMPERATURE SENSOR	/53.D7
-A36.M.X	K	+K	CONNECTOR KEYPAD 1	=H	+H5	EMERGENCY STEERING PRESSURE SWITCH	/25.B6
-A36.X	K	+K4	CONNECTOR KEYPAD 1	=H	+H5	CONNECTOR EMERGENCY STEERING PRESSURE SWITCH	/25.C6
-A37	K	+K4	KEYPAD 2	=H	+H4	EMERGENCY STEERING CHECK PRESSURE SWITCH	/25.B8
-A37.L	K	+K	KEYPAD 2 LogHandler	=H	+H4	CONNECTOR EMERGENCY STEERING CHECK PRESSURE SWITCH	/25.C8
-A37.L.X	K	+K	CONNECTOR KEYPAD 2 LogHandler	=H	+H	AIR FILTER CONTAMINATION	/56.C6
-A37.M	K	+K	KEYPAD 2	=H	+H	CONNECTOR AIR FILTER CONTAMINATION	/56.C6
-A37.M.X	K	+K	CONNECTOR KEYPAD 2	=H	+H1	HYDRAULIC OIL TEMPERATURE SENSOR	/47.C5
-A37.S4.OUT	K	+K2	CONNECTOR	=H	+H1	CONNECTOR HYDRAULIC OIL TEMPERATURE SENSOR	/47.C5
-A37.S4.OUT	K	+K2	CONNECTOR	=H	+H	HORN	/33.C3

BMK	SYSTEM	LOCATION	FUNCTION	PAGE
-A17.a.X1	H	+H3	CONNECTOR OUTPUT MODULE 1	/46.D3
-A17b	H	+H3	OUTPUT MODULE A17b	/89.B1
-A17b.X1	H	+H3	CONNECTOR ADDITIONAL CONTROLLER OUTPUT MODULE 1	/42.B7
-A17c	H	+H3	OUTPUT MODULE: A17c	/117.B1
-A17c.X1	H	+H3	CONNECTOR COMPACT MODULE 1	/118.C3
-A21	K	+K4	HEATING AND AIR CONDITIONING SYSTEM	/69.A3
-A21.X1	K	+K4	CONNECTOR HEATING AND AIR CONDITIONING SYSTEM	/58.B5
-A25	F	+F3	TRANSMISSION	/72.F1
-A25.X1	F	+F3	CONNECTOR TRANSMISSION	/43.C4
-A26	K	+K4	CONTROL LEVER CAN MODULE	/70.B3
-A26*	K	+K4	LogHandler CONTROL LEVER CAN MODULE	/147.D3
-A26*.X	K	+K4	CONNECTOR LogHandler CONTROL LEVER CAN MODULE	/147.D3
-A26.X	K	+K4	CONNECTOR CONTROL LEVER CAN MODULE	/41.E8
-A29	K	+K6	CENTRAL CONTROL UNIT JOYSTICK STEERING	/99.B1
-A29.X1	K	+K6	CONNECTOR CENTRAL CONTROL UNIT JOYSTICK STEERING	/94.E7
-A29.X3	K	+K6	CONNECTOR CENTRAL CONTROL UNIT JOYSTICK STEERING	/94.E8
-A29a	K	+K	JOYSTICK STEERING	/99.G15
-A30	K	+K2	LIDAT MODULE	/71.B1
-A30.X	K	+K	CONNECTOR LIDAT MODULE	/62.D3
-A30.X1	K	+K2	CONNECTOR LIDAT MODULE	/62.E1
-A30a.X	K	+K2	CONNECTOR CLAAS DIAGNOSIS	/123.D4
-A35	K	+K2	ADDITIONAL CONTROLLER	/132.B1
-A35.X	K	+K2	CONNECTOR ADDITIONAL CONTROLLER	/124.E8
-A36	K	+K4	KEYPAD 1	/129.C4
-A36.L	K	+K	KEYPAD 1 LogHandler	/152.C1
-A36.L.X	K	+K	CONNECTOR KEYPAD 1 LogHandler	/151.B7
-A36.M	K	+K	KEYPAD 1	/143.A2
-A36.M.X	K	+K	CONNECTOR KEYPAD 1	/141.D1
-A36.X	K	+K4	CONNECTOR KEYPAD 1	/128.E8
-A37	K	+K4	KEYPAD 2	/130.C4
-A37.L	K	+K	KEYPAD 2 LogHandler	/152.C5
-A37.L.X	K	+K	CONNECTOR KEYPAD 2 LogHandler	/151.D8
-A37.M	K	+K	KEYPAD 2	/143.E2
-A37.M.X	K	+K	CONNECTOR KEYPAD 2	/141.D3
-A37.S4.OUT	K	+K2	CONNECTOR	/33.B6
-A37.S4.OUT	K	+K2	CONNECTOR	/33.B6

12466553  
ITEM CODE  
DRAWING INDEX  
000

GG 4 EVO  
1333 90100 02 00  
DRAWING NUMBER

PROJECT  
ISO 19016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	SERIAL NUMBER	BMK-INDEX	PAGE	OF
<b>LIDOS Gerät</b>	<b>XXXXX</b>	<b>ELECTRICAL SCHEMATIC;</b>	<b>7</b>	<b>OF</b>
			CREATION DATE	08.10.2019 15:49

12466553  
ITEM CODE  
DRAWING INDEX  
000

GG<sub>4</sub>EVO  
1333 90100 02 00  
DRAWING NUMBER

PROJECT  
ISO 16016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

BMK	SYSTEM	LOCATION	FUNCTION	PAGE
-Splice.CAN5	=K*	+K	SPICE	/141.D6
-Splice.CAN5	=K	+K	SPICE	/133.E4
-Splice.CAN5	=K	+K.	SPICE	/144.D4
-Splice.CLAAS	=K	+K	SPICE	/123.D1
-Splice.CLAAS	=K	+K	SPICE	/123.D2
-Splice.CLAAS	=K	+K	SPICE	/123.D2
-Splice.CLAAS	=K	+K	SPICE	/123.D2
-Splice.E14.1	=H	+H	SPICE	/29.D8
-Splice.E14.2	=H	+H	SPICE	/29.E8
-Splice.E18.X	=V	+V	SPICE	/112.C8
-Splice.F5	=K	+K	SPICE	/124.C4
-Splice.F12	=K	+K	SPICE	/126.B5
-Splice.F15.H	=B	+B	SPICE	/24.D5
-Splice.F36	=K	+K	SPICE	/40.D2
-Splice.F36	=K	+K	SPICE	/135.D3
-Splice.F57	=K	+K	SPICE	/63.C2
-Splice.F66	=K	+K	SPICE	/52.C6
-Splice.K7	=K	+K	SPICE	/33.C1
-Splice.K12	=K	+K	SPICE	/84.D7
-Splice.K15.H	=B	+B	SPICE	/24.D3
-Splice.K17	=K	+K	SPICE	/52.E6
-Splice.M4	=K	+K	SPICE	/33.B8
-Splice.M7	=K	+K	SPICE	/108.E6
-Splice.R615	=H	+H	SPICE	/121.B1
-Splice.R616	=H	+H	SPICE	/121.B2
-Splice.V15	=K	+K2	SPICE	/24.B7
-Splice.V200	=K	+K	SPICE	/114.F2
-Splice.Vcc_V	=K	+K	SPICE	/154.B8
-Splice.X1	=K.	+K.	SPICE	/39.F4
-Splice.X1	=K	+K	SPICE	/24.B2
-Splice.X1	=V	+V2	SPICE	/41.B5
-Splice.X1.M	=K	+K	SPICE	/140.F4
-Splice.X1LB	=K	+K	SPICE	/157.C4
-Splice.X2	=K.	+K.	SPICE	/39.F6
-Splice.X2	=H	+H	SPICE	/45.C3
-Splice.X2.M	=K	+K	SPICE	/140.F6

BMK	SYSTEM	LOCATION	FUNCTION	PAGE
-Splice.X2LB	=V	+V	SPICE	/157.C5
-Splice.X3	=H	+H	SPICE	/29.F3
-Splice.X3	=K	+K	SPICE	/39.D5
-Splice.X3.M	=K	+K	SPICE	/140.D5
-Splice.X3LB	=V	+V	SPICE	/157.D5
-Splice.X4	=H	+H	SPICE	/29.C7
-Splice.X4LB	=V	+V	SPICE	/157.C7
-Splice.X5	=H	+H	SPICE	/46.C2
-Splice.X5	=K	+K	SPICE	/147.C2
-Splice.X5LB	=V	+V	SPICE	/157.D7
-Splice.X6	=H	+H	SPICE	/51.C1
-Splice.X6	=K	+K	SPICE	/147.E2
-Splice.X7	=H	+H	SPICE	/51.B7
-Splice.X9	=H	+H	SPICE	/56.C1
-Splice.X9	=K	+K	SPICE	/33.A7
-Splice.X11	=H	+H	SPICE	/46.C6
-Splice.X12	=K	+K3	SPICE	/85.D8
-Splice.X15	=K	+K	SPICE	/36.C3
-Splice.X17	=K	+K	SPICE	/59.C3
-Splice.X18	=K	+K	SPICE	/59.C7
-Splice.X19	=K	+K	SPICE	/59.A3
-Splice.X20	=K	+K	SPICE	/59.A6
-Splice.X21	=K	+K	SPICE	/81.A7
-Splice.X22	=K	+K	SPICE	/59.A7
-Splice.X23	=K	+K	SPICE	/59.A5
-Splice.X24	=K	+K	SPICE	/59.C5
-Splice.X25	=K	+K	SPICE	/59.C5
-Splice.X26	=K	+K	SPICE	/59.A8
-Splice.X27	=K	+K	SPICE	/59.A5
-Splice.X47.2	=K	+K	SPICE	/82.C6
-Splice.X47.5	=K	+K	SPICE	/82.C4
-SPICE.X60.1	=K	+K	SPICE	/61.C5
-SPICE.X60.2	=K	+K	SPICE	/61.C5
-Splice.X60e	=K	+K	SPICE	/124.C7
-Splice.X60e	=K	+K	SPICE	/124.C6
-Splice.X74	=K	+K	SPICE	/94.B6

MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**



BMK-INDEX  
ELECTRICAL SCHEMATIC;

12466553

ITEM CODE

000

DRAWING INDEX

GG\_4\_EVO

1333 90100 02 00

PROJECT

DRAWING NUMBER

ISO 18018: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX

INTERIOR ILLUMINATION, SEAT COMPRESSOR, DOOR CONTACT SWITCH  
ELECTRICAL SCHEMATIC;


**LIEBHERR**  
FACTORY LBH

PAGE 27

OF

CREATION DATE

08.10.2019 15:49



8

7

6

5

4

3

2

1

A

B

C

D

E

F

12466553  
ITEM CODE  
DRAWING INDEX  
000

GG\_4\_EVO  
PROJECT  
DRAWING NUMBER  
1333 90100 02 00

ISO 18018: The reproduction is prohibited, distribution and utilization of this document as its contents to others without registration.  
express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design.

MACHINE TYPE  
**LIDOS Gerät**


SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

REVERSING CAMERA; FRONT CAMERA  
ELECTRICAL SCHEMATIC;

PAGE 37 OF

CREATION DATE 09.10.2019 15:49




1 2 3 4 5 6 7 8  
A B C D E F

12466553  
ITEM CODE  
DRAWING INDEX  
000

GG\_4\_EVO  
1333 90100 02 00  
DRAWING NUMBER

PROJECT

ISO 18016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without registration.



MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

HYDRAULIC OIL TEMPERATURE SENSOR  
ELECTRICAL SCHEMATIC;

PAGE 47 OF  
CREATION DATE 09.10.2019 15:49





-A17a		Modul Nr.:		Modulname:					
ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN
A17a.24V_B1	/46.E1		POWER SUPPLY BANK 1	0	A17a.24V				0
A17a.24V_Logic	/45.F7		POWER SUPPLY	0	A17a.24V	/38.D4		CAN LOW	41
A17a.GND	/46.E1		GROUND	0	A17a.CAN_Low	/38.C4		CAN LOW	42
A17a.PWM1	/43.A2		PARKING BRAKE SOLENOID VALVE	0	A17a.CAN_Low				43
A17a.PWM2	/42.A2		TILT-OUT PROPORTIONAL SOLENOID VALVE	0	A17a.GND_D02				44
A17a.PWM3	/42.A2		TILT-IN PROPORTIONAL SOLENOID VALVE	0	A17a.GND_PWM1	/43.F2		PARKING BRAKE SOLENOID VALVE	45
A17a.PWM4	/42.A4		LIFTING PROPORTIONAL SOLENOID VALVE	0	A17a.GND_PWM2	/42.F1		TILT-OUT PROPORTIONAL SOLENOID VALVE	46
A17a.PWM9	/41.A1		WORKING HYDRAULICS PILOT PRESSURE SOLENOID VALVE	0	A17a.GND_PWM3	/42.F2		TILT-IN PROPORTIONAL SOLENOID VALVE	47
A17a.PWM10	/42.A4		LOWERING PROPORTIONAL SOLENOID VALVE	0	A17a.GND_PWM4	/42.F4		LIFTING PROPORTIONAL SOLENOID VALVE	48
A17a.PWM11	/42.A5		3RD FUNCTION A PROPORTIONAL SOLENOID VALVE	0	A17a.GND_PWM9	/41.F1		WORKING HYDRAULICS PILOT PRESSURE SOLENOID VALVE	49
A17a.PWM12	/42.A6		3RD FUNCTION B PROPORTIONAL SOLENOID VALVE	0	A17a.GND_PWM10	/42.F3		LOWERING PROPORTIONAL SOLENOID VALVE	50
A17a.GND	/46.E5		GROUND	0	A17a.GND_PWM11	/42.F5		LOWERING PROPORTIONAL SOLENOID VALVE	51
A17a.24V_Logic	/46.E5		POWER SUPPLY BANK 3	0	A17a.GND_PWM12	/42.F6		3RD FUNCTION A PROPORTIONAL SOLENOID VALVE	52
A17a.24V_B3	/46.D3		POWER SUPPLY BANK 2	0	A17a.GND_D04			3RD FUNCTION B PROPORTIONAL SOLENOID VALVE	53
A17a.24V_B2	/46.D3		GROUND	0	A17a.FH	/26.A2		ROAD TRAVEL SWITCH	54
A17a.GND_Logic	/45.F7		GROUND	0	A17a.FI2	/24.E3		BATTERY MAIN SWITCH	55
A17a.GND	/46.D3		GROUND	0	A17a.CAN_High	/38.D5		CAN HIGH	56
A17a.PWM5	/47.A6		FANS SPEED PROPORTIONAL SOLENOID VALVE	0	A17a.CAN_High	/38.C5		CAN HIGH	57
A17a.PWM6	/48.A3		WARNING BUZZER	0	A17a.GND				58
A17a.PWM7	/41.A2		RIDE CONTROL SOLENOID VALVE	0	A17a.GND_PWM5				59
A17a.PWM8	/25.A5		EMERGENCY STEERING PUMP MOTOR	0	A17a.GND_PWM6	/47.F6		FANS SPEED PROPORTIONAL SOLENOID VALVE	60
A17a.PWM13	/47.A7		SOLENOID VALVE FAN DRIVE, REVERSIBLE	0	A17a.GND_PWM7	/48.F3		WARNING BUZZER	61
A17a.PWM14	/46.D6		GROUND	0	A17a.GND_PWM8	/41.F2		RIDE CONTROL SOLENOID VALVE	62
A17a.PWM15	/46.D6		POWER SUPPLY BANK 4	0	A17a.GND_PWM13				63
A17a.PWM16	/46.D6		POWER SUPPLY DIGITAL OUTPUT 1	0	A17a.GND_PWM14	/25.F1		EMERGENCY STEERING PUMP MOTOR	64
A17a.GND	/46.C5		GROUND	0	A17a.GND_PWM15	/47.F7		SOLENOID VALVE FAN DRIVE, REVERSIBLE	65
A17a.24V_Logic	/64.D1		REVERSING HEADLIGHT	0	A17a.GND_PWM16				66
A17a.24V_B4	/64.D1		POWER SUPPLY DIGITAL OUTPUT 2	0	A17a.GND_PWM16				67
A17a.CAN_Res	/64.D1		POWER SUPPLY BANK 3	0	A17a.GND				68
A17a.24V	/64.D1		POWER SUPPLY DIGITAL OUTPUT 3	0	A17a.GND_FH				69
A17a.GND_D01	/46.C1		CENTRAL LUBRICATION SYSTEM MOTOR	0	A17a.GND_FI2				70
A17a.V_D01	/64.F4		POWER SUPPLY DIGITAL OUTPUT 4	0					
A17a.V_D02	/64.F4		POWER SUPPLY BANK 1	0					
A17a.V_D03	/64.F4		CENTRAL LUBRICATION SYSTEM MOTOR	0					
A17a.V_D04	/64.F4		POWER SUPPLY DIGITAL OUTPUT 1	0					
A17a.GND_D03	/64.F4		CENTRAL LUBRICATION SYSTEM MOTOR	0					




12466553  
ITEM CODE  
000  
DRAWING INDEX

GG\_4\_EVO  
1333 9010 02 00  
DRAWING NUMBER

PROJECT

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

<b>A4a</b>	LBH ID 93030665 ZNG 1464 67391 01 00 003	SICHERUNGSTESTER FUSE - TEST
F1-5A	INPUT&OUTPUT MODUL 1	OUTPUT MODUL 1 DO1
F2-5A	INPUT MODUL 1	OUTPUT MODUL 1 DO2
F3-5A	RESERVE	OUTPUT MODUL 1 DO3
F4-5A	OUTPUT MODUL 1 BK2	OUTPUT MODUL 1 DO4
F5-5A	OUTPUT MODUL 1 BK2	OUTPUT MODUL 1 DO4
F6-1A	SCHALTER AUFSTIEG SWITCH ASCENT	OUTPUT MODUL 1 BK4
F6-1A	B785 HUMIDITY SENSOR	OUTPUT MODUL 1 BK4
*	B785 HUMIDITY SENSOR	A774 AdBlue TANK
F7-2A	B726 NOX SENSOR UP	A774 AdBlue TANK
B726 NOX SENSOR UP	M715 Exhaust Flap Actuator 1	
F8-2A	B727 NOX SENSOR DOWN	B730 ÖLNIVEAUGEBER
B727 NOX SENSOR DOWN	B730 OIL LEVEL SENSOR	
F9-2A	B783 NH3 SENSOR	F23-10A WARNBLINKFUNKTION
B783 NH3 SENSOR	HAZARD WARNING SYSTEM	
F10-2A	LIDEC PS2	F24-10A GETRIEBE KL.30
*	LIDEC PS2	TRANSMISSION KL.30
F11-5A	WASSERVENTILE Y70, Y774	F25-10A SCHLAUCHHEIZUNG
*	WATER VALVE Y70, Y774	E770, E771 SCR LINEHEAT G1+2
F12-5A	RESERVE	F26-10A A709 SCR LUFTPUMPE
RESERVE	A709 SCR AIR PUMP	
F13-5A	DIAGNOSE MOTOR	F27-7,5AK15/30 SICHERHEITSKREIS
*	DIAGNOSTIC ENGINE	K15/30 SAFETY CIRCUIT
F14-30A	LIDEC PS1 / ECU3	JUMPER NICHT IN VERWENDUNG
LIDEC PS1 / ECU3	NOT USED	
*	NICHT IN VERWENDUNG BEI STUFE 5 NOT IN USE AT STAGE 5	



MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

OVERVIEW FUSE STICKER A4a  
ELECTRICAL SCHEMATIC;



12466553  
ITEM CODE  
DRAWING INDEX  
000

GG\_4\_EVO  
1333 90100 02 00  
DRAWING NUMBER

PROJECT  
ISO 18016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without registration.  
Violations are prohibited, distribution and utilization of this document as well as the communication of its contents to others without registration.

MACHINE TYPE  
**LIDOS Gerät**


SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

OPTION 2in1 STEERING SWITCH  
ELECTRICAL SCHEMATIC;

PAGE 97 OF

CREATION DATE 08.10.2019 15:49



1 2 3 4 5 6 7 8

A B C D E F

12466553  
ITEM CODE  
DRAWING INDEX  
000

GG\_4\_EVO  
1333 90100 02 00  
DRAWING NUMBER

PROJECT

ISO 18016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without registration, express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design.


MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

OPTION SAFETY BELT LIMIT SWITCH  
ELECTRICAL SCHEMATIC;

PAGE 107 OF  
CREATION DATE 09.10.2019 15:49



1 2 3 4 5 6 7 8

A

B

C

D

E

F



=H +H3		-A17c		Modul Nr.: Modulname:					
ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN
A17c:24V_B1	/118.D2		POWER SUPPLY BANK 1	0	A17c:24V				0
A17c:24V_logic	/118.D1		POWER SUPPLY	2	A17c:24V			CAN LOW	41
A17c:GND	/118.D2		GROUND	0	A17c:CAN_Low	/118.D7		CAN LOW	42
A17c:PWM1	/119.A6		SOLENOID VALVE PIPE BREAK PROTECTION	0	A17c	/118.D7			43
A17c:PWM2	/119.A7		WORKING BASKET LOCKING VALVE	0	A17c:GND_D02				44
A17c:PWM3	/119.A8		WORKING BASKET LOAD SENSING PRESSURE REDUCTION	0	A17c:GND_PWM1	/119.F6		SOLENOID VALVE PIPE BREAK PROTECTION	45
A17c:PWM4				0	A17c:GND_PWM2	/119.F7		WORKING BASKET LOCKING VALVE	46
A17c:PWM9				0	A17c:GND_PWM3	/119.F8		WORKING BASKET LOAD SENSING PRESSURE REDUCTION	47
A17c:PWM10				0	A17c:GND_PWM4				48
A17c:PWM11				0	A17c:GND_PWM9				49
A17c:PWM12				0	A17c:GND_PWM10				50
A17c:GND	/118.D3		GROUND	0	A17c:GND_PWM11				51
A17c:24V_logic	/118.D4		POWER SUPPLY BANK 3	0	A17c:GND_PWM12				52
A17c:24V_B3	/118.D4		POWER SUPPLY BANK 2	0	A17c:GND_D04			WORKING BASKET	53
A17c:24V_B2	/118.D3		GROUND	0	A17c:F11	/119.D5			54
A17c:GND_logic	/118.D1		GROUND	0	A17c:F12	/119.D4			55
A17c:GND	/118.D4		GROUND	0	A17c:CAN_High	/118.D8		CAN HIGH	56
A17c:PWM5				0	A17c:CAN_High	/118.D8		CAN HIGH	57
A17c:PWM6				0	A17c:GND				58
A17c:PWM7				0	A17c:GND_PWM5				59
A17c:PWM8				0	A17c:GND_PWM6				60
A17c:PWM13				0	A17c:GND_PWM7				61
A17c:PWM14				0	A17c:GND_PWM8				62
A17c:PWM15				0	A17c:GND_PWM13				63
A17c:PWM16	/118.D5		GROUND	0	A17c:GND_PWM14				64
A17c:GND_logic	/118.D5		POWER SUPPLY BANK 4	0	A17c:GND_PWM15				65
A17c:24V_B4	/118.D5		POWER SUPPLY BANK 4	0	A17c:GND_PWM16				66
A17c:CAN_Res	/118.D6		CAN TERMINATOR	0	A17c:GND				67
A17c:24V				0	A17c:GND_F11				68
A17c:GND_D01				0	A17c:GND_F12				69
A17c:V_D01				0					70
A17c:V_D02				0					
A17c:V_D03				0					
A17c:V_D03				0					
A17c				0					
A17c:D04				0					
A17c:GND_D03				0					

12466553

ITEM CODE  
DRAWING INDEX  
000

GG\_4\_EVO  
1333 90100 02 00

PROJECT  
DRAWING NUMBER

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require registration and utility model or design registration.


MACHINE TYPE  
**LIDOS Gerät**

SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

MANUAL WIPE, HORN, RADIO RADIO MUTE SWITCH  
ELECTRICAL SCHEMATIC;

PAGE 127 OF  
CREATION DATE 09.10.2019 15:49



RESERVE

1 2 3 4 5 6 7 8

A


B

C

D

E

F



12466553

ITEM CODE

DRAWING INDEX

000

GG\_4\_EVO

PROJECT

DRAWING NUMBER

1333 9010 02 00

ISO 10716: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX

XMSB04

LIEBHERR  
FACTORY LBH

VERSION 2 LogHandler INPUT MODULE  
ELECTRICAL SCHEMATIC;

PAGE 147

OF

09.10.2019 15:49

8

1

2

3





























4

5

6

7

8



12466553

ITEM CODE DRAWING INDEX 000

GG\_4\_EVO 1333 90100 02 00

DRAWING NUMBER

PROJECT registration. ISO 19018. The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design.

MACHINE TYPE  
**LIDOS Gerät**


SERIAL NUMBER  
**XXXXX**

**LIEBHERR**  
FACTORY LBH

VERSION 2 LogHandler LIGHTING  
ELECTRICAL SCHEMATIC;

PAGE 157 OF

CREATION DATE 08.10.2019 15:49



REPLACEMENT FOR MARKED	Imbbap1
DATE	13.12.2017 09:59
CHECKED	Imbbua0
TECHNICAL REFEREE	

CONFIDENTIAL

**LIEBHERR**  
FACTORY LMB






**A3**

DESIGNATION  
ELECTRICAL WIRING DIAGRAM

DESCRIPTION  
STARTER, ALTERNATOR, COMPRESSOR FOR AIR CONDITIONER

ARTICLE CODE	11392207	SYSTEM	=M	LOCATION	+M
DRAWING NUMBER	96 006 9309 90	INDEX	000	SHEET 8	FROM 16

DATE	13.12.2017 09:59
CHECKED	Imbbua0
TECHNICAL REFEREE	



## 110.4 Electronic control unit

### 110.4.1 General overview of electronic control system

Valid for: L586-1761;

#### 1 Layout




Fig. 473: General overview of electronic control system

BMK	Component	CAN line	CAN address
A9	Immobiliser (option)	3	107
A11	Control unit	3	97
A15	Central control unit (Master5-Premium)		

LBH/12252628/01/211-20191218\_155739/en

g2074993

1 Layout




Fig. 482: Output module with type plate

- |   |                                    |    |                     |
|---|------------------------------------|----|---------------------|
| 1 | Housing made of die-cast aluminium | 6  | Serial number       |
| 2 | Goretex membrane                   | 7  | Date of manufacture |
| 3 | Connector                          | 8  | Specification index |
| 4 | Type plate                         | 9  | Article code        |
| 5 | Device designation                 | 10 | Voltage range       |

Output modules consist of various electronic components, fitted in a die-cast aluminium housing. Depending on the device type, up to 4 output modules can be installed.




Fig. 483: Plug assignment of output modules

- |   |                               |    |                                    |
|---|-------------------------------|----|------------------------------------|
| 1 | Power supply for bank 1 and 2 | 8  | Power supply for bank 3 and 4      |
| 2 | Power supply for logic        | 9  | Encoder supply voltage 24 V        |
| 3 | Earth for logic               | 10 | Frequency measurement inputs       |
| 4 | Power outputs 1.3 A, bank 1   | 11 | Common earth                       |
| 5 | Power outputs 1.3 A, bank 2   | 12 | Power supply 8 A, switching output |
| 6 | Power outputs 1.3 A, bank 4   | 13 | 8 A, switching output              |
| 7 | Power outputs 1.3 A, bank 3   | 14 | CAN interface                      |

2 Function

The output module is part of the control system and is linked to the central control unit via a CAN bus interface. The central control unit can specify the current from the outputs via the CAN bus. The module regulates what currents are required

LBH/12252628/01/211-2019/12/18\_155739/en

# 120 Gearbox

## Contents

120.1	Overview of transmission <i>L586-1761;</i>	120-2
120.2	Transmission hydraulics	120-16
120.2.1	Overview of transmission hydraulics <i>L586-1761;</i>	120-16
120.2.2	Gear pump <i>L586-1761;</i>	120-20
120.2.3	Transmission control valve block <i>L586-1761;</i>	120-21
120.2.4	Hydrostat module <i>L586-1761;</i>	120-24
120.3	Transmission electronics	120-29
120.3.1	Overview of electrical control system of transmission <i>L586-1761;</i>	120-29
120.3.2	Filter bypass switch <i>L586-1761;</i>	120-30
120.3.3	Gear shifting proportional solenoid <i>L586-1761;</i>	120-31
120.3.4	Pressure sensor for hydrostat <i>L586-1761;</i>	120-32
120.3.5	Engine speed sensor <i>L586-1761;</i>	120-33
120.3.6	Temperature sensor <i>L586-1761;</i>	120-34
120.3.7	Proportional solenoid for position control <i>L586-1761;</i>	120-34

LBH/12252628/01/211-2019/12/18\_155739/en

Name	Description	Name	Description	Name	Description
<b>W2</b>	Shaft 2	<b>Z7</b>	Gearwheel 7		
<b>ZS1</b>	Sun gear 1	<b>Z8</b>	Gearwheel 8		

Tab. 225: Key

To start the machine moving, the double yoke drive both rotary groups simultaneously. The pump **T1** swivels out, while the motor **T2** swivels in.

As a result, the pump **T1** delivers oil through the duct **A** to drive the motor **T2**. Because the pump **T1** is only at a small angle and the motor **T2** is almost at the maximum angle, a very high output torque is transmitted to the closed clutch **K1**. The machine moves purely under hydraulic power with maximum tractive force.

As soon as the machine starts moving, the ring gear **ZH** also starts turning. The ring gear **ZH** turns in the same direction as the gearwheel **Z5**. This reduces the speed transmitted to the sun gear **ZS1** and thus also the speed of the pump **T1** in relation to the engine speed. Some of the power is then transferred mechanically via the ring gear **ZH** and the two gearwheels **Z6** and **Z9** to the clutch **K1**.

**2.3.3 Machine moving and accelerating (clutch K1 closed)**




Fig. 496: Machine moving and accelerating (clutch K1 closed)

Name	Description	Name	Description	Name	Description
<b>A</b>	Duct A	<b>ZS2</b>	Sun gear 2	<b>Z9</b>	Gearwheel 9

LBH/12252628/01/211-2019/12 18\_155739/en

sag01809

### 120.2.3 Transmission control valve block

Valid for: L586-1761;

#### 1 Layout




Fig. 502: Transmission control valve block (from front left)

- |   |                                                          |   |                                                          |
|---|----------------------------------------------------------|---|----------------------------------------------------------|
| 1 | Main pressure valve 20 bar                               | 5 | Secondary spool for reverse travel direction clutch (KR) |
| 2 | Secondary spool for clutch 2 (K2)                        | 6 | Secondary spool for clutch 1 (K1)                        |
| 3 | Secondary spool for forward travel direction clutch (KV) | 7 | Secondary spool for clutch 3 (K3)                        |
| 4 | Secondary spool for optional connection                  | 8 | Pressure reducing valve 9 bar                            |

BMK	Function	BMK	Function	BMK	Function
Y1	Proportional solenoid for clutch 2 (K2)	Y3	Proportional solenoid for optional connection	Y5	Proportional solenoid for clutch 1 (K1)
Y2	Proportional solenoid for forward travel direction clutch (KV)	Y4	Proportional solenoid for reverse travel direction clutch (KR)	Y6	Proportional solenoid for clutch 3 (K3)

Tab. 231: Equipment codes

The transmission control valve block is bolted to front of transmission.

LBH/12252628/01/211-2019/12/18\_155739/en

### 120.3.3 Gear shifting proportional solenoid

Valid for: L586-1761;

#### 1.1 Layout




Fig. 510: Gear shifting proportional solenoid

BMK	Function
Y1	Proportional solenoid for clutch 2 (K2)
Y2	Proportional solenoid for forward travel direction clutch (KV)
Y3	Proportional solenoid for 1st optional connection
Y4	Proportional solenoid for reverse travel direction clutch (KR)
Y5	Proportional solenoid for clutch 1 (K1)
Y6	Proportional solenoid for clutch 3 (K3)


Tab. 240: Equipment codes

The gear shift proportional control solenoids are fitted in the valve block.

#### 2.1 Function

The gear shift proportional control solenoids are used to operate the clutches.

## 2.2 Self-locking differential



sec01804

Fig. 519: Self-locking differential

- |   |                               |    |                                 |
|---|-------------------------------|----|---------------------------------|
| 1 | Left half shaft               | 8  | Right half shaft                |
| 2 | Locking discs for left wheel  | 9  | Tight axle tapered gear         |
| 3 | Crown wheel                   | 10 | Compensation tapered gear       |
| 4 | Compensation axle             | 11 | Axle input shaft (tapered gear) |
| 5 | Right thrust ring             | 12 | Left thrust ring                |
| 6 | Differential housing          | 13 | Left axle tapered gear          |
| 7 | Locking discs for right wheel |    |                                 |

### 2.2.1 Speed balance

When cornering, the wheel on the inside of the bend covers less distance than the wheel on the outside. This means that the inside wheel turns at a lower speed than the outer wheel.

The axle input shaft **11** drives the crown wheel **3**. This is rigidly connected to the differential housing **6**. Along with the differential housing **6**, two compensation axles **4** and therefore four compensation tapered gears **10** rotate around the half shafts **1** and **8**. The axle tapered gears **9** and **13** are driven by the compensation tapered gears **10**.

The compensation tapered gears **10** do not turn as long as the wheels are turning at the same speed.

If one wheel turns faster than the other, this is compensated by the compensation tapered gears **10** rotating around the compensation axles **4**. The half shaft of the inside wheel turns slower and the half shaft of the outside wheel turns faster than the crown wheel **3** by the same amount. The speed of the axle input shaft **11** remains the same.

The radial seals **8** protect the bearings from dirt.

## 140.1.2 Articulation lock

Valid for: L586-1761;

### 1 Layout




Fig. 526: Engaging the articulation lock

- |   |             |   |           |
|---|-------------|---|-----------|
| 1 | Locking bar | 3 | Pin       |
| 2 | Bracket     | 4 | Split pin |

The articulation bearing is fitted between the front and rear sections.

### 2 Function

The articulation lock creates a rigid connection between the front and rear sections. Steering is no longer possible.

This means the steering is blocked, for example, when transporting the machine or for maintenance.

### 2.3.1 Opening solenoid valve for quick coupler

Solenoid valve for quick coupler 2 determines which side of hydraulic cylinder for quick coupler locking is pressurised. In order to open quick coupler, solenoid valve for quick coupler 2 is energized.

## 150.2.3 Quick coupler electrics

### 150.2.3.1 Quick coupler electric control unit

Valid for: L586-1761;

#### 1 Basic function




Fig. 533: Quick coupler electric control unit

Position	Description	Position	Description
A16a	Input module A16a	K233	Safety shutdown relay
A17a	Output module A17a	S23	Quick coupler button
F238	Quick coupler fuse	Y53	Quick coupler solenoid valve
K231	Quick coupler unlocking relay	Y53a	Quick coupler load sensing signal solenoid valve
K232	Latching function relay		

Tab. 257: Items

The quick coupler is unlocked and locked using the *quick coupler* button **S23**.

The electronic control unit is powered via the quick coupler fuse **F238**.

The quick coupler solenoid valve **Y53** is controlled by the quick coupler unlocking relay **K231**.

LBH/12252628/01/211-2019/12/18\_155739/en

## 2.1 Basic function

The cab is equipped with a hot water heater and an air conditioning unit as standard.

## 2.2 Hot water heating function




Fig. 540: Hot water heating function

- |   |                            |   |                            |
|---|----------------------------|---|----------------------------|
| 1 | Fresh air flap             | 6 | Heat exchanger             |
| 2 | Blower                     | 7 | Cooling/heating mixer flap |
| 3 | Evaporator                 | 8 | Mixer plate                |
| 4 | Cooling water forward flow | 9 | Air distributor flap       |
| 5 | Cooling water return flow  |   |                            |

The blower 2 draws in ambient air. The air drawn in is forced through the evaporator 3 to the heat exchanger 6.

The heat exchanger is heated by hot coolant from the engine.

The air is heated as it flows through the heat exchanger. The heated air is distributed through the flap 9 to the cab.

The outlet temperature is regulated using the cooling/heating mixer flap 7. The outlet temperature depends on the mixing ratio between ambient air coming directly from the evaporator and ambient air that has been heated by the heat exchanger.

The air flow is controlled by the various speeds of the blower.

## 160.3.3 Air conditioning controller

Valid for: L586-1761;

### 1 Layout




Fig. 549: Air conditioning controller A21

**X1** Connector A21.X1

**X2** Connector A21.X2

Air conditioning controller is installed heating and air conditioning unit.

### 2 Function

Air conditioning controller A21 is connected via CAN bus to central control unit.

Air conditioning controller is responsible for controlling heating and air conditioning unit.

Air conditioning controller processes data from sensors and controls servo motors.

#### 2.1.1 Connector A21.X1

This plug connects air conditioning controller to vehicle components (such as central control unit, air conditioning compressor and condenser fan).

Pin	Function	Pin	Function
1	Terminal 30	16	CAN_Low OUT
2	Ground	17	CAN_High OUT
3	Terminal 15	18	Ground
4	Auxiliary heater	19	Terminal 30
5	Signal from air conditioning pressure switch B27	20	Spare
6	Spare signal from air conditioning pressure switch	21	Spare
7	Spare	22	Spare
8	Condenser fan M13	23	Spare
9	Door contact S70	24	Spare
10	Condenser coupling Y22	25	Spare

With the parallel circuit, 24 volts are present at each condenser fan. The fans run at high speed.

**Condenser fan operation in serial circuit (low speed):**




Fig. 555: Condenser fan operation in serial circuit (low speed)

- B** Pressure switch for increasing the fan speed
- B27** Air conditioning pressure switch
- A21** Air conditioning controller
- K10** Relay
- K11** Relay
- 1** Condenser fan M13
- 2** Condenser fan M13a

The pressure switch for increasing the fan speed **B** is open.

The relay **K10** is activated via an output on the air conditioning controller **A21**.


The relay **K10** powers the condenser fan M13 **1** and then the condenser fan M13a **2**.

In the series circuit, the applied voltage (24 V) is distributed equally (12 V each) to the two condenser fans.

The two condenser fans run at low speed.

**Condenser fan operation in parallel circuit (high speed):**

LBH/12252628/01/211-2019/12/18\_155739/en



## 2.5 Non-scheduled lubrication intensity (cycle settings)

You can use the *central lubrication system* key to make the following settings:

- Setting the lubrication intensity (75%, 100%, 125%)
- Non-scheduled lubrication

The LEDs indicate the following conditions when the ignition is switched on:

- LED 1 lights up: 75% lubrication intensity set (for light duty)
- LED 2 lights up: 100% lubrication intensity set (for medium duty)
- LED 3 lights up: 125% lubrication intensity set (for heavy duty)
- LED 1 or 2 or 3 flashes: lubrication cycle in progress
- LEDs 1 + 2 + 3 lights up: grease has reached low level
- LEDs 1 + 2 + 3 flash and service code: system fault

## 2.6 Setting the lubrication intensity




Fig. 565: Lubrication processes

- |          |                             |          |                             |
|----------|-----------------------------|----------|-----------------------------|
| <b>A</b> | Lubrication cycle (strokes) | <b>2</b> | Lubrication for medium duty |
| <b>1</b> | Lubrication for light duty  | <b>3</b> | Lubrication for heavy duty  |

Press and hold the *central lubrication system* key (>2 s) to switch to setting mode.

Each time you press the button, the mode changes to the next one up and after the highest mode switches back to the first (i.e. 75% - 100% - 125% - 75% - ... etc.)

The cycle time for medium-duty operation (mode 2) can be altered in the Sculi diagnostic software using the [CWadCGrTimeMode2](#) parameter.

During the lubrication cycle **A** the number of set strokes are performed. The shorter the pauses between the lubrication cycles, the more grease is supplied to the lubricating points.

The number of lubricating cycles and the associated default values can be seen in the Sculi diagnostic software using the variable [CDCentrGrPulsesPerCycle](#).

## 2 Function

### 2.1 Basic function




Fig. 574: Function

- 1 Central control unit
- 2 Antenna
- 3 LiDAT module

- F11 Fuse F11 terminal 15
- F48 Fuse F48 terminal 30

The central control unit 1 transmits machine data via the LAN interface (LAN4) to the LiDAT module 3. The LiDAT module is powered via fuses F11 and F48.

LiDAT module is connected to the antenna 2 via 2 antenna cables.

Antenna is used to send and receive position data and transmit data.

The following functions can be checked on the display:

- Cable connection between central control unit and LiDAT module.
- Availability of position data.

## 190.3 Remote control for door lock

Valid for: L586-1761;

### 1 Layout




Fig. 594: Remote control for door lock

- |          |                              |          |                       |
|----------|------------------------------|----------|-----------------------|
| <b>1</b> | Remote control for door lock | <b>3</b> | Electrical components |
| <b>2</b> | Cab door                     |          |                       |

With remote control for door lock **1**, cab door **2** can be locked, unlocked and opened. See operating manual for more information.

Electrical components for controlling door latch and the door lock are installed behind interior trim of cab door.

Pin assignment of A35.X			
Pin	Function	Pin	Function
F4	Analogue input (with pull-down resistor)	M4	Ground

Tab. 274: Plug assignment

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL