

en

Service manual

Wheel loader

Document ID

Order number: 12252628
Issued: 2020-03-26
Version: 03
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 586-1761

Contact

Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	020.14.3.2	SXE-2 100	020-36
	020.14.3.3	SXE-2 150	020-37
	020.14.3.4	SXE-2 220	020-37
	020.14.3.5	SXE-2 400	020-37
	020.14.3.6	SXE-2 760	020-37
030	Maintenance		030-1
030.1	Maintenance and inspection schedule		030-10
030.2	Filling quantities and lubrication chart		030-15
030.2.1	Lubricant filling quantity <i>L586-1761;</i>		030-15
030.2.2	Fuel and operating fluid filling quantity <i>L586-1761;</i>		030-15
030.3	Lubricants and fuels		030-16
030.3.1	General information on lubricants and fuels		030-16
	030.3.1.1	General questions	030-16
	030.3.1.2	Safety data sheets	030-16
	030.3.1.3	Technical data sheets	030-16
	030.3.1.4	Specific Liebherr standards	030-16
030.3.2	General information on changing lubricants and fuels		030-16
030.3.3	Converting hydraulic system from mineral oils to biodegradable hydraulic fluids		030-17
030.3.4	Diesel fuels <i>L586-1761;</i>		030-17
	030.3.4.1	Minimum quality requirement	030-17
	030.3.4.2	Operating temperatures of diesel fuels	030-18
	030.3.4.3	Minimum quality requirement	030-18
030.3.5	Diesel exhaust fluid <i>L586-1761;</i>		030-18
	030.3.5.1	Liebherr recommendation	030-18
	030.3.5.2	Minimum quality requirement	030-18
030.3.6	Engine oils <i>L586-1761;</i>		030-19
	030.3.6.1	Liebherr recommendation	030-19
	030.3.6.2	Minimum quality requirement	030-19
	030.3.6.3	Changing intervals	030-19
	030.3.6.4	Complicating factors	030-20

	040.1.5.3	Separ fuel pre-filter <i>L586-1761;</i>	040-21
040.1.6	Air filter system		040-21
	040.1.6.1	Air filter <i>L586-1761;</i>	040-22
	040.1.6.2	Vacuum switch <i>L586-1761;</i>	040-23
040.1.7	Exhaust system		040-23
	040.1.7.1	Exhaust gas treatment (stage V): overview <i>L586-1761;</i>	040-24
	040.1.7.2	Exhaust gas treatment (stage IV / tier 4f): overview <i>L586-1761;</i>	040-33
	040.1.7.3	Metering unit <i>L586-1761;</i>	040-38
	040.1.7.4	Sampling module <i>L586-1761;</i>	040-41
	040.1.7.5	Exhaust treatment sensors <i>L586-1761;</i>	040-42
040.1.8	Compressed air system		040-43
	040.1.8.1	Overview of the compressed air system <i>L586-1761;</i>	040-44
	040.1.8.2	Compressor <i>L586-1761;</i>	040-46
	040.1.8.3	Air dryer <i>L586-1761;</i>	040-47
	040.1.8.4	SCR system air supply valve <i>L586-1761;</i>	040-48
040.2	Clutch <i>L586-1761;</i>		040-49
040.3	Splitter box <i>L586-1761;</i>		040-51
050	Cooling system		050-1
050.1	Cooling system: General overview <i>L586-1761;</i>		050-2
050.2	Cooling system hydraulics		050-3
	050.2.1	Overview of cooling system hydraulics <i>L586-1761;</i>	050-4
	050.2.2	Fan pump <i>L586-1761;</i>	050-8
	050.2.3	Fan motor <i>L586-1761;</i>	050-9
050.3	Cooling system electronics		050-13

010.3.1.3	Modifications and descriptions	010-38
010.3.1.4	Tightening torques	010-38
010.3.2	Liebherr standards for assembly instructions and tightening torques	010-44
010.4	Preservation guidelines	010-45
010.4.1	General information	010-45
010.4.2	Machine out of service for an unknown period of time	010-45
010.4.3	Putting the machine out of service	010-46
010.4.3.1	Out of service for up to 2 months	010-46
010.4.3.2	Out of service for up to 12 months	010-47
010.4.3.3	Out of service for longer than 12 months	010-48
010.4.4	Putting back into service	010-48
010.4.4.1	After being out of service for 2 months	010-48
010.4.4.2	After being out of service for 12 months	010-49
010.4.4.3	After being out of service for longer than 12 months	010-49
010.5	Preservation guidelines for the SCR system	010-50
010.5.1	Putting out of service for longer than 2 months	010-50
010.5.2	Starting up after being out of service for longer than 2 months	010-50

010.1.4.2 Roll over protective structure (ROPS)

Danger to life

Damaged falling object protective structures

- Do not put machine into service with damaged falling object protective structures.
- Do not put machine into service with deformed falling object protective structures.
- Do not use falling object protective structures with structural changes.
- Do not use repaired falling object protective structures.
- Do not perform welding on falling object protective structures.
- Do not cut or saw falling object protective structures.
- Do not drill falling object protective structures.

Exceeding of total weight

- Make sure that total weight of machine (see identification plate) is not exceeded.
- Make sure that the machine does not exceed the total weight with heavy working tools.
- Make sure that the machine does not exceed the total weight after changing the working attachment.
- Make sure that the machine does not exceed the total weight with add-ons or after retrofitting.

010.1.4.3 Falling object protective structures (FOPS)

Danger to life

Damaged falling object protective structures

- Do not put machine into service with damaged falling object protective structures.
- Do not put machine into service with deformed falling object protective structures.
- Do not use falling object protective structures with structural changes.
- Do not use repaired falling object protective structures.
- Do not perform welding on falling object protective structures.
- Do not cut or saw falling object protective structures.
- Do not drill falling object protective structures.

010.1.5 Emergency equipment on the machine

010.1.5.1 Emergency exit (standard)






Danger to life

Incorrect labelling

- Make sure that all information signs are present.
- Make sure that all information signs are legible.


010.2 Special tools for maintenance and repair work

010.2.1 Special tools, general

Designation	Item code	Remark	Fig.
Refractometer	11830573	For checking acid density of batteries, antifreeze concentration in coolant and diesel exhaust fluid	
24 volt vacuum pump	7408148	For preventing loss of oil when working on hydraulic system	
Testing and filling device for hydro accumulators, with case	8460226	For testing and filling hydro accumulators	
Pressure gauge (40 bar), class 1.0	7361288	For testing hydraulic pressure	
Pressure gauge (250 bar), class 1.0	7361285	For testing hydraulic pressure	


LBH/12252628/03/211-20200327_070249/en

010.2.10 Special tools for front axle

Designation	Item code	Remark	Fig.
Positioning tool	12244602	For mounting the bevel gear shaft seal ring	




Tab. 13: Special tools for front axle

010.2.11 Special tools for rear axle

Designation	Item code	Remark	Fig.
Positioning tool	12244602	For mounting bevel gear shaft seal ring	

Tab. 14: Special tools for rear axle

010.2.12 Special tools for the air conditioning system

Designation	Item code	Remarks	Fig
Valve insert remover	11834779	For changing valve inserts in the filling port of air conditioning hoses.	
Valve insert in air conditioning hose filling port	11834778	For replacing defective valve inserts. Set of 10	
Vacuum pump	7027552	For evacuating the air conditioning system	

LBH/12252628/03/211-20200327_070249/en

Metric standard threads and fine threads				Metric standard threads and fine threads			
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fZnnc-480h-L valid \geq M6)				All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)			
Minimum total coefficient of friction $\mu_G = 0.09$				Minimum total coefficient of friction $\mu_G = 0.11$			
Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm	Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm
M 33	8.8	370	1550	M 33	8.8	370	1800
	10.9	550	2250		10.9	540	2600
	12.9	640	2600		12.9	630	3100
M 33 x 1.5	8.8	430	1650	M 33 x 1.5	8.8	420	1950
	10.9	630	2450		10.9	620	2900
	12.9	740	2800		12.9	730	3400
M 33 x 2	8.8	420	1600	M 33 x 2	8.8	410	1900
	10.9	610	2400		10.9	600	2800
	12.9	720	2800		12.9	700	3300
M 36	8.8	440	1950	M 36	8.8	430	2300
	10.9	650	2900		10.9	630	3400
	12.9	760	3400		12.9	740	3900
M 36 x 1.5	8.8	520	2150	M 36 x 1.5	8.8	510	2600
	10.9	760	3200		10.9	750	3800
	12.9	890	3700		12.9	870	4400
M 36 x 3	8.8	470	2050	M 36 x 3	8.8	460	2400
	10.9	690	3000		10.9	680	3500
	12.9	810	3500		12.9	790	4100
M 39	8.8	530	2500	M 39	8.8	520	3000
	10.9	770	3700		10.9	760	4400
	12.9	910	4400		12.9	890	5100
M 39 x 1.5	8.8	610	2800	M 39 x 1.5	8.8	600	3300
	10.9	900	4000		10.9	880	4800
	12.9	1050	4700		12.9	1030	5600
M 39 x 3	8.8	560	2600	M 39 x 3	8.8	550	3100
	10.9	820	3900		10.9	810	4500
	12.9	960	4500		12.9	940	5300

Tab. 21: Bolt prestressing forces and tightening torques

*The tightening torques for fZn bolts <M10 are non-binding because no fixed friction coefficient window is defined in the LH10215295 standard. According to the

020.7.6	Parking brake hydro accumulator <i>L586-1761;</i>	020-22
020.8	Electrical system	020-23
020.8.1	Central control unit (Master5-Premium) <i>L586-1761;</i>	020-23
020.8.2	Input module <i>L586-1761;</i>	020-23
020.8.3	Output module <i>L586-1761;</i>	020-23
020.8.4	Battery <i>L586-1761;</i>	020-24
020.8.5	Voltage transformer <i>L586-1761;</i>	020-24
020.8.6	Reversing camera <i>L586-1761;</i>	020-24
020.9	Gearbox	020-25
020.9.1	Transmission <i>L586-1761;</i>	020-25
020.9.2	Filter bypass switch B85 <i>L586-1761;</i>	020-25
020.9.3	Proportional solenoid for gear shifting Y1, Y2, Y3, Y4, Y5, Y6 <i>L586-1761;</i>	020-25
020.9.4	Pressure sensor for hydrostat B80, B81 <i>L586-1761;</i>	020-26
020.9.5	Speed sensor B82, B83, B84 <i>L586-1761;</i>	020-26
020.9.6	Transmission oil temperature sensor B86 <i>L586-1761;</i>	020-26
020.9.7	Proportional solenoid for position control Y7 <i>L586-1761;</i>	020-27
020.10	Axles and drive shafts	020-28
020.10.1	Front axle <i>L586-1761;</i>	020-28
020.10.2	Rear axle <i>L586-1761;</i>	020-28
020.10.3	Drive shaft between diesel engine and transmission <i>L586-1761;</i>	020-28
020.10.4	Drive shaft between transmission and front axle <i>L586-1761;</i>	020-29
020.10.5	Cardan shaft between transmission and rear axle <i>L586-1761;</i>	020-29
020.10.6	Tyres <i>L586-1761;</i>	020-29
020.10.6.2	Special tyres	020-30

020.3 Cooling system

020.3.1 Fan pump

Valid for: L586-1761;

Description	Unit	Value
Type		External gear pump
Displacement per turn	cm ³	14
Direction of rotation		Anticlockwise

020.3.2 Fan motor

Valid for: L586-1761;

Description	Unit	Value
Type		External gear motor
Displacement per turn	cm ³	22.5
Direction of rotation		Anticlockwise
Pressure relief	bar	220
Weight	kg	6.68

020.3.3 Hydraulic oil temperature sensor B8

Valid for: L586-1761;

Description	Unit	Value
Minimum temperature	°C	-30
Maximum temperature	°C	130
Resistance at 20 °C	Ω	1000
Connecting thread	mm	M14x1.5
Tightening torque	Nm	30

020.8 Electrical system

020.8.1 Central control unit (Master5-Premium)

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP65
Power supply (logic unit)	VDC	7.0 – 36.0
Rated voltage	VDC	24
Operating temperature	°C	-40 to +60
Weight	kg	2

020.8.2 Input module

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP6K9K
Power supply (logic unit)		See sticker on module
Rated voltage	VDC	24
Operating temperature	°C	-40 to +85
Operation at ambient air pressure	mbar	500 to 1100
Weight	kg	1.77
Module connector tightening torque	Nm	3

020.8.3 Output module

Valid for: L586-1761;

Description	Unit	Value
Protection class (with plug connected)		IP6K9K
Power supply (logic unit)		See sticker on module
Rated voltage	VDC	24
Operating temperature	°C	-40 to +85
Operation at ambient air pressure	mbar	500 to 1100
Weight	kg	1.77
Module connector tightening torque	Nm	3

020.13 Operator's cab, heating and air conditioning

Valid for: L586-1761;

020.13.1.1 Air conditioning compressor

Description	Unit	Value
Manufacturer		Sanden
Refrigerant oil (PAG oil)		ZXL 100 PG

020.13.2 Air conditioning pressure switch

Valid for: L586-1761;

Description	Unit	Value
Low pressure OFF	bar	2 ^{±0.2}
Low pressure ON	bar	2.1 ^{±0.3}
High pressure OFF	bar	27 ^{±2}
High pressure ON	bar	20 ^{±3}
Increase fan speed OFF	bar	14 ^{±1.2}
Increase fan speed ON	bar	17 ^{±1.2}

030.4.9.4	Personnel detection: cleaning sensor <i>L586-1761;</i>	030-129
030.4.10	Gearbox	030-130
030.4.10.1	Transmission: checking the oil level <i>L586-1761;</i>	030-130
030.4.10.2	Changing gear oil and gear oil filter <i>L586-1761;</i>	030-133
030.4.10.3	Change the transmission hydrostat oil filter. <i>L586-1761;</i>	030-136
030.4.11	Axles and drive shafts	030-137
030.4.11.1	Axles Changing the oil <i>L586-1761;</i>	030-137
030.4.11.2	Checking drive shafts <i>L586-1761;</i>	030-139
030.4.11.3	Checking the tyre pressure <i>L586-1761;</i>	030-141
030.4.11.4	Checking the wheel tightness <i>L586-1761;</i>	030-143
030.4.12	Steel parts of the basic machine	030-143
030.4.12.1	Cooler hood: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-143
030.4.12.2	Engine hood: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-144
030.4.12.3	Right cab access: Lubricating moving parts with penetrating oil <i>L586-1761;</i>	030-145
030.4.12.4	Service hatches: cleaning and maintaining seals <i>L586-1761;</i>	030-145
030.4.13	Working attachment	030-146
030.4.13.1	Lift arms: Checking the bucket bearing seals <i>L586-1761;</i>	030-146
030.4.13.2	Lift arms: checking bucket bearing bushings <i>L586-1761;</i>	030-147
030.4.13.3	Checking the lift arm bucket stops <i>L586-1761;</i>	030-148
030.4.13.4	Bucket: Check the teeth or undercut blade for wear and replace if necessary <i>L586-1761;</i>	030-150
030.4.13.5	Lubricate and test the bearings on the quick coupler. <i>L586-1761;</i>	030-153
030.4.13.6	High dump bucket: Lubricating the bearing <i>L586-1761;</i>	030-154

030.2 Filling quantities and lubrication chart

Specifications in the quantity column:

- The values stated for the filling quantities in the table are only guidelines.
- The dipstick and level markings are always mandatory.
- Each time the oil is replaced or topped up, check the level in the unit in question.

Valid for: L586-1761;

030.2.1 Lubricant filling quantity

Valid for: L586-1761;

Designation	Quantity
Diesel engine (with filter change)	42 l
Hydraulic system: system content	210 l
Hydraulic system: tank capacity (exchange amount)	95 l
Splitter box	1.2 l
Transmission	55 l
Front axle	60 l
Rear axle	60 l

Tab. 30: Lubricant filling quantity

030.2.2 Fuel and operating fluid filling quantity

Valid for: L586-1761;

Designation	Quantity
Fuel tank	500 l
Diesel exhaust fluid tank	67.5 l
Cooling system (system content)	73 l
Windscreen washer system	5.3 l
Air conditioning refrigerant	1.25 ^{+0.02} kg
CO ₂ equivalent	1.79 t
Refrigerant oil for air conditioning compressor	210 cm ³

Tab. 31: Fuel and operating fluid filling quantity

030.3.14 Windscreen washer fluid

Valid for: L586-1761;

030.3.14.1 Liebherr recommendation

Liebherr recommends standard windscreen washer fluid with anti-freeze.

030.3.14.2 Minimum quality requirement

Use mixture of water and denatured alcohol.

030.3.15 Refrigerant oil for air conditioning compressor

Valid for: L586-1761;

030.3.15.1 Liebherr recommendation

Designation
ZXL 100 PG (PAG Oil)

Tab. 56: Liebherr recommendation

Position	Component	Check
3	Working attachment	Check working attachment for loose bolts, damage and wear.
4	Diesel exhaust fluid tank	Check SCR system for leaks and damage.
5	Underside of engine compartment	Open cover plates on underside of diesel engine. Check underside of engine compartment for damage, loose bolts and leaks.
6	Underside of wheel loader	Check underside of wheel loader for loose bolts, leaks and damage. Check transmission for leaks and damage.
7	Cab access	Check fluid level in windscreen washer tank and central lubrication system (option).
8	Cooling system	Check cooling system for loose bolts, leaks and damage.
9	Diesel engine	Check SCR system for loose bolts and clips. Check SCR system for damage. Check SCR system for leaks.
10	Operator's cab	Check mirrors and other visual aids for damage. Check indicators and control elements for damage. Check service codes. Check function of installed cameras (reversing camera etc.).
11	Wheel wedges	Check chock for damage. Check function of chock.

Tab. 58: Checking machine is in proper condition

030.4.3.2 Removing loose parts, dirt, ice and snow from machine

Valid for: L586-1761;

Make sure following requirements are fulfilled:

- Machine is in maintenance position 1.



Note

Ensure safe machine operation.


- ▶ Remove any loose parts, coarse dirt, mud, ice, snow etc.
- ▶ Carefully clean machine with a high-pressure cleaner.
 - ▷ (For more information see: [Cleaning machine, page 030-35](#))

030.4.3.3 Cleaning machine

Valid for: L586-1761;

Thoroughly clean the machine of all dirt and deposits in the following situations:

- After completing each job
- Before maintenance work
- Before repairs



G2005553

Fig. 97: Sampling point on the splitter box

- | | | | |
|---|---------------|---|---------------|
| 1 | Splitter box | 3 | Sampling hose |
| 2 | Dipstick tube | 4 | Hand pump |

- ▶ Start the engine and wait 3 minutes.
 - ▷ The oil is circulated.
- ▶ Put machine in maintenance position 1.



WARNING

Hot components!
Risk of injury.

- ▶ Do not touch components of the exhaust system and the engine.

- ▶ Take out dipstick.
- ▶ Insert the sampling hose 3 to 5 cm below the oil level.
- ▶ Fill the sample container using the hand pump 4.
- ▶ Remove the sampling hose.
- ▶ Put the dipstick back in again.

Coolant circuit

The coolant sample is taken from the coolant equalising reservoir using a hand pump.

- ▶ Remove oil traces on diesel engine.
- ▶ Start diesel engine and check oil pressure.
 - ▷ *Engine oil pressure* symbol must not light up.
- ▶ Turn off diesel engine.

**WARNING**

Hot components!
Injury.

- ▶ Do not touch components of exhaust system and diesel engine.

- ▶ Check that oil filter is leak-tight.
- ▶ After 2 or 3 minutes, check whether oil level on dipstick is between **MIN** and **MAX** markings.

If the oil level is not between the **MIN** and **MAX** markings:

- ▶ Correct oil level.

030.4.4.4 Checking diesel engine belt drive

Valid for: L586-1761;

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- The diesel engine and exhaust system have cooled down.




Fig. 107: Checking diesel engine belt drive

- | | | | |
|----------|---------------|----------|-------------------|
| 1 | Pulleys | 3 | Deflector roller |
| 2 | V-ribbed-belt | 4 | Tensioning device |

Following damage could occur on V-ribbed belt:

- Broken ribs
- Lumps of rubber on belt
- Accumulated dirt or grit
- Ribs coming loose from belt
- Cracks across back
- Cracks across several ribs

- ▶ Install new fuel pre-filter **6**.
- ▶ Check the seal **4** and replace it if necessary.
- ▶ Check that cover **2** is clean, put it on again and tighten screws **3** crosswise and evenly.
- ▶ Close drain valve **7**.
- ▶ Tighten the bleeder screw **1** with a torque of 6 Nm.
- ▶ Put hand pump in the *RUN* position **9**.
- ▶ Bleed the fuel system.

Bleeding fuel system

Bleeding fuel system is necessary after:

- Changing fuel filter
- Emptying fuel tank

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.

Make sure that following tool is ready.

- Receptacle



WARNING

Highly flammable consumables!
Beware of burns.

- ▶ Avoid naked lights and fire.




Fig. 117: Bleeding fuel system

- 1** Hand pump in the *PUMP* position **2** Hand pump in the *RUN* position

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The service access is open.
- The engine has cooled down.
- Suitable protective equipment is used.




Fig. 127: Air filter: Changing the safety element

- | | | | |
|---|----------------------|---|----------------|
| 1 | Dust discharge valve | 4 | Main element |
| 2 | Service cover | 5 | Safety element |
| 3 | Fixing clips | 6 | Filter housing |

- ▶ Release the fixing clips **3** on the service cover **2**.
- ▶ Take off the service cover **2**.
- ▶ Remove the main element **4**.
- ▶ Clean the service cover **2** and the filter housing **6** with a clean cloth.
- ▶ Remove the safety element **5**.
- ▶ Lightly oil the sealing faces of the new safety element **5** and the main element **4**.
- ▶ Install the new safety element **5** and the main element **4**.
- ▶ Put the service cover **2**, with the dust discharge valve **1** facing down, on the filter housing **6**.
- ▶ Close the fixing clips **3**.

030.4.4.18 Dust protection for alternator (option): cleaning or replacing filter element

Valid for: L586-1761;

Make sure that following preconditions are met::

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.
- Suitable protective equipment is used.




Fig. 139: Diesel engine: check profile clamps.

- | | | | |
|---|---------------------|---|---|
| 1 | Profile clip | 5 | Bolt clamp |
| 2 | Profile clip | 6 | Diesel exhaust fluid injector |
| 3 | Profile clip | 7 | Temperature sensor, pressure sensor, differential pressure line, screw connection |
| 4 | Hinge strap bracket | 8 | NO _x sensor, NH ₃ sensor |

► Check components are tight.

If component is loose:

► Tighten component with tightening torque according to table.

Position	Component	Tightening torque
1	Clip	23 ^{±2} Nm
2	Clip	18 ^{+2/-1} Nm
3	Clip	23 ^{±2} Nm
4	Hinge strap bracket	21 ^{±1} Nm
5	Bolt clamp	23 ^{±2} Nm
6	Diesel exhaust fluid injector	5 ^{±0.5} Nm
7	Temperature sensor, pressure sensor, differential pressure line, screw connection	35 ^{±5} Nm
8	NO _x sensor, NH ₃ sensor	50 ^{±10} Nm

Tab. 63: Tightening torques

LBH/12252628/03/211-20200327_070249/en




Fig. 147: Coolant diagram

- A** Freezing point - orange scale: top up with pure antifreeze and corrosion inhibitor
- B** Freezing point - blue scale: top up with pure water
- C** Total capacity of the cooling system
- D** Amount to top up

- ▶ Enter identified freezing point on the orange scale **A** or the blue scale **B**.
- ▶ Enter the total capacity of the cooling system **C**.
- ▶ From where the two lines cross, follow a horizontal line to read off the amount to top up **D**.

Example 1:

- ▶ Identified freezing point = -29 °C.
- ▶ Total capacity of the cooling system = 60 l.
 - ▷ Freezing point too high.
 - ▷ Amount of pure antifreeze and corrosion inhibitor to top up = 6,5 l.

LBH/12252628/03/211-20200327_070249/en

- ▶ Screw in the breather filter 2.
- ▶ Remove the plug 1 for protection against unauthorised opening, and keep it in a safe place.

030.4.6.2 Draining off condensate and sediment from the hydraulic tank

Valid for: L586-1761;

Make sure that the following requirements are fulfilled:

- The machine has not been started for at least an hour.
- The machine is in maintenance position 1.
- The service hatches are open.

Make sure that the following tools are ready:

- Drain hose
- Receptacle




Fig. 156: Draining off condensate and sediment from the hydraulic tank

- | | | | |
|---|-----------------|---|----------------------------|
| 1 | Breather filter | 3 | Hydraulic tank drain valve |
| 2 | Connector | | |



Note

To completely drain the condensate and sediment, the impurities must settle on the bottom of the hydraulic tank.

- ▶ Do not start the machine for at least an hour.

- ▶ Insert the plug 2 in the breather filter 1.
 - ▷ The anti-twist device is released.
- ▶ Unscrew the breather filter 1 by two turns.
 - ▷ The tank preload pressure is released.
- ▶ Place a receptacle under the machine.
- ▶ Unscrew the cap from the drain valve 3.
- ▶ Screw the drain hose onto the drain valve 3.
 - ▷ Condensate and sediment drain off.
- ▶ Let the condensate and sediment drain into the receptacle.

When clean hydraulic oil comes out:

- ▶ Unscrew the drain hose from the drain valve 3.
- ▶ Screw the cap onto the drain valve 3.

Checking the front axle brake discs for wear




Fig. 168: Checking the front axle brake discs for wear

- 1 Screw plug
- 2 Micrometer

► Unscrew the plug 1 on the left wheel hub of the front axle.




Fig. 169: Checking the front axle brake discs for wear

- 2 Micrometer
- 3 Inching brake pedal

► Have somebody fully depress and hold down the brake pedal.
 ▷ The brake discs are in the end position.

► Screw in the micrometer 2 by hand as far as it will go (maximum tightening torque 0.5 Nm).

► Mark the position of the micrometer 2.




Fig. 170: Checking the front axle brake discs for wear

- 2 Micrometer
- 3 Inching brake pedal

LBH/12252628/03/211-20200327_070249/en

2	Front working headlights	8	Engine bonnet working headlight
3	Marker light (optional)	9	Brake light, tail light, rear indicator
4	Front indicator light	10	Reversing light
5	Driving headlights	11	Flash (optional)
6	Front section working headlight (optional)	12	License plate light (optional)

- ▶ Turn on all the lights.
- ▶ Check all the lights work properly.

When you are checking the brake light:

- ▶ Press the inching brake pedal.

To check the reversing light:

- ▶ Start the machine.
- ▶ Release the parking brake.
- ▶ Select reverse travel direction.
- ▶ Test the reversing light.

If lights have to be adjusted or defective bulbs replaced:

- ▶ Contact Liebherr customer service.

To test the horn:

- ▶ Activate the horn using the button on the steering column switch.

030.4.9.2 Batteries: Checking the acid level and terminals

Valid for: L586-1761;

The batteries are housed in the ballast weight and can be accessed by opening the ballast cover.

The batteries must always be in perfect condition in order for the machine to work reliably.

Make sure that the following requirements are fulfilled:

- The machine is in maintenance position 1.
- The battery main switch is off.
- The battery main switch key has been taken out.
- The ballast cover is open.

Make sure that the following tools are ready:

- Safety glasses
- Acid-resistant gloves
- Terminal brush
- Refractometer (item code: 11830573)
- Battery plug tool (item code: 11839123)

Make sure that the following equipment is ready:

- Distilled or demineralised water (DIN 43530)

Topping up oil




Fig. 189: Topping up oil and checking oil level

- | | | | |
|---|-----------------|---|------------|
| 1 | Oil sight glass | 4 | HOT range |
| 2 | Cap | 5 | COLD range |
| 3 | Filling tube | | |

- ▶ Top up oil through filling tube 3 until oil reaches top of COLD 5 range.
- ▶ Close cap 2.
- ▶ Start diesel engine and let it run for two minutes at low idling speed.
 - ▷ Oil is circulated.



WARNING

Unintended movement of machine!
Injury.

- ▶ Make sure that parking brake is activated.
- ▶ Make sure there is nobody in operator's cab.

NOTICE

Oil level indicator will not show right value if machine is on a slope!
Incorrect oil level indicated.

- ▶ Make sure machine is parked on completely level ground when checking oil level.

- ▶ With diesel engine running, check whether oil level is in COLD range 5.

If oil level is too low:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Top up oil.

If oil level is too high:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Drain oil.

If oil level is correct:

- ▶ Bring gear oil up to operating temperature. (For more information see: [Gear oil operating temperature, page 030-173](#))

Cleaning the recirculated air filter




Fig. 210: Cleaning the recirculated air filter

- | | | | |
|---|------------------|---|-------------------------|
| 1 | Filter cartridge | 3 | Recirculated air filter |
| 2 | Pre-filter | 4 | Knurled screw |































- ▶ Unscrew the knurled screw **4**.
 - ▷ The filter cartridge **1** is unlocked.
- ▶ Move the filter cartridge **1** forward and take it out.
- ▶ Take the pre-filter **2** out of the filter cartridge **1** and clean it (by blowing it out or washing it).
- ▶ Take out the recirculated air filter **3** and clean it (blow it out).
- ▶ Put in the clean recirculated air filter **3**.
- ▶ Put the pre-filter **2** into the filter cartridge **1** and fit them.
- ▶ Screw in the knurled screw **4**.
 - ▷ The filter cartridge **1** is locked.

030.4.14.2 Operator's cab: changing fresh air filter and recirculated air filters

Valid for: L586-1761;

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 1.
- The right cab access is extended.
- Suitable protective equipment is used.

2. Calibrations									
Test / adjustment	1000 h	2000 h	Unit	Required value	Measured	Adjusted	Adjusting point	Test point	Figure
Working hydraulics									
Multi-lever control (option): calibration 									
Manual lever calibration		○							
Calibrating working hydraulics angle sensors 									
Manual calibration of lift arm position angle sensor		○							
Manual calibration of bucket position angle sensor		○					 		
Proportional solenoids in control valve block: calibration 									
Automatic calibration of proportional solenoids for lifting and tilting		○							
Manual calibration of proportional solenoids for 3rd function (option)	◇	◇							
Manual calibration of proportional solenoids for 4th function (option)	◇	◇							
Steering system									
Joystick for joystick steering (option): calibration 									
Automatic calibration of joystick		○							
Angle sensor for articulation angle (option): calibration									
Machine with steering wheel steering: 									
Machine without steering wheel steering: 									
Manual calibration of articulation angle sensor		○							
Control block for joystick steering (option): calibration 									
Automatic calibration of position sensor of main spool valve		○							
Manual calibration of position sensor of emergency spool valve (using steering joystick)		○							
Automatic calibration of proportional solenoids for main spool valve and emergency spool valve		○							

LBH/12252628/03/211-20200327_070249/en

Manual calibration of travelling pedal

- ▶ Set the **MXThrottlePdIStartAdjust** variable to **1**.
 - ▷ The calibration function is active for 8 seconds.
- ▶ Fully depress the travelling pedal within 8 seconds and then release it.
- ▶ Wait until the variable **MXThrottlePdIStartAdjust** returns to **0**.
 - ▷ Calibration is completed.
- ▶ Check that the calibration was successful.

Checking whether calibration is successful

- ▶ Check whether the value of the **PRMaAnThrottlePdIRequest** variable corresponds to the required value when the travelling pedal is not pressed and when it is fully depressed.

Description	Unit	Value
Variable with the travelling pedal not pressed	%	0
Variable with the travelling pedal fully depressed	%	100

If a required value is not reached:

- ▶ Repeat the calibration.

If the required values are reached:

- ▶ Calibration was successful. Calibrate the inching function.

Manual calibration of the inching function

- ▶ Set the **MXInchPdIStartAdjust** variable to **1**.
 - ▷ The calibration function is active for 8 seconds.
- ▶ Fully depress the inching brake pedal within 8 seconds and then release it.
- ▶ Wait until the variable **MXInchPdIStartAdjust** returns to **0**.
 - ▷ Calibration is completed.
- ▶ Check that the calibration was successful.

Checking whether calibration is successful

- ▶ Check whether the value of the **PRMaAnInchPdIRequest** variable corresponds to the required value when the inching brake pedal is not pressed and when it is fully depressed.

Description	Unit	Value
Variable with inching brake pedal not pressed	%	100
Variable with inching brake pedal fully depressed	%	0

If a required value is not reached:

- ▶ Repeat the calibration.

If the required values are reached:

- ▶ Calibration was successful. Switch off ignition.

Automatic calibration of the proportional solenoids for lifting and tilting

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The machine is parked on level ground.

Make sure that the following tools are ready:

- Laptop with Sculi diagnostic software
- ▶ Start the diesel engine.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ In the variables editor, select the **Working hydraulics** folder.
- ▶ Select the **Calibrate angle proportional solenoids** sub-folder.
- ▶ Make sure that the parking brake is activated.
- ▶ Raise the lift arms half way.
- ▶ Tilt the bucket half way in.
- ▶ Set the variable **MXSWEEHStartValveAdjust** to **1**.
 - ▷ Calibration takes place automatically.
 - ▷ During the calibration there may be very slight movements of the lift arms.



Note

If the control lever is moved, the calibration is stopped!

- ▶ Do not move the control lever during calibration.

- ▶ Wait until the variable **MXSWEEHStartValveAdjust** returns to **0**.
 - ▷ Calibration is completed.

If a service code appears during the 1st attempt:

- ▶ Calibration has failed. Repeat the calibration.

If a service code appears during the 2nd attempt:

- ▶ Calibration has failed again. Carry out manual calibration of the proportional solenoids for lifting and tilting.
- ▶ Contact the technical customer service department.

If no service code appears:

- ▶ Calibration was successful. Turn off the diesel engine.

Manual calibration of the proportional solenoids for lifting and tilting



Note

Manual calibration for lifting and tilting is not necessary when the machine is working properly.

- ▶ Only carry out manual calibration for lifting and tilting if automatic calibration fails.

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The machine is in the maintenance position for adjustment procedures.

Make sure that the following tools are ready:

- Laptop with Sculi diagnostic software




Fig. 234: Control valve block: secondary pressure relief valves

- | | | | |
|---|--|----|--|
| 1 | Secondary pressure relief valve for tilting out | 5 | LS-pressure cut-off |
| 2 | Secondary pressure relief valve for tilting in | 6 | Primary pressure relief valve |
| 3 | Secondary pressure relief valve for lifting (main spool) | PA | Working pump high pressure test connection |
| 4 | Secondary pressure relief valve for lifting (additional spool) | | |

Preparations

- ▶ Connect a pressure gauge (600 bar) to high pressure test connection **PA** on control valve block.
- ▶ Turn adjusting screw on primary pressure relief valve **6** by exactly one turn clockwise.
 - ▷ Opening pressure of primary pressure relief valve is higher than that of secondary pressure relief valves.
- ▶ Turn adjusting screw on LS-pressure cut-off valve **5** by exactly one turn clockwise.
 - ▷ Opening pressure of LS-pressure cut-off valve is above opening pressure of secondary pressure relief valves.

Checking and adjusting

- ▶ Start diesel engine.



Fig. 241: Moist surfaces, no visible oil leak

- ▶ Document the damage and observe whether the condition deteriorates.
- If the condition deteriorates:
- ▶ Replace the hydraulic lines.

Medium damage to the hydraulic lines

Cracks or cuts up to the steel fabric or steel fabric exposed due to damage to the outer jacket

The damage to the outer jacket (such as cracks, cuts or abrasions) through which the steel fabric is exposed is classified as medium damage if the steel fabric is undamaged. Damage to the steel fabric is classified as severe damage.



Fig. 242: Cracks or cuts up to the steel fabric or steel fabric exposed due to damage to the outer jacket




Fig. 248: Steering pump flow regulator (standby pressure)

1 Flow regulator

PL Steering pump high pressure test connection

- ▶ Connect a pressure gauge (40 bar) to high pressure test connection **PL** on steering pump.
- ▶ Start diesel engine.
- ▶ Allow diesel engine to run at low idling speed.
 - ▷ Standby pressure can be checked at high pressure test connection **PL**.
- ▶ Check that standby pressure **PL** is correct.

Description	Unit	Value
Standby pressure PL	bar	25 ±2

If required value is not reached:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Adjust adjusting screw of flow regulator **1**.



Note

To adjust flow regulator:

- ▶ Turn adjusting screw clockwise to reduce standby pressure.
- ▶ Turning adjusting screw anti-clockwise increases standby pressure.

- ▶ Repeat check and adjustment until required value is reached.

If required value is reached:

- ▶ Turn off diesel engine and take out ignition key.
- ▶ Disconnect pressure gauge from high pressure test connection **PL**.

LBH/12252628/03/211-20200327_070249/en

sep02011

- ▷ Service file is created.
- ▷ Service file with current date **4** is displayed in list of service files **2**.
- ▶ Select corresponding service file from list of available service files **2**.
 - ▷ Corresponding service file is marked.
- ▶ Select “Export MDDb” function **3**.
- ▶ Save service file.
 - ▷ Service file is created in form of a zip file.

Troubleshooting

If no service file is displayed with current date **4**:

- ▶ Close Sculi diagnostic software.
 - ▶ Switch off ignition. Wait until all LEDs on the central control unit have gone out. Switch on ignition.
 - ▶ Repeat creation of service file.
-

030.6.9.2 Central control unit (Master5): software update

Valid for: L586-1761;

Machine software is transferred in form of a MSB file (Machine Software Bundle) to central control unit (Master5).

Each MSB file contains machine-specific serial number. As a result, a MSB file can only be transferred to the central control unit (Master5) of machine with corresponding serial number.

MSB file is created via the “MSB Online Tool”.

An Internet connection is required for the “MSB Online Tool”.

Internet address “MSB Online Tool”: <https://www.lidat.liebherr.com/MsbOnline>

Creating MSB file

Make sure following requirements are met:

- Internet connection is available.
- Corresponding permissions for the “MSB Online Tool” are available.
- ▶ Open “MSB Online Tool”.

Overview of CAN addresses (valid for Master5 software item code 12467218)		
Address	CAN module	CAN line
IA16 (45)	Analogue universal inputs, input module A16a	1
IF02 (53)	Frequency measurement inputs, input module A16a	1
IR02 (81)	Resistance measurement inputs, input module A16a	1
OA16 (22)	Analogue universal outputs, output module A17a	1
OD04 (14)	Digital outputs, output module A17a	1
SFTY (6)	Safety function, output module A17a	1
IF02 (50)	Frequency measurement inputs, output module A17a	1
KTSX (105)	Sensor for fuel level B25	1
MOA (92)	Engine control unit	1
MOD2 (93)		1
AGN (94)		1
AE16 (95)		1
IA16 (47)	Analogue universal outputs, input module (optional)	1
IF02 (55)	Frequency measurement inputs, input module (optional)	1
IR02 (83)	Resistance measurement inputs, input module (optional)	1
OA16 (23)	Analogue power outputs, output module (not used)	1
OD04 (15)	Digital outputs, output module (optional)	1
SFTY (7)	Safety function, output module (optional)	1
IF02 (51)	Frequency measurement inputs, output module (optional)	1
WGHT (108)	Weighing module (optional)	1
IA16 (48)	Analogue universal outputs, input module (optional)	1
IF02 (56)	Frequency measurement inputs, input module (optional)	1
IR02 (84)	Resistance measurement inputs, input module (optional)	1
IA16 (47)	Analogue universal inputs, input module A16b	2
IF02 (55)	Frequency measurement inputs, input module A16b	2
IR02 (83)	Resistance measurement inputs, input module A16b	2
IA16 (45)	Analogue universal inputs, input module A16L	2
IF02 (53)	Frequency measurement inputs, input module A16L	2
IR02 (81)	Resistance measurement inputs, input module A16L	2
JD (65)	Control lever	2
JA08 (66)		2
JD (67)	Module for joystick steering	2
JA08 (68)		2
IA16 (48)	Analogue universal inputs, input module A16M	2
IF02 (56)	Frequency measurement inputs, input module A16M	2

LBH/12252628/03/211-20200327_070249/en




Fig. 279: Tyres: setting radius

r Radius

U Circumference

**Note**

Tyre deformation due to weight of machine!
Incorrect measurement when measuring the radius.

- ▶ Measure the circumference if possible.
- ▶ When measuring the radius directly, only measure in the highlighted area.

- ▶ Measure circumference **U** of a tyre on the front axle and calculate the radius **r**: $r = U / (2 * \pi)$

or

Measure the radius **r** of a tyre directly at the front axle (centre of the axle to centre of the running surface).

- ▶ Switch on the ignition.
- ▶ Connect the Sculi diagnostic software to the machine.
- ▶ Enter the radius **r** in metres in the variable **CRSDCMachWheelRadius**.

030.6.12 Working attachment

030.6.12.1 Valve block for quick coupler (option): Pressure reducing valve

Valid for: L586-1761;

This equipment is optional.

Make sure that the following requirements are fulfilled:

- The hydraulic oil is at operating temperature.
- The machine is in the maintenance position for adjustment procedures.

Make sure that the following tools are ready:

- Pressure gauge (600 bar)




Fig. 292: Saving, sending, printing report

- | | | | |
|---|----------------------------|---|------------------|
| 1 | “Executing Report” display | 4 | “Send” function |
| 2 | Window | 5 | “Print” function |
| 3 | “Save” function | | |

- ▶ Check whether report was successfully created.
 - ▷ “Executing Report” 1 display turns steady red.
 - ▷ Window 2 displays data.
 - ▷ “Save” 3, “send” 4 and “print” 5 functions can be selected.

- ▶ “Save” 3 report locally.

or

“Send” 4 report as email.

or

“Print” 5 report.

Creating snapshot

- ▶ Connect to the LiDAT module. (For more information see: [LiDAT: connecting to LiDAT module, page 030-249](#))

The exhaust throttle valve acts as an engine brake under the following conditions:

- When the machine is in engine braking mode (negative torque).
- When the diesel engine exceeds a defined speed threshold.

040.1.2 Electrical components of diesel engine

Valid for: L586-1761;

1 Layout



Note

The BMK codes used refer to the electrical diagram of the diesel engine.




Fig. 319: Electrical components of diesel engine

Position	Component	Position	Component
A700	Engine control unit	B730	Engine oil level sensor
B701	Oil pressure sensor	E703	Heating flange
B702	Fuel pressure sensor	F700	Heater flange response fuse
B704	Rail pressure sensor	F705	Fuse for signal B+
B707	Charge air temperature sensor	G700	Alternator
B709	Fuel temperature sensor	Y703	High pressure pump VCV
B711	Engine speed sensor	Y707	High pressure pump PCV
B713	Camshaft speed sensor	Y760	Compressor coupling

The fuel cooler 9 cools the returning fuel. The fuel temperature must not exceed 60 °C.

2.2 Diagram of the fuel system on the diesel engine




Fig. 330: Diagram of the fuel system on the diesel engine

- | | | | | | |
|---|---------------------------|----|----------------------------------|----|-----------------------|
| 1 | Injection nozzles | 6 | Distributor rail | 11 | Fuel low pressure |
| 2 | Engine control unit (ECU) | 7 | Fuel from the fuel tank | 12 | Fuel high pressure |
| 3 | High-pressure fuel pump | 8 | Return line to fuel tank | 13 | Fuel return (leakage) |
| 4 | Fuel pre-delivery pump | 9 | High-pressure line (common rail) | | |
| 5 | Fuel fine filter | 10 | Fuel suction side | | |

The fuel pre-delivery pump 4 draws up fuel via the fuel pre-filter and the common rail 6.

The fuel pre-delivery pump 4 delivers the fuel via the engine control unit (ECU) 2 to the fuel fine filters 5.

The fuel goes from the fuel fine filter 5 to the high-pressure fuel pump 3.

The high-pressure fuel pump 3 delivers the fuel under high pressure to the high-pressure line (common rail) 9. The high-pressure line (common rail) 9 distributes the fuel to the injection nozzles 1.

The fuel is injected through the injection nozzle 1 to the combustion chamber.

The fuel injection is regulated by the engine control unit 2.

Unused fuel flows back through the fuel return (leakage) line 12 to the fuel tank.

LBH/12252628/03/211-20200327_070249/en

2.3 Function




Fig. 339: Function

- | | | |
|--|---|---|
| 1 Diesel engine | 8 Temperature sensor at DOC inlet B723 | 15 Slip catalyst (CUC) |
| 2 Exhaust throttle valve | 9 Diesel oxidation catalyst (DOC) | 16 Differential pressure sensor B722 |
| 3 Air filter | 10 Diesel exhaust fluid nozzle | 17 Temperature sensor at outlet of SCR catalytic converter B772 |
| 4 Metering unit | 11 Temperature sensor at intake of SCR catalytic converter B771 | 18 NO _x sensor at outlet of the SCR catalytic converter B727 |
| 5 Air from the compressed air system | 12 Mixing section | 19 NH ₃ sensor B783 |
| 6 Diesel exhaust fluid tank | 13 Filter module (SCR + DPF) | |
| 7 NO _x sensor in front of the DOC B771a | 14 SCR catalytic converter (SCR) | |

Exhaust gas treatment is achieved by selective catalytic reduction (SCR) and a diesel particulate filter (DPF).

The exhaust gas from the diesel engine flows through the throttle valve 2 to the diesel oxidation catalyst (DOC) 9.

The diesel oxidation catalyst (DOC) 9 consists of a substrate with an oxidation coating. The diesel oxidation catalyst increases the NO₂ share in the exhaust gas. This improves the regeneration of the filter module 13. During the active regeneration, fuel (HC) is injected into the exhaust line. This triggers an exothermal reaction in the DOC. The exhaust temperature rises up to 540 °C.

g2073006

LBH/12252628/03/211-20200327_070249/en

2.5 Diesel exhaust fluid injection




Fig. 348: Diesel exhaust fluid injection

- | | |
|-----------------------------|---|
| 1 Diesel exhaust fluid tank | 4 Diesel exhaust fluid pressure and temperature sensor A776.4 |
| 2 Diesel exhaust fluid pump | 5 Diesel exhaust fluid nozzle |
| 3 Metering unit | |

The diesel exhaust fluid pump 2 draws up diesel exhaust fluid from the diesel exhaust fluid tank 1.

The diesel exhaust fluid is directed via the metering unit 3 to the diesel exhaust fluid nozzle 5.

The diesel exhaust fluid temperature sensor 4 measures the pressure and the temperature of the fluid in the metering unit.

In the nozzle, the diesel exhaust fluid is mixed with compressed air. This makes the spray finer and distributes it more evenly through the mixing section.

2.6 Exhaust throttle valve




Fig. 349: Exhaust throttle valve

- | | |
|--------------------------|-----------|
| 1 Exhaust throttle valve | 3 Linkage |
| 2 Servo motor M715 | |

The exhaust throttle valve is mainly used for thermal management of the engine.

040.1.8.3 Air dryer

Valid for: L586-1761;




Fig. 361: Air dryer

- | | | | |
|---|-------------------------------------|----|---------------------|
| 1 | Filter cartridge | 7 | Pressure controller |
| 2 | Compressed air from the compressor | 8 | Fine filter |
| 3 | Regeneration accumulator | 9 | Granulate filter |
| 4 | Compressed air accumulator | 10 | Check valve |
| 5 | Pressure controller adjusting screw | 11 | Restrictor port |
| 6 | Drain valve | 12 | Silencer |

The air dryer is installed in the right ballast weight.

2.1 Function

The outside air drawn in by the compressor always contains a certain amount of moisture. This moisture can damage the compressed air system. Therefore, an air dryer is fitted behind the compressor. The air dryer reduces the humidity in the compressed air system.

Compressed air flows from the compressor 2 to the air dryer. The compressed air flows through the fine filter 8 and the granulate filter 9. The granulate in the filter removes moisture from the compressed air.

The dried air flows through the check valve 10 to the compressed air accumulator 4. At the same time, compressed air flows through restrictor port 11 to the regeneration accumulator 3.

The pressure controller 7 is set to 10 bar. If the pressure behind the check valve rises above 10 bar, the pressure controller cuts in. This actuates the drain valve 6.

When the drain valve 6 is actuated, compressed air from the compressor escapes through the silencer 12 to the outside. This lowers the pressure at the check valve 10. The check valve closes.

The drop in pressure in front of the check valve causes dry air from the regeneration accumulator 3 to flow through the restrictor port 11 via the filters 9 and 8 through the drain valve 6 and the silencer 12 to the outside.

- | | | | | | |
|----------|--------------------------------------|-----------|---------------------------------------|-----------|---------------------------------|
| 2 | Return flow from control valve block | 8 | Oil supply for compact brake valve | 14 | Compact brake valve return flow |
| 3 | Return filter | 9 | Working pump suction port | 15 | Return flow from servostat |
| 4 | Breather filter | 10 | Working pump suction port drain valve | 16 | Hydraulic oil cooler |
| 5 | Sight glass for hydraulic oil level | 11 | In-line filter 80 µm | | |
| 6 | Fan pump | 12 | Fan motor | | |

Name	Test point
PK	Cooling system high pressure

Tab. 95: Test points

BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	Y13	Fan speed proportional solenoid

Tab. 96: Equipment codes

Thresholds		
Temperature limits	Current to proportional solenoid	System pressure (at engine speed of 1750 min ⁻¹)
Hydraulic oil	88 °C	Minimum current (standard setting: 600 mA)
Coolant	99 °C	
Charge air	80 °C	
Gear oil	88 °C	
		100 ^{±10} bar

Tab. 109: Thresholds

If a limit is exceeded, it has following effects:

- Current applied to fan speed proportional solenoid **Y13** is reduced to minimum level.
- A warning sound goes off.
- A service code is displayed.
- For the coolant and charge air, power output of diesel engine is also reduced.
- For the transmission, emergency mode is activated.

2.4 Sensor failure

If temperature sensor for hydraulic oil **B8** or temperature sensor for gear oil **B86** fails, proportional solenoid for fan speed **Y13** is energised with minimum current (default value: 600 mA).

Minimum current can also be adjusted by means of variable **CRFCFanCurrMin** in Sculi diagnostic software.

Description	Current at proportional solenoid (standard setting)	System pressure
Sensor failure B8 or B86	600 mA	100 ^{±10} bar

Tab. 110: Sensor failure

If temperature sensor for air intake **B707** or temperature sensor for coolant **B708** fails, a substitute value is used. Control of fan speed is performed using remaining sensors.

Description	Substitute value in case of sensor failure
Temperature sensor for charge air B707	-100 °C
Temperature sensor for coolant B708	-100 °C

Tab. 111: Sensor failure

Name	Test point	Name	Test point	Name	Test point
MT	Servo pressure for tilt-out function	PA^{A)}	Working pump high pressure		

Tab. 117: Test points

- A) Test point on working pump
 B) Test point on control valve block

BMK	Function	BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	B91	Pressure sensor for lift cylinder ring side	B93	Pressure sensor for tilt cylinder ring side
B90	Pressure sensor for lift cylinder piston side	B92	Pressure sensor for tilt cylinder piston side		

Tab. 118: Equipment codes

Working hydraulics consist of following components:

- Hydraulic tank (For more information see: [080.2.1 Overview of hydraulic tank, page 080-6](#))
- Working pump (For more information see: [060.2 Working pump, page 060-7](#))
- Control block (For more information see: [060.3 Control block for Z-bar kinematics, page 060-15](#))
- Pilot control (For more information see: [060.4.1 Pilot control valve block, page 060-24](#))
- Ride control (For more information see: [060.5.1 Overview of ride control system, page 060-26](#))
- Lift cylinder
- Tilt cylinder

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2.4 Power regulator




Fig. 391: Power regulator characteristic

- | | |
|---|--|
| P Pump pressure in bar | B Maximum flow rate |
| Q Flow rate in litres per minute | C Maximum pressure at maximum flow rate |
| 1 Output curve (hyperbola) | D Maximum flow rate with pressure cut-off activated |
| A LS-pressure cut-off | |

Power regulator prevents a certain drive power from being exceeded. Power regulator restricts drive power along an output curve 1 of flow rate x high pressure. Output curve 1 is a shape of a hyperbola (hyperbolic control).




Fig. 392: Power regulator inactive / power regulator active (at maximum swivel angle)

- | | | |
|-----------------------------|---------------------------------------|---|
| 1 Positioning piston | 4 Connection to flow regulator | 7 Connection to operating pressure |
| 2 Piston with roller | 5 Power regulator | |
| 3 Regulating lever | 6 Regulating spring | |

The operating pressure 7 acts via ring face of piston 2 on regulating lever 3 and thus moves power regulator 5 against regulating piston spring 6. During this process, torque with which regulating lever 3 acts on power regulator 5 increases as angle of axial tapered piston rotary group increases. When axial tapered piston rotary group is at a large angle (= greater flow rate), less pressure is required to exert same force on power regulator 5 than when axial tapered piston rotary group is at a narrow angle.

When set drive power is exceeded, regulating lever 3 is moved so far out that power regulator 5 connects flow regulator 4 to operating pressure 7 on all connections. Flow regulator 4 therefore always connects return piston to operating pressure 7, regardless of its position. This moves rotary group to a smaller angle and drive power taken off is reduced.

LBH/12252628/03/211-20200327_070249/en

Tilt out and lowering functions also have additional replenishing valves **10** and **19**.

Feeder valves prevent cavitation during rapid working movements by allowing oil to flow from tank side to consumers. Cavitation can occur, for instance, when lifting arms are rapidly lowered. As lifting arms are lowered under their own weight, no load is created. Consequently, working hardly moves out and delivers too little oil.

2.10 Preload valve for 2nd tank duct

There are two tank channels running through control valve block **1**. Tank duct 1 is connected to hydraulic tank **67**. Tank duct 2 is connected to tank duct 1 by preload valve for 2nd tank duct **3**. This valve has a preload pressure of 8 bar to 10.8 bar in 2nd tank duct. This means that if cavitation occurs, oil flows more quickly to consumers via replenishing valves.

060.6 Electronics of the working hydraulics

060.6.1 Overview of electrical controls the working hydraulics

Valid for: L586-1761;

1 Layout




Fig. 402: Overview of electrical controls the working hydraulics

1 Lift arms

2 Control block

BMK	Function	BMK	Function
A15	Central control unit	Y32a	Proportional solenoid for lowering
A17a	Output module A17a	Y32b	Proportional solenoid for lifting
A26	CAN module for control lever	Y33a	Proportional solenoid for 3rd function A3
B60	Angle sensor for bucket position	Y33b	Proportional solenoid for 3rd function B3
B61	Angle sensor for lift arm position	Y34a	Proportional solenoid for 4th function A4
Y31a	Proportional solenoid for tilting out	Y34b	Proportional solenoid for 4th function B3
Y31b	Proportional solenoid for tilting in		

Tab. 142: Equipment codes

LBH/12252628/03/211-20200327_070249/en

1 Layout




Fig. 409: Pipe break protection valve block (lift cylinder)

- | | |
|--|---|
| 1 Safety valve and pipe break protection valve | 5 Return flow to leak oil strainer |
| 2 Pilot control valve | 6 Connection to other valve block for pipe break protection |
| 3 Oil supply through control valve block | 7 Connection for lift cylinder piston side |
| 4 Pilot control valve for lowering (control block) | |

Name	Test point
X	Venting connection

Tab. 149: Test points

One valve block for pipe break protection is installed on each lift cylinder.

2 Function




Fig. 410: Valve block for pipe break protection: hydraulic diagram

- | | |
|---|--|
| 1 Valve block for pipe break protection | 7 Pilot control valve for lowering (control block) |
|---|--|

See next page for continuation of the image legend

LBH/12252628/03/211-20200327_070249/en

BMK	Function
B8	Hydraulic oil temperature sensor

Tab. 155: Equipment codes

Hydraulic tank is fitted behind cooling system.

Hydraulic tank consists of following components:

- Steel tank (For more information see: 080.2.2 Steel tank, page 080-8)
- Return filter (For more information see: 080.2.3 Return filter, page 080-10)
- Breather filter (For more information see: 080.2.5 Breather filter, page 080-11)
- Leak oil strainer (For more information see: 080.2.4 Leak oil strainer, page 080-11)
- Drain valves
- Hydraulic oil temperature sensor B8 (For more information see: 050.3.2 Hydraulic oil temperature sensor, page 050-16)

2 Function




Fig. 416: Hydraulic tank diagram

- | | |
|---|--|
| 1 Hydraulic tank | 13 Hydraulic tank drain valve |
| 2 Return filter | 14 Emergency steering pump suction port |
| 3 Main filter element 10 µm | 15 Fan pump and brake pump suction port |
| 4 Bypass valve 2.5 bar | 16 Working pump suction port drain valve |
| 5 Strainer mesh 100 µm | 17 Working pump suction port |
| 6 Breather filter | 18 Steering pump suction port |
| 7 Fine filter | 19 Fan motor leak oil |
| 8 Outlet valve 0.65 bar | 20 Return flow from compact brake valve and pilot control |
| 9 Inlet valve 0.03 bar | 21 Leak oil from steering pump and working pump |
| 10 Leak oil strainer 100 µm | 22 Return flow from hydraulic oil cooler |
| 11 Steel tank | 23 Return flow from control valve block |
| 12 Sight glass for hydraulic oil level | |

090.1 Steering system overview

Valid for: L586-1761;

1 Layout




Fig. 426: Steering system (steering to left)

- | | | | | | |
|---|--------------------------------------|----|---------------------------------|----|---|
| 1 | Hydraulic tank | 7 | Steering pump | 13 | Steering stabilisation valve block |
| 2 | Return filter | 8 | Valve block for steering system | 14 | Steering damper hydro accumulator |
| 3 | Breather filter | 9 | Hydraulic oil cooler | 15 | Steering damper hydro accumulator |
| 4 | Return flow from control valve block | 10 | Collector pipe | 16 | Left steering cylinder with stroke limit damping |
| 5 | Sight glass for hydraulic oil level | 11 | Return line from fan motor | 17 | Right steering cylinder with stroke limit damping |
| 6 | Emergency steering pump | 12 | Servostat | | |

sle02001

LBH/12252628/03/211-20200327_070249/en

090.3 Servostat

Valid for: L586-1761;

1 Layout




Fig. 436: Servostat (from front left and from front right)

- | | | | |
|---|---|----|--|
| 1 | Secondary pressure relief valve for steering to left | 7 | Feeder valve for steering to left |
| 2 | Connection for steering wheel shaft | 8 | Feeder valve for steering to the right |
| 3 | Secondary pressure relief valve for steering to right | 9 | Connection for steering to left |
| 4 | Return flow to collector pipe | 10 | Connection for steering to the right |
| 5 | Oil supply from steering pump | 11 | Load sensing signal to working hydraulics pump |
| 6 | Metering pump | | |

Servostat is bolted underneath cab floor.




Fig. 437: Secondary pressure relief valve: secondary pressure relief valve

- | | | | |
|---|---------------------------------|---|---------------------------------|
| 1 | Secondary pressure relief valve | 3 | Connection to steering cylinder |
| 2 | Compression spring | 4 | Connection to tank port |

090.5.2 Emergency steering pump

Valid for: L586-1761;

1 Layout




Fig. 449: Emergency steering pump (from front left)

- 1 Suction port from hydraulic tank 2 Oil supply to servostat 3 Gear pump

BMK	Function
M8	Electric motor for emergency steering pump

Tab. 166: Equipment codes

Emergency steering pump is mounted in frame of rear section level with right ballast weight.

The emergency steering pump consists of a gear pump **3** with a pressure relief valve and electric motor **M8**.

090.6 Joystick steering

090.6.1 Joystick steering: overview (combined with steering wheel steering)

Valid for: L586-1761;

This equipment is optional.

1 Layout

Joystick steering consists of following components:

- Hydraulic tank (For more information see: 080.2.1 Overview of hydraulic tank, page 080-6)
- Steering pump (For more information see: 090.2 Steering pump, page 090-7)
- Servostat (For more information see: 090.3 Servostat, page 090-13)
- Joystick steering control valve block (For more information see: 090.6.3 Joystick steering control valve block, page 090-40)
- Steering cylinder (For more information see: 090.4.1 Steering cylinder, page 090-16)
- Steering stabilisation valve block (For more information see: 090.4.2 Steering stabilisation valve block, page 090-17)
- Emergency steering (For more information see: 090.5.1 Emergency steering overview, page 090-21)
- Hydraulic oil cooler

- | | | | | | |
|---|-------------------------------|----|--|----|-----------------|
| 5 | Throttle check valve | 12 | Load sensing signal to working hydraulics pump | 19 | Shuttle valve 2 |
| 6 | Return flow to collector pipe | 13 | Servo oil strainer for main spool valve | | |
| 7 | Oil supply from steering pump | 14 | Emergency spool valve | | |

Name	Test point
M A1	Servo pressure for steering to the left (main spool valve) A)

Tab. 177: Test points

A) Thread M10x1

BMK	Function	BMK	Function	BMK	Function
B70	Main spool valve position sensor	Y70	Proportional solenoid for steering to the left (main spool valve)	Y73	Proportional solenoid for steering to the right (emergency spool valve)
B71	Emergency spool valve position sensor	Y71	Proportional solenoid for steering to the left (spool valve for emergency steering function)		

Tab. 178: Equipment codes

The joystick steering control valve block is mounted in the vehicle frame on the left side of the vehicle, just in front of the rear axle.

090.6.4.2 Joystick with position tracking

Valid for: L586-1761;

1.1 Layout




Fig. 467: Joystick with position tracking

1 Joystick

BMK	Function	BMK	Function
A29a	Joystick electronics	S72	Joystick steering switch (armrest)
S2e	Travel direction switch joystick	X71s	Plug connection for joystick
S71 ^{A)}	Joystick steering switch		

Tab. 185: Equipment codes

A) Does not apply to joystick steering without steering wheel steering

Joystick with position tracking is located on left armrest.

LBH/12252628/03/211-20200327_070249/en

2 Function

2.1 Basic function




Fig. 473: Hydraulic diagram of brake system (parking brake activated)

- | | | | | | |
|----|-------------------------------------|----|---------------------------------------|----|---|
| 1 | Hydraulic tank | 18 | Return flow from control valve block | 39 | Pressure regulator piston for 1st brake circuit |
| 2 | Return filter | 19 | Emergency steering pump suction port | 40 | Return flow from pilot control |
| 3 | Main filter element 10 µm | 20 | Working pump suction port drain valve | 41 | Return flow to collector pipe |
| 4 | Bypass valve 2.5 bar | 21 | Working pump suction port | 42 | Parking brake hydro accumulator |
| 5 | Strainer mesh 100 µm | 22 | Diesel engine | 43 | Hydro accumulator for service brake (2nd brake circuit) |
| 6 | Breather filter | 23 | Fan pump | 44 | Hydro accumulator for service brake (1st brake circuit) |
| 7 | Fine filter | 24 | Brake pump | 45 | Hydro accumulator for service brake (2nd brake circuit) |
| 8 | Outlet valve 0.65 bar | 25 | Fan motor oil supply | 46 | Hydro accumulator for service brake (1st brake circuit) |
| 9 | Inlet valve 0.03 bar | 30 | Compact brake valve | 47 | Oil supply for pilot control |
| 10 | Leak oil strainer 100 µm | 31 | Inlet restrictor | 48 | Orifice |
| 11 | Steel tank | 32 | Accumulator charge valve | 49 | Parking brake (disc brake) |
| 12 | Sight glass for hydraulic oil level | 33 | Pilot valve | 50 | Front axle |
| 13 | Hydraulic tank drain valve | 34 | Inlet check valve | 51 | Service brake, 1st brake circuit (wet disc brake) |
| 14 | Steering pump suction port | 35 | Inverted shuttle valve | 52 | Service brake, 1st brake circuit (wet disc brake) |
| 15 | Fan motor leak oil | 36 | Check valve for parking brake | 55 | Rear axle |

See next page for continuation of the image legend

LBH/12252628/03/211-20200327_070249/en

At same time, oil flows through connecting ducts **8** and **12** to readjusting springs. When oil pressure in brake circuits is high enough, oil pressure and return springs push pressure regulating pistons back against pressure regulating spring **14**. Connection to hydro accumulators is interrupted again. This maintains a steady braking pressure in brake circuits as long as pedal position remains unchanged.

If inching brake pedal **1** is pushed down further, oil pressure also increases in brake circuits and higher oil pressure is required to push pressure regulator pistons back against pressure regulator spring **14**.

2.6 Parking brake

When parking brake solenoid valve Y10 is energised, oil flows from parking brake hydro accumulator to disc brake. Parking brake disengages.

2.7 Brake light pressure switch

Pressure switch for brake light B12 in 2nd brake circuit switches on brake light at a brake pressure of 5 ± 0.5 bar.

2.7.1 Brake accumulator pressure sensor

Brake accumulator pressure sensor B19 measures pressure in hydro accumulator of service brake and sends this to central control unit. If pressure falls below a set value, *brake accumulator pressure too low* symbol appears in display.

In service brake, brake pressure constantly increases up to cut-out pressure and then slowly and steadily falls back to cut-in pressure. If value that central control unit receives from brake accumulator pressure sensor is not plausible or not constant for a certain time, central control unit detects a faulty sensor and generates a service code.

110.3 Circuit diagrams

Valid for: L586-1761;

The circuit diagrams for the electrical system show the functional sequences for the entire machine, including optional attachments. Options in the circuit diagrams are shown in green. All components and connectors are correctly labelled and shown with the appropriate symbol so that they can be clearly identified. The key contains an additional list of the components with their designations.



The wiring diagrams can also be called up in the spare parts programme LIDOS under electrical system assemblies. These can be opened in an e3v format via the info button next to assembly circuit diagram.

The circuit diagrams are divided up as follows:

- Overview chart
- Contents
- Key
- BMK list
- Circuit diagrams
- Component overviews

The circuit diagrams contain links that can be activated with a mouse click.

1.1.1 Abbreviations

Abbreviation	Designation
SH	Service hours
EP	Electroproportional
WH	Wiring harness
LED	LED
LFD	Liebherr ride control system
SV	Solenoid valve
PWM	Pulse width modulation (proportional output)
PSV	Proportional solenoid valve
BMK	Equipment code

Tab. 203: Abbreviations

1.1.2 Designation of components with “-”

The designations of the components and connectors are always shown with “-”, e.g.:

Description	Component designation
-A10	Display

Tab. 204: Example of component designation

1.1.3 Location code with “+”

Location codes are always shown with “+”. The location code shows where the component is situated in the machine.

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-B93.X	=V	+V3	CONNECTOR PRESSURE SENSOR TILT CYLINDER RING SIDE	=K	+K	CONNECTOR INTERIOR ILLUMINATION	/109.D8
-B581	=B	+B	HEATING AIR DRYER	=K	+K	CONNECTOR INTERIOR ILLUMINATION	/52.D8
-B581.X	=B	+B	CONNECTOR AIR DRYER	=V	+V1	DRIVING HEADLIGHT LEFT	/52.D8
-B710	=M	+M	FUEL PRE-FILTER WATER SENSOR	=V	+V1	CONNECTOR DRIVING HEADLIGHT LEFT	/50.D8
-B710.X	=M	+M	CONNECTOR FUEL PRE-FILTER WATER SENSOR	=V	+V	CONNECTOR ADAPTER CABLE	/50.C8
-B722	=M	+M	SCR-F DIFERENTIAL PRESSURE SENSOR	=V	+V	CONNECTOR ADAPTER CABLE	/50.C7
-B722.X	=M	+M	CONNECTOR SCR-F DIFERENTIAL PRESSURE SENSOR	=V	+V1	LED DRIVING HEADLIGHT RIGHT	/50.C7
-B723	=M	+M	DOC INLET TEMPERATURE SENSOR	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/50.C4
-B723.X	=M	+M	CONNECTOR DOC INLET TEMPERATURE SENSOR	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/50.C4
-B726	=H	+H	SCR CATALYTIC CONVERTER INLET NOX SENSOR	=V	+V1	DRIVING HEADLIGHT RIGHT	/54.D5
-B726.X	=H	+H	CONNECTOR SCR CATALYTIC CONVERTER INLET NOX SENSOR	=V	+V1	CONNECTOR DRIVING HEADLIGHT RIGHT	/54.D5
-B727	=H	+H	SCR CATALYTIC CONVERTER OUTLET NOX SENSOR	=V	+V	CONNECTOR ADAPTER CABLE	/54.D6
-B727.X	=H	+H	CONNECTOR SCR CATALYTIC CONVERTER OUTLET NOX SENSOR	=V	+V	CONNECTOR ADAPTER CABLE	/54.D6
-B730.X	=M	+M	CONNECTOR ENGINE OIL PRESSURE	=V	+V1	LED DRIVING HEADLIGHT LEFT	/56.D3
-B737	=K	+K	AMBIENT TEMPERATURE SENSOR	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	/50.C5
-B737.X	=K	+K	CONNECTOR AMBIENT TEMPERATURE SENSOR	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	/50.C5
-B771	=M	+M	SCR CATALYTIC CONVERTER INLET TEMPERATURE SENSOR	=B	+B2	TAIL LIGHT RIGHT	/50.C1
-B771.SCR-F	=H	+H	DOC OUTLET TEMPERATURE SENSOR	=B	+B2	CONNECTOR TAIL LIGHT RIGHT	/50.C3
-B771.SCR-F.X	=H	+H	CONNECTOR DOC OUTLET TEMPERATURE SENSOR	=K	+K	MARKER LIGHT LEFT	/50.C3
-B771.X	=M	+M	CONNECTOR SCR CATALYTIC CONVERTER INLET TEMPERATURE SENSOR	=K	+K	MARKER LIGHT RIGHT	/50.C1
-B771a.X	=H	+H	CONNECTOR DOC OUTLET TEMPERATURE SENSOR	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/50.B3
-B772	=M	+M	SCR CATALYTIC CONVERTER OUTLET TEMPERATURE SENSOR	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/50.C2
-B772.X	=M	+M	CONNECTOR SCR CATALYTIC CONVERTER OUTLET TEMPERATURE SENSOR	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/50.C2
-B774	=H	+H	DIESEL EXHAUST FLUID TANK	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/55.D5
-B774.X	=H	+H	CONNECTOR DIESEL EXHAUST FLUID TANK	=V	+V	WORKING HEADLIGHT FRONT LEFT	/55.D5
-B783	=H	+H	NH3 SENSOR	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/55.D2
-B783.X	=H	+H	CONNECTOR NH3 SENSOR	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/55.D2
-CAN 2 + 3.X	=K	+K	CONNECTOR CAN	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/39.B8
-CAN 2 + 3.X	=K	+K	CONNECTOR CAN	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/39.B8
-CAN5.1.B	=K	+K	CONNECTOR CAN	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/123.C4
-CAN5.1.S	=K	+K	CONNECTOR CAN	=V	+V	WORKING HEADLIGHT FRONT RIGHT	/123.C4
-E1	=B	+B1	TAIL LIGHT LEFT	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/29.E3
-E1.X	=B	+B1	CONNECTOR TAIL LIGHT LEFT	=K	+K3	WORKING HEADLIGHT REAR LEFT	/29.E3
-E2	=K	+K	INTERIOR ILLUMINATION	=K	+K3	WORKING HEADLIGHT REAR LEFT	/27.E2
-E2.X1	=K	+K	CONNECTOR INTERIOR ILLUMINATION	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	/27.D2
-E2.X2	=K	+K	CONNECTOR INTERIOR ILLUMINATION	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	/27.D2

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-E2.X3	=K	+K	CONNECTOR INTERIOR ILLUMINATION	=V	+V1	CONNECTOR DRIVING HEADLIGHT LEFT	/115.E5
-E2.X4	=K	+K	CONNECTOR INTERIOR ILLUMINATION	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3	=V	+V1	DRIVING HEADLIGHT LEFT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT LEFT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3.Xa	=V	+V	CONNECTOR ADAPTER CABLE	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3.Xb	=V	+V	CONNECTOR ADAPTER CABLE	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3a	=V	+V1	LED DRIVING HEADLIGHT RIGHT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3a.X	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E3b.X	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT RIGHT	/115.E5
-E4	=V	+V1	DRIVING HEADLIGHT RIGHT	=V	+V1	CONNECTOR DRIVING HEADLIGHT RIGHT	/29.E6
-E4.X	=V	+V1	CONNECTOR DRIVING HEADLIGHT RIGHT	=V	+V1	CONNECTOR DRIVING HEADLIGHT RIGHT	/29.E5
-E4.Xa	=V	+V	CONNECTOR ADAPTER CABLE	=V	+V	CONNECTOR ADAPTER CABLE	/116.D6
-E4.Xb	=V	+V	CONNECTOR ADAPTER CABLE	=V	+V	CONNECTOR ADAPTER CABLE	/116.E6
-E4a	=V	+V1	LED DRIVING HEADLIGHT LEFT	=V	+V1	LED DRIVING HEADLIGHT LEFT	/115.D6
-E4a.X	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	/115.E6
-E4b.X	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	=V	+V1	CONNECTOR LED DRIVING HEADLIGHT LEFT	/115.E5
-E5	=B	+B2	TAIL LIGHT RIGHT	=B	+B2	CONNECTOR TAIL LIGHT RIGHT	/29.E7
-E5.X	=B	+B2	CONNECTOR TAIL LIGHT RIGHT	=K	+K	MARKER LIGHT LEFT	/29.E7
-E8	=K	+K	MARKER LIGHT LEFT	=K	+K	MARKER LIGHT RIGHT	/29.E4
-E9	=K	+K	MARKER LIGHT RIGHT	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/29.E6
-E10	=K	+K3	WORKING HEADLIGHT FRONT LEFT	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/31.D4
-E10.X	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	=K	+K3	WORKING HEADLIGHT FRONT LEFT	/31.D4
-E10a	=K	+K3	WORKING HEADLIGHT FRONT LEFT	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/31.D4
-E10a.X	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT LEFT	=V	+V	WORKING HEADLIGHT FRONT LEFT	/82.D5
-E10b	=V	+V	WORKING HEADLIGHT FRONT LEFT	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT LEFT	/82.D5
-E10b.X	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT LEFT	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/31.D6
-E11	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/31.D6
-E11.X	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	/31.D7
-E11a	=K	+K3	WORKING HEADLIGHT FRONT RIGHT	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/31.D7
-E11a.X	=K	+K	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	=V	+V	WORKING HEADLIGHT FRONT RIGHT	/82.D7
-E11b	=V	+V	WORKING HEADLIGHT FRONT RIGHT	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	/82.D7
-E11b.X	=V	+V	CONNECTOR WORKING HEADLIGHT FRONT RIGHT	=K	+K3	WORKING HEADLIGHT REAR LEFT	/81.D3
-E12	=K	+K3	WORKING HEADLIGHT REAR LEFT	=K	+K3	WORKING HEADLIGHT REAR LEFT	/81.D4
-E12.b	=K	+K3	WORKING HEADLIGHT REAR LEFT	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	/81.D4
-E12.b.X	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	/81.E3
-E12.X	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	=K	+K3	CONNECTOR WORKING HEADLIGHT REAR LEFT	/81.E3

12466553
ITEM CODE
DRAWING INDEX
000

GG 14 EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT
ISO 18016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	SERIAL NUMBER	BMK-INDEX	PAGE	OF
LIDOS Gerät	XXXXX	ELECTRICAL SCHEMATIC;	9	
			CREATION DATE	08.10.2019 15:49

BMK	SYSTEM	LOCATION	FUNCTION	LOCATION	SYSTEM	FUNCTION	PAGE
-V103	=K	+K	BLOCKING DIODE	+K	=K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	/101.D1
-V103	=K	+K2	FREE-WHEELING DIODE	+K2	=A4a	JUMPER HAZARD WARNING SYSTEM	/84.C7
-V104	=K	+K2	FREE-WHEELING DIODE	+K2	=K	CONNECTOR CAB FLOOR	/59.B5
-V200	=A4	+K	BLOCKING DIODE	+K	=K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	/100.C5
-V200	=K	+K	BLOCKING DIODE RECEIVING UNIT / CONTROL UNIT	+K	=K	CONNECTOR CAB FLOOR	/113.C6
-V200.X	=K	+K	CONNECTOR BLOCKING DIODE	+K2	=A4a	JUMPER HAZARD WARNING SYSTEM	/113.C6
-V201	=A4	+K	BLOCKING DIODE	+K	=K	CONNECTOR CAB FLOOR	/100.C5
-V202	=A4	+K	BLOCKING DIODE	+K	=A4	JUMPER RESERVE	/100.C6
-V203	=A4	+K	BLOCKING DIODE	+K2	=A4	JUMPER	/100.D8
-VU110	=K	+K	BLOCKING DIODE	+23	=K6	CONNECTOR CAB REAR WALL	/115.A6
-VU110.	=K	+K	BLOCKING DIODE	+25	=K6	CONNECTOR CAB REAR WALL	/29.A6
-VU110.X1	=K	+K	CONNECTOR BLOCKING DIODE	+17	=K6	CONNECTOR CAB REAR WALL	/115.A6
-VU110.X2	=K	+K	CONNECTOR BLOCKING DIODE	+18	=K6	CONNECTOR CAB REAR WALL	/115.A6
-W1	=K	+K3	ANTENNA	+19	=K6	CONNECTOR CAB REAR WALL	/36.D5
-X-E29.B	=K	+K	CONNECTOR CAB FLOOR	+20	=K6	CONNECTOR CAB REAR WALL	/104.C5
-X-E29.S	=K	+K	CONNECTOR CAB FLOOR	+K6	=K	CONNECTOR CAB REAR WALL	/104.C5
-X1.B	=K	+K	CONNECTOR CAB FLOOR	+K6	=K	CONNECTOR CAB REAR WALL	/32.D4
-X1.B.25a	=K	+K	CONNECTOR CAB FLOOR	+K6	=K	CONNECTOR CAB REAR WALL	/33.B3
-X1.B.2b	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR RESERVE	/101.F4
-X1.B.43a	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K6	=K	CONNECTOR CAB REAR WALL	/101.A2
-X1.B.a.20 + f1	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+H	=H	CONNECTOR ENGINE BONNET	/102.C4
-X1.B.S.43	=K	+K	CONNECTOR EMERGENCY ACTUATION OF PARKING BRAKE	+H	=H	CONNECTOR ENGINE BONNET	/103.E2
-X1.J	=A4a	+K2	JUMPER HAZARD WARNING SYSTEM	+K	=K	CONNECTOR VISIBLE REVERSING ALARM	/30.C4
-X1.S	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR VISIBLE REVERSING ALARM	/32.C4
-X1.S.25a	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR 2in1 STEERING	/33.A3
-X1.S.2a	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR 2in1 STEERING	/101.F4
-X1.S.43.	=K	+K	CONNECTOR EMERGENCY ACTUATION OF PARKING BRAKE	+K2	=K	CONNECTOR JOYSTICK STEERING	/103.C3
-X1.S.43b	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K2	=K	CONNECTOR JOYSTICK STEERING	/101.D1
-X1.S.43b.	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K2	=K	CONNECTOR JOYSTICK STEERING	/101.D1
-X1.S.43c	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR FUSE BOARD	/101.E1
-X1.S.a.15	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR FUSE BOARD	/102.D4
-X1.S.a.20	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K3	=K	CONNECTOR FUSE BOARD	/102.D4
-X2.9&10 CLAAS	=K	+K	CONNECTOR DIAGNOSTIC PLUG ENGINE CONTROL UNIT	+K	=K	CONNECTOR FUSE BOARD	/61.C6
-X2.9&10 CLAAS	=K	+K	CONNECTOR CLAAS DIAGNOSIS	+K	=K	CONNECTOR FUSE BOARD	/123.C1
-X2.B	=K	+K6	CONNECTOR CAB FLOOR	+H	=H	CONNECTOR FANS SPEED PROPORTIONAL SOLENOID VALVE	/58.C6
-X2.B.65	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR FUSE BOARD	/108.E7

BMK	SYSTEM	LOCATION	FUNCTION	LOCATION	SYSTEM	FUNCTION	PAGE
-X2.B.67b	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	/101.C8
-X2.J	=A4a	+K2	JUMPER HAZARD WARNING SYSTEM	+K2	=A4a	JUMPER HAZARD WARNING SYSTEM	/30.C5
-X2.S	=K	+K6	CONNECTOR CAB FLOOR	+K6	=K	CONNECTOR CAB FLOOR	/58.C6
-X2.S.67a	=K	+K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	+K	=K	CONNECTOR AUTOMATIC DELAYED ENGINE STOP	/101.B8
-X3.B	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/95.D7
-X3.J	=A4a	+K2	JUMPER HAZARD WARNING SYSTEM	+K2	=A4a	JUMPER HAZARD WARNING SYSTEM	/30.C7
-X3.S	=K	+K	CONNECTOR CAB FLOOR	+K	=K	CONNECTOR CAB FLOOR	/95.D7
-X4.J	=A4	+K	JUMPER RESERVE	+K	=A4	JUMPER RESERVE	/27.B6
-X5.J	=A4	+K2	JUMPER	+K2	=A4	JUMPER	/27.B6
-X5a**.B	=K6	+23	CONNECTOR CAB REAR WALL	+23	=K6	CONNECTOR CAB REAR WALL	/154.A8
-X5a**.B	=K6	+25	CONNECTOR CAB REAR WALL	+25	=K6	CONNECTOR CAB REAR WALL	/154.D6
-X5a**.B	=K6	+17	CONNECTOR CAB REAR WALL	+17	=K6	CONNECTOR CAB REAR WALL	/154.B5
-X5a**.B	=K6	+18	CONNECTOR CAB REAR WALL	+18	=K6	CONNECTOR CAB REAR WALL	/154.B6
-X5a**.B	=K6	+19	CONNECTOR CAB REAR WALL	+19	=K6	CONNECTOR CAB REAR WALL	/154.B7
-X5a**.B	=K6	+20	CONNECTOR CAB REAR WALL	+20	=K6	CONNECTOR CAB REAR WALL	/154.B8
-X5a**.S	=K	+K6	CONNECTOR CAB REAR WALL	+K6	=K	CONNECTOR CAB REAR WALL	/150.B3
-X5a*.S	=K	+K6	CONNECTOR CAB REAR WALL	+K6	=K	CONNECTOR CAB REAR WALL	/139.A2
-X5a.B	=K	+K6	CONNECTOR CAB REAR WALL	+K6	=K	CONNECTOR CAB REAR WALL	/40.D2
-X5a.B.23-	=K	+K	CONNECTOR RESERVE	+K	=K	CONNECTOR RESERVE	/113.C3
-X5a.S	=K	+K6	CONNECTOR CAB REAR WALL	+K6	=K	CONNECTOR CAB REAR WALL	/40.D2
-X16.B	=H	+H	CONNECTOR ENGINE BONNET	+H	=H	CONNECTOR ENGINE BONNET	/32.D4
-X16.S	=H	+H	CONNECTOR ENGINE BONNET	+H	=H	CONNECTOR ENGINE BONNET	/32.D4
-X16a.B	=K	+K	CONNECTOR VISIBLE REVERSING ALARM	+K	=K	CONNECTOR VISIBLE REVERSING ALARM	/83.D7
-X16b.S	=K	+K	CONNECTOR VISIBLE REVERSING ALARM	+K	=K	CONNECTOR VISIBLE REVERSING ALARM	/83.D3
-X17.B	=K	+K	CONNECTOR 2in1 STEERING	+K	=K	CONNECTOR 2in1 STEERING	/97.C8
-X17.S	=K	+K	CONNECTOR 2in1 STEERING	+K	=K	CONNECTOR 2in1 STEERING	/97.C8
-X19B	=K	+K2	CONNECTOR JOYSTICK STEERING	+K2	=K	CONNECTOR JOYSTICK STEERING	/26.B5
-X19B.	=K	+K2	CONNECTOR JOYSTICK STEERING	+K2	=K	CONNECTOR JOYSTICK STEERING	/97.B7
-X19S	=K	+K2	CONNECTOR JOYSTICK STEERING	+K2	=K	CONNECTOR JOYSTICK STEERING	/96.B5
-X26.B	=K	+K	CONNECTOR FUSE BOARD	+K	=K	CONNECTOR FUSE BOARD	/81.D3
-X26.S	=K	+K	CONNECTOR FUSE BOARD	+K	=K	CONNECTOR FUSE BOARD	/81.E3
-X26a.S	=K	+K3	CONNECTOR FUSE BOARD	+K3	=K	CONNECTOR FUSE BOARD	/81.E4
-X27.B	=K	+K	CONNECTOR FUSE BOARD	+K	=K	CONNECTOR FUSE BOARD	/81.D4
-X27.S	=K	+K	CONNECTOR FUSE BOARD	+K	=K	CONNECTOR FUSE BOARD	/81.D4
-X28.B	=H	+H	CONNECTOR FANS SPEED PROPORTIONAL SOLENOID VALVE	+H	=H	CONNECTOR FANS SPEED PROPORTIONAL SOLENOID VALVE	/47.B6
-X28.B	=K	+K	CONNECTOR FUSE BOARD	+K	=K	CONNECTOR FUSE BOARD	/81.D6

12466553 000
ITEM CODE DRAWING INDEX

GG4_EVO 1333 90100 02 00
DRAWING NUMBER

PROJECT
ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	SERIAL NUMBER	BMK-INDEX	PAGE	OF
LIDOS Gerät	XXXXX	ELECTRICAL SCHEMATIC;	19	
			CREATION DATE	08.10.2019 15:49


12466553

ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 15016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without registration, express authorization and utilization of this document as well as the communication of its contents to others without registration.



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

STEERING COLUMN SWITCH, BRAKE LIGHT, LICENCE PLATE LIGHT
ELECTRICAL SCHEMATIC;

PAGE 29 OF 8
CREATION DATE 08.10.2019 15:49

12466553
ITEM CODE

000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT

ISO 15018: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.


MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX


LIEBHERR
FACTORY LBH

DISPLAY CAN 3
ELECTRICAL SCHEMATIC;

PAGE 39 OF
CREATION DATE 09.10.2019 15:49



CAN 3



12466553
ITEM CODE

000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 19016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät






SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

POWER SUPPLY ENGINE CONTROL UNIT
ELECTRICAL SCHEMATIC;

PAGE 49 OF

CREATION DATE 09.10.2019 15:49



1 2 3 4 5 6 7 8

A

B

C

D

E

F

12466553
ITEM CODE
000
DRAWING INDEX

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT
registration. ISO 15926. The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization require compensation. All rights reserved in the case of patent, utility model or design.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

CONDENSER FAN
ELECTRICAL SCHEMATIC;

PAGE 59 OF

08.10.2019 15:49
CREATION DATE



-K	A21.X1.PMIE
+K4	A
-A21	CONDENSER FAN
/68.C1	OUTPUT
	CAN.

HEATING AND AIR CONDITIONING SYSTEM

ITEM CODE 12466553
DRAWING INDEX 000

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER

ISO 19018: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

+K4		-A21		Modul Nr.: HEIZ-KLIMA Modulname:		Stecker	Pin
Phys.Adr.	Blatt	EA	Beschreibung				
A21.X1.KB0	58.E2		POWER SUPPLY	0	1		
A21.X1.GND	58.E2		GROUND	0	2		
A21.X1.K15	58.E4		POWER SUPPLY	0	3		
A21.X1.PME	704.A6		AUXILIARY HEATER	0	4		
A21.X1.PME	58.A5		HIGH PRESSURE AND LOW PRESSURE AIR CONDITIONING PRESSURE SWITCH	0	5		
A21.X1.PME				0	6		
A21.X1.PME	59.F1		CONDENSER FAN	0	7		
A21.X1.PME				0	8		
A21.X1.PME	27.E3		DOOR CONTACT SWITCH	0	9		
A21.X1.PME	58.A6		AIR-CONDITIONING COMPRESSOR MAGNETIC COUPLING	0	10		
A21.X1.PME				0	11		
A21.X1.PME				0	12		
A21.X1.CAN1	59.C8		CAN LOW	0	13		
A21.X1.CAN1	59.C8		CAN HIGH	0	14		
A21.X1.CAN1	59.C8		CAN TERMINATOR	0	15		
A21.X1.CAN1			CAN LOW	0	16		
A21.X1.CAN1	59.C8		CAN HIGH	0	17		
A21.X1.PME	58.E3		GROUND	0	18		
A21.X1.PME	58.E3		POWER SUPPLY	0	19		
A21.X1.PME			PROTECTIVE VENTILATION SYSTEM	0	20		
A21.X1.PME			PROTECTIVE VENTILATION SYSTEM	0	21		
A21.X1.PME				0	22		
A21.X1.PME				0	23		
A21.X1.PME				0	24		
A21.X1.PME				0	25		
A21.X1.PME				0	26		
A21.X1.PME				0	27		
A21.X1.PME				0	28		
A21.X1.PME				0	29		
A21.X1.PME				0	30		
A21.X1.PME				0	31		
A21.X1.PME				0	32		
A21.X1.PME				0	33		
A21.X1.PME				0	34		
A21.X1.PME				0	35		
A21.X1.PME				0	36		
A21.X1.PME				0	37		
A21.X1.PME				0	38		
A21.X1.PME				0	39		
A21.X1.PME				0	40		



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OVERVIEW HEATING AND AIR CONDITIONING SYSTEM
ELECTRICAL SCHEMATIC;

PAGE 69 OF

CREATION DATE 09.10.2019 15:49

12466553

ITEM CODE

GG_4_EVO

PROJECT

ISO 10716: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

000

DRAWING INDEX



1333 90100 02 00

DRAWING NUMBER

F7-5A	ADDITIONAL MODULE OUTPUT 1	DO3	STEER WHEEL ANGLE 2	Vcc LATCHING	F13-5A	F13-5A	LENRAD WINKEL 2	Vcc SELBSTHALTUNG	ADDITIONAL MODULE OUTPUT 1	F6-5A	ADDITIONAL MODULE OUTPUT 1	DO2	Vcc ARMREST AKTIV	F12-3A	F12-3A	Vcc ARMLEHNE AKTIV	ADDITIONAL MODULE OUTPUT 1	F5-5A	ADDITIONAL MODULE OUTPUT 1	DO1	STEER ANGLE 2	F5-5A	KNICKWINKEL SENSOR 2	F11-3A	F11-3A	EMERGEN VALVE POSITION FEEDBACK	F10-3A	F10-3A	NOTBETRIEB LAGERÜCKMELDUNG	LENRAD WINKEL 1	F4-5A	STEER WHEEL ANGLE 1	F4-5A	EMERGEN VALVE POSITION FEEDBACK	F3-3A	NOTBETRIEB LAGERÜCKMELDUNG	STEER ANGLE 1	F3-3A	EMERGEN VALVE Vcc LOGIC	F9-5A	F9-5A	NOTBETRIEB Vcc LOGIC	KNICKWINKEL SENSOR1	F2-3A	STEER VALVE POSITION FEEDBACK	JUMPER n.c.	X1-JP	F2-3A	HAUPTKREIS LAGERÜCKMELDUNG	JUMPER n.c.	F1-5A	HAUPTKREIS Vcc LOGIC	F1-5A	STEER VALVE Vcc LOGIC	HAUPTKREIS Vcc LOGIC
-------	----------------------------	-----	---------------------	--------------	--------	--------	-----------------	-------------------	----------------------------	-------	----------------------------	-----	-------------------	--------	--------	--------------------	----------------------------	-------	----------------------------	-----	---------------	-------	----------------------	--------	--------	---------------------------------	--------	--------	----------------------------	-----------------	-------	---------------------	-------	---------------------------------	-------	----------------------------	---------------	-------	-------------------------	-------	-------	----------------------	---------------------	-------	-------------------------------	-------------	-------	-------	----------------------------	-------------	-------	----------------------	-------	-----------------------	----------------------

ZNG 1464 67393 01 00 001

LBH ID 11419535




MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OVERVIEW FUSE STICKER A4b
ELECTRICAL SCHEMATIC;

<p>1 2 3 4 5 6 7 8</p>	<p>1246653 ITEM CODE DRAWING INDEX 000</p>	<p>GG_I4_EVO 1333 9010 02 00 DRAWING NUMBER</p>	<p>PROJECT</p>	<p>ISO 1018: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.</p>	<p>Modul Nr.: Modulname: -A17b</p>	<table border="1"> <thead> <tr> <th>ADDRESS</th> <th>PAGE</th> <th>EA</th> <th>DESCRIPTION</th> <th>CONNECTOR PIN</th> <th>ADDRESS</th> <th>PAGE</th> <th>EA</th> <th>DESCRIPTION</th> <th>CONNECTOR PIN</th> </tr> </thead> <tbody> <tr> <td>A17b.24V_B1</td> <td>/88.D5</td> <td></td> <td>POWER SUPPLY BANK 1</td> <td>0</td> <td>A17b.24V</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.24V_logic</td> <td>/88.D4</td> <td></td> <td>POWER SUPPLY</td> <td>0</td> <td>A17b.24V</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.GND</td> <td>/88.D5</td> <td></td> <td>GROUND</td> <td>0</td> <td>A17b.CAN_Low</td> <td>/87.C5</td> <td></td> <td>CAN LOW</td> <td>0</td> </tr> <tr> <td>A17b.PWM1</td> <td>/88.A1</td> <td></td> <td>JOYSTICK STEERING MAIN VALVE B</td> <td>0</td> <td>A17b</td> <td>/87.C5</td> <td></td> <td>CAN LOW</td> <td>0</td> </tr> <tr> <td>A17b.PWM2</td> <td>/156.A1</td> <td></td> <td>TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_D02</td> <td>/95.F6</td> <td></td> <td>GROUND</td> <td>0</td> </tr> <tr> <td>A17b.PWM3</td> <td>/156.A2</td> <td></td> <td>TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM1</td> <td>/98.F1</td> <td></td> <td>JOYSTICK STEERING MAIN VALVE B</td> <td>0</td> </tr> <tr> <td>A17b.PWM4</td> <td>/156.A3</td> <td></td> <td>GRABBER BACK PROPORTIONAL SOLENOID</td> <td>0</td> <td>A17b.GND_PWM2</td> <td>/156.F1</td> <td></td> <td>TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.PWM9</td> <td>/156.A4</td> <td></td> <td>GRABBER FORWARD PROPORTIONAL SOLENOID</td> <td>0</td> <td>A17b.GND_PWM3</td> <td>/156.F2</td> <td></td> <td>TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.PWM10</td> <td>/156.A7</td> <td></td> <td>OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM4</td> <td>/156.F3</td> <td></td> <td>GRABBER BACK PROPORTIONAL SOLENOID</td> <td>0</td> </tr> <tr> <td>A17b.PWM11</td> <td>/42.A7</td> <td></td> <td>4TH FUNCTION A PROPORTIONAL SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM9</td> <td>/156.F4</td> <td></td> <td>GRABBER FORWARD PROPORTIONAL SOLENOID</td> <td>0</td> </tr> <tr> <td>A17b.PWM12</td> <td>/42.A8</td> <td></td> <td>4TH FUNCTION B PROPORTIONAL SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM10</td> <td>/156.F7</td> <td></td> <td>OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.GND</td> <td>/88.D5</td> <td></td> <td>GROUND</td> <td>0</td> <td>A17b.GND_PWM11</td> <td>/42.F7</td> <td></td> <td>4TH FUNCTION A PROPORTIONAL SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.24V_logic</td> <td>/88.D6</td> <td></td> <td>POWER SUPPLY BANK 3</td> <td>0</td> <td>A17b.GND_PWM12</td> <td>/42.F8</td> <td></td> <td>4TH FUNCTION B PROPORTIONAL SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.24V_B2</td> <td>/88.D5</td> <td></td> <td>POWER SUPPLY BANK 2</td> <td>0</td> <td>A17b.GND_D04</td> <td></td> <td></td> <td>LIGHTING CONTROL</td> <td>0</td> </tr> <tr> <td>A17b.GND_logic</td> <td>/88.D4</td> <td></td> <td>GROUND</td> <td>0</td> <td>A17b.F1</td> <td>/111.E2</td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.GND</td> <td>/88.D6</td> <td></td> <td>GROUND</td> <td>0</td> <td>A17b.CAN_High</td> <td>/87.C4</td> <td></td> <td>CAN HIGH</td> <td>0</td> </tr> <tr> <td>A17b.PWM5</td> <td>/111.F6</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT RIGHT</td> <td>0</td> <td>A17b.CAN_High</td> <td>/87.C4</td> <td></td> <td>CAN HIGH</td> <td>0</td> </tr> <tr> <td>A17b.PWM6</td> <td>/111.F5</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT RIGHT</td> <td>0</td> <td>A17b.GND</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.PWM7</td> <td>/156.A5</td> <td></td> <td>RAISE LOG PUSHER SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM5</td> <td>/112.F7</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT MIDDLE</td> <td>0</td> </tr> <tr> <td>A17b.PWM8</td> <td>/156.A6</td> <td></td> <td>LOWER LOG PUSHER SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_PWM6</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.PWM13</td> <td>/111.F8</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT LEFT</td> <td>0</td> <td>A17b.GND_PWM7</td> <td>/156.F5</td> <td></td> <td>RAISE LOG PUSHER SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.PWM14</td> <td>/111.F7</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT LEFT</td> <td>0</td> <td>A17b.GND_PWM8</td> <td>/156.F6</td> <td></td> <td>LOWER LOG PUSHER SOLENOID VALVE</td> <td>0</td> </tr> <tr> <td>A17b.PWM15</td> <td>/112.A5</td> <td></td> <td>DIMMABLE WORKING HEADLIGHT MIDDLE</td> <td>0</td> <td>A17b.GND_PWM13</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.PWM16</td> <td>/88.A3</td> <td></td> <td>JOYSTICK STEERING MAIN VALVE A</td> <td>0</td> <td>A17b.GND_PWM14</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.GND</td> <td>/88.D7</td> <td></td> <td>GROUND</td> <td>0</td> <td>A17b.GND_PWM15</td> <td>/98.F3</td> <td></td> <td>JOYSTICK STEERING MAIN VALVE A</td> <td>0</td> </tr> <tr> <td>A17b.GND_logic</td> <td>/88.D7</td> <td></td> <td>POWER SUPPLY BANK 4</td> <td>0</td> <td>A17b.GND_PWM16</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.24V_B4</td> <td>/88.D7</td> <td></td> <td>CAN TERMINATOR</td> <td>0</td> <td>A17b.GND</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.CAN_Res</td> <td>/87.C6</td> <td></td> <td></td> <td>0</td> <td>A17b.GND_F1</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.24V</td> <td>/96.D2</td> <td></td> <td>JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE</td> <td>0</td> <td>A17b.GND_FF2</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.GND_D01</td> <td>/98.F5</td> <td></td> <td>POWER SUPPLY DIGITAL OUTPUT 1</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.V_D01</td> <td>/96.A4</td> <td></td> <td>JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.V_D02</td> <td>/95.F5</td> <td></td> <td>POWER SUPPLY DIGITAL OUTPUT 2</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.D02</td> <td>/95.A5</td> <td></td> <td>RELAY POWER SUPPLY EMERGENCY STEERING CIRCUIT</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.V_D03</td> <td>/95.F7</td> <td></td> <td>POWER SUPPLY DIGITAL OUTPUT 3</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.D03</td> <td>/96.A3</td> <td></td> <td>JOYSTICK STEERING SWITCHING RELAY</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b</td> <td></td> <td></td> <td></td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.D04</td> <td></td> <td></td> <td></td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>A17b.GND_D03</td> <td>/95.F8</td> <td></td> <td>GROUND</td> <td>0</td> <td></td> <td></td> <td></td> <td></td> <td>0</td> </tr> </tbody> </table>	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN	A17b.24V_B1	/88.D5		POWER SUPPLY BANK 1	0	A17b.24V				0	A17b.24V_logic	/88.D4		POWER SUPPLY	0	A17b.24V				0	A17b.GND	/88.D5		GROUND	0	A17b.CAN_Low	/87.C5		CAN LOW	0	A17b.PWM1	/88.A1		JOYSTICK STEERING MAIN VALVE B	0	A17b	/87.C5		CAN LOW	0	A17b.PWM2	/156.A1		TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE	0	A17b.GND_D02	/95.F6		GROUND	0	A17b.PWM3	/156.A2		TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM1	/98.F1		JOYSTICK STEERING MAIN VALVE B	0	A17b.PWM4	/156.A3		GRABBER BACK PROPORTIONAL SOLENOID	0	A17b.GND_PWM2	/156.F1		TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE	0	A17b.PWM9	/156.A4		GRABBER FORWARD PROPORTIONAL SOLENOID	0	A17b.GND_PWM3	/156.F2		TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE	0	A17b.PWM10	/156.A7		OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE	0	A17b.GND_PWM4	/156.F3		GRABBER BACK PROPORTIONAL SOLENOID	0	A17b.PWM11	/42.A7		4TH FUNCTION A PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM9	/156.F4		GRABBER FORWARD PROPORTIONAL SOLENOID	0	A17b.PWM12	/42.A8		4TH FUNCTION B PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM10	/156.F7		OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE	0	A17b.GND	/88.D5		GROUND	0	A17b.GND_PWM11	/42.F7		4TH FUNCTION A PROPORTIONAL SOLENOID VALVE	0	A17b.24V_logic	/88.D6		POWER SUPPLY BANK 3	0	A17b.GND_PWM12	/42.F8		4TH FUNCTION B PROPORTIONAL SOLENOID VALVE	0	A17b.24V_B2	/88.D5		POWER SUPPLY BANK 2	0	A17b.GND_D04			LIGHTING CONTROL	0	A17b.GND_logic	/88.D4		GROUND	0	A17b.F1	/111.E2			0	A17b.GND	/88.D6		GROUND	0	A17b.CAN_High	/87.C4		CAN HIGH	0	A17b.PWM5	/111.F6		DIMMABLE WORKING HEADLIGHT RIGHT	0	A17b.CAN_High	/87.C4		CAN HIGH	0	A17b.PWM6	/111.F5		DIMMABLE WORKING HEADLIGHT RIGHT	0	A17b.GND				0	A17b.PWM7	/156.A5		RAISE LOG PUSHER SOLENOID VALVE	0	A17b.GND_PWM5	/112.F7		DIMMABLE WORKING HEADLIGHT MIDDLE	0	A17b.PWM8	/156.A6		LOWER LOG PUSHER SOLENOID VALVE	0	A17b.GND_PWM6				0	A17b.PWM13	/111.F8		DIMMABLE WORKING HEADLIGHT LEFT	0	A17b.GND_PWM7	/156.F5		RAISE LOG PUSHER SOLENOID VALVE	0	A17b.PWM14	/111.F7		DIMMABLE WORKING HEADLIGHT LEFT	0	A17b.GND_PWM8	/156.F6		LOWER LOG PUSHER SOLENOID VALVE	0	A17b.PWM15	/112.A5		DIMMABLE WORKING HEADLIGHT MIDDLE	0	A17b.GND_PWM13				0	A17b.PWM16	/88.A3		JOYSTICK STEERING MAIN VALVE A	0	A17b.GND_PWM14				0	A17b.GND	/88.D7		GROUND	0	A17b.GND_PWM15	/98.F3		JOYSTICK STEERING MAIN VALVE A	0	A17b.GND_logic	/88.D7		POWER SUPPLY BANK 4	0	A17b.GND_PWM16				0	A17b.24V_B4	/88.D7		CAN TERMINATOR	0	A17b.GND				0	A17b.CAN_Res	/87.C6			0	A17b.GND_F1				0	A17b.24V	/96.D2		JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE	0	A17b.GND_FF2				0	A17b.GND_D01	/98.F5		POWER SUPPLY DIGITAL OUTPUT 1	0					0	A17b.V_D01	/96.A4		JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE	0					0	A17b.V_D02	/95.F5		POWER SUPPLY DIGITAL OUTPUT 2	0					0	A17b.D02	/95.A5		RELAY POWER SUPPLY EMERGENCY STEERING CIRCUIT	0					0	A17b.V_D03	/95.F7		POWER SUPPLY DIGITAL OUTPUT 3	0					0	A17b.D03	/96.A3		JOYSTICK STEERING SWITCHING RELAY	0					0	A17b				0					0	A17b.D04				0					0	A17b.GND_D03	/95.F8		GROUND	0					0	<p>MACHINE TYPE LIDOS Gerät</p> <p>SERIAL NUMBER XXXXX</p> <p>OPTION OUTPUT MODULE A17b ELECTRICAL SCHEMATIC;</p> <p>PAGE 89 OF CREATION DATE 08.10.2019 15:49</p>
ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR PIN																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V_B1	/88.D5		POWER SUPPLY BANK 1	0	A17b.24V				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V_logic	/88.D4		POWER SUPPLY	0	A17b.24V				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND	/88.D5		GROUND	0	A17b.CAN_Low	/87.C5		CAN LOW	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM1	/88.A1		JOYSTICK STEERING MAIN VALVE B	0	A17b	/87.C5		CAN LOW	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM2	/156.A1		TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE	0	A17b.GND_D02	/95.F6		GROUND	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM3	/156.A2		TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM1	/98.F1		JOYSTICK STEERING MAIN VALVE B	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM4	/156.A3		GRABBER BACK PROPORTIONAL SOLENOID	0	A17b.GND_PWM2	/156.F1		TURN GRABBER RIGHT PROPORTIONAL SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM9	/156.A4		GRABBER FORWARD PROPORTIONAL SOLENOID	0	A17b.GND_PWM3	/156.F2		TURN GRABBER LEFT PROPORTIONAL SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM10	/156.A7		OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE	0	A17b.GND_PWM4	/156.F3		GRABBER BACK PROPORTIONAL SOLENOID	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM11	/42.A7		4TH FUNCTION A PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM9	/156.F4		GRABBER FORWARD PROPORTIONAL SOLENOID	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM12	/42.A8		4TH FUNCTION B PROPORTIONAL SOLENOID VALVE	0	A17b.GND_PWM10	/156.F7		OSCILLATING CYLINDER LOCKOUT SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND	/88.D5		GROUND	0	A17b.GND_PWM11	/42.F7		4TH FUNCTION A PROPORTIONAL SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V_logic	/88.D6		POWER SUPPLY BANK 3	0	A17b.GND_PWM12	/42.F8		4TH FUNCTION B PROPORTIONAL SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V_B2	/88.D5		POWER SUPPLY BANK 2	0	A17b.GND_D04			LIGHTING CONTROL	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND_logic	/88.D4		GROUND	0	A17b.F1	/111.E2			0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND	/88.D6		GROUND	0	A17b.CAN_High	/87.C4		CAN HIGH	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM5	/111.F6		DIMMABLE WORKING HEADLIGHT RIGHT	0	A17b.CAN_High	/87.C4		CAN HIGH	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM6	/111.F5		DIMMABLE WORKING HEADLIGHT RIGHT	0	A17b.GND				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM7	/156.A5		RAISE LOG PUSHER SOLENOID VALVE	0	A17b.GND_PWM5	/112.F7		DIMMABLE WORKING HEADLIGHT MIDDLE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM8	/156.A6		LOWER LOG PUSHER SOLENOID VALVE	0	A17b.GND_PWM6				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM13	/111.F8		DIMMABLE WORKING HEADLIGHT LEFT	0	A17b.GND_PWM7	/156.F5		RAISE LOG PUSHER SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM14	/111.F7		DIMMABLE WORKING HEADLIGHT LEFT	0	A17b.GND_PWM8	/156.F6		LOWER LOG PUSHER SOLENOID VALVE	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM15	/112.A5		DIMMABLE WORKING HEADLIGHT MIDDLE	0	A17b.GND_PWM13				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.PWM16	/88.A3		JOYSTICK STEERING MAIN VALVE A	0	A17b.GND_PWM14				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND	/88.D7		GROUND	0	A17b.GND_PWM15	/98.F3		JOYSTICK STEERING MAIN VALVE A	0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND_logic	/88.D7		POWER SUPPLY BANK 4	0	A17b.GND_PWM16				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V_B4	/88.D7		CAN TERMINATOR	0	A17b.GND				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.CAN_Res	/87.C6			0	A17b.GND_F1				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.24V	/96.D2		JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE	0	A17b.GND_FF2				0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND_D01	/98.F5		POWER SUPPLY DIGITAL OUTPUT 1	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.V_D01	/96.A4		JOYSTICK STEERING SAFETY CIRCUIT SOLENOID VALVE	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.V_D02	/95.F5		POWER SUPPLY DIGITAL OUTPUT 2	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.D02	/95.A5		RELAY POWER SUPPLY EMERGENCY STEERING CIRCUIT	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.V_D03	/95.F7		POWER SUPPLY DIGITAL OUTPUT 3	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.D03	/96.A3		JOYSTICK STEERING SWITCHING RELAY	0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b				0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.D04				0					0																																																																																																																																																																																																																																																																																																																																																																																																				
A17b.GND_D03	/95.F8		GROUND	0					0																																																																																																																																																																																																																																																																																																																																																																																																				



12466553
ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00

PROJECT
DRAWING NUMBER
1333 90100 02 00

ISO 15016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without registration, express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

INPUT MODULE A16a	
CAN:	
/66.C1	INPUT
-A16a	PRESSURE SENSOR TILT CYLINDER PRESSURE SENSOR
+H3	IRVIEBoomPressBottom
=H	A16a.LJ11

X110

-A16a.X110

BK/1Q



-B90.X110

BK/1Q

INPUT MODULE A16a	
CAN:	
=H	A16a.GND
+H3	PRYM LIFT CYLINDER PRESSURE SENSOR
-A16a	PRYM LIFT CYLINDER PRESSURE SENSOR
/66.F1	GROUND
T. 15	

CAN:

INPUT MODULE A16a

INPUT MODULE A16a	
CAN:	
/66.C1	INPUT
-A16a	RING SIDE LIFT CYLINDER PRESSURE SENSOR
+H3	IRVIEBoomPressRod
=H	A16a.LJ12

X111

-A16a.X111

BK/1Q



-B91.X111

BK/1Q

INPUT MODULE A16a	
CAN:	
=H	A16a.GND
+H3	RING SIDE LIFT CYLINDER PRESSURE SENSOR
-A16a	RING SIDE LIFT CYLINDER PRESSURE SENSOR
/66.F1	GROUND
T. 15	

CAN:

INPUT MODULE A16a

INPUT MODULE A16a	
CAN:	
/66.C1	INPUT
-A16a	PRESSURE SENSOR TILT CYLINDER RING SIDE
+H3	IRFueLevelBers
=H	A16a.LJ14

X112

-A16a.X112

BK/1Q



-B92.X112

BK/1Q

INPUT MODULE A16a	
CAN:	
=H	A16a.GND
+H3	PRESSURE SENSOR TILT CYLINDER RING SIDE
-A16a	PRESSURE SENSOR TILT CYLINDER RING SIDE
/66.E1	GROUND
T. 15	

CAN:

INPUT MODULE A16a

INPUT MODULE A16a	
CAN:	
/66.D1	INPUT
-A16a	PRESSURE SENSOR TILT CYLINDER RING SIDE
+H3	IRFueLevelBers
=H	A16a.LJ14

X113

-A16a.X113

BK/1Q



-B93.X113

BK/1Q

INPUT MODULE A16a	
CAN:	
=H	A16a.GND
+H3	PRESSURE SENSOR TILT CYLINDER RING SIDE
-A16a	PRESSURE SENSOR TILT CYLINDER RING SIDE
/66.D1	GROUND
T. 15	

CAN:

INPUT MODULE A16a


MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIBEHRER
FACTORY LBH

OPTION WEIGHING DEVICE LIBEHRER
ELECTRICAL SCHEMATIC;

PAGE 109 OF
CREATION DATE 09.10.2019 15:49



OUTPUT MODULE: A17c

CAN: /117.C2
 OUTPUT: GRMBValve_RS
 +H3: A17c.PWM1
 =H: A17c.PWM1

X144
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C2
 OUTPUT: MCRING BASKET LOCKING VALVE
 +H3: GRMBValve_AV
 =H: A17c.PWM2

X145
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C2
 OUTPUT: GRMBValve_LS, NoIReduce
 +H3: A17c.PWM3
 =H: A17c.PWM3

X146
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C2
 OUTPUT: A17c.GND_PWM1
 +H3: A17c.GND_PWM1
 =H: A17c.GND_PWM1

X147
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C2
 OUTPUT: A17c.GND_PWM2
 +H3: A17c.GND_PWM2
 =H: A17c.GND_PWM2

X148
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C5
 OUTPUT: SOLENOID VALVE PIPE BREAK PROTECTION
 +H3: A17c.PWM1
 =H: A17c.PWM1

X146
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C5
 OUTPUT: WORKING BASKET LOCKING VALVE
 +H3: A17c.PWM2
 =H: A17c.PWM2

X147
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

OUTPUT MODULE: A17c

CAN: /117.C5
 OUTPUT: A17c.GND_PWM3
 +H3: A17c.GND_PWM3
 =H: A17c.GND_PWM3

X148
 -A17c.X11

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50

WH/1.50

BK/1.50


WH/1.50

BK/1.50

WH



KEYPAD 1



ADDRESS	TYPE	PAGE	DESCRIPTION	CONNECTOR	PIN
A36.1		/128.E8	CAN LOW	X	1
A36.2		/128.E7	CAN HIGH	X	2
A36.3			CAN TERMINATOR	X	3
A36.4			GROUND	X	4
A36.5			S3_IN INPUT	X	5
A36.6			S4_IN INPUT	X	6
A36.7			CAN LOW	X	7
A36.8			CAN HIGH	X	8
A36.9		/128.D1	GROUND	X	9
A36.10		/128.D2	POWER SUPPLY	X	10
A36.11			S3_OUT OUTPUT	X	11
A36.12			S4_OUT OUTPUT	X	12



ITEM CODE 12466553
DRAWING INDEX 000

PROJECT GG_4_EVO
DRAWING NUMBER 1333 90100 02 00

12466553

ISO 15018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

VERSION 1 MULTILEVER CONTROL STARTING SWITCH
ELECTRICAL SCHEMATIC;

PAGE 139 OF

CREATION DATE 09.10.2019 15:49



12466553
ITEM CODE

000
DRAWING INDEX

GG_4_EVO
1333 9010 02 00
DRAWING NUMBER

PROJECT

ISO 18018: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX


LIEBHERR
FACTORY LBH

VERSION 2 LogHandler
ELECTRICAL SCHEMATIC;

PAGE 149 OF

CREATION DATE

08.10.2019 15:49



CONTROL LEVER CAN MODULE L


CONTROL LEVER CAN MODULE CONTROL LEVER CAN MODULE L

CONTROL LEVER CAN MODULE CONTROL LEVER CAN MODULE L

12466553
ITEM CODE
DRAWING INDEX
000

GG_4_EVO
1333 90100 02 00
DRAWING NUMBER

PROJECT
registration. ISO 18018. The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design.



CENTRAL LUBRICATION SYSTEM CYCLE SENSOR


MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX


LIEBHERR
FACTORY LBH

OPTION GRABBER CAMERA LogHandler CENTRAL LUBRICATION SYSTEM
ELECTRICAL SCHEMATIC;
















PAGE 159 OF
CREATION DATE 08.10.2019 15:49




OIL PRESSURE SENSOR








0.0 bar/g = 0.5V
3.0 bar/g = 1.5V
6.0 bar/g = 2.5V
9.0 bar/g = 3.5V
12.0 bar/g = 4.5V




CHARGE AIR TEMPERATURE & PRESSURE








-40 ... +130°C
25°C = 1990R
100°C = 180R



FUEL PRESSURE SENSOR



0.0 bar/g = 0.5V
3.0 bar/g = 1.5V
6.0 bar/g = 2.5V
9.0 bar/g = 3.5V
12.0 bar/g = 4.5V



REPLACEMENT FOR MARKED	Imbbap1	LOCATION	SYSTEM	INDEX
0	13.12.2017 09:59	=IM	11392207	000
CHECKED	Imbbua0	SHEET 10	FROM 16	+M
TECHNICAL REFEREE				

ARTICLE CODE	11392207	INDEX	000
DRAWING NUMBER	96 006 9309 90	INDEX	000
DATE	13.12.2017 09:59	INDEX	000
CHECKED	Imbbua0	INDEX	000
TECHNICAL REFEREE		INDEX	000

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

DESIGNATION	ELECTRICAL WIRING DIAGRAM	DESCRIPTION	OIL PRESSURE SENSOR, CHARGE AIR TEMPERATURE & PRESSURE, FUEL PRESSURE SENSOR
-------------	---------------------------	-------------	--

2 Function

The machine is electronically controlled by the central control unit (Master5-Premium) **A15**.

The central control unit is connected via the CAN lines to the CAN devices.

At the end of each CAN line there is a 120 Ω resistor. That resistor is normally integrated in the CAN devices and can be activated by plugging in an electrical connector (jumper).

Every CAN node has its own CAN address. The system is able to identify the individual components through this address. The addresses are preset and must normally only be changed if the input modules or the output modules are exchanged.

The CAN addresses can be called up in Sculi diagnostic software using *INFO* button.

For more information see the section on addressing the CAN modules. ([For more information see: Addressing CAN module and checking system information, page 030-234](#))

110.4.2 Central control unit (Master5-Premium)

Valid for: L586-1761;

1 Function




Fig. 492: Central control unit (Master5-Premium)

Position	Function	Position	Function
1	Ventilation membrane	LAN 3	LAN interface
X1	Plug connector (12-pin)	LAN 4	LAN interface
X2	Plug connector (12-pin)	LAN 5	LAN interface
LAN 1	LAN interface	LAN 6	LAN interface
LAN 2	LAN interface		

Tab. 207: Items

110.5 Electrical components of the driver's cab

110.5.1 Fuse and relay boards

Valid for: L586-1761;

1 Fuse and relay board A4




Fig. 502: Fuse and relay board

The fuse and relay board A4 is mounted on the rear wall of the operator's cab.
The fuse and relay board carries and connects the electrical components.

LBH/12252628/03/211-20200327_070249/en

Signal from battery main switch **S15** is also read from output module **A17a**. If battery main switch **S15** is turned off when diesel engine is running, a service code appears on display and a warning sound is issued.

LEDs **H15** indicate status of electric battery main switch.

Green LED lights up when following conditions are met:

- Battery main switch **ON**
- Start switch in position **0**

Green LED flashes when following conditions are met:

- Battery main switch **OFF**
- Start switch in position **0**
- Switch-off delay (5 minutes) is active

Red LED lights up when following conditions are met:

- Battery main switch **ON**
- Start switch in position **I**

Battery main switch (S15)	Start switch (S1)	LED (H15)	Description
OFF	0 position	No display	No power supply at relay for electric battery main switch K15.H .
			Power supply of machine is interrupted.
ON	0 position	Green	Relay for electric battery main switch K15.H is supplied with voltage via start switch S1 .
			Voltage from battery main switch S15 is present at control input of battery main switch.
			Switching contact at relay for electric battery main switch K15.H is closed.
			Machine is supplied with voltage.
ON	Position I	Red	Relay for electric battery main switch K15.H is not supplied with voltage via start switch S1 .
			Voltage from battery main switch S15 is present at control input of battery main switch.
			Switching contact at relay for electric battery main switch K15.H remains closed.
			Machine is supplied with voltage.
OFF	0 position	Flashing green	Relay for electric battery main switch K15.H is supplied with voltage via start switch S1 .
			Voltage from battery main switch S15 is not present at control input of battery main switch.
			Switch-off delay (5 minutes) is active
			Machine is supplied with voltage.

Tab. 221: Operating statuses

LBH/12252628/03/211-20200327_070249/en

2.3 Hydrostat and planetary carrier

2.3.1 Machine at a standstill, travel direction selected




Fig. 517: Machine at a standstill, travel direction selected

Name	Description	Name	Description	Name	Description
A	Duct A	ZS2	Sun gear 2	Z9	Gearwheel 9
B	Duct B	ZP1	Planetary gear 1	KV	Forward travel direction clutch
T1	Rotary group 1	ZP2	Planetary gear 2	KR	Reverse travel direction clutch
T2	Rotary group 2	ZH	Ring gear	K1	Clutch 1
W1	Shaft 1	Z6	Gearwheel 6	K2	Clutch 2
W2	Shaft 2	Z7	Gearwheel 7		
ZS1	Sun gear 1	Z8	Gearwheel 8		

Tab. 230: Key

The clutch K1 is closed. The ring gear ZH is connected via the gearwheel Z8 and the clutch K1 to the output. This means that when the machine is at a standstill, so is the ring gear ZH.

LBH/12252628/03/211-20200327_070249/en

BMK	Function	BMK	Function	BMK	Function
B80	Pressure sensor for duct AB	Y1	Proportional solenoid for clutch 2 (K2)	Y5	Proportional solenoid for clutch 1 (K1)
B81	Pressure sensor for duct A	Y2	Proportional solenoid for forward travel direction clutch (KV)	Y6	Proportional solenoid for clutch 3 (K3)
B85	Filter bypass switch	Y3	Proportional solenoid for optional connection	Y7	Proportional solenoid for position control
B86	Gear oil temperature sensor	Y4	Proportional solenoid for reverse travel direction clutch (KR)		

Tab. 236: Equipment codes

The transmission hydraulics perform following tasks:

- Shifting clutches
- Transmitting power to hydrostat module
- Lubricating transmission

The gear pump **2** draws oil from hydraulic tank and pumps it to gear oil filters in filter head **40**.

If gear oil filters are clogged, filter bypass valve **41** opens. This ensures lubrication even if gear oil filters are clogged.

After gear oil filters, oil flows to transmission control valve block **25** and to hydrostat module **45**.

The transmission control valve block **25** shifts clutches hydraulically. Oil that is not required for clutches flows on to lubricate bearings. For bearing lubrication, lubricating pressure valve **24** in duct plate **23** reduces pressure. The oil that flows out during this returns via gear oil cooler **66** to oil sump.

The hydrostat module **45** transmits some of power hydraulically. To do this, two axial piston rotary groups in hydrostat module **45** operate in a closed circuit.

2.2 Proportional solenoid valves for couplings

For all couplings, same proportional solenoid valves are installed. For some, proportional solenoids are switched to black and white.

Following proportional solenoids are switched proportionally:

- Proportional solenoid for forward travel direction coupling **Y2**
- Proportional solenoid for reverse travel direction coupling **Y4**

Following proportional solenoids are switched black/white:

- Proportional solenoid for coupling 1 **Y5**
- Proportional solenoid for coupling 2 **Y1**
- Proportional solenoid for coupling 3 **Y6**

120.3 Transmission electronics

120.3.1 Overview of electrical control system of transmission

Valid for: L586-1761;

1




Fig. 531: Diagram


1 Transmission

BMK	Function	BMK	Function
A15	Central control unit	X60d	Diagnostic connector for transmission (not used)
A25	Transmission control unit (TCU)	Y1	Proportional solenoid for clutch 2 (K2)
B80	Pressure sensor for duct AB	Y2	Proportional solenoid for forward travel direction clutch (KV)
B81	Pressure sensor for duct A	Y3	Proportional solenoid for 1st optional connection
B82	Speed sensor for sun gear 2	Y4	Proportional solenoid for reverse travel direction clutch (KR)
B83	Output speed sensor	Y5	Proportional solenoid for clutch 1 (K1)
B84	Speed sensor for reverse travel direction clutch	Y6	Proportional solenoid for 2nd optional connection
B85	Filter bypass switch	Y7	Proportional solenoid for position control
B86	Gear oil temperature sensor		

Tab. 244: Equipment codes

LBH/12252628/03/211-20200327_070249/en

The self-locking differential is integrated in the central housing. The wheel hubs contain the den service brake for the 1st brake circuit. The service brake is a wet disc brake.



sac01801

Fig. 540: Central housing with self-locking differential: sectional view

- | | | | |
|----|-------------------------------|----|---------------------------------|
| 1 | Left half shaft | 12 | Right trumpet arm |
| 2 | Left trumpet arm | 13 | Right half shaft |
| 3 | Tapered roller bearing | 14 | Tight axle tapered gear |
| 4 | Locking discs for left wheel | 15 | Compensation tapered gear |
| 5 | Crown wheel | 16 | Tapered roller bearing |
| 6 | Compensation axle | 17 | Axle input shaft (tapered gear) |
| 7 | Main housing | 18 | Tapered roller bearing |
| 8 | Right thrust ring | 19 | Transmission drive flange |
| 9 | Differential housing | 20 | Left thrust ring |
| 10 | Locking discs for right wheel | 21 | Left axle tapered gear |
| 11 | Tapered roller bearing | | |

LBH/12252628/03/211-20200327_070249/en

140 Steel parts of the basic machine

Contents

140.1	Vehicle frame	140-2
140.1.1	Articulation bearing <i>L586-1761;</i>	140-2
140.1.2	Articulation lock <i>L586-1761;</i>	140-3
140.2	Covering	140-4
140.2.1	Linear motor for opening the engine hood <i>L586-1761;</i>	140-4

150.2.2 Quick coupler hydraulics

150.2.2.1 Overview of quick coupler hydraulics

Valid for: L586-1761;

1 Layout




Fig. 555: Overview of quick coupler hydraulics (from front left)

- | | | | |
|---|--|---|--|
| 1 | Valve block for quick coupler | 5 | Check valve |
| 2 | Oil supply from working pump (via control valve block) | 6 | Quick coupler locking hydraulic cylinder |
| 3 | Return flow to control valve block | 7 | Preload valve 15 bar |
| 4 | Load sensing signal for working pump (via control valve block) | | |

Name	Test point
MS	Quick coupler closing pressure

Tab. 257: Test points

BMK	Function	BMK	Function
Y53	Solenoid for opening quick coupler	Y53a	Quick coupler load sensing signal solenoid

Tab. 258: Equipment codes

Quick coupler hydraulics consist of following components:

- Valve block for quick coupler (For more information see: [Valve block for quick coupler, page 150-7](#))
- Quick coupler locking hydraulic cylinder

LBH/12252628/03/211-20200327_070249/en

Entry to operator's cab is via cab access and door on left.

2.2 Strength according to ROPS/FOPS

Operator's cab is a safety cab which is tested and approved in accordance with ROPS/FOPS.

ROPS (roll over protective structure) refers to mechanical rigidity in event of vehicle falling over.

FOPS (falling object protective structure) refers to rigidity of cab on event of objects falling onto it.

For more information on ROPS/FOPS regulations: ([For more information see: Roll over protective structure \(ROPS\), page 010-13](#)) ([For more information see: Falling object protective structures \(FOPS\), page 010-13](#))

Malfunction	Cause	Remedy
Not enough cooling	Not enough refrigerant in the air conditioning circuit	Correct the refrigerant level
	Air in the air conditioning circuit	Evacuate and refill the air conditioning unit
	Expansion valve blocked	Check the expansion valve
	Condenser blocked	Check the condenser
	Valve plates in the air conditioning compressor are defective	Check the valve plates

Tab. 269: Air conditioning: Troubleshooting

160.3.2 Heating and air conditioning unit

The refrigerant expands. The expansion reduces the pressure energy in the refrigerant and quickly cools the evaporator.

The evaporator **10** is exposed to hot air from the cab and transfers the heat to the refrigerant. This thermal exchange cools the cab air and heats the refrigerant.

The heated refrigerant evaporates and turns to gas. This change of state requires additional energy from the (warm) evaporator, which further reduces the temperature.

The warmed, gaseous refrigerant is drawn in by the air conditioning compressor **1** again.

160.4.2 Air conditioning compressor

Valid for: L586-1761;

1 Layout





Fig. 579: Sectional view of air conditioning compressor

- | | |
|--|--------------------------------------|
| 1 Outlet port | 8 Piston |
| 2 Intake port | 9 Swash plate |
| 3 Housing | 10 Shaft with axial face seal |
| 4 Compressor coupling Y22 with pulley | 11 Cover with guide hub |
| 5 Intake and discharge valve | 12 Bearing |
| 6 Screw connection | 13 Connecting rod |
| 7 Valve plate | |

The air conditioning compressor with magnetic coupling is attached to the engine and driven by a V-ribbed-belt.

2 Function

The air conditioning compressor acts as a pump, drawing in refrigerant in a gaseous condition from the evaporator, compressing it and delivering it to the condenser.



Note

To prevent the axial face seal of the shaft **10** from drying out, the air conditioning compressor should be started up once a month, even when it is cold outside.

2.1 Overall system

The electrically powered central lubrication pump delivers the grease to the main progressive distributor and distributes it to the secondary progressive distributors. Each secondary progressive distributor delivers the grease to its lubrication points. The central control unit (Master4) controls the set lubrication and pause times of the central lubrication pump.

2.2 Progressive lubrication

The automatic central lubrication system is a progressive system. It lubricates progressively. That means the lubrication points are lubricated in succession.

2.3 Diagram of Liebherr automatic central lubrication system




Fig. 586: Diagram of the central lubrication system with overview of lubrication points (Z-kinematics)

- | | | | | | |
|---|------------------------------|---|-------------------------------------|---|--------------------------|
| 1 | Central lubrication pump | 4 | Secondary progressive distributor 6 | 7 | High pressure hose (NW4) |
| 2 | Main progressive distributor | 5 | Secondary progressive distributor 5 | 8 | High pressure hose (NW6) |
| 3 | Pulse generator | 6 | Secondary progressive distributor 4 | 9 | Polyamide pipe |

LBH/12252628/03/211-20200327_070249/en

The flow rate depends on the piston diameter. Each progressive distributor requires at least three pumping elements to work properly.

The distributors must always be installed in a horizontal position.




Fig. 598: Progressive distributor

- | | |
|--|--|
| 1 Grease intake | 5 Basic end element |
| 2 Outlets to lubrication points and distributors | 6 Basic middle element |
| 3 Metering elements | 7 Outlets to lubrication points and distributors |
| 4 Dummy element | 8 Basic initial element |

The progressive distributor consists of a number of distributor plates connected together by tie rods with washers and nuts. The metering elements are fastened to the basic elements with hex socket screws. The individual elements are sealed with O-rings.

2 Function

2.1 Basic function




Fig. 599: Piston settings for the progressive distributor SXE-2

- | | |
|----------------------|----------------------------|
| A-C Piston positions | 1-6 Grease channel outlets |
| I-III Piston | |

LBH/12252628/03/211-20200327_070249/en

The LiDAT module is equipped with an internal rechargeable battery 1. The battery is charged using the battery voltage when terminal 30 is activated (battery main switch ON).

The charge status of the battery is monitored internally. If the battery is fully charged or damaged, the charging process is stopped.

1.5 Status display with indicator lamp (LED)













Fig. 607: Status display with indicator lamp (LED)

1 Indicator lamp (LED)

Indicator lamp (LED) 1 signals operating status of LiDAT module.

Colour	Code	Status
 Green	Flashes, 1 second on, 1 second off	OK, application runs on terminal 30.
 Green	Flashes, 1 second on, 10 second off	OK, application runs on internal rechargeable battery (optional).
 Green	Steady light	Starts or shuts down.
 White	Steady light	Application is restored or an update is performed.
 Yellow	Steady light	There are non-critical errors.
 Yellow	Flashes, 1 second on, 1 second off	No W-LAN reception (optional).
 Red	Flashes, 1 second on, 1 second off	Critical error
 Blue	Flashes, 1 second on, 1 second off	No GNSS reception.
 Magenta	Flashes, 1 second on, 1 second off	No GSM reception.

Tab. 277: Status display with indicator lamp (LED)

LBH/12252628/03/211-20200327_070249/en

2.2 Remote control




Fig. 625: Remote control

- | | | | |
|---|---------------|---|------------------------|
| 1 | Lock button | 3 | Unlock and open button |
| 2 | Unlock button | | |

Remote control sends encrypted signals to receiving unit and control unit.

Remote control is powered by a replaceable button battery inside case.

Remote control and receiving unit and control unit are programmed at factory before delivery. Programming is performed using a programming code. Programming code is enclosed on a label of remote control on delivery.

If a remote control is defective or lost, a new remote control can be requested from factory. Programming is performed using corresponding programming code.

If programming code is lost, a new programming code must be requested. If a new programming code is needed, remote control and receiving unit and control unit must be reprogrammed.

200 Diagnosis

Contents

200.1	Malfunctions	200-2
200.1.1	Warning symbols	200-2
200.1.2	SCR system warning symbols	200-3
200.1.3	Service code indicator in display	200-4
200.2	Troubleshooting	200-6
200.2.1	Replacing fuses	200-6
200.2.1.1	Fuses on fuse board A4 in the operator's cab	200-6
200.2.1.2	Fuses on fuse board A4a in the left ballast weight	200-9
200.2.1.3	Fuses on fuse board A4b in the operator's cab	200-11

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL