

en

Service manual

Wheel loader

Document ID

Order number: --
Issued: 2020-08-28
Version: 00
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 509-1778

Contact

Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
A – 5500 Bischofshofen

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	030.3.5.3	Minimum quality requirement	030-17
030.3.6	Refrigerant <i>L509-1778</i> ;		030-18
030.3.7	Coolant <i>L509-1778</i> ;		030-18
	030.3.7.1	Requirements for the water used	030-18
	030.3.7.2	Antifreeze and corrosion inhibitor	030-18
	030.3.7.3	Minimum quality requirement	030-18
030.3.8	Hydraulic oil <i>L509-1778</i> ;		030-19
	030.3.8.1	Liebherr recommendation	030-19
	030.3.8.2	Minimum quality requirement	030-19
	030.3.8.3	Oil analysis	030-19
	030.3.8.4	Oil change	030-20
030.3.9	Transmission <i>L509-1778</i> ;		030-20
	030.3.9.1	Liebherr recommendation	030-20
	030.3.9.2	Minimum quality requirement	030-20
030.3.10	Axle oil <i>L509-1778</i> ;		030-20
	030.3.10.1	Liebherr recommendation	030-20
	030.3.10.2	Minimum quality requirement	030-21
030.3.11	Brake oil <i>L509-1778</i> ;		030-21
	030.3.11.1	Liebherr recommendation	030-21
030.3.12	Lubrication grease <i>L509-1778</i> ;		030-21
	030.3.12.1	Liebherr recommendation	030-21
	030.3.12.2	Minimum quality requirement	030-21
030.3.13	Lubrication grease for sliding surface on telescopic lift arms <i>L509-1778</i> ;		030-22
	030.3.13.1	Liebherr recommendation	030-22
	030.3.13.2	Minimum quality requirement	030-22
030.3.14	Windscreen washer fluid <i>L509-1778</i> ;		030-22
	030.3.14.1	Liebherr recommendation	030-22
	030.3.14.2	Minimum quality requirement	030-22
030.3.15	Refrigerant oil for air conditioning compressor <i>L509-1778</i> ;		030-23

090	Steering system	090-1
090.1	Steering system overview <i>L509-1778;</i>	090-2
090.2	Servostat <i>L509-1778;</i>	090-4
100	Brake system	100-1
100.1	Overview of brake system <i>L509-1778;</i>	100-2
100.2	Service brake	100-7
100.2.1	Inch/brake unit <i>L509-1778;</i>	100-7
100.2.2	Inching function angle sensor <i>L509-1778;</i>	100-13
100.2.3	Brake light pressure switch <i>L509-1778;</i>	100-15
100.2.4	Drum brake <i>L509-1778;</i>	100-16
100.3	Parking brake	100-21
100.3.1	Valve block for parking brake and differential lockout <i>L509-1778;</i>	100-21
100.3.2	Orifice bypass solenoid valve <i>L509-1778;</i>	100-23
110	Electrical system	110-1
110.1	Electronic control unit	110-2
110.1.1	Central control unit (Master5 Mini) <i>L509-1778;</i>	110-2
110.1.2	Modules	110-4
110.1.2.1	Compact module <i>L509-1778;</i>	110-5
110.2	Electrical components of the driver's cab	110-11
110.2.1	Fuse boards <i>L509-1778;</i>	110-11
110.2.2	Door contact switch <i>L509-1778;</i>	110-13
110.3	Electrical components in the rear section	110-14
110.3.1	Battery installation <i>L509-1778;</i>	110-14

010.1.2.5 Disposal

Danger to life

Unapproved disposal of gas containers and pressure vessels

- Before disposal, completely depressurise pressure vessel.
- Before disposal, professionally empty pressure vessel.
- Adhere to safety instructions of pressure vessel manufacturer.

Unapproved disposal of refrigerant

- Have refrigerant disposed of by refrigerant recycling point.
- Adhere to safety data sheet of refrigerant during disposal.

Environmental pollution

Unapproved disposal of machine

- Make sure that the individual elements of the machine are disposed of correctly after the service life.
- Dispose of elements of machine in line with valid country-specific waste disposal guidelines and relevant valid laws.
- Remove fuels, operating fluids and lubricants from all components before disposal.
- Collect and store fuels, operating fluids and lubricants in suitable containers before disposal.
- Adhere to instructions of relevant manufacturer when disposing of fuels, operating fluids and lubricants.
- Have fuels, operating fluids and lubricants disposed of by old oil recycling point.

010.1.3 Description of staff

010.1.3.1 Personal protective equipment

Operators, assistants and maintenance staff are responsible for the following:

- Wearing personal protective equipment
- Regular cleaning and care of protective equipment
- Immediate replacement of damaged parts of protective equipment

The protective equipment consists of following elements:

- Protective helmet
- Safety glasses
- Hearing protection
- Breathing equipment
- Protective gloves
- Warning clothing (reflective, in signal colour)
- Safety boots
- Special protective clothing
 - To prevent burns
 - To prevent freezing
 - To prevent acid burns
 - To prevent stabbing and cutting injuries

- Use viewing devices if necessary to observe areas around the machine that cannot be seen directly.
- Position working attachment so that sufficient visibility is ensured.
- Work with spotter if visibility is restricted.
- Agree on which hand signs to use.
- If necessary communicate via radio.
- Make sure that spotter is outside danger zone.
- In conditions of poor visibility use illumination in accordance with the applicable regulations.
- Work with extra care and attention in poor visibility and changing weather.
- Only use sun visors if field of vision is not restricted.

Incorrect operation

- Comply with national regulations regarding sufficient visibility in the operator's cab.
- Before operation, check viewing devices for function, cleanliness and correct setting.
- Adjust mirrors so that the best possible all-round visibility is guaranteed.
- Immediately repair defective viewing devices or have them replaced.
- Clean dirty cab windows.
- Avoid covering of visual aids by working attachment.

Damage

Incorrect changes

- Make sure that modifications to the machine do not impair visibility.
- Perform risk analysis again.
- Test machine according to current standards.
- Test machine according to regulations applicable at place of use.
- Depending on the test result, take appropriate measures.
- Inform operator about modifications.

010.1.6.7 Protection against vibration

Injuries


Incorrect working method

- Use machine, working attachment and working tool adapted to the task.
- Check condition of machine (tyre pressure, brakes, steering, mechanical connections, ...).
- Ensure that operator's seat is functional and complies with national regulations.
- Adjust operator's seat to weight and size of operator.
- Adjust shock absorption to weight and size of operator.
- Do not use jerky movements to steer, brake, accelerate and shift gears.
- Do not use jerky movements to move and load working attachment.

Incorrect travel






- Adapt speed to route.
- Travel slowly on rough terrain.
- Travel around obstacles and very rough terrain.
- Travel over longer distances (for example, on public roads) at a suitable (medium) speed.

010.2.5 Special tools for the service brake

Designation	Item code	Remark	Fig.
Feeler gauge 4.3 mm/4.5 mm	8145535	For checking the brake discs for wear	

Tab. 8: Special tools for the service brake

010.2.6 Special tools for the electrical system

Designation	ID number	Remark	Fig.:
Digital multimeter	10018500	For measuring voltage, current, resistance and frequency	
Test probe, red	884191214	For measurements at plug connections	
Test probe, black	884191114	For measurements at plug connections	
Solenoid tester	10028268	For testing solenoid valves	
Battery plug tool	11839123	For opening the plugs on the battery cells	

LBH/—/00/211—20200828_082818/en

Metric standard threads and fine threads				Metric standard threads and fine threads			
At least one element of the bolted joint (bolts, washers, nuts etc.) with the following surface: fIZn = zinc flake coating (LH standard 10021432, LH standard 10215295 fIZnnc-480h-L valid \geq M6)				All elements of the bolted joint (bolts, washers, nuts etc.) with the following surface: Black oxide or phosphated Galvanised (LH standard 10215295 Fe//ZnNi(12)5//Cn//T2)			
Minimum total coefficient of friction $\mu_G = 0.09$				Minimum total coefficient of friction $\mu_G = 0.11$			
Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm	Thread	Strength class	Assembly prestressing forces F_M in kN	Tightening torques M_A in Nm
M 22 x 1.5	8.8	180	480	M 22 x 1.5	8.8	180	570
	10.9	270	700		10.9	260	830
	12.9	310	820		12.9	310	970
M 24	8.8	190	570	M 24	8.8	185	660
	10.9	280	840		10.9	270	970
	12.9	320	980		12.9	320	1140
M 24 x 1.5	8.8	220	620	M 24 x 1.5	8.8	215	730
	10.9	320	910		10.9	320	1080
	12.9	380	1070		12.9	370	1250
M 24 x 2	8.8	210	600	M 24 x 2	8.8	205	710
	10.9	310	890		10.9	300	1040
	12.9	360	1040		12.9	350	1220
M 27	8.8	245	830	M 27	8.8	240	970
	10.9	360	1230		10.9	360	1450
	12.9	420	1450		12.9	420	1650
M 27 x 1.5	8.8	280	900	M 27 x 1.5	8.8	280	1060
	10.9	410	1300		10.9	410	1550
	12.9	480	1550		12.9	480	1850
M 27 x 2	8.8	270	880	M 27 x 2	8.8	260	1030
	10.9	400	1300		10.9	390	1500
	12.9	460	1500		12.9	460	1800
M 30	8.8	300	1140	M 30	8.8	290	1300
	10.9	440	1650		10.9	430	1950
	12.9	520	1950		12.9	510	2250
M 30 x 1.5	8.8	350	1240	M 30 x 1.5	8.8	350	1450
	10.9	520	1800		10.9	510	2150
	12.9	610	2150		12.9	590	2500
M 30 x 2	8.8	340	1220	M 30 x 2	8.8	330	1450
	10.9	500	1800		10.9	490	2100
	12.9	580	2100		12.9	570	2450

LBH/-/00/211-20200828_082818/en

020.10	Gearbox	020-33
020.10.1	Transmission <i>L509-1778;</i>	020-33
020.10.2	Output B101 speed sensor <i>L509-1778;</i>	020-33
020.10.3	Hydro accumulator for external servo pressure and service brake <i>L509-1778;</i>	020-33
020.11	Axles and drive shafts	020-34
020.11.1	Front axle with engageable differential lockout <i>L509-1778;</i>	020-34
020.11.2	Rear axle when front axle has engageable differential lockout <i>L509-1778;</i>	020-34
020.11.3	Drive shaft <i>L509-1778;</i>	020-34
020.11.4	Tyres <i>L509-1778;</i>	020-34
020.11.4.2	Special tyres	020-35
020.12	Working attachment	020-37
020.12.1	Quick coupler locking hydraulic cylinder <i>L509-1778;</i>	020-37
020.13	Operator's cab, heating and air conditioning	020-38
020.13.1	Dryer <i>L509-1778;</i>	020-38
020.13.2	Pressure switches <i>L509-1778;</i>	020-38
020.14	Lubrication system	020-39
020.14.1	Central lubrication pump EP1 <i>L509-1778;</i>	020-39
020.14.2	Progressive distributor <i>L509-1778;</i>	020-39
020.14.2.1	MX-F	020-39
020.14.2.2	MX-F 25	020-39
020.14.2.3	MX-F 45	020-39
020.14.2.4	MX-F 75	020-40
020.14.2.5	MX-F105	020-40

Load curve for pallet, other




Fig. 67: Load curve for pallet, other

LBH/-00/211-20200828_082818/en

020.4 Working hydraulics

020.4.1 Working pump

Valid for: L509-1778;

Description	Unit	Value
Type		KP25.38D0
Direction of rotation		Clockwise
Displacement per turn	cm ³	38
Maximum displacement	l/min	94
Weight	kg	14

020.4.2 Pilot control hydro accumulator

Valid for: L509-1778;

Description	Unit	Value
Volume	l	0.32
Nitrogen filling pressure at 21 °C	bar	15 ±1
Weight	kg	1.39

020.4.3 Stabilisation module

Valid for: L509-1778;

This equipment is optional.

Description	Unit	Value
Type		RSM2-10B2X
Weight	kg	4.7

020.4.4 Ride control hydro accumulator

Valid for: L509-1778;

This equipment is optional.

Description	Unit	Value
Number		1
Volume	l	0.75
Gas-side oil filling	cm ³	70
Weight	kg	4

020.10 Gearbox

020.10.1 Transmission

Valid for: L509-1778;

Description	Unit	Value
Type		367
1st gear ratio		2.75
2nd gear ratio		1.31
Weight	kg	76

020.10.2 Output B101 speed sensor

Valid for: L509-1778;

Description	Unit	Value
Type		Hall sensor
Number of teeth at the measuring point		48

020.10.3 Hydro accumulator for external servo pressure and service brake

Valid for: L509-1778;

Description	Unit	Value
Volume	l	0.32
Weight	kg	1.3

030.4.4.5	Diesel engine: changing V-belt <i>L509-1778;</i>	030-63
030.4.4.6	Diesel engine: checking valve clearance <i>L509-1778;</i>	030-64
030.4.4.7	Fuel tank: draining condensate and sediment <i>L509-1778;</i>	030-68
030.4.4.8	Draining off condensate from the fuel pre-filter <i>L509-1778;</i>	030-69
030.4.4.9	Changing fuel pre-filter element <i>L509-1778;</i>	030-70
030.4.4.10	Changing fuel fine filter element <i>L509-1778;</i>	030-71
030.4.4.11	Cleaning the service cover and dust discharge valve of the air filter system <i>L509-1778;</i>	030-73
030.4.4.12	Checking air filter vacuum switch function <i>L509-1778;</i>	030-74
030.4.4.13	Cleaning or changing main element of air filter system <i>L509-1778;</i>	030-76
030.4.4.14	Changing safety element of air filter system <i>L509-1778;</i>	030-78
030.4.4.15	Checking that diesel engine intake and exhaust system is in good condition and not loose or leaking <i>L509-1778;</i>	030-79
030.4.4.16	Cleaning or changing diesel particulate filter <i>L509-1778;</i>	030-82
030.4.5	Cooling system	030-88
030.4.5.1	Cooling system: checking coolant level <i>L509-1778;</i>	030-88
030.4.5.2	Coolant: checking anti-freeze and corrosion protec- tion agent concentration <i>L509-1778;</i>	030-90
030.4.5.3	Cleaning the cooling system <i>L509-1778;</i>	030-97
030.4.5.4	Changing coolant in cooling system <i>L509-1778;</i>	030-98
030.4.6	Hydraulic components	030-101
030.4.6.1	Checking oil level in hydraulic tank <i>L509-1778;</i>	030-101
030.4.6.2	Draining off condensate and sediment from hydraulic tank <i>L509-1778;</i>	030-103
030.4.6.3	Hydraulic tank: changing filter cartridge in return- suction filter <i>L509-1778;</i>	030-104

Customer:.....Machine type:.....Serial no.:.....Operating hours:.....Date:.....

Maintenance / inspection after service hours							Tasks to be performed				
On handover	All 8-10 h	All 50 h	All 500 h	All 1000 h	All 2000 h	Other intervals	Additional labelling	By maintenance staff	By authorised specialist staff	Confirm tasks	See page
								■ Once-only activity ● Repeat interval † If necessary ✱ Annually before the winter Additional labelling ††† Assistance required ‡ Have this task carried out exclusively by a certified electrician	□ Once-only activity ○ Repeat interval † If necessary		
			○	○	○	†			Fill windscreen washer fluid in the windscreen washer system.	■	030-147
			○	○	○				Lubricate locking mechanism and cylinder of operator's cab with penetrating oil.	■	030-148
				○	○	†			Clean and maintain the seals of the operator's cab.	■	030-149
			○	○	○				Air conditioning (option): check V-belt.	■	030-150
					○				Air conditioning (option): change V-belt (at least every 2 years)	■	030-152
			○	○	○				Check the indicator bead in the air conditioning dryer-collector unit.	■	030-154
			○	○	○				Heating and air conditioning unit (option): test function.	■	030-155
Lubrication system											
□		●	○	○	○				Check level in grease reservoir of central lubrication system (option).	■	030-156
□		●	○	○	○				Central lubrication system (option): check pipes, hoses and lubrication points for leaks and damage.	■	030-157
□		●	○	○	○				Central lubrication system (option): check lubrication of bearings.	■	030-158

LBH/-/00/211-20200828_082818/en

030.3.15 Refrigerant oil for air conditioning compressor

Valid for: L509-1778;

030.3.15.1 Liebherr recommendation

Designation
ZXL 100 PG (PAG Oil)

Tab. 53: Liebherr recommendation



Note

See Section 030.2 for filling quantities

Specifications for sampling

- ▶ Enter component of consumed fuel.

Machine location / remark

If machine is operated on site with difficulty factors:

- ▶ Enter difficulty factor.

Examples of difficulty factors:

- Working in extreme climates
- Working in elevations and depressions
- Working in water
- Working in dust-intensive use

Customer specifications

Kunde Customer / Client

Kundennummer Customer number
Firma Company
Name Name
Straße, Postfach Street, P.O. Box
Land, PLZ, Ort Country, ZIP, City
Telefon, Mobil Phone, Mobile
E-Mail Email
Probenentnahme durch Sampling by
Probe betrifft Firma Sample relates to

Fig. 119: Customer specifications

- ▶ Enter customer specifications.

LBH/-/00/211-20200828_082818/en

**CAUTION**

Hot fluids!
Burns.

- ▶ Avoid skin contact with fluids.

- ▶ Connect test line 1 to high pressure test connection **PA** on control valve block.
- ▶ Drain at least 0.2 l of hydraulic oil into receptacle.
 - ▷ Test line 1 is flushed.
- ▶ Fill sample container 2.
- ▶ Disconnect test line 1 from high pressure test connection **PA**.
- ▶ Turn off diesel engine.
- ▶ Prepare sample container for shipping. (For more information see: [Preparing sample container for shipping, page 030-38](#))

Gear oil

Coolant sample is taken from transmission.

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 1.
- Service access is open.
- Machine is cold.
- Sampling point is cleaned.

Make sure that following tools are ready:

- Hand pump
- Sampling hose
- Analysis set (For more information see: [Analysis set, page 030-36](#))




Fig. 150: Sampling point on transmission

- | | |
|---|---|
| <ul style="list-style-type: none"> 1 Filling plug 2 Sampling hose | <ul style="list-style-type: none"> 3 Hand pump |
|---|---|

- ▶ Loosen nut **2** and screw **1**.
- ▶ Adjust V-belt tension with screw **3**.
- ▶ Tighten nut **2** and screw **1**.
- ▶ Check V-belt tension and correct if necessary.
- ▶ Start diesel engine and let it run for 5 minutes.
- ▶ Turn off diesel engine.
- ▶ Put machine in maintenance position 1.

**WARNING**

Hot components!
Risk of injury.

- ▶ Do not open the service hatch until the engine has cooled down.

- ▶ Check V-belt tension again and correct it if necessary.

030.4.4.5 Diesel engine: changing V-belt

Valid for: L509-1778;

Changing V-belt

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 1.
- Diesel engine has cooled down.
- Service access is open.




Fig. 160: Setting V-belt tension

- | | |
|--|--|
| <ul style="list-style-type: none"> 1 Screw 2 Counter nut | <ul style="list-style-type: none"> 3 Adjusting screw |
|--|--|

- ▶ Loosen nut **2** and screw **1**.
- ▶ Relieve V-belt with screw **3**.
- ▶ Remove V-belt.

030.4.4.11 Cleaning the service cover and dust discharge valve of the air filter system

Valid for: L509-1778;



Note

If the valve is damaged, the dust discharge function is impaired and the filters become clogged more quickly.

- ▶ With the diesel engine running at lower idle speed, you should clearly feel air pulsating at the dust discharge valve.

Make sure that following requirements are met:

- Machine is in maintenance position 1.
- Service access is open.
- Diesel engine has cooled down.
- Suitable protective equipment is used.

Cleaning the service cover




Fig. 170: Clean the service cover and dust discharge valve of the air filter system.

- | | | | |
|---|----------------------|---|----------------|
| 1 | Dust discharge valve | 3 | Service cover |
| 2 | Fixing clips | 4 | Filter housing |

- ▶ Open fixing clips 2 and take off the service cover 3.
- ▶ Clean the service cover 3 and place it back onto the filter housing 4.
 - ▷ The dust discharge valve 1 must face down.
- ▶ Place the service cover 3 fully over the filter housing 4.
- ▶ Close the fixing clips 2.

Cleaning the dust discharge valve



Note

When using the machine in dusty conditions:

- ▶ Check and empty the dust discharge valve more often.

- ▶ Remove fastening bolts **5** around circumference of diesel particulate filter **2**.
- ▶ Remove output module **3**.
- ▶ Remove diesel particulate filter **2**.
- ▶ Attach new metal seals to new diesel particulate filter.
- ▶ Fit a new diesel particulate filter.
- ▶ Replace the bolts and nuts around the diesel particulate filter.
- ▶ Screw the new diesel particulate filter on to the diesel oxidation catalyst and the output module again.
- ▶ Install differential pressure line **4** to diesel particulate filter.
- ▶ Start diesel engine.

**WARNING**

Rotating parts!
Risk of injury.

- ▶ Do not touch rotating parts of the engine.

**WARNING**

Hot components!
Risk of injury.

- ▶ Do not touch components of the exhaust system and the engine.

- ▶ Check that diesel particulate filter does not leak.
- ▶ Turn off diesel engine.
- ▶ Confirm that diesel particulate filter has been changed with the Yanmar SMARTASSIST diagnostic software.

Confirm that diesel particulate filter has been changed with the Yanmar SMARTASSIST diagnostic software.

Make sure that following requirements are met:

- Machine is in maintenance position 1.

Make sure that following tools are ready:

- Laptop Yanmar SMARTASSIST diagnostic software
- Diagnostic cable for Yanmar SMARTASSIST diagnostic software
- ▶ Connect the Yanmar SMARTASSIST diagnostics software with diesel engine.

- ▷ Amount of pure antifreeze and corrosion inhibitor to top up = 6,5 l.

Example 2:

- ▶ Identified freezing point = -58 °C.
- ▶ Total capacity of the cooling system = 60 l.
 - ▷ Freezing point too low.
 - ▷ Amount of pure water to top up = 6.5 l.

Correcting the antifreeze and corrosion inhibitor concentration




Fig. 192: Correcting the antifreeze and corrosion inhibitor concentration

- | | |
|-----------------------|---------------|
| 1 Cap of water cooler | 3 Drain valve |
| 2 Water cooler | |

- ▶ Place a receptacle under the machine.
- ▶ Unscrew the cap from the drain valve 3.
- ▶ Screw drain hose onto drain valve 3.
 - ▷ Coolant flows out.
- ▶ Drain off as much coolant as the amount to be topped up.
- ▶ Unscrew drain hose from drain valve 3.
- ▶ Screw the cap onto the drain valve 3.

NOTICE

Non-approved coolant!
Damage to the engine and cooling system.

- ▶ Only use coolant that meets the Liebherr specifications.
 - ▶ Do not mix coolants with and without silicates.
-

- ▶ Completely fill water cooler 2 2 with pure anti-freeze and corrosion protection agent or pure water.
- ▶ Close cap of water cooler 1.
- ▶ Start diesel engine.

030.4.6.2 Draining off condensate and sediment from hydraulic tank

Valid for: L509-1778;

Make sure that following requirements are fulfilled:

- Machine has not been started for at least an hour.
- Machine is in maintenance position 1.
- Service access is open.

Make sure that following tools are ready:

- Drain hose
- Receptacle



Note

To completely drain condensate and sediment, impurities must settle on bottom of hydraulic tank.

- ▶ Do not start the machine for at least an hour.



Fig. 202: Draining off condensate and sediment from the hydraulic tank

- | | | | |
|---|-----------------|---|-------------|
| 1 | Breather filter | 3 | Drain valve |
| 2 | Plug | | |

- ▶ Insert plug 2 in breather filter 1.
 - ▷ The anti-twist device is released.
- ▶ Unscrew the breather filter 1 by two turns.
 - ▷ The tank preload pressure is released.
- ▶ Place a receptacle under the machine.
- ▶ Unscrew the cap from the drain valve 3.
- ▶ Screw the drain hose onto the drain valve 3.
 - ▷ Condensate and sediment drain off.
- ▶ Let condensate and sediment drain into receptacle.

When clean hydraulic oil comes out:

- ▶ Unscrew drain hose from drain valve 3.
- ▶ Screw the cap onto the drain valve 3.
- ▶ Tighten the breather filter 1.
- ▶ Pull out the plug 2 and keep it in a safe place.
 - ▷ The breather filter is protected from accidental opening.
- ▶ Check the oil level in the hydraulic tank.

Description	Unit	Value
Minimum thickness s1 of each brake lining	mm	2.0

If required value is not reached:

- ▶ Replace brake shoes.

If required value is reached:

- ▶ Check gap.

Checking gap



Fig. 213: Checking gap

1 Brake lining (2x)

s2 Gap (2x)

- ▶ Use a feeler gauge to check that both gaps **s2** are correct.

Description	Unit	Value
Gap s2	mm	0.55 ^{+0.30}

If required value is not reached:

- ▶ Check adjuster.

If required value is reached:

- ▶ Put plugs back in inspection openings.

030.4.8.4 Service brake: checking brake plates for wear

Valid for: L509-1778;



WARNING

Changes in braking performance are a sign that brake discs are worn!
Accidents.

- ▶ If there are changes in braking performance, check gap and wear on brake discs.



WARNING

Longer braking distance!
Accidents.

- ▶ Replace brake discs before they become too worn.

- ▶ Fill axle oil up to bottom of opening. (For more information see: 030.2.1 Lubricant filling quantity, page 030-14)

If the oil level is correct:

- ▶ Screw in filling plug 1 and tighten it to 45 ± 5 Nm.
- ▶ Repeat procedure on the rear axle.
- ▶ Check oil level in wheel hubs.

Checking oil level in wheel hubs




Fig. 221: Checking oil level in wheel hubs

1 Maintenance plug (4x)

- ▶ Park machine so that oil level marking on left wheel hub of front axle is horizontal (maintenance plug 1 at 9 o'clock).
- ▶ Put machine in maintenance position 2.
- ▶ Carefully open maintenance plug 1 on left wheel hub of front axle.
- ▶ Check that the oil level is up to bottom of the opening.

If oil level is too low:

- ▶ Check wheel hub for leaks.
- ▶ Fill axle oil up to bottom of opening. (For more information see: 030.2.1 Lubricant filling quantity, page 030-14)

If oil level is correct:

- ▶ Screw in maintenance plug 1 and tighten it to 45 ± 5 Nm.
- ▶ Repeat process for the other wheel hubs.

030.4.11.2 Changing axle oil

Valid for: L509-1778;

Make sure that following requirements are fulfilled:

- Oil is at operating temperature.
- Machine is in maintenance position 2.

- ▶ Apply silicon spray to the seal 1.
- ▶ (For more information see: [Opening service hatches, page 030-26](#))

030.4.13 Working attachment

030.4.13.1 Quick coupler: checking function

Valid for: L509-1778;

Make sure the following preconditions are met:

- Diesel engine has started.
- The lift arms have been lowered.
- The working attachment is tilted in.



WARNING

Persons in the danger area!
Risk of injury.

- ▶ Make sure there is nobody in the danger area.
-
- ▶ Unlock quick coupler and lock it again.
 - ▷ This prevents the locking pins from jamming and preventing the quick coupler from being released.
 - ▶ For safety reasons, check that quick coupler is locked again.

030.4.13.2 Lubricating telescopic lift arms and working attachment

Valid for: L509-1778;

For jobs that require daily cleaning, lift arms and working attachment must be lubricated every day.

Make sure that following requirements are fulfilled:

- Machine is in maintenance position 2.
- The working attachment is disconnected for lubricating points near the bucket coupling, which are difficult to access.
- The lubricating point has been cleaned.

- ▶ Remove energy chain **5**: loosen screws **6**.
- ▶ Change slide elements. (For more information see: [Changing slide elements, page 030-144](#))

Changing slide elements at top rear




Fig. 243: Supporting lift arms for changing slide elements at top rear

1	Extension	5	Energy chain
2	Base section	6	Screw (4x)
3	Protective flap	7	Rear top slide element (4x)
4	Screw (4x)		


- ▶ Turn steering wheel as far as it will go.
 - ▷ Slide elements are more accessible.
- ▶ Retract extension **1** to stop.

NOTICE

Improper support of lift arms!
Damage to working attachment.

- ▶ Ensure that no hydraulic hoses get caught and pinched.
- ▶ Make sure that linkage is not touching.

- ▶ Support lift arms with supporting material on extension **1**.
 - ▷ Slide elements at top rear are relieved.
- ▶ Turn off diesel engine and take out ignition key.
- ▶ Remove protective flap **3**: loosen screws **4**.
- ▶ Remove energy chain **5**: loosen screws **6**.
- ▶ Change slide elements. (For more information see: [Changing slide elements, page 030-144](#))



92051807


Fig. 254: Setting V-belt tension

- | | |
|---|---|
| <p>1 Tensioning device</p> <p>2 Air conditioning compressor</p> | <p>3 V-belt of compressor magnetic coupling</p> |
|---|---|
- ▶ Relieve V-belt 3 with tensioning device 1.
 - ▶ Remove V-belt 3.
 - ▶ Install new V-belt.
 - ▶ Set V-belt tension. (For more information see: [Setting V-belt tension, page 030-153](#))

Setting V-belt tension

Make sure that following requirements are met:





- Machine is in maintenance position 1.
- Diesel engine has cooled down.
- Service access is open.



92051807

Fig. 255: Setting V-belt tension

- | | |
|---|---|
| <p>1 Tensioning device</p> <p>2 Air conditioning compressor</p> | <p>3 V-belt of compressor magnetic coupling</p> |
|---|---|

Symbol	Meaning	Symbol	Meaning
⇒	Machine in blocked condition		Checkbox
○	Always carry out		Link to the instructions
◇	Only if necessary		Sculi diagnostic software is required
	Entry field		Read the values from the display

Tab. 79: Key




Fig. 267: Connecting SMARTASSIST-Direct diagnostics software to diesel engine

- 1 ECU Access tab
- 2 Set Value Copy function
- 3 Data Rate function
- 4 Engine function
- 5 ECU Search function
- 6 Serial number of ECU
- 7 Start function

- ▶ Switch on battery main switch.
- ▶ Switch on ignition.
- ▶ Run SMARTASSIST-Direct diagnostic software.
- ▶ Select *ECU Access* tab 1.
- ▶ Select *Set Value Copy* function 2.
- ▶ For the *Data Rate* function 3 select a connection speed of 250k.
- ▶ Select *Engine* function 4.
- ▶ Select *ECU Search* function 5.
 - ▷ Serial number of ECU 6 is displayed.
- ▶ Select *Start* function 7.
 - ▷ Connection is made to engine control unit (ECU).




Fig. 268: Saving data

- 1 ECU Backup (ECU to PC) function
- 2 Old ECU data function
- 3 Next function
- 4 Next function

LBH-/007/211-20200828_082818/en

g2052594




Fig. 284: Test connection for standard version / test connection for version with reversible fan drive

PK Cooling system high pressure test connection

Preparations

NOTICE

Pressure peak when automatically switching on the reversible fan drive!
Damage to the fan motor.

- ▶ Make sure the reversible fan drive is deactivated.
- ▶ Connect a pressure gauge (250 bar) to cooling system high pressure test connection **PK**.
- ▶ Start diesel engine.
- ▶ Connect Sculi diagnostic software to machine.
- ▶ In variables editor, select **Check cooling system** folder.

Maximum operating pressure

- ▶ Force variable **IRHydrTempSens_KG** to 0 ohms.
 - ▷ This simulates a failure of hydraulic oil temperature sensor.
 - ▷ Central control unit energises fan speed proportional solenoid with minimum current.



Note

Variable **IRHydrTempSens_KG** is automatically reset to its original value when ignition is switched **OFF**.

- ▶ If necessary, force value to 0 ohms again when repeating test.

- ▶ Increase engine speed to maximum.
- ▶ Check that high pressure **PK** corresponds to required value.




Fig. 288: Ride control hydro accumulator: nitrogen filling

- | | | | |
|---|----------------------------------|----|---|
| 1 | Screw plug for relief valve | 9 | Outlet pressure gauge |
| 2 | Relief valve | 10 | Pressure control valve |
| 3 | Ride control hydro accumulator | 11 | Outlet valve for pressure reducer |
| 4 | Screw plug for hydro accumulator | 12 | Testing and filling device |
| 5 | Nitrogen cylinder | 13 | Pressure gauge for hydro accumulator filling pressure |
| 6 | Cylinder valve | 14 | Handwheel |
| 7 | Pressure reducer | 15 | Drain valve |
| 8 | Cylinder pressure gauge | | |

- ▶ Unscrew screw plug for relief valve 1 from stabilisation module.



WARNING

Descending lift arms!
Injury.

- ▶ Make sure that the full weight of the lift arms rests on the ground.

- ▶ Unscrew relief valve 2 by one turn.
 - ▷ Hydraulic pressure in hydro accumulator 3 is relieved into hydraulic tank.
- ▶ Install vacuum pump. (For more information, see Liebherr service documentation on removing and installing components)
- ▶ Place collecting pan under hydro accumulator 3.
- ▶ Remove hydro accumulator 3.
 - ▷ Oil side of hydro accumulator 3 is depressurised.
- ▶ Unscrew protective cap on hydro accumulator 3.



Note

Hydro accumulator 3 does not have an integrated check valve.

- ▶ Only loosen screw plug for hydro accumulator 4 before attaching testing and filling device.
- ▶ Only screw on screw plug for hydro accumulator 4 with testing and filling device.

- ▶ Loosen screw plug for hydro accumulator 4.
- ▶ Screw testing and filling device 12 onto hydro accumulator.




Fig. 298: Travel pump: high pressure relief valves

- | | | | |
|---|---|----|---|
| 1 | Pressure cut-off valve | 8 | Lock screw |
| 2 | Reverse travel direction high pressure relief valve | 9 | Valve insert |
| 3 | Forward travel direction high pressure relief valve | 10 | High pressure relief compression spring |
| 4 | Screw plug | 11 | Valve seat |
| 5 | O-ring | 12 | Adjusting screw |
| 6 | Replenishing function compression spring | MH | Travel pump high pressure test connection |
| 7 | O-ring | | |

Preparations

- ▶ Connect a pressure gauge (600 bar) to the high pressure test connection **MH** on the travel pump.
- ▶ Turn adjusting screw on pressure cut-off valve **1** by exactly one turn clockwise.
 - ▷ Opening pressure of pressure cut-off is above opening pressure of high pressure relief valves.

Checking and adjusting

- ▶ Start diesel engine.
- ▶ Connect Sculi diagnostic software to machine.
- ▶ In the variables editor, select the **Block curve calibration** folder.
- ▶ Set variable **MXdrBlockMan** to **1**.
 - ▷ Machine is in blocked condition.



Note

Variable **MXdrBlockMan** is automatically reset to its original value **0** when ignition is switched **OFF**.

- ▶ If necessary, reset value to **1** when repeating test.

Make sure that following requirements are fulfilled:

- ❑ Machine is in maintenance position 2.




Fig. 303: Inching brake pedal: basic setting

- | | | | |
|---|--------------|---|---------------------------|
| 1 | Counter nut | 3 | Pressure regulator piston |
| 2 | Threaded rod | x | Play (0.5 mm to 1 mm) |

- ▶ Start diesel engine.



WARNING

Unintended movement of machine!
Injury.

- ▶ Make sure that parking brake is activated.
- ▶ Make sure there is nobody in operator's cab.

- ▶ Remove bellows.
- ▶ Unscrew counter nut 1.
- ▶ Turn threaded rod 2 by hand up to stop on actuator piston 3.
 - ▷ Threaded rod 2 is in contact with actuator piston 3.
- ▶ Unscrew threaded rod 2 by half a turn.
 - ▷ Play x between threaded rod 2 and actuator piston 3 is about 0.5 mm to 1 mm.
- ▶ Tighten counter nut 1.

To check basic setting, inching brake pedal must be actuated by hand. If inching brake pedal is actuated by hand, light play must be felt before first action point.

- ▶ Actuate inching brake pedal by hand up to first action point.
- ▶ Check whether light play is present before reaching first action point.

If there is no light play before first action point:

- ▶ Repeat basic setting.

If there is a light play before first action point:

- ▶ Install bellows.

- ▶ Select “New” function 1.
- ▶ Select “PME 1 address book” address book 2.
- ▶ Select “Master 5 Ethernet” address 3.
- ▶ Select “Connect” function 4.
 - ▷ Connection to central control unit (Master5) is established.

Checking connections settings




Fig. 318: Checking connections settings

- | | | | |
|---|----------------------------------|---|-----------------------------|
| 1 | “New” function | 3 | “Master 5 Ethernet” address |
| 2 | “PME1 address book” address book | 4 | “Edit” function |

- ▶ Run Sculi diagnostic software.
- ▶ Select “New” function 1.
- ▶ Select “PME1 address book” address book 2.
- ▶ Select “Master 5 Ethernet” address 3.

Troubleshooting

If “Master 5 Ethernet” address is not present:

- ▶ Create “Master 5 Ethernet” address. (For more information see: [Creating “Master 5 Ethernet” address, page 030-224](#))
- ▶ Select “Edit” function 4.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




Fig. 329: Temperature/pressure diagram for air conditioning unit

- | | | | |
|---|---|---|--|
| 1 | Ambient temperature in °C | 4 | High pressure range depending on the ambient temperature |
| 2 | Low pressure range depending on the ambient temperature | 5 | High and low pressure in bar |
| 3 | Outlet temperature depending on the ambient temperature | 6 | Outflow temperature in °C |

- ▶ Connect pressure gauge strip to the quick couplings.
- ▶ Start diesel engine.
- ▶ Switch on air conditioning unit (maximum cooling).
- ▶ Set heater fan to maximum.
- ▶ Allow air conditioning compressor to run for 3 to 5 minutes.
- ▶ Measure outflow temperature at left driver-level nozzle.
- ▶ Read the values from the pressure gauge strip and compare with the temperature/pressure diagram.
 - ▷ The values must agree with the diagram.

If the values do not agree:

- ▶ Remedial measures see service docu: Documentation_Wheel-Loaders_Repair-instructions_Other_air conditioning_Basics of air conditioning

030.6.13 Options

030.6.13.1 LiDAT: connecting to LiDAT module

Valid for: L509-1778;


Make sure that following requirements are fulfilled:

- Ignition is switched off.

040 Drive group

Contents

040.1	Engine	040-2
040.1.1	Diesel engine overview <i>L509-1778;</i>	040-2
040.1.2	Electrical components of diesel engine <i>L509-1778;</i>	040-10
040.1.3	Fuel system	040-11
040.1.3.1	Overview of fuel system <i>L509-1778;</i>	040-12
040.1.3.2	Fuel level sensor <i>L509-1778;</i>	040-14
040.1.3.3	Fuel pre-filter <i>L509-1778;</i>	040-15
040.1.3.4	Fuel fine filter <i>L509-1778;</i>	040-16
040.1.4	Air filter system	040-17
040.1.4.1	Air filter <i>L509-1778;</i>	040-17
040.1.4.2	Vacuum switch for air filter <i>L509-1778;</i>	040-18
040.1.5	Exhaust system	040-18
040.1.5.1	Overview of diesel particulate filter <i>L509-1778;</i>	040-19



g2047315

Fig. 352: Electrical components of diesel engine

A4a.K62	Relay for starter	B712	Exhaust gas temperature sensor
B705	Charge air temperature sensor	G1	Alternator
B706	Sensor for coolant temperature	M1	Starter
B710	Camshaft speed sensor		

040.1.3 Fuel system

Regeneration type	Description	Soot particles in grammes per litres (g/L)	Passive or active regeneration
Assisted regeneration (Assist Regeneration)	Exhaust gas temperature regulation via throttle valve and EGR valve. Exhaust gas temperature increased by injecting more fuel. Exhaust gas temperature remains below 350 °C.	From 8 g/L	Active regeneration
Reset regeneration (Reset Regeneration)	Every 100 service hours. Exhaust gas temperature regulation via throttle valve and EGR valve. Exhaust gas temperature increased by injecting more fuel. Exhaust gas temperature above 350 °C	0 g/L to 8 g/L	Active regeneration
Manual regeneration (Stationary Regeneration)	Manually initiated. Exhaust gas temperature regulation via exhaust throttle valve and EGR valve. Exhaust gas temperature increased by injecting more fuel. Increased engine speed. Exhaust gas temperature above 350 °C	From 10 g/L	Active regeneration
Service regeneration (Recovery Regeneration)	Activated using SMARTASSIST diagnostic software or <i>regenerate diesel particulate filter</i> switch/button. Exhaust gas temperature regulation via throttle valve and EGR valve. Exhaust gas temperature increased by injecting more fuel. Increased engine speed. Exhaust gas temperature above 350 °C	From 12 g/L	Active regeneration
DPF-Reinigen	Remove and clean DPF.		Active regeneration

Tab. 85: Regeneration types

2 Function

2.1 Basic function




Fig. 381: Fan motor: hydraulic diagram (diesel engine is running)

- | | | | |
|----------|--------------------|----------|---|
| 1 | Fan pump | 4 | Fan speed proportional solenoid valve |
| 2 | Gear motor | 5 | Oil supply via fan pump |
| 3 | Replenishing valve | 6 | Return flow to travel motor (housing flushing / cooling) and hydraulic oil cooler |

Name	Test point
PK	Cooling system high pressure

Tab. 93: Test points

BMK	Function
Y13	Fan speed proportional solenoid

Tab. 94: Equipment codes

The fan motor drives the fan blade.

2.2 Fan speed proportional solenoid valve

The fan speed proportional solenoid valve **4** controls the fan speed by directing oil past the gear motor **2**. The more oil that flows through the bypass, the lower the output speed. To do this, the central control unit energises the fan speed proportional solenoid **Y13**.

If the fan speed proportional valve **Y13** fails, the bypass remains closed. This means the maximum quantity of oil flows through the gear motor **2**, and the fan turns at maximum speed. This prevents the cooling fluids from overheating in the event of a system fault (fail-safe behaviour).

The fan speed proportional solenoid **4** valve thus protects the fan system from excessive pressure. If the pressure exceeds the maximum permitted level, the fan speed proportional solenoid valve **4** also opens the bypass.

10 Filter separator plate	23 Return flow from control valve block	39 Hydraulic oil drain valve
11 Bypass valve 2.0 bar	24 Diesel engine	40 Hydraulic oil cooler
12 Screen for replenishing pump 125 µm	25 Fan pump	
13 Preload valve 0.5 bar	26 In-line filter 80 µm	

Name	Test point
PK	Cooling system high pressure

Tab. 103: Test points

BMK	Function	BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	Y13	Fan speed proportional solenoid	Y50	Fan reversal solenoid

Tab. 104: Equipment codes

If the reversible fan drive is activated, the central control unit energises the fan reversal solenoid **Y50**. The oil supply and return flow on the fan motor **34** are thus switched and the fan changes its direction of rotation.

The proportional solenoid valve for fan speed **31** works in the same way as the standard version.

050.4.2 Fan reversal valve block

Valid for: L509-1778;

1 Layout




Fig. 389: Valve block for fan reversal (from front left and from rear right)

- | | |
|--|---|
| 1 Solenoid valve for fan reversal | 5 Connection for fan motor (high pressure when fan reversal deactivated) |
| 2 Fan reversal valve block | 6 Connection for fan motor (high pressure when fan reversal activated) |
| 3 Oil supply via fan pump | 7 Feeder valve |

See next page for continuation of the image legend

LBH/00/211-20200828_082818/en

skt024/06

When it is not energised, there is no connection to pilot control unit and control block.

060.6 Pipe break protection

060.6.1 Pipe break protection: overview

Valid for: L509-1778;

This equipment is optional for lift cylinders and tilt cylinders.

1 Layout

070 Travel hydraulics

Contents

070.1	Overview of travel hydraulics <i>L509-1778;</i>	070-2
070.2	Travel pump <i>L509-1778;</i>	070-9
070.3	Travel motors	070-25
070.3.1	Travel motor <i>L509-1778;</i>	070-25

Name	Test point	Name	Test point	Name	Test point
G	Replenishing pressure	MH	Travel pump high pressure	X1	Control pressure for forward travel direction

Tab. 136: Test points

BMK	Function	BMK	Function
B102	Travel pump high pressure sensor	Y3	Reverse travel direction solenoid
Y2	Forward travel direction solenoid	Y105	Control pressure proportional solenoid (travel pump)

Tab. 137: Equipment codes

The travel pump is attached together with the working pump to the diesel engine (tandem arrangement).

The travel pump is a Axial piston variable displacement pump for the closed circuit with an internal gear pump as a replenishing pump.

2.6 Control of swivel angle by the control pressure proportional valve




Fig. 430: Control of swivel angle by the control pressure proportional valve (forward travel direction)

- | | | | | | |
|---|-------------------------------------|---|--------------------------------------|---|----------------------------|
| 1 | Regulating spring | 3 | Connection to the positioning piston | 5 | Connection to pump housing |
| 2 | Control pressure proportional valve | 4 | Oil from the replenishing pump | | |

BMK	Function
Y105	Control pressure proportional solenoid (travel pump)

Tab. 142: Equipment codes

The control pressure proportional valve **2** generates the control pressure that moves the variable displacement pump. To do this, the central control unit energises the control pressure proportional solenoid **Y105** via the compact module.

The central control unit increases the current from the following parameters:

- Position of travelling pedal
- Position of inching brake pedal
- Presence of overspeed or excess travel speed
- Presence of excessive temperature of hydraulic oil
- Active load limiting function
- Set speed limit (V_{max})

When de-energised, the spring force of regulating spring **1** moves the proportional valve **2** so that the control pressure flows into the pump housing **5**.

When the control pressure proportional solenoid **Y105** is energised, it moves the proportional valve **2** against the spring force of regulating spring **1**. As a result, the proportional valve **2** opens the connection to the replenishing pressure duct **4** until the control pressure and the spring force of regulating spring **1** move the proportional valve **2** back against the proportional solenoid **Y105**.

LBH-/007/211-20200828_082818/en

BMK	Function
Y106	Servo pressure proportional solenoid (travel motor)

Tab. 151: Equipment codes

The swivel angle of axial piston rotary group is regulated by the central control unit via the servo pressure valve 2 electrically and proportionally.

If the proportional solenoid for servo pressure Y106 is not energised, the servo pressure valve 2 connects the servo pressure M1 with the motor housing. The high pressure 1 pushes the axial piston rotary group to a smaller swivel angle. Output speed and high pressure rise.

If the central control unit energises the proportional solenoid for servo pressure Y106, it moves the servo pressure valve 2 against the spring force of 2nd regulating spring 3. The servo pressure valve 2 thus connects the positioning piston 7 to the high pressure 1. Due to the larger surface on the positioning piston 7, the high pressure 1 swivels the axial piston rotary group to a larger swivel angle. Output speed and high pressure decrease.

As the swivel angle increases, the 1st regulating spring 5 is preloaded more. If the spring force of 1st regulating spring 5 exceeds the force of proportional solenoid for servo pressure Y106, the servo pressure valve 2 disconnects the high pressure 1 from the positioning piston 7 again. As a result, the swivel angle is maintained based on the current at the proportional solenoid for servo pressure Y106.

2.3.1 Gear changes

During a gear change, swivel angle of travel motor is adjusted in order to synchronise output speed with new transmission ratio. Because at this point no high pressure is available for adjustment, oil is fed from hydro accumulator for external servo pressure and service brake via external servo pressure solenoid. (For more information see: [Function, page 120-10](#)) (For more information see: [Gearshift strategy, page 120-19](#))

2.4 Discharge (cooling)




Fig. 439: Discharge if no travel direction is selected / discharge for forward travel direction

- | | | | |
|---|-----------------------------|---|-----------------------|
| 1 | Discharge valve | 3 | Pressure relief valve |
| 2 | Connection to motor housing | 4 | Orifice |

Oil is constantly drained via the discharge valve 1 and pressure relief valve 3 from the closed circuit to the motor housing 2. The replenishing pump replaces this oil with cooled oil from the hydraulic tank. The discharge thus cools the entire closed circuit.

2 Function

2.1 Basic function




Fig. 445: Return-suction filter: hydraulic diagram

1	Return suction filter	8	Feeder valve
2	Temperature valve	9	Connection to steel tank
3	Filter element 10 µm	10	Replenishing pump suction port
4	Filter separator plate	11	Return flow from servostat, inch/braking unit and solenoid valve for transmission control unit
5	Bypass valve 2.0 bar	12	Return flow from hydraulic oil cooler (uncooled)
6	Screen for replenishing pump 125 µm	13	Return flow from hydraulic oil cooler (cooled)
7	Preload valve 0.5 bar	14	Return flow from control valve block

Return suction filter collects and filters oil returning from hydraulic components. Oil then flows into steel tank.

Replenishing pump draws oil through strainer 6 directly from return suction filter.

7	Return suction filter	26	Gear pump	47	Chamber isolation for steering right (emergency steering function)
8	Temperature valve	27	Priority valve	48	Check valve
9	Filter element	28	Throttle	49	Feeder valve for steering to left
10	Filter separator plate	29	Fine filter	50	Feeder valve for steering to the right
11	Bypass valve 2.0 bar	30	Throttle	51	Secondary pressure relief valve for steering to left
12	Screen for replenishing pump 125 µm	31	Throttle	52	Secondary pressure relief valve for steering to right
13	Preload valve 0.5 bar	32	Travel pump	53	LS pressure relief valve
14	Feeder valve	33	Diesel engine	54	Throttle
15	Steel tank	34	Oil supply for control valve block	55	Throttle check valve
16	Hydraulic oil drain valve	35	Return flow from transmission control solenoid valve	56	Steering cylinder
17	Fan pump suction port	36	Return flow from inch/brake unit		
18	Sight glass for hydraulic oil level	40	Servostat		

BMK	Function
B8	Hydraulic oil temperature sensor

Tab. 156: Equipment codes

The steering system is an open circuit. This means that, after leaving the consumer, the oil flows to the hydraulic tank rather than directly back to the pump.

Working pump **25** draws oil from hydraulic tank **1** and transports it via priority valve **27** to control block **34** and servostat **40**. Priority valve **27** distributes oil to two systems. Steering system has priority of supply.

Servostat **40** delivers a measured quantity of oil to steering cylinder **56** with every turn of steering wheel. The servostat **56** also generates a load sensing signal which regulates priority valve **27**.

Oil returning from steering cylinder **56** flows through return suction filter **7** back into hydraulic tank **1**.

13 Preload valve 0.5 bar	34 Flushing orifice 1,0 mm	58 Spring accumulator brake piston for parking brake
14 Feeder valve	35 Valve block for parking brake and differential lockout	59 Brake piston for service brake (1st brake circuit)
15 Steel tank	36 Check valve 1	60 Drum brake
16 Hydraulic oil drain valve	37 Check valve 2	61 Brake piston for service brake (2nd brake circuit)
17 Working pump suction port	38 Flushing throttle 1.5 mm	62 Return flow from servostat
18 Fan pump suction port	39 Parking brake solenoid valve	63 Return flow from pilot control unit
19 Sight glass for hydraulic oil level	40 Solenoid valve for differential lockout	64 Return flow from transmission control solenoid valve

Name	Test point	Name	Test point
G	Replenishing pressure (2x)	M4	Brake pressure in 1st brake circuit (front axle)

Tab. 161: Test points

Name	Test point
G	Replenishing pressure (2x)

Tab. 162: Test points

BMK	Function	BMK	Function	BMK	Function
B8	Hydraulic oil temperature sensor	R1	Inching function angle sensor	Y11	Orifice bypass solenoid
B12	Brake light pressure switch	Y10	Parking brake solenoid	Y55	Solenoid for differential lockout

Tab. 163: Equipment codes

2.1.1 Service brake

The service brake is a dual-circuit brake. The braking effect in the 1st brake circuit is generated by the wet disc brake on the front axle **55**.

The braking effect in the 2nd brake circuit is generated in the drum brake **61**, which is flange-mounted on the front axle **55**. Because there is no differential in the gearbox, the drum brake acts on both axles.

When the inching brake pedal is pressed, only the inching brake pedal **R1** is activated during the first two thirds of the pedal displacement. (For more information see: [Position of inching brake pedal, page 070-22](#)) Inching hydrostatically brakes machine. Service brake itself is not activated until final third of pedal displacement.

2.1.1.1 Braking sequence in the 1st brake circuit

The replenishing pump **26** supplies inch/brake unit **45** with oil. The service brake pressure control piston **46** directs oil to service brake pistons **57** and **59**. The service brake pistons **57** and **59** thus actuate the wet disc brake in front axle **55**. The pressure transmitted is proportional to the force applied to the pedal.

2.1.1.2 Braking sequence in 2nd brake circuit

The main brake cylinder **47** pushes oil out of the equalizing reservoir **49** into the service brake piston **61** in the drum brake **60**.

100.2.3 Brake light pressure switch

Valid for: L509-1778;

1 Layout




Fig. 470: Brake light pressure switch: sectional view

1	Brake pressure from inch/brake unit	6	Compression spring
2	Membrane	7	Adjusting screw
3	Pin	8	Connection contact
4	Contact plate	9	Connection contact
5	Switch contact	10	Switch contact

The brake light pressure switch B12 is mounted on the main service brake cylinder.

2 Function

2.1 Basic function




Fig. 471: Brake light pressure switch: equivalent circuit diagram

The brake light pressure switch closes at a brake pressure of $10^{\pm 1}$ bar. This causes the brake light to light up when braking.

110 Electrical system

Contents

110.1	Electronic control unit	110-2
110.1.1	Central control unit (Master5 Mini) <i>L509-1778;</i>	110-2
110.1.2	Modules	110-4
110.1.2.1	Compact module <i>L509-1778;</i>	110-5
110.2	Electrical components of the driver's cab	110-11
110.2.1	Fuse boards <i>L509-1778;</i>	110-11
110.2.2	Door contact switch <i>L509-1778;</i>	110-13
110.3	Electrical components in the rear section	110-14
110.3.1	Battery installation <i>L509-1778;</i>	110-14

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-R16	=K	+K2	SERIES RESISTOR	=K	+K2	SERIES RESISTOR	/71.B7
-R120	=K	+K2	TERMINATING RESISTOR CONTROL LEVER	=K	+K2	TERMINATING RESISTOR CONTROL LEVER	/31.B5
-R_H47	=K	+K2	SERIES RESISTOR	=K	+K2	SERIES RESISTOR	/17.D7
-S1	=K	+K4	STARTING SWITCH	=K	+K4	STARTING SWITCH	/16.A4
-S1.X1	=K	+K4	CONNECTOR STARTING SWITCH	=K	+K4	CONNECTOR STARTING SWITCH	/16.A5
-S1.X1.6	=K	+K4	CONNECTOR OPTION IMMOBILISER	=K	+K4	CONNECTOR OPTION IMMOBILISER	/16.A8
-S1.X2	=K	+K4	CONNECTOR STARTING SWITCH	=K	+K4	CONNECTOR STARTING SWITCH	/16.B5
-S2b	=K	+K	CONTROL LEVER	=K	+K	CONTROL LEVER	/31.E5
-S2b.X	=K	+K	CONNECTOR CONTROL LEVER	=K	+K	CONNECTOR CONTROL LEVER	/31.E3
-S2b.X1049	=K	+K	CONNECTOR CONTROL LEVER	=K	+K	CONNECTOR CONTROL LEVER	/31.E4
-S3	=K	+K1	STEERING COLUMN SWITCH	=K	+K1	STEERING COLUMN SWITCH	/41.E1
-S3.X1	=K	+K1	CONNECTOR STEERING COLUMN SWITCH	=K	+K1	CONNECTOR STEERING COLUMN SWITCH	/41.E1
-S3.X2	=K	+K1	CONNECTOR STEERING COLUMN SWITCH	=K	+K1	CONNECTOR STEERING COLUMN SWITCH	/41.D2
-S4	=K	+K	HAZARD WARNING SYSTEM SWITCH	=K	+K	HAZARD WARNING SYSTEM SWITCH	/41.A2
-S4.X	=K	+K	CONNECTOR HAZARD WARNING SYSTEM SWITCH	=K	+K	CONNECTOR HAZARD WARNING SYSTEM SWITCH	/41.A2
-S6	=K	+K	PARKING LIGHT AND LOW BEAM SWITCH	=K	+K	PARKING LIGHT AND LOW BEAM SWITCH	/36.B1
-S6.X	=K	+K	CONNECTOR PARKING LIGHT AND LOW BEAM SWITCH	=K	+K	CONNECTOR PARKING LIGHT AND LOW BEAM SWITCH	/36.A2
-S7	=K	+K	FRONT WORKING HEADLIGHTS SWITCH	=K	+K	FRONT WORKING HEADLIGHTS SWITCH	/37.A6
-S7.X	=K	+K	CONNECTOR FRONT WORKING HEADLIGHTS SWITCH	=K	+K	CONNECTOR FRONT WORKING HEADLIGHTS SWITCH	/37.B6
-S7a	=K	+K4	SWITCH ADDITIONAL HEADLIGHT REAR	=K	+K4	SWITCH ADDITIONAL HEADLIGHT REAR	/39.B4
-S7a.X	=K	+K4	CONNECTOR SWITCH ADDITIONAL HEADLIGHT REAR	=K	+K4	CONNECTOR SWITCH ADDITIONAL HEADLIGHT REAR	/39.B4
-S8	=K	+K4	REAR WORKING HEADLIGHTS SWITCH	=K	+K4	REAR WORKING HEADLIGHTS SWITCH	/38.B7
-S8.X	=K	+K4	CONNECTOR REAR WORKING HEADLIGHTS SWITCH	=K	+K4	CONNECTOR REAR WORKING HEADLIGHTS SWITCH	/38.B6
-S8a	=K	+K4	REAR WORKING HEADLIGHTS SWITCH MULTIFUNCTIONAL	=K	+K4	REAR WORKING HEADLIGHTS SWITCH MULTIFUNCTIONAL	/38.B4
-S8a.X	=K	+K4	CONNECTOR REAR WORKING HEADLIGHTS SWITCH MULTIFUNCTIONAL	=K	+K4	CONNECTOR REAR WORKING HEADLIGHTS SWITCH MULTIFUNCTIONAL	/38.B4
-S9	=K	+K4	FLASHING BEACON SWITCH	=K	+K4	FLASHING BEACON SWITCH	/40.C3
-S9.X	=K	+K4	CONNECTOR FLASHING BEACON SWITCH	=K	+K4	CONNECTOR FLASHING BEACON SWITCH	/40.D3
-S9a	=K	+K4	FLASHING BEACON SWITCH MULTIFUNCTIONAL	=K	+K4	FLASHING BEACON SWITCH MULTIFUNCTIONAL	/40.C5
-S9a.X	=K	+K4	CONNECTOR FLASHING BEACON SWITCH MULTIFUNCTIONAL	=K	+K4	CONNECTOR FLASHING BEACON SWITCH MULTIFUNCTIONAL	/40.C5
-S13	=K	+K	REAR WINDOW WASHER SYSTEM SWITCH	=K	+K	REAR WINDOW WASHER SYSTEM SWITCH	/43.B3
-S13.X	=K	+K	CONNECTOR REAR WINDOW WASHER SYSTEM SWITCH	=K	+K	CONNECTOR REAR WINDOW WASHER SYSTEM SWITCH	/43.C3
-S14	=K	+K4	BUCKET RETURN-TO-DIG SWITCH	=K	+K4	BUCKET RETURN-TO-DIG SWITCH	/21.C6
-S14.X	=K	+K4	CONNECTOR BUCKET RETURN-TO-DIG SWITCH	=K	+K4	CONNECTOR BUCKET RETURN-TO-DIG SWITCH	/21.C6
-S15	=H	+H4	BATTERY MAIN SWITCH	=H	+H4	BATTERY MAIN SWITCH	/18.C7
-S16	=K	+K4	RIDE CONTROL BUTTON	=K	+K4	RIDE CONTROL BUTTON	/22.C7
-S16.X	=K	+K4	CONNECTOR RIDE CONTROL BUTTON	=K	+K4	CONNECTOR RIDE CONTROL BUTTON	/22.D7

BMK	SYSTEM	LOCATION	FUNCTION	SYSTEM	LOCATION	FUNCTION	PAGE
-MP6_c	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/44.F3
-MP6_d	=H	+H2	REAR SECTION GROUNDING POINT	=H	+H2	REAR SECTION GROUNDING POINT	/23.F7
-MP6_e	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/45.F3
-MP6_f	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/60.B2
-MP6a	=H	+H2	GROUNDING POINT REAR SECTION	=H	+H2	GROUNDING POINT REAR SECTION	/33.A2
-MP6b	=H	+H4	REAR SECTION GROUNDING POINT	=H	+H4	REAR SECTION GROUNDING POINT	/89.F2
-MP7_a	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/18.D7
-MP7_b	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/44.F6
-MP7_j	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/37.E2
-MP7_k	=K	+K3	OPERATOR'S CAB GROUNDING POINT	=K	+K3	OPERATOR'S CAB GROUNDING POINT	/25.E3
-MP8_a	=K	+K	GROUNDING POINT PIPE BREAK PROTECTION	=K	+K	GROUNDING POINT PIPE BREAK PROTECTION	/26.F5
-MP177	=K	+K	OPERATOR'S CAB GROUNDING POINT	=K	+K	OPERATOR'S CAB GROUNDING POINT	/23.F2
-MP184	=K	+K3	GROUNDING POINT COOLANT PREHEATER	=K	+K3	GROUNDING POINT COOLANT PREHEATER	/64.F2
-MP B25	=H	+H2	GROUND FUEL LEVEL SENSOR	=H	+H2	GROUND FUEL LEVEL SENSOR	/66.F7
-MP ECU	=M	+M	GROUNDING POINT ENGINE CONTROL UNIT	=M	+M	GROUNDING POINT ENGINE CONTROL UNIT	/89.B2
-MP TANK	=H	+H2	GROUND FUEL LEVEL SENSOR	=H	+H2	GROUND FUEL LEVEL SENSOR	/80.F3
-MPR	=K	+K3	GROUNDING POINT ANTENNA	=K	+K3	GROUNDING POINT ANTENNA	/89.B2
-P30	=M	+M	HEATER FLANGE PRE-HEAT SYSTEM	=M	+M	HEATER FLANGE PRE-HEAT SYSTEM	/44.D6
-R1	=K	+K6	INCHING FUNCTION ANGLE SENSOR	=K	+K6	INCHING FUNCTION ANGLE SENSOR	/81.D3
-R1.X	=K	+K6	CONNECTOR INCHING FUNCTION ANGLE SENSOR	=K	+K6	CONNECTOR INCHING FUNCTION ANGLE SENSOR	/27.D3
-R1a	=K	+K	MANUAL INCHING ANGLE SENSOR	=K	+K	MANUAL INCHING ANGLE SENSOR	/27.D3
-R1a.X	=K	+K	CONNECTOR MANUAL INCHING ANGLE SENSOR	=K	+K	CONNECTOR MANUAL INCHING ANGLE SENSOR	/28.D5
-R5	=K	+K6	ACCELERATOR PEDAL ANGLE SENSOR	=K	+K6	ACCELERATOR PEDAL ANGLE SENSOR	/28.D4
-R5.X	=K	+K6	CONNECTOR ACCELERATOR PEDAL ANGLE SENSOR	=K	+K6	CONNECTOR ACCELERATOR PEDAL ANGLE SENSOR	/27.D6
-R6a	=K	+K3	MIRROR HEATER LEFT	=K	+K3	MIRROR HEATER LEFT	/27.E6
-R6a.X	=K	+K3	CONNECTOR MIRROR HEATER LEFT	=K	+K3	CONNECTOR MIRROR HEATER LEFT	/45.E1
-R6b	=K	+K3	MIRROR HEATER RIGHT	=K	+K3	MIRROR HEATER RIGHT	/45.D1
-R6b.X	=K	+K3	CONNECTOR MIRROR HEATER RIGHT	=K	+K3	CONNECTOR MIRROR HEATER RIGHT	/45.E2
-R9a	=A4	+K2	EXCITATION RESISTOR 100 OHM	=A4	+K2	EXCITATION RESISTOR 100 OHM	/45.D2
-R9b	=A4	+K2	EXCITATION RESISTOR 220 OHM	=A4	+K2	EXCITATION RESISTOR 220 OHM	/17.B4
-R10	=M	+M	FUEL PREHEATING	=M	+M	FUEL PREHEATING	/17.B5
-R10.X	=M	+M	CONNECTOR FUEL PREHEATING	=M	+M	CONNECTOR FUEL PREHEATING	/66.C7
-R11	=K	+K3	REAR WINDOW HEATER	=K	+K3	REAR WINDOW HEATER	/66.D7
-R11.X1	=K	+K3	CONNECTOR REAR WINDOW HEATER	=K	+K3	CONNECTOR REAR WINDOW HEATER	/45.E3
-R11.X2	=K	+K3	CONNECTOR REAR WINDOW HEATER	=K	+K3	CONNECTOR REAR WINDOW HEATER	/45.D3
							/45.E3


13442271
ITEM CODE
DRAWING INDEX
000

L509T-1778
DRAWING NUMBER
1778 0090 01 00

PROJECT
ISO 18016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE	SERIAL NUMBER	BMK-INDEX	PAGE	OF
LIDOS Gerät	XXXXX	ELECTRICAL SCHEMATIC	10	
			CREATION DATE	23.07.2020 13:12

WORKING HYDRAULICS LOCKOUT



PROJECT
L509T-1778

DRAWING NUMBER
1778 00090 01 00

ITEM CODE
13442271

DRAWING INDEX
000

ISO 18016: The reproduction is prohibited, distribution and utilization of this document as well as the communication of its contents to others without registration.

MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX



LIEBHERR
FACTORY LBH

OPTION Vmax OPTION SPEED
ELECTRICAL SCHEMATIC


PAGE 30 OF
CREATION DATE 23.07.2020 13:12

OPTION Vmax

OPTION SPEED



OPTION BEACON



PROJECT
L509T-1778

ITEM CODE
13442271

DRAWING NUMBER
1778 0090 01 00

DRAWING NUMBER
1778 0090 01 00

ISO 19016: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

OPTION BEACON
ELECTRICAL SCHEMATIC

PAGE 40 OF

CREATION DATE 23.07.2020 13:12

13442271
ITEM CODE

000
DRAWING INDEX

L509T-1778
1778 0090 01 00
PROJECT

1778 0090 01 00
DRAWING NUMBER

ISO 19016: The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

FUEL LEVEL SENSOR
ELECTRICAL SCHEMATIC

PAGE 50 OF

CREATION DATE 23.07.2020 13:12



1 2 3 4 5 6 7 8


A B C D E F

GROUND COMPACT MODULE A28

13442271
ITEM CODE
000
DRAWING INDEX

L509T-1778
DRAWING NUMBER
1778 0090 01 00

PROJECT
L509T-1778
1778 0090 01 00
registration. ISO 19018. The reproduction is prohibited, distribution and utilization of its contents to others without express authorization as well as the communication of its contents to others without registration.



MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

GROUND COMPACT MODULE A28
ELECTRICAL SCHEMATIC

1 2 3 4 5 6 7 8

PROJECT
L509T-1778

ITEM CODE
13442271

DRAWING NUMBER
1778 00090 01 00

DRAWING NUMBER
1778 00090 01 00

ISO 19018: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät


SERIAL NUMBER
XXXXX


LIEBHERR
FACTORY LBH

RESERVE FUSE RESERVE RELAY
ELECTRICAL SCHEMATIC

PAGE 70 OF

CREATION DATE 23.07.2020 13:12





GROUND ENGINE CONTROL UNIT

ITEM CODE 13442271

DRAWING INDEX 000

PROJECT L509T-1778

DRAWING NUMBER 1778 00090 01 00

ISO 19018: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

MACHINE TYPE
LIDOS Gerät

SERIAL NUMBER
XXXXX

LIEBHERR
FACTORY LBH

GROUND ENGINE CONTROL UNIT
ELECTRICAL SCHEMATIC

PAGE 80 OF

CREATION DATE 23.07.2020 13:12

ITEM CODE
13442271

DRAWING INDEX
000

PROJECT
L509T-1778

DRAWING NUMBER
1778 00090 01 00

ISO 19018: The reproduction is prohibited, distribution and utilisation of this document as well as the communication of its contents to others without express authorization is prohibited. Violations require compensation. All rights reserved in the case of patent, utility model or design registration.

OVERVIEW DIAGNOSIS CLAAS

-A30.a Modul Nr.: Modulname: CLASSTELEMETRIE											
ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR	PIN	ADDRESS	PAGE	EA	DESCRIPTION	CONNECTOR	PIN
A30.a.1	/91.F3		CAN LOW 0		1						25
A30.a.2	/91.F2		CAN HIGH 0		2						26
A30.a.3			CAN LOW 1		3						27
A30.a.4			CAN HIGH 1		4						28
A30.a.5			RS232 TX		5						29
A30.a.6			POWER SUPPLY		6						30
A30.a.7	/91.F5		T. 15		7						31
A30.a.8	/91.F4		GROUND		8						32
					9						33
					10						34
					11						35
					12						36
					13						37
					14						38
					15						39
					16						40
					17						41
					18						42
					19						
					20						
					21						
					22						
					23						
					24						

MACHINE TYPE

LIDOS Gerät

SERIAL NUMBER

XXXXX

LIEBHERR

FACTORY LBH

PAGE 90 OF

CREATION DATE 23.07.2020 13:12

OVERVIEW DIAGNOSIS CLAAS
ELECTRICAL SCHEMATIC

110.2 Electrical components of the driver's cab

110.2.1 Fuse boards

Valid for: L509-1778;

1 Fuse board A4




Fig. 491: Fuse board

LBH-/00/211-20200828_082818/en

Name	Description	Name	Description	Name	Description
SD1	Shifting unit with synchro unit	Z2	Gearwheel 2 (66 teeth)	Z4	Gearwheel 4 (51 teeth)

Tab. 191: Key




Fig. 500: Gear shifting: sectional view (in neutral position (For more information see: Neutral position, page 120-13))

- | | | | |
|---|-------------------------------|---|-------------------------------|
| 1 | Shift sleeve | 4 | Pressure chamber for 1st gear |
| 2 | Shift fork | 5 | Piston |
| 3 | Pressure chamber for 2nd gear | 6 | Shift rod |

Name	Description
SD1	Shifting unit with synchro unit

Tab. 192: Key

Name	Test point
PF	External servo pressure

Tab. 204: Test points

BMK	Function
Y104	Solenoid for external servo pressure

Tab. 205: Equipment codes

Valve block for external servo pressure is installed in vehicle frame, on right next to travel motor.

2 Function




Fig. 509: Valve block for external servo pressure: hydraulic diagram (travel direction is selected)

- | | | | |
|----------|--|----------|---|
| 1 | Valve block for external servo pressure | 4 | Solenoid valve for external servo pressure |
| 2 | External servo pressure reducing valve | 5 | Connection to hydro accumulator for external servo pressure |
| 3 | Check valve for external servo pressure | 6 | Connection to travel motor |

Name	Test point
PF	External servo pressure

Tab. 206: Test points

BMK	Function
Y104	Solenoid for external servo pressure

Tab. 207: Equipment codes

Pressure reducing valve block **1** is always supplied with high pressure from travel hydraulics via travel motor **6**, regardless of travel direction.

External servo pressure reducing valve **2** reduces high pressure of oil from travel hydraulics to 210 bar and directs it via external servo pressure solenoid valve **4** to external servo pressure hydro accumulator **5**.

2 Function

2.1 Basic function

The axle performs the following functions:

- Transmitting torque and engine speed to the wheels.
- Increasing the output torque by gearing down in the crown wheel and planetary gear.
- Braking machine using wet disc brake (service brake).

2.2 Engageable differential lockout

The differential can be 100% locked by pressing a button on the control lever. A claw coupling locks the differential and in this way connects the two output sides of axle to each other. (For more information see: [Overview of engageable differential lockout, page 130-6](#))

2.3 Wet disc brake (service brake for 1st brake circuit and parking brake)

The wet disc brake contains several brake discs arranged in succession. The brake discs have a non-twisting connection alternately with the output and axle housing. The brake discs rotate in axle oil to cool them.

During braking, the service brake piston or the parking brake piston clamps the brake discs. The friction between the discs generates the braking effect.

The force of the service brake piston is generated with oil from the inch/brake unit.

The force of the parking brake piston is generated by cup springs. The parking brake is opened hydraulically.

2.4 Drum brake (service brake for 2nd brake circuit)

(For more information see: [100.2.4 Drum brake, page 100-16](#))

2.5 Wheel hub

There is a planetary gear in the wheel hub. The planetary gear reduces the speed and increases the torque.

The bearing is fastened by the bearing covers bolted onto both sides. The bearing pins are held firmly in place in the bearing holes of the rear and front sections by tensioners.

Sealing rings protect the bearing points from dirt.

140.1.2 Articulation lock

Valid for: L509-1778;

1 Layout




Fig. 524: Releasing articulation lock

- | | |
|------------------------------------|---------------------------------|
| 1 Retaining pin | B Articulation lock open |
| A Articulation lock engaged | |

The articulation bearing is fitted between the front and rear sections.

2 Function

The articulation lock creates a rigid connection between the front and rear sections. Steering is no longer possible.

This means the steering is blocked, for example, when transporting the machine or for maintenance.

Malfunction	Cause	Remedy
High-pressure switch switches off	Too much refrigerant in the air conditioning circuit	Correct the refrigerant level
	Air in the air conditioning circuit	Evacuate and refill the air conditioning system
	Condenser blocked	Check the condenser
Low-pressure switch switches off	Not enough refrigerant in the air conditioning circuit	Correct the refrigerant level
	Expansion valve blocked	Check the expansion valve
Bubbles in the sight glass	Too much refrigerant in the air conditioning circuit	Correct the refrigerant level
	Not enough refrigerant in the air conditioning circuit	Correct the refrigerant level
Not enough cooling	Not enough refrigerant in the air conditioning circuit	Correct the refrigerant level
	Air in the air conditioning circuit	Evacuate and refill the air conditioning system
	Expansion valve blocked	Check the expansion valve
	Condenser blocked	Check the condenser
	Valve plates in the air conditioning compressor are defective	Check the valve plates

Tab. 220: Air conditioning troubleshooting table

2.4 Cab air filter




Fig. 530: Cab air filter

- 1 Screws
- 2 Cover
- 3 Cab air filter

LBH/007211-20200828_082818/en

190 Options

Contents

190.1	LiDAT	190-2
190.1.1	Overview of LiDAT <i>L509-1778;</i>	190-2
190.1.2	LiDAT on machine <i>L509-1778;</i>	190-4
190.1.3	LiDAT module (LiTU3) <i>L509-1778;</i>	190-5

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL