



5003ZT

Compact Excavator

**SERVICE
MANUAL**

PART #918178

Revision B - 04/09

MUSTANG  [®]

Mustang Manufacturing Company, Inc.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Type decals and component numbers




Fig. 3: Diesel engine number

Engine number

The type decal (arrow) is located on the cylinder-head cover (engine).

Example: Yanmar 46557




Fig. 4: Hydraulic pump type decal

Hydraulic pump number

The type decal (arrow) is located on the hydraulic pump housing.




Fig. 5: Main valve block type decal

Main valve block number

The type decal (arrow) is located on the lower side of the main valve block.




Fig. 6: Travel drive type decal

Travel drive number

The type decal (arrow) is located on the travel drive.





Fig. 7: Swivel unit type decal

Swivel unit number

The type decal (arrow) is located on the swivel unit.

Engine compartment: overview (SN AH00578 and before)



| Ref. No. | Description |
|----------|-------------------------|
| 91 | Main valve block |
| 92 | Hydraulic test ports |
| 93 | Fuel water separator |
| 94 | Fuel filter |
| 95 | Engine oil dipstick |
| 96 | Engine oil filter |
| 97 | Engine |
| 98 | Engine oil filler cap |
| 99 | Coolant tank |
| 100 | Engine coolant radiator |
| 101 | Hydraulic oil cooler |
| 102 | Washer system tank |

Model-specific tightening torques

| 5003ZT - Hardware application | Size / Grade | lb-ft. (Nm) |
|-------------------------------|--------------|-------------|
| Live ring | M14 10.9 | 133 (180)* |
| Track roller | M16 10.9 | 203 (275)* |
| Drive pinion | M14 10.9 | 133 (180)* |
| Travel drive | M14 10.9 | 133 (180)* |
| Gear motor | M16 10.9 | 203 (275)* |
| Angled engine bracket | M10 8.8 | 33 (45) |
| Engine mounting | M10 8.8 | 33 (45) |
| Pump mounting | M10 10.9 | 52 (70) |
| Pump | M12 10.9 | 81 (110) |
| Swivel joint | M10 10.9 | 47 (64)* |
| Counterweight | M20 8.8 | 214 (290)* |

* All hardware with an * must have an appropriate thread-locking compound applied.

General tightening torques

Tightening torques for hydraulic screw connections (dry assembly)

| Hose fittings for hydraulic applications (light application, DKOL) | | | | |
|--|---------------|---------|--------------------|----------------------------------|
| Nominal ø DN | Outer ø RA | Thread | Width across flats | Tightening torque (lb-ft.) Nm |
| 05 | 6L | M12X1.5 | W/F 14 | 11 (15) |
| 06 | 8L | M14X1.5 | W/F 17 | 15 (20) |
| 08 | 10L | M16X1.5 | W/F 19 | 30 (40) |
| 10 | 12L | M18X1.5 | W/F 22 | 37 (50) |
| 12 | 15L | M22X1.5 | W/F 27 | 55 (75) |
| 16 | 18L | M26X1.5 | W/F 32 | 63 (85) |
| 20 | 22L | M30X2 | W/F 36 | 74 (100) |
| 25 | 28L | M36X2 | W/F 41 | 133 (180) |
| 32 | 35L | M45X2 | W/F 55 | 162 (220) |

Galvanized and dry surface (O-ring slightly oiled). Torque tolerance: -10%
Values determined empirically and to be applied as approximate figures.

| Metric hose fittings for hydraulic applications (heavy application, DKOL) | | | | |
|---|---------------|---------|--------------------|----------------------------------|
| Nominal ø DN | Outer ø RA | Thread | Width across flats | Tightening torque (lb-ft.) Nm |
| 05 | 8S | M16X1.5 | W/F 19 | 30 (40) |
| 06 | 10S | M18X1.5 | W/F 22 | 37 (50) |
| 08 | 12S | M20X1.5 | W/F 24 | 44 (60) |
| 10 | 14S | M22X1.5 | W/F 27 | 55 (75) |
| 12 | 16S | M24X1.5 | W/F 30 | 66 (90) |
| 16 | 20S | M30X2 | W/F 36 | 74 (100) |
| 20 | 25S | M36X2 | W/F 41 | 133 (180) |
| 25 | 30S | M42X2 | W/F 50 | 199 (270) |
| 32 | 38S | M52X2 | W/F 60 | 295 (400) |

Galvanized and dry surface (O-ring slightly oiled). Torque tolerance: -10%
Values determined empirically and to be applied as approximate figures.

Maintenance

Fluids and lubricants

| Component/application | Engine/machine fluid | Specification | Season/temperature | Capacities ¹ |
|-----------------------|--|---|--|-------------------------------------|
| Diesel engine | Engine oil | SAE 10W-40 ² ; API: CD, CF, CF-4, CI-4; ACEA: E3, E4, E5; JASO: DH-1 | -4°F (-20°C) 104°F (+40°C) | 2.1 gal. (7.8 L) |
| Travel drive | Gearbox oil ³ | Q8 T 55, SAE 85W-90 ⁴ | Year-round | About 0.3 gal. (1.3 L) each |
| | | Q8 T 55, SAE 80W-90 ⁵ | | |
| | | FINA PONTONIC GLS, SAE 85W-90 | | |
| Hydraulic oil tank | Hydraulic oil | HVLP46 ⁶ | Year-round | 21.1 gal. (80 L) |
| | Biodegradable oil ⁷ | PANOLIN HLP Synth 46 | | |
| | | FINA BIOHYDRAN SE 46 | | |
| | | BP BIOHYD SE-46 | | |
| Grease | Roller and friction bearings (live ring ball bearing race) | FINA Energrease L21M ⁸ | Year-round | As required |
| | Open gear (live ring gears) | BP Energrease MP-MG2 ⁹ | Year-round | As required |
| Grease zerks | Multipurpose grease ¹⁰ | FINA Energrease L21 M ¹¹ | Year-round | As required |
| Battery terminals | Acid-proof grease ¹² | FINA Marson L2 | Year-round | As required |
| Fuel tank | Diesel fuel | 2-D, ASTM D975 - 94 (USA) | Summer or winter diesel depending on outside temp. | 20.6 gal. (78 L) |
| | | 1-D, ASTM D975 - 94 (USA) | | |
| | | EN 590: 96 (EU) | | |
| | | ISO 8217 DMX (International) | | |
| | | BS 2869 - A1 (GB) | | |
| | | BS 2869 - A2 (GB) | | |
| Radiator | Coolant | Soft or distilled water + antifreeze ASTM D4985 | Year-round | 1.8 gal. (7.0 L) |
| Air conditioning | Refrigerating agent | R134a ¹³ | Year-round | ~2.1 lbs. (~950 g) |
| | Compressor oil | Sanden SP20 (SN AD07125 and below) | Year-round | 7.45 cu. in. (122 cm ³) |
| | | Sanden SP20 (SN AH00579 and up) | Year-round | 5.5 cu. in. (90 cm ³) |
| Washer system | Cleaning agent | Water + antifreeze | Year-round | 0.32 gal. (1.2 L) |

- The capacities indicated are approximated values; only use the oil level check to determine the correct oil level
- According to DIN 51502
- Hypoid gearbox oil based on basic mineral oil (SAE 85W-90 according to DIN 51502), (API GL-4, GL5)
- The Q8 T55 SAE 85W-90 gearbox oil is no longer produced.
- The Q8 T55 SAE 80W-90 gearbox oil is used from 10/2006 onwards. Do not mix both gearbox oils!
- According to DIN 51524 section 3
- Hydraulic ester oils (HEES)
- KF2K-25 according to DIN 51502 multipurpose lithium grease with MoS² additive
- KP2N-20 according to DIN 51502 EP multipurpose calcium sulphonate complex grease
- KF2K-25 according to DIN 51502 multipurpose lithium grease with MoS² additive
- KF2K-25 according to DIN 51502 multipurpose lithium grease with MoS² additive
- Standard acid-proof grease
- According to DIN 8960

Stationary fuel pumps

General

Only refuel from stationary fuel pumps. Fuel from barrels or canisters is usually contaminated.

Even the smallest particles of dirt can cause:

- Increased engine wear.
- Malfunctions in the fuel system.
- Reduced effectiveness of the fuel filters.

Diesel fuel specification

Only use high-grade fuels.

| Grade | Cetane number | Use |
|----------------------------------|----------------|---|
| • No. 2-D according to DIN 51601 | Min. 45 | For normal outside temperatures |
| • No. 1-D according to DIN 51601 | | For outside temperatures below 39°F (4°C) or for operation above 4921 ft. (1500 m) altitude |

Bleeding the fuel system



DANGER!

If the fuel, as it drains, comes into contact with hot engine parts or the exhaust system, there is an increased -

Risk of burns.

⚠ Never bleed the fuel system if the engine is hot.

Bleed the fuel system in the following cases:

- After removing and re-attaching the fuel filter, pre-filter, or the fuel lines.
- After running the fuel tank empty.
- After running the engine again, after a long period out of service.

⚠ Bleed the fuel system as follows:

- Fill the fuel tank.
- Turn the ignition key to the first position.
- Wait about five minutes while the fuel system bleeds itself automatically.
- Start the engine.

If the engine runs smoothly for a while, and then stops; or if it does not run smoothly:

- Turn off the engine.
- Bleed the fuel system again as described above.
- Have this checked by authorized service technicians.

Replacing the filter




Fig. 18: Removing the lower housing section




Fig. 19: Removing the filter element




Fig. 20: Replacing the inside filter

- Replace outside filter **A** as follows:

- ☞ Turn off the engine.
- ☞ Remove the key and keep it with you.
- ☞ Let the engine cool down.
- ☞ Open the engine cover.
- ☞ Remove dirt and dust from the air filter and the area around the air filter.
- ☞ Fold both bow clips **C** on cover section **D** to the outside.
- ☞ Remove cover section **D**.
- ☞ Carefully remove outside filter **A** with slight turning movements.
- ☞ **Make sure** all dirt (dust) inside the upper and lower housing sections, including the dust valve **E**, has been removed.
 - ☞ Clean the parts with a clean lint-free cloth, DO NOT use compressed air.
- ☞ Check the air filter cartridges for damage, only install intact filters.
- ☞ Carefully insert new outside filter **A** in the upper housing section.
- ☞ Position cover section **D** (make sure it is properly seated).
- ☞ Close both bow clips **C**.


- Replace inside filter **B** as follows:

- ☞ Turn off the engine.
- ☞ Remove the key and keep it with you.
- ☞ Let the engine cool down.
- ☞ Open the engine cover.
- ☞ Remove dirt and dust from the air filter and the area around the air filter.
- ☞ Fold both bow clips **C** on cover section **D** to the outside.
- ☞ Remove cover section **D**.
- ☞ Carefully remove outside filter **A** with slight turning movements.
- ☞ Carefully remove inside filter **B**.
 - ☞ Cover the air supply at the end of the filter with a clean lint-free cloth to prevent dust from entering the engine.
 - ☞ **Make sure** all dirt (dust) inside the upper and lower housing sections, including the dust valve **E**, has been removed.
 - ☞ Clean the parts with a clean lint-free cloth, DO NOT use compressed air.
 - ☞ Remove the cloth from the air supply.
- ☞ Check the air filter cartridges for damage. Only install intact filters.
- ☞ Carefully insert outside filter **A** in the upper housing section.
- ☞ Position cover section **D** (make sure it is properly seated).
- ☞ Close both bow clips **C**.

NOTE:

Make sure dust valve **E** points downward after it is installed.

Primary pressure limiting valves



| Ref. No. | Description | |
|----------|--|--------|
| 1 | Pump primary pressure limiting valve 1 | PPLV 1 |
| 2 | Pump primary pressure limiting valve 2 | PPLV 2 |
| 3 | Pump primary pressure limiting valve 3 | PPLV 3 |
| 4 | Pressure limiting valve | PLV 4 |

Checking hydraulic pressure lines

Safety instructions

**DANGER!**

Use caution when checking hydraulic lines, especially when searching for leaks. Hydraulic oil escaping under high pressure can penetrate the skin and cause serious injuries.

Risk of personal injury.

☞ *Always consult a doctor immediately, even if the wound appears insignificant, to be sure that serious infections do not set in.*

☞ *Always follow these instructions:*

- Only tighten leaking screwed fittings and hose connections after you have released the system pressure.
- Never weld or solder damaged or leaking pressure lines and connections. Always replace damaged parts with new ones.
- Never search for leaks with your bare hands, always wear protective gloves.
- Only use paper or wood to check for minor leaks, never use an unprotected light or open flame.
- Only authorized dealers should replace damaged flexible lines.

- Leaking or damaged pressure lines must be immediately repaired or replaced by an authorized technician.
- Replace hydraulic hoses every six years from the date of manufacture, even if they do not appear to be damaged.

Observe all relevant safety regulations for hydraulic lines, as well as safety regulations regarding accident prevention and occupational health and safety and DIN20066, part 5.

The date of manufacture (month or quarter and year) is stated on the flexible line.

Example:

The indication "1 Q/05" means manufactured in the 1st quarter of 2005.




Fig. 7: Hydraulic hose manufacture date

Using a Booster Battery (Jump-Starting)**WARNING!**

- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries. When jump-starting from a booster battery, make final connection (negative) at engine frame away from battery. A discharged battery can create flammable gases. Sparks or open flames can cause this gas, and the battery, to explode.
- ⚠ DO NOT jump-start or charge a frozen battery. Warm battery to 60° F (16° C) before connecting to a charger. Unplug charger before connecting or disconnecting cables to battery.

**IMPORTANT!**

When jump-starting from another machine, be sure the second machine is not running while using the unstarted machine's glow plugs. High voltage spikes from a running machine can burn out the glow plugs.

**IMPORTANT!**

Damage to the alternator can occur if:

- Engine is operated with battery cables disconnected.
- Battery cables are connected when using a fast charger or when welding on the machine. When welding on the machine, remove both cables from the battery and ground welder to machine frame near repair area.
- Extra battery cables (booster cables) are incorrectly connected.

Be very careful when jump-starting the machine. Booster battery must be 12-volt.

Jump-starting procedure:

- Turn ignition key to the "OFF" position.
- Open the engine cover.
- Connect one end of the cable to the positive (+) terminal on the booster battery. Connect the other end of the same cable to the positive (+) terminal on the battery of the machine to be started.

NOTE:

If the machine is equipped with a battery disconnect switch, connect the other end of the cable connected to the positive (+) terminal of the booster battery to the positive (+) terminal on the battery disconnect switch of the machine to be started.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Removing/Tightening order for cylinder head bolts

☞ Order for removing the cylinder-head bolts.



NOTE:

Only complete work on the cylinder head if the engine is cold.

☞ Mount the cylinder-head bolts:

➤ Tightening torque:


- 1st pass 31.4 – 33.6 lb-ft. (42.6 – 45.5 Nm)
- 2nd pass 62.9 – 67.2 lb-ft. (85.3 – 91.1 Nm)



IMPORTANT!

Remember the order for tightening the cylinder-head bolts.


☞ See figure below.



NOTE:

Oil the threads and the contact surfaces of the cylinder-head bolts before mounting them.

Fuel system



Engine Troubleshooting

| Problem | Possible causes |
|---|--|
| Engine does not start or is not easy to start | No fuel |
| | Air in fuel system |
| | Wrong SAE grade of engine lubrication oil |
| | Fuel grade does not comply with specifications |
| | Defective or discharged battery |
| | Loose or oxidized cable connections in starter circuit |
| | Defective starter, or pinion does not engage |
| | Wrong valve clearance |
| | Defective fuel injector |
| | Defective starting relay |
| | Defective glow plug / intake air preheater |
| | Defective solenoid switch |
| | Cut-off solenoid does not attract |
| | Cut-off solenoid without current |
| High pressure created immediately in the hydraulic system | |
| Engine starts, but does not run smoothly | Fuel grade does not comply with specifications |
| | Wrong valve clearance |
| | Injection line leaks |
| | Defective fuel injector |
| | Air in fuel system |
| Engine overheats, temperature warning system responds | Oil level too low |
| | Damaged water pump |
| | Oil level too high |
| | Dirty air filter |
| | Dirty cooler fins |
| | Defective fan, torn or loose V-belt |
| | Defective thermostat |
| | Resistance in cooling system too high, flow capacity too low |
| Defective fuel injector | |

Pump assignment

Hydraulic supply by pump 1


- Bucket section.
- Boom section.
- Left-hand side drive section.

Hydraulic supply by pump 2

- Right-hand side drive section.
- Dipper arm section.
- Auxiliary hydraulics section.





Hydraulic supply by pump 3

- Dozer blade section.
- Upper carriage rotation section.
- (Option not available).
- Boom swivel section.
- Drive counterbalancing system section.




Pilot valve for dozer blade

- Pilot valve with pedals for remote control of directional valves.
- Consists of a pedal and two pressure reducing valves.



| Ref. No. | Description | Ref. No. | Description |
|----------|------------------|----------|---|
| A | Pedal | 1 | Dozer blade cylinder extension control |
| B | Adjusting screws | 2 | Dozer blade cylinder retraction control |
| C | Protective caps | 3 | Tank line |
| D | Mounting plate | 4 | Supply from pilot oil supply unit |
| E | Tappet | | |
| F | Springs | | |



| Ref. No. | Description | Ref. No. | Description |
|----------|--------------------------|----------|---------------------------|
| 1 | O-ring | 22 | Space washer |
| 2 | Motor housing | 23 | O-ring |
| 3 | O-ring | 24 | O-ring |
| 4 | Plug | 25 | Parking brake piston |
| 5 | O-ring | 26 | Brake piston spring |
| 6 | Bearing | 27 | Bearing |
| 7 | Motor shaft | 28 | Pin |
| 8 | Plate | 29 | Motor head |
| 9 | Piston | 30 | Anti-cavitation valve |
| 10 | Plate | 31 | Spring |
| 11 | Bush | 32 | O-ring |
| 12 | Pin | 33 | Plug |
| 13 | Cylinder block | 34 | O-ring |
| 14 | Plate | 35 | Shock valve |
| 15 | Spring | 36 | O-ring |
| 16 | Plate | 37 | O-ring |
| 17 | Circled | 38 | Plug |
| 18 | Control disc | 39 | Screw |
| 19 | Parking brake steel ring | 40 | O-ring |
| 20 | Brake disc | 41 | Brake release valve block |
| 21 | O-ring | 42 | Screw |

Electrical system

Ohm's Law (defines current, voltage and resistance relationship)

Ohm's law is a mathematical formula that is used to describe the relationship between voltage, current, and resistance.

Current "I" – Ampere (A)

Voltage "E" – Volt (V)

Resistance "R" – Ohm (Ω)



Output

Power "P" – Watt (W)

$$P = E \times I = R \times I^2 = E^2/R$$

Measuring equipment and methods

Multi-function measuring device

- Measurements of values (E, R, I, P).
- Continuity test.
- Diode test.

Calculate measuring range using known data (E, R, I, P) and set before measuring.

Follow AC/DC basic setting.

➡ AC = alternating current/voltage.

➡ DC = direct current/voltage.

Test device with acoustic and optical signal output

- Continuity test in de-energized machine electrical system and of wiring harnesses.

Wiring diagram legend (SN AC02889 and before)


| No. | Description | Section | Loc. |
|-----|--------------------------------------|---------|------|
| A1 | Radio | E14 | Opt |
| B1 | Fuel indicator | F6 | |
| B2 | Horn | D/E10 | |
| B6 | Engine oil temperature sensor | E6 | |
| B11 | Loudspeaker | E15 | Opt |
| B12 | Loudspeaker | E15 | Opt |
| E7 | Rear roof lights | F14 | Opt |
| E9 | Front roof light | F13 | Opt |
| E10 | Front roof light | | Opt |
| E11 | Boom light | F8/9 | |
| E14 | Interior light | E/F13 | |
| E15 | Socket (e.g., cigarette lighter) | A14 | |
| F1 | Main fuse: starter, preheating | E2 | |
| F2 | Main fuse | E1 | |
| F3 | Indicators, engine relay | A4 | |
| F4 | Boom working light | A7 | |
| F5 | Cab working lights | A8 | |
| F6 | Valves, horn | A9 | |
| F7 | Fan, air conditioning | A10 | |
| F8 | Wiper, interior light | A12 | |
| F9 | Rotating beacon, radio | A13 | |
| F10 | Socket (e.g., cigarette lighter) | A14 | |
| G1 | Alternator | F3 | |
| G2 | Battery | F1 | |
| H2 | Preheating indicator | B3 | |
| H3 | Engine temperature indicator | B3 | |
| H4 | Engine oil pressure indicator | B3 | |
| H5 | Alternator charge function indicator | B3 | |
| H6 | Air filter indicator | B3 | |
| H7 | Hydraulic oil filter indicator | B3 | |
| H9 | Not assigned | C3 | Opt |
| H28 | Rotating beacon | F13 | Opt |
| H33 | Spare indicator | B3 | |
| H30 | Spare indicator | C3 | |
| K5 | Preheating high current relay | E4 | |
| K6 | Preheating time lag relay | D5 | |
| K7 | Start high current relay | E2 | |
| K8 | Cutoff solenoid time lag relay | E3 | |
| K9 | Cutoff solenoid switching relay | E3 | |
| M1 | Starter | F2 | |
| M2 | Wiper motor | F13 | Opt |
| M4 | Fan | C12 | Opt |
| M5 | Washer pump | F8 | Opt |
| M7 | Not assigned | F1 | Opt |
| M9 | Fuel pump | F3 | |
| P1 | Hourmeter | B3 | |
| P2 | Fuel level indication | B3 | |
| P3 | Engine oil temperature gauge | A3 | |
| R1 | Intake air preheater | F5 | |
| S1 | Preheating start switch | A1 | |

| No. | Description | Section | Loc. |
|-------|--|---------|------|
| S2 | Engine oil pressure switch | F5 | |
| S3 | Engine temperature switch | E5 | |
| S4 | Air filter pressure switch | F6 | |
| S5 | Hydraulic oil pressure switch | F7 | |
| S15 | Ventilation switch | A10 | |
| S16 | Boom working light switch | A7 | |
| S17 | Cab working light switch | A8 | Opt |
| S18 | Rotating beacon switch | A/B 13 | Opt |
| S20 | Wiper/washer switch | A12 | Opt |
| S21 | High speed switch | A9 | |
| S21.1 | High-speed joystick button (prepared) | E9 | Opt |
| S27 | Additional hydraulics/swivel joystick button | D10 | |
| S28 | Safety switch | C12 | |
| S30 | Additional control circuit joystick button | D9 | Opt |
| S31 | Additional control circuit joystick button | D9 | Opt |
| S41 | Not assigned | E8 | Opt |
| S42 | Not assigned | A6 | Opt |
| S48 | Not assigned | C9 | Opt |
| S51 | Air conditioning switch | A11 | Opt |
| S52 | Air conditioning pressure switch | E12 | Opt |
| S54 | Air conditioning thermostat | D12 | Opt |
| S55 | Horn joystick button | C10 | |
| V1 | Recovery diode | E4 | |
| X1 | 13-pole connection – engine/chassis | D4-6 | |
| X2 | 11-pole connection – engine/chassis | D7-9 | |
| X3 | 2-pole main connection | D0 | |
| X4 | 9-pole connection – not assigned | C/D1 | |
| X5 | 7-pole connection – armrest/chassis | D11/12 | |
| X6 | 5-pole connection – armrest switch | C11/12 | |
| X7 | 6-pole connection – joystick (right) | C/D 11 | |
| X8 | 6-pole connection – joystick (left) | D11 | |
| X10 | 15-pole connection – instrument panel | B/C3 | |
| X11 | Not assigned | B6 | |
| X12 | 9-pole connection – cab | C13/14 | |
| X13 | 5-pole connection – engine temperature | A3 | |
| X14 | 2-pole connection – auto-idle setting | D3/4 | |
| X15 | 1-pole connection – drive alarm | D1 | |
| X16 | 3-pole connection – drive alarm | E2 | |
| X19 | 1-pole connection – socket | F7 | |
| XE11 | 2-pole connection – boom working light | E9 | |
| XS41 | Not assigned | E8 | |
| Y1 | Cutoff solenoid | F4 | |
| Y3 | High-speed solenoid valve | F9 | |
| Y13 | Solenoid valve for safety valve | F11 | |
| Y14 | Solenoid valve – not assigned | F9 | Opt |
| Y15 | Solenoid valve – auxiliary hydraulics/swivel | F10 | |
| Y16 | Solenoid valve – additional control circuit | F10 | Opt |
| Y17 | Solenoid valve – additional control circuit | F11 | Opt |
| Y31 | Solenoid valve – air conditioning | F12 | Opt |

Wiring diagram (legend)

Boom working light wiring harness

XE11



| No. | Up to | To | Color |
|-----|---------------------------|-----------------------|---------|
| 53 | XE11/1 boom working light | E1 boom working light | grn/yel |
| 54 | XE11/2 boom working light | E1 boom working light | blk |

Long dipper arm

Specifications

| Long dipper arm | |
|---|----------------|
| Difference in length in relation to standard dipper arm | 11.8" (300 mm) |

NOTE:

Read the lift capacity table when using a long dipper arm.

Auxiliary hydraulics connections


NOTE:

Follow the Operator's Manual of the attachment manufacturer for connecting the auxiliary hydraulics to the attachment.

Quick-couplers (cannot be joined under pressure)

| Port | Function |
|------|---|
| T | Pressure line quick-coupler 12.5 1/2" (13 mm) |
| U | Return pressure line quick-coupler 12.5 1/2" (13 mm) |
| V | Unpressurized return-to-tank line quick-coupler 17 3/4" (19 mm) |

Couplings according to ISO 16028



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL