

# SERVICE MANUAL

## EI45C EVO Crawler Excavator

Part number 48034213  
English  
June 2016



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## INTRODUCTION

Safety glass for all windows	
Shock-less cab suspension by 4-point fluid mounting	
Sliding front window with auto lock	
Built-in type full-color LCD monitor display	
Membrane switch on monitor display	
Windshield wiper & washer	
AM/FM Radio with auto-tuner	
Floor mat	
Polycarbonate roof hatch & Sun shade	
Auto air-conditioner	
Top guard OPG level 1 (in CAB structure)	
Roll - over protective structure (ROPS)	
Operator's seat	
Low frequency mechanical suspension with helical springs and double acting hydraulic damper.(Achieves ISO7096 in category EM6)	
With following features	
Manual weight adjustment	Backrest angle adjustment
Seat height adjustment	Adjustable pivoting armrests
Adjustable headrest	Retractable seat belt
Adjustable lumbar support	Control consoles adjust independently of seat
Others	
Rear view mirror (Cab side & Right side)	

### Undercarriage

Travel motor	Variable displacement axial piston motor	
Brake	Mechanical disc brake	
Hydraulic service brake	Brake valve	
Final drive	Planetary gear reduction	
Travel speeds	High	<b>5.6 km/h (3.480 mph)</b> (Automatic travel speed shifting)
	Low	<b>3.4 km/h (2.113 mph)</b>
Drawbar pull	<b>116 kN (26077.837 lb)</b>	
Number of carrier rollers (each side)	1	
Number of carrier rollers (each side)	7	
Number of shoes (each side)	43	
Type of shoe	Triple grouser shoe	
Link pitch	<b>171.5 mm (6.752 in)</b>	
Width of shoe	<b>600 mm (23.622 in)</b> (S.T.D)	
Grade-ability	<b>70 % ( 35 ° )</b>	

### Dozer blade

Width of blade	<b>2590 mm (101.969 in)</b>
Height of blade	<b>570 mm (22.441 in)</b>
Max. lift above ground	<b>515 mm (20.3 in)</b>
Min. drop below ground	<b>520 mm (20.472 in)</b>

### Mass

Operating mass	<b>13500 kg (29762.41 lb)</b>
with <b>2.50 m (8.2021 ft)</b> Arm, <b>0.5 m<sup>3</sup></b> Bucket, <b>600 mm (23.622 in)</b> grouser shoe, operator, lubricant, coolant and full fuel tank	
Shipping mass	<b>12900 kg (28439.63 lb)</b>
Operating mass - (operator mass [ <b>75 kg (165.35 lb)</b> ]) + <b>90 %</b> of fuel mass + bucket mass [ <b>400 kg (881.85 lb)</b> ])	
Counter weight mass	<b>2200 kg (4850.17 lb)</b>
Ground pressure	<b>0.036 MPa (5.2218 psi)</b>

INTRODUCTION

**Gallons (U.S) to liters**

U.S.-gal.	0	1	2	3	4	5	6	7	8	9	U.S.-gal.
	liters	liters	liters	liters	liters	liters	liters	liters	liters	liters	
----		3.7853	7.5707	11.3560	15.1413	18.9266	22.7120	26.4973	30.2826	34.0680	----
10	37.8533	41.6386	45.4239	49.2093	52.9946	56.7799	60.5653	64.3506	68.1359	71.9213	10
20	75.7066	79.4919	83.2772	87.0626	90.8479	94.6332	98.4186	102.203	105.989	109.774	20
30	113.559	117.345	121.130	124.915	128.701	132.486	136.271	140.057	143.842	147.627	30
40	151.413	155.198	158.983	162.769	166.554	170.339	174.125	177.910	181.695	185.481	40
50	189.266	193.051	196.837	200.622	204.407	208.193	211.978	215.763	219.549	223.334	50
60	227.119	230.905	234.690	238.475	242.261	246.046	249.831	253.617	257.402	261.187	60
70	264.973	268.758	272.543	276.329	280.114	283.899	287.685	291.470	295.255	299.041	70
80	302.826	306.611	310.397	314.182	317.967	321.753	325.538	329.323	333.109	336.894	80
90	340.679	344.464	348.250	352.035	355.820	359.606	363.391	367.176	370.962	374.747	90
100	378.532	382.318	386.103	389.888	393.674	397.459	401.244	405.030	408.815	412.600	100

**Liters to gallons (U.S)**


liters	0	1	2	3	4	5	6	7	8	9	liters
	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	U.S.gal.	
----		0.2642	0.5284	0.7925	1.0567	1.3209	1.5851	1.8492	2.1134	2.3776	----
10	2.6418	2.9060	3.1701	3.4343	3.6985	3.9627	4.2268	4.4910	4.7552	5.0194	10
20	5.2836	5.5477	5.8119	6.0761	6.3403	6.6044	6.8686	7.1328	7.3970	7.6612	20
30	7.9253	8.1895	8.4537	8.7179	8.9820	9.2462	9.5104	9.7746	10.0388	10.3029	30
40	10.5671	10.8313	11.0955	11.3596	11.6238	11.8880	12.1522	12.4164	12.6805	12.9447	40
50	13.2089	13.4731	13.7372	14.0014	14.2656	14.5298	14.7940	15.0581	15.3223	15.5865	50
60	15.8507	16.1148	16.3790	16.6432	16.9074	17.1716	17.4357	17.6999	17.9641	18.2283	60
70	18.4924	18.7566	19.0208	19.2850	19.5492	19.8133	20.0775	20.3417	20.6059	20.8700	70
80	21.1342	21.3984	21.6626	21.9268	22.1909	22.4551	22.7193	22.9835	23.2476	23.5118	80
90	23.7760	24.0402	24.3044	24.5685	24.8327	25.0969	25.3611	25.6252	25.8894	26.1536	90
100	26.4178	26.6820	26.9461	27.2103	27.4745	27.7387	28.0028	28.2670	28.5312	28.7954	100

## Engine - Remove

1. Use a wrench [ **17 mm**] to remove the bolt (1), and then remove the battery cable (2) on the negative side.
  - After removing the terminal and harness, secure them so that they do not interfere with the frame and other parts.  
Also, cover with a rubber cap to protect against sparks.

Tightening torque for bolt installation: **10.6 - 13.0 N·m (7.82 - 9.59 lb ft)**.

2. Remove the counterweight.  
For details, see **Counterweight - Remove (39.140)**.
3. Remove the muffler.  
For details, see **Exhaust muffler - Remove (10.254)**.
4. Remove the pump.  
For details, see **Pump - Remove (35.106)**.




LPIL12CX00141AB 1

5. Use a wrench [ **19 mm**] to remove the bolt (1), use a wrench [ **7 mm**] to loosen the hose bands (2) and (3), and then remove the intercooler hose (high-temperature side) (4) and hose (5) from the air cleaner.

Tightening torque for band (2) installation: **8.8 - 9.8 N·m (6.49 - 7.23 lb ft)**


Tightening torque for band (3) installation: **6.3 - 7.3 N·m (4.65 - 5.38 lb ft)**



LPIL12CX00142AB 2

6. Loosen the hose bands (1), and then remove the intercooler hose (low-pressure side) (2).

Tightening torque for hose band (2) installation: **8.8 - 9.8 N·m (6.49 - 7.23 lb ft)**




LPIL12CX00143AB 3

### Crank gear removal

1. Remove the crank gear from the crankshaft.

### Idle gear A removal


1. Remove the idle gear A from the idle gear A shaft.
  - Remove idle gear A, idle gear A flange, and idle gear A shaft.



LPIL12CX00755AA 54

### Oil pump assembly removal

1. Remove the oil pump assembly from the timing gear case.




LPIL12CX00756AA 55

### Timing gear case removal

1. Remove the timing gear case from the cylinder block.
  - Install bolt (1) in the diagram to the inside of timing gear case and bolt (2) from the crankcase side.

**NOTICE:** Be sure to remove the bolts.


2. Remove the gasket from the cylinder block.



LPIL12CX00757AB 56


3. Install the camshaft bearing cap to the cylinder head.

- Apply engine oil to the journal section of the cylinder head.
- Face the bearing cap front mark to the engine front side, and assemble in numbered order to the cylinder head.



LPIL12CX00642AA 75

- Confirm that the alignment marks (1) of the camshaft bearing cap and the camshaft are aligned.




LPIL12CX00643AB 76

4. Apply the engine oil to the bolt.

- Apply engine oil to the threaded portion and tighten the bearing cap.
- Tighten the bearing cap to the specified torque in the order shown in the diagram.


Tightening torque: **18 N·m (13 lb ft)**



LPIL12CX00644AA 77

- After rotating the crankshaft 720°, the marks on the collared end of the crankshaft and that of the bearing cap should align.

1. Exhaust camshaft gear
2. Inlet camshaft gear
3. Idle gear D




LPIL12CX00646AB 78

### Rocker arm shaft assembly removal

1. Remove the rocker arm shaft assembly from the cylinder head.
  1. Exhaust rocker arm shaft assembly
  2. Bolt
  3. Bolt
  4. Inlet rocker arm shaft assembly

**NOTE:** If reusing the rocker arm shaft assembly, install it to its original position.




LPIL12CX00096AB 33

### Cylinder head assembly removal

1. Remove the bolt (2) from the timing gear case.
2. Remove the nut (1) from the timing gear case.
3. Loosen the bolt using a wrench.

**NOTE:** Loosen and remove the cylinder head bolts in the order shown in the diagram.


**NOTICE:** Do not reuse the bolts.



LPIL12CX00097AB 34

4. Remove the cylinder head from the cylinder block.

**NOTE:** Remove with the inlet manifold.



LPIL12CX00098AB 35


### Cylinder head gasket removal

1. Remove the cylinder head gasket from the cylinder head.

**NOTICE:** Do not reuse the gasket.


3. Install the camshaft bearing cap to the cylinder head.

- Apply engine oil to the journal section of the cylinder head.
- Face the bearing cap front mark to the engine front side, and assemble in numbered order to the cylinder head.



LPIL12CX00642AA 55

- Confirm that the alignment marks (1) of the camshaft bearing cap and the camshaft are aligned.




LPIL12CX00643AB 56

4. Apply the engine oil to the bolt.

- Apply engine oil to the threaded portion and tighten the bearing cap.
- Tighten the bearing cap to the specified torque in the order shown in the diagram.


Tightening torque: **18 N·m (13 lb ft)**



LPIL12CX00644AA 57

- After rotating the crankshaft 720°, the marks on the collared end of the crankshaft and that of the bearing cap should align.

1. Exhaust camshaft gear
2. Inlet camshaft gear
3. Idle gear D




LPIL12CX00646AB 58

## Gear case cover removal

1. Remove the bracket from the gear case and vacuum pump.


**NOTE:** Remove the left fan shroud bracket (1) and fan shroud stay (2).



B776173D 46


2. Remove the cover from the gear case cover.

1. Power steering pump hole cover



LPIL12CX00752AB 47

3. Remove the gear case cover from the gear case.



LPIL12CX00753AA 48

## Crank gear removal

1. Remove the crank gear from the crankshaft.




## Camshaft - Install

### Camshaft preparing

1. Set the No. 1 cylinder to the compression top dead center.


**NOTE:** Turn the crankshaft forward and set the No. 1 cylinder to the compression top dead center.  
Use a mirror to find the No. 1 cylinder compression top dead center set position (1).



LPIL12CX00649AB 1


### Camshaft installation

1. Align the camshaft gear with the alignment mark.
  - As indicated in the diagram, align the alignment marks of the inlet camshaft gear (2) and the exhaust camshaft gear (1), as well as the alignment mark of idle gear D (3).
2. Install the camshaft to the cylinder head.



LPIL12CX00641AB 2

3. Install the camshaft bearing cap to the cylinder head.
  - Apply engine oil to the journal section of the cylinder head.
  - Face the bearing cap front mark to the engine front side, and assemble in numbered order to the cylinder head.




LPIL12CX00642AA 3

### Cylinder head cover removal

1. Remove the cylinder head cover from the cylinder head.

**NOTICE:** Do not damage the oil seal lip section with the injector connector.

**NOTE:** Move the head cover to the left side of the engine and lift it up to remove.




LPIL12CX00056AA 4

### Cam end gasket removal

1. Remove the cam end gasket (1) from the cylinder head.

**NOTE:** Thoroughly remove the liquid gasket remaining on the cylinder head.



LPIL12CX00057AB 5

### Oil seal removal

1. Remove the oil seal from the cylinder head cover.

**NOTE:** When removing the oil seal from the cylinder head cover, remove it from under the cylinder head cover.


## Cylinder head - Install

### Cylinder head gasket preparation

1. Select the cylinder head gasket.
  - Measure the piston head protrusion to select the cylinder head gasket grade.
  - Remove scale deposits on the top surface of the cylinder block and carbon buildup on the piston head.
2. Use a dial gauge to measure the piston.
  - Measure the piston head protrusion.


**NOTICE:** Make all the measuring points as close to the cylinder block as possible.  
 The difference of the protrusions between the pistons must be the standard value or below.  
 If the piston protrusion is outside the standard range, perform disassembly and assembly.

Specified value: **0.05 mm (0.0020 in)** or less




LPIL12CX00624AA 1

1. Measurement location
2. Measurement location
3. Measurement location
4. Measurement location



LPIL12CX00625AB 2


1. Measurement location
2. Measurement location
3. Measurement location
4. Measurement location



LPIL12CX00626AB 3

- After rotating the crankshaft 720°, the marks on the collared end of the crankshaft and that of the bearing cap should align.

1. Exhaust camshaft gear
2. Inlet camshaft gear
3. Idle gear D




LPIL12CX00646AB 11

### Baffle plate installation

1. Install the baffle plate (1) to the cylinder head.

Tightening torque: **10 N·m (7 lb ft)**




LPIL12CX00651AB 12

### Rocker arm adjustment

1. Loosen the adjust screw using special tool.


Special tool: Valve clearance adjust nut wrench  
(Refer to **Crankshaft - Special tools (10.103)**)



LPIL12CX00647AA 13

- Use the adjust nut wrench (3) to loosen each adjust screw of the rocker arm.


1. Driver
2. Ring spanner



LPIL12CX00648AB 14

3. Clean the cylinder liner using a scraper.
  - Remove carbon from the top of the cylinder bore using a scraper.
4. Remove the piston from the cylinder block.
  - Pull out the piston and connecting rod to the cylinder head side.

**NOTICE:** Be careful not to damage the oil jet and cylinder block when pushing out the connecting rod.



LPIL12CX00767AA 65


### Connecting rod bearing removal

1. Remove the connecting rod bearing from the connecting rod.

**NOTE:** When reusing bearings, sort them in the order of cylinders so that they do not get mixed up with bearings from other cylinders.

4. Temporarily tighten the injector (1) to the cylinder head.
  - Install and temporarily tighten the injector (1), injector clamp, and clamp bolt to the cylinder head.
  - When installing the injector (1) to the cylinder head, confirm that the injector gasket is installed to the injector (1).

**NOTICE:** When replacing the injector, record the injector ID code (2) of the new injector.  
Record the 24 letters on the injector ID plate.




LPIL12CX00656AB 72

### Injection pipe installation

**NOTICE:** When high-pressure lines in the fuel system are removed, always replace them with new lines.  
Reusing them causes damaged seal surfaces and fuel leaks.

1. Temporarily tighten the injection pipe (1) to the injector and common rail assembly.
  - Apply engine oil to the threaded portion of the sleeve nut on the injector side of the injection pipe (1) and the O-ring of the injector.
  - When installing, do not damage the injector sleeve gasket.
  - Using an open-end wrench, lightly tighten the sleeve nut on the common rail side until it is firmly attached.
  - Tighten the sleeve nuts on the injector side until they can no longer be turned by hand.
2. Securely tighten the injector to the cylinder head.
  - Tighten the injector clamp (2) bolt to the specified torque.



LPIL12CX00656AB 73

3. Securely tighten the injection pipe (1) to the injector.
  - Tighten the sleeve nut on the injector side of the injection pipe (1) to the specified torque.


Tightening torque: **30 N·m (22 lb ft)**
4. Securely tighten the injection pipe (1) to the common rail assembly.
  - Tighten the sleeve nut on the common rail side of the injection pipe (1) to the specified torque.

Tightening torque: **25 N·m (18 lb ft)**

Tightening torque: **7.8 N·m (5.753 lb ft)** clamp nut

### Flywheel housing removal


1. Remove the flywheel housing (1) from the crankcase.
  - Loosen the bolt indicated with arrows using a tool while holding down the nut on the opposite side.



LPIL12CX00760AB 4

### Oil seal retainer removal

1. Remove the oil seal retainer from the cylinder block and crankcase.
  - Remove the retainer with the oil seal on.



LPIL12CX00761AA 5

7. Install the bearing cap on the cylinder block.


Tightening torque: **166 N·m (122.44 lb ft)**

**NOTE:** After temporarily tightening the bolts, tighten to the specified torque in the order shown in the diagram.

**NOTICE:** Do not rotate the crankshaft after the bolts are tightened.

8. Remove the bearing cap from the cylinder block.

**NOTE:** Loosen the bolts and gently take out the bearing cap.



14D4656B

14D4656B 3

9. Use a plastigauge to measure the oil clearance.

Standard value: **0.032 - 0.077 mm (0.0013 - 0.0030 in)**


Limit value: **0.11 mm (0.0043 in)**

**NOTE:** Measure the widest part of the plastigauge that was crushed when tightening the bearing cap.

Determine the oil clearance at the journal section.

**NOTE:** If the oil clearance exceeds the limit value, replace all the main bearing or crankshaft as a set.

Remove the plastigauge from the bearing and crankshaft.



CB1DD2A0

CB1DD2A0 4

## Crankshaft inspection

1. Inspect the crankshaft.

**NOTE:** Inspect the crank journal and crank pin surfaces for wear and damage.

Inspect the oil seal installation surface for excessive wear and damage.

Inspect the oil port for clogging.

## Crankshaft measurement

2. Place the crankshaft on the V block.

**NOTE:** Carefully set the crankshaft.


3. Use a dial gauge to measure the runout.

Standard value: **0.05 mm (0.0020 in) max**

**NOTE:** Slowly rotate the crankshaft and measure the runout.

**NOTE:** Measure the outer diameter of the journal and pin sections and calculate the difference between the maximum and minimum lengths.

Measure at 4 locations each for journal section and pin section.




AD31DFC3

AD31DFC3 5

4. Temporarily tighten the injector (1) to the cylinder head.
  - Install and temporarily tighten the injector (1), injector clamp, and clamp bolt to the cylinder head.
  - When installing the injector (1) to the cylinder head, confirm that the injector gasket is installed to the injector (1).

**NOTICE:** When replacing the injector, record the injector ID code (2) of the new injector.  
Record the 24 letters on the injector ID plate.



LPIL12CX00656AB 84

### Injection pipe installation

**NOTICE:** When high-pressure lines in the fuel system are removed, always replace them with new lines.  
Reusing them causes damaged seal surfaces and fuel leaks.

1. Temporarily tighten the injection pipe (1) to the injector and common rail assembly.
  - Apply engine oil to the threaded portion of the sleeve nut on the injector side of the injection pipe (1) and the O-ring of the injector.
  - When installing, do not damage the injector sleeve gasket.
  - Using an open-end wrench, lightly tighten the sleeve nut on the common rail side until it is firmly attached.
  - Tighten the sleeve nuts on the injector side until they can no longer be turned by hand.
2. Securely tighten the injector to the cylinder head.
  - Tighten the injector clamp (2) bolt to the specified torque.

Tightening torque: **26 N·m (19 lb ft)**

3. Securely tighten the injection pipe (1) to the injector.
  - Tighten the sleeve nut on the injector side of the injection pipe (1) to the specified torque.


Tightening torque: **30 N·m (22 lb ft)**

4. Securely tighten the injection pipe (1) to the common rail assembly.

- Tighten the sleeve nut on the common rail side of the injection pipe (1) to the specified torque.

Tightening torque: **25 N·m (18 lb ft)**

Tightening torque: **7.8 N·m (5.753 lb ft)** clamp nut



LPIL12CX00656AB 85

## Fuel filters - Disassemble

### Fuel safety information

**CAUTION:**

- Oil leaks can cause a fire. Therefore, after the work and inspection, wipe off any spilled fuel and check for any leaks after starting the engine.

### Disassembly of fuel filter


**NOTICE:** Be careful not to let the dirt get in the filter during work.

1. Prepare the drain pan.
2. Drain the fuel from the case.

**NOTE:** Loosen the drain plug.


3. Use the special tool to remove the case from the fuel filter body.

Special tool: Filter wrench (Refer to **Crankshaft - Special tools (10.103)**)



C617F15D 1

1. Level ring
2. O-ring
3. Case



3B7B82AE 2

## Common rail - Remove

### Injector safety information

**NOTICE:** The fuel system holes and gaps that form the fuel path, including inside the injectors, are manufactured to high precision.

After removing parts, always place caps or covers to prevent entry of foreign matter as it could cause a malfunction.

### Battery ground cable disconnect


1. Disconnect the battery ground cable from the battery.

**NOTICE:** Do not disconnect the battery cable for **1 min** after turning OFF the ignition switch.

### Fuel pipe removal

2. Remove the fuel pipe (1) from the fuel supply pump and common rail assembly.

**NOTICE:** The fuel pipe cannot be reused.




2B7385B7 1

### Leak-off pipe removal


1. Remove the fuel leak-off pipe (1) from the fuel supply pump and common rail assembly.

**NOTE:** Do not reuse the gasket.



LPIL12CX00079AB 2


5. Disconnect the oil return pipe (1) from the turbocharger assembly.
6. Remove the oil return pipe (1) from the crankcase.



LPIL12CX00195AB 3

7. Remove the turbocharger assembly (2) from the exhaust manifold.

**NOTE:** Do not reuse the gasket.



F89C796A

F89C796A 4


---

## Exhaust Gas Recirculation (EGR) valve - Install

1. Install the EGR valve (1) to the inlet manifold.

Tightening torque: **27 N·m (20 lb ft)**

2. Connect the harness connector to the EGR valve (1).



LPIL12CX00505AB 1

## Battery ground cable connect


1. Connect the battery ground cable to the battery.

---

## Coolant thermostat - Install

1. Install the thermostat (1) to the cylinder head assembly.

**NOTE:** Install the jiggle valve (2) to face the engine front side.



LPIL12CX00954AB 1

## Water outlet pipe installation

1. Install the water outlet pipe to the cylinder head assembly.

Tightening torque: **25 N·m (18.44 lb ft)**

2. Connect the radiator upper hose to the water outlet pipe.

## Coolant filling

1. Replenish the radiator assembly with coolant.

## Battery ground cable connect

1. Connect the battery ground cable to the battery.

### **Coolant filling**


1. Replenish the radiator assembly with coolant.

### **Battery ground cable connect**

1. Connect the battery ground cable to the battery.

- 1 Swing motor
- 2 Center joint
- 3 Control valve





Pressure line

Tank line

Pilot pressure line



Pilot tank line

Electric line

- |  |                                  |
|--|----------------------------------|
| 1. Cushion valve                       | 13. Control valve                |
| 2. Boom (up)                           | 14. Upper pilot pressure sensor  |
| 3. Boom (down)                         | 15. Travel pilot pressure sensor |
| 4. Boom cylinder                       | 16. Console lever lock switch    |
| 5. Load holding valve check            | 17. Monitor display              |
| 6. Bleed-off                           | 18. Computer A                   |
| 7. Check A                             | 19. P1 pressure sensor           |
| 8. Back pressure check valve           | 20. P2 pressure sensor           |
| 9. Remote control valve (boom, bucket) | 21. Hydraulic pump               |
| 10. Lever lock                         | 22. Check valve                  |
| 11. Pressure boost relief              | 23. Oil cooler                   |
| 12. 4 stack solenoid valve             |                                  |





Pressure line



Tank line



Pilot pressure line



Pilot tank line




Electric line

1. Travel motor
2. Travel remote control valve
3. Travel high speed
4. Console lever lock switch
5. 4 stack solenoid valve
6. Travel mode select switch
7. Computer A
8. Control valve
9. Travel pilot pressure sensor
10. Hydraulic pump
11. Horsepower control proportional valve
12. Oil cooler
13. Check valve
  - a. High flow




Measuring port	P1 port
Measurement pressure	<b>27.9 MPa (4047 psi)</b>

8. Using the swing pressure measurement procedure for reference, lock the swing, and check the swing pressure.  
Check the currently set pressure.  
The number of shims for adjustment is determined by the difference between the current pressure and the set pressure.
9. Remove the swing motor port relief assembly from the motor main unit.
  - When removing both sides at the same time, mark the assemblies so that they can be re-assembled on the correct sides.  
Fasten the port relief assembly with a vise table, take-off the cap, then remove the piston, liner, spacer, poppet, shim, and spring.
10. Remove the poppet and spring and add (or remove) one or more shims between the spring and spacer. Find the number of shims in Step **[Invalid Reference]**. After adjusting the shims, install the poppet, spring, spacer, shims, piston, and liner in the sleeve. Fasten the sleeve on the vise table and install the cap. Cap tightening torque: **156.9 N·m (115.72 lb ft)**.



LPIL12CX01643AA 11




LPIL12CX01644AA 12

### Pilot Pressure Adjustment


1. Install the pressure gauge (1).  
While holding the plug with a wrench [ 24 mm] (2), adjust with a hexagon wrench [ 6 mm] (3).

Engine speed	<b>2000 RPM</b>
Lever operation	Neutral
Measuring port	P3
Set pressure	<b>Max. 3.92 MPa (568.6 psi)</b>




LPIL12CX01645AB 13

9. Use a wrench [ **7 mm** ] to loosen the hose bands (1), and then remove the drain hoses (2) and (3).
- Use caps to cover the lines to prevent any entry of water, dust or dirt.




LPIL12CX01688AB 9

10. Use wrenches [ **19 mm, 22 mm, 27 mm** ] to remove the drain hoses.
- Mark the hydraulic oil tank and hoses so that the connectors match at the time of assembly.
  - Attach caps or plugs to the hydraulic oil tank and hoses to prevent any entry of water, dust or dirt.
  - Clean the hydraulic oil tank and hoses by spraying them with a parts cleaner to prevent scratches and prevent dirt from accumulating on the connectors.




SMIL13CEX0054AB 10

1. Drain hose [use **22 mm** wrench]
2. Drain hose [use **22 mm** wrench]
3. Drain hose [use **27 mm** wrench]
4. Drain hose [use **19 mm** wrench]
5. Drain hose [use **22 mm** wrench]
6. Drain hose [use **19 mm** wrench]
7. Drain hose [use **19 mm** wrench]
8. Drain hose [use **19 mm** wrench]
9. Drain hose [use **27 mm** wrench]




SMIL13CEX0055AB 11



SMIL13CEX0056AB 12

### Low tilting (low flow) command priority mechanism

1. Discharge volume  $Q$
2. Discharge pressure (  $1.33P_1 + 0.67P_2$  )




SMIL13CEX0977AA 3

The flow control and the horsepower control tilting command is transmitted to the feedback lever and spool via the large openings [C and F sections] of lever 1 and lever 2, but since the C and F sections have a structure in which a pin D4 projects into a large hole D8, the pin (**897**) only contacts the lever that makes the tilting smaller and the D8 hole for the lever on the side that has the larger tilting command state is free rather than being in contact with the pin (**897**).

This type of mechanical selection method gives priority to flow control and horsepower control commands with low tilting.

### Power shift control (decreased horsepower control)

1. Discharge volume  $Q$
2. Discharge pressure (  $P_1 + P_2$  )




LPIL12CX02774AB 4


Use the power shift pressure  $P_f$  to arbitrarily control the pump set horsepower. (See the Discharge pressure (  $P_1 + P_2$  ) )

When the power shift pressure  $P_f$  increases, the compensation rod (**623**) is moved to the right via the pin (**898**) and the compensation piston (**621**), so the pump tilting angle and the horsepower setting are reduced in the same way as was explained with the overload prevention operation of horsepower control.

By contrast, as the power shift pressure  $P_f$  decreases, the horsepower setting increases.




LPIL12CX02775FB 1



LPIL12CX02080FB 2

Regulator operation explanation diagram


- A. Front side regulator
- B. Rear side regulator



LPIL12CX01285FB 2

Port	Port size	Port name
5b52	G1/4	Arm 1-in pilot line
5b51	G1/4	Arm 1-in pilot line
4a4	G1/4	Arm 2-in pilot line
4a3	G1/4	Bucket-close pilot line
4a2	G1/4	Boom-down pilot line
4a1	G1/4	Right travel forward pilot line
5b4	G1/4	Option pilot line
5b3	G1/4	Boom 2-up pilot line
5b2	G1/4	Right swing pilot line
5b1	G1/4	Left travel backward pilot line
Pi4	G1/4	Negative control power save signal
Pi3	G1/4	Negative control power save signal
5A5	*3/4 SAE standard pressure	Arm-out line
5B5	*3/4 SAE standard pressure	Arm-in line
5A2	*1/2 SAE standard pressure	Swing left line
5B2	*1/2 SAE standard pressure	Swing right line
5A1	*3/4 SAE standard pressure	Left travel forward line
5B1	*3/4 SAE standard pressure	Left travel backward line
P1 (PR)	*3/4 SAE high pressure	Pressure line


The port size with \* indicates the flange size.



LPIL12CX02209HB 4


- |                  |  |
|------------------|--|
| 1. Parallel path | 3. Straight travel signal switchover spool |
| 2. Ball check    | 4. Straight travel switchover valve        |

13. Attach the 2 eyebolts (1) (M12) to the control valve.




SMIL15CEX4402AB 12

14. Attach shackles (1) to the eyebolts, and lift the control valve (3) with a lifting equipment and wire ropes (2).



SMIL15CEX4403AB 13


15. Settle the control valve (1) on a wood plank (2) or other block.



SMIL15CEX4404AB 14

## Pressure-reducing valve - Overview

### Reducing valve (single)




SML14CEX4797EB 1

Port	Port name	Port size
A	Boom (2)	G1/4
P	Pressure	G1/4
T	Return	G1/4

## Drainage block - Overview

### Manifold under cab



SML14CEX3580EA 1

Port	Port size	Port	Port size
P1	G3/8	T1	G3/8
P2	G3/8	T2	G3/8
P3	G3/8	T3	G3/8
P4	G1/4	T4	G1/4
P5	G1/4	T5	G1/4

## Cushion valve - Assemble

This valve has a structure that forms small gaps.

It is precision processed and the parts are carefully selected and fit together, so do not disassemble it as much as possible.

If assembly and disassembly is unavoidable, pay attention to the following. (The product warranty may be invalidated.)

- Only assemble in a clean location with minimal dirt.
- Use only clean tools and cleaning oil and handle them with care.
- Clean the disassembled parts and prepared parts.
- Study the internal structure before starting the work and prepare the parts required by the disassembly objective and scope.


### Reverse operation spool section

1. Assemble the cap screw (1) with O-ring (2) on the spool (3).

- Tightening torque: **9.8 - 14.7 N·m (7.23 - 10.84 lb ft)**

**CAUTION:**

Use a piece of wood (jig) (4) to prevent scratches.



LPIL12CX01885AB 1


2. Insert the spool assemblies (1) assembled in Step 1 into the body.

- Insert the springs (2) and assemble the plugs (3) with the O-rings (4) attached.

- Tightening torque: **39.2 - 49.0 N·m (28.91 - 36.14 lb ft)**

**CAUTION:**

The spool assemblies are symmetrical left/right, so the insertion direction does not matter.




LPIL12CX01888AB 2

## Pedal control - Disassemble

1. Use a shock plate to secure the remote control valve in a vise, and then remove the bellows (1) from the cover (2).


- Be careful not to tear the bellows.



SMIL14CEX1449AB 1


2. Use a hexagon wrench (1) on the hexagon socket head locking screws to loosen them.

Be careful, as application of **LOCTITE® 241** makes the loosening torque high.



SMIL14CEX1450AB 2

3. Place a round rod [D 8 mm (0.315 in) or less] against one end of the cam shaft (1) and lightly strike it with a hammer to remove the shaft.




SMIL14CEX1451AB 3

4. Remove the cams (1) as an assembly with the locking screws and lock nuts attached.


Record the positions of the cams in relation to the covers (2).

- Be careful when removing, as the push rods (3) may fly off.




SMIL14CEX1452AB 4

Make sure that the bellows are properly mounted in the groove and not twisted, as this may reduce anti-dust and anti-moisture protection.




SMIL15CEX3786AB 13

5. Use a wrench [ **19 mm** ] to remove the grease hose (1) that feeds grease to the swing motor reduction gear bearing.




LPIL12CX01429AB 5

6. Use a wrench [ **19 mm** ] to remove the 3 bolts (1), and then remove the under cover (2).
- Tightening torque for bolt installation: **63.7 - 73.5 N·m (46.983 - 54.211 lb ft)**




LPIL12CX01430AB 6

7. Use a wrench [ **13 mm** ] to remove the bolt (2) on the clamp (1) for the hose.




LPIL12CX01431AB 7

8. Use a wrench [ **13 mm** ] to remove the 2 bolts (2) from the bracket (1) for the feed port hose.




SMIL13CEX0045AB 8

21. Tighten the tightening bolts (36) [ 12 mm hexagon diameter] between the cover (32) and housing (26) to a tightening torque of **156.9 N·m (115.7 lb ft)**



SMIL15CEX4802AA 21


22. Installation of make-up  
Install the checks (37) and springs (38) on the cover (32) and tighten the caps (39) [ 14 mm hexagon diameter] to a tightening torque of **137.3 N·m (101.3 lb ft)**.



SMIL15CEX4803AA 22


23. Installation of relief assembly  
Install the relief assemblies (34) [ 14 mm hexagon diameter] to the covers (17) tightened to a tightening torque of **78.5 N·m (57.9 lb ft)**.

- Be careful with the installation direction.




SMIL15CEX4804AA 23

24. Assembly confirmation  
Open the inlet and outlet ports and apply **2.94 MPa (426.45 psi)** pilot pressure to the brake release port (be careful as oil will come out from the motor drain port at this time), and check that the output shaft rotates smoothly more than once at a torque of **39.2 N·m (28.912 lb ft)**. There is an assembly problem if it does not rotate, so disassemble the swing unit again and inspect it.



SMIL15CEX4805AA 24



LPIL12CX02791FB 13

- \*1. Pilot pressure
- \*2. Drain
- \*3. Y surface
- \*4. W chamber


## Reduction gear

The rotational movement of the hydraulic motor shaft is transmitted to the 1<sup>st</sup>-stage sun gear 1 (4) spline coupled with the shaft (102).

At this time, the 1<sup>st</sup>-stage planetary gear 1 (5) is meshed with the sun gear 1, and the planetary gear 1 meshes with the hub (1) while rotating and rotates in orbit around the hub. This orbital movement rotates the 2<sup>nd</sup>-stage sun gear 2 (8) coupled to carrier 1 (3) and carrier 1 fixed to the planetary gear 1.

This rotation is transmitted to the hub (ring gear) through the 2<sup>nd</sup>-stage planetary gear 2 (9) fit into the carrier 2 (7) that is spline coupled with the spindle (2), and this becomes the reduction gear output rotation. (Rotation is also transmitted from the 1<sup>st</sup>-stage planetary gear 1)

2. Remove the O-rings **(135)** and **(139)** from the piston **(112)**.
  - Do not reuse the removed O-rings **(135)** and **(139)**.




LPIL12CX02438AA 33

### Disassembly of hydraulic motor parts


- Oil will spill out when the travel motor is turned side-ways, so place a container under the travel motor.

1. Tilt the travel motor **90°**.
2. Drain the oil inside the travel motor.
3. Remove the 4 partner plates **(116)** and 3 friction plates **(115)**.




LPIL12CX02439AA 34

4. Hold the cylinder block **(104)** with one hand and rotate it alternately 2 - 3 times to detach the shoes **(106)** attached to the swash plate **(103)**.
  - If the cylinder block is removed as is, the parts attached to the cylinder block (pistons **(105)**, shoes) will become detached from the cylinder block and fall inside the spindle **(2)** because the shoe is attached to the swash plate.
5. Remove the cylinder block **(104)** from the shaft **(102)**.



LPIL12CX02440AA 35

6. Remove the piston assemblies (pistons **(105)**, shoes **(106)**) from the cylinder block **(104)**.
  - When removing the piston assembly, hold the retainer plate **(107)** with both hands and remove the pistons **(105)** and shoes **(106)** together. The pistons **(105)** and shoes **(106)** are pressed and held together at the spherical hole sections of the pistons. Pistons **(105)** and shoes **(106)** cannot be separated without damaging the shoes **(106)**. When replacement is necessary, replace them as 1 set. (referred to as piston assembly in the right side figure)



LPIL12CX02441AA 36

## Travel motor - Preliminary test

### Initial pre-conditioning operation

Slowly operate the machine and perform air-bleeding for inside the motor circuit and inside the line according the Operator's Manual for the Machine Main Unit.

First, perform an operation check by repeating "C direction rotation and stopping and A direction rotation and stopping" a number of times at low-speed rotation.

At this time, remaining air inside the circuit may cause abnormal noises from the valves, etc. The abnormal noises will stop as air is bled out while operation is done repeatedly at low speed.

If abnormal noises go away through repeated operation over a while, there is no problem with the motor and it can be used as is.

If operation is done repeatedly and abnormal noises do not stop, there is an abnormality within the motor and it should be replaced.

Check for the presence of oil leaking from the motor, line port sections, each line and each piece of equipment. When oil leaking has been confirmed, retighten the bolts and line joints at the location where the leak is occurring to the specified torque.

After checking is completed, raise the pressure and perform load operation, and check that no abnormal noises or vibrations, etc. are occurring in the motor.

**NOTICE:** When tightening lines, etc. after confirming oil leaking, make sure to have operation of hydraulic devices stopped.

**NOTICE:** Make sure that the operating pressure on the motor is low when checking for oil leaking. If the operating pressure is high and there is oil leaking, there is the danger of oil spraying out.

### Performance confirmation test

After the travel motor maintenance is complete, perform a performance confirmation test according to the procedure below.


### Required instruments and tools

Name	Quantity
For pressure gauge [ 3.43 MPa (498 psi)]	2
For measuring cylinder [ 5 l (1.32 US gal)]	1
Stop watch	1

## Special jig


Cylinder assembly requires the following special jigs:

For bushing removal and press fitting




LPIL12CX02045AA 11

For wiper ring press fitting




LPIL12CX02046AA 12

Seal ring insertion jig



LPIL12CX02047AA 13


Seal ring calibration jig



LPIL12CX02048AA 14

## Disassembly of bushing


1. Raise the snap ring (28) with a screwdriver, and then remove it from the cylinder head.
2. For the bushing (33), use the bushing removal jig (32) as in the diagram on the right and press out the bushing with a press.



SMIL15CEX1763AB 13

### 31. Bushing

- a. Press with the press.




LPIL12CX02062AB 14

## Removal of pin bushing

1. Remove the wiper ring (24) from the tube and piston rod. Remove it by using a screwdriver in the same manner as for the cylinder head.
2. Use the metal block (35) to remove the pin bushing (37).

34. Press

36. Jig



LPIL12CX02063AB 15

## Cleaning and storage

Clean the removed parts with white kerosene, and then apply hydraulic oil, cover the parts, and store them. If they are left disassembled, there is a danger of their collecting rust and dust and not being able to function adequately after they are assembled again.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

5. Tie the cylinder rod with wire **(1)** so that it cannot come out.




SMIL14CEX4814AB 5

6. Turn the key switch **(1)** "OFF" and stop the engine.




LPIL12CX01551AB 6

7. Switch the key switch "ON" again, and then turn the control lever **(1)** about 10 times to bleed out any pressure. Do not operate the arm at this time.



LPIL12CX01552AB 7

8. Move the travel lever **(1)** back and forth about 5 times to bleed off the pressure. Switch the key switch "OFF".



LPIL12CX01553AB 8

# Contents

---

## Frames and ballasting - 39

### Ballasts and supports - 140

#### SERVICE

##### Counterweight

Prepare .....	3
Remove .....	4
Install .....	6

# Index


---

## Tracks and track suspension - 48

### Tracks - 100


Track chain - Install .....	7
Track chain - Install - Shoe plate .....	11
Track chain - Prepare .....	4
Track chain - Prepare - Shoe plate .....	9
Track chain - Remove .....	5
Track chain - Remove - Shoe plate .....	10
Track chain - Service limits .....	3

7. Use a special fiber cloth to thoroughly wipe the sliding surface of the floating seal to prevent any dust or scratches.




LPIL12CX01189AA 7

8. Apply engine oil to the floating seals (1) on the hubs (2) and (3).




LPIL12CX01190AB 8

9. Install the O-ring (4) to the shaft (1), and then install the shaft to the hub (2) and fasten it with the hub pin (3).



LPIL12CX01191AB 9

10. Install the shaft (2) to the roller (1).



LPIL12CX01192AB 10


## Track support roller - Remove

1. Use a box wrench [ **19 mm** ] to loosen the check valve **(1)** to release grease, and then loosen the track shoe tension.  
Do not loosen the check valve all at once.  
Loosen it slowly while monitoring the grease output and shoe loosening.  
Use a rag to catch grease that trickles out of the check valve.




### WARNING:

- If the check valve **(1)** is too loose, it may fly off.
- Do not place your body in front.




LPIL12CX01237BB 1

2. Use a jack **(3)** to lift the top of the shoe, and then insert wood planks **(4)** to separate the shoe **(2)** and upper roller **(1)** by about **10 mm (0.394 in)**.




LPIL12CX01238AB 2

3. Use a box wrench **24 mm** to remove the 2 bolts **(2)**, and then remove the upper roller **(1)**.



LPIL12CX01239AB 3

## Air conditioning - Overview - Air conditioner unit



SMIL14CEX1892HB 1

# Contents

---

## Electrical systems - 55

### Electrical system - 000

#### TECHNICAL DATA

Electrical system	
Special tools .....	3
General specification .....	4

#### FUNCTIONAL DATA

Electrical system	
Component localization .....	48
Component localization - Code table .....	61
Electrical schema - Overall .....	63
Electrical schema - Block diagram .....	65
Overview - Electrical symbol list .....	73
Electrical schema - Connector wiring diagram .....	74
Electrical schema .....	125


#### SERVICE

Electrical system	
Service instruction .....	193
Service instruction .....	196

## Horn (HIGH)

Part No.: KHR21440


Basic frequency: **415 Hz**



SMIL15CEX7590BA 57

## Gate lock limit switch

Part No.: KHR14930



SMIL15CEX7591BA 58

Electrical systems - Electrical system

F14	Fuse <b>10 A</b> : DC/DC converter	X33	Lifting equipment connector
F15	Fuse <b>5 A</b> : air conditioner heater unit	X34	Fan reverse connector
F16	Fuse <b>15 A</b> : air conditioner blower	X36	<b>12 V</b> output (for radio)
F17	Fuse <b>5 A</b> : air conditioner compressor	X37	Wire harness indicator jumper
F18	Fuse <b>10 A</b> : spare	X38	Free swing connector
F19	Fuse <b>15 A</b> : fuel feed pump	X45	Air suspension seat
F20	Fuse <b>10 A</b> : option line	X56	Beacon connector
F41	Fusible link <b>50 A</b> : backup	X74	Diagnostic switch connector
F42	Fuse <b>15 A</b> : cont	X76	Free swing solenoid valve connector
F43	Fusible link <b>65 A</b> : fuse box	X77	HBCV pressure sensor connector
F44	Fusible link <b>50 A</b> : safety RL	K103	Air conditioner compressor relay
F46	Fuse <b>15 A</b> ; F7 (ROOM LAMP & RADIO)	X78	Beacon connector (for crane)
G1	Battery	X82	Beacon switch connector
G2	Alternator	Y2	Pilot pressure solenoid valve (blue tape)
H2	Travel alarm	Y3	Swing brake solenoid valve (pink band)
H1	Audible warning device	Y4	Second stage travel solenoid valve (red tape)
H4	Speaker right	Y5	Second stage relief solenoid valve (yellow tape)
H5	Speaker left	Y7	Main pump power proportional solenoid valve
H9	Alarm <b>24 V, 107 dB</b>	Y8	Air conditioner magnet clutch
H10	Camera 1 (rear)	Y9	Option 2 speed solenoid (blue tape)
H11	Camera 2 (right side)	Y11	Main pump flow proportional solenoid valve
K2	Glow plug relay	Y23	Option 1 knob (R) - Right solenoid valve (blue tape)
K3	Horn relay	Y24	Option 1 knob (R) - Left solenoid valve (red tape)
K7	Battery relay	Y25	Option 2 knob (L) - Right solenoid valve (blue tape)
K10	Working light relay (upper structure/boom)	Y26	Option 2 knob (L) - Left solenoid valve (red tape)
K11	Working light relay (cab)	Y27	Option select solenoid valve (red tape)
K17	Blower off relay	Y35	Suction control valve ( SCV )
K30	Refuel pump relay	Y62	Option press. proportional solenoid valve
K31	Refuel pump stop relay	Y63	INJ1 (No. 1)
K34	Starter cut relay	Y64	INJ2 (No. 3)
K35	Room lamp relay	Y65	INJ3 (No. 4)
K36	Left speaker relay	Y66	INJ4 (No. 2)
K37	Right speaker relay	Y67	Option select solenoid valve (blue tape)
K63	ECM relay	Y68	Option 2 speed solenoid valve (red tape)
K64	Key ON relay		









# Contents

---

## Electrical systems - 55

### Harnesses and connectors - 100

#### FUNCTIONAL DATA

##### Wiring harnesses

Electrical schematic sheet 01 - Legend .....	4
Electrical schematic sheet 02 - Starting circuit .....	6
Electrical schematic sheet 03 - Power distribution .....	8
Electrical schematic sheet 04 - Power distribution .....	10
Electrical schematic sheet 05 - Engine-turbo controller .....	12
Electrical schematic sheet 06 - Engine controller .....	14
Electrical schematic sheet 07 - Engine controller .....	16
Electrical schematic sheet 08 - Engine controller .....	18
Electrical schematic sheet 09 - Engine-injectors and sensors .....	20
Electrical schematic sheet 10 - Engine - VGS turbo, EGR valve .....	22
Electrical schematic sheet 11 - Engine-lamp, audio, fuel pump and washer .....	24
Electrical schematic sheet 12 - Engine-solenoid valve .....	26
Electrical schematic sheet 13 - Engine-switches and proportional S/V .....	28
Electrical schematic sheet 14 - Engine-sensors .....	30
Electrical schematic sheet 15 - Engine-refuel pump .....	32
Electrical schematic sheet 16 - Option line circuit .....	34
Electrical schematic sheet 17 - Option line circuit- pedal type .....	36
Electrical schematic sheet 18 - Option line circuit- solenoid type .....	38
Electrical schematic sheet 19 - Main cab-controller A .....	40
Electrical schematic sheet 20 - Main cab-controller A .....	42
Electrical schematic sheet 21 - Main cab-controller B .....	44
Electrical schematic sheet 22 - Main cab-controller B .....	46
Electrical schematic sheet 23 - Main cab-inter connector .....	48
Electrical schematic sheet 24 - Main cab-monitor display .....	50
Electrical schematic sheet 25 - Main cab-wiper controller .....	52
Electrical schematic sheet 26 - Main cab-lamp and speaker .....	54
Electrical schematic sheet 27 - Main cab-can circuit .....	56
Electrical schematic sheet 28 - Main cab-ECM inter connector .....	58
Electrical schematic sheet 29 - Main cab-relays .....	60
Electrical schematic sheet 30 - Main cab-relays .....	62
Electrical schematic sheet 31 - Main cab-switches .....	64


**Wiring harnesses - Electrical schematic sheet 15 - Engine-refuel pump**

Type	Components	Connectors/link	Description
Sensor	B83		Pressure sensor
Sensor	B84		Pressure sensor (pilot bucket close)
Sensor	B85		Pressure sensor (pilot boom up)
Alarm	H9		Alarm
Relay	K30		Refuel pump relay
Relay	K31		Refuel pump stop relay
Motor	M14		Fuel feed pump motor
Switch	S61		Refuel pump switch
Connector	CN.D53	<b>CN.D53</b>	Pressure sensor (pilot boom up)
Connector	CN.D54	<b>CN.D54</b>	Pressure sensor (pilot bucket close)
Connector	CN.D55	<b>CN.D55</b>	Pressure sensor (pilot bucket close)
Connector	CN.D76	<b>CN.D76</b>	
Connector	CN.D81-1	<b>CN.D81-1</b>	Refuel pump relay
Connector	CN.D81-2	<b>CN.D81-2</b>	Refuel pump stop relay
Connector	CN.D81-3	<b>CN.D81-3</b>	Fuel feed pump motor
Connector	CN.D81-4	<b>CN.D81-4</b>	Refuel pump switch
Connector	CN.D81-5	<b>CN.D81-5</b>	
Connector	CN.D81-6	<b>CN.D81-6</b>	Alarm
Connector	CN.D81-7	<b>CN.D81-7</b>	Alarm


## Wiring harnesses - Electrical schematic sheet 30 - Main cab-relays

Type	Components	Connectors/link	Description
Relay	K3		Horn relay
Relay	K10		Working light (upperstructure / attachment) relay
Relay	K11		Working light (cab) relay
Relay	K35		Room lamp relay
Relay	K36		Speaker left relay
Relay	K37		Speaker right relay
Relay	K77		Beacon relay
Connector	CN.A16	<b>CN.A16</b>	Relay horn
Connector	CN.A17	<b>CN.A17</b>	Relay lamp: upper
Connector	CN.A18	<b>CN.A18</b>	Relay lamp: cab
Connector	CN.A19	<b>CN.A19</b>	Relay beacon
Connector	CN.A20	<b>CN.A20</b>	Relay room lamp
Connector	CN.A21	<b>CN.A21</b>	Relay speaker:R
Connector	CN.A22	<b>CN.A22</b>	Relay speaker:L
Connector	CN.A23	<b>CN.A23</b>	To controller C
Connector	CN.A51	<b>CN.A51</b>	
Connector	CN.A55	<b>CN.A55</b>	

**CONNECTOR CN.A6 - CONTROLLER B (Male)**




SMIL15CEX9246AA 11



SMIL15CEX9239AA 12

Pin	From	Wire	Description	Color-Size	Frame
2	CN.A25-M-P-8	69A		BY	SHEET 21
3	CN.A25-M-P-1	065A		Y	
4	CN.A2-P-12	56		PL	SHEET 20
6	CN.A41-M-P-4	040D		P	SHEET 23
10	CN.A25-M-P-3	066A		YL	SHEET 21
12	CN.A2-P-4	55		PW	SHEET 20
14	CN.A42-M-P-4	041D		PG	SHEET 23


**CONNECTOR CN.E4 - CRANK ANGLE SENSOR (Male)**




SMIL15CEX9413AA 55

Pin	From	Wire	Description	Color-Size	Frame
1	CN.D7-M-P-4	310A		VW-0.75	<b>SHEET 08</b>
2	CN.D7-M-P-1	312B		G-0.75	
3	CN.D7-M-P-2	311B		GrB- 0.75	

**CONNECTOR CN.B10 - BEACON (Male)**




SMIL15CEX9323AA 21



SMIL15CEX9314AA 22

Pin	From	Wire	Description	Color-Size	Frame
2	SP-720B-P-X	722		B-0.85	<b>SHEET 31</b>
3	CN.A49-M-P-9	842B		LG-0.85	<b>SHEET 33</b>

**CONNECTOR CN.E11 - WATER TEMPERATURE SENSOR (Male)**



SMIL15CEX9416AA 55

Pin	From	Wire	Description	Color-Size	Frame
1	CN.D10-F-P-5	340A		L -0.75	<b>SHEET 08</b>
2	SP-343-P-X	343C		G -0.75	
3	CN.D10-F-P-6	XXB		R -0.75	

**CONNECTOR CN.C20 - CAMERA 3 (BLUE TAPE) (Male)**


Pin	From	Wire	Description	Color-Size	Frame
1	SP-960A-P-X	970		R	SHEET 38
2	SP-961A-P-X	971		B	
3	CN.C4-F-P-3	972A		YR	SHEET 24
4	CN.C4-F-P-13	973A		WR	

---


**CONNECTOR CN.A37 - MEMORY CLEAR (Female)**

Pin	From	Wire	Description	Color-Size	Frame
1	CN.A53-F-P-13	084A		BrY	<b>SHEET 06</b>

**CONNECTOR CN.A53 (Female)**




SMIL15CEX9335AA 7



SMIL15CEX9333AA 8

Pin	From	Wire	Description	Color-Size	Frame
1	CN.A38-M-P-2	142G		WR-1.25	<b>SHEET 28</b>
2	CN.A09-P-1	370B		YR-0.85	<b>SHEET 29</b>
3	CN.A15-P-2	373A		LR-0.85	
4	SP-011-P-X	301A		BrR-0.85	
5	CN.A48-F-P-5	302A		LG-0.85	<b>SHEET 34</b>
6	CN.A10-P-5	303		GW-0.85	<b>SHEET 29</b>
7	CN.A41-M-P-1	040A		P	<b>SHEET 23</b>
8	CN.A42-M-P-1	041M		PG	
9	CN.A27-M-P-6	050E		V	<b>SHEET 27</b>
10	CN.A27-M-P-14	051E		VG	
11	SP-082C-P-X	082A		PB	
12	SP-080B-P-X	080A		PL	
13	CN.A37F-P-1	084A		BrY	

**CONNECTOR CN.57-11**




SMIL15CEX9455AA 54


Pin	From	Wire	Description	Color-Size	Frame
1	SP-854A-P-X	860		GL	SHEET 18
2	SP-535D-P-X	535E		GY	

## Wire connectors - Component diagram 08

CONNECTOR CN.D80 - AIR CLEANER PRESSURE SWITCH (Male)



SMIL15CEX9397AA 1



SMIL15CEX9395AA 2


Pin	From	Wire	Description	Color-Size	Frame
1	S62-P-IN	650A		Y-1.25	SHEET 13
2	S62-P-OUT	533B		Y-1.25	

Wiring harnesses - Electrical schematic sheet 37 - Air-conditioner unit .....	76
Wiring harnesses - Electrical schematic sheet 38 - Camera .....	78
Wiring harnesses - Electrical schematic sheet 39 - Console switches .....	80
Wiring harnesses - Electrical schematic sheet 40 - Knob-right and knob-left .....	82
Wiring harnesses - Electrical schematic sheet 41 - GPS antenna and GSM antenna .....	84
Wire connectors - Component diagram 00 .....	87
Wire connectors - Component diagram 01 .....	142
Wire connectors - Component diagram 02 .....	190
Wire connectors - Component diagram 03 .....	231
Wire connectors - Component diagram 04 .....	252
Wire connectors - Component diagram 05 .....	269
Wire connectors - Component diagram 06 .....	304
Wire connectors - Component diagram 07 .....	320
Wire connectors - Component diagram 08 .....	332
Wire connectors - Component diagram 09 .....	351
Wiring harnesses - Electrical schematic sheet 01 - Legend .....	4
Wiring harnesses - Electrical schematic sheet 02 - Starting circuit .....	6

## Suction control valve

The suction control valve is installed on the supply pump portion, and controls the fuel force-feed to the common rail. The ECM controls the fuel discharge amount by regulating the energizing time to the suction control valve.

1. Suction control valve




SMIL15CEX7792AB 3

## Fuel temperature sensor

The fuel temperature sensor is installed on the supply pump, and the thermistor changes the resistance according to the temperature change. The resistance becomes lower when the fuel temperature is high, and higher when the fuel temperature is low. The ECM applies **5 V** to the fuel temperature sensor through the pull-up resistor, and calculates the fuel temperature from changes in the voltage, which is used to control the supply pump, etc. The voltage becomes lower when the resistance is lower, and it becomes higher when the resistance is higher.

**NOTE:** Do not replace the fuel temperature sensor. When a malfunction is found, replace the supply pump assembly.




SMIL14CEX3995AA 4

## Common rail (fuel rail)

The common rail (fuel rail) receives the fuel from the supply pump, retains the fuel pressure, and distributes the fuel to each cylinder. The fuel pressure sensor and the pressure limiter are installed on the common rail (fuel rail).

1. Pressure limiter
2. Fuel pressure sensor
3. Common rail



SMIL15CEX7793AB 5

# Index

---

## Electrical systems - 55

### Engine control system - 015

Engine Control Unit (ECU) - Fault code index .....	35
Engine Control Unit (ECU) - Install .....	43
Engine Control Unit (ECU) - Prepare .....	41
Engine Control Unit (ECU) - Remove .....	42
Engine Control Unit (ECU) - Static description .....	37
Engine Control Unit (ECU) - Wiring schema .....	28
Engine control system - Component identification .....	4
Engine control system - Component localization .....	19
Engine control system - Dynamic description .....	6
Engine control system - Inspect .....	39
Engine control system - Static description .....	3
Engine speed/RPM sensor - Inspect .....	45
Engine speed/RPM sensor - Install .....	46
Engine speed/RPM sensor - Remove .....	44
Engine timing sensors Camshaft sensor - Inspect .....	48
Engine timing sensors Camshaft sensor - Install .....	49
Engine timing sensors Camshaft sensor - Remove .....	47

## Visual inspection

Careful visual inspection is required for several symptom procedures. This can lead to correcting a problem without further inspections, and can save valuable time. The inspection includes the following:

Whether there is improper connection of the connector.

Especially for CKP sensor and CMP sensor.

Correct wiring connections, tightening, and disconnection.

Whether the power of any commercial accessories is being taken from the ECM power.

Whether the ECM ground is clean and securely installed in the correct location.

Correct connections, cracks, and twists in the pipes and hoses related to fuel, air or oil. Extensively check for any leaks or blockage.


Whether there is any fuel leaks or pipe damage in the fuel system.

Whether the structure allows for air deposit due to layout of the fuel filter (c), pre-filter (a) and electromagnetic pump (b).

Check whether they are arranged to prevent air accumulation as Isuzu genuine pre-filters (a) do not have any plugs for air removal. Also check whether the inlet and outlet of the electromagnetic pump (b) have an appropriate layout. Fix layouts which have the electromagnetic pump (b) inlet on the upper side or have an outlet toward the motion direction of the machine.

Abnormalities of the air intake system parts.

Abnormalities of the exhaust system parts.



## Diagnostic aids

Fuel cut-off, fuel freezing, air entering fuel line, filter abnormality, line abnormality, fuel quality, fuel tank and other fuel system abnormalities

Filter clogging, intake air line abnormality and other intake air system abnormalities

Supply pump abnormality

The diagnostic trouble code for nonpressure fuel feeding of supply pump is diagnosed while the engine is running.

Accordingly, if the engine does not start due to nonpressure fuel feeding caused by a supply pump abnormality, no diagnostic trouble code is detected.

Pressure limiter operation/internal seal deterioration and other common rail abnormalities

Injector abnormality, fuel not injected

System down due to malfunctions.

Engine abnormality caused by seizing, compression pressure deficiency and other mechanical troubles

ACG failure.

Troubles related to the hydraulic pump and other device on the machine

Effect of wireless devices, lights, or other electrical components installed after purchase

ECM failure.

- |               |                  |
|---------------|------------------|
| 1. Rectifier  | 6. Front bracket |
| 2. Field coil | 7. Rotor         |
| 3. Stator     | 8. Rear bracket  |
| 4. Bearing    | 9. Regulator     |
| 5. Pulley     | 10. Bearing      |

# Contents

---

## Electrical systems - 55

### Fuel injection system - 010

#### FUNCTIONAL DATA

Fuel injection system	
Dynamic description - Feed pump automatic stop .....	3
Fuel filter sensor	
Dynamic description Fuel Filter Water Level Abnormality .....	4

#### SERVICE

Fuel filter sensor	
Prepare .....	5
Remove .....	6
Install .....	7
Fuel filter restriction sensor	
Remove .....	8
Install .....	9
Fuel temperature sensor	
Remove .....	10
Inspect .....	18
Install .....	19
Common rail pressure sensor	
Remove .....	28
Install .....	29
Fuel shutoff solenoid	
Remove .....	30
Install .....	31

# Index

---

## Electrical systems - 55

### Fuel injection system - 010

Common rail pressure sensor - Install .....	29
Common rail pressure sensor - Remove .....	28
Fuel filter restriction sensor - Install .....	9
Fuel filter restriction sensor - Remove .....	8
Fuel filter sensor - Dynamic description Fuel Filter Water Level Abnormality .....	4
Fuel filter sensor - Install .....	7
Fuel filter sensor - Prepare .....	5
Fuel filter sensor - Remove .....	6
Fuel injection system - Dynamic description - Feed pump automatic stop .....	3
Fuel shutoff solenoid - Install .....	31
Fuel shutoff solenoid - Remove .....	30
Fuel temperature sensor - Inspect .....	18
Fuel temperature sensor - Install .....	19
Fuel temperature sensor - Remove .....	10


## Coolant high temperature sensor - Install

1. Install the overheat switch on the water outlet pipe (1).

Tightening torque: **31 N·m (22.86 lb ft)**

2. Connect the harness connector to the overheat switch (2).

3. Coolant temperature sensor



3D3C2D21

3D3C2D21 1

# Contents

---

## Electrical systems - 55

### Cab controls - 512

#### FUNCTIONAL DATA

Cab controls	
Dynamic description - Work mode control .....	4
Dynamic description - Travel speed selection .....	6
Cab radio set	
Dynamic description - Radio mute .....	8
Horn control switch	
Dynamic description .....	9
Instrument cluster	
Electrical schema .....	10
Static description - Screen display list .....	11
Static description - CHECK screen list .....	12
Static description - List of control unit screens .....	31
Static description - Model select .....	40
Static description - Throttle volume default setting .....	46
Static description - Password setting .....	47
Static description - Clock adjustment .....	48
Static description - Parameter setting .....	50
Static description - Option flow pressure setting .....	52
Static description - Screen brightness setting .....	55
Dynamic description - Fuel gauge .....	56
Dynamic description - Coolant temperature gauge .....	58
Dynamic description - Oil temperature gauge .....	60
Dynamic description - Monitor display dimming .....	62
Dynamic description - ECO gauge .....	64
Dynamic description - Diagnostic trouble code indicator .....	65
Dynamic description - Clock .....	66
Dynamic description - Fuel economy gauge .....	67
Static description - Service monitor .....	68
Static description - SETUP screen list .....	78

#### SERVICE

Instrument cluster	
Prepare .....	84

DIGITAL OUT-2	1	Battery relay
	2	2 pumps flow solenoid
	3	Option return line switch solenoid
	4	Travel alarm
DIGITAL OUT-3	1	
	2	Window washer signal
	3	-
	4	-
DIGITAL OUT-4	1	-
	2	-
	3	-
	4	-

### Sensor input

CONTROL UNIT		2 / 4
POTENTIO - 1	: 0 4 . 0 0	V
POTENTIO - 2	: 0 4 . 0 1	V
POTENTIO - 3	: 0 4 . 0 2	V
POTENTIO - 4	: 0 4 . 0 3	V
POTENTIO - 5	: 0 4 . 0 4	V
POTENTIO - 6	: 0 4 . 0 5	V
POTENTIO - 7	: 0 4 . 0 6	V
POTENTIO - 8	: 0 4 . 0 7	V
POTENTIO - 9	: 0 4 . 0 8	V

SMIL14CEX0538EA 3

POTENTIO-1	V	P1 pump pressure sensor
POTENTIO-2	V	P2 pump pressure sensor
POTENTIO-3	V	N1 pump pressure sensor
POTENTIO-4	V	N2 pump pressure sensor
POTENTIO-5	V	Swing pilot pressure sensor
POTENTIO-6	V	Upper pilot pressure sensor
POTENTIO-7	V	Travel pilot pressure sensor
POTENTIO-8	V	Fuel filter clog sensor
POTENTIO-9	V	Engine throttle switch

### Sensor input

CONTROL UNIT		3 / 4
POTENTIO - 10	0 4 . 0 7	V
SENSOR - 1	9 9 9 9	Ω
SENSOR - 2	9 9 9 . 9	Ω
SENSOR - 1	0 4 . 0 5	V
SENSOR - 2	0 4 . 0 6	V
FREQUENCY IN	0	Hz


SMIL14CEX0539EA 4

POTENTIO-10	V	Overload pressure sensor (Europe and Japan only)
SENSOR-1	Ω	Hydraulic oil temperature sensor
SENSOR-2	Ω	Fuel level sensor

## Instrument cluster - Dynamic description - Monitor display dimming


### Purpose

Adjusts the brightness of the backlight through operation that is linked to the working light and solar radiation sensor.



SMIL15CEXZ398FB 1

- |                           |   |
|---------------------------|---|
| 1. Monitor                | 5. Working light relay  |
| 2. Computer A             | a. Dimming level automatic adjustment by solar radiation sensor |
| 3. Solar radiation sensor | b. Working light linked dimming by working light relay          |
| 4. Working light switch   |   |



LPIL12CX01018EB 2

- \*1. Boom-up proportional valve
- \*2. Travel pressure sensor
- \*3. Computer A
- \*4. Computer B
- \*5. Boom-up pressure sensor
- \*6. Arm-in pressure sensor
- \*7. Bucket-close pressure sensor

### Operation


1. The operator operates the shovel.
2. The system judges the operator status
3. When the system judges that digging operation is being performed, it controls boom 2- down proportional valve.
4. When the operator stops arm-in full lever operation or performs travel, the system controls boom 2-down proportional valve.

### Bucket control

Mostly in the second half of leveling and when collecting dirt and sand during digging, the spool opening is opened so that a larger volume can flow.

### Configuration

The larger the output current, the more the secondary pressure output is suppressed.



LPIL12CX01019EB 3

- \*1. Travel pressure sensor
- \*2. Computer A
- \*3. Computer B
- \*4. Bucket-close reverse proportional valve
- \*5. Boom-up pressure sensor
- \*6. Arm-in pressure sensor
- \*7. Bucket-close pressure sensor

### Operation explanation

1. The operator operates the shovel.





## Wiper relays - Prepare

Items to prepare:

- Wrench [ **10 mm**]
- Box wrench [ **10 mm**]
- Phillips Screw driver
- Screw driver


P0380-Glow plug circuit [ECM] .....	131
P0381-Diagnostic trouble code 0381 glow plug system error [ECM] .....	133
P0404-Exhaust gas recirculation 1 control circuit range/performance [ECM] .....	135
P0409-Exhaust gas recirculation 1 sensor circuit [ECM] .....	137
P0521-Engine oil low pressure error [ECM] .....	139
P0522-Oil pressure sensor circuit low [ECM] .....	141
P0523-Oil pressure sensor circuit high [ECM] .....	143
P0563-System voltage high [ECM] .....	145
P0601-Internal control module memory check sum error [ECM] .....	146
P0602-Control module programming error [ECM] .....	147
P0604-Internal control module random access memory (RAM) error [ECM] .....	148
P0606-ECM/PCM processor [ECU] .....	149
P060B-Internal control module A/D processing performance [ECM] .....	150
P0615-Starter relay circuit [ECM] .....	151
P0641-Sensor Voltage System Error [ECM] .....	153
P0650-Check engine lamp system error [ECM] .....	155
P0651-Sensor voltage system error [ECM] .....	157
P0685-ECM main relay control system low input [ECM] .....	160
P0687-ECM power relay control circuit high [ECM] .....	161
P0697-Sensor voltage system error [ECM] .....	162
P06AF-EDU injector custom ic, check sum, communication line [ECM] .....	163
P1093-Fuel rail pressure (FRP) too low [ECM] .....	164
P1097-Diagnostic trouble code 1097 boost temperature sensor system low input (intercooler outlet) [ECM] .....	168
P1098-Diagnostic trouble code 1098 boost temperature sensor system high input (intercooler outlet) [ECM] .....	169
P1261-Injector positive voltage control circuit group 1 [ECM] .....	171
P1262-Injector positive voltage control circuit group 2 [ECM] .....	172
P1404-Exhaust gas recirculation 1 closed position performance [ECM] .....	173
P1606-SWIC1 Internal error, communication circuit error [ECM] .....	175
P160B-AD-IC failure error [ECM] .....	176
P1621-Control module EEPROM error [ECM] .....	177
P1622-Control module EEPROM hardware error [ECM] .....	179
P1655-Sensor reference voltage 4 circuit [ECM] .....	181
P20DE-Fuel filter clog error (first stage) [ECM] .....	182
P20DF-Fuel filter clog sensor error (abnormally low voltage) [ECM] .....	184
P20E0-Fuel filter clog sensor error (abnormally high voltage) [ECM] .....	186
P2122-Pedal position sensor 1 circuit low input [ECM] .....	188
P2123-Pedal position sensor 1 circuit high input [ECM] .....	190
P2127-Pedal position sensor 2 circuit low input [ECM] .....	192
P2128-Pedal position sensor 2 circuit high input [ECM] .....	194
P2138-Pedal position sensor 1 – 2 voltage correlation [ECM] .....	196
P2146-Fuel injector group 1 supply voltage circuit [ECM] .....	198

## 7201-Travel high-speed solenoid signal abnormality

### Control Module : MCM

#### Solution:

1. Use the below image for the fault code resolution process:



LPIL12CX00897GB 1

- |                                  |                                |
|----------------------------------|--------------------------------|
| 1. Computer A                    | 7. Relay battery               |
| 2. Engine computer               | 8. Battery 24 V                |
| 3. Travel pilot pressure sensor  | 9. Fuse key                    |
| 4. Crank angle sensor            | 10. Relay key switch turned ON |
| 5. Fuse computer                 | 11. Fusible link fuse box      |
| 6. 2 stage travel solenoid valve | 12. Key switch                 |


a. CAN communication

## 7428-Fuel filter water level

### Control Module : MCM

#### Solution:

1. Use the below image for the fault code resolution process:



1. Computer A
2. Level switch

Check that the "FUEL FILTER" display appears.

Drain the fuel filter.

Turn the key switch ON.

Check for the diagnostic trouble code 7428.

A. If diagnostic trouble code 7428 is displayed, proceed to Step 2.

2. Inspect the connection status of each connector. Make sure that all the connectors are secured.

A. If diagnostic trouble code 7428 is displayed, proceed to Step 3.

3. Turn the key switch OFF and disconnect the fuel filter water level switch connector **CN.D89**.

Inspect for continuity between the terminals 1 and 2 of the fuel filter water level switch connector **CN.D89** fuel filter water level switch side.

A. If there is no continuity, replace the fuel filter water level switch **(2)**.

B. If there is continuity, replace computer A **(1)**.

**Wiring harnesses - Electrical schematic sheet 11 (55.100)**

**Wiring harnesses - Electrical schematic sheet 06 (55.100) Wiring harnesses - Electrical schematic sheet 10 (55.100)**

---

## P0335-Crankshaft position sensor circuit

### Control Module : ECM

#### Solution:

1. Check and diagnose the trouble code setting conditions before you proceed with the diagnostics code P0335.

Diagnostic trouble codes P0016, P0336, P0340 and P1655 are not set.

The CMP sensor signal pulse is detected.

While the engine is running, the ECM detects that the CKP sensor signal pulse is not generated.

2. Check and diagnose the below fault codes before you proceed with the diagnostics code P0335.

Diagnostic trouble code P0340

Diagnostic trouble code P1655

3. Turn OFF the starter switch.

Disconnect the harness connector **CN.E4** from the crankshaft position sensor.

Turn ON the starter switch.

Measure the voltage between the **5 V** power supply circuit and normal GND of the crankshaft position sensor harness connector **CN.E4**.

If the reading is less than or equal to the **4.5 V**, inspect to see if there is an open circuit or high resistance with the **5 V** power supply circuit between the ECM and the crankshaft position sensor.

A. If a problem is found, repair the **5 V** power supply circuit.

B. If there are no problems, proceed to Step 4.

4. Measure the voltage between the signal circuit and normal GND of the crankshaft position sensor harness connector **CN.E4**.

If the reading is more than or equal to the **5.5 V**, inspect to see if there is a short circuit to the battery or ignition power supply with the signal circuit between the ECM and the crankshaft position sensor.

#### **NOTE:**

- *There must be no disconnection or high resistance.*
- *There must be no short circuit to GND.*

A. If a problem is found, repair the signal circuit.

B. If there are no problems, proceed to Step 5.

5. Measure the voltage between the signal circuit of the crankshaft position sensor harness connector **CN.E4** and a normal GND again.

If the reading is less than or equal to **4.5 V**, inspect the **5 V** power supply circuit between the ECM and the crankshaft position sensor.

A. If a problem is found, repair the signal circuit.

B. If there are no problems, proceed to Step 6.

6. Measure the voltage between the **5 V** power supply circuit and GND circuit of the crankshaft position sensor harness connector **CN.E4**.

If the reading is more than or equal to **4.5 V**, inspect to see if there is poor connection with the crankshaft position sensor harness connector **CN.E4**.

A. If a problem is found, repair the harness connector **CN.E4**.

Disconnect the harness connector **CN.E6** from the boost sensor.

Turn ON the starter switch.

Measure the voltage between the throttle position sensor **5 V** power supply circuit and GND of the throttle position sensor harness connector **CN.B2**.

- A. If it is greater than or equal to **4.5 V**, replace the boost sensor. (Refer to “ **Boost pressure sensor - Remove (55.014)**” and “ **Boost pressure sensor - Install (55.014)**”)
- B. If it is less than or equal to **4.5 V**, inspect for a short circuit to GND in the throttle position sensor **5 V** power supply circuit between the ECM and throttle position sensor.  
If a problem is found, repair the throttle position sensor **4.5 V** power supply circuit.
8. Inspect for a short circuit to the GND in the fuel filter pressure sensor **5 V** power supply circuit between the ECM and fuel filter pressure sensor.
  - A. If a problem is found, repair the fuel filter pressure sensor **5 V** power supply circuit.
  - B. If there are no problems, proceed to Step **9**.
9. Inspect for a short circuit to the GND in the boost sensor **5 V** power supply circuit between the ECM and boost sensor.
  - A. If a problem is found, repair the boost sensor **5 V** power supply circuit.
  - B. If there are no problems, proceed to Step **10**.
10. Replace the ECM. (Refer to “ **Engine Control Unit (ECU) - Remove (55.015)**” and “ **Engine Control Unit (ECU) - Install (55.015)**”).  
Set the injector identification code and the engine number on the ECM.
11. Confirm resolution:
  1. Clear the diagnostic trouble code using the trouble diagnosis scan tool.
  2. Turn the starter switch OFF for **1 min** or longer.
  3. Start the engine.
  4. Perform a test-run under the conditions for running the Diagnostic Trouble Code.

**NOTE:** *The setting conditions such as engine operating hours or coolant temperature depend on the diagnostic trouble code.*

5. Use the trouble diagnosis scan tool to confirm that a diagnostic trouble code has not been detected.  
Conditions for setting the Diagnostic Trouble Codes such as engine run time or coolant temperature, etc., vary depending on the Diagnostic Trouble Codes.

**Wiring harnesses - Electrical schematic sheet 09 (55.100) Wiring harnesses - Electrical schematic sheet 07 (55.100) Wiring harnesses - Electrical schematic sheet 14 (55.100) Wiring harnesses - Electrical schematic sheet 20 (55.100)**

---

## P20DF-Fuel filter clog sensor error (abnormally low voltage)

### Control Module : ECM

#### Solution:

1. Check and diagnose the trouble code setting conditions before you proceed with the diagnostics code P20DF.

Diagnostic trouble code P060B is not detected.

The ECM detects that the fuel filter pressure sensor voltage is **0.1 V** or lower for **5 s**.

2. Check and diagnose the below fault codes before you proceed with the diagnostics code P20DE.

Diagnostic trouble code P0641

3. Turn OFF the starter switch.

Measure the voltage between the **5 V** power supply circuit of the harness connector of the fuel filter pressure sensor and normal ground.

If the voltage is equal or less than **4.5 V**, inspect for a disconnection or high resistance in the 5 V power supply circuit between the ECM and fuel filter pressure sensor.

Start the engine.

#### **NOTE:**

- *The fuel filter pressure sensor shares use of the 5 V power supply circuit with other sensors.*
- *A diagnostic trouble code may be detected for the sensors sharing use of this circuit.*

A. If a problem is found, repair the **5 V** power supply circuit.

B. If there are no problems, proceed to Step 4.

4. Connect a test cable with fuse between the **5 V** power supply circuit of the harness connector of the fuel filter pressure sensor and signal circuit.

Check the value indicated on the fuel filter pressure sensor (clog) with the trouble diagnosis scan tool.

If the voltage is equal or more than **4.5 V**, inspect for a contact defect in the harness connector of the fuel filter pressure sensor.

A. If a problem is found, repair the harness connector.

B. If the harness connector is normal, replace the fuel filter pressure sensor. (Refer to “ **Fuel filter restriction sensor - Remove (55.010)**” and “ **Fuel filter restriction sensor - Install (55.010)**”)

Proceed to Step 5.

5. Inspect the signal circuit between the ECM and fuel filter pressure sensor.

#### **NOTE:**

- *There must be no disconnection or high resistance.*
- *There must be no short circuit to ground.*

A. If a problem is found, repair the signal circuit.

B. If there are no problems, proceed to Step 6.

6. Inspect for a contact defect in the ECM harness connector **CN.D1-02**.

A. If a problem is found, repair the harness connector **CN.D1-02**.

B. If the harness connector **CN.D1-02** is normal, replace the ECM. (Refer to “ **Engine Control Unit (ECU) - Remove (55.015)**” and “ **Engine Control Unit (ECU) - Install (55.015)**”).

7. Set the injector identification code and the engine number on the ECM.

A. If the voltage exceeds **1.5 - 3.5 V**, replace the ECM. (Refer to “ **Engine Control Unit (ECU) - Remove (55.015)**” and “ **Engine Control Unit (ECU) - Install (55.015)**”).

7. Set the injector identification code and the engine number on the ECM.

8. Turn OFF the starter switch.

Connect the harness connector to the control unit of the actual unit.

Turn ON the starter switch.

Measure the voltage between the CAN- High terminal and GND of the termination resistor harness connector.

**CN.D4**

Measure the voltage between the CAN- Low terminal and GND the termination resistor harness connector **CN.D4**.

A. If the voltage exceeds **1.5 - 3.5 V**, replace the ECM. (Refer to “ **Engine Control Unit (ECU) - Remove (55.015)**” and “ **Engine Control Unit (ECU) - Install (55.015)**”).

9. Set the injector identification code and the engine number on the ECM.

10. Turn OFF the starter switch.

Connect the harness connector to the control unit of the actual unit.

Turn ON the starter switch.

Measure the voltage between the CAN- High terminal and GND of the termination resistor harness connector.

**CN.D4**

Measure the voltage between the CAN- Low terminal and GND of the termination resistor harness connector

**CN.D4**.

A. If the voltage exceeds **1.5 - 3.5 V**, replace the control unit of the machine.

B. If the voltage is within **1.5 - 3.5 V**, replace the termination resistor.

11. Confirm resolution:

1. Clear the Diagnostic Trouble Code using the trouble diagnosis scan tool.

2. Turn the starter switch OFF for **1 min** or longer.

3. Start the engine.

4. Perform a test-run under the conditions for running the Diagnostic Trouble Code.

5. Use the trouble diagnosis scan tool to confirm that a Diagnostic Trouble Code has not been detected.

Conditions for setting the Diagnostic Trouble Codes such as engine run time or coolant temperature, etc., vary depending on the Diagnostic Trouble Codes.

**Wiring harnesses - Electrical schematic sheet 05 (55.100) Wiring harnesses - Electrical schematic sheet 06 (55.100) Wiring harnesses - Electrical schematic sheet 07 (55.100) Wiring harnesses - Electrical schematic sheet 08 (55.100)**

11. Use wrenches [ **19 mm**, **36 mm** ] to remove the hoses **(1)**, **(2)**, **(3)**, **(4)**, **(5)** and **(6)**.

- Mark the hoses and lines so that the connectors match at the time of installation.
- Use caps or plugs to cover the hoses and lines to prevent any entry of water, dust or dirt.
- Clean the hoses and lines by spraying them with a parts cleaner to prevent scratches and prevent dirt from accumulating on the connectors.

**(1)** Bucket hose [use **36 mm** wrench]


**(2)** Bucket hose [use **36 mm** wrench]

**(3)** Arm hose [use **36 mm** wrench]

**(4)** Arm hose [use **36 mm** wrench]


**(5)** 2nd option hose [use **19 mm** wrench]

**(6)** 2nd option hose [use **19 mm** wrench]




SMIL13CEX0162AB 11

12. Use a wrench [ **24 mm** ] to remove the bolt **(1)** and washer **(2)**.



SMIL13CEX1080AB 12

13. Use a slide hammer **(1)** [ **36 mm** ] to remove the pin **(2)**.



SMIL13CEX1081AB 13



© 2016 CNH Industrial Italia S.p.A.

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND CONSTRUCTION policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND CONSTRUCTION Dealer.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL