



**ENGINE**

**8045.25...**

**Service  
manual**


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




Remove thermostat support (1) and water pump (2).




Remove hydraulic pump from support, followed by transfer pump (1).




Take off the drive pulley on crankshaft. Lock flywheel in position using special retaining fixture 993600352. Lift the tab of lock plate (1) and with a suitable wrench slacken nut (2) securing the alternator/water pump drive pulley hub (3).




First remove cover (2), backout nut (3) then take down the fuel injection pump (1). The nut serves as puller for drive gear (4).



Apply fixture 99340033 (1) and pull out hub (2).




Remove the complete rocker shaft (1).



When installing piston/con rod sets into their associated cylinder check that:

- Connecting rod number is same as the number of the cylinder in which it is fitted.




- Wording "LATO PUNTERIE" (tappet side) on piston top faces the camshaft.
  - Numbers stamped on connecting rods are located on side opposite the camshaft.
  - Piston ring gaps are positioned offset and 120° apart.
- Before insertion, lubricate the pistons, rings and liner bores.


**PISTON AND CONNECTING ROD SET ASSEMBLY DATA**

1. Piston - 2. Combustion chamber - 3. Corresponding cylinder number stamping area - 4. Camshaft

**NOTE** - The con rod cap screws may be re-used as long as their thread diameter measured between 19 and 35 mm from thread start is not less than 10.5 mm.




Fitting the piston/connecting rod assemblies (3) into cylinders using special ring compressor 99360605 (1).




At end of assembly check the TDC position of pistons (4) relative to engine block top face using a magnetic base dial gauge (3).  
Piston top standout over face (1) shall be 0.46 to 0.79 mm max.


**ENGINE ASSEMBLY**




Using brackets 99361033 secure cylinder block on service revolving stand 99322205. Fit the camshaft bushings... Fix the timing gear cover (1) and fit the intermediate gear shaft (2).




Through openings (2) in gear (3) tighten screws (1) securing the camshaft-to-cylinder block retaining plate.



Oil the tappets (1) and introduce in their respective housings in cylinder block.



Install camshaft gear (3) intermediate gear (2) lubricate the journals of camshaft (1) and insert in block.



Fit main bearing halves (1) on supports in crankcase; next, using hoist and sling, raise crankshaft and lower down gently onto the main bearings.

FAULT	CAUSE	REMEDY
<b>Engine runs unevenly</b>	Injector operation defective.	Check that needle does not bind or seize in its housing in nozzle and that calibration meets specifications.
	Fuel lines clogged.	Disconnect line: clean accurately and replace any found to be excessively dented or distorted.
	Injection pump setting to engine incorrect.	Re-adjust to ensure fuel release in conformity with the specified advance angles.
	Crankshaft knocking caused by excessive play in one or more main/ connecting rod bearings or high end float.	Re-grind journals and crankpins and fit undersize bearings. Replace thrust rings with oversize rings.
	Crankshaft out of balance.	Check alignment; if necessary, correct as required and check balance.
	Flywheel screws slackened.	Replace the slack screws and tighten the others to the specified torque.
	Connecting rods misaligned.	Straighten connecting rods on the hydraulic press and check the parallelism of axes.
	Piston thumping due to slap.	Ream out the cylinder liners and fit oversize pistons.
	Piston pin noise caused by excessive clearance in skirt bosses and small end bushings.	Replace piston pin or, if necessary, also the piston.
	Con rod bushings loose.	Replace bushings as required.
Valve train noisy (tapping).	Re-adjust valve to rocker clearance and check for broken springs, excessive valve stem-to-guides and/or tappets-to-housing clearances.	



# SAFETY RULES

## GENERAL

Study the Operation and Maintenance Instruction Manual before starting, operating, maintaining, fueling, or servicing machine.

Read and heed all machine-mounted safety signs before starting, operating, maintaining, fueling or servicing machine.

Machine-mounted safety signs have been color coded yellow with black border and lettering for WARNING and red with white border and lettering for DANGER points.

Never attempt to operate the machine or its tools from any position other than seated in the operator's seat. Keep head, body, limbs, hands and feet inside operator's compartment at all times to reduce exposure to hazards outside the operator's compartment.

Do not allow unauthorized personnel to operate, service or maintain this machine.

Always check work area for dangerous features. The following are examples of dangerous work areas: slopes, overhangs, timber, demolitions, fire, high walls, dropoff, backfills, rough terrain, ditches, ridges, excavations, heavy traffic, crowded parking, crowded maintenance and closed areas. Use extreme care when in areas such as these.

An operator must know the machine's capabilities. When working on slopes or near dropoffs be alert to avoid loose or soft conditions that could cause sudden tipping or loss of control.

Do not jump on or off machine. Keep two hands and one foot, or two feet and one hand, in contact with steps, grab rails and handles at all times.

Do not use controls or hoses as handholds when climbing on or off machine. Hoses and controls are movable and do not provide a solid support. Controls also may be inadvertently moved causing accidental machine or equipment movement.

Keep operator's compartment, stepping points, grab-rails and handles clear of foreign objects, oil, grease, mud or snow accumulation to minimize the danger of slipping or stumbling. Clean mud or grease from shoes before attempting to mount or operate the machine.

Be careful of slippery conditions on stepping points, hand rails, and on the ground. Wear safety boots or shoes that have a high slip resistant sole material.

For your personal protection, do not attempt to climb on or off machine while machine is in motion.

Never leave the machine unattended with the engine running.

Always lock up machine when leaving it unattended. Return keys to authorized security. Heed all shutdown procedures of the Operation and Maintenance Instruction Manual. Always set the parking brake when leaving the machine for any reason.

Do not wear rings, wrist watches, jewelry, loose or hanging apparel, such as ties, torn clothing, scarves, unbuttoned, or unzipped jackets that can catch on moving parts. Wear proper safety equipment as authorized for the job. Examples: hard hats, safety shoes, heavy gloves, ear protectors, safety glasses or goggles, reflector vests, or respirators. Consult your employer for specific safety equipment requirements.

Do not carry loose objects in pockets that might fall unnoticed into open compartments.

Do not use machine to carry loose objects by means other than attachments for carrying such objects.

DO NOT CARRY RIDERS unless the machine is equipped for carrying people to reduce personal exposure to being thrown off.

Do not operate machinery in a condition of extreme fatigue or illness. Be especially careful towards the end of the shift.

Roll Over Protective Structures are required on wheel loaders, dozer tractors, track type loaders, graders and scrapers by local or national requirements. DO NOT operate this machine without a Roll over Protective Structure.

Do not operate a machine without a falling object protective structure (FOPS).

Do not operate this machine without a rear canopy screen when machine is equipped with rear mounted towing winch.

Seat belts are required to be provided with roll over protective structures or roll protection cabs by local or national regulations. Keep the safety belt fastened around you during operation.

Where noise exposure exceeds 90 dBA for 8 hours, wear authorized ear protective equipment per local or national requirements that apply.

Keep clutches and brakes on machine and attachments such as power control units, winches and master clutches adjusted according to Operation and Maintenance Instruction Manuals of the manufacturers at all times. DO NOT adjust machine with engine running except as specified.

Do not operate a machine with brakes out of adjustment. See the Operation and Maintenance Instruction Manual.

Move carefully when under, in or near machine or implements. Wear required protective equipment, such as hard hat, safety glasses, safety shoes, ear protectors.

To move a disabled machine, use a trailer or low boy truck if available. If towing is necessary, provide warning signals as required by local rules and regulations and follow Operation and Maintenance Instruction Manual recommendations. Load and unload on a level area that gives full support to the trailer wheels. Use ramps of adequate strength, low angle and proper height. Keep trailer bed clean of clay, oil and all materials that become slippery. Tie machine down securely to truck or trailer bed and block tracks (or wheels) as required by the carrier.






To prevent entrapment in cabs or mounted enclosures, observe and know the mechanics of alternate exit routes.

On machines equipped with suction radiator fans, be sure to periodically check all engine exhaust parts for leaks as exhaust gases are dangerous to the operator. Keep a vent open to outside air at all times when operating within a closed cab.

**STARTING FLUID IS FLAMMABLE.** Follow the recommendations as outlined in the Operation and Maintenance Instruction Manual and as marked on the containers. Store containers in cool, well-ventilated place secure from unauthorized personnel. **DO NOT PUNCTURE OR BURN CONTAINERS.** Follow the recommendations of the manufacturer for storage and disposal.

Wire rope develops steel slivers. Use authorized protective equipment such as heavy gloves, safety glasses when handling.

## CAPSCREW AND TORQUE VALUES

Capscrew Head Markings	SAE Grade Number	Capscrew Size									
		1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1
Manufacturer's marks may vary		Threads per inch									
	1 or 2	20	18	16	14	13	12	11	10	9	8
	5	28	24	24	20	20	18	18	16	14	14
	6 or 7	5	11	18	28	39	51	83	105	160	235
	8	6	13	20	30	41	55	95	115	175	250
		8	17	31	49	75	110	150	270	395	590
		10	19	35	55	85	120	170	295	435	660
		10	19	34	55	85	120	167	280	440	660
		12	21	38	61	95	130	187	300	480	730
		12	24	44	70	105	155	210	375	605	910
		14	27	49	78	120	170	240	420	675	990

XI

### Notes:

1. Always use the torque values listed above when specific torque values are not available.
2. Do not use above values in place of those specified in other sections of this manual; special attention should be observed.
3. The above is based on use of clean, dry threads.
4. Reduce torque by 10% when engine oil is used as a lubricant.
5. Reduce torque by 20% if new plated capscrews are used.
6. Capscrews threaded into aluminum may require reductions in torque of 30% of more of Grade 5 capscrews torque and must attain two capscrew diameters of thread engagement.

### CAUTION:

If replacement capscrews are of a higher grade than originally supplied, adhere to torque specifications for that replacement.

## 1.2 TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	TOOLS REQUIRED	TEST	SOLUTION		
Starter will not crank engine(Continued)	Starter brush springs weak			Check spring tension and replace if necessary		
	Starter commutator dirty or worn			Polish and/or machine commutator and under-cut mica if necessary		
	Starter armature shaft bushings worn (armature drags on fields)			Replace worn bushings and related parts		
Starter pinion will not engage with flywheel ring gear	Starter armature burned out			Replace armature		
	Grease or dirt in starter drive mechanism			Disassemble and clean the drive assembly		
<b>FUEL SYSTEM</b>	Broken or excessively worn parts			Replace broken or worn parts		
	<b>FUEL SYSTEM</b>					
	Insufficient fuel supply to fuel injection nozzles	No fuel in fuel tank		Observe dipstick reading	Fill fuel tank with specified fuel. Vent fuel system	
		Inoperative fuel transfer pump	Vacuum gauge	Install gauge between tank and pump and run engine tests	If vacuum is below specification, repair or replace transfer pump	
		Fuel injection nozzle valve binding in valve body	Nozzle tester	Pop nozzles for pressure, pattern and sound	Replace valve assembly in nozzle holder body	
		Fuel lines, filter, sediment bowl clogged	Engine diagnostic kit	Visual, run engine performance test and compare results	Clean fuel system components. Replace fuel filter	
		Fuel injection pump malfunctioning	Engine diagnostic kit	Run engine performance test and compare results	Repair or replace fuel injection pump	
		Fuel injection nozzles improperly adjusted	Nozzle tester	Pop nozzles for pressure, pattern and sound	Adjust fuel injection nozzles	
		Air in fuel system	Loose fuel line fitting or leak in fuel line on suction side of fuel transfer pump		Visual	Tighten loose fittings or replace damaged fuel lines
			Damaged gasket on fuel filter		Visual	Replace gasket


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 1.3 TESTING

T-91352

### 1.3.3.10


Turn the function switch to the "light" position.



### 1.3.3.11

The digital display will show rpm indicating "zero" and the degrees display will read "zero-point-zero".


T-91386



### 1.3.3.12

Place the "trigger" switch in the "low" position.

T-91353



### 1.3.3.13

If the battery voltage falls below 7 volts as the tractor is started, the unit may "lock-up". If this should happen, momentarily disconnect the positive battery clip. This will re-set the microprocessor in the unit.


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 1.4 REPAIR PROCEDURES

T-90690

### 1.4.1.3.9


Disconnect and tag two wires to upper and lower transmission oil cooler sensors.(Upper shown)



### 1.4.1.3.10

Disconnect and tag wire to transmission oil level sensor at dipstick.


T-90691



### 1.4.1.3.11

Remove three clamps attaching wiring harness to top of converter housing.


T-90692



### 1.4.1.3.12

Disconnect and tag wire from injection pump.

T-90693



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 1.4 REPAIR PROCEDURES

### 1.4.2 DISASSEMBLY AND ASSEMBLY

#### 1.4.2.1

Refer to **TRANSMISSION** (section 2) for repair procedures for the Transmission assembly.

#### 1.4.2.2

Refer to **8045 ENGINE** service manual for repair procedures for the Engine assembly.

### 1.4.3 INSTALLATION

#### 1.4.3.1

Follow reverse procedures as outlined in **REMOVAL**.



### WARNING

Lift and handle all heavy parts with a lifting device or proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.


Use proper tools to bring holes into alignment. "DO NOT USE FINGERS OR HANDS".

## 1.4 REPAIR PROCEDURES

T-90801

### 1.4.8.2.4


Install fuel filler tube and tighten four capscrews securely.



T-88941

### 1.4.8.2.5


Install fuel tank drain plug.



T-90695

### 1.4.8.2.6

Install two hoses to fuel pump.



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.


## 1.4.11.2 INSTALLATION

# 1.4 REPAIR PROCEDURES

T-91370

### 1.4.11.2.1


Make sure the engine positioned with the number one cylinder on its compression stroke with the timing marks properly align.



T-91380

### 1.4.11.2.2


Reposition the pump against the drive housing and replace the mounting capscrews. Lightly snug the capscrews "finger tight".



T-100051

### 1.4.11.2.3


Located on the fuel pump drive gear, near the gear teeth is a timing mark. This timing mark must be aligned with the timing mark on the other drive gear. Install the drive gear onto the shaft of the pump, being careful that you have align the timing marks.



T-91381

### 1.4.11.2.4

Tighten the drive gear puller nut to specified torque. Now you can attach the fuel pump drive housing cover and tighten the retaining capscrews.



Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 2.1 GENERAL DESCRIPTION

Fig. 2-3 illustrates engagement of 1st forward speed.

Drive is transmitted as follows:

- Flexible coupling (13), connected to the flywheel, moves torque converter impeller wheel (U) which transmits drive to turbine wheel (V) splined to the transmission input shaft (16).
- Spool (4) directs oil pressure to forward clutch (A) positively connecting shaft (15) to shaft (16).
- Spool(5) directs oil pressure to clutch(1), thus connecting shaft (16) to shaft (18) through the two first speed gears. Shaft(18) in turn drives shaft (24) and transmission output shaft (23).

The complete gear engagement pattern is as follows:

SPEED	SHAFTS ENGAGED	
FORWARD	1st	15-16-18-24-23
	2nd	15-16-17-18-24-23
	3rd	15-16-17-19-24-23
REVERSE	1st	15-14-17-16-18-24-23
	2nd	15-14-17-18-24-23
	3rd	15-14-17-19-24-23

### 2.1.4.3 Modulation Valves

Two modulation valves are provided, one for forward and one for reverse.

Detail (a), Fig.2-3, illustrates the modulating stage of 1st forward clutch engagement. Modulation valve (6) opens oil return port (20) to prevent pressure rise in the forward speed clutch(A) apply gallery. Oil gradually fills the accumulator chamber (7) through trimmer orifice (21). Accumulator piston moves to compress spring (22) resulting in a gradual increase in apply circuit pressure.

When accumulator piston reaches end of stroke, modulation valve (6) closes return port (20) and apply circuit pressure reaches its maximum value.

Oil pressure on spring (22) return plunger (7) to its initial position immediately after reverse is engaged.

### 2.1.4.4 Trans. Disengagement with Brake Applied

When the brake pedal is actuated, a piston hydraulic pump, connected in parallel to the brake pump sends oil in (3) to move spool (10).


The spool, pushed downward closes the pressure oil inlet, and discharges the oil from the gear clutch engaged before.

Detail "C" in Fig.2-3 shows the operation of spool (10) with valve block positioned in 2nd reverse gear.




## WARNING


The hydraulic portion of the brake system requires a solid column of brake fluid, free of air bubbles, if it is to function properly. If air is present in the hydraulic fluid, compression of the air bubbles may nullify effective stroking of the brake actuating piston and will make the brakes ineffective. Possible personal injury or property damage could result.



4890



- █ Olio in pressione - Main oil pressure
- ▤ Olio a pressione intermedia - Intermediate oil pressure
- █ Olio aspirazione o scarico - Intake or exhaust oil
- ▨ Olio in lubrificazione - Lubricating oil
- █ Olio in pressione in arrivo dalla pompa collegata al pedale freni - Oil from the pump connected to the brake pedal



4890 A




Fig. 2-3 Schema idraulico trasmissione

a. Distributore in fase di moderazione nell'innesto della prima marcia avanti - b. Distributore in neutro - c. Distributore in seconda marcia indietro nella fase di disinnesto cambio in frenatura - A. Marcia avanti - B. Dalla pompa collegata al pedale freni - C. Convertitore - D. Distributore - Fa. Filtro sull'aspirazione - Fm. Filtro sulla mandata - I. Marcia indietro - N. Neutro - P. Manometro pressione olio comando cambio - Pa. Pompa alimentazione convertitore-cambio - S. Scambiatore di calore - Sc. Segnalatore bassa pressione olio di lubrificazione - T. Termometro olio - U. Pompa convertitore - V. Turbina convertitore - W. Statore - 1. Prima velocità - 2. Seconda velocità - 3. Terza velocità - 4. Asta distributrice comando marce avanti e indietro - 5. Asta distributrice comando marce avanti e indietro - 6. Valvole moderatrici - 7. Accumulatori valvole moderatrici - 8. Valvola di regolazione pressione olio cambio - 9. Valvola di sicurezza convertitore - 10. Asta disinnesto cambio - 11. Valvola di sicurezza filtro (Fm) - 12. Dispositivo sicurezza avviamento - 13. Giunto - 14. Albero di rinvio retromarcia - 15. Albero ingresso cambio - 16. Albero marcia avanti - 17. Albero marcia indietro e seconda velocità - 18. Albero prima velocità - 19. Albero terza velocità - 20. Scarico valvola moderatrice - 21. Strozzatura - 22. Molla - 23. Albero uscita cambio - 24. Albero rinvio uscita cambio


Fig. 2-3 Converter-transmission hydraulic system

a. Valve block in 1st forward apply retard phase - b. Valve block in neutral - c. Valve block in 2nd reverse gear during transmission clutch disengagement with brakes applied - A. Forward speed - B. From the pump connected to the brake pedal - C. Converter - D. Valve block - Fa. Filter on suction line - Fm. Filter on delivery line - I. Reverse speed - N. Neutral - P. Transmission oil pressure gauge - Pa. Transmission-converter charging pump - S. Oil cooler - Sc. Low lube oil pressure indicator - T. Oil temperature gauge - U. Impeller wheel - V. Converter turbine wheel - W. Stator wheel - 1. 1st speed - 2. 2nd speed - 3. 3rd speed - 4. Forward and reverse spool - 5. 1st, 2nd and 3rd speed spool - 6. Retarder valves - 7. Retarder valve accumulators - 8. Transmission oil pressure regulator valve - 9. Converter safety valve - 10. Transmission cut-off speed - 11. Filter by-pass valve (Fm) - 12. Neutral start device - 13. Coupling - 14. Reverse idler shaft - 15. Transmission input shaft - 16. Forward speed shaft - 17. Reverse and 2nd speed shaft - 18. 1st speed shaft - 19. 3rd speed shaft - 20. Retarder valve oil return port - 21. Trimmer orifice - 22. Spring - 23. Transmission output shaft - 24. Transmission idler output shaft

## 2.4 REPAIR PROCEDURES


### 2.4.4.13

Remove control valve bolts and lockwashers.



### 2.4.4.14

Remove control valve assembly. Use caution not to lose detent springs and balls.




### 2.4.4.15

Support converter housing with a chain hoist.




### WARNING

Lift and handle all heavy parts with a lifting device of proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.



### 2.4.4.16

Remove all bolts securing transmission to converter housing.




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 2.4 REPAIR PROCEDURES

### 2.4.4.53

Remove forward clutch piston ring sleeve retainer ring.




### 2.4.4.54

If piston ring sleeve or forward clutch rear bearing is to be replaced, tap bearing from rear of housing.



### WARNING

It is unsafe to strike hardened steel parts with anything other than a soft iron or non-ferrous hammer. When installing or removing such parts wear safety glasses with side shields and heavy gloves, etc., to reduce the possibility of injury.



## 2.4 REPAIR PROCEDURES

### 2.4.8 FORWARD, REVERSE AND 2ND CLUTCH ASSEMBLY


#### 2.4.8.1

Install inner and outer clutch piston seal rings. Size rings as previously explained. Position piston in clutch drum.




#### 2.4.8.2

Install piston return spring spacer, Belleville spring washers and retainer ring.




#### 2.4.8.3

Install 1st steel disc.



#### 2.4.8.4

Install one friction disc.



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 2.4 REPAIR PROCEDURES

### 2.4.11.9


Position reverse idler and bearing assembly into converter housing.

NOTE: Long hub gear out.




### 2.4.11.10

Install reverse idler shaft capscrews and lockwashers. Tighten capscrews 7.86 - 8.68 daNm (58 - 64 lbs.ft).



### 2.4.11.11

Install bearing retainer plate, lock plate and idler gear capscrews. Tighten capscrews 7.86 - 8.68 daNm (58 - 64 lbs.ft). Bend lock plate tabs over capscrew heads to prevent loosening.



### 2.4.11.12

Tap forward clutch shaft rear bearing into bearing bore with bearing snap ring toward front of housing. Align roll pin in forward clutch shaft piston ring sleeve with groove in housing. Tap sleeve into position and secure with sleeve retainer ring.



### WARNING


It is unsafe to strike hardened steel parts with anything other than a soft iron or non-ferrous hammer. When installing or removing such parts wear safety glasses with side shields and heavy gloves, etc., to reduce the possibility of injury.



## 2.4 REPAIR PROCEDURES


2.4.11.48

Install forward clutch pilot bearing.



2.4.11.49

Position new gasket on front of transmission housing. A thin coat of chassis grease will hold gasket in place. Spread ears on the reverse clutch front bearing locating ring. Lock pliers open to hold snap ring open.




2.4.11.50

Position converter housing assembly on transmission case. Use caution not to disturb housing O-rings or gasket.



### WARNING

Lift and handle all heavy parts with a lifting device or proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.



2.4.11.51


Tap converter housing into place. Use caution as not to damage reverse clutch front piston ring. Note aligning stud.



### WARNING


It is unsafe to strike hardened steel parts with anything other than a soft iron or non-ferrous hammer. When installing or removing such parts wear safety glasses with side shields and heavy gloves, etc., to reduce the possibility of injury.

Use proper tools to bring holes into alignment. "DO NOT USE FINGERS OR HANDS".



## 2.4 REPAIR PROCEDURES

### 2.4.13 REFERENCE DRAWINGS



T-85457

FIG. 2-9 BASIC DESIGN

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 2.4 REPAIR PROCEDURES

### 2.4.13 REFERENCE DRAWINGS

#### *Legend for Fig. 2-14*

- |                                |  |
|--------------------------------|--|
| 1. <i>Actuator assembly</i>    | 17. <i>Switch actuating pin</i>        |
| 2. <i>O-ring</i>               | 18. <i>Neutral switch</i>              |
| 3. <i>Spring</i>               | 19. <i>Spool stop</i>                  |
| 4. <i>Retainer pin</i>         | 20. <i>Oil seal</i>                    |
| 5. <i>Piston seal</i>          | 21. <i>Forward &amp; reverse spool</i> |
| 6. <i>Piston</i>               | 22. <i>Declutch spool</i>              |
| 7. <i>Seal ring</i>            | 23. <i>Spring</i>                      |
| 8. <i>Speed selector spool</i> | 24. <i>Modulator housing</i>           |
| 9. <i>Plug</i>                 | 25. <i>Accumulator spring (inner)</i>  |
| 10. <i>Oil seal</i>            | 26. <i>Accumulator spring (outer)</i>  |
| 11. <i>Plug</i>                | 27. <i>Accumulator valve</i>           |
| 12. <i>Housing</i>             | 28. <i>O-ring</i>                      |
| 13. <i>Detent ball</i>         | 29. <i>Plug</i>                        |
| 14. <i>Spring</i>              | 30. <i>Regulator spring</i>            |
| 15. <i>Gasket</i>              | 31. <i>Regulator spool</i>             |
| 16. <i>Spool stop</i>          | 32. <i>Gasket</i>                      |

### 3.2 TROUBLESHOOTING


SYMPTOM	PROBABLE CAUSE	TOOLS REQUIRED	TEST	SOLUTION
Noise	Incorrect lubricant or level too low Improperly adjusted wheel bearings Damage to planetary gears Pinion to ring gear backlash is too low Poor pattern between pinion and ring gear	Operator's Manual    Micrometer	Compare oil specifications Examination Examination Check backlash Examination	Check level, fill with correct lubricant Adjust bearings Replace gears Adjust backlash to specifications Correct pattern
Lubricant Loss	Lubricant leaks at planetary cover Lubrication level too high Excessive foaming of lubricant Breather plugged Damaged seals Worn yoke		Examination If oil blows from breather, check oil level Examination Examination Examination If oil leaks from yoke may be seals or yoke	Tighten capscrews or reseal cover and capscrews Fill differential to proper level Drain and fill with correct lubricant Clean breather Replace Replace seal or yoke
Overheating	Incorrect lubricant or level incorrect Excessive gear wear Pinion gear assembly adjusted too tight in the differential		Examination Examination Examination	Check level, fill with correct lubricant Replace gears Correct to proper adjustment

## 3.4 REPAIR PROCEDURES

T-89318

### 3.4.2.13


Remove axle thrust button.



### 3.4.2.14

Disconnect hydraulic brake line.


T-89217



### 3.4.2.15

Remove brake caliper capscrews. Note location of each capscrew as they are different .


T-89193



### 3.4.2.16

Remove brake caliper.

T-89194




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 3.4 REPAIR PROCEDURES

T-91110

### 3.4.2.53


Tap the end of the pinion to loosen it.



### 3.4.2.54

Remove the pinion, inner bearing, spacer and shims.


T-91111



### 3.4.2.55

Tap out the outer bearing and seal.


T-91112



### 3.4.2.56

Remove the outer bearing, race and seal.

T-91113



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 3.4 REPAIR PROCEDURES


T-91135

**3.4.3.25**  
Install the seal.




**3.4.3.26**  
Install the flange, washer, and nut. Tighten the nut to specified torque.

T-91128



**3.4.3.27**  
Stake the nut in two places.


T-91136



### ASSEMBLE DIFFERENTIAL CASE TO CARRIER

**3.4.3.28**  
Place the differential on the carrier and place bearing races on bearings.

T-91137




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 3.4 REPAIR PROCEDURES

T-89194

### 3.4.3.64


Install brake caliper assembly.



### 3.4.3.65

Coat capscrews with thread lock P/N 75000776 (Loctite 262). Shoulder capscrew goes into the larger hole (top on front axle, bottom on rear axle).


T-89193



### 3.4.3.66

Tighten capscrews to specified torque.

T-89192



### 3.4.3.67

Install brake line to axle assembly.

T-89217




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

### 3.6 SPECIFICATIONS

#### 3.6.3 AXLE MOUNTING

ITEM	STEP #	NAME	TORQUE	
			daNm	FT-LBS
A	3.4.4.5	U-joint capscrews	5.3-5.9	39-43
B	3.4.4.3	Rear axle support capscrews	60	445
		Front axle attaching capscrews	4.25	315
C	3.4.3.79	Axle support cover capscrews	22	145
		Midship bearing support capscrews	16.7-18.6	123-137

ITEM	STEP #	NAME	DIMENSIONS	
			mm	in.
		<b>End play</b>		
D	3.4.3.77	Oscillating axle end play	0.3 - 0.7	0.012 - 0.027
		Shim thickness available	0.5, 1.0	0.020, 0.039
E		Support I. D.	175.0-175.04	6.890 - 6.891
		Bushing O. D.	175.108 - 175.128	6.8940-6.8948
		Bushing I. D. (installed)	160.0 - 160.08	6.299 - 6.302
		Pivot hub O. D.	159.82 - 159.915	6.293 - 6.296
F		Axle housing bore	105.0 - 105.05	4.134 - 4.136
		Pivot hub O. D.	105.013 - 105.048	4.1343 - 4.1357




T-85383

## 4.4 REPAIR PROCEDURES

### 4.4.1.5

Disconnect tube attached to bottom of brake pump.


T-91306



### 4.4.1.6

Remove the four capscrews holding the pump to the engine.


T-89033



### 4.4.1.7

When installing the brake pump onto the engine, be sure that the pump's small outlet is on top. Tighten the attaching capscrews to specified torque. Install new O-rings on the pump inlet and outlet lines.

T-89033



### 4.4.1.8

Fill the implement tank with oil as specified on the lubrication chart decal.

T-90469




Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 4.4 REPAIR PROCEDURES

### 4.4.2.2.21

Remove two (2) alignment dowel sleeves from pressure control body.


T-90998



### 4.4.2.2.22

Remove pump inlet fitting.


T-90987



### 4.4.2.2.23

Remove inlet check valve.


T-90985



### 4.4.2.2.24

Remove low brake fluid pressure switch.

T-90984



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 4.4 REPAIR PROCEDURES

### 4.4.3.3.5


Thread spring retaining cap into cylinder until it seats.  
Place cylinder in a vise and tighten retaining cap.

T-90953



### WARNING


Brake valves have a heavy spring compressed inside them. Always follow recommended procedures when assembling or disassembling these valves.



### 4.4.3.3.6

Install rear axle brake fluid supply tip check valve and tighten.


T-90954



### 4.4.3.3.7

Install front axle brake fluid supply tip check valve and tighten.

T-90958



## 4.4 REPAIR PROCEDURES

T-89168

### 4.4.5.3


With the pedal depressed loosen the brake bleeder fitting located on the brake caliper. (Wheel and tire removed for picture clarity.) Tighten the fitting before the assistant lifts his foot from the pedal. Repeat the steps until a solid column of fluid flows from the fitting.



### WARNING

The hydraulic portion of the brake system requires a solid column of brake fluid, free of air bubbles, if it is to function properly. If air is present in the hydraulic fluid, compression of the air bubbles may nullify effective stroking of the brake actuating piston and will make the brakes ineffective. Possible personal injury or property damage could result.


Brake fluid reservoirs must be filled with fluid to the proper level. Fill with specified fluid.




### 4.4.5.6

Be sure to keep the master cylinder reservoirs full of fluid during the bleeding process. Repeat the procedure for all other brakes.

T-90498



Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.



## 5.2 TROUBLESHOOTING

### 5.2.2 IMPLEMENT SYSTEM

SYMPTOM	PROBABLE CAUSE	TOOLS REQUIRED	TEST	SOLUTION	
Lack of Hydraulic Power	Low hydraulic oil level		Observe oil level gauge with bucket flat on ground	If low, fill to proper level	
	Clogged suction screen			Clean suction screen	
	Foaming oil caused by air in suction line		Shut down machine and check the oil tank for foam in oil	Tighten all fittings or replace faulty hoses	
	Foaming oil caused by improper oil	Operator manual	Compare specifications to those of oil	Fill implement oil tank with specified fluid	
	Leaking piston packing			Replace packing	
	Main relief valve set too low	Pressure gauge	See Sec 5.3	Adjust pressure	
	Dirt holding relief valve open	Pressure gauge	See Sec 5.3	Loosen the adjusting screw two turns and operate the machine, then reset pressure setting	
	Hydraulic Pump defective	Flow meter	Conduct flow test of pump	If pump test low, rebuild or replace pump	
	System Oil Overheating	Hydraulic level too low or overfilled		Observe the oil level with the bucket flat upon the ground	If incorrect, add or drain oil
		Restricted suction line	Flow meter	Pump flow test See Sec 5.3	Clean line
		Improper oil	Operator manual	Compare specifications to those of oil	Fill implement oil tank with specified fluid
Main relief valve open		Pressure gauge	Check main relief opening pressure	Clean the valve and reset pressure	

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 5.3 TESTING

### 5.3.2.4.3

Warm the machine's implement oil system to normal working conditions.



## WARNING

Observe all start up and shut down procedures and **'WARNINGS'** listed in the operation and maintenance instruction manual.

Do not run the engine or this machine in closed areas without proper ventilation to remove deadly exhaust gases.

The machine and it's attachments are to be operated only by qualified operator seated in the operator's seat.

Before starting machine, check, adjust and lock the operator's seat for maximum comfort and control of the machine.

Replace seat belts every two years on open canopy units and every three years on machinery with cabs or at change of ownership.

### 5.3.2.4.4


Operate the machine at low idle. Place the implement in the tip back position. Allow the bucket to remain in that position. Raise the boom. Dump the bucket quickly and note the pressure on the gauge.



T-90425

### 5.3.2.4.5

Compare the results of the test with the specifications for the boom lift relief valve. If the test pressure does not fall within specifications, adjust the boom lift circuit relief valve opening pressure. The circuit relief valve must be removed from the valve body and adjusted. Turning the screw in raises pressure while turning the screw out reduces pressure.



T-90913

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 5.4 REPAIR PROCEDURES


5.4.2.2.15  
Remove center spacer.

T-91055




5.4.2.2.16  
Remove gerotor meter housing.

T-91054



5.4.2.2.17  
Remove gerotor inner gear.

T-91053



5.4.2.2.18  
Remove the drive.

T-91052



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

### 5.4.3 STEERING CYLINDER

## 5.4 REPAIR PROCEDURES


T-88929

#### 5.4.3.1

Drain Implement oil tank

### DANGER


Fluid under pressure - turn cap or cover slowly to relieve pressure before removing.



#### 5.4.3.2

Remove access cover from the loader frame.


T-89797



#### 5.4.3.3

Remove the capscrews and lock plate holding the steering cylinders front and rear pins in position.

T-89870



#### 5.4.3.4

Remove the front and rear pin by driving the pin from the boss and rod.

T-89873



### WARNING

It is unsafe to strike hardened steel parts with anything other than a soft iron or non-ferrous hammer. When installing or removing such parts wear safety glasses with side shields and heavy gloves, etc., to reduce the possibility of injury.

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 5.4 REPAIR PROCEDURES

### 5.4.5.2.5

The bucket spool detent's parts will appear in this order: end cap, spacer, guide, solenoid, capscrews and washers, housings with detent balls and spool.


T-90890



### 5.4.5.2.6

The boom spool detent is comprised of basically the same parts but in a different order. The order is: end cap, guide, capscrews and washers, solenoid, adapter, spring, detent balls, housing and spool.

T-90891



### 5.4.5.2.7

Mark each of the valve cartridges and their position on the valve stack. Remove the cartridges.


T-90912



### 5.4.5.2.8

Remove the spool seal retainers from the eye end of the spools.

T-90911



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

Turn on the master switch. Test the system for leaks and proper operation.

**⚠ WARNING**


Do not run the engine of this machine in closed areas without proper ventilation to remove deadly exhaust gasses.

Observe all start up and shut down procedures and "WARNINGS" listed in the operation and maintenance instruction manual.

This machine and its attachments are to be operated only by qualified operator seated in the operator's seat.

Before starting machine, check, adjust and lock the operator's seat for maximum comfort and control of the machine.

Replace seat belts every two years on open canopy units and every three years on machinery with cabs or at change of ownership.




## 5.5 TOOLS

Service tools required to perform the repair operations in this manual are listed below. Order tools from your **FIATALLIS®** dealer unless otherwise noted.

All other tools are considered to standard tools which can be ordered from local tool suppliers.

<u>Topic No.</u>	<u>Tool Description</u>	<u>Part No.</u>
5.3	Flow meter 200 gpm	75300836
5.3	Multi-gauge 150-600-5000 psi	75300110
5.4.6.4	Wrench	75300478
5.4.7.4	Wrench	75300478
5.4.8.2	Wrench	75300478

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.




## 6.1 HITCH

T-89914

### 6.1.2.21


Remove the capscrews holding the bushing retainer to the hitch.



### 6.1.2.22

Pry the bushing retainer from the hitch.


T-89915



### 6.1.2.23

Place the retainer on a clean work surface and remove the two capscrews holding the seal retainer to the bushing retainer.


T-89916



### 6.1.2.24

Remove the seal from the retainer.

T-89918



## WARNING

It is unsafe to strike hardened steel parts with anything other than a soft iron or non-ferrous hammer. When installing or removing such parts wear safety glasses with side shields and heavy gloves, etc., to reduce the possibility of injury.


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**6.2.1.5**

**Remove four capscrews, washers and nut attaching hood to frame.**

**6.2 HOOD**


T-90312



**6.2.1.6**

**Remove capscrew and locknut attaching spring supports to top of radiator and remove hood.**

T-91320






## CAB GROUP

- A. Connector to Flasher Unit  
Optional 79083348  
Varianti or standard
- B. Connector to Clutch Cut-off Relay
- C. Connector to Front Wiper Motor
- D. Connector to Timer Motor
- E. Connector to Buzzer Unit
- F. Connector to Electronic Data Monitor (Connection "B")
- G. Connector to Electronic Data Monitor (Connection "A")
- H. Connectors to Turn Signal Switch  
Optional 79083348  
Varianti or standard
- I. Connectors to Light Switch
- J. Connector to Front Wiper Switch
- K. Connector to Rear Wiper Switch
- L. Connector to Emergency Flasher Switch  
Optional 79083348  
Varianti or standard
- M. Connectors to Rear Flood Light Switch
- N. Connector to Key Switch
- O. Connectors to Cold Weather Starting Aid Switch  
Optional 79082673  
Varianti
- P. Connector to Key Switch
- Q. Connector to Clutch Cut-off Switch
- R. Connectors to Cab Flood Light Switch
- S. Connectors to Rotating Beacon Switch  
Optional 79085677  
Varianti
- T. Connector to right hand side of Cab (Dome Lights, Cab Flood Lights & Beacon)
- U. Connectors to Cigarette Lighter
- V. Connector to Hour Meter
- W. Connector to Tachometer  
Optional 79083655  
Varianti
- X. Connector to Indicator Light Panel
- Y. Connector to Indicator Light Panel
- Z. Connector to Rear Wiper Motor
  
- AA. Connector to Air Conditioner Switch  
Optional  
Varianti
- BB. Connector to Cab Heater Blower Switch  
Optional 79084143  
Varianti
- CC. Connector to Boom Kick-out Relay
- DD. Connector to Bucket Kick-out Relay  
Optional 79081216  
Varianti
- EE. Connector to Fuse BLock
- FF. Connectors to Starter Relay Switch
- GG. Cab Flood Lights
- HH. Cab Dome Light

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**CAB GROUP  
FRONT WIPER MOTOR 'C'**




T-85978

**ITEM # WIRE #**

- OC 000 To Front Wiper Switch "J", Wiper Switch "J" to Rear Wiper Switch "K"
- 10 822 To Front Wiper Switch "J"
- 11 873 To Front Wiper Switch "J"
- 12 881 To Front Wiper Switch "J"
- 13 882 To Front Wiper Switch "J"

**NOTE:** Connector will index to Wiper Motor


**LOCATION:** Below Front Windshield



T-89666

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

**CAB GROUP  
KEY SWITCH "N" & "P"**



T-85997

**ITEM # WIRE #**


39	390	To Light Switch "I" (Post 58/57)
42	235	To Light Switch "I" (Post 15)
52	887	To Fuse Block "EE"
53	887	To Fuse Block "EE"
54	903	To Cab to Rear Frame Group (Connector "B", Item #15, Page 86)
56a	860	To Cold Weather Starting Aid Switch "O"
57	802	To Starter Relay Switch "GG"

NOTE: Connector "N" will index to Switch

LOCATION: Right hand Instrument Panel

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**CAB GROUP  
INDICATOR LIGHT PANEL "Y"**



- A. Turn Signals
- B. Clutch Cut-off
- C. Emergency Flashers
- D. Parking Brake


**ITEM # WIRE#**

- OC 000 To Indicator Light Panel "X" and Cab Ground
- 2a 112 To Emergency Flasher Switch "L"
- 3 114 To Flasher Unit "A"
- 60 660 To Clutch Cut-off Switch "Q"
- 61 691 To Clutch Cut-off Switch "Q"
- 76 662 To Cab to Front Frame Group (Connector "B", Item #13, Page 54)

**LOCATION:** Right hand Instrument Panel

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

**CAB GROUP  
EMERGENCY STEERING PUMP PRESSURE SWITCH RELAY "B"**



**ITEM # WIRE #**

1. 000 To Emergency Steering Buzzer Relay "A" and Emergency Steering Flow Valve Pressure Switch Relay "C".
2. 835 To Emergency Steering Buzzer Relay "A" and Front Frame Connector "F" (Steering Pump Pressure Switch).
4. 893 To Emergency Steering Buzzer Relay "A" and Emergency Steering Flow Valve Pressure Switch Relay "C".
5. 604 To Emergency Steering Flow Valve Pressure Switch Relay "C" and Indicator Light Panel "E".


**NOTE:** Connector will index to Relay

**LOCATION:** Left hand side of Seat in bottom of Console Panel, See Page 8

Optional  
Variants

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**CAB GROUP  
COLD WEATHER STARTING AID GROUP**



T-100012

- A. Boot
- B. Harness
- C. Cold Weather Starting Aid

**ITEM # WIRE #**





- 0. 000 To Ground in Cab
- 56. 860 To Cab wire 860 (Cab Group, Item #56)

**NOTE:** Connectors will index.

**LOCATION:** Left hand side of Hydraulic Tank Assembly.

Optional 79082673  
Varianti

**CAB TO FRONT FRAME GROUP  
ELECTRONIC DATA MONITOR 'I'**



T-85993


ITEM # WIRE #

17 613 To Connector "B"

LOCATION: Left hand Instrument Panel

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**FRONT FRAME GROUP  
CONNECTOR 'H' TO HORN 'X'**




T-100006

ITEM # WIRE #

- 5. 000 To ground in Cab
- 27. 119 To Connector "D"


Location: Front Frame



T-90637

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**FRONT FRAME GROUP  
BUCKET KICK-OUT PICKUP SWITCH 'U'**



T-100010


**ITEM # WIRE #**

- 1. 000 To ground in Cab
- 6. 995 To Connector "A" (positive)
- 7. 981 To Connector "A" (output)

**NOTE:** Post "A" must index to Post "A"  
Post "B" must index to Post "B"

**Maximum operating distance:** 5mm (0.20in)


**LOCATION:** Right hand Bucket Cylinder  
Optional 79081216  
Varianti or standard



T-90639

**Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.**

**CAB TO REAR FRAME GROUP  
TIMER RELAY "I"**



T-85992

ITEM # WIRE #

9 589 To Connector "A"

NOTE: Connector will index to Timer Relay

LOCATION: Left hand side of Seat in bottom of Console Panel. See Page 8.


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## REAR FRAME GROUP

### ITEM # WIRE #

1. 777 Starter Relay Switch in Cab to Starter "I"
2. 777 Alternator "Y" to Starter "I"
3. 000 Cab ground to Clutch Cut-off Valve "J" & Rear Flood Light Connectors "E"
4. 000 Rear Frame ground to Neutral Start Switch "H" & Transmission Oil Pressure Switch "K"
5. 000 Rear Frame ground to Water Level Sending Unit "N" (Post B) and Air Filter Restriction Indicator Switch "O" and Brake Fluid Level Sending Units "P" & "Q"
6. 000 Rear Frame ground to Engine Oil Pressure Switch "W" (Post B) and Brake Lights "AA" & "BB"
7. 000 Lamp, Number Plate "Z" to ground on Rear Frame
8. 693 Connector "A" to Transmission Lube, Oil Pressure Switch "S"
9. 589 Connector "A" to Transmission Oil level Sending Unit "U"
10. 503 Connector "A" to Engine Oil Pressure Switch "W" (Post A)
11. 637 Connector "A" to Alternator "Y"
12. 580 Connector "A" to Hydraulic Tank Oil filter Restriction Indicator Switch "T"
13. 559 Connector "A" to Transmission Oil Temperature Sending Unit "R"
14. 569 Connector "A" to Engine Oil Level Sending Unit "X"
15. 903 Connector "B" to Fuel Shut-off Solenoid "M"
16. 907 Connector "B" to Neutral Start Switch "H"
17. 888 Connector "B" to Starter "I"
18. 224 Connector "B" to Connector "E" for Rear Flood Lights "CC"
19. 175 Connector "B" to Rear Brake Lights "AA" & "BB"
20. 975 Connector "B" to Clutch Cut-off Valve "J"
21. 976 Connector "B" --- (pig tail) ----
22. 557 Connector "C" to Fuel Level Sending Unit "V"
23. 528 Connector "C" to Water Temperature Sending Unit "L"
24. 663 Connector "C" to Air filter Restriction Indicator Switch "O"
25. 661 Connector "C" to Brake Fluid Level Sending Unit "P" & "Q"
26. 555 Connector "C" to Fuel Level Sending Unit
27. 520 Connector "C" to Water Level Send Unit "N"
28. 581 Connector "C" to Transmission Oil Pressure Switch "K"
29. 109 Connector "D" to Connector "F" for Rear Brake, Tail & Turn Signal Light "EE"
30. 103 Connector "D" to Connector "G" for Rear Brake, Tail & Turn Signal Light "DD"
31. 330 Connector "D" to Connector "F" for Rear Brake, Tail & Turn Signal Light "EE"
32. 337 Connector "D" to Lamp, Number Plate
33. 339 Connector "D" to Connector "G" for Rear Brake, Tail & Turn Signal Light "DD"
34. 175 Connector "D" to Connectors "F" & "G" for Rear Brake, Tail & Turn Signal Lights "DD" & "EE"


**REAR FRAME GROUP  
TRANSMISSION OIL TEMPERATURE SENDING UNIT "R"**



ITEM # WIRE #

13 559 To Connector "A"

LOCATION: Right hand side of the Transmission Housing




T-100014

T-90636

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

**REAR FRAME GROUP  
REAR BRAKE LIGHT GROUP ("AA" & "BB")**



T-100018

**STANDARD EQUIPMENT**

**ITEM # WIRE #**

- 6 000 To Rear Frame ground
- 19 175 To Connector "B"

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.


# ELECTRONIC DATA MONITOR

T-91435

## TESTING

### 7.2.1

When identifying problems within a particular circuit, it is best to know how the circuit operates. The Electronic Data Monitor has two cables that come out the back. The cable's wires connect to the power source as well as level and pressure switches. It is best to identify cable contact positions and where the cable leads. Knowing where the wires connect will aid if the wires are suspected of having an open or short circuit.




### 7.2.2

Cable "A" leads go from the monitor and to the following locations:

#### Position Wire#

- |   |     |   |
|---|-----|---|
| 1 | 581 | To Transmission Shift Pressure Switch       |
| 2 | 589 | To Transmission Oil Level Sending Unit      |
| 3 | 693 | To Transmission Lubrication Pressure Switch |
| 4 | 569 | To Engine Oil Level Sending Unit            |
| 5 | 520 | To Coolant Level Sending Unit               |
| 6 | 888 | To Starter Relay Switch                     |
| 7 | 555 | To Fuel Level Sending Unit                  |
| 8 | 557 | To Fuel Level Sending Unit                  |




T-85993

### 7.2.3

Cable "B" leads go from the monitor and to the following locations:

#### Position Wire#

- |    |     |  |
|----|-----|--|
| 1  | 887 | To Fuse Block                                |
| 2  | 000 | To Cab Ground                                |
| 3  | 104 | To Buzzer Unit                               |
| 4  | 559 | To Transmission Oil Temperature Sending Unit |
| 5  | 661 | To Brake Fluid Level Sending Unit            |
| 6  | 105 | To Buzzer Unit                               |
| 7  | 528 | To Water Temperature Sending Unit            |
| 8  | 637 | To Alternator                                |
| 9  | 503 | To Engine Oil Pressure Switch                |
| 10 | 580 | To Implement Oil Filter Restriction Switch   |
| 11 | 871 | To Fuse Block                                |
| 12 | 663 | To Air Filter Restriction Switch             |
| 13 | 613 | To Low Brake System Pressure Switch          |
| 14 |     | Not Used                                     |
| 15 |     | Not Used                                     |
| 16 |     | Not Used                                     |




T-85993

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

# ELECTRONIC DATA MONITOR

## IMPLEMENT FILTER RESTRICTION LIGHT STAYS ON AFTER INSTALLING NEW FILTER ELEMENTS



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 8.2 TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	TOOLS REQUIRED	TEST	SOLUTION
<p>No heat (Heater)</p>	<ol style="list-style-type: none"> <li>1. Heater control valve malfunctioning</li> <li>2. Blower motor malfunctioning</li> <li>3. Heater core clogged or leaking</li> <li>4. Heater hoses or shut-off valves clogged</li> <li>5. No hot water from engine</li> </ol>			<ol style="list-style-type: none"> <li>1a. Check control linkage</li> <li>1b. Repair or replace valve</li> <li>2a. Check fuse</li> <li>2b. Repair or replace blower motor</li> <li>3. Repair or replace heater core</li> <li>4a. Turn shut-off valves "OPEN"</li> <li>4b. Disconnect hoses from heater core and flush hoses to remove restriction</li> <li>5. Correct engine problem</li> </ol>


Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 8.3 REPAIR PROCEDURES

T-90560

### 8.3.1.33


Shut off valves supplying fluid to heater.



### 8.3.1.34

Disconnect two heater hoses located at right rear of cab.

T-90559



### 8.3.1.35


Position lifting device of proper capacity above cab and attach a strap through the cab door and out the side window. (May want to install 4 lifting eyes to the four holes at top of cab.)

T-89619



## WARNING


Lift and handle all heavy parts with a lifting device or proper capacity. Be sure parts are supported by proper slings and hooks. Use lifting eyes if provided. Watch out for people in the vicinity.



### 8.3.1.36

Disconnect and remove the four mounting capscrews and lock nuts attaching the cab to the frame.

T-89616



Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

### 8.3.2.33

Turn on master electrical switch.



## WARNING


Study the operation and maintenance instruction manual through before starting, operating, main- taining, fueling or servicing this machine.

This machine and its attachments are to be operated only by a qualified operator seated in the operator's seat.

Machine-mounted safety signs have been color coded yellow with black border and lettering for warning, and red with white border and lettering for danger points.

This symbol is your safety alert sign. It means "ATTENTION!" "BECOME ALERT!" "YOUR SAFETY IS INVOLVED".

Read and heed all safety instructions carrying the signal words "WARNING" and "DANGER".



## 8.3 REPAIR PROCEDURES

T-88026

### 8.3.3.6 HEATER & BLOWER FAN

#### 8.3.3.6.1 Heater Removal

##### 8.3.3.6.1.1

Remove floor mat.



##### 8.3.3.6.1.2

Loosen setscrew on hydraulic controls lock lever and remove lever.


T-90569



##### 8.3.3.6.1.3

Unscrew knobs on hydraulic control levers.

T-90570



##### 8.3.3.6.1.4

Remove right front cab corner panel.

T-88029



Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 8.3 REPAIR PROCEDURES


T-88029

8.3.3.6.5.10  
Install right front cab corner panel.




8.3.3.6.5.11  
Install boot and knobs to hydraulic control levers.

T-90570



8.3.3.6.5.12  
Install hydraulic controls lock lever and tighten set-screw.

T-90569



8.3.3.6.5.13  
Install floor mat.

T-88026




Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 8.3 REPAIR PROCEDURES

### 8.3.3 CAB DISASSEMBLY & ASSEMBLY

#### 8.3.3.10 REFERENCE DRAWINGS



T-85641

FIG. 8-1 CAB ASSEMBLY

1. CAB ASSEMBLY  
2. NUT  
3. BUSHING  
4. SPACER

5. WASHER  
6. WASHER  
7. CAPSCREW

Study SAFETY RULES in the front of this manual thoroughly for the protection of machine and safety of personnel.

## 8.4 TOOL SECTION

Service tools required to perform the repair operations in this manual are listed below. Order tools from your **FIATALLIS®** dealer unless otherwise noted.

All other tools are considered to be standard tools which can be ordered from local tool suppliers.

<b><u>DESCRIPTION</u></b>	<b><u>PART NO.</u></b>
Glass and seal removal and installation tool	_____
Wire cutters	_____
Torque wrench	<u>75300810</u>
Putty knife	_____
Silicone sealant	<u>70935406</u>

Study **SAFETY RULES** in the front of this manual thoroughly for the protection of machine and safety of personnel.

### III MACHINE LUBRICANT/VISCOSITY SPECIFICATION TABLE

Find lubricant to use and viscosity as follows: Example -- 2 (4)

1st Number, Lubricant Reference Code: Refer to page 7

2nd Number, (in parenthesis), Viscosity Chart Code: Refer to page 8

\* Preferred

CRAWLER TRACTORS	Trans & Conv	St. Clutch Bevel Gear	Track Rollers	Carrier Rollers & Idlers	Final Drive Sides	Impl Hyd	Track Release Housing
FD5	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FD7	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FD9	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
10C	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FD14E	*1 (-) 5 (4)	2 (4)	2 (4)	2 (4)	11 (12)	*2 (4) 4 (4) 7 (4)	-
FD30B	*4 (4) 5 (4) 6 (4)	3 (9) 4 (9) 2 (9)	2 (10)	2 (9)	11 (12) *12 (-)	2 (7) 4 (7) 7 (7)	8 (11)
FD40B	*4 (4) 5 (4) 6 (4)	3 (9) 4 (9) 2 (9)	2 (10)	2 (9)	11 (12) *12 (-)	2 (7) 4 (7) 7 (7)	8 (11)
FD50	*4 (4) 5 (4) 6 (4)	3 (9) 4 (9) 2 (9)	2 (10)	2 (9)	11 (12) *12 (-)	2 (7) 4 (7) 7 (7)	8 (11)
FL5B	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FL7B	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FL10E	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-
FL14E	*1 (-) 5 (4)	6 (4)	6 (10)	6 (10)	12 (-)	6 (5)	-
FL20	*1 (-) 5 (4)	2 (4)	2 (10)	2 (10)	11 (12) *12 (-)	*2 (4) 4 (4) 7 (4)	-

## FD9 CRAWLER DOZER

S/N 030114, 030202 - UP

### ENGINE

	<b>IVECO 8065.25.095</b>		
Bore & stroke	194 x 115 mm		
Displacement	5.9L		
Firing order	1-5-3-6-2-4		
Low idle, (high idle)	rpm	800-850 (2200-2300)	
Converter stall	rpm	1960-2030	
Hydraulic stall	rpm	2140-2240	
Full stall (converter & implement)	rpm	1640-1740	
Valve clearance, Cold Intake (Exhaust)	inch	0.010 (0.014)	mm 0.25 (0.35)
Oil pressure, Min. @low idle (high idle)	PSI	10 (43)	bar 0.7 (2.96)
Cylinder compression, minimum @ cranking speed	PSI	304	bar 21
Nozzle pressure	PSI	3335-3451	bar 230-238
Intake manifold pressure @ converter stall	In. Hg.	27	cm Hg 68.6
Exhaust manifold temp., Max. @ converter stall	°F	1130	°C 610
Air Cleaner restriction, Max. @ converter stall	In. H <sub>2</sub> O	25	cm. H <sub>2</sub> O 63.5

### TRANSMISSION/TORQUE CONVERTER

Main pressure @ high idle, neutral	PSI	206-213	bar 14.2-14.6
Lube pressure high idle, neutral	PSI	28	bar 1.9
Converter relief @ high idle, neutral	PSI	95-118	bar 6.5-8.1
Trimmer valve poppet pressure	PSI	18-23	bar 1.25-1.55
Pump flow @2100 rpm	GPM	17.7	L/min 67
Scavenging pump flow @ 2100 rpm	GPM	18.3	L/min 71

### STEERING/BRAKES

Steering pressure @ high idle	PSI	333-340	bar 23-24
Brake pressure @ high idle	PSI	391-449	bar 27-31
Pump flow @ high idle @ steering pressure	GPM	9.5 (8 min.)	L/min 36 (30)

### IMPLEMENT HYDRAULICS

Main pressure @ high idle	PSI	2140	bar 148
Pump flow @ high idle @ 1500 psi	GPM	30 (25 min.)	L/min 114 (94)

### CAPACITIES, refill (approximate)

	GALS	TYPE	LITER
Engine cooling system	6	COOLANT	23
Engine crankcase	3.7	EO	14
Transmission/converter	6.5	TF	24.5
Steering clutch, bevel gear	4.2	EO	15.5
Final drives (each)	3.5	MGO	13
Implement hydraulic system	13	HO	49
Fuel tank	52	Diesel	198
Track idler & rollers	2	EO	7.5

# FD40B CRAWLER DOZER

S/N 89A 35110 - UP

## ENGINE

	Cummins KT19C			
Bore & stroke	159 X 159 mm			
Displacement	19 L			
Firing order	1-5-3-6-2-4			
Low idle, (high idle)	rpm	750-800 (2200-2400)		
Converter stall	rpm	1720-1780		
Hydraulic stall	rpm	N/A		
Full stall (converter & implement)	rpm	N/A		
Valve clearance, Cold intake (Exhaust)	inch	*	mm	*
Oil pressure, Min. @low idle (high idle)	PSI	*	bar	*
Cylinder compression, minimum @ cranking speed	PSI	*	bar	*
Nozzle pressure	PSI	*	bar	*
Intake manifold pressure @ converter stall	In. Hg.	*	mm Hg.	*
Exhaust manifold temp., Max. @ converter stall	°F	*	°C	*
Air Cleaner restriction, Max. @ converter stall	In. H <sub>2</sub> O	25	cm H <sub>2</sub> O	63.5

\*Contact Cummins distributor

## TRANSMISSION/TORQUE CONVERTER

Main pressure @ high idle neutral	PSI	175-229	bar	12-15.1
Clutch apply pressure @ high idle	PSI	175-200	bar	12-13.8
Lube pressure @ high idle	PSI	70-80	bar	4.8-5.5
Converter out @ high idle, neutral	PSI		bar	
Converter 3rd forward	PSI	100-110	bar	6.8-7.5
Inhibit pump neutral	PSI	80-120	bar	5.5-8.3
Inhibit pump pressure differential	PSI	80-120	bar	5.5-8.3
Pump flow @ 1450 rpm, neutral	GPM	47 (43 min)	L/min	178 (168)
Lube flow, high idle	GPM	38 (36 min)	L/min	143 (136)
Clutch flow all ranges	GPM	4 (3min)	L/min	15 (11)
Converter in @ high idle, neutral	GPM	37 (31 min)	L/min	140 (119)
Converter out @ high idle, neutral	GPM	35 (29 min)	L/min	132 (112)

## STEERING/BRAKES

Pump flow @ high idle @ steering pressure (section)	GPM	11.5 (9.5 min)	L/min	43 (36)
Brake pressure @ low idle, neutral	PSI	apply 10 release 55	bar	0.7—3.8
Steering pressure @ low idle PTO & no brakes (St. levers 1/2 travel (trans signal press 180 psi)	PSI	480	bar	33

## IMPLEMENT HYDRAULICS

Main relief @ high idle, ripper (tilt)	PSI	2000 (2000)	bar	138 (138)
Power assist	PSI	240-285	bar	16.5-19.6
Circuit relief ripper (tilt)	PSI	2600 (2600)	bar	179 (179)
Circuit relief ripper pitch	PSI	2850-3150	bar	197-217
Power assist pump @ high idle & 0 pressure	GPM	14.4 (12 min)	L/min	54 (45)
Main pump @ high idle & 1500 pressure				
1st section	GPM	77 (65 min)	L/min	291 (246)
2nd section	GPM	34 (12 min)	L/min	128 (109)

## CAPACITIES

	GAL	TYPE	LITER
Engine cooling system	28	Coolant	106
Engine crankcase	15	EO	57
Transmission/converter	16	TF	61
Steering clutch/bevel gear	50.5	TF	191
Final drives, each	15	MGO	56
Implement hydraulic system	30	TF	113
Implement hydraulic system with ripper	39	TF	148
Fuel tank	235	DIESEL	890

# FR7B WHEEL LOADER

S/N 630101 - UP

<b>ENGINE</b>		IVECO 8045.05.395	
Bore & stroke		104 X 115 mm	
Displacement		3.9 L	
Firing order		1-3-4-2	
Low idle, (high idle)	rpm	820-870 (2690-2740)	
Converter stall	rpm	2470-2570	
Hydraulic stall	rpm	2500-2600	
Full stall (converter & implement)	rpm	1850-2000	
Valve clearance, Cold Intake (Exhaust)	inch	0.010 (0.014)	mm 0.25 (0.35)
Oil pressure, Min. @low idle (high idle)	PSI	10 (43)	bar 0.7 (2.96)
Cylinder compression, minimum @ cranking speed	PSI	304	bar 21
Nozzle pressure	PSI	3335-3451	bar 230-238
Intake manifold pressure @ converter stall	In. Hg.	N/A	mm Hg. N/A
Exhaust manifold temp., Max. @ converter stall	°F	1148	°C 620
Air Cleaner restriction, Max. @ converter stall	In. H <sub>2</sub> O	25	cm H <sub>2</sub> O 63.5

## TRANSMISSION/TORQUE CONVERTER

Main pressure @ high idle, neutral	PSI	180-220	bar	12.4-15.1
Lube pressure high idle, neutral	PSI	15-25	bar	1.1-1.7
Converter out @ high idle, neutral	PSI	70 max	bar	4.8
Converter out @ 2000 rpm	PSI	25 min	bar	1.7
Pump @ 2500 rpm	GPM	19.8	L/min	75

## STEERING/BRAKES

Steering pressure @ high idle, neutral	PSI	1975-2088	bar	136-144
Steering crossover relief	PSI	2855-2940	bar	197-203
Pump flow @ 2500 rpm @ 100 psi	GPM	17	L/min	65
Brake air pressure	PSI	N/A	bar	N/A
Brake pump pressure @ high idle, neutral	PSI	N/A	bar	N/A
Brake pump flow	GPM	N/A	L/min	N/A

## IMPLEMENT HYDRAULICS

Main pressure @ high idle	PSI	2885-2825	bar	185-195
Circuit relief valve, raise	PSI	3290-3375	bar	227-233
Circuit relief valve, dump	PSI	1710-1770	bar	118-122
Circuit relief valve, retract	PSI	3000-3090	bar	207-213
Pump flow @2500 rpm @ 100 psi	GPM	25	L/min	95
Pilot pressure @high idle, neutral	PSI	N/A	bar	N/A
Pilot pressure @ low idle, neutral	PSI	N/A	bar	N/A
Pilot reducer pressure ( engine off, bucket at 6' 8")	PSI	N/A	bar	N/A
Pilot pump flow @	GPM	N/A	L/min	N/A
Cycle times @ high idle, neutral				
Full raise	sec	6-7		
Retract @ full raise	sec	0.7-1.0		

## CAPACITIES, refill (approximate)

	GALS	TYPE	LITER
Engine cooling system	5	COOLANT	19
Engine crankcase	2.4	EO	9
Transmission/converter	5	TF	19
Transmission transfer case	N/A	N/A	N/A
Axle (1) including differential & planetaries	5.4	MGO	20.5
Implement hydraulic system	8	HO	30
Brake system	0.1	EO	0.4
Fuel tank	34	DIESEL	130

# FR11 WHEEL LOADER

# S/N 530101 - UP

<b>ENGINE</b>		IVECO 8065.SI.25 (ALL 004)		
Bore & stroke		104 X 115 mm		
Displacement		5.9 L		
Firing order		1-5-3-6-2-4		
Low idle, (high idle)	rpm	760-810 (2600-2650)		
Converter stall	rpm	2360-2460		
Hydraulic stall	rpm	2440-2540		
Full stall (converter & implement)	rpm	1840-1980		
Valve clearance, Cold Intake (Exhaust)	inch	0.010 (0.014)	mm	0.25 (0.35)
Oil pressure, Min. @low idle (high idle)	PSI	10 (43)	bar	0.7 (2.96)
Cylinder compression, minimum @ cranking speed	PSI	304	bar	21
Nozzle pressure	PSI	3335-3451	bar	230-238
Intake manifold pressure @ converter stall	In. Hg.	27	mm Hg.	686
Exhaust manifold temp., Max. @ converter stall	°F	1130	°C	610
Air Cleaner restriction, Max. @ converter stall	In. H <sub>2</sub> O	25	cm H <sub>2</sub> O	63.5

## TRANSMISSION/TORQUE CONVERTER

Main pressure @ high idle, neutral	PSI	217-247	bar	15-17
Lube pressure high idle, neutral	PSI	N/A	bar	N/A
Converter out @ high idle, neutral	PSI	72 max	bar	5 max
Converter out @ converter stall	PSI	36 min	bar	2.5 min
Pump @ 2400 rpm	GPM	17.75	L/min	67.2

## STEERING/BRAKES

Steering pressure @ high idle, neutral	PSI	2044-2160	bar	141-149
Steering crossover relief	PSI	2900-3200	bar	200-220
Pump flow @ 2400 RPM @ 100 psi	GPM	35	L/min	132
Brake air pressure	PSI	105-120	bar	7.2-8.3
Brake pump pressure @ high idle, neutral	PSI	N/A	bar	N/A
Brake pump flow	GPM	N/A	L/min	N/A

## IMPLEMENT HYDRAULICS

Main pressure @ high idle, neutral	PSI	2465-2610	bar	170-180
Circuit relief valve, raise	PSI	N/A	bar	N/A
Circuit relief valve, dump	PSI	1340-1440	bar	92.4-99.3
Circuit relief valve, retract	PSI	2800-3200	bar	193-221
Total Pump flow @2400 rpm @ 100 psi	GPM	52	L/min	196
Pilot pressure @high idle, neutral	PSI	N/A	bar	N/A
Pilot pressure @ low idle, neutral	PSI	N/A	bar	N/A
Pilot reducer pressure ( engine off, bucket at 6' 8")	PSI	N/A	bar	N/A
Pilot pump flow @	GPM	N/A	L/min	N/A
Cycle times @ high idle, neutral				
Full raise	sec	6-7		
Retract @ full raise	sec	3-4		

## CAPACITIES, refill (approximate)

	GALS	TYPE	LITER
Engine cooling system	8.5	COOLANT	32
Engine crankcase	3.8	EO	14.5
Transmission/converter	4.5	TF	17
Transmission transfer case	N/A	N/A	N/A
Axle (1) including differential & planetaries	15.8	MGO	60
Implement hydraulic system	17.2	HO	65
Brake system	0.5	BF	2
Fuel tank	50	DIESEL	189

## FR160 WHEEL LOADER    S/N 580101-UP

<b>ENGINE</b>		IVECO 8365.25.584	
Bore & stroke		115 X 130 mm	
Displacement		8.1 L	
Firing order		1-5-3-6-2-4	
Low idle, (high idle)	rpm	870-920 (2360-2420)	
Converter stall	rpm	2210-2350	
Hydraulic stall	rpm	2230-2370	
Full stall (converter & implement)	rpm	1680-1880	
Valve clearance, Cold Intake (Exhaust)	inch	0.012 (0.020)	mm 0.30 (0.50)
Oil pressure, Min. @low idle (high idle)	PSI	20 (43)	bar 1.4 (3.0)
Cylinder compression, minimum @ cranking speed	PSI	341	bar 23.5
Nozzle pressure	PSI	3335-3450	bar 230-238
Intake manifold pressure @ converter stall	In. Hg.	25	mmHg 620
Exhaust manifold temp., Max. @ converter stall	°F	1075	°C 580
Air Cleaner restriction, Max. @ converter stall	In. H <sub>2</sub> O	25	cmH <sub>2</sub> O 62.5
Pump timing to engine	B.T.D.C	22-24°	

<b>TRANSMISSION/TORQUE CONVERTER</b>		4WG200	
Main pressure @ high idle, neutral	PSI	230-260	bar 16-18
Converter out @ high idle, neutral	PSI	36	bar 2.5
Converter out @ converter stall	PSI	na	bar na
Pump @ 2100 rpm min.	GPM	25	L/min 97

<b>STEERING/BRAKES</b>			
Steering pressure @ high idle, neutral	PSI	2680-2750	bar 185-190
Steering crossover relief	PSI	3700-3840	bar 255-265
Pump flow @ 2100 RPM @ 100 psi	GPM	44	L/min 170
Brake pressure (at accumulator)	PSI	1800-2175	bar 1-25-150
Brake pressure (at booster inlet)	PSI	1260-1300	bar 86-90
Brake pump flow @ 1000 RPM & 100 psi	GPM	5.2	L/min 20.1

<b>IMPLEMENT HYDRAULICS</b>			
Main pressure @ high idle, neutral	PSI	2830-2970	bar 195-205
Circuit relief valve, raise	PSI	3265-3405	bar 225-235
Circuit relief valve, dump	PSI	3265-3405	bar 225-235
Circuit relief valve, retract	PSI	3265-3405	bar 225-235
Total Pump flow @2100 rpm @ 100 psi	GPM	64	L/min 246
Pilot pressure	PSI	441	bar 30
Cycle times @ high idle, neutral			
Full raise	sec	6.6	
Retract @ full raise	sec	2	

<b>CAPACITIES, refill (approximate)</b>			
Engine cooling system	GALS	TYPE	LITER
Engine crankca	10	COOLANT	37.5
Transmission/converter	3.9	EO	14.5
Axle (1) including differential & planetaries	4.8	TF	18
Implement hydraulic system	8.8	MGO*	33
Brake system	30	HO	112
Fuel tank	0.4	BF	1.5
	79	DIESEL	286

\* Super Max Trac requires lubricant with LS additive

## FG65C MOTOR GRADER S/N 85S005001-UP

### ENGINE

		IVECO/Ford New Holland - 444	
Bore & Stroke	cu.in.	4.4 x 4.4	cu.mm 111.8 x 111.8
Displacement	CID	268	L 4.4
Firing Order		1-3-4-2	
Low-idle	rpm	800-900	
High-idle	rpm	2400-2500	
Convertor Stall	rpm	2040-2140	
Horse Power - Gross		80	Kw 59.7
- Net		72.6	Kw 54.1
Valve Clearance - intake		0.14-.018	mm 0.36-0.46
(Cold) - exhaust		.017-.021	mm 0.43-0.53
Cylinder Compression @ 200 RPM	PSI	375	bar 25.85
Injection Nozzle Pressure	PSI	3480-3596	bar 240-248
Engine Oil Pressure - lo idle	PSI	10	bar 0.7
(Operating Temp.) - hi idle	PSI	30	bar 2.7

### TRANSMISSION / TORQUE CONVERTER

Model/Type	Torque Conv. Trans.	ZF Model F&S 280 ZF 6WG 100	
Trans. Clutch Apply Pressure	PSI	232-261	bar 16-18
Trans. Lube Pressure	PSI	4.5-14.5	bar 0.3-1.0r
Torque Convertor Charging Pressure	PSI	29-35	bar 2.0-2.4
Charging Pump Flow @ 2000 Engine RPM	GPM	13.2	L/min 50.0

### HYDRAULIC SYSTEM

Hydraulic Pump Flow - Implement	GPM	11.4	L/min 43.2
(Dual Section) - Steering	GPM	6.7	L/min 25.6
Relief Pressure - Implement	PSI	2000	bar 137.9
@ Engine High Idle - Steering	PSI	1350	bar 93.1
Tire Pressure	PSI	25	bar 1.7

### CAPACITIES (REFILL) Type

Engine Crankcase	SAE 15W40	3.0 Gal	11.4 L
Cooling System	50/50 water/ethylene Glycol	5.0 Gal	18.9 L
Hydraulic System	SAE 10W	16.0 Gal	60.6 L
Trans./Convertor	SAE 15W40 or ZFTE-MLD3	3.5 Gal	13.2 L
Circle Turn Gear Box	SAE 80/90W(EP)	.6 QT	0.57 L
Brake System	SAE 10W	1.2 QT	1.13 L
Rear Axle	SAE 15W40	5.5 Gal	20.8 L
Tandem Case (Each)	SAE 80/90	3.0 Gal	11.4 L
Fuel Tank	No.2 Diesel	34.0 Gal	128.7 L

# 161 TRACTOR SCRAPER

**Tr. S/N 13S 00101 - UP**  
**Sc. S/N 18A 00101 - UP**

## ENGINE

Firing order  
 Low idle, (high idle)  
 Converter Stall  
 Valve clearance, Cold Intake (Exhaust)  
 Oil pressure, Min. @ high idle, hot  
 Cylinder compression pressure  
 Diff. between cyls. (max.)  
 Nozzle pressure  
 Intake manifold press. @ conv. stall  
 Exhaust manifold temp. @ conv. stall  
 Oil or coolant temp. differential  
 across heat exchangers  
 Air Cleaner restriction, Max. @ stall  
 \*See Cummins distributor for complete  
 engine information

CUMMINS: V-903-C265

1-5-4-3-6-3-7-2

rpm 600-650 (2375-2420)

rpm 2010-2070

inch \*

PSI \*

PSI \*

PSI \*

PSI \*

in. hg \*

°F \*

°F 10 (min.)

in. H<sub>2</sub>O 30

°C -12

cm H<sub>2</sub>O 76

## TRANSMISSION/TORQUE CONVERTER

Main press. @ high idle, neutral  
 Trans. clutch apply pressure @ high idle  
 Lube press. high idle, neutral  
 Converter out, high idle, neutral  
 Converter out, @ 1000 rpm, neutral  
 Converter lock-up, @ high idle, neutral  
 and 2nd thru 6th  
 Pilot press., high idle, neutral  
 Pump flow @ high idle  
 Shift solenoids min. voltage

PSI 195-215 bar 13.4-14.8

PSI 195-215 bar 13.4-14.8

PSI 20-30 bar 1.4-2

PSI 36-38 bar 2.5-2.6

PSI 60-65 bar 4.1-4.5

PSI 195-215 bar 13.4-14.8

PSI 36-38 bar 2.5-2.6

gpm 36 (29 min.) L/min 136 (109)

V 16

## STEERING/BRAKES

Steering pressure @ high idle  
 Steering pump @ high idle  
 Steering crossover relief  
 Brake air pressure

PSI 1975-2025 bar 136-140

gpm 41(34 min.) L/min 155 (128)

PSI 2550-2650 bar 176-183

PSI 85-105 bar 5.9-7.3

## IMPLEMENT HYDRAULICS

Scraper syst. pressure @ high idle  
 Pump flow @ high idle @ 1500 psi  
 scraper/elevator system  
 Elevator motor system  
 Ejector system

PSI 2375-2425 bar 164-167

gpm 28 (23 min.) L/min 106 (87)

gpm 86 (73 min.) L/min 325 (276)

gpm 34 (28 min.) L/min 128 (106)

## CAPACITIES, refill (approximate)

Engine cooling system  
 Engine crankcase, incl. filters  
 Transmission/converter  
 Planetaries and axle (total)  
 Brake reservoir, each  
 Impl. hydraulic system  
 Fuel tank  
 Elevator gear box

GALS	TYPE	LITER
17	COOLANT	64
9	EO	34
16	TF	60
11	MGO	41
.35	BF	1.3
60	HO	227
122	Diesel	461
2	MGO	7.6

# FE40 EXCAVATOR

<b>ENGINE</b>	<b>IVECO 8215.22.523</b>		
Bore & stroke	137 X 156 mm		
Displacement	13.8 L		
Firing order	1-5-3-6-2-4		
Low idle, (high idle)	rpm	800-850 (2200±50)	
Valve clearance, Cold Intake (Exhaust)	inch	0.012 (0.016)	mm 0.3 (0.4)
Oil pressure, Min. @low idle (high idle)	PSI	42-57	bar 2.9-3.9
Cylinder compression, minimum @ cranking speed	PSI	313	bar 21.6
Nozzle pressure	PSI	3625-3740	bar 250-258
Intake manifold pressure @ hydraulic stall	In. Hg.		mm Hg.
Exhaust manifold temp., Max. @ hydraulic stall	°F		°C
Air Cleaner restriction, Max. @ hydraulic stall	In. H <sub>2</sub> O		cm H <sub>2</sub> O

## HYDRAULIC SYSTEM

Pump flow @ 4061 + 4061 + 8122 psi @ 2100 eng. rpm (after regulator cut-in)	GPM		L/min
Pump flow @ 2100 eng. rpm (before regulator cut-in)	GPM		L/min
Main pressure @ high idle	PSI	4040-4080	bar 278-281
Pump regulator cut-in pressure	PSI		bar
Power assist reducing pressure	PSI		bar
Swing motor crossover pressure :	PSI		bar
Ch. Valve (to accumulator, from pumps)	PSI		bar
Pilot relief pressure	PSI	435 (bench test)	bar 30
Overload valve pressure (6)	PSI	5050-5100	bar 348-351

## CAPACITIES, refill (approximate)

	GALS	TYPE	LITER
Engine cooling system	13	COOLANT	50
Engine crankcase	7.6	EO	29
Swing reduction unit	4	MGO	15
Travel reduction unit	2.6	MGO	10
Implement hydraulic system	132	HO	500
Fuel tank	132	DIESEL	500


## FE40 with Modified Hydraulic System

High idle	RPM	2300 ± 50	
Hydraulic stall with 2 circuits	RPM	2050-2100	
Main relief	PSI	4150 ±175	bar 286-288
Swing pressure - old style	PSI	4640	bar 320
Swing pressure - new style	PSI	4930	bar 340
Governor Cut-in pressure	PSI	4350 combined	bar 300

## CRAWLER LOADERS

Model	Power kw/Hp DIN6270	Operating weight ton	bucket standard m <sup>3</sup>	breakout force ton	Tipping load Kg	Shoe mm	Dump height mm
FL5B	52/71	803	1.0	5.7	5371	360	2470
FL7B	63/86	9.6	1.15	7.9	6693	360	2580
FL9	68/93	11.2	1.24	9.0	7100	360	2680
FL10E	94/127	13.6	1.53	11.1	9120	380	2800
FL14E	125/170	17.7	2.1	15.7	12550	425	3000
FL20	173/235	26.3 27.3	2.67 3.1	21.6	17240	500	3280

FIATALLIS MOTORSCRAPERS							
Models	Power Hp (SAE)	Scraper type	Wheel drive n°	Heaped capacity m³	Rated load ton	Weight empty ton	Tires standard
260B	342	Conventional	2	16.1	22.8	26.5	29.5x29
261B	342	Elevating	2	17.6	24.0	28.5	29.5x29
161	229	Elevating	2	11.5	17.0	20.3	26.5x25



	A	B	C	D	E	F	G	H	I	*
260B	3250	11785	7165	280	3455	3150	3050	2285	3630	460
261B	3250	11785	7340	240	3555	3150	3000	2285	3660	430
161	3035	10695	6885	300	3125	2745	2670	2085	3050	440

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL