

# SERVICE MANUAL

**P2350 / P3440 / P3550 /  
P4460 / P4580 / P4760 /  
P4950**  
Air Cart

**Part number 47827462**  
1<sup>st</sup> edition English  
April 2017



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


## Hand signals

P Series Air Carts

It is often necessary to communicate using hand signals in agricultural operations when noise or distance inhibit communication by voice. The **ASAE S351** standard illustrates these hand signals, which provide an easy means of communication, particularly in the interest of safety.




**THIS FAR TO GO** - Place palms at ear level facing head and move laterally inward to indicate remaining distance to go.



**COME TO ME** - Raise the arm vertically overhead, palm to the front, and rotate in large horizontal circles.




**MOVE TOWARD ME, FOLLOW ME** - Point toward person(s), vehicle(s), or unit(s), beckon by holding the arm horizontally to the front, palm up, and motioning toward the body.




**MOVE OUT, TAKE OFF** - Face the desired direction of movement; hold the arm extended to the ear; then swing it overhead and forward in the direction of desired movement until it is horizontal, palm down.




**STOP** - Raise hand upward to the full extent of the arm, palm to the front. Hold that position until the signal is understood.




**SPEED IT UP, INCREASE SPEED** - Raise the hand to the shoulder, fist closed; thrust the fist upward to the full extent of the arm and back to the shoulder rapidly several times.




**SLOW IT DOWN, DECREASE SPEED** - Extend the arm horizontally sideways, palm down, and wave arm downward



**START THE ENGINE** - Simulate cranking of vehicles by moving arm in circular motion at waist level.



**STOP THE ENGINE** - Draw right hand, palm down, across the neck in a "throat cutting" motion from left to right.



**LOWER EQUIPMENT** - Make circular motion with either hand pointing to the ground.



**RAISE EQUIPMENT** - Make circular motion with either hand at head level.

# INTRODUCTION

Operation of meter control handles. Note that meter **NOTE: The decal in a particular location shows the**  
handle should be placed in storage position when **correct handle orientation.**  
tank is not in use.


Quantity: 1 per meter bank

Part number: 47681087

47681088


47681089

47681090




47681087 12

On the side of each meter bank (20).



SAIL15SE00405AA 13

## Basic instructions - Electrical testing - Short circuit to ground



RCIL06PTR021CAA 1

Short circuit to ground occurs when any part of a circuit is in contact with a ground source when it is not intended. Where the test leads are applied depends on the component or circuit tested:

- When testing a sensor, for example, disconnect the sensor from its connector.
- When testing a controller harness, disconnect the harness at the controller connector and the malfunctioning component at its connector on the harness.
- When testing a harness, disconnect the harness connectors at its source and its terminal.

1. Turn system power OFF.
2. Disconnect the connectors for the circuits to be tested.
3. Identify the pins or cavities that need to be tested.
4. Select the resistance setting on the multimeter.
5. Touch one of the test leads from the multimeter to the pin or cavity on one end of the circuit.
6. Touch the other test lead to the pin or cavity on the other end of the circuit.
7. Read the value on the multimeter.
8. The resistance reading should be greater than **100 Ω** to indicate an open circuit. If the circuit is not open, the wire is shorted to ground.

**NOTE:** The **100 Ω** value is a representative value used throughout the diagnostic procedures in this manual. The expected resistance reading for an open circuit is "infinite" resistance or "open line" on the multimeter. The actual reading on the multimeter depends on the wire gauge – 0.8, 1.2, 2.0, 3.0 – and the distance between the test points.

9. Locate and repair the source of the short. Or replace the shorted wire or component.

# Contents

---

## Front axle system - 25


[25.400] Non-powered front axle .....	25.1
---------------------------------------	------

## Rear axle system - Non-powered rear axle

Table 1

Location	Torque
Front caster wheels	<b>169 N·m +/- 26 N·m ( 125 lb ft +/- 19 lb ft)</b>
Front steered wheels	<b>441 N·m +/- 66 N·m ( 325 lb ft +/- 49 lb ft)</b>
Rear single wheels	<b>441 N·m +/- 66 N·m ( 325 lb ft +/- 49 lb ft)</b>
Rear dual wheels	<b>931 N·m +/- 140 N·m ( 687 lb ft +/- 103 lb ft)</b>

9. Check wheel bolt torque after the first 10 hours and re torque to the values shown in Table 1.
10. Torque bolts to **85%** of the listed torque then torque to the full value.
11. Tighten the bolts in the order shown. This pattern will apply for all 10 bolt wheels.



SAIL15SE00437AA 3

# Contents

---

## Brakes and controls - 33

### Hydraulic service brakes - 202

#### TECHNICAL DATA

Brake caliper	
General specification (*)	3

#### FUNCTIONAL DATA


Hydraulic service brakes	
Dynamic description (*)	4
Component diagram (*)	5
Brake pump	
Detailed view (*)	7
Brake block	
Detailed view (*)	8

#### SERVICE

Hydraulic service brakes	
Check (*)	9
Bleed (*)	10
Adjust (*)	12


(\*) See content for specific models

## Hydraulic systems - Overview



SAIL15SE00439FA 1

**Fans and alternator**



SAIL15SE00440FA 2


**Deluxe auger**

---

## Hydraulic systems - Hydraulic schema 350 Bu tow between single shoot with no auger

P2350	
-------	--

Ref	Description
(A)	Case drain
(B)	Fan pressure
(C)	Fan return
(1)	Check valve
(2)	Check valve
(3)	Fan motor
(4)	Alternator motor
(5)	Check valve



SAIL15SE01287GA 1

## Hydraulic systems - Hydraulic schema 460 Bu and 580 Bu and 760 Bu and 950 Bu tow behind double shoot with auxiliary tank and deluxe auger/conveyor

P4460	
P4580	
P4760	
P4950	

Ref	Description
(A)	Upper fan pressure
	Auxiliary tank fill return
(B)	Upper fan return
	Auxiliary tank fill pressure
(C)	Case drain
(D)	Lower fan pressure
	Auger / conveyor return
(E)	Lower fan return
	Auger / conveyor pressure
(1)	Check valve
(2)	Check valve
(3)	Filter
(4)	Ball valve
(5)	Check valve
(6)	Pressure compensated valve
(7)	Auxiliary tank fill rotary motor
(8)	Rotary valve, see <b>Auxiliary tank fill system valves - Hydraulic schema (35.870)</b> for valve block details
(9)	Upper fan motor
(10)	Auxiliary tank fill fan motor
(11)	Lower fan motor
(12)	Auger motor
(13)	Rotary valve
(14)	Auger/conveyor control valve, see <b>Seeding auger control valve - Hydraulic schema (35.744)</b> for valve block details
(15)	Tilt cylinder
(16)	Rotate outer arm cylinder
(17)	Lift cylinder
(18)	Rotate arm cylinder
(19)	Alternator motor
(20)	Check valve
(21)	Check valve



## **Hydraulic systems - 35**

### **Seeding and planting hydraulic circuits - 744**

**P2350, P3440, P3550 , P4460, P4580, P4760, P4950**

# Index

---

## Hydraulic systems - 35

### Seeding and planting hydraulic circuits - 744

Auger drive system - Assemble .....	16
Auger drive system - Overhaul .....	14
Seeding auger control valve - Detailed view deluxe auger rotary valve .....	10
Seeding auger control valve - Detailed view manual auger ball valve .....	9
Seeding auger control valve - Detailed view manual auger control valve .....	6
Seeding auger control valve - Detailed view Valve block hydraulic hose connections .....	5
Seeding auger control valve - Hydraulic schema .....	4
Seeding auger control valve - Overview - valve functions .....	3
Seeding auger hydraulic cylinders - Detailed view - manual auger .....	12


## Auxiliary tank fill system feeder motor - Install

P3550	
P4580	
P4760	
P4950	

### Prior operation:


#### Auxiliary tank fill system feeder motor - Remove (35.870)

1. Fasten the motor to the mount bracket using the previously removed hardware.




SAVM16SE00214AA 1

2. Align the drive sprocket with the drive and install the coupler (4) .
3. Fasten the motor mount (3) to the auxiliary tank hopper using the previously removed hardware.



SAVM16SE00212AA 2

4. Reinstall the top (1) and bottom (2) plates using the previously removed hardware (3) .



SAVM16SE00435AA 3

5. Install the hoses on the motor ports, matching the ports with the hose tags installed earlier.
6. Test the operation of the motor and the rotor.

# Contents

---

## Frames and ballasting - 39

## Drawbar and hitch assembly - 110

### TECHNICAL DATA

Drawbar and hitch assembly	
Drawbar - Configure .....	3

### SERVICE

Tongue or hitch	
Drawbars and towing hitches - Check (*) .....	5
Jack	
Front hitch support - Grease (*) .....	6

(\*) See content for specific models

**Row crop and controlled traffic tire option****Row crop rear dual**

		Tire size	Inflation Pressure 10 km/h (6 mph)	Inflation Pressure 16 km/h (10 mph)
P2350	Tow-between	480/80R42 151A8	138 kPa (20 psi)	159 kPa (23 psi)
	Tow-behind	AC85	117 kPa (17 psi)	138 kPa (20 psi)

**Row crop and controlled traffic front**

		Tire size	Inflation Pressure 10 km/h (6 mph)	Inflation Pressure 16 km/h (10 mph)
P2350	Tow-behind	380/90R46 159A8 AC85	117 kPa (17 psi)	159 kPa (23 psi)
P3440	Tow-behind	380/90R46 159A8 AC85	117 kPa (17 psi)	159 kPa (23 psi)
P4460	Tow-behind	380/90R46 159A8 AC85	117 kPa (17 psi)	159 kPa (23 psi)

**Row crop and controlled traffic front tires– steered front axle**

			Tire size	Load index	Single / Dual	Inflation Pressure 10 km/h (6 mph)	Inflation Pressure 16 km/h (10 mph)
P2350	Front	Base	18.4-38 R1 TD19	8PR	Single	90 kPa (13 psi)	90 kPa (13 psi)
		High flotation	650/75R38 SFT	172A8	Single	41 kPa (6 psi)	41 kPa (6 psi)
P3440	Front	Base	18.4-38 R1 TD19	8PR	Single	90 kPa (13 psi)	90 kPa (13 psi)
		High flotation	650/75R38 SFT	172A8	Single	41 kPa (6 psi)	41 kPa (6 psi)
P4460	Front	Base	18.4-38 R1 TD19	8PR	Single	90 kPa (13 psi)	90 kPa (13 psi)
		High flotation	650/75R38 SFT	172A8	Single	41 kPa (6 psi)	41 kPa (6 psi)

**Controlled traffic rear single**

		Tire size	Inflation Pressure 10 km/h (6 mph)	Inflation Pressure 16 km/h (10 mph)
P2350	Tow-between	800/70R38 176A8	83 kPa (12 psi)	62 kPa (9 psi)
	Tow-behind	SFT	103 kPa (15 psi)	83 kPa (12 psi)
P3440	Tow-between	800/70R38 176A8	117 kPa (17 psi)	138 kPa (20 psi)
	Tow-behind	SFT	117 kPa (17 psi)	138 kPa (20 psi)
P4460	Tow-between	800/70R38 176A8	138 kPa (20 psi)	200 kPa (29 psi)
	Tow-behind	SFT	117 kPa (17 psi)	159 kPa (23 psi)


# Contents

---

## Electrical systems - 55


[55.000] Electrical system .....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.301] Alternator.....	55.3
[55.302] Battery.....	55.4
[55.404] External lighting .....	55.5
[55.516] Seeding control system .....	55.6
[55.517] Cab seeding controls.....	55.7
[55.545] Auger.....	55.8
[55.640] Electronic modules .....	55.9
[55.785] Precision farming system .....	55.10
[55.DTC] FAULT CODES.....	55.11

4. Fuse 5 (1) is located near the calibration switches. It fuses ECU\_PWR that is used by the UCM, sensors, and 12 V circuitry in the motors.



SAIL15SE00915AA 4

5. Fuse 6 (1) is located near the UCM. It fuses PWR to the UCM and to the coil of Relay 1. (The ground side of the coil is controlled by the UCM.)



SAIL15SE00911AA 5

6. Replace blown fuses with the same value.


**NOTICE:** Do not use higher value fuses. Damage to the wiring harness or connectors may occur.

## Wiring harnesses - Electrical schematic sheet 01 12V power - 350 Bu tow behind

P2350

Type	Component	Connector / Link	Description
ECU	A-008	X-203B	UCM 3B
ECU	A-012	X-204B	UCM 4B
ECU	A-014	X-202B	UCM 2B
ECU	A-015	X-201B	UCM 1B
ECU	A-016	X-201A	UCM 1A
Fuse	F-05	X-452	ECU PWR
Fuse	F-06	X-451	HSD PWR
Connector	X-014	X-014	AUGER CONTROL
Connector	X-101 1	X-101	AIR CART ISOBUS CONNECTOR (IBBC)
Connector	X-101 2	X-101	AIR CART ISOBUS CONNECTOR (IBBC)
Connector	X-101 3	X-101	AIR CART ISOBUS CONNECTOR (IBBC)
Connector	X-101 4	X-101	AIR CART ISOBUS CONNECTOR (IBBC)
Connector	X-101 5	X-101	AIR CART ISOBUS CONNECTOR (IBBC)

Electrical systems - Harnesses and connectors




SHT\_9 1

## Wiring harnesses - Electrical schematic sheet 06 Local Interconnect Network (LIN) bus and motor position assignment - 350 Bu tow between

P2350

Type	Component	Connector / Link	Description
ECU	<b>A-005</b>	<b>X-203B</b>	UCM 3B
ECU	<b>A-009</b>	<b>X-204B</b>	UCM 4B
Connector	X-401 A	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 B	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 C	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 D	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 E	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 F	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 G	<b>X-401</b>	TANK 1 MOTORS
Connector	X-401 H	<b>X-401</b>	TANK 1 MOTORS
Connector	X-402 A	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 B	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 C	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 D	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 E	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 F	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 G	<b>X-402</b>	TANK 2 MOTORS
Connector	X-402 H	<b>X-402</b>	TANK 2 MOTORS

Electrical systems - Harnesses and connectors




SHT\_2 1

**Wiring harnesses - Electrical schematic sheet 11 In-tank and auxiliary tank sensor harness - 435 Bu and 460 Bu tow behind**

P3440	
P4460	

Type	Component	Connector / Link	Description
Ground	<b>GND-006</b>	<b>X-218</b>	LADDER GROUND
Ground	<b>GND-008</b>	<b>X-219</b>	TOP PLATE GROUND
Connector	X-210	<b>X-210</b>	AUX BIN SENSORS
Connector	X-215	<b>X-215</b>	BIN SENSORS
Connector	X-216	<b>X-216</b>	LOW BIN
Connector	X-217	<b>X-217</b>	BIN LEVEL
Connector	X-220A	<b>X-220A</b>	TOP DISCONNECT
Connector	X-270	<b>X-270</b>	AUX TANK SENSORS

Electrical systems - Harnesses and connectors




SHT\_8 1

## Wiring harnesses - Electrical schematic sheet 05 10 motor harness (1 per tank) - 555 Bu and 580 Bu tow behind

P3550	
P4580	

Type	Component	Connector / Link	Description
Dust cap	<b>DC-411</b>	DC-411	DUST CAP / LOOP PLUG FOR X-411
Dust cap	<b>DC-416</b>	DC-416	DUST CAP / LOOP PLUG FOR X-416
Dust cap	<b>DC-420</b>	DC-420	DUST CAP / LOOP PLUG FOR X-420
Ground	<b>GND-001</b>	<b>X-423</b>	PIPE GROUND
Ground	<b>GND-002</b>	<b>X-424</b>	PIPE GROUND
Ground	<b>GND-003</b>	<b>X-425</b>	SUB-HOPPER FRAME GROUND
Connector	X-410	<b>X-410</b>	TANK MOTORS
Connector	X-411	<b>X-411</b>	MOTOR 1
Connector	X-412	<b>X-412</b>	MOTOR 2
Connector	X-413	<b>X-413</b>	MOTOR 3
Connector	X-414	<b>X-414</b>	MOTOR 4
Connector	X-415	<b>X-415</b>	MOTOR 5
Connector	X-416	<b>X-416</b>	MOTOR 6
Connector	X-417	<b>X-417</b>	MOTOR 7
Connector	X-418	<b>X-418</b>	MOTOR 8
Connector	X-419	<b>X-419</b>	MOTOR 9
Connector	X-420	<b>X-420</b>	MOTOR 10

Electrical systems - Harnesses and connectors




SHT\_2 1

**Wiring harnesses - Electrical schematic sheet 10 Light module function -  
555 Bu and 580 Bu tow between**

P3550	
P4580	

Type	Component	Connector / Link	Description
ECU	A-019	X-201B	UCM 1B
ECU	A-020	X-202B	UCM 2B
Connector	X-209	X-209	LIGHT MODULE

Electrical systems - Harnesses and connectors




SHT\_7 1

**Wiring harnesses - Electrical schematic sheet 03 Sensors: tank pressure, motor power monitor - 950 Bu tow behind**

P4950

Type	Component	Connector / Link	Description
ECU	A-001	X-202B	UCM 2B
ECU	A-002	X-201A	UCM 1A
ECU	A-017	X-204A	UCM 4A
ECU	A-022	X-202A	UCM 2A
ECU	A-024	X-204B	UCM 4B
Connector	X-231	X-231	PRESSURE 1
Connector	X-232	X-232	PRESSURE 2
Connector	X-233	X-233	PRESSURE 3
Connector	X-234	X-234	PRESSURE AUX


Electrical systems - Harnesses and connectors



SAVE17SE00089JA 1

**Wiring harnesses - Electrical schematic sheet 01 Cart lighting power and meter lighting - 2 tank air carts**


Type	Component	Connector / Link	Description
Fuse	F-01	X-531	CART LIGHTING (15A)
Connector	X-530	X-530	AIR CART LIGHTING
Connector	X-532	X-532	LIGHT SWITCH
Connector	X-533	X-541	PLATFORM LIGHTS
Connector	X-535	X-535	METER LIGHT 1
Connector	X-536	X-536	METER LIGHT 2
Connector	X-538	X-538	METER LIGHT 3
Connector	X-539	X-539	AUGER LIGHTS
Connector	X-541	X-541	PLATFORM LIGHTS
Connector	X-554	X-554	TO MOTOR HARNESS
Connector	X-555	X-555	AIR CART LIGHTING




## Wire connectors - Component diagram 21 350 Bu tow behind

P2350

### X-211 - BIN 1 SENSORS (87706919) (Female)




87706919 1  
**87706919**



SAIL15SE01312AA 2

Pin	From	Wire	Description	Color-Size	Frame
A	SP-AC30-P-X	160	LOW BIN1	YE - 0.8	SHEET 08
B	SP-AC19-P-X	164	+12V SEN	OR - 0.8	
C	SP-AC31-P-X	172	BIN LEVEL1	YE - 0.8	
D	SP-AC18-P-X	168	SEN DGND	BL - 0.8	
E	SP-AC67-P-X	209	TRIG BIN LEVEL	WH - 0.8	

### X-212 - BIN 2 SENSORS (87706919) (Female)




87706919 3  
**87706919**


## Wire connectors - Component diagram 41 350 Bu tow behind

P2350

### X-410 - TANK MOTORS (84137497) (Male)




84137497 1  
**84137497**




SAIL16SE00166AA 2

Pin	From	Wire	Description	Color-Size	Frame
A	SP-MR01-P-X	89	MGND	BK - 3	SHEET 05
B	SP-MR07-P-X	74	LIN	YE - 0.8	
C	SP-MR12-P-X	13	LIN_PWR	OR - 0.8	
D	SP-MR03-P-X	218	MPWR	RD - 3	
E	SP-MR01-P-X	35	MGND	BK - 3	
F	SP-MR14-P-X	264	CH_GND	BK - 1	
G	X-411 (Female) pin 4 MOTOR 1	63	XWDC	WH - 0.8	
H	SP-MR03-P-X	147	MPWR	RD - 3	

### X-411 - MOTOR 1 (87708148) (Female)




87708148 3  
**87708148**




SAIL16SE00130AA 16

Pin	From	Wire	Description	Color-Size	Frame
3	X-448A (Male) pin A ALTERNATOR	280	ALT_ENABLE	RD - 0.8	SHEET 09

**X-219 - TOP PLATE GROUND (47607318)**




47607318 13  
**47607318**




SAIL15SE00466AA 14

Pin	From	Wire	Description	Color-Size	Frame
1	X-220A (Female) pin A TOP DISCONNECT	295	GND	BK - 2	SHEET 11

**X-416 - MOTOR 6 (87708148) (Female)**




87708148 13  
**87708148**



SAIL15SE00941AA 14

Pin	From	Wire	Description	Color-Size	Frame
1	SP-MR09-P-X	84	LIN	YE - 0.8	<b>SHEET 05</b>
2	SP-MR02-P-X	42	MGND	BK - 1	
3	SP-MR13-P-X	27	LIN PWR	OR - 0.8	
4	X-415 (Female) pin 5 MOTOR 5	68	XWDC	WH - 0.8	
5	X-417 (Female) pin 4 MOTOR 7	69	XWDC	WH - 0.8	
6	SP-MR04-P-X	54	MPWR	RD - 1	

**X-417 - MOTOR 7 (87708148) (Female)**




87708148 15  
**87708148**


## Wire connectors - Component diagram 10 435 Bu and 460 Bu tow behind

P3440	
P4460	

### X-101 - AIR CART ISOBUS CONNECTOR (IBBC) (84074256) (Female)




84074256 1  
**84074256**



SAIL16SE00301AA 2

Pin	From	Wire	Description	Color-Size	Frame
1	SP-AC01-P-X	276	GND	BK - 5	<b>SHEET 01</b>
2	SP-AC02-P-X	144	ECU_GND	BK/WH - 2	
3	SP-AC04-P-X	215	PWR	OR - 5	
4	<b>X-452 pin A</b> ECU PWR	177	ECU_PWR	OR - 3	
6	SP-AC12-P-X	304	TBC_PWR	RD - 0.5	<b>SHEET 02</b>
7	SP-AC11-P-X	305	TBC_RTN	BK - 0.5	
8	SP-AC10-P-X	306	CAN_H	YE - 0.5	
9	SP-AC09-P-X	307	CAN_L	GN - 0.5	

Electrical systems - Harnesses and connectors




SAIL15SE00937AA 4

Pin	From	Wire	Description	Color-Size	Frame
A	SP-IT02-P-X	126	GND	BK - 2	SHEET 11


Electrical systems - Harnesses and connectors

Pin	From	Wire	Description	Color-Size	Frame
A	SP-AC54-P-X	21	MGND	BK - 3	SHEET 06
B	SP-AC65-P-X	2	LIN	YE - 0.8	
C	SP-AC66-P-X	139	LIN_PWR	OR - 0.8	
D	SP-AC58-P-X	30	MPWR_AUX	RD - 3	
E	SP-AC54-P-X	20	MGND	BK - 3	
F	SP-AC68-P-X	269	CH_GND	BK - 1	
G	X-203B pin 7 UCM 3B	11	XWDC_AUX	WH - 0.8	
H	SP-AC58-P-X	70	MPWR_AUX	RD - 3	

**X-448A - ALTERNATOR (87693745) (Male)**




87693745 13  
**87693745**



SAIL16SE00042AA 14


Pin	From	Wire	Description	Color-Size	Frame
A	X-449 (Female) pin 3 ALTERNATOR	96	ALT_ENABLE	RD - 0.8	SHEET 09

**X-449 - ALTERNATOR (84163450) (Female)**




84163450 15  
**84163450**

**X-211 - BIN 1 SENSORS [ GB-AC208P] (87706919) (Female)**




87706919 3  
**87706919**




SAIL16SE00017AA 4

Pin	From	Wire	Description	Color-Size	Frame
A	SP-AC30-P-X	160	LOW BIN1	YE - 0.8	<b>SHEET 08</b>
B	SP-AC19-P-X	116	+12V SEN	OR - 0.8	
C	SP-AC31-P-X	172	BIN LEVEL1	YE - 0.8	
D	SP-AC18-P-X	123	SEN DGND	BL - 0.8	
E	SP-AC67-P-X	209	TRIG BIN LEVEL	WH - 0.8	

**X-212 - BIN 2 SENSORS [ GB-AC208Q] (87706919) (Female)**




87706919 5  
**87706919**



SAIL16SE00042AA 4


Pin	From	Wire	Description	Color-Size	Frame
1	SP-AC19-P-X	153	+12V SEN	OR - 0.8	SHEET 07
2	<b>X-201A pin 15</b> UCM 1A	134	FAN RPM1	YE - 0.8	
3	SP-AC18-P-X	133	SEN DGND	BL - 0.8	

**X-262 - LOWER FAN RPM (2) (87696551)**




87696551 5

**87696551**




SAIL16SE00042AA 6

Pin	From	Wire	Description	Color-Size	Frame
1	SP-AC19-P-X	135	+12V SEN	OR - 0.8	SHEET 07
2	<b>X-201A pin 16</b> UCM 1A	137	FAN RPM2	YE - 0.8	
3	SP-AC18-P-X	136	SEN DGND	BL - 0.8	



SAIL16SE00016AA 10


Pin	From	Wire	Description	Color-Size	Frame
1	SP-AC68-P-X	284	CH_GND	BK - 1	SHEET 06



SAIL16SE00044AA 8


Pin	From	Wire	Description	Color-Size	Frame
3	SP-AC05-P-X	198	HSD_PWR	OR - 0.8	SHEET 01
4	SP-AC05-P-X	197	HSD_PWR	OR - 0.8	
9	SP-AC05-P-X	199	HSD_PWR	OR - 0.8	
17	SP-AC05-P-X	200	HSD_PWR	OR - 0.8	
23	X-209 (Male) pin 1 LIGHT MODULE	256	LH WARN	VT - 0.8	
24	X-209 (Male) pin 2 LIGHT MODULE	257	RH WARN	VT - 0.8	
26	SP-AC08-P-X	186	GND	BK - 0.8	
27	X-209 (Male) pin 3 LIGHT MODULE	258	BRAKES	VT - 0.8	
28	X-231 (Female) pin 3 PRESSURE 1	102	TANK_PRES1	YE - 0.8	
29	X-232 (Female) pin 3 PRESSURE 2	103	TANK_PRES2	YE - 0.8	
30	X-233 (Female) pin 3 PRESSURE 3	216	TANK_PRES3	YE - 0.8	
31	X-234 (Female) pin 3 PRESSURE AUX	113	TANK_PRES_AUX	YE - 0.8	
34	SP-AC08-P-X	187	GND	BK - 0.8	

**X-203B - UCM 3B (84130760)**



84130760 9


**84130760**



SAIL16SE00046AA 4


Pin	From	Wire	Description	Color-Size	Frame
A	X-204A pin 18 UCM 4A	121	CAL_TANK1	YE - 0.8	SHEET 04
B	SP-AC16-P-X	110	SEN_DGND	BL - 0.8	

**X-242 - CAL TANK 2 (87692855)**




87692855 5

**87692855**



SAIL16SE00046AA 6


Pin	From	Wire	Description	Color-Size	Frame
A	X-204A pin 23 UCM 4A	122	CAL_TANK2	YE - 0.8	SHEET 04
B	SP-AC16-P-X	111	SEN_DGND	BL - 0.8	



SAIL15SE00941AA 12


Pin	From	Wire	Description	Color-Size	Frame
1	SP-MR09-P-X	83	LIN	YE - 0.8	SHEET 05
2	SP-MR02-P-X	41	MGND	BK - 1	
3	SP-MR12-P-X	22	LIN PWR	OR - 0.8	
4	X-414 (Female) pin 5 MOTOR 4	67	XWDC	WH - 0.8	
5	X-415 (Male) pin 4 MOTOR 5	47	47	WH - 0.8	
5	X-416 (Female) pin 4 MOTOR 6	68	XWDC	WH - 0.8	
6	SP-MR04-P-X	53	MPWR	RD - 1	

**X-416 - MOTOR 6 (87708148) (Female)**




87708148 13

**87708148**




SAIL15SE00941AA 14




SAIL15SE00915AA 6

Pin	From	Wire	Description	Color-Size	Frame
A	X-101 (Female) pin 4 AIR CART ISOBUS CONNECTOR (IBBC)	177	ECU_PWR	OR - 3	SHEET 01
B	SP-AC03-P-X	112	ECU_PWR	OR - 3	

**X-218 - LADDER GROUND (84127304)**




84127304 15  
**84127304**



SAIL15SE00937AA 16


Pin	From	Wire	Description	Color-Size	Frame
1	SP-IT02-P-X	296	GND	BK - 1	<b>SHEET 11</b>

**X-219 - TOP PLATE GROUND (47607318)**




47607318 17  
**47607318**

**X-402 - TANK 2 MOTORS (84137524) (Female)**



84137524 3


**84137524**



SAIL16SE00166AA 4

Pin	From	Wire	Description	Color-Size	Frame
A	SP-AC52-P-X	206	MGND	BK - 3	<b>SHEET 06</b>
B	SP-AC64-P-X	3	LIN	YE - 0.8	
C	SP-AC66-P-X	140	LIN_PWR	OR - 0.8	
D	SP-AC56-P-X	32	MPWR_2	RD - 3	
E	SP-AC52-P-X	18	MGND	BK - 3	
F	SP-AC68-P-X	282	CH_GND	BK - 1	
G	<b>X-203B pin 5</b> UCM 3B	9	XWDC2	WH - 0.8	
H	SP-AC56-P-X	91	MPWR_2	RD - 3	

**X-403 - TANK 3 MOTORS (84137524) (Female)**



84137524 5

**84137524**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**X-445 - RELAY 1 CTRL (82012083)**




82012083 7  
**82012083**



SAIL15SE00910AA 8

Pin	From	Wire	Description	Color-Size	Frame
1	X-201A pin 19 UCM 1A	214	RELAY_CTRL1	WH - 0.8	SHEET 09
2	SP-AC05-P-X	229	PWR	OR - 0.8	

**X-447 - RELAY 2 UCM POWER (297910A1)**




RCIL06\_297910A1 9  
**297910A1**


## Wire connectors - Component diagram 21 760 Bu tow behind

P4760

### X-210 - AUX BIN SENSORS (87706919) (Female)




87706919 1  
**87706919**



SAIL15SE01312AA 2

Pin	From	Wire	Description	Color-Size	Frame
A	X-270 (Male) pin 4 AUX TANK SENSORS	162	LOW_BIN	YE - 0.8	SHEET 12
B	X-270 (Male) pin 5 AUX TANK SENSORS	166	+12V_SEN	OR - 0.8	
C	X-270 (Male) pin 6 AUX TANK SENSORS	174	BIN_LEVEL	YE - 0.8	
D	X-270 (Male) pin 7 AUX TANK SENSORS	170	SEN_DGND	BL - 0.8	
E	X-270 (Male) pin 8 AUX TANK SENSORS	254	TRIG BIN LEVEL	WH - 0.8	

### X-211 - BIN 1 SENSORS(87706919) (Female)




87706919 3  
**87706919**


## Wire connectors - Component diagram 26 760 Bu tow behind

P4760

### X-260 - GROUND SPD (REAR) (87696551)




87696551 1  
**87696551**




SAIL16SE00129AA 2

Pin	From	Wire	Description	Color-Size	Frame
1	SP-AC21-P-X	154	+12V SEN	OR - 0.8	SHEET 08
2	X-201B pin 2 UCM 1B	132	GROUND SPD_REAR	YE - 0.8	
3	SP-AC17-P-X	131	SEN_DGND	BL - 0.8	

### X-261 - UPPER FAN RPM (1) (87696551)




87696551 3  
**87696551**




SAIL16SE00121AA 10

Pin	From	Wire	Description	Color-Size	Frame
1	SP-MR14-P-X	86	CH_GND	BK - 1	SHEET 05

**X-425 - SUB-HOPPER FRAME GND (47607318)**




47607318 11  
**47607318**



SAIL16SE00166AA 12


Pin	From	Wire	Description	Color-Size	Frame
1	SP-MR14-P-X	87	CH_GND	BK - 1	SHEET 05



SAIL16SE00044AA 8

Pin	From	Wire	Description	Color-Size	Frame
3	SP-AC05-P-X	198	HSD_PWR	OR - 0.8	SHEET 01
4	SP-AC05-P-X	197	HSD_PWR	OR - 0.8	
9	SP-AC05-P-X	199	HSD_PWR	OR - 0.8	
17	SP-AC05-P-X	200	HSD_PWR	OR - 0.8	
23	X-209 (Male) pin 1 LIGHT MODULE	256	LH WARN	VT - 0.8	
24	X-209 (Male) pin 2 LIGHT MODULE	257	RH WARN	VT - 0.8	
26	SP-AC08-P-X	186	GND	BK - 0.8	
27	X-209 (Male) pin 3 LIGHT MODULE	258	BRAKES	VT - 0.8	
28	X-231 (Female) pin 3 PRESSURE 1	102	TANK_PRES1	YE - 0.8	
29	X-232 (Female) pin 3 PRESSURE 2	103	TANK_PRES2	YE - 0.8	
30	X-233 (Female) pin 3 PRESSURE 3	216	TANK_PRES3	YE - 0.8	
31	X-234 (Female) pin 3 PRESSURE AUX	113	TANK_PRES_AUX	YE - 0.8	
34	SP-AC08-P-X	187	GND	BK - 0.8	


**X-203B - UCM 3B (84130760)**




84130760 9

**84130760**

**X-243 - CAL TANK 3 (87692855)**




87692855 7  
**87692855**



SAIL16SE00046AA 8


Pin	From	Wire	Description	Color-Size	Frame
A	X-204A pin 24 UCM 4A	101	CAL_TANK3	YE - 0.8	SHEET 04
B	SP-AC16-P-X	118	SEN_DGND	BL - 0.8	

**X-244 - CAL AUX TANK (87692855)**




87692855 9  
**87692855**

**X-419 - MOTOR 9 (87708148) (Female)**




87708148 19  
**87708148**




SAIL15SE00941AA 20

Pin	From	Wire	Description	Color-Size	Frame
1	SP-MR11-P-X	67	LIN	YE - 0.8	<b>SHEET 05</b>
2	SP-MR02-P-X	43	MGND	BK - 1	
3	SP-MR13-P-X	82	LIN PWR	OR - 0.8	
4	<b>X-418 (Female) pin 5</b> MOTOR 8	53	XWDC	WH - 0.8	
5	<b>X-420 pin 4</b> MOTOR 10	89	XWDC	WH - 0.8	
6	SP-MR04-P-X	44	MPWR	RD - 1	

**X-574 - FULL SENSOR 1 (87706919) (Female)**




87706919 7  
**87706919**



SAIL15SE00935AA 8


Pin	From	Wire	Description	Color-Size	Frame
A	X-578 (Female) pin C FULL INDICATOR 1	14	TANK_FULL1	YE - 1	SHEET 01
B	SP-TF01-P-X	20	PWR	OR - 1	
D	SP-TF02-P-X	19	GND	BL - 1	

**X-575 - FULL SENSOR 2 (87706919) (Female)**




87706919 9  
**87706919**


**X-02 - TRANSPORT LOCK (87687242) (Female)**



87687242 3  
**87687242**




SAIL15SE00427AA 4  
**Conveyor**




SAIL15SE00443AA 5  
**Auger**

Pin	From	Wire	Description	Color-Size	Frame
2	F-01-P-B 10A FUSE	2	FUSED PWR	RD - 2	SHEET 01
3	X-01 (Female) pin A RF RECEIVER	3	PWR	OR - 2	

**X-544 - FIELD LIGHT 2 (Female)**




87695582 7  
**87695582**



SAIL15SE00879AA 8


Pin	From	Wire	Description	Color-Size	Frame
1	SP-LP03-P-X	31	FIELD_LIGHT	VT - 2	SHEET 02
2	SP-LP04-P-X	35	FIELD_GND	BK - 2	

**X-545 - FIELD LIGHT 3 (Female)**




87695582 9  
**87695582**

**X-547 - AUX FILL LIGHT (Female)**



87695582 13


**87695582**



SAIL15SE00878AA 14

Pin	From	Wire	Description	Color-Size	Frame
1	SP-LP01-P-X	21	LIGHT_PWR	VT - 1	SHEET 02
2	SP-LP02-P-X	26	LIGHT_GND	BK - 1	

**X-548 - PLATFORM LIGHT 2 (Female)**




87695582 15

**87695582**

## Wire connectors - Component diagram 32 Transport lighting

### X-321 - RIGHT TAIL (Female)




87692858 1

**87692858**

Pin	From	Wire	Description	Color-Size	Frame
A	SP-TB02-P-X	38	GND	WH - 1	SHEET 02
B	SP-TB04-P-X	39	TAIL	BR - 1	
C	X-009 (Female) pin 6 MODULE	53	RT_ENHANCED	GN - 2	

### X-322 - RIGHT BRAKE/TAIL LAMP



87692858 2

**87692858**

Pin	From	Wire	Description	Color-Size	Frame
A	X-321 (Male) pin A RIGHT TAIL	525	525	BK - 0.8	SHEET 02
B	X-321 (Male) pin B RIGHT TAIL	526	TAIL LIGHT	WH - 0.8	
C	X-321 (Male) pin C RIGHT TAIL	528	RT_ENHANCED	RD - 0.8	

---

## Electrical components - Fuse description 350 Bu tow behind

P2350	
-------	--

### *F-05 - ECU PWR (Fuse)*

Component Type	Fuse
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-452 (Female)</b>

### *F-06 - HSD PWR (Fuse)*

Component Type	Fuse
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-451 (Female)</b>

---

## Electrical components - Sensor description 435 Bu and 460 Bu tow behind

P3440	
P4460	

### ***B-001 - GROUND SPD (FRONT) (Sensor)***

Component Type	Sensor
Wiring frames	<b>SHEET 07</b>
Connectors	<b>X-259 (Female)</b>

### ***B-002 - LOWER FAN RPM (2) (Sensor)***

Component Type	Sensor
Wiring frames	<b>SHEET 07</b>
Connectors	<b>X-262 (Female)</b>

### ***B-005 - UPPER FAN RPM (1) (Sensor)***

Component Type	Sensor
Wiring frames	<b>SHEET 07</b>
Connectors	<b>X-261 (Female)</b>

### ***B-006 - GROUND SPD (REAR) (Sensor)***

Component Type	Sensor
Wiring frames	<b>SHEET 07</b>
Connectors	<b>X-260 (Female)</b>

**A-024 - UCM 4B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 03</b>
Connectors	<b>X-204B (Female)</b>

**A-025 - UCM 4A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 08</b>
Connectors	<b>X-204A (Female)</b>

**A-026 - UCM 1B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 10</b>
Connectors	<b>X-201B (Female)</b>

**A-027 - UCM 1A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 09</b>
Connectors	<b>X-201A (Female)</b>

**A-012 - UCM 4B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-204B (Female)</b>

**A-013 - UCM 1A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 10</b>
Connectors	<b>X-201A (Female)</b>

**A-014 - UCM 2B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-202B (Female)</b>

**A-015 - UCM 1B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-201B (Female)</b>

**A-016 - UCM 1A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-201A (Female)</b>

**A-017 - UCM 4A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 03</b>
Connectors	<b>X-204A (Female)</b>

**A-020 - UCM 2B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 11</b>
Connectors	<b>X-202B (Female)</b>

**A-021 - UCM 1A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 08</b>
Connectors	<b>X-201A (Female)</b>

**A-022 - UCM 2A (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 03</b>
Connectors	<b>X-202A (Female)</b>

**A-024 - UCM 4B (ECU)**

Component Type	ECU
Wiring frames	<b>SHEET 03</b>
Connectors	<b>X-204B (Female)</b>

---

## Electrical components - Fuse description 2 tank air carts tank full indicator

*F-01 - FULL INDICATOR FUSE (Fuse)*

Component Type	Fuse
Wiring frames	<b>SHEET 01</b>
Connectors	<b>X-572 (Female)</b>

Wire connectors - Component diagram 20 435 Bu and 460 Bu tow behind (*)	339
Wire connectors - Component diagram 20 435 Bu and 460 Bu tow between (*)	397
Wire connectors - Component diagram 20 555 Bu and 580 Bu tow behind (*)	453
Wire connectors - Component diagram 20 555 Bu and 580 Bu tow between (*)	512
Wire connectors - Component diagram 20 760 Bu tow behind (*)	568
Wire connectors - Component diagram 20 950 Bu tow behind (*)	623
Wire connectors - Component diagram 21 350 Bu tow behind (*)	252
Wire connectors - Component diagram 21 350 Bu tow between (*)	299
Wire connectors - Component diagram 21 435 Bu and 460 Bu tow behind (*)	346
Wire connectors - Component diagram 21 435 Bu and 460 Bu tow between (*)	404
Wire connectors - Component diagram 21 555 Bu and 580 Bu tow behind (*)	460
Wire connectors - Component diagram 21 555 Bu and 580 Bu tow between (*)	519
Wire connectors - Component diagram 21 760 Bu tow behind (*)	575
Wire connectors - Component diagram 21 950 Bu tow behind (*)	630
Wire connectors - Component diagram 22 350 Bu tow behind (*)	257
Wire connectors - Component diagram 22 350 Bu tow between (*)	304
Wire connectors - Component diagram 22 435 Bu and 460 Bu tow behind (*)	353
Wire connectors - Component diagram 22 435 Bu and 460 Bu tow between (*)	411
Wire connectors - Component diagram 22 555 Bu and 580 Bu tow behind (*)	467
Wire connectors - Component diagram 22 555 Bu and 580 Bu tow between (*)	526
Wire connectors - Component diagram 22 760 Bu tow behind (*)	581
Wire connectors - Component diagram 22 950 Bu tow behind (*)	636
Wire connectors - Component diagram 23 350 Bu tow behind (*)	259
Wire connectors - Component diagram 23 350 Bu tow between (*)	306
Wire connectors - Component diagram 23 435 Bu and 460 Bu tow behind (*)	355
Wire connectors - Component diagram 23 435 Bu and 460 Bu tow between (*)	413
Wire connectors - Component diagram 23 555 Bu and 580 Bu tow behind (*)	469
Wire connectors - Component diagram 23 555 Bu and 580 Bu tow between (*)	528
Wire connectors - Component diagram 23 760 Bu tow behind (*)	583
Wire connectors - Component diagram 23 950 Bu tow behind (*)	638
Wire connectors - Component diagram 23 Pressure sensor	734
Wire connectors - Component diagram 24 350 Bu tow behind (*)	261
Wire connectors - Component diagram 24 350 Bu tow between (*)	308
Wire connectors - Component diagram 24 435 Bu and 460 Bu tow behind (*)	358
Wire connectors - Component diagram 24 435 Bu and 460 Bu tow between (*)	416
Wire connectors - Component diagram 24 555 Bu and 580 Bu tow behind (*)	472
Wire connectors - Component diagram 24 555 Bu and 580 Bu tow between (*)	531
Wire connectors - Component diagram 24 760 Bu tow behind (*)	586
Wire connectors - Component diagram 24 950 Bu tow behind (*)	641
Wire connectors - Component diagram 25 350 Bu tow behind (*)	264

(\*) See content for specific models



Seeding control system	
Inspect .....	62
Seeding tank sensors	
Adjust tank full sensor (auxiliary tank) .....	65
Cleaning tank low, tank level, and tank full sensors .....	66
Electrical test for tank and meter pressure sensors .....	67
Cleaning tank pressure sensors .....	69
Cleaning meter pressure sensors .....	74
Seeding fan speed sensor	
Clearance .....	78
Seeding wheel speed sensor	
Clearance .....	79
Flow monitoring	
Check .....	80

## DIAGNOSTIC

Flow monitoring	
Troubleshooting (*) .....	81
Problem solving The console recognizes the flow gateway but not the flow remotes .....	82

(\*) See content for specific models

---

## Flow monitoring - Dynamic description

P Series Air Carts	
--------------------	--

The flow monitoring system is intended to inform the operator that product is not flowing through the secondary distribution hoses.

The flow system is available in 2 configurations. It can be a Basic Flow System which consists of a Flow Gateway and 1 to 24 sensors. It can monitor up to 24 secondary distribution hoses.

An Expanded Flow System consists of one Flow Gateway plus 1 to 15 additional Flow Remotes. Each remote can have for 1 to 24 sensors attached to it. This system can monitor up to 384 secondary distribution hoses.

**NOTICE:** *The Flow Monitoring Assembly Manual gives step-by-step instructions for setting up the flow system. Many problems may be avoided if the instructions are followed carefully.*

The operation of the flow system is mainly automatic. However, the following points are helpful in understanding the operation of the system.

- Flow sensors are assigned to shoots. Meters are then assigned to shoots.
- The sensors work by determining if the flow sensor has detected material passing by. Each time a flow sensor detects the passage of material it sends a signal to the ECU.
- A certain amount of product passing the sensor and creating a signal is necessary to detect a flow. The sensitivity can be adjusted to suit different products and application situations.
- All leads that do not have a sensor attached, must have a dust cap installed.


**NOTE:** *The flow system may not work satisfactorily if the product flow rate is less than the equivalent of canola at 3 kg/ha at 5 km/h ( 3 lbs/ac at 3 mph).*

### ALARMS

**NOTE:** *Alarms may not occur if flow Electronic Control Units (ECUs) are not assigned correctly. Always check setup upon initial operation. If a change to the distribution system is made, be sure to change the flow configuration accordingly.*

When the meter is turned on, allow an amount of time to pass to let product travel from the meter to the sensors. If inadequate flow is detected after the time delay, an alarm will sound.

- If there is an inadequate flow alarm and you check the flow status, any ECU with no flow will be in red. Select the ECU to see which flow sensor is reporting inadequate flow. From this information it is possible to identify the specific secondary distribution hoses to check for blockage in the hose or other obstructions. Refer to the Flow Monitoring Operator's manual for more information.
- A no flow alarm could have several other causes. Check for an empty or near empty air cart tank. The ground opener may have obstructions. There may be an air leak in either the primary or secondary distribution system (e.g., hose came off). There could also be an obstruction or other problem with the primary (air cart) manifold or in the headers.
- If the air cart metering system is turned off, all sensors will report no flow.




105179S 3

Flow Remote Harness, 9 Input with RS232

Position	Circuit Description
L1	SENSOR 9 GROUND
L2	SENSOR 8 GROUND
L3	SENSOR 8 POWER
M1	SENSOR 9 POWER
M2	SENSOR 7 GROUND
M3	SENSOR 7 POWER
N1	SENSOR 6 GROUND
N2	SENSOR 5 GROUND
N3	SENSOR 5 POWER
P1	SENSOR 6 POWER
P2	SENSOR 4 GROUND
P3	SENSOR 4 POWER
R1	SENSOR 2 GROUND
R2	SENSOR 3 GROUND
R3	SENSOR 3 POWER
S1	SENSOR 2 POWER
S2	SENSOR 1 GROUND
S3	SENSOR 2 POWER
T1	RS232_TX
T2	RS232_RX
T3	ECU_GND
W1	SW12V_GND
W2	FLOW_GND
W3	ECU_PWR
X1	
X2	FLOW_PWR
X3	CAN_L_IMPL
Y1	CAN_H_FLOW
Y2	CAN_L_FLOW
Y3	CAN_H_IMPL

**P11 - Connector to RS232**




DEU\_DTM06-3S 5

Position	Circuit Description
1	SWITCH 12 VOLT GROUND
2	RS_232TX
3	RS_232RX

6. Check the inside of the sensor mount tube for debris build-up and clean if required.
7. If the sensor port cannot be cleaned, replace the sensor. The replacement sensors are supplied with a filter.

### Clean sensor (filter)

8. The new sensor has microscopic pores that block dust and water but allow air to pass through. The filter is a gray/black disk on the face of the sensor.
9. Carefully remove any debris from the filter **(1)**. Be sure not to damage or remove the filter.



SAIL17SE00146AA 5

**NOTICE:** Do not remove the filter from the sensor.

10. The filter is a slippery material so it will resist debris sticking to it. If cleaning is necessary:
  - A. Do not use metal tools to scrape debris off of the filter or face of the sensor.
  - B. Do not use high pressure air or water since this could damage the filter or damage the sensing element from overpressure
  - C. Use tap water and a clean cloth or tissue to clean the face of the filter.
  - D. Do not touch the center of the filter with greasy/oily hands as this may plug the pores in the filter.

## Seeding calibration switch - Dynamic description

The calibration toggle switches on the left side of the air cart are used to control which tanks will meter out product when the calibration push button is pressed.

- The positions of these toggle switches are ignored during seeding so they can be left on or off when calibration is complete.
- Priming of the meters can be done via the prime button on the display in the tractor or via the calibration push button.
- For priming from the display the toggle switch positions are ignored and the tank selection on the display is used to determine which tanks to prime.
- For priming via the calibration push button the toggle switches determine which tanks to prime.



## **Electrical systems - 55**

### **Auger - 545**

**P2350, P3440, P3550 , P4460, P4580, P4760, P4950**

## One or more auger/conveyor control functions not working

**NOTICE:** To avoid unexpected movement of the auger/conveyor during this test turn off power to the RF receiver by moving the transport lock arm to the lock position.

1. Press the green "ON" button on the remote. Then press each function button (buttons 1 to 10) one at a time. If the red LED on the remote lights continuously while each button is being held then proceed to the next step.


A. If the LED on the remote lights for some buttons but fails to light for one or more buttons the remote may be faulty and should be replaced.

**NOTE:** You will have to register the new remote with the RF receiver before it will be able to control the auger/conveyor. See **Auger - Basic instructions (77.100)**.

B. If the LED light on the remote is dim and/or fades out when a button is held the batteries may be weak. Replace batteries with four fresh alkaline AAA batteries making sure the batteries are installed with the correct orientation. Inspect battery holder for corrosion. Clean if necessary. Make sure holder is inserted into the remote with the correct orientation.

2. For the following steps the hydraulics, RF receiver and remote need to be on so engage the hydraulics, move the transport lock arm to the unlock position, and press the green "ON" button on the remote before proceeding.


**Connector X-004 - Radar**



RCIL06\_247724A1 4  
**247724A1**

PIN NUMBER	CIRCUIT ID	CIRCUIT REFERENCE	ELECTRICAL SCHEMATIC FRAME
1	PLUG	OPEN	N/A
2	59B LG-0.8	SIG	<b>SHEET 05</b>
3	PLUG	OPEN	N/A
4	PLUG	OPEN	N/A

**Connector X-005 - CAN BUS Terminator**



256348A1 5  
**256348A1**

PIN NUMBER	CIRCUIT ID	CIRCUIT REFERENCE	ELECTRICAL SCHEMATIC FRAME
A	23B R-0.8	ECU_PWR	<b>SHEET 05</b>
B	46B R-0.8	TBC_PWR	<b>SHEET 06</b>
C	20B B-0.8	ECU_GND	<b>SHEET 05</b>
D	48B B-0.8	TBC_RTN	<b>SHEET 06</b>
E	47B Y-0.8	CAN_H	<b>SHEET 06</b>
F	49B DG-0.8	CAN_L	<b>SHEET 06</b>

# Contents

---

## Electrical systems - 55

### FAULT CODES - DTC

#### DIAGNOSTIC

401TMM-07 - Tank T - Motor MM - Motor Stall detected. Check meter cartridge for obstruction. [Air Cart UCM] .....	8
402TMM-04 - Tank T - Motor MM Motor Voltage Below Normal [Air Cart UCM].....	10
403TMM-07 - Tank T - Motor MM - Motor detected internal failure. Cycle power, replace motor if problem persists. [Air Cart UCM] .....	12
404TMM-07 - Tank T - Motor MM - Motor detected overtemp and shut down. Check meter cartridge for binding. [Air Cart UCM].....	13
405TMM-07 - Tank T - Motor MM - Motor having difficulty turning. Check meter cartridge for obstruction. [Air Cart UCM] .....	15
406000-12 - All Meter Motors - Lost communication with all motors. Check air cart harness and UCM connections. [Air Cart UCM].....	17
40600T-12 - Tank T Meter Motors - Lost communication with all motors on tank. Check motor harness connections. [Air Cart UCM].....	19
406TMM-12 - Tank T - Motor MM - Lost communication with motor. Check motor and connections. [Air Cart UCM] .....	22
410000-11 - Brake ECU not detected. AIR CART BRAKES MAY NOT BE WORKING! [Air Cart UCM]	24
410001-11 - Brake ECU reporting system failure. AIR CART BRAKES MAY NOT BE WORKING! [Air Cart UCM] .....	27
410002-11 - Brake ECU did not respond to tractor brake pedal. AIR CART BRAKES MAY NOT BE WORKING! [Air Cart UCM].....	28
520200-03 - 5V Sensor Power (+5V_EXT), Voltage above normal, or shorted to high source [Air Cart UCM] .....	30
520200-04 - 5V Sensor Power (+5V_EXT), Voltage below normal, or shorted to low source [Air Cart UCM] .....	31
520208-00 - Wheel Ground Speed Sensor, Data valid, but above normal operating range - most severe level [Air Cart UCM].....	33
520208-03 - Wheel Ground Speed Sensor, Voltage above normal, or shorted to high source [Air Cart UCM] .....	34
520208-05 - Wheel Ground Speed Sensor, Current below normal, or open circuit [Air Cart UCM].....	35
520208-08 - Wheel Ground Speed Sensor, Abnormal frequency, pulse width, or period [Air Cart UCM]	37
520209-00 - GPS Ground Speed Sensor, Data valid but above normal operation range - most severe level [Air Cart UCM] .....	39
520209-03 - GPS Ground Speed Sensor, Voltage above normal, or shorted to high source [Air Cart UCM] .....	40
520209-05 - GPS Ground Speed Sensor, Current below normal, or open circuit [Air Cart UCM] .....	41
520209-08 - GPS Ground Speed Sensor, Abnormal frequency, pulse width, or period [Air Cart UCM] ..	43

## 40600T-12 - Tank T Meter Motors - Lost communication with all motors on tank. Check motor harness connections.

### Control Module: Air Cart UCM

#### Context:

The UCM lost communications with all motors on the tank indicated by the fault. This procedure covers codes: 406001-12, 406002-12, 406003-12, 406004-12.

#### Cause:

Bad connection or open circuit.

#### Possible failure modes:

1. Bad connection or open circuit in LIN bus wiring.
2. Bad connection or open circuit on LIN\_PWR, MPWR, or MGND wiring.

#### Solution:

1. Perform the electrical connector check procedure on the TANK x MOTORS connector, where 'x' is the tank indicated by the fault code.

Inspect wires and contacts at both mating ends of all connectors referenced by the diagnostic procedures. Repair all contacts that are bent, broken, or improperly seated in their connector housing. Clean dirty or corroded contacts.

Ensure that connector mating ends are securely mated back together.

Cycle power and check for active fault

A. Fault still present, go to step 2.

B. Fault not present, return unit to field operation.

2. Disconnect the TANK x MOTORS connector, where 'x' is the tank indicated by the fault code, and measure the following voltages:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
MPWR_x (TANK x MOTORS, cavity D)	UCM chassis	> 22 V	Normal
		≤ 22 V	Check for bad/intermittent connection or open circuit on MPWR_x wire in main harness.
LIN_PWR (TANK x MOTORS, cavity C)	UCM chassis	Battery voltage	Normal
		< Battery voltage	Check for bad/intermittent connection or open circuit on LIN_PWR wire in main harness.
LIN (TANK x MOTORS, cavity B)	UCM chassis	~ Battery voltage	Normal
		< Battery voltage	Check for bad/intermittent connection or open circuit on LIN wire in main harness.

A. Measurements normal or fault still present after repair made. Go to step 3.

B. Fault not present, return unit to field operation.

3. Disconnect the TANK x MOTORS connector, where 'x' is the tank indicated by the fault code, and measure the following voltage:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
+12V_SEN (GROUND SPD REAR, cavity 1)	SEN_DGND (GROUND SPD REAR, cavity 3)	Battery voltage	Normal
		< Battery voltage	Check for open circuit or high resistance ( > <b>10 Ω</b> ) on +12V_SEN wire.

- A. Measurement normal or fault still present after repair made. Go to step **4**.
- B. Fault not present, return unit to field operation.
- 4. Replace the sensor indicated by the fault with a known good sensor. Cycle power.
  - A. Fault still present, reinstall original sensor, go to step **5**.
  - B. Fault not present, return unit to field operation.
- 5. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
  - A. Fault still present, reinstall original UCM, submit a concern through ASIST.
  - B. Fault not present, return unit to field operation.

## 520211-00 - Mechanical Work Switch, Data valid but above normal operation range - most severe level

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally high voltage on its work switch signal input.

#### Cause:

Short to high source, or defective component.

#### Possible failure modes:

1. High short on signal wiring between device and UCM.
2. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 2.
- B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Disconnect the connector at the sensor indicated by the fault code. Measure the following voltages on the implement harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
WORK_SW (WORK SWITCH, cavity 2)	SEN_DGND (WORK SWITCH, cavity 1)	~8 V	Normal
		> 8.5 V	Check for high short on WORK_SW wire.

- A. Measurement normal or fault still present after repair made. Go to step 3.
- B. Fault not present, return unit to field operation.
3. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
  - A. Fault still present, reinstall original UCM, submit a concern through ASIST
  - B. Fault not present, return unit to field operation

## 520220-05 - Tank 3 Low Product Sensor, Current below normal, or open circuit

### Control Module: Air Cart UCM

#### Context:

The UCM detected an open circuit condition on its tank low sensor input.

#### Cause:

Bad connection or open circuit, or defective component.

#### Possible failure modes:

1. Bad connection or open circuit in signal wiring between device and UCM.
2. Bad connection or open circuit in power wiring to device.
3. Faulty device.
4. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

A. Fault still present, go to step 2.

B. Fault not present, return unit to field operation and monitor for recurring fault.

2. Perform the electrical connector check procedure on the connector at the sensor, on the BIN 3 SENSORS bulkhead connector mounted in the wall of the tank, and on the UCM 3B connector.

Inspect wires and contacts at both mating ends of all connectors referenced by the diagnostic procedures. Repair all contacts that are bent, broken, or improperly seated in their connector housing. Clean dirty or corroded contacts.

Ensure that connector mating ends are securely mated back together.

Cycle power and check for active fault

A. Fault still present, go to step 3.

B. Fault not present, return unit to field operation.

3. Disconnect the BIN 3 SENSORS bulkhead connector mounted in the wall of the tank. Measure the following voltages on the implement harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
LOW_BIN3 (BIN 3 SENSORS, cavity A)	SEN_DGND (BIN 3 SENSORS, cavity D)	3 – 5 V	Normal
		V < 3 V	Check for open circuit or high resistance ( > 10 Ω ) on LOW_BIN3 wire.

## 520223-04 - Tank 3 Depth Sensor, Voltage below normal, or shorted to low source

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally low voltage on its tank depth sensor signal input.

#### Cause:

Short to low source, or defective component.

#### Possible failure modes:

1. Low short on signal wiring between device and UCM.
2. Faulty device.
3. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 2.
- B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Disconnect the BIN 3 SENSORS bulkhead connector mounted in the wall of the tank. Measure the following voltages on the implement harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
BIN_LEVEL3 (BIN 3 SENSORS, cavity C)	SEN_DGND (BIN 3 SENSORS, cavity D)	2 – 5 V	Normal
		< 2 V	Check for low short on BIN_LEVEL3.

- A. Measurement normal or fault still present after repair made. Go to step 3.
- B. Fault not present, return unit to field operation.
3. Replace the sensor indicated by the fault with a known good sensor. Cycle power.
  - A. Fault still present, reinstall original sensor, go to step 4.
  - B. Fault not present, return unit to field operation.
4. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
  - A. Fault still present, reinstall original UCM, submit a concern through ASIST.
  - B. Fault not present, return unit to field operation.

- A. Replacement fuse blows within three minutes. The problem is in the MPWR wiring in the motor harness. Repair or replace the motor harness. Go to step 1.
- B. Replacement fuse does not blow within three minutes. Go to step 5.
5. Reconnect motors one at a time. Wait for three minutes and check the fuse after each motor is reconnected.
  - A. Fuse blows within three minutes of reconnecting a motor. Replace motor with a known good motor. Replace fuse. Repeat step 5 for remaining motors.
  - B. Fuse does not blow after all motors have been reconnected. Return unit to field operation and monitor for recurring fault
6. Turn on the calibration toggle switch for the tank indicated by the fault code, and turn off all other calibration toggle switches. Use the calibration pushbutton on the side of the air cart to turn the meters for at least three minutes.
  - A. Fuse blows during meter motor operation. Go to step 7.
  - B. Fuse does not blow during meter motor operation. Go to step 10.
7. Remove all meter cartridges, check for obstructions.
  - A. Obstructions found and cleared. Go to step 8.
  - B. No obstructions found. Go to step 9.
8. Use the calibration pushbutton on the side of the air cart to turn the meters for at least three minutes.
  - A. Fuse blows during meter motor operation. Go to step 9
  - B. Fuse does not blow during meter motor operation. Return unit to field operation and monitor for recurring fault.
9. Disconnect all motors. Reconnect motors one at a time. Use the calibration pushbutton on the side of the air cart to turn the connected meter motors for at least three minutes.
  - A. Fuse blows within three minutes of operating a reconnected motor. Replace motor with a known good motor. Replace fuse. Repeat step 9 for remaining motors.
  - B. Fuse does not blow after all motors have been reconnected and operated. Return unit to field operation and monitor for recurring fault.
10. Check for intermittent shorts in the motor pigtail wires, motor harness, and main harness between the motor harness connector and the fuse box by flexing along the length of these pigtails/harnesses.
  - A. Fuse blows or wiring damage found during flex test. Repair or replace affected harness. Return unit to field operation and monitor for recurring fault
  - B. Fuse does not blow and no wiring damage found. Go to step 11.
11. The problem can likely only be exposed under field operating conditions. It may only be seen when the meters are under load (i.e. metering product) and/or operating at a high RPM, or when vibration is being induced while the air cart is moving. Suggested actions include:
  - A. While stationary, meter product at the application rate that was being used when the problem first occurred. Attempt to isolate a faulty motor if the problem is reproduced.
  - B. Run meters without product at a high RPM. Attempt to isolate a faulty motor if the problem is reproduced.
  - C. Drive over terrain similar to field conditions with the meters running with or without product. Check for intermittent shorts or attempt to isolate a faulty motor if the problem is reproduced.
  - D. Swap motors from the affected tank with a tank that is not having issues. Note that system power must be cycled after motors are moved in order for their positions to be reassigned. If the problem moves with the motors, move individual motors until a faulty motor is isolated. If the problem does not move with the motors, check for a harness issue.
  - E. Submit a concern through ASIST.

- B. Fault not present, return unit to field operation.
- 4. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
  - A. Fault still present, reinstall original UCM, submit a concern through ASIST.
  - B. Fault not present, return unit to field operation.

## 520245-03 - ECU\_PWR (12VB), Voltage above normal, or shorted to high source

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally high voltage on its ECU\_PWR (12VB) signal.

#### Cause:

Short to high source, or defective component.

#### Possible failure modes:

1. High short on power wire.
2. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present. Go to step 2.
  - B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Disconnect connector 1A from the UCM and measure the following voltage with the tractor power on:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
ECU_PWR (12VB) (UCM 1A, cavity 26)	UCM chassis	<= Battery	Normal
		> Battery	Look for high short on ECU_PWR (12VB) wire.

- A. Measurement normal or fault still present after repair made. Go to step 3.
  - B. Fault not present, return unit to field operation.
3. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
    - A. Fault still present, reinstall original UCM, submit a concern through ASIST.
    - B. Fault not present, return unit to field operation.

## 520250-04 - 12V PWR from Tractor Voltage below normal. Check connections, UCM POWER relay, UCM HSD\_PWR fuse, and tractor fuse

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally low voltage on its 12V PWR ("noisy power") supply from the tractor.

#### Cause:

Low battery voltage, blown fuse, bad connection or open circuit, short to low source, excessive current draw, or defective component.

#### Possible failure modes:

1. Low tractor battery voltage, tractor alternator not running or not charging.
2. Blown PWR fuse on tractor or air cart.
3. Bad connection or open circuit in PWR wiring.
4. Bad connection or open circuit in GND wiring.
5. Low short on PWR.
6. Bad connection to UCM power relay, or relay defective.
7. Excessive current draw from other device connected to PWR on air cart and/or seed tool.
8. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 2.
  - B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Disconnect the IBBC (Implement Bus Breakaway Connector) at the front of the air cart. Measure the following voltages on the tractor/seed tool connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
PWR (cavity 3)	GND (cavity 1)	11 – 16 V	Normal
		~0 V	Check tractor fuse, relay, PWR wiring, and GND wiring. Check seed tool wiring if tow-behind cart with seed tool connected.
		< 11 V	Check for discharged/failed tractor batteries, failed tractor alternator, or low short on PWR.

- A. Measurement normal or fault still present after repair made. Go to step 3.
- B. Fault not present, return unit to field operation.

## 520271-03 - Tank 1 Cal Toggle Switch, Voltage above normal, or shorted to high source

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally high voltage on its tank calibration toggle switch signal input.

#### Cause:

Bad connection while switch on, short to high source, or defective component.

#### Possible failure modes:

1. Bad connection in signal wiring between device and UCM.
2. Bad connection in ground wiring to device.
3. High short on signal wiring between device and UCM.
4. Faulty device.
5. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step2.
  - B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Perform the electrical connector check procedure on the connector for the indicated motor.
 

Inspect wires and contacts at both mating ends of all connectors referenced by the diagnostic procedures. Repair all contacts that are bent, broken, or improperly seated in their connector housing. Clean dirty or corroded contacts.

Ensure that connector mating ends are securely mated back together.

Cycle power and check for active fault

    - A. Fault still present, go to step 3.
    - B. Fault not present, return unit to field operation.
  3. Disconnect the connector at the switch indicated by the fault code. Measure the following voltages on the harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
CAL_TANK1 (CAL TANK 1, cavity A)	SEN_DGND (CAL TANK 1, cavity B)	~8 V	Normal
		< 7.5 V	Check for high resistance ( > 10 Ω ) on CAL_TANK1 wire to UCM, or on SEN_DGND to frame ground.
		> 8.5 V	Check for high short on CAL_TANK1 wire.

## 520302-04 - Tank 2 Pressure Sensor, Voltage below normal, or shorted to low source

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally low voltage on the indicated tank pressure sensor signal input.

#### Cause:

Short to low source, open circuit, or defective component.

#### Possible failure modes:

1. Low short or open circuit on signal wiring between device and UCM.
2. Low short or open circuit on power wiring to device.
3. Faulty device.
4. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 2.
- B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Disconnect the connector at the sensor indicated by the fault code. Check the resistance between TANK\_PRES and SEN\_AGND on the implement harness connector.
  - A. Resistance is greater than **20000 Ω**, go to the step 3.
  - B. Resistance is less than **20000 Ω**. Check for low short on TANK\_PRES between device and UCM. If fault is still present, go to step 3.
3. Disconnect the connector at the sensor indicated by the fault code. Measure the following voltages on the harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
+5V_EXT (TANK PRESSURE, cavity 1)	Frame ground point	5 V	Normal
		<5 V	Check for low short or open circuit on +5V_EXT wire.

- A. Measurement normal or fault still present after repair made. Go to step 4.
- B. Fault not present, return unit to field operation.
4. Replace the sensor with a known good sensor. Cycle power.
  - A. Fault still present, reinstall original sensor, go to step 5.

- B. Fault not present, return unit to field operation.
- 5. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
  - A. Fault still present, reinstall original UCM, submit a concern through ASIST.
  - B. Fault not present, return unit to field operation.

- A. Fault still present, reinstall original UCM, submit a concern through ASIST.
- B. Fault not present, return unit to field operation.

## 521221-03 - Aux Tank Low Product Sensor, Voltage above normal, or shorted to high source

### Control Module: Air Cart UCM

#### Context:

The UCM detected an abnormally high voltage on its tank low sensor signal input.

#### Cause:

Bad connection or open circuit, short to high source, or defective component.

#### Possible failure modes:

1. Bad connection or open circuit in ground wiring to device.
2. High short on signal wiring between device and UCM.
3. Faulty device.
4. Faulty UCM hardware or software.

#### Solution:

1. Determine if the fault code is still active:

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 2.
- B. Fault not present, return unit to field operation and monitor for recurring fault.
2. Perform the electrical connector check on the connector at the sensor, at the AUX BIN SENSORS bulkhead connector mounted in the wall of the tank, and at the AUX TANK SENSORS connector on the main harness
 

Inspect wires and contacts at both mating ends of all connectors referenced by the diagnostic procedures. Repair all contacts that are bent, broken, or improperly seated in their connector housing. Clean dirty or corroded contacts.

Ensure that connector mating ends are securely mated back together.

Cycle power and check for active fault

  - A. Fault still present, go to step 3.
  - B. Fault not present, return unit to field operation.
3. Disconnect the AUX BIN SENSORS bulkhead connector mounted in the wall of the tank. Measure the following voltages on the implement harness connector:

Measure with Voltmeter		Measured Voltage	Interpretation and Action
Positive lead	Negative lead		
LOW_BIN (AUX BIN SENSORS, cavity A)	SEN_DGND (AUX SENSORS, cavity D)	3 – 5 V	Normal
		< 3 V	Check for open circuit or high resistance ( > 10 Ω ) on SEN_DGND wire to frame ground.
		> 5 V	Check for high short on LOW_BIN wire.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present, go to step 4.
  - B. Fault not present. Check for low shorts on the tank 1 in-tank harness. Check for faulty tank 1 sensor.
4. Disconnect the bulkhead connectors for the remaining tanks one at a time, performing the active fault check after each disconnection.

Cycle system power or reset the UCM.

Select Main Menu > Diagnostics tab > Faults and check both ACTIVE and INACTIVE faults. See **Cab seeding controls - Check faults (55.517)**.

Review: Fault Count, First Time, Latest Time

Also view the voltage/current/frequency bar graphs for the faulted signal as measured by the UCM. Select Main Menu > Diagnostics tab > Signal Monitor and choose the faulted signal. See **Cab seeding controls - Check signal monitor (55.517)**.

- A. Fault still present after all bulkhead connectors disconnected, go to step 5.
  - B. Fault still present after all bulkhead connectors disconnected, go to next step.
5. Perform the UCM troubleshooting procedure. See **Controller Area Network (CAN) data bus - Problem solving UCM (55.640)**.
- A. Fault still present, reinstall original UCM, submit a concern through ASIST.
  - B. Fault not present, return unit to field operation.


# Contents

---

## Metering system - 61


[61.904] Product metering .....	61.1
---------------------------------	------

3. Once the drive side control shaft has been adjusted such that the connecting link indicator arrow is inside the closed indicator target on the motor side, adjust the cartridge side to the same exposed length (**A**) of threaded rod for equal positioning.




SAIS15SE01252AA 4

4. Check all meter modules to ensure the connecting link indicator arrow is inside the closed indicator target on the motor side of the meter housing.



SAIS15SE01253AA 5

5. Tighten the threaded rod until the meter modules meet the above criteria.
6. Set the top position of the clean out door on the meter banks to the open position.



SAVM15SE01254AA 6

**NOTE:** Inspect all of the meter modules to see if the connecting link indicator arrow is inside the open indicator target on the meter housing motor side.


# Contents

---


## Seeding - 77

[77.100] Product handling and delivery drive system .....	77.1
[77.101] Seeding fan system .....	77.2
[77.150] Auxiliary tank fill system.....	77.3
[77.904] Air distribution system.....	77.4

7. Set fastener strip on a solid flat surface. Strike top-side of fasteners and staples with firm hammer blows. Move back and forth across fastener strip until all staples are clinched.



SAIL16SE00107AA 3



SAIL16SE00108AA 4

8. Repeat steps 3 to 7 for the other end of the belt.


## Single fan - Remove

### ⚠ CAUTION

**Heavy parts!**  
**Support designated component(s) with adequate lifting equipment.**  
**Failure to comply could result in minor or moderate injury.**


C0166A

1. Support the fan with a suitable lifting device.
2. Remove the three hydraulic hoses (1), (2), and (3) from the hydraulic fan motor (4).
3. Cap all hydraulic hoses and motor ports to prevent entry of foreign material.



SAVM16SE00419AA 1


4. Disconnect the fan sensor wiring harness connector (1).



SAIL16SE00042AA 2

5. Remove the six M10 x 40 flange bolts (2), washers (2) and the six M10 nuts (3) from the fan plenum.

**NOTE:** Two of the flange bolts and two of the nuts are not visible in this illustration.




SAVM17SE00132AA 3

## Air distribution system - Overview plenum and meter run configuration

The illustration shows a double shoot configuration with eight primary runs. **(Tn)** indicates the top run where **(T)** is top and **(n)** is the number of the run. **(Bn)** indicates the bottom run where **(B)** is bottom and **(n)** is the number of the run.

Table 1 shows which air cart runs match to the plenum ports. Runs are numbered from the rear of the cart in the direction of travel.



SAVM15SE00997BA 1

Table 1

### Blanked and active runs

4 run	
Plenum outlet	Meter run
B1	L3
B2	X
B3	X
B4	L2
B5	L4
B6	X
B7	X
B8	L1
T1	U3
T2	X
T3	X
T4	U2
T5	U4
T6	X
T7	X
T8	U1
5 run	
Plenum outlet	Meter run
B1	L4

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL