

SW651 Series

SHOP MANUAL

SAKAI®

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2-4-4. Frame (center pin)2-043
2-4-5. Steering cylinder2-044
2-4-6. Steering circuit2-045

3. Brake System

3-1. Brake system (brake pedal)2-046
3-2. Description and operation of brake circuit2-047


4. Sprinkler

4-1. Sprinkler piping2-048

5. Electric System

5-1. Layout of panel and relays2-049
5-2. Location of electric components2-050
5-3. Electric wiring diagram2-051

2-1-4. Hydraulic circuit (SW651B)



2-2-10. Description and operation of propulsion system

- ◆ See the hydraulic circuit on pages 2-020 to 2-021.

Description of propulsion system

Made up of propulsion pump (3), front propulsion motor (10), front drum (12), rear propulsion motor (11), rear drum (13) high/low speed switching solenoid valve (16) and brake release solenoid valve (17).

Basic function of propulsion pump and propulsion motor

- Propulsion pump

A piston pump is used which allows adjusting the travel speed by varying inclination of the swash plate to change the piston stroke, and switching forward-reverse travel by reversing the discharge port with the control of servo valve.

- Propulsion motor

A piston motor is used which allows switching high/low speed travel by varying displacement volume of the motor (or varying piston stroke).

Operation (It is assumed that the machine is traveling forward.)

★ Parking brake has been released.

- ◆ Assemblies such as pump assembly and motor assembly are indicated by numbers such as (1) and (2), while component parts in the assemblies are shown by small letters such as (a) and (b).
- Both front and rear motors are hydraulically connected in parallel.
- When forward-reverse lever (F-R lever) is shifted to "Forward", forward-reverse valve of the pump functions to allow the servo piston (b) to tilt the swash plate of the pump in the "forward" travel direction.
- This allows the oil to discharge from the propulsion pump to forward travel circuit (port A) and the oil is discharged and divided at the pump outlet to enter in the "forward travel port" of propulsion motor.

★ Port B is assigned for front motor and port B is for rear motor.

- The divided oil fed into the forward travel ports of the motor drives the motor, flows out of the port on opposite side, and merges at the inlet of the pump returning to suction port of the pump.

NOTE: Because the propulsion circuit is a closed loop circuit (HST), the "discharge port" differs from forward to reverse travel.

Release of parking brake

- When the brake release solenoid valve (17) is energized, the valve actuates allowing the oil in the charge circuit to discharge out of the valve to flow into the brake release port of the propulsion motor.
- The oil entered in the motor moves the brake piston to release the brake.


On normal vibration

When the shaft rotates counter-clockwise viewed from the vibrator motor:


- Operation of [① through ④] in the figure on the right will be carried out at a single revolution of the shaft.
- Although the movable weight (2) shifts to the opposite side of the fixed weight (1) and mass of the fixed weight decreases, total mass increases as 2 sets of vibratory shaft rotate in the same direction by which vibratory force is generated in all circumference.

★ Vibration is generated in all circumference by repetition of operation [① through ④] illustrated in the figure.


Fixed: Fixed weight
 Movable: Movable weight
 Thick: Thicker side of weight
 Thin: Thinner side of weight




SW6512031



SW6512032



SW6512033




SW6512034

Steering wheel rotating speed and flow control

* In the steering mechanism, flow rate of oil into the steering cylinders depends on the rotating speed of the steering wheel.

- The steering valve (Orbitrol) controls oil flow by varying the angular displacement. While the steering wheel is being rotated, sleeve (2) chases the rotation of spool (1) to close the oil ports.
- With increasing speed of the steering wheel rotation, the angular displacement between the spool and sleeve increases. Flow increases.



Pump flow and force to operate the steering wheel

- With sufficient pump flow, force required to operate the steering wheel is equal to sliding resistance of sleeve (2) and rotor. The steering wheel is very light to rotate.
- If the pump flow is insufficient, the angular displacement between the spool and sleeve is at maximum. In spite of wide opening of oil ports, flow from the pump to the rotor is small. The rotor rotates slowly.
- This makes spool rotating speed greater than rotor speed to provide maximum angular displacement. The spool rotates the rotor via the cross pin and drive shaft. At this time, the rotor acts as a hydraulic pump. The steering wheel is heavy to rotate.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

INSPECTION & ADJUSTMENT

2-8. Adjustment of F-R lever/speed shift lever linkage

★ When the F-R lever linkage has been renewed (or reconnected) or if the F-R lever fails to move smoothly, adjust as described below:

1. Adjustment

★ Hydraulic oil temperature:
 $50 \pm 5^\circ\text{C}$ ($122 \pm 41^\circ\text{F}$)

★ Since the levers controlling both forward/reverse and gear change are positioned by notch balls, inspect the mounting dimensions of the cable and the stroke of the control lever on the pump.

1) Fit the cable (3) to adjust mounting distance of the section (4) to be specified.

★ Specified distance of section (4):
190mm (74.8in.)



2) Put the control lever (5) at its neutral position to fit the cable (3).

3) Check that the stroke of control lever (5) on the pump is as specified.

★ Maximum stroke of lever (the same applies to forward and reverse):

a: 40°

b: 40°



	Possible cause	Remedy
	Starter faulty.	Renew.
	Wire harness connecting safety relay terminal C to starter terminal C is broken or poorly connected.	Repair or renew wire.
<p>7 YES</p>	Safety relay faulty.	Renew.
<p>6 YES</p> <p>Is stated voltage present at safety relay terminal N that carries wire BrW? • 20~28V • Turn starter switch to START.</p>	Wire harness of color BY connecting safety relay switch to interlock relay terminal 3 is broken or poorly connected.	Repair or renew wire.
<p>7 NO</p> <p>8 YES</p>	To "A" on page 4-204.	
<p>8 NO</p> <p>Is stated voltage present at safety relay terminal 3 that carries wire BY? • 20~28V • Turn starter switch to START.</p>	Alternator faulty	Repair or renew wire.
<p>6 NO</p>	Wire harness of color BY connecting safety relay terminal B to starter terminal B is broken or poorly connected.	Repair or renew wire.
	Battery relay faulty.	Renew.
	Wire harness connecting battery relay power IN terminal to battery (+) terminal is broken or poorly connected.	Repair or renew wire.
	To "D" on page 2-204.	
	Wire harness of color W connecting battery relay power IN terminal to starter switch terminal B is broken or poorly connected.	Repair or renew wire.
	Battery capacity lowered.	Charge or renew battery.


E-06 Horn does not sound

★First, check that fuse is not blown.

★The voltage measurement should be taken with the starter switch ON.

		Possible cause	Remedy
<p>1</p> <p>Is stated voltage present at horn terminal that carries wire GY?</p> <ul style="list-style-type: none"> • 20~28V • Switch on horn switch. 	<p>2 YES</p> <p>Is resistance of horn earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect wire from horn. 	Horn faulty.	Renew.
	<p>NO</p> <p>3</p> <p>Is stated voltage present at horn relay terminal 5 that carries wire GY?</p> <ul style="list-style-type: none"> • 20~28V • Switch on horn switch. 	Horn earth wire not connected or incorrectly connected.	Repair or renew wire.
	<p>YES</p> <p>4 YES</p> <p>Is stated voltage present at horn relay terminals 1 and 3 that carry wire Gy?</p> <ul style="list-style-type: none"> • 20~28V 	Wire GY from horn to horn relay terminal 5 not connected or incorrectly connected.	Repair or renew wire.
	<p>NO</p> <p>4 NO</p> <p>To "A" on this page.</p> <p>Wire Gy from fuse to horn relay terminals 1 and 3 not connected or incorrectly connected.</p>	Repair or renew wire.	
<p>A</p> <p>5</p> <p>Is stated voltage present at horn switch terminal that carries wire P?</p> <ul style="list-style-type: none"> • 20~28V • Switch OFF horn switch. 	<p>6 YES</p> <p>Is resistance between horn switch terminals normal?</p> <ul style="list-style-type: none"> • Lower than 1Ω when switched ON. • Disconnect wires from horn switch. 	Horn switch faulty.	Renew.
	<p>NO</p> <p>7 YES</p> <p>Is resistance of horn switch earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect wires from horn switch. 	Horn switch earth wire not connected or incorrectly connected.	Repair or renew wire.
	<p>YES</p> <p>8 YES</p> <p>Is stated voltage present at horn relay terminal 2 that carries wire P?</p> <ul style="list-style-type: none"> • 20~28V • Switch OFF horn switch. 	Horn switch faulty.	Renew.
	<p>NO</p> <p>8 NO</p> <p>Wire P from horn switch to horn relay terminal 2 not connected or incorrectly connected.</p> <p>Horn relay faulty.</p>	Repair or renew wire.	


Electric wiring diagram for mode E-06




SW6514006

E-10 High/low speed fails to be switched

- ★First, ensure that the fuse is not damaged.
- ★Measure the voltage with the starter switch ON.



Electric wiring diagram for mode E-10



SW6514009

		Possible cause	Remedy
		Lamp bulb damaged.	Renew.
		Monitor display faulty.	Renew monitor display.
<p>5 YES</p> <p>Is resistance of wire BrR from monitor display to check relay terminal 5 as specified?</p> <p>• Lower than 1 Ω</p> <p>• Disconnect each end of wire.</p>		Wire BrR from check relay terminal 3 to monitor display not connected or incorrectly connected.	Repair or renew wire.
<p>6 YES</p>		Check relay faulty.	Renew.
<p>NO</p> <p>7 YES</p> <p>Is resistance of check relay earth wire as specified?</p> <p>• Lower than 1 Ω</p> <p>• Disconnect wires from relay.</p>		Check relay earth wire not connected or incorrectly connected.	Repair or renew wire.
<p>NO</p> <p>8 YES</p> <p>Does starter run?</p> <p>• Turn starter switch to START.</p>		Wire RB from fuse to monitor display not connected or incorrectly connected.	Repair or renew wire.
		Fuse is burnt out.	Renew.
		Wire Lg from check relay terminal 1 to alternator terminal L not connected or incorrectly connected.	Repair or renew wire.
		Wire R from starter switch terminal ACC to check relay terminal 2 not connected or incorrectly connected.	Repair or renew wire.
		Starter switch faulty (between terminals A and ACC).	Renew.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL