

# Tigercat<sup>®</sup>

## X822C/LX822C/X830C/LX830C FELLER BUNCHER

# SERVICE MANUAL

SERIAL NUMBER 822\*2001 TO 822\*3000

SERIAL NUMBER 830\*2001 TO 830\*3000



ISSUE 1.0, DECEMBER 2015

**Tigercat Industries Inc.**

P.O. Box 637  
Brantford, Ontario  
Canada N3T 5P9

Tel: (519) 753-2000  
Fax: (519) 753-8272

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

VIBRATION AND NOISE LEVEL INSIDE CAB

<b>Noise Level Inside Cab dB(A)</b>				
As per Tigercat test ETR00047				
	Microphone direction:			
	Forward	Rear	Left	Right
<b>Driving max speed (High)</b>	77	76	77	76
<b>Driving max speed (Low)</b>	73	72	72	73
<b>Boom operation</b>	72	73	72	73

NOISELEVELS.PDF



Wear a suitable hearing protective device such as earmuffs or earplugs to protect against noise. Prolonged exposure to loud noise can cause impairment or loss of hearing. This machine exceeds 70 dB(A) in the cab and exceeds 85 dB(A) when servicing machine engine.

Check with your local Safety Commission to determine if hearing protection is required at these levels.



<b>Vibration Level - Whole-body</b>				
As per Tigercat test ETR007 & ISO 2631-1				
Weighted rms acceleration (m/s <sup>2</sup> )				
	Seat		Seat-back	Feet
	Health	Comfort		
<b>Driving max speed (High)</b>				
x-axis (back-to-chest)	0.2370		0.5630	0.4020
y-axis (right-to-left)	0.2310		0.3200	0.4200
z-axis (buttocks-to-head)	0.4660		0.2110	0.6140
S	0.6571	0.5700	0.4850	0.2850
<b>Driving max speed (Low)</b>				
x-axis (back-to-chest)	0.1140		0.2150	0.1200
y-axis (right-to-left)	0.0764		0.0977	0.1440
z-axis (buttocks-to-head)	0.2170		0.0669	0.2230
S	0.2890	0.2568	0.1800	0.1000
<b>Boom operation</b>				
x-axis (back-to-chest)	0.4510		0.6140	0.1830
y-axis (right-to-left)	0.3710		0.2470	0.3300
z-axis (buttocks-to-head)	0.4440		0.0838	0.3670
S	0.9304	0.7310	0.5070	0.1740

<b>Vibration Level - Hand/Arm</b>	
As per Tigercat test ETR007	
Weighted rms acceleration (m/s <sup>2</sup> )	
<b>Driving max speed (High)</b>	
S	1.770
<b>Driving max speed (Low)</b>	
S	1.170
<b>Boom operation</b>	
S	0.770

\*Note for hand/arm, all weighted RMS acceleration values are below 2.5 m/s<sup>2</sup> as per clause 3.6.3 Machinery Directive 98/37/EC Annex 1.

VIBRATION LEVEL.PDF

- NEVER travel across a STEEP slope or side hill.
- Always carry any load on the uphill side of the machine.
- Do not lift or move objects that exceed machine stability.
- Always be prepared to release the load in case it causes the machine to tip.
- Always position the cab so that you have a clear view in the direction of travel. Be aware of ground conditions and obstacles in the machine's path before moving the machine.
- When crossing obstacles (boulders, stumps, ditches etc.) the machine can shift rapidly, greatly affecting the stability of the machine. Move slowly over obstacles, and position the boom against the ground to reduce the risk of the machine shifting rapidly.
- Backing over obstacles unexpectedly while travelling down a slope poses a tipping risk. Know the path of the tracks whenever the machine is moved.
- When climbing a slope the boom should face uphill and the attachment should be kept close to the ground (FIG. 3). When descending a slope the boom should face down hill and the attachment should be kept close to the ground (FIG. 4). Be aware that the machine is in its least stable position on a slope with the boom to the rear. Be particularly aware of machine stability when changing directions on, or travelling back down a slope.
- As you gain experience, recognize that the maximum slope on which the machine can operate cannot be defined simply by an angle value. Variables in surface terrain, soil types, rocks, boulders, stumps, and fallen trees, changing weather conditions, and first and foremost the operator's experience and skill levels greatly affect the maximum slope limitations. Be aware that these factors can result in a shallow slope posing greater risk than a relatively steeper slope. **DO NOT attempt to work on slopes beyond your personal capability level.**



## LIGHTNING SAFETY AWARENESS



### WHAT IS A LIGHTNING STRIKE?

Lightning is a discharge of the electricity produced by a thunderstorm. As the thunderstorm develops, many small particles of ice within the storm clouds bump together. These collisions create a positive charge at the top of a cloud and a negative charge at the bottom. As this continues a second positive charge builds up on the ground beneath the cloud, concentrated around high objects such as hills, trees, buildings, equipment and even people.

When the difference between the electrical charge in the cloud and on the ground becomes great enough to overcome the resistance of the insulating air between them, an electrical current flows instantly. This is a lightning strike.

The electrical potential in a lightning strike can be as much as 100 million volts. Lightning strikes can occur over very large distances, even as much as 60 km (37 mi). Lightning travels both in front of and behind a thunderstorm and so strikes happen even when rain has not started or has stopped. Lightning can hit in the same place, many times and often spreads out over 18 m (60 ft) within the soil around the strike point.

Thunder always accompanies lightning. When lightning occurs, the air through which it travels is instantaneously heated to a temperature more than 28,000°C (50,000°F). The air expands rapidly due to this heating, then quickly contracts as it cools. It is this contracting shock wave that we hear as thunder.

In many areas of the world, lightning strikes are second only to flooding as the greatest cause of storm related deaths and injuries. Although only 10% of lightning strike victims are killed, virtually all from cardiac or respiratory arrest, over 70% of those that survive suffer severe, life-long injury and disability. The symptoms of a lightning strike include memory loss, fatigue, chronic pain, dizziness, sleeping difficulty and the inability to complete several tasks at one time.

### LIGHTNING SAFETY

In spite of the popular myth that being struck by lightning is an unlikely event, the facts show that lightning strikes occur frequently. As a result loggers are at high risk because their work is outdoors and close to known strike points such as tall trees and heavy equipment.

Loggers can increase their chances of avoiding a lightning strike by following a few simple safety practices.

1. Designate a member of your crew to
  - Monitor daily weather forecasts
  - Observe local weather conditions
  - Alert all other members of the crew when a possible lightning threat develops.
2. Don't start or continue any work that cannot be stopped immediately, when a storm moves nearby.
3. Anticipate a high-risk situation and take action early by moving to a low-risk location. Do not hesitate. If there is lightning, you are in danger.
4. Obey the rule - **If you see lightning, Flee. If you hear thunder, Clear.**
5. Do not follow the now obsolete guideline to take shelter when the time between seeing lightning and hearing thunder is 30 seconds or less. This does not provide sufficient time to ensure safety. Always follow step 4.
6. Remain in your safe location for 30 minutes after the last sight of lightning or the last sound of thunder.

The safest location during lightning activity is inside a fully enclosed, substantially constructed building, a house, office, school, shopping area, etc. These are the safest because of the electrical wiring and plumbing that they contain. Should lightning strike, the electrical current will travel through the wiring or plumbing into the ground. When such a building is nearby, always seek shelter there first.

CRUSH HAZARD




This label warns of the **CRUSH HAZARD** caused by the cab tilting.

Be sure that all personnel are clear when tilting the cab. Operating the cab tilt function with personnel in the crush zone **COULD RESULT IN DEATH OR SERIOUS INJURY!**

Keep all personnel clear of the machine before operating the cab tilt function.

CRUSH HAZARD



This label warns of the **CRUSH HAZARD** caused by the engine enclosure door.

Be sure that all personnel are clear when opening and closing the engine enclosure door. Operating the engine enclosure door with personnel in the crush zone **COULD RESULT IN DEATH OR SERIOUS INJURY!**

Keep all personnel clear of the machine before operating the engine enclosure door.

CRUSH HAZARD, LEVELER



:This label warns of the **CRUSH HAZARD** caused by movement of the leveling frames and cylinders when not properly supported.

Never work under the machine or near the leveler area when it is unsupported. Contact with moving frames and cylinders **COULD RESULT IN DEATH OR SERIOUS INJURY!**

Properly support and brace the leveler cylinders and shut off engine before performing service work in this area.

# USING HIGH-SPEED DISC SAWS SAFELY

---



This information is intended to encourage logging organizations and operators to develop and practice additional rules that suit particular terrain conditions and job requirements. It is also intended to assist towards a quicker understanding of how and why things can happen when a high speed disc saw is in use; and hence to assist in development of safe operating practices.




The following information is in addition to any safety instructions or recommended safe operating practices that may already be in circulation.



## CONTENTS - APPENDIX TO SECTION 1

COMMENTS AND INSTRUCTIONS	
DIRECTION OF THROW.....	A.7
HIGH ANGLE WRIST ROTATION ABILITY .....	A.8
RECOGNIZING THE DANGERS.....	A.7
THROWING LONG WOOD PIECES .....	A.10
DANGERS.....	A.3
FOREWORD .....	A.2
BE AWARE OF THE HAZARDS .....	A.3
OTHER INSTRUCTIONS .....	A.3
SAFE PRACTICES .....	A.3
SEVERAL TYPES OF HEADS INVOLVED .....	A.2
STORED ENERGY.....	A.3
HIGH ANGLE WRIST ROTATION CAPABILITY .....	A.9
SAW HEAD DON'TS .....	A.15
TYPE OF HOUSING MAKES A DIFFERENCE.....	A.4

Figures 8 and 9 show two ways that this might happen in the woods if using the saw head of figure 4 (where the throw contact can be long). A slab, still partly attached to a well backed-up tree bole and wet with sap, makes an ideally bad throw situation which could unintentionally occur in woods work. A small log in a pile of other logs might also be propelled out with enough length of continued contact with the blade to reach near saw tip speed.



## TIGERCAT OIL SAMPLING PROGRAM

### OIL SAMPLE COLLECTION PROCEDURES

Fill out the Sample Information Form (SIF) completely and accurately. When taking multiple oil samples, fill out all of the required SIF's in their entirety, prior to taking any oil samples. Then, immediately package each completed SIF together with the matching oil sample in the black outer shipping container as each individual sample is taken. This will reduce the possibility of mixing up or incorrectly identifying the SIF's and oil samples. Incorrectly identified samples could result in a false warning alarm.


The accuracy of the lab analysis results is very dependent on the quality of the oil sample taken. Collection of clean oil samples that are representative of the main body of oil are essential if meaningful lab results are to be obtained. Erroneous readings may result if proper collection, handling, packaging and shipping practices are not followed prior to the sample being tested by the lab. To be able to accurately compare and trend the lab results over time, all follow-up samples should be consistently taken from the same location using the same techniques as all previous samples.

- Ensure that all sample valves and drain plugs are clean and free of debris.
- Remove the sample bottle cap only when ready to take the sample. Keep the cap clean – **DO NOT** put it in your pocket or let it get contaminated in any way.
- **DO NOT** allow any airborne dirt, etc. to enter the sample bottle.
- Avoid contamination of the sample – replace the sample bottle cap immediately after filling the bottle to approximately  $\frac{3}{4}$  full.

All samples taken should be immediately forwarded to the lab for processing.

Contact your Tigercat dealer to purchase additional or replacement hydraulic sample valves or drain plugs.

In cases where oil samples must be pumped or otherwise drawn out of a reservoir or housing, a hand operated oil suction pump is also available from your Tigercat dealer.



### Hydraulic Oil Samples:

- Hydraulic oil samples should be taken from the circulating oil flow at operating temperature, with no functions actuated, using sample valves that are permanently located on the machine whenever possible.
- Purge the sample valve before taking a representative oil sample. Drain a minimum of 90 to 120 ml (3-4 ounces) of oil into a separate container and discard this oil using approved recycling methods.
- Replace the dust cover on the sample valve immediately after taking the oil sample and sealing the sample bottle.


### Gearbox Samples:


- These samples can be taken during the oil change process.
- To obtain a representative oil sample, ensure the oil is warm and has not settled very long (within 30 minutes of shutdown).
- Place the required drain container under the machine to capture the used oil to be discarded using approved recycling methods.
- Remove the drain plug and allow approximately 50% of the oil to drain, then place the sample bottle in the stream of draining oil to obtain a representative sample.

# APPROVED HYDRAULIC OILS

In addition to providing the vehicle with its normal operational functions, hydraulic oil is also used to fill the swing gearbox and brake.

Use one of the following oils to fill or replenish the hydraulic system.





822C-195

## FUEL TANK STRAINER

A 150 micron stainless steel fuel strainer (5) is screwed onto the end of the fuel supply pipe located inside the fuel tank. The strainer is accessible by removing the clean-out cover (6).

### CHANGING/CLEANING THE STRAINER

**NOTE:** This should only be required if excessive quantities of foreign material has built up inside the tank.

1. Park machine on level ground with attachment resting on the ground.
2. Stop engine. Turn battery disconnect switch to the OFF position. Always install a “**DO NOT START ENGINE**” sign on the operator’s cab door and in the engine compartment when making repairs to the machine.
3. Remove the drain plug (8) and drain the fuel tank.
4. Disconnect the fuel supply and return hoses at the fuel tank. Remove the clean-out cover (6) and O-ring (7).

5. Before removing strainer (5), clean any debris from inside bottom of tank and wipe clean.
6. Remove the fuel strainer (5) using the hex on the end of strainer. Carefully clean the strainer. **NOTE:** rough handling can cause damage.
7. Check for a buildup of foreign material where the strainer screws onto the pipe.
8. Reinstall the strainer (5) using the hex on end.
9. Reinstall fuel tank clean-out cover (6) with a NEW O-ring (7) and reinstall fuel supply and return hoses.
10. Replace drain plug (8), refuel and check for leaks.
11. Turn battery disconnect switch ON and start engine, check for leaks again.
12. Clean up any spilled fuel before returning machine to operation.


### **WARNING**

**To lower the risk of causing accidental fires, DO NOT leave fuel or oil soaked rags laying around.**

## AIR INTAKE MAINTENANCE

### ENGINE AIR PRECLEANER

The engine air precleaner cleans engine air before it reaches the air cleaner filter elements. It removes contaminants such as dust, powder, insects, rain and snow. This precleaner is self powered and self cleaning requiring virtually no maintenance. However, it should be checked periodically to make sure that foreign materials have not plugged the intake area or the discharge port area and that the rotor spins freely.



### AIR INTAKE SEAL

Periodically check to ensure seal on top of precleaner is making proper contact with the sealing surface of the inside top of the power door. Hot air leakage at this seal will reduce engine power.



# EATON Aeroquip

# Assembly Torque

## Recommended Parallel Connection Assembly torque

Eaton recommends that a Torque wrench be used to assure proper fitting assembly of these connections.

The values listed are for steel connections. Contact Teaton for torque values for other materials.

### Straight Thread O-Ring Boss Low Pressure with 37° (SAEJ514)

Dash Size	Thread Size (inches)	Jam Nut or Straight Fitting Torque lb.-ft.	Jam Nut or Straight Fitting Torque Newton Meters
-03	3/8-24	8-9	12-13
-04	7/16-20	13-15	18-20
-05	1/2-20	14-15	19-21
-06	9/16-18	23-24	32-33
-08	3/4-16	40-43	55-57
-10	7/8-14	43-48	59-64
-12	1 1/16-12	68-75	93-101
-14	1 3/16-12	83-90	113-122
-16	1 5/16-12	112-123	152-166
-20	1 5/8-12	146-161	198-218
-24	1 7/8-12	154-170	209-230
-32	2 1/2-12	218-240	296-325

### Straight Thread O-Ring Boss High Pressure with ORS (J1453)

Dash Size	Thread Size (inches)	Jam Nut or Straight Fitting Torque lb.-ft.	Jam Nut or Straight Fitting Torque Newton Meters
-03	3/8-24	8-10	11-16
-04	7/16-20	14-16	20-22
-05	1/2-20	18-20	24-27
-06	9/16-18	24-26	33-35
-08	3/4-16	50-60	68-78
-10	7/8-14	72-80	98-110
-12	1 1/16-12	125-135	170-183
-14	1 3/16-12	160-180	215-245
-16	1 5/16-12	200-220	270-300
-20	1 5/8-12	210-280	285-380
-24	1 7/8-12	270-360	370-490

### ORS

Dash Size	Thread Size (inches)	Swivel Nut Torque lb.-ft.	Swivel Nut Torque Newton Meters
-04	9/16-18	10-12	14-16
-06	11/16-20	18-20	24-27
-08	13/16-16	32-35	43-47
-10	1-14	46-50	62-68
-12	1 3/16-12	65-70	88-95
-16	1 7/16-12	92-100	125-136
-20	1 11/16-12	125-140	170-190
-24	2-12	150-165	204-224

### SAE 37° (JIC)

Dash Size	Thread Size (inches)	Swivel Nut Torque lb.-ft.	Swivel Nut Torque Newton Meters
-04	7/16-20	11-12	15-16
-05	1/2-20	15-16	20-22
-06	9/16-18	18-20	24-28
-08	3/4-16	38-42	52-58
-10	7/8-14	57-62	77-85
-12	1 1/16-12	79-87	108-119
-16	1 5/16-12	108-113	148-154
-20	1 5/8-12	127-133	173-182
-24	1 7/8-12	158-167	216-227
-32	2 1/2-12	245-258	334-352

### Metric

Thread Size		Straight Adapter or Locknut Torque	
mm	lb.-ft.	Newton Meters	
M10x1	13-15	18-20	
M12x1.5	15-19	20-25	
M14x1.5	19-23	25-30	
M16x1.5	33-40	45-55	
M18x1.5	37-44	50-60	
M20x1.5	52-66	70-90	
M22x1.5	55-70	75-95	
M26x1.5	81-96	110-130	
M27x2	96-111	130-150	
M33x2	162-184	220-250	
M42x2	170-192	230-260	
M48x2	258-347	350-470	

### BSP

Nominal Thread Size		Straight Adapter or Locknut Torque	
inches**	lb.-ft.	Newton Meters	
G1/8-28	13-15	18-20	
G1/4-19	19-23	25-30	
G3/8-19	33-40	45-55	
G1/2-14	55-70	75-95	
G3/4-14	103-118	140-160	
G1-11	162-184	220-250	
G1 1/4-11	170-192	230-260	
G1 1/2-11	258-347	350-470	

\*\* "G" denotes parallel threads, other than ISO 6149 (Port connection only)


# Tigercat X822C/LX822C/X830C/LX830C Feller Buncher

## SECTION 4 - HYDRAULIC SYSTEM


### CONTENTS - SECTION 4

ISSUE 1.0, DECEMBER 2015


DIFFUSERS/STRAINERS, HYDRAULIC OIL RETURN .....	4.13
FILTERS	
CHARGE PILOT .....	4.12
DIFFUSERS/STRAINERS - HYDRAULIC TANK.....	4.9
DIFFUSERS/STRAINERS, REPLACEMENT .....	4.13
FILTER/BREATHING - HYDRAULIC TANK .....	4.9
RESTRICTION PRESSURE SWITCH, HYDRAULIC OIL .....	4.11
RETURN, HYDRAULIC OIL .....	4.9
HAND FILL PUMP - HYDRAULIC OIL .....	4.17
HIGH PRESSURE LIMITING CONTROL VALVE	
SET LOAD SENSE RELIEF VALVE .....	4.38
HYDRAULIC OIL LEVEL SIGHT GAUGES.....	4.8
HYDRAULIC OIL TANK	
ADDING HYDRAULIC OIL .....	4.17
DESCRIPTION .....	4.7
DIFFUSERS/STRAINERS .....	4.13
FILTER/BREATHING .....	4.14
FILTER RESTRICTION PRESSURE SWITCH .....	4.11
HYDRAULIC OIL FILTERS.....	4.9
INSTALLING A VACUUM PUMP.....	4.15
HYDRAULIC OIL TANK - ACCESS COVER .....	4.13
HYDRAULIC PUMPS	
ATTACHMENT PUMP.....	4.20
FAN/CHARGE PUMP .....	4.20
MAIN PUMP.....	4.18
SAW PUMP.....	4.20
TRACK DRIVE PUMPS .....	4.20
HYDRAULIC SYSTEM OPERATION	
CIRCUIT DESCRIPTION.....	4.26
CLAMPS AND ACCUMULATING ARMS CIRCUIT.....	4.3
FAN DRIVE SYSTEM .....	4.5
FLOW ON DEMAND AND LOAD COMPENSATION .....	4.26
MAIN HYDRAULIC SYSTEM; BOOM, SWING, TILT, LEVELER .....	4.3
MARGIN PRESSURE.....	4.20
MARGIN PRESSURE, SET.....	4.37
PILOT CIRCUIT .....	4.5
PRESSURE GAUGE CONNECTIONS.....	4.37
SAW CIRCUIT .....	4.5
SWING SYSTEM.....	4.3
TRACK DRIVE SYSTEM.....	4.3, 4.6
HYDRAULIC SYSTEM - REFILLING .....	4.16
HYDRAULIC TANK PRESSURIZATION INSTRUCTIONS .....	4.14
LOAD SENSING	
BASIC DESCRIPTION.....	4.22
BASIC PRINCIPLES.....	4.21
OPERATING TIPS .....	4.24
SET LOAD SENSE RELIEF VALVE .....	4.38
SET MARGIN PRESSURE.....	4.37



13. Attach bleed hose (located in the compartment behind cab above hydraulic tank) to the coupler on the return manifold.
14. Route hose to a waste oil container.
15. Use fill pump to raise hydraulic oil level up to the FULL line, replacing oil lost during filter change.
16. As oil is being pumped into the tank, purge air out the bleed hose from the return manifold until a steady stream of oil is coming from the bleed hose.
17. Disconnect bleed hose from the coupling at the return manifold.
18. Clean up any spilled oil.
19. Start the engine and check for leaks.
20. Run engine at IDLE speed for at least five minutes to purge any remaining air from the filter system. Then STOP the engine for 15 minutes to allow air bubbles in the hydraulic tank to rise.
21. Re-check hydraulic oil level – top-up as needed.



#### **FILTER RESTRICTION PRESSURE SWITCH**

The bypass valves built into each filter head, preset at 1.7 bar (25 psi) will open in the event the elements become restricted. Before these valves are activated, a 1.4 bar (20 psi) filter restriction pressure switch installed in the return manifold, will send a signal to the computer control system when an oil flow in excess of 1.4 bar (20 psi) is encountered at the return filters. This pressure switch closes and the hydraulic oil filter bypass icon  displays RED on the MD3 computer. The master alarm and alarm light will sound and flash.

#### **IMPORTANT!**

Do not use these warnings as a substitute for checking the oil level at regular intervals. Refer to SCHEDULED MAINTENANCE in SECTION 3 of THIS MANUAL.

This information is assuming that operating conditions and running temperatures are NORMAL.

**LOAD SENSING**

**BASIC PRINCIPLES**







**Figs. 1 & 2** Early hydraulic systems used a fixed displacement pump, with valves to control or adjust flow rates or speeds. This throttling or restricting pump flow to achieve control over the functions causes excess oil to flow over the relief valve. This results in wasting power and at the same time creates heat. SEE FIGS. 1 & 2.

**Figs. 3 & 4** In an attempt to recover some of the wasted energy, variable volume pumps evolved. These pumps are power regulated or horsepower controlled and since they reduce the pumps output to maintain a constant system hp, oil flow over the relief valve is less, therefore reducing the wasted power losses and heat generation. SEE FIGS. 3 & 4.

The power wasted in the horsepower control system is still considerable and still requires constant "throttling" by the operator if he wants the speeds to remain as selected.


**Figs. 5 & 6** The load control system was developed to address the problems outlined above.

This system combines the energy saving benefits of flow on demand with load compensation at each work port. The compensator eliminates the need for operator flow adjustments (throttling). SEE FIGS. 5 & 6.



**CONTROL VALVE SPOOL OPERATION**


To achieve load sensing compensation, each control spool has two compensator valves and two L.S. check valves. These compensator valves can be either in the form of a shuttle valve or a ball, depending on the function being controlled.




**(A)** Each work port (A & B) has a compensator valve and shuttle valve. Each valve section also has two return passages (T) and two load sensing passages (LS). Each valve section has only one supply passage (P).


With the control valve spool held in neutral by the centering springs in both pilot caps, the pump discharge is blocked. Therefore, the control valves are closed centre. Pump discharge, work port, return, and load sensing passages are all blocked by the spool. Oil in the work ports is trapped.

With all control valve spools in neutral, pump discharge or "standby" oil pressure is approximately 400-600 psi.



**(B)** Whenever a single function is operated, pilot oil flows to a control valve end cap. Pilot oil will start to move the spool against the centering spring on the opposite end of the spool. The load sensing port (LS) is the first port to open. When the LS port is opened, the shuttle cavity is at LS pressure. Since this is the first function being operated, there is no LS pressure in the manifold and the shuttle does not move.







## Tigercat X822C/LX822C/X830C/LX830C Feller Buncher Electrical and Computers

ELECTRICAL SCHEMATICS	
ACCESSORIES SCHEMATIC .....	6.76
CAB SWITCHES AND LIGHTS SCHEMATIC .....	6.75
ENGINE CAN AND DIAGNOSTIC PLUG SCHEMATIC .....	6.74
ENGINE ECU SCHEMATIC.....	6.77
HVAC AND COOLING FAN CONTROL SCHEMATIC.....	6.78
IGNITION SWITCH/START AND PILOT SCHEMATIC.....	6.73
JOYSTICKS SCHEMATIC .....	6.79
LH XA2 MODULE SCHEMATIC .....	6.83
MD3 SCHEMATIC .....	6.80
RH XA2 MODULE SCHEMATIC.....	6.85
SWITCHES AND SENSORS SCHEMATIC .....	6.82
VALVE SOLENOIDS SCHEMATIC .....	6.84
WEBASTO DIESEL HEATER AND BOTTOM FUELING SCHEMATIC.....	6.86
XS2 CAB MODULE SCHEMATIC .....	6.81
ENGINE FAULT CODE MESSAGES .....	6.57
ENGINE FAULT CODE MESSAGES - CRITICAL.....	6.47
ERROR MESSAGES .....	6.48
FUSES AND RELAYS .....	6.5
ID-TAG.....	6.17
INFORMATION MESSAGES, BLUE .....	6.57
IQANRUN 2 .....	6.62
ADJUST .....	6.70
CONNECT TO THE MD3 WITH IQANRUN 2.....	6.64
IQANRUN 2 QUICK SUMMARY .....	6.62
ADJUST .....	6.63
CONNECT TO THE MD3 WITH IQANRUN2 .....	6.62
GET CLONE.....	6.62
GET SETTINGS .....	6.62
LOGIN .....	6.62
LOGS .....	6.63
MEASURE (GRAPH) .....	6.63
SEND CLONE .....	6.62
SEND SETTINGS .....	6.62
SYSTEM.....	6.63
UPDATE .....	6.62
LOGIN.....	6.65
LOGS .....	6.72
MEASURE/ GRAPH .....	6.71
REQUIRED EQUIPMENT & INFORMATION .....	6.62
SERVICING THE MD3 WITH IQANRUN 2.....	6.62
SYSTEM .....	6.72
UPDATE APPLICATION .....	6.66
GET CLONE FILE .....	6.66
GET SETTINGS FILE .....	6.67
UPDATE APPLICATION TO MD3 .....	6.68
IQAN SOFTWARE .....	6.60
APPLICATION PROGRAM UPDATES	
FOR PRODUCT SERVICE BULLETINS.....	6.61
DOWNLOADING APPLICATIONS FROM DEALER WEBSITE .....	6.61
SERVICING THE MD3 WITH IQANRUN 2.....	6.62

Tigercat X822C/LX822C/X830C/LX830C Feller Buncher Electrical and Computers







 **ADJUSTMENT MENU**



From the Main Display press the **F2** button to select the ADJUSTMENT MENU.



The adjustment menu icon  is on display along with the following adjustment selections:

- Oil Grade Adjustments  - Press the **F2** button.
- Auto Accumulation Mode Status  - Press the **F3** button.
- Press the  button to return to the Main Display.



 **OIL GRADE SELECTION**



Press the **F2** button to select the OIL GRADE Menu from the ADJUSTMENT MENU.

The oil grade menu lists the following:

- ISO22
- ISO32
- MULTI (UNIVIS ULTRA)
- ISO46
- ISO68


Press the  or  button to scroll to the desired oil grade and press OK.


The information is used by the machine program to adapt hydraulic oil temperature messages for the operating range of each Hydraulic Oil Grade.

Hydraulic oil grade information is shown on the Main Display below the hydraulic oil temperature gauge.

Refer also to APPROVED HYDRAULIC OILS in SECTION 3 of this manual for hydraulic oil operating range information.

Refer also to COMPUTER - MESSAGES -CRITICAL - HYDRAULIC OIL TEMPERATURE HIGH in this section for more information about the hydraulic oil temperature message.

Press the  button to return to the Adjustment menu.

Press the  button again to return to the Main Display.

**DM1 INFORMATION**



This menu provides a status of fault detection related to the MD3 Computer.

**ANTI-STALL**



This menu provides information related to the Anti-Stall system.


**SENSORS**



This menu provides information from the various sensors on the machine. Use the up or down arrow buttons to highlight the input to be viewed. Once highlighted the bottom line of this menu will show which module this input is connected to and the corresponding pin # at that module.

In the example above the LS Pressure sensor is highlighted. The bottom line of the menu shows that this is connected to the XA2-A0 module at Pin 13 of the C1 connector plug.


CRITICAL MESSAGES



**ENGINE STOP**

This message is displayed, the alarm light flashes and the alarm sounds when the engine stops while the ignition switch is in the RUN position and/or when critical engine alarms are triggered.

Refer to engine manufacturer's manual for specific information regarding the engine.



**HYDRAULIC OIL LEVEL EXTREMELY LOW**

This message is displayed, the alarm light flashes and the alarm sounds when the main hydraulic tank oil level is extremely low.

Turn OFF the engine immediately when this alarm is activated. Operating the machine with a low hydraulic oil level can cause hydraulic pumps to fail.

Look for signs of broken hoses or other leaks. Repair leaks and refill the main hydraulic tank to FULL mark on the sight gauge. Restart engine and inspect for leaks.

**NOTE:** The hydraulic oil level icon illuminates RED when a hydraulic oil level extremely low critical message is activated.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**XS2 MODULE NO CONTACT ERROR**



Expect all machine functions controlled by this module to cease and all alarms associated with this module to be triggered.

**1. CHECK FOR OTHER ERROR/ALARM MESSAGES ON SCREEN**

Press OK to acknowledge each error message. Note that module no contact errors are followed by other alarm messages associated with the module(s) which is(are) out of contact.


If XS2-A0 MODULE NO CONTACT is the only module in the NO CONTACT error message, the likely causes are:

- Power - Fuse (XS2 MODULE)
- Ground
- Address (ID-Tag)

If the XS2-A0 MODULE NO CONTACT is followed by an XA2-A0 and XA2-A1 NO CONTACT error the likely cause is the CAN wire connection

Status	Flash		
Normal operation (yel.)			
Error code	Error	Primary Flash (red) Error category	Secondary Flash (yellow) Error description
1:n	See note <sup>a</sup>		
2:n	See note <sup>a</sup>		
3:1	CAN error		
3:2	Address error		
4:1	Memory error <sup>b</sup>		
FE	Fatal error		

a. Error groups 1:n and 2:n are controlled by the master.  
b. FRAM memory error.



**2. CHECK MODULE STATUS INDICATORS**

The XS2 module also indicates error status through the yellow/red blinking LED. This gives an immediate diagnosis as to the nature of the error that has occurred.

**(A) Supply Voltage LED (green).**

LED with green light ON indicates supply voltage is ON.

LED OFF indicates supply voltage is OFF.

**(B) Status indicator LED (yellow/red).**

LED yellow flashing light indicates status is correct.

LED flashing red light indicates error status as follows:

- One red primary flash and one secondary yellow flash indicates an error controlled by the master (MD3).
- Two red primary flashes in a row and one yellow secondary flash indicates an error controlled by the master (MD3).
- Three red primary flashes in a row and one yellow secondary flash indicates that the fault is related to the CAN-bus.
- Three red primary flashes in a row and two yellow secondary flashes in a row indicates that the fault is related to the address.
- Four red primary flashes in a row and one yellow secondary flash indicates a memory error.
- Continuous red primary flashing indicates a fatal error.

Internal diagnostics in the master (MD3) can be used to get more information about the XS2 module. The following values are supervised:

- Internal temperature (°C)
- Power supply (V)
- Reference voltage (V)
- CAN address voltage (V)

### **ADJUST**

Allows access to adjustment groups. In addition to adjust groups normally accessible on screen additional adjust groups that require sufficient rights restricted by username and password login. Refer to IQANRUN 2 - ADJUST in this section for details.

### **MEASURE (GRAPH)**

Allows the user record, graph and measure group channel readings during machine operation, testing or setup procedures. These recordings can be saved or printed. Refer to IQANRUN 2 - MEASURE (GRAPH) in this section for details.

### **LOGS**


Allows the user to access to logs for service troubleshooting, maintenance documentation or clearing. Some log operations require sufficient rights to perform. Refer to IQANRUN 2 - LOGS in this section for details.


### **SYSTEM**

Allows the user to access system information including machine serial number information. Refer to IQANRUN 2 - SYSTEM in this section for details.





LH XA2-A0 MODULE







**PUMP DRIVE GEARBOX**

The pump drive gearbox mounted on the back of the engine drives the 6 hydraulic pumps. The internal components of the pump drive gearbox are lubricated via a lube pump that draws oil from the bottom of the gearbox and injects it back in, at the top of the gearbox. Mounted adjacent to the gearbox is the Pump Drive Gearbox Oil Reservoir and Oil Level Gauge.



**PUMP DRIVE GEARBOX MAINTENANCE GUIDE**



It is very important to maintain the correct level of oil in the gearbox at all times. An oil level sight gauge is remote mounted to the side of the upper frame just below the accumulator. The oil level must be checked **ONLY** when the machine is on level ground and the oil is **HOT**. Always wait at least 5 minutes after stopping the engine before checking the oil level. Do not overfill as this can cause the gearbox to overheat.

If adding oil to the reservoir ensure that the oil level in the gauge moves up as the oil is added. If the level fails to move check the vent at the top of the tube for blockage.

**MAIN PUMP**

For operation and adjustment of this pump refer to SECTION 4 of this manual.

---

**MAIN CONTROL VALVE**

For operation and description of this valve refer to SECTION 4 of this manual

---

**OIL COOLER CIRCUIT DESCRIPTION**

The oil cooler circuit operates as a part of the main hydraulic circuit.

The main pump draws oil from the hydraulic tank and sends it to the main control valve. Return oil from the main control valve sections exits the base manifold at two 'T' ports and 5.1 bar (75 psi) internal check valves. From the bottom port, the oil passes through the oil cooler via the oil cooler bypass return manifold, which includes a 100 psi bypass valve for the oil cooler. From the top port the oil returns directly to the return manifold via a 120 psi check valve.

The cooler bypass ensures that the differential pressure between the oil cooler inlet and outlet does not exceed set limits. Increases in pressure within the oil cooler can occur in cold weather when oil temperatures at start-up are very low.

Cooling of the oil occurs as air is drawn over the oil cooler cooling fins by the cooling fan. Cooled oil then passes back through the cooler bypass valve and on to the return manifold and return filters and then to the hydraulic tank. A (1.7 bar) 25 psi bypass valve is incorporated into each pair of return filter heads.

Oil entering the hydraulic tank from the return manifold and filters passes through 3 strainers situated inside the tank below the oil surface.

Refer to HYDRAULIC OIL TANK in SECTION 4 of this MANUAL. Refer also to SECTION 2 and SECTION 3 of the OPERATOR'S MANUAL.

Refer to HYDRAULIC SYSTEM OPERATION - MAIN HYDRAULIC SYSTEM in SECTION 4 of this manual.

---

**ELECTRONIC ADJUSTMENT PROCEDURE**

When the fan switch is in the Auto position the fan will reverse direction automatically to purge the radiator and screens. The frequency of the direction change or purge interval is adjustable on the MD3 controller.

**TIME PURGE INTERVAL ADJUSTMENT**




Press the menu button (☰) to go to the MAIN MENU.



Press F1 to access the Adjust menu.



Using the up or down arrow buttons scroll to the Machine Parameters menu and press OK.



Use the up arrow or down arrow buttons to scroll to Time Purge Interval and press OK.

## HYDROSTATIC DRIVE MOTOR

The hydrostatic drive motor is a variable displacement, bent-axis, axial piston type motor.

High pressure oil, from the hydrostatic pump, enters the motor via port A or port B, depending on the direction of travel required. This oil is then directed to a set of pistons inside the motor rotating group cylinder housing. These pistons push against the back of the output shaft at an angle, causing the shaft to rotate.

The piston motor is made variable by changing the angle of the motor rotating group cylinder housing relative to the end of the output shaft. This angle determines the size or displacement of the motor. The displacement determines the output speed and torque of the motor. Increasing the displacement, increases the torque output while reducing the output speed of the motor. Reducing the displacement reduces the torque and increases the speed.


The displacement of the motor is changed by an internal control cylinder which receives high pressure oil from the *begin of stroke* valve. The hydrostatic drive motor normally stays at

the smallest displacement in order to drive the machine as fast as possible.

Only when the pressure in the high pressure side of the closed loop exceeds the *begin of stroke* preset level does the displacement of the motor begin to increase.

As the motor displacement automatically increases, the machine speed automatically slows but the motor is able to drive the machine up steeper slopes and to travel on rougher or wetter terrain. As the pressure in the high pressure side of the closed loop falls below the *begin of stroke* pressure, the motor displacement automatically returns to the smallest displacement and the machine speeds up.

A flushing valve is incorporated into the hydrostatic drive motor to provide a regulated flow of oil from the low pressure side of the closed loop into the motor case. This flow reduces the possibility of the buildup of contamination particles within the closed loop by providing a continuous change of oil. The flushing valve oil also assists in cooling of the hydrostatic drive motor. The flushing valve flow is fixed and no adjustment is required.



LX870C-28

DRIVE MOTOR - LH SIDE SHOWN


### TRACK DRIVE PRESSURE AND SPEED SETTINGS

#### DRIVE PUMP HIGH PRESSURE RELIEF VALVES


#### IMPORTANT!

Park the machine on flat solid ground and place the felling head securely on the ground before performing any service work.

1. Raise the hydraulic oil temperature to no higher than **40°C (100°F)**.  
**NOTE: DO NOT** heat to operating temperature prior to starting this procedure, significant heating will occur during this test. Constantly monitor hydraulic oil temperature during this test procedure.



2. Connect two 0-700 Bar (0-10000 psi) pressure gauges to test ports **M<sub>b</sub>** and **M<sub>a</sub>** on the left track drive pump.
3. Start engine and set throttle to IDLE.
4. Position the felling head in the vertical position and swing the boom to the LEFT side of the machine.
5. Place the felling head on the ground and lift the track clear of ground by forcing down with the boom controls (hoist down and stick out).




6. Use blocks to firmly support the track frame in the raised position. **DO NOT** place your arms, legs or body under the track while in the raised position.
7. From inside the cab close and latch the front door and press the PILOT RESET switch to activate pilot system.




8. Fully depress the left track foot pedal and at the same time use the down arrow on the MD3 screen to adjust the track speed so the track is just moving.

**NOTE:** Do not turn the key off until instructed. If the key is turned off the track speed control automatically reverts back to maximum. If for any reason the key is turned off prior to completing the tests this step will need to be repeated.



880-303

**TRACK SAG FILL VALVE**

845C-002

**CW182**  
USED ON R6140 & R6152  
UNDERCARRIAGES

**TRACK SAG ADJUSTMENT**

To tighten the track, use a grease gun and add grease at the fill valve. Add grease until the track sag dimension is within recommended limits. Refer to MEASURING TRACK SAG in THIS SECTION for recommended limits.

To loosen the track, slowly loosen the fill valve until grease begins to escape through the vent passage in the valve body housing. Grease will vent around the valve body threads. Remove grease until the track sag dimension is within recommended limits. Refer to MEASURING TRACK SAG in THIS SECTION for recommended limits.

**NOTE:** The track sag fill valve is mechanically restricted from being removed completely.

# Tigercat X822C/LX822C/X830C/LX830C Feller Buncher

## SECTION 12 - BOOM FUNCTIONS

### CONTENTS - SECTION 12

ISSUE 1.0, DECEMBER 2015


ADJUST OIL FLOW TO CYLINDERS (CYLINDER CYCLE TIMES).....	12.9
BOOM CONTROL VALVE .....	12.3
CIRCUIT DIAGRAM, 'ER BOOM SYSTEM' .....	12.4
CYLINDER CYCLE TIMES, TYPICAL.....	12.10
ER BOOM SYSTEM.....	12.6
HYDRAULIC SCHEMATIC, BOOM CIRCUIT .....	12.5
PARKING BOOM.....	12.6
SET MAIN BOOM, STICK AND TILT PORT RELIEF VALVES.....	12.7
TILT CYLINDER FLOW ADJUSTMENT .....	12.3, 12.11

**TILT CYLINDER (ROD END) FLOW AND SPEED ADJUSTMENT**


This adjusting screw restricts the flow of oil leaving the rod end of the TILT cylinder when tilting FORWARD.

When correctly set, this restriction will prevent cylinder damage.

1. Ensure the hydraulic oil is at operating temperature.



2. Connect a 0-345 Bar (0-5000 psi) pressure gauge on the main valve manifold 'P' test port.
3. Start the engine and place the throttle control in the FULL position.
4. From inside the cab, close and latch the front door and press the PILOT RESET switch to activate the pilot system.
5. Place the ANTI-STALL switch in the OFF position.
6. Raise the boom and place the felling head in the fully TILT BACK position (cylinder fully retracted).




7. Loosen the locknut on the restriction adjustment screw. While holding the joystick in the fully TILT FORWARD position, observe the pressure gauge and record the TILT travel speed from stop to stop\*\*. Turn the restriction adjustment screw to adjust the speed and turn the spool travel stop adjustment screw on the main control valve to maintain 55-70 bar (800-1000 psi) pump pressure.

If the TILT speed is too fast, turn the restriction adjustment screw IN. If the TILT speed is too slow, turn the restriction adjustment screw OUT.

If the pump pressure reading is too low, increase the flow by turning the TILT spool travel stop adjusting screw (bottom adjuster) OUT. If the pump pressure is too high, decrease the flow by turning the adjusting screw IN.

**NOTE:** The Tilt restriction and (to a lesser extent) the spool travel stop adjustment both affect the TILT forward speed. Similarly, the TILT restrictor has a small affect on the pump pressure. Alternate between adjustments making moderate changes until the desired speed and pressure ranges are achieved.

8. Tighten the locknut on the restriction adjustment screw taking care NOT to turn the adjusting screw at the same time.
9. Check the pressures again after tightening the locknut.
10. Turn OFF the engine and remove the gauge.




## CHECK PORT RELIEF VALVES

**! DANGER**

Extreme care and attention must be exercised when making adjustments to the leveling hydraulic and electrical circuits. Ensure that all personnel not directly associated with the servicing are well clear of the machine. The whole upper frame/cab/engine compartment, boom and attachment can tilt unexpectedly from side to side or forward and backwards during servicing, creating *pinch points* between the upper frame and track and the ground.

1. Ensure hydraulic oil is at operating temperature.




2. Park the machine on level ground. Lower the attachment to the ground.
3. Engage the swing brake.
4. Turn the engine OFF.



5. Turn the battery disconnect switch OFF.
6. Install the leveling cylinder support brace to prevent tilting of the upper frame during this procedure.
7. Remove the access plate under the main valve to access the LS relief valve adjustment.

8. Turn the battery disconnect switch on.




9. Connect a 0-350 Bar/0-5000 psi pressure gauge to the remote 'P' test port located under the track low valve in the hydraulic tank compartment.
10. Start the engine and set the throttle speed to the IDLE position.
 

**NOTE:** It may be necessary to increase the engine RPM sufficiently to prevent the engine from stalling.
11. Close the cab door.
12. Press the PILOT RESET switch to activate the pilot system.
13. Place the anti-stall switch in the OFF position.

**LEVELER ADJUSTMENT SETTINGS**

These settings (defined below) fine tune the operating speeds, start/stop ramps and cylinder tracking for the leveler functions.

**MIN = MINIMUM CURRENT (mA)**




Minimum current settings control function start speed. Coils on hydraulic valves require a certain amount of current before they begin to operate the valve. The Min current value is the current that will be sent to the hydraulic valve coil when the function switch is activated.

The Min current is adjusted to a value that causes the function to just begin to creep.

**NOTE:** Use the default setting of 300 mA when setting the Min Current.

**MAX = MAXIMUM CURRENT (mA)**



Maximum current settings control the maximum speed the function will operate at. Increasing this value will increase the travel speed of the cylinder.

**NOTE:** The mA +(extend) and mA- (retract) settings for the left and right cylinders need to be set separately to avoid tracking (one cylinder extending or retracting faster than the other).


**START RAMP**

This is the amount of time in mS that it takes for the current to get from the Min Current value to the Max Current when turning on a function. A higher setting will cause a delay in the time that it takes the function to reach top speed. Note that if the mS setting is set to 0ms then the min current setting is negated as the function will start at max current as soon as it is turned on.

**STOP RAMP**

This is the amount of time in mS that it takes for the current to get from the Max Current to the Min current when turning off a function. A higher setting will cause a delay in the time that it takes for the function to come to a stop from top speed. Note that if the mS setting is set at 0mS then the min current setting is negated and the function would stop as soon as it is turned off.

Below is a typical graph showing the four settings.



**NOTE:** The start and stop ramps adjust both the left and right cylinders to the same value.

**FORWARD LEVELING SPEED**

This adjusts both the left and right cylinder speeds proportionally to their respective Max mA+(cylinder extend) settings.

**REAR LEVELING SPEED**

This adjusts the left and right cylinder speeds proportionally to their respective Max mA-(cylinder retract) settings.

# Tigercat X822C/LX822C/X830C/LX830C Feller Buncher

## SECTION 15 – SWING

### CONTENTS - SECTION 15

ISSUE 1.0, DECEMBER 2015

ADJUST SWING BEARING BACKLASH	
ADJUSTMENT TOOL .....	15.13
DEACTIVATING SWING BRAKING SYSTEM.....	15.13
HARDNESS GAP .....	15.15
PILOT MANIFOLD .....	15.13
SWING BEARING POSITIONING .....	15.16
TORQUE SEQUENCE, SWING BEARING MOUNTING BOLTS.....	15.15
CIRCUIT DESCRIPTION .....	15.3
CIRCUIT DESCRIPTION, SWING DRIVE HYDRAULIC .....	15.2
CIRCUIT DIAGRAM, SWING DRIVE HYDRAULIC .....	15.4
ENGINE ECU, DISCONNECT .....	15.11, 15.17
FILTER/BREATHER, HYDRAULIC TANK.....	15.17
HYDRAULIC CIRCUIT, SWING SYSTEM.....	15.4
HYDRAULIC SCHEMATIC, SWING SYSTEM.....	15.5
SCHEMATIC DIAGRAMS	
PRIORITY VALVE SCHEMATIC .....	15.3
SWING DRIVE MOTOR .....	15.2
SWING SYSTEM HYDRAULIC .....	15.5
SWING BEARING BACKLASH, ADJUSTING.....	15.13
SWING BEARING POSITIONING.....	15.16
SWING BEARING REPLACEMENT .....	15.17
MAXIMUM LOAD ZONE.....	15.19
MOUNTING BOLTS.....	15.18
SEAL, INTERNAL SEAL.....	15.20
SWING BEARING SEAL, INTERNAL .....	15.20
SWING BEARING WEAR LIMITS.....	15.12
SWING DRIVE GEARBOX	
LOWER BEARING LUBRICATION.....	15.10
UPPER GEARING LUBRICATION .....	15.10
SWING DRIVE LUBRICATION	
PRE FILLING SWING PUMP AND MOTOR.....	15.11
SWING PUMP AND MOTOR, PREFILLING .....	15.11
SWING SYSTEM HYDRAULIC SCHEMATIC.....	15.5
SWING VALVE PRIORITY CIRCUIT DESCRIPTION .....	15.3

**PREFILLING SWING MOTOR**

When the swing motor has been removed and replaced for service, it is important to prefill it with hydraulic oil prior to starting the engine.

1. After replacing the motor and the hose is reconnected, refill the hydraulic tank.



2. Disconnect the multi-pin plug from the engine ECU to prevent engine starting.



3. To help purge air from the system, loosen the hose connection for the swing motor case drain return on the motor.
4. Crank the engine over for 5 to 10 seconds, stop cranking, wait 20 seconds then crank engine over again for 5 to 10 seconds.
5. Have an assistant watch for oil to flow from the case drain return hose. Once oil free of air is seen, stop cranking engine and tighten hose connection.
6. Install the multi-pin plug on the engine ECU.
7. Clean up any spilled oil.
8. Start engine and set engine speed to **IDLE**. Very gently operate swing system five times in each direction.

# Tigercat X822C/LX822C/X830C/LX830C Feller Buncher

## SECTION 17 - SAW DRIVE

---

### CONTENTS - SECTION 18

ISSUE 1.0, DECEMBER 2015

CIRCUIT DESCRIPTION		
INTERMITTENT SAW CIRCUIT .....	17.12	
JOYSTICK ELECTRICAL CIRCUIT .....	17.14	
SAW CIRCUIT DESCRIPTION.....	17.5	
CIRCUIT DIAGRAMS		
ELECTRICAL CIRCUIT DIAGRAM.....	17.8	
ELECTRICAL CIRCUIT DIAGRAM (INTERMITTENT SAW).....	17.17	
HYDRAULIC CIRCUIT DIAGRAM.....	17.6	
HYDRAULIC CIRCUIT DIAGRAM (INTERMITTENT SAW).....	17.15	
JOYSTICK ELECTRICAL CIRCUIT (INTERMITTENT SAW).....	17.14	
ELECTRONIC ADJUSTMENT PROCEDURE .....		17.18
BAR FEED DELAY .....	17.20	
CLAMP WHILE SAWING (FC5185 ONLY).....	17.20	
RETURN TIME LIMIT .....	17.19	
SAW AUTO RETURN .....	17.18	
MOTOR BEGIN OF STROKE. SEE FELLING HEAD MANUAL .....		17.11
MOTOR MINIMUM DISPLACEMENT. SEE FELLING HEAD MANUAL .....		17.11
PRESSURE SETTINGS.....		17.10, 17.13
CHECKING MAX CURRENT.....	17.9	
PRESSURE SETTINGS, PORT RELIEF VALVES.....		17.9
SCHEMATICS		
HYDRAULIC CIRCUIT SCHEMATIC.....	17.7	
HYDRAULIC SCHEMATIC (INTERMITTENT SAW) .....	17.16	
SAW CONTROL VALVE SCHEMATIC .....	17.3	
SAW PUMP SCHEMATIC.....	17.2	

**SET MOTOR BEGIN OF REGULATION TO 221  
BAR (3200 PSI)**

Refer to the felling attachment manufacturer's service literature for this procedure.

**IMPORTANT!**

The motor begin of regulation setting must be at least 27.6 Bar/400 psi. lower than the pump P.O.R. setting.

---

**SET MOTOR MINIMUM DISPLACEMENT**

Refer to the felling attachment manufacturer's service literature for this procedure.

---

# Tigercat X822C/LX822C/X830C/LX830C Feller Buncher

## SECTION 18 - WRIST AND CLAMPS

### CONTENTS - SECTION 18


ISSUE 1.0, DECEMBER 2015

ATTACHMENT CONTROL VALVE .....	18.4, 18.20
ATTACHMENT HYDRAULIC CONNECTIONS .....	18.9
ATTACHMENT PUMP .....	18.2
CIRCUIT DESCRIPTION .....	18.12
ACCUMULATOR ARM.....	18.12
CLAMP ARM.....	18.12
WRIST .....	18.12
CIRCUIT DIAGRAMS	
ATTACHMENT ELECTRICAL CIRCUIT DIAGRAM.....	18.15
JOYSTICK ELECTRICAL CIRCUIT DIAGRAM.....	18.11
WRIST, CLAMP AND ACCUMULATING ARMS HYDRAULIC CIRCUIT DIAGRAM .....	18.13
COMPUTER CONTROL SYSTEM.....	18.10
DEFAULT SETTINGS TABLE.....	18.32
ELECTRONIC ADJUSTMENT PROCEDURE	
ACCUMULATOR ADJUSTMENT.....	18.37
ADJUSTMENT EXAMPLE.....	18.26
AUTO-ACCUMULATE SETTINGS .....	18.41
CLAMP ADJUSTMENT.....	18.33
WRIST ADJUSTMENT .....	18.27
WRIST DEFAULT SETTINGS.....	18.32
FILTER/BREATHER, HYDRAULIC TANK.....	18.43
HYDRAULIC TANK PRESSURIZATION INSTRUCTIONS .....	18.43
JOYSTICK CONTROLS.....	18.11
PRESSURE CHECKING.....	18.17
CHECKING CLAMPS/WRIST PRESSURES .....	18.21
CHECKING MAX CURRENT.....	18.17
CHECKING 'POR' PRESSURE .....	18.20
PRESSURE SETTINGS, PORT RELIEF VALVES.....	18.17
REPLACING	
MAIN PRESSURE RELIEF VALVE .....	18.24
PORT RELIEFS .....	18.24
SCHEMATICS	
ATTACHMENT VALVE SCHEMATIC.....	18.6, 18.7, 18.9
INLET SECTION SCHEMATIC.....	18.4
JOYSTICK ELECTRICAL SCHEMATIC .....	18.11
WRIST, CLAMP AND ACCUMULATING ARMS HYDRAULIC SCHEMATIC.....	18.14
XA2 #1 MODULE SCHEMATIC.....	18.16


**JOYSTICK CONTROLS**

The factory installed left (1) and right (2) joysticks are equipped with thumb switches and finger buttons that are used as an operator interface with the electronic control system to activate

the clamp arm, accumulator arm and wrist functions. Refer also to JOYSTICK in SECTION 2 of the OPERATOR'S MANUAL for a complete description of factory equipped joystick control function.




**LEFT JOYSTICK**




**RIGHT JOYSTICK**

STANDARD TIGERCAT 6 BUTTON JOYSTICKS : NOT APPLICABLE FOR ALL MACHINES



1. Wrist CCW
2. Level Left (if equipped)
3. Level Right (if equipped)
4. Not Used
5. Accumulator Arm Open
6. Accumulator Arm Close
7. Wrist CCW




1. Not Used
2. Level Forward (if equipped)
3. Level Back (if equipped)
4. Wrist CW
5. Clamp Arm Close
6. Clamp Arm Open
7. Wrist CW

## CHECKING CLAMPS/WRIST PRESSURES

**WARNING**

Accumulator and clamp arms open and close very rapidly. The felling head will also be rotated side to side during this procedure. Operator must ensure that no one is near the felling head during these procedures.

**WARNING**

Position the felling head on the ground during this procedure except when checking the wrist port relief valves. The swing brake should be applied at all times during this procedure.

**NOTE:** The relief valves are cartridge type reliefs and are not adjustable. If the observed pressures are not within 3.5 bar (50 psi) of the specified pressure the cartridge will require replacement.


1. Ensure the hydraulic oil is at operating temperature.
2. Park the machine on level ground with the attachment resting firmly on the ground.
3. Apply the swing brake.
4. Turn OFF the engine.
5. Remove the ignition key.
6. Turn OFF the battery disconnect switch.
7. Connect a 0-350 bar (0 - 5,000 psi) pressure gauge to the attachment control valve 'PX' test port.
8. Turn ON the battery disconnect switch.
9. Check that all personnel are clear of the machine before starting the engine.
10. Insert the ignition key and turn to the ON position.
11. Sound horn to warn personnel of machine start up.

12. From inside the cab, close and latch the cab door.
13. Turn the engine ON and set throttle to HIGH IDLE.

## CLAMP ARM

**WARNING**

The following adjustments are made with the engine running. Take extreme care to keep away from moving parts and hot surfaces.



1. Loosen the lock nuts on the clamp feed reducer screws.
2. Turn the feed reducer screws clockwise (IN) all the way.
3. Tighten the lock nuts.



Using the up or down arrow buttons adjust the -(CCW) Wrist Start setting. Adjustment of this setting (along with the - CCW Min setting ) will determine how the Wrist will start in the CCW direction. Increasing this setting will result in a less aggressive start while decreasing the setting will result in a more aggressive start. Once the setting has been adjusted press OK.



Using the up arrow or down arrow buttons adjust the -(CCW) Wrist Stop setting. Adjustment of this setting (along with the - CCW Min setting) will determine how the wrist stops in the CCW direction. Increasing this setting will result in a less aggressive stop while decreasing the setting will result in a more aggressive stop. Once the setting has been adjusted press OK. The CCW wrist adjustment is now complete.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL