

SERVICE MANUAL - ENGINE

MODELS 1F1/1F2

QD32 Diesel Engine



SERVICE

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TIGHTENING TORQUE


Standard Bolt Tightening Torque

Upper: Lubricated (Antirust oil is applied to abrasive faces of threads and seating faces)


Lower: No lubrication (Threads and seating faces are completely degreased).

	Thread Size		Unit	4T (Bolt)	7T (Bolt)	9T (Bolt)	
	Diameter	Pitch					
Hexagon Head Bolt and Nut	M6	1	Nm	3.82 - 4.41	6.37 - 7.45	9.22 - 10.8	
			kg-m	0.39 - 0.45	0.65 - 0.76	0.94 - 1.1	
			in/lb	34 - 39	56 - 66	82 - 95	
			Nm	5.00 - 6.47	8.43 - 10.8	11.8 - 15.7	
			kg-m	0.51 - 0.66	0.86 - 1.1	1.2 - 1.6	
			ft/lb, in/lb*	44 - 57*	75 - 95*	9 - 12	
	M8	1.25	Nm	9.32 - 10.8	15.7 - 17.7	22.6 - 25.5	
			kg-m	0.95 - 1.1	1.6 - 1.8	2.3 - 2.6	
			ft/lb, in/lb*	82 - 95*	12 - 13	17 - 19	
			Nm	12.7 - 15.7	20.6 - 26.5	29.4 - 37.3	
			kg-m	1.3 - 1.6	2.1 - 2.7	3.0 - 3.8	
	M10	1.25	ft/lb	9 - 12	15 - 20	22 - 27	
			Nm	19.6 - 22.6	32.4 - 38.2	47.1 - 53.9	
			kg-m	2.0 - 2.3	3.3 - 3.9	4.8 - 5.5	
			ft/lb	14 - 17	24 - 28	35 - 40	
			Nm	25.5 - 33.3	43.1 - 54.9	61.8 - 78.5	
			kg-m	2.6 - 3.4	4.4 - 5.6	6.3 - 8.0	
		1.5	ft/lb	19 - 25	32 - 41	46 - 58	
			Nm	18.6 - 21.6	30.4 - 36.3	44.1 - 52	
			kg-m	1.9 - 2.2	3.1 - 3.7	4.5 - 5.3	
			ft/lb	14 - 16	22 - 27	33 - 38	
	Flanged Bolt	M6	1	Nm	24.5 - 31.4	41.2 - 52	58.8 - 74.5
				kg-m	2.5 - 3.2	4.2 - 5.3	6.0 - 7.6
				ft/lb	18 - 23	30 - 38	43 - 55
Nm				4.9 - 5.69	8.14 - 9.51	11.8 - 13.7	
kg-m				0.5 - 0.58	0.83 - 0.97	1.2 - 1.4	
ft/lb, in/lb*				43 - 50*	72 - 84*	9 - 10	
M8		1.25	Nm	5.98 - 7.65	9.81 - 12.7	14.7 - 18.6	
			kg-m	0.61 - 0.78	1.0 - 1.3	1.5 - 1.9	
			ft/lb, in/lb*	53 - 68*	87 - 113*	11 - 14	
			Nm	11.8 - 13.7	19.6 - 23.5	28.4 - 33.3	
			kg-m	1.2 - 1.4	2.0 - 2.4	2.9 - 3.4	
			ft/lb	9 - 10	14 - 17	21 - 25	
			Nm	14.7 - 18.6	24.5 - 31.4	35.3 - 45.1	
			kg-m	1.5 - 1.9	2.5 - 3.2	3.6 - 4.6	
			ft/lb	11 - 14	18 - 23	26 - 33	

TROUBLE DIAGNOSES AND CORRECTIONS



TROUBLE DIAGNOSES AND CORRECTIONS



ENGINE MECHANICAL

SECTION **EM**

CONTENTS


SERVICE DATA AND SPECIFICATIONS . . .	EM-2
General Specifications	EM-2
Inspection and Adjustment	EM-2
Tightening Torque	EM-9
CHECKING COMPRESSION PRESSURE (ON-VEHICLE SERVICE)	EM-10
Inspection	EM-10
CYLINDER HEAD	EM-11
Component Parts	EM-11
Removal (On-Vehicle Service)	EM-12
Disassembly	EM-12
Inspection	EM-13
Assembly	EM-19
Installation (On-Vehicle Service)	EM-20
OIL SEAL	EM-23
Replacement (On-Vehicle Service)	EM-23
ENGINE OVERHAUL	EM-25
Component Parts	EM-25
Disassembly	EM-26
Inspection and Replacement	EM-29
Assembly	EM-39
SPECIAL SERVICE TOOLS	EM-45
Special Service Tools	EM-45

NOTE:

This section contains information and specifications for both carbureted general overseas market (GOM) models, as well as, electronic control models (manufactured in USA.) Therefore, prior to taking any action, ensure the specifications and/or procedures are for the proper fuel delivery system; carbureted or electronic controlled.

CYLINDER HEAD

Component Parts







⊗ : Always replace when disassembled

☐ : Nm (kg-m, ft/lb)

☐ : Nm (kg-m, in/lb)

EMM0578

CYLINDER HEAD



Installation (On-Vehicle Service) (Cont'd)

2. Install the Cylinder Head.

Cylinder Head identification mark:

Identification number (on cylinder head)
Float mark
5

3. Apply oil to the thread portion and seat surface of Bolts and tighten Cylinder Head Bolts using Tool.

CAUTION

• Tightening procedure

1st:

**Tighten Bolts to 39 - 44 Nm
(4.0 - 4.5 kg-m, 29 - 33 ft/lb)**

2nd:

**Tighten Bolts to 59 - 64 Nm
(6.0 - 6.5 kg-m, 43 - 47 ft/lb)**

3rd:

- Mark exhaust side of Cylinder Head and Cylinder Head Bolts with paint as shown.
- Turn all Bolts 90±10 degrees clockwise.
- Check to ensure the paint mark of each Bolt is facing the front of the vehicle.

4. Apply engine oil and install Push Rods.

5. Install the Rocker Shaft Assembly.

Rocker Shaft Bracket Bolt:

 20 - 25 Nm (2.0 - 2.5 kg-m, 168 - 216 in/lb)

NOTE:

Adjust intake and exhaust Valve clearances temporarily. Refer to ET section.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

ENGINE OVERHAUL

Inspection and Replacement (Cont'd)

Connecting Rod Bearing Clearance

Connecting rod bearing clearance:

Standard

0.035 - 0.081 mm (0.0014 - 0.0032 in)

Limit

Less than 0.15 mm (0.0059 in)

1. Install the Connecting Rod Bearing to the Connecting Rod and Cap.
2. Install the Connecting Rod Cap to the Connecting Rod.

NOTE:

Apply oil to the thread portion of Bolts and seating surface of Nuts.

3. Measure the inside diameter "A" of Bearing.
4. Measure the outside diameter "Dp" of the Pin Journal in the Crankshaft.
5. Calculate the Connecting Rod Bearing clearance.

$$\text{Connecting Rod Bearing clearance} = A - Dp$$





Connecting Rod Bend and Torsion

Bend and torsion:

Limit

0.05 mm (0.0020 in)

per 100 mm (3.94 in) length



Connecting Rod Small End Bushing Clearance

1. Measure the inside diameter "A" of the Connecting Rod Small End Bushings.
2. Measure the outside diameter "D" of the Piston Pin.
3. Calculate the Connecting Rod Small End Bushing clearance.

$$\text{Connecting rod small end bushing clearance} = A - D$$

Bushing clearance:

Standard

0.025 - 0.045 mm (0.0010 - 0.0018 in)

Limit

0.15 mm (0.0059 in)

ENGINE OVERHAUL


Assembly (Cont'd)

- d. Install the Crankshaft Thrust Washer at the 4th Journal from front.

NOTE:

Install the Thrust Washer so the Oil Groove can face the Crankshaft.

- e. Tighten the Main Bearing Cap Bolts gradually in stages, starting from two to three separate stages, from center Bearing and moving outward in sequence.

 : 167 - 177 Nm (17.0 - 18.0 kg-m, 123 - 130 ft/lb)

- f. Measure Crankshaft free end play at No. 4 Bearing.

Crankshaft free end play: mm (in)

Standard





0.055 - 0.140 (0.0022 - 0.0055)

Limit

0.40 (0.0157)

NOTE:

If Crankshaft free end play is beyond the limit, replace No. 4 Main Bearing Thrust Washer. Refer to "SERVICE DATA AND SPECIFICATIONS".



TROUBLE DIAGNOSES AND CORRECTIONS

Engine Lubrication System

Condition	Probable Cause	Corrective Action
Oil leakage	Damaged or cracked Pump body cover.	Replace.
	Oil leakage from Gasket and Oil Seal.	Replace.
	Oil leakage from Regulator Valve.	Tighten or replace.
	Oil leakage from Blind Plug.	Replace.
Decreased oil pressure	Lack of oil in engine Oil Pan.	Correct.
	Dirty Oil Strainer.	Clean or replace.
	Damaged or worn Pump Rotors.	Replace.
	Malfunctioning Regulator.	Replace.
	Use of poor quality engine oil.	Replace.
Warning lamp remains "on" - engine running	Decreased oil pressure.	Previously mentioned.
	Oil Pressure Switch unserviceable.	Replace.
	Electrical fault.	Check circuit.
Noise	Excessive backlash in Pump Gears.	Replace.

COOLING SYSTEM

Cooling System Inspection

Checking Hoses

Check hoses for proper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.



Checking Radiator Cap

Apply pressure to the Radiator Cap by means of a Cap Tester to confirm pressure capacity.

Radiator Cap relief pressure:

78 - 98 kPa

(0.78 - 0.98 bar, 0.8 - 1.0 kg/cm², 11 - 14 psi)



Checking Cooling System for Leaks

Apply pressure to the cooling system by means of a tester to check for leakage.

Testing pressure:


98 kPa (0.98 bar, 1.0 kg/cm², 14 psi)



CAUTION

- Higher than the specified pressure may cause Radiator damage.

INJECTION PUMP






Removal

1. Remove the Injection Tube.



CAUTION

- **Cover the Injection Nozzle Assembly with a plug to prevent dust entry.**
2. Remove the Fuel Cut Solenoid Wire.
 3. Remove the Accelerator Wire and disconnect the Spill Hose, Fuel Inlet Hose and Fuel Return Hose.
 4. Separate the Flare Nut at the Injection Pump.
 5. Remove the Dust Cover and loosen the Injection Pump Drive Gear Nut.



BLEEDING FUEL SYSTEM

Bleeding Fuel System (Engine on Vehicle)



- Air should be bled out of fuel system when the Injection Pump is removed or fuel system is repaired.
- Protect the Pump and Engine Mounts from fuel splash with rags.
- If the Engine will not start after bleeding air, loosen the Injection Tubes at the Nozzle side and crank the Engine until fuel overflows from Injection Tube. Tighten the Injection Tube Flare Nuts.

NOTE:

If the Engine does not operate smoothly after it has started, race it two or three times.

Without Air Vent Screw

Method A

Move the Priming Pump up and down until there is suddenly more resistance in the movement.




Method B

1. Loosen the Injection Pump Bleeder Screw/or disconnect the Return Hose and prime.
2. Make sure fuel overflows at the Bleeder Screw/Tube end, then tighten it/connect the Hose.

With Air Vent Screw

Method A

1. Loosen the Air Vent Screw (1).
2. Move the Priming Pump (2) up and down until no further airbleed comes out of the Air Vent Screw (1).
3. Tighten the Air Vent Screw (1).
4. Move the Priming Pump (2) up and down until there is suddenly more resistance in the movement.



BATTERY

Charging



CAUTION

- Carry out charging with negative cable removed.
- Do not allow electrolyte temperature to go over 45°C (113°F).

Clean a corroded terminal with a brush and common baking-soda solution.



WARNING


- Keep the Battery away from open flames, arcs, sparks or lit cigarettes while it is being charged.
- Have a well-ventilated working area.
- When connecting the charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.

Battery Freezing



CAUTION

- Use extreme caution to avoid freezing a Battery.



CHARGING SYSTEM

Disassembly (Cont'd)

3. Remove the Attaching Nuts and take out the Stator Assembly.





Rotor

Pull the Rear Bearing off from the Rotor Assembly with a press or Bearing Puller.

Once removed, the Bearing cannot be reused. Replace with a new one.

Stator

Disconnect the Stator Coil Lead Wires from the Diode Terminals



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL