



FZ6-SS FZ6-SSC

SERVICE MANUAL

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SWINGARM AND DRIVE CHAIN	4-68
REMOVING THE SWINGARM	4-70
REMOVING THE DRIVE CHAIN	4-71
CHECKING THE SWINGARM	4-71
INSTALLING THE SWINGARM	4-72
CHECKING THE DRIVE CHAIN	4-73

CHAPTER 5 ENGINE




ENGINE	5-1
DRIVE SPROCKET	5-1
EXHAUST PIPE	5-2
LEADS AND HOSES	5-3
ENGINE	5-5
INSTALLING THE ENGINE	5-6
CAMSHAFTS	5-8
CYLINDER HEAD COVER	5-8
CAMSHAFTS	5-9
REMOVING THE CAMSHAFTS	5-11
CHECKING THE CAMSHAFTS	5-12
CHECKING THE TIMING CHAIN, CAMSHAFT SPROCKETS, AND TIMING CHAIN GUIDES	5-14
CHECKING THE TIMING CHAIN TENSIONER	5-14
INSTALLING THE CAMSHAFTS	5-15
CYLINDER HEAD	5-19
REMOVING THE CYLINDER HEAD	5-20
CHECKING THE CYLINDER HEAD	5-20
INSTALLING THE CYLINDER HEAD	5-21
VALVES AND VALVE SPRINGS	5-22
REMOVING THE VALVES	5-24
CHECKING THE VALVES AND VALVE GUIDES	5-25
CHECKING THE VALVE SEATS	5-27
CHECKING THE VALVE SPRINGS	5-29
CHECKING THE VALVE LIFTERS	5-30
INSTALLING THE VALVES	5-30
STARTER CLUTCH AND GENERATOR	5-32
STATOR COIL ASSEMBLY	5-32
REMOVING THE GENERATOR	5-34
REMOVING THE STARTER CLUTCH	5-35
CHECKING THE STARTER CLUTCH	5-36
INSTALLING THE STARTER CLUTCH	5-36
INSTALLING THE GENERATOR	5-37

Clock mode

To set the clock:

1. Push the “SELECT” button and “RESET” button together for at least two seconds.
2. When the hour digits start flashing, push the “RESET” button to set the hours.
3. Push the “SELECT” button, and the minute digits will start flashing.
4. Push the “RESET” button to set the minutes.
5. Push the “SELECT” button and then release it to start the clock.



Item	Standard	Limit
Camshafts		
Drive system Camshaft cap inside diameter Camshaft journal diameter Camshaft-journal-to-camshaft-cap clearance Intake camshaft lobe dimensions	Chain drive (right) 23.008 ~ 23.029 mm (0.9058 ~ 0.9067 in) 22.967 ~ 22.980 mm (0.9042 ~ 0.9047 in) 0.028 ~ 0.062 mm (0.0011 ~ 0.0024 in) 0.08 mm (0.0032 in)
		
Measurement A	32.45 ~ 32.55 mm (1.278 ~ 1.282 in)	32.40 mm (1.276 in)
Measurement B	24.95 ~ 25.05 mm (0.982 ~ 0.986 in)	24.90 mm (0.980 in)
Exhaust camshaft lobe dimensions		
		
Measurement A	32.45 ~ 32.55 mm (1.278 ~ 1.282 in)	32.40 mm (1.276 in)
Measurement B	24.95 ~ 25.05 mm (0.982 ~ 0.986 in)	24.90 mm (0.980 in)
Max. camshaft runout	...	0.06 mm (0.0024 in)
		



ELECTRICAL SPECIFICATIONS

Item	Standard	Limit
System voltage	12 V	...
Ignition system		
Ignition system type	DC. T.C.I.	...
Ignition timing	5° BTDC at 1,300 r/min	...
Advancer type	Digital	...
Crankshaft position sensor resistance/color	248 ~ 372 Ω at 20°C (68°F)/Gy-B	...
T.C.I. unit model (manufacturer)	F8T811 (MITSUBISHI)	...
Ignition coils		
Model (manufacturer)	JO383 (DENSO)	...
Minimum ignition spark gap	6 mm (0.24 in)	...
Primary coil resistance	1.53 ~ 2.07 Ω at 20°C (68°F)	...
Secondary coil resistance	12.0 ~ 18.0 kΩ at 20°C (68°F)	...
Spark plug cap		
Material	Resin	...
Resistance	10.0 kΩ at 20°C (68°F)	...
Charging system		
System type	A.C. magneto	...
Model (manufacturer)	F5VX (MORIC)	...
Normal output	14 V/310 W at 5,000 r/min	...
Stator coil resistance/color	0.22 ~ 0.34 Ω at 20°C (68°F)/W-W	...
Rectifier/regulator		
Regulator type	Semi conductor short circuit	...
Model (manufacture)	SH719AA (SHINDENGEN)	...
No-load regulated voltage	14.1 ~ 14.9 V	...
Rectifier capacity	18 A	...
Withstand voltage	240 V	...
Battery		
Battery type	GT12B-4	...
Battery voltage/capacity	12 V/10 Ah	...
Specific gravity	1.320	...
Manufacturer	GS	...
Ten hour rate amperage	1.0 A	...
Headlight type	Halogen bulb	
Bulbs (voltage/wattage × quantity)		
Headlight	12V 60 W/55 W × 1	...
	12 V 55 W × 1	...
Tail/brake light	12 V 5 W/21 W × 1	...
Front turn signal/position light	12 V 21 W/5 W × 2	...
Rear turn signal light	12 V 21 W × 2	...
Licence light	12 V 5 W × 1	...
Meter light	EL	...




EAS00032

CHASSIS

Lubrication point	Lubricant
Steering bearings and bearing races (upper and lower)	
Front wheel oil seal (right and left)	
Rear wheel oil seal	
Rear wheel drive hub oil seal	
Rear wheel drive hub mating surface	
Rear brake pedal shaft	
Sidestand pivoting point and metal-to-metal moving parts	
Link and sidestand switch contact point	
Throttle grip inner surface	
Brake lever pivoting point and metal-to-metal moving parts	
Clutch lever pivoting point and metal-to-metal moving parts	
Rear shock absorber collar	
Pivot shaft	
Swingarm pivot bearing	
Swingarm head pipe end, oil seal and bush	
Engine mount bolts (rear upper and lower)	
Shift pedal shaft	
Shift shaft joint	
Rear footrest ball and metal-to-metal moving parts	
Main stand metal-to-metal moving parts	




- ① Cylinder head
- ② Intake camshaft
- ③ Exhaust camshaft
- ④ Crankshaft






- A** Either right or left side arrangement for the left handlebar switch lead coupler and radiator fan motor coupler can be accepted.
- B** Point the L-shape terminal to the front side of the vehicle.
- C** Hook the starter motor lead to the alternate pawls on the battery cover.
- D** Route the crank shaft position sensor lead above the starter motor leads.
- E** To the crankshaft position sensor.
- F** Clamp the starter motor lead and crank shaft position sensor lead. Point the projected part of the tip to the inner side of the vehicle.
- G** Pass the radiator hose, coolant reservoir hose, wire harness and starter motor lead in order through the lower side of the vehicle.
- H** Set the 4-pin coupler in the connector cover after wiring it.
- I** To the sidestand switch.
- J** To the speed sensor.
- K** To the A.C. magneto.
- L** To the oil level gauge.
- M** To the rear brake/light switch.
- N** To the neutral switch.
- O** Push the wire harness in the groove of the mud guard.
- P** Point the opening section of the clamp upward.
- Q** To the rear turn signal (right)
- R** To the rear turn signal (left)



EAS00040

FUEL TANK



Order	Job/Part	Q'ty	Remarks
	Removing the fuel tank		Remove the parts in the order listed. Disconnect. Refer to "SEAT". Refer to "COWLINGS".
	Seat		
	Front cowling inner panel (left and right)		
1	Fuel hose	1	
2	Fuel sender coupler	1	
3	Fuel pump coupler	1	
4	Fuel tank drain hose	1	
5	Fuel tank breather hose (except for CAL) Canister hose (for CAL)	1	NOTE: _____ There is a white paint mark on the fuel tank breather hose.
6	Fuel tank	1	
7	Fuel pump	1	

- c. Round off the original valve pad number according to the following table.

Last digit	Rounded value
0 or 2	0
5	5
8	10

EXAMPLE:


Original valve pad number
= 148 (thickness = 1.48 mm (0.058 in))

Rounded value = 150

- d. Locate the rounded number of the original valve pad and the measured valve clearance in the valve pad selection table. The point where the column and row intersect is the new valve pad number.

NOTE: _____

The new valve pad number is only an approximation. The valve clearance must be measured again and the above steps should be repeated if the measurement is still incorrect.



- e. Install the new valve pad ① and the valve lifter ②.

NOTE: _____

- Lubricate the valve pad with molybdenum disulfide grease.
- Lubricate the valve lifter with molybdenum disulfide oil.
- Install the valve lifter and the valve pad in the correct place.
- The valve lifter must turn smoothly when rotated by hand.


- f. Install the exhaust and intake camshafts, timing chain and camshaft caps.

	<p>Camshaft cap bolt 10 Nm (1.0 m•kg, 7.2 ft•lb)</p>
--	---



7. Install:

- spark plug
- spark plug caps

 **18 Nm (1.8 m•kg, 13 ft•lb)**

NOTE: _____

Before installing the spark plug, clean the spark plug and gasket surface.

8. Install:

- radiator lower hose bracket bolt
- radiator lower bolt

EAS00065

**MEASURING THE COMPRESSION
PRESSURE**

The following procedure applies to all of the cylinders.

NOTE: _____

Insufficient compression pressure will result in a loss of performance.

1. Measure:

- valve clearance

Out of specification → Adjust.

Refer to “ADJUSTING THE VALVE CLEARANCE”.

2. Start the engine, warm it up for several minutes, and then turn it off.

3. Remove:

- rider seat

Refer to “SEAT”.

- front cowling inner panel (left and right)

Refer to “COWLINGS”.

- fuel tank

Refer to “FUEL TANK”.

- air filter case

Refer to “AIR FILTER CASE”.

- battery

Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3.

- battery box

- battery box bracket

Refer to “BATTERY BOX AND BATTERY BOX BRACKET”.

- heat protector plate

4. Remove:

- cover
- ignition coils
- spark plug caps
- spark plugs

NOTE:

When installing the air filter element into the air filter case cover, make sure their sealing surfaces are aligned to prevent any air leaks.


6. Install:
 - fuel tank
Refer to “FUEL TANK”.
 - front cowl inner panel (left and right)
Refer to “COWLINGS”.
 - rider seat
Refer to “SEAT”.

EAS00095

CHECKING THE THROTTLE BODY JOINTS

The following procedure applies to all of the throttle body joints and intake manifolds.

1. Remove:
 - throttle bodies
Refer to “THROTTLE BODIES” in chapter 7.
2. Check:
 - throttle body joints ①
Cracks/damage → Replace.
3. Install:
 - throttle bodies
Refer to “THROTTLE BODIES” in chapter 7.



ADJUSTING THE REAR BRAKE/ CHECKING THE BRAKE FLUID LEVEL

CHK
ADJ



3. Adjust:

- rear brake light switch

Refer to “ADJUSTING THE REAR BRAKE LIGHT SWITCH”.



EAS00115

CHECKING THE BRAKE FLUID LEVEL

1. Stand the motorcycle on a level surface.

NOTE:

- Place the motorcycle on a suitable stand.
- Make sure the motorcycle is upright.



2. Check:

- brake fluid level

Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.




Recommended brake fluid
DOT 4

- A Front brake
- B Rear brake


⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

Charging method using a constant voltage charger



I8350102




I2010201

- c. Remove the wheel bearings ③ with a general bearing puller.
- d. Install the new wheel bearings and oil seals in the reverse order of disassembly.

CAUTION:

Do not contact the wheel bearing inner race ① or balls ②. Contact should be made only with the outer race ③.



Use a socket ④ that matches the diameter of the wheel bearing outer race and oil seal.




EAS00531

CHECKING THE BRAKE DISCS


The following procedure applies to all of the brake discs.

- 1. Check:
 - brake disc
 - Damage/galling → Replace.



I2210202

- 2. Measure:
 - brake disc deflection
 - Out of specification → Correct the brake disc deflection or replace the brake disc.

	Brake disc deflection limit (maximum)
	Front: 0.1 mm (0.004 in)
	Rear: 0.15 mm (0.006 in)

- a. Place the motorcycle on a suitable stand so that the wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 2 ~ 3 mm (0.08 ~ 0.12 in) below the edge of the brake disc.





EAS00575

ADJUSTING THE REAR WHEEL STATIC BALANCE


NOTE: _____

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
 - Adjust the rear wheel static balance with the brake disc and rear wheel drive hub installed.
-

1. Adjust:


- rear wheel static balance
Refer to “ADJUSTING THE FRONT WHEEL STATIC BALANCE”.

EAS00585



Order	Job/Part	Q'ty	Remarks
	Disassembling the front brake master cylinder		Disassemble the parts in the order listed.
①	Dust boot	1	
②	Circlip	1	
③	Master cylinder kit	1	
④	Spring	1	
⑤	Master cylinder	1	
⑥	Push rod	1	
			For assembly, reverse the disassembly procedure.


EAS00615



Order	Job/Part	Q'ty	Remarks
	Disassembling the front brake calipers		Disassemble the parts in the order listed. NOTE: _____ The following procedure applies to both of the front brake calipers. _____
①	Brake pad	2	
②	Brake caliper piston	2	
③	Brake caliper piston seal	4	
④	Brake pad spring	1	
⑤	Bleed screw	1	
			For assembly, reverse the disassembly procedure.

EAS00647


FRONT FORK
FRONT FORK LEGS



Order	Job/Part	Q'ty	Remarks
	Removing the front fork legs		Remove the parts in the order listed.
	Front wheel		Refer to "FRONT WHEEL AND BRAKE DISCS".
	Front brake calipers		Refer to "FRONT AND REAR BRAKES".
1	Front fender	1	
2	Cap bolt	1	Loosen.
3	Upper bracket pinch bolt	1	Loosen.
4	Under bracket pinch bolt	1	Loosen.
5	Front fork leg	1	
			For installation, reverse the removal procedure.

EAS00664

HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	Removing the handlebar		Remove the parts in the order listed.
1	Grip end	2	
2	Handlebar grip (left)	1	
3	Clutch switch connector	1	Disconnect.
4	Left handlebar switch	1	
5	Clutch cable	1	
6	Clutch lever	1	
7	Right handlebar switch	1	
8	Throttle grip	1	
9	Throttle cable	2	
10	Front brake light switch connector	1	Disconnect.
11	Front brake master cylinder holder	1	
12	Front brake master cylinder	1	
13	Upper handlebar holder	2	
14	Handlebar	1	For installation, reverse the removal procedure.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

EAS00694

REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.

2. Remove:

- rear wheel



Refer to “REAR WHEEL AND BRAKE DISC”.

3. Remove:

- rear shock absorber assembly lower bolt ①

NOTE:

While removing the rear shock absorber assembly lower bolt, hold the swingarm so that it does not drop down.




4. Remove:

- rear shock absorber assembly upper bolt ①
- rear shock absorber assembly

EAS00188


ENGINE

ENGINE DRIVE SPROCKET



5

Order	Job/Part	Q'ty	Remarks
	Removing the drive sprocket		
	Drive chain		Loosen. Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.
1	Lock nut	2	Loosen.
2	Shift rod	1	
3	Shift arm	1	
4	Drive sprocket cover	1	
5	Nut	1	
6	Lock washer	1	
7	Drive sprocket	1	
			For installation, reverse the removal procedure.



EAS00198

REMOVING THE CAMSHAFTS


1. Remove:
 - pickup rotor cover
 Refer to "CRANKSHAFT POSITION SENSOR AND PICKUP ROTOR".
2. Align:
 - "T" mark (a) on the pickup rotor (with the crankcase mating surface (b))




- a. Turn the crankshaft clockwise.
- b. When piston #1 is at TDC on the compression stroke, align the "T" mark (a) on the pickup rotor with the crankcase mating surface (b).

NOTE: _____


TDC on the compression stroke can be found when the camshaft lobes are turned away from each other.



3. Loosen:
 - camshaft sprocket bolts (1)





4. Loosen:
 - cap bolt (2)
5. Remove:
 - timing chain tensioner (3)
 - gasket



6. Remove:
 - timing chain guide (exhaust side)
 - camshaft caps (4)
 - dowel pins

CAUTION: _____

To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a criss-cross pattern, working from the outside in.





EAS00233


INSTALLING THE CYLINDER HEAD

1. Install:
 - gasket **New** ①
 - dowel pins ②
2. Install:
 - cylinder head

NOTE: _____
 Pass the timing chain through the timing chain cavity.

3. Tighten:
 - cylinder head bolts ① ~ ⑩


1st	 19 Nm (1.9 m•kg, 14 ft•lb)
2nd	 50 Nm (5.0 m•kg, 36 ft•lb)
 - cylinder head bolts ⑪, ⑫

	12 Nm (1.2 m•kg, 8.7 ft•lb)
---	------------------------------------

NOTE: _____

- Lubricate the cylinder head bolts with engine oil.
- Tighten the cylinder head bolts in the proper tightening sequence as shown and torque them in two stages.
- First, tighten the bolts ① ~ ⑩ to approximately 19 Nm (1.9 m•kg, 14 ft•lb) with a torque wrench and then tighten the 50 Nm (5.0 m•kg, 36 ft•lb).


4. Install:
 - exhaust camshaft
 - intake camshaft
 Refer to “INSTALLING THE CAMSHAFTS”.



NOTE: _____

- Make sure that each valve is installed in its original place.
- Install the valve springs with the larger pitch (a) facing up.

(b) Smaller pitch



4. Install:


- valve cotters (1)

NOTE: _____

Install the valve cotters by compressing the valve springs with the valve spring compressor (2) and the valve spring compressor attachment (3).




Valve spring compressor
90890-04019, YM-04019
Valve spring compressor attachment
90890-04108, YM-01253



5. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.

CAUTION: _____

Hitting the valve tip with excessive force could damage the valve.




6. Install:

- valve pad (1)
- valve lifter (2)

NOTE: _____

- Lubricate the valve lifter and valve pad with molybdenum disulfide oil.
- The valve lifter must move smoothly when rotated with a finger.
- Each valve lifter and valve pad must be reinstalled in its original position.


11171102



EAS00328

CHECKING THE SHIFT SHAFT


1. Check:
 - shift shaft ①
Bends/damage/wear → Replace.
 - shift shaft spring ②
Damage/wear → Replace.



EAS00330

CHECKING THE STOPPER LEVER

1. Check:
 - stopper lever ①
Bends/damage → Replace.
 - Roller turns roughly → Replace the stopper lever.



EAS00332

INSTALLING THE SHIFT SHAFT

1. Install:
 - shift shaft spring stopper ①

22 Nm (2.2 m•kg, 16 ft•lb)

- washers
- shift shaft ②

NOTE:

- Apply LOCTITE® to the threads of the shift shaft spring stopper.
- Hook the ends ③ of the stopper lever spring onto the stopper lever ④ and the crankcase boss.
- Mesh the stopper lever with the shift drum segment assembly.


2. Install:
 - shift shaft cover

NOTE:


Lubricate the oil seal lips with lithium-soap-based grease.

2. Measure:

- clutch spring free length ①
Out of specification → Replace the clutch springs as a set.



Clutch spring free length
55 mm (2.17 in)
<Limit>: 52.3 mm (2.06 in)



EAS00284

CHECKING THE CLUTCH HOUSING

1. Check:


- clutch housing dogs
Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE: _____

Pitting on the clutch housing dogs will cause erratic clutch operation.

2. Check:

- bearing
Damage/wear → Replace the bearing and clutch housing.



EAS00285


CHECKING THE CLUTCH BOSS

1. Check:

- clutch boss splines
Damage/pitting/wear → Replace the clutch boss.

NOTE: _____

Pitting on the clutch boss splines will cause erratic clutch operation.




EAS00286

CHECKING THE PRESSURE PLATE

1. Check:

- pressure plate ①
Cracks/damage → Replace.
- bearing ②
Damage/wear → Replace.



EAS00378

INSTALLING THE OIL STRAINER

1. Install:
- oil strainer ①
 - relief valve ②


NOTE: _____


Make sure to check the arrow mark (a) located on the oil strainer housing for the front and rear direction of the engine and then install the oil strainer so that its arrow mark points to the front side of the engine.


EAS00380

INSTALLING THE OIL PAN

1. Install:
- oil pipe
 - oil delivery pipe
2. Install:
- dowel pins
 - gasket **New**
 - oil pan ①
 - oil level switch ②

 **12 Nm (1.2 m•kg, 8.7 ft•lb)**

 **10 Nm (1.0 m•kg, 7.2 ft•lb)**


 **43 Nm (4.3 m•kg, 31 ft•lb)**


⚠ WARNING _____

Always use new copper washers.

NOTE: _____

- Tighten the oil pan bolts in stages and in a crisscross pattern.
- Lubricate the oil level switch O-ring with engine oil.



**Piston ring side clearance****Top ring**

0.030 ~ 0.065 mm
 (0.0012 ~ 0.0026 in)
 <Limit>: 0.115 mm (0.0045 in)

2nd ring

0.030 ~ 0.065 mm
 (0.0012 ~ 0.0026 in)
 <Limit>: 0.125 mm (0.0049 in)

2. Install:

- piston ring
 (into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.

Ⓐ 5 mm (0.20 in)

3. Measure:

- piston ring end gap
 Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

**Piston ring end gap****Top ring**

0.25 ~ 0.35 mm
 (0.0098 ~ 0.0138 in)
 <Limit>: 0.60 mm (0.0236 in)

2nd ring

0.7 ~ 0.8 mm
 (0.0276 ~ 0.0315 in)
 <Limit>: 1.15 mm (0.0453 in)

Oil ring


0.10 ~ 0.35 mm
 (0.0039 ~ 0.0138 in)

CHECKING THE PISTON PINS

The following procedure applies to all of the piston pins.

1. Check:

- piston pin
 Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.




Order	Job/Part	Q'ty	Remarks
⑮	Bearing housing	1	For installation, reverse the removal procedure.
⑯	Bearing	1	



EAS00456

INSTALLING THE RADIATOR

1. Install:
 - radiator
 - coolant hoses
2. Fill:
 - cooling system
(with the specified amount of the recommended coolant)
Refer to “CHANGING THE COOLANT” in chapter 3.
3. Check:
 - cooling system
Leaks → Repair or replace any faulty part.
4. Measure:
 - radiator cap opening pressure
Below the specified pressure → Replace the radiator cap.
Refer to “CHECKING THE RADIATOR”.



EAS00473


CHECKING THE WATER PUMP

1. Check:
 - water pump housing ①
 - water pump cover ②
 - impeller ③
 - rubber damper ④
 - rubber damper holder ⑤
 - water pump seals
 - oil seal

Cracks/damage/wear → Replace.
2. Check:
 - bearing

Rough movement → Replace.
3. Check:
 - water pump outlet hose
 - radiator outlet hose

Cracks/damage/wear → Replace.



EAS00475


ASSEMBLING THE WATER PUMP

1. Install:
 - bearing
 - oil seal **New** ①

(into the water pump housing ②)

NOTE: _____

- Before installing the oil seal, apply tap water or coolant onto its out surface.
 - Install the oil seal with a socket that matches its outside diameter.
- _____



2. Install:
 - water pump seal **New** ①

CAUTION: _____

Never lubricate the water pump seal surface with oil or grease.

NOTE: _____

- Install the water pump seal with the special tools.
 - Before installing the water pump seal, apply Yamaha bond No.1215 or Quick Gasket ② to the water pump housing ③.
- _____






7. Verify the operation of the sensor or actuator.
 - Sensor operation
The data representing the operating conditions of the sensor appears on the trip LCD.
 - Actuator operation
Set the engine stop switch to “ON” to operate the actuator.
* If the engine stop switch is set to “ON”, set it to “OFF”, and then set it to “ON” again.
8. Turn the main switch to “OFF” to cancel the the diagnostic mode.

NOTE: _____

To perform a reliable diagnosis, make sure to turn “OFF” the power supply before every check and then start right from the beginning.



Fault code No.	30	Symptom	The motorcycle has overturned.
Used diagnostic code No. 08 (lean angle cut-off switch)			
Order	Inspection operation item and probable cause	Operation item and countermeasure	Reinstatement method
1	The motorcycle has overturned.	Raise the motorcycle upright.	Reinstated by turning the main switch ON (however, the engine cannot be restarted unless the main switch is first turned OFF).
2	Installed condition of the lean angle cut-off switch	Check the installed area for looseness or pinching.	
3	Connected condition of connector Inspect the coupler for any pins that may have pulled out. Check the locking condition of the coupler.	If there is a malfunction, repair it and connect it securely. Lean angle cut-off switch coupler Main wiring harness ECU coupler	
4	Defective lean angle cut-off switch	Execute the diagnostic mode (code No. 08) Replace if defective. <ol style="list-style-type: none"> 1. Remove the lean angle cut-off switch from the motorcycle. 2. Connect the lean angle cut-off switch coupler to the wireharness. 3. Connect the pocket tester (DC 20 V) to the lean angle cut-off switch coupler as shown. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p style="margin: 0;">Tester positive probe → blue ①</p> <p style="margin: 0;">Tester negative probe → yellow/green ②</p> </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div> <ol style="list-style-type: none"> 4. When turning the lean angle cut-off switch approx. 65°, the voltage reading change from 1.0 V to 4.0 V. 5. Is the emergency stop switch OK? 	



EAS00730

CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:

Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end of the coupler ① taking care not to loosen or damage the leads.



Pocket tester
90890-03112, YU-3112

NOTE:

- Before checking for continuity, set the pocket tester to “0” and to the “Ω × 1” range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.

The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.


NOTE:

“○—○” indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between red and brown/red when the switch is set to “P”.

There is continuity between red, brown/blue and brown/red when the switch is set to “ON”.



EAS00754

15. Wiring

- Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?





Replace the ECU.



Properly connect or repair the ignition system's wiring.


STARTER MOTOR

ELEC



3. Install:

- starter motor yoke ①
- O-ring ② **New**
- front cover ③
- rear cover ④
- bolts ⑤

 **3.4 Nm (0.34 m•kg, 2.5 ft•lb)**

NOTE:

Align the match marks (a) on the starter motor yoke with the match marks (b) on the front and starter motor rear covers.



EAS00790

3. The tail/brake light fails to come on.

1. Tail/brake light bulb and socket

- Check the tail/brake light bulb and socket for continuity. Refer to “CHECKING THE BULBS AND BULB SOCKETS”.
- Are the tail/brake light bulb and socket OK?

↓ YES


↓ NO

Replace the tail/brake light bulb, socket or both.

2. Voltage

- Connect the pocket tester (DC 20 V) to the tail/brake light coupler (wire harness side) as shown.

Positive tester probe → blue ①
Negative tester probe → black ②



- Turn the main switch to “ON”.
- Measure the voltage (DC 12 V) of blue ② on the tail/brake light coupler (wire harness side).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.

Wiring circuit from the main switch to the tail/brake light coupler is faulty and must be repaired.

EAS00791

4. The turn signal/position light fails to come on.

1. Turn signal/position light and socket

- Check the turn signal/position light bulb and socket for continuity. Refer to “CHECKING THE BULBS AND BULB SOCKETS”.
- Are the turn signal/position light bulb and socket OK?

↓ YES

↓ NO



Replace the turn signal/position light bulb, socket or both.

2. Voltage

- Connect the pocket tester (DC 20 V) to the turn signal/position light coupler (wire harness side) as shown.

- A** Left turn signal/position light
- B** Right turn signal/position light

Left turn signal/position light
Positive tester probe → blue ①
Negative tester probe → black ②
Right turn signal/position light
Positive tester probe → blue/red ③
Negative tester probe → black ④



- Turn the main switch to “ON”.
- Measure the voltage (DC 12 V) of blue ① or blue/red ③ on the turn signal/position light coupler (wire harness side).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.


The wiring circuit from the main switch to the turn signal/position light coupler is faulty and must be repaired.



EAS00807

**COOLING SYSTEM
CIRCUIT DIAGRAM**

- ① Main switch
- ⑥ Fuse (main)
- ⑨ Battery
- ⑱ Coolant temperature sensor
- ⑳ ECU
- ④② Fuse (radiator fan motor)
- ④③ Radiator fan motor relay
- ④④ Radiator fan motor
- ④⑦ Fuse (ignition)





TROUBLESHOOTING

The warning light starts to indicate the self-diagnosis sequence.

Check:

1. fuel pump thermistor
2. oil level switch

NOTE:

• Before troubleshooting, remove the following part(-s):


1. seat
2. front cowling inner panel (left and right)
3. fuel tank

• Troubleshoot with the following special tool(-s).



Pocket tester
90890-03112, YU-3112

1. Fuel pump thermistor
CIRCUIT DIAGRAM



- ⑬ Fuel pump
- ⑳ Multi-function meter

1. Wire harness

- Check the wire harness for continuity. Refer to "CIRCUIT DIAGRAM".
- Is the wire harness OK?



Repair or replace the wire harness.

2. Fuel pump thermistor

- Check the fuel pump thermistor for continuity. Refer to "The fuel level indicator light fails to come on".
- Is the fuel pump thermistor OK?



Replace the multi-function meter.

Replace the fuel pump.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL