

**YANMAR**

**SERVICE MANUAL**

**WHEEL LOADER**

**V7**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# 1. GENERAL CAUTIONS FOR MAINTENANCE WORK

- (3) When the hose is pressurized, the hose length varies slightly at the bend. Allow this change to occur and do not try to fasten the bend.




- (4) It is necessary for the hose to have ample slackness for elongation and contraction, because its length will change by +2 % to -4 % when used at high pressure.




- (5) Use the proper adapters, not pipes, in order to reduce the number and length of joints and improve the external appearance.



- (6) Use an elbow to prevent excessive twisting or bending of the hose.



- (7) Use adapters to make the hose as straight as possible. The outside appearance can be improved by avoiding the use of hoses that are too long.



## 2. TECHNICAL DATA

Item	Unit	V7
<b>Main specifications of machine</b>		
<b>Transmission</b>		
Type	-	HYDROMATIK Closed circuit hydraulic transmissione)
Pump	-	With variable displacement
Hydrostatic motor	-	With double displacement
<b>Axle</b>		
Front	-	Rigid
Rear	-	Oscillating
Oscillating	Deg	20
Total reduction	-	16,91 : 1
Differential reducers	-	Conventional (automatic proportional limited-slip differential)
Final gears	-	Epicyclic reducers
<b>Brake</b>		
Service	-	Drum - type on the front axle working on all the wheels
Parking	-	Manual lever on the drum type of the front axle
<b>Engine</b>		
<b>Main specifications</b>		
Engine model	-	4TNV88-BDSA2
Type	-	Vertical type series water- cooled 4cycle diesel engine
Combustion system	-	Direct injection
Number of cylinders - Bore × Stroke	pcs - mm x mm	4 - ø88 x 90
Total displacement	cm <sup>3</sup>	2190
Rated output / engine speed (GROSS)	kW/rpm	35 / 3000
Compression pressure at 250 rpm	Mpa	3.33 - 3.53
Specific fuel consumption	L/h	-
Maximum idling speed	rpm	3235
Minimum idling speed	rpm	3185
Engine dry mass (excluding air cleaner and silencer)	kg	170
Lubricating method	-	Forced lubrication with trochoid pump
Specific lubricating oil consumption	g/kW•h	-

## 2. TECHNICAL DATA

### **2-7 Electrical Diagram**

To consult the electrical diagrams, refer to the specific chapter "5-2 Electrical diagram" on page 5-2-1.

## 4. ENGINE

### WARNING

#### EXHAUST HAZARD!



- NEVER operate the engine in an enclosed area such as a garage, tunnel, underground room, manhole or ship's hold without proper ventilation.
- NEVER block windows, vents, or other means of ventilation if the engine is operating in an enclosed area. All internal combustion engines create carbon monoxide gas during operation. Accumulation of this gas within an enclosure could cause illness or even death.
- Make sure that all connections are tightened to specifications after repair is made to the exhaust system.
- Failure to comply could result in death or serious injury.

### WARNING

#### ALCOHOL AND DRUG HAZARD!



- NEVER operate the engine while you are under the influence of alcohol or drugs.
- NEVER operate the engine when you are feeling ill.
- Failure to comply could result in death or serious injury.

### WARNING

#### EXPOSURE HAZARD!



- Wear personal protective equipment such as gloves, work shoes, eye and hearing protection as required by the task at hand.
- NEVER wear jewelry, unbuttoned cuffs, ties or loose-fitting clothing when you are working near moving / rotating parts such as the cooling fan, flywheel or PTO shaft.
- ALWAYS tie back long hair when you are working near moving / rotating parts such as a cooling fan, flywheel, or PTO shaft.
- NEVER operate the engine while wearing a headset to listen to music or radio because it will be difficult to hear the alert signals.
- Failure to comply could result in death or serious injury.

### WARNING

#### BURN HAZARD!








- If you must drain the engine oil while it is still hot, stay clear of the hot engine oil to avoid being burned.
- ALWAYS wear eye protection.
- Wait until the engine cools before you drain the engine coolant. Hot engine coolant may splash and burn you.
- Keep your hands and other body parts away from hot engine surfaces such as the muffler, exhaust pipe, turbocharger (if equipped) and engine block during operation and shortly after you shut the engine down. These surfaces are extremely hot while the engine is operating and could seriously burn you.
- Failure to comply could result in death or serious injury.

## 4. ENGINE

### 4-2-2 Special Service Tools

Note: Tools not having Yanmar part numbers must be acquired locally.

No	Tool Name	Applicable Model and Tool Size				Illustration		
1	Valve Guide Tool (For Removing Valve Guides)	L1	L2	d1	d2	 <p>0000827</p>		
		20 mm	75 mm	7.5 mm	11 mm			
		Locally Manufactured						
2	Valve Guide Tool (For Installing Valve Guides)	L1	L2	d1	d2	 <p>0000828</p>		
		15 mm	65 mm	14 mm	20 mm			
		Locally Manufactured		Allowance L1: 0 to -0.3 mm				
3	Wrist Pin Bushing Tool (For Removing / Installing of Wrist Pin Bushings)	L1	L2	d1	d2	 <p>0000829</p>		
		20 mm	100 mm	26 mm	29 mm			
		Locally Manufactured		Allowance d1: -0.3 to -0.6 mm	Allowance d2: -0.3 to -0.6 mm			
4	Valve Spring Compressor (For Removing / Installing Valve Springs)	Yanmar Part No. 129100-92630				 <p>0000830</p>		
5	Stem Seal Tool (for Installing Stem Seals)	d1	d2	d3	L1	L2	L3	 <p>0000820</p>
		16.2 mm	22 mm	13.5 mm	18.8 mm	65 mm	4 mm or more	
		Allowance: d1: ±0.2 mm L1: ±0.1 mm Locally Manufactured						


## 4. ENGINE

### Inspection of Rocker Arm Assembly

#### Rocker Arm Shaft Hole Diameter

Use a telescoping gauge and micrometer to measure the inside diameter of all the rocker arm support brackets and the rocker arms (**Figure 4-2-12**). Record the measurements. See "3-2 Engine Service Standard" section for the service limit.


Inspect contact areas (**Figure 4-2-12, (1)**) for excessive wear or damage.



**Figure 4-2-12**

#### Rocker Arm Shaft Outside Diameter

Use a micrometer to measure rocker arm shaft diameter. Measure at each rocker arm location in two directions 90° apart (**Figure 4-2-13**). Record the measurements. See "3-2 Engine Service Standard" section for the service limit.




**Figure 4-2-13**

### Inspection of Valve Guides

Visually inspect the valve guides for distortions, scoring or other damage.

Note: Measure valve guides while they are installed in cylinder head.

Use a telescoping gauge and micrometer to measure the inside diameter of the valve guide. Measure in three places and 90° apart (**Figure 4-2-14**). Record the measurements. See "3-2 Engine Service Standard" section for the service limit. Replace valve guides if not within specification.




**Figure 4-2-14**

### Inspection of Cylinder Head

#### Cylinder Head Distortion

Put the cylinder head flat and inverted (combustion side up) on the bench. Use a straightedge and feeler gauge to measure cylinder head distortion (**Figure 4-2-15**). Measure diagonally and along each side. Record the measurements. See "3-2 Engine Service Standard" section for the service limit.




**Figure 4-2-15**

If distortion exceeds the service limit, resurface or replace the cylinder head. Remove only enough material to make the cylinder head flat, but do not remove more than 0.008 in. (0.20 mm).

## 4. ENGINE


- Tighten the lock nut (**Figure 4-2-38, (1)**), while holding the valve bridge (**Figure 4-2-38, (3)**) with a wrench (**Figure 4-2-38, (2)**). Verify that the valve clearance (**Figure 4-2-38, (4)**) is zero "0".



**Figure 4-2-38**

*Note: There is a tendency for the clearance to decrease slightly when the lock nut is tightened. It is suggested that you make the initial clearance adjustment is made slightly on the "loose" side before tightening the lock nut.*

- To adjust the actual valve clearance between the rocker arm and the valve bridge, insert a feeler gauge (**Figure 4-2-39, (1)**) of the correct thickness (See *Adjustment Specifications* on page 6-4) between the rocker arm (**Figure 4-2-38, (2)**) and valve bridge (**Figure 4-2-38, (3)**). Record the results and use this value as an indication of wear.




**Figure 4-2-39**

- If adjustment is required, proceed to the next step.
- Loosen the valve adjusting screw lock nut (**Figure 4-2-40, (5)**) and valve adjusting screw (**Figure 4-2-40, (4)**) on the rocker arm (**Figure 4-2-40, (3)**) and check the clearance gap (**Figure 4-2-40, (2)**) for evidence of dirt or wear.

*Note: There is a tendency for the clearance to decrease slightly when the lock nut is tightened. It is suggested that you make the clearance adjustment is made slightly on the "loose" side before tightening the lock nut.*

- Adjust the valve clearance (**Figure 4-2-40, (2)**) by turning the adjusting screw (**Figure 4-2-40, (4)**) until there is a slight "drag" on the feeler gauge when sliding it between the rocker arm and the valve bridge.




**Figure 4-2-40**

- Hold the adjusting screw (**Figure 4-2-40, (4)**) while tightening the valve adjusting screw lock nut (**Figure 4-2-40, (5)**). Recheck the clearance.
- Apply oil to the contact surface between the adjusting screw and push rod.
- Rotate the crankshaft to measure and adjust the set of valves. Continue until all valves are measured and adjusted.

## 4. ENGINE


- **Method B:** Use a feeler gauge to measure the clearance (**Figure 4-2-59, (3)**) between the thrust bearing (**Figure 4-2-59, (1)**) and crankshaft (**Figure 4-2-59, (2)**). Record the measurement. See "3-2 Engine Tightening Torque" section for tightening torque.



**Figure 4-2-59**


4. Remove the main bearing caps (**Figure 4-60,(1)**). Remove the bearing inserts (**Figure 4-2-60, (2)**) and thrust bearings (**Figure 4- 2-60, (3)**).

Note: Do not remove the crankshaft gear unless the gear or crankshaft are damaged and require replacement.



**Figure 4-2-60**

5. Wipe oil from the bearing insert and crankshaft journal surfaces.
6. Place a piece of PLASTIGAGE® (**Figure 4-2-61, (1)**) along the full width of the bearing insert.




**Figure 4-2-61**

### NOTICE

Do not rotate the crankshaft when using PLASTIGAGE. A false reading may result.

7. Reinstall the bearing cap and tighten to specification. See "3-7-2 Engine Tightening Torque" section for tightening torque.
8. Remove the bearing cap.



**Figure 4-2-62**


9. Compare the width of the flattened PLASTIGAGE (**Figure 4-2-62, ( 1 )**) to the graduation marks on the package. The mark that most closely matches the width of the flattened PLASTIGAGE will indicate the bearing oil clearance. Record the measurement. See "3-2 Engine Service Standard" section for the service limit.
10. Repeat with the remaining main bearings.

Note: Be sure to note the markings on the main bearing caps, or make marks so they can be reinstalled in the same order as they were removed. The "arrows" on the main bearing caps point to the flywheel end of the engine.

## 4. ENGINE


- Lubricate and install the wrist pin (**Figure 4-2-86, (6)**) through the piston and connecting rod.
- Reinstall the second circlip (**Figure 4-2-86, (5)**) and ensure it is securely seated in the groove.

Note: If installing new piston rings the end gap must be checked and adjusted as necessary. See *Inspection of Pistons, Piston Rings and Wrist Pin* on page 4-2-34. Use a piston ring end gap filing tool to adjust the piston ring end gap on new piston rings.



**Figure 4-2-86**

Note: Reinstall the top and second piston rings with the stamped “makers mark” (**Figure 4-2-87, (1)**) facing the top of the piston. The “makers mark” may vary in appearance but will always be located on the top surface of the piston ring adjacent to the piston ring gap. The oil ring and oil ring expander can be installed either side up.



**Figure 4-2-87**


### NOTICE

Always use a piston ring installation tool (expander) when installing piston rings. Never attempt to install piston rings by hand.

- Reinstall the oil ring expander (**Figure 4-2-88, (4)**). Install the oil ring (**Figure 4-2-88, (3)**) with the end gap at 180° from the expander end gap.
- Reinstall the second compression ring (**Figure 4-2-88, (2)**). This ring is identified by its dark color and tapered face profile.
- Reinstall the top compression ring (**Figure 4-2-88, (1)**). This ring is identified by its silver color and barrel-shaped face profile.

### NOTICE

The oil ring expander (**Figure 4-2-88, (4)**) end gap must be located 180° from the oil ring (**Figure 4-2-88, (3)**) end gap.



**Figure 4-2-88**

- Stagger the piston ring end gaps at 120° intervals (**Figure 4-2-89, (1, 2, and 3)**). Do not position the top piston ring end gap in line with the wrist pin.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


## 4. ENGINE

### FUEL SYSTEM SPECIFICATIONS

#### Special Torque Chart

Component	Tightening torque	Lubricating oil application (Thread portion and seat surface)
Fuel injector retainer bolt	39.2 N·m	Not applied
Fuel pump drive gear nut	78 - 88 N·m	Not applied
High-pressure fuel injection line nuts	29 - 34 N·m	Not applied
Fuel return line bolts	7.8 - 9.8 N·m	Not applied
Fuel injection pump mounting nuts	23 - 28 N·m	Not applied
Fuel injector nozzle case nut	39.2 - 44.1 N·m	Not applied
Fuel injection pump plunger plug	30 - 35 N·m	Not applied

## 4. ENGINE




**Figure 4-3-18**

22. If required, remove the intake manifold and fuel pump insulator to access the fuel injection pump mounting nuts.

*Note: The MP2 fuel injection pumps (TNV88 model engines) are fastened to the gear case with three (3) studs and nuts.*

23. Remove the fuel injection pump (**Figure 4-3-18, (1)**). For purposes of future injection timing purposes, record the fuel injection pump timing index number located on the boss on the engine side (back) of the of the fuel injection pump (**Figure 4-3-19, (1)**).



**Figure 4-3-19**

### NOTICE


Do not rotate the crankshaft with the injection pump removed.

24. If the fuel injection pump requires servicing, it must be sent to an authorized YANMAR FIE repair facility for repair and calibration, or replaced with a new fuel injection pump.



### NOTICE

- Never remove or attempt to remove the tamper-proof devices from the full-load fuel adjusting screw or the high-speed throttle limit screw on the fuel injection pump and governor assembly. These adjustments have been made at the factory to meet all applicable emissions regulations and then sealed.
- Never attempt to make any adjustments to these sealed adjustment screws. If adjustments are required, they can be made only by a qualified fuel injection shop that will ensure the injection pump continues to meet all applicable emissions regulations and then replace the tamper-proof seals.
- Tampering with or removing these devices may void the “YANMAR Limited Warranty.”

## 4. ENGINE



**Figure 4-3-43**



**Figure 4-3-44**

10. Rotate the crankshaft counter-clockwise until the dial indicator shows that the injection pump plunger is at the bottom of its stroke. Rock the crankshaft back and forth slightly to confirm a point where the dial indicator shows no movement. Zero the dial indicator.
11. Slowly rotate the crankshaft clockwise until the dial indicator shows a pump plunger lift of 2.5 mm (0.098 in.).
12. Check the position of the flywheel target timing mark (previously determined) (**Figure 4-3-44, (1)**) in relation to the timing reference mark (**Figure 4-3-44, (2)**) on the flywheel housing or engine back plate. If the two marks are aligned, the fuel injection timing is correct. If the marks do not align, the fuel injection timing must be adjusted. See *Adjusting Fuel Injection Timing* on page 4-3-22.
13. If the injection timing is correct, remove the dial indicator and adapter. Replace the pump plunger plug and its copper gasket and tighten to specifications. Replace the flywheel inspection port cover. Open the fuel supply valve and remove the clamp from the fuel supply hose and the fuel return hose.
14. Prime the fuel system. Operate the engine and check for leaks.

### Adjusting Fuel Injection Timing

If the timing marks did not align when performing the *Checking Fuel Injection Timing* on page 4-3-22, the following steps must be performed to properly time the engine.


1. Leave the dial indicator installed in the fuel injection pump. Do not disturb the reading on the dial indicator.
2. Rotate the flywheel until the target timing mark (**Figure 4-3-45, (1)**) and the timing reference mark (**Figure 4-3-45, (2)**) on the flywheel housing or back plate are aligned.

### NOTICE

Do not rotate the crankshaft during the remainder of this procedure.

## 4. ENGINE

### 4-4-4 Engine Coolant Pump Components



K0000031A-01X

- 1 – Thermostat cover
- 2 – Thermostat cover gasket
- 3 – Thermostat
- 4 – Thermostat O-ring
- 5 – Special O-ring
- 6 – Engine coolant pump
- 7 – Temperature switch

- 8 – Gasket
- 9 – Engine coolant pump gasket
- 10 – V-belt
- 11 – Engine coolant pump V-pulley
- 12 – Spacer
- 13 – Engine coolant fan
- 14 – Water temperature sensor  
(Electronically controlled engine)


**Figure 4-4-2**

## 4. ENGINE

### 4-5-4 Checking Engine Oil Pressure

Perform an engine oil pressure check if there is any indication of low oil pressure such as the oil pressure indicator is on or the oil pressure gauge indicates low oil pressure.

1. Disconnect the wire lead from the oil pressure switch or sending unit (**Figure 4-5-2, (1)**).




**Figure 4-5-2**

2. Remove the oil pressure switch.
3. Install a mechanical oil pressure gauge in the oil pressure switch port.
4. Start the engine:
  - If the mechanical oil pressure test gauge indicates good oil pressure, replace the faulty oil pressure switch or sending unit or faulty machine oil pressure gauge in instrument panel.
  - If the mechanical oil pressure test gauge indicates low oil pressure, troubleshoot the lubrication system to locate the cause of the low oil pressure. See *Troubleshooting Charts*. Repair as necessary.

### 4-5-5 Trochoid Oil Pump

#### Oil Pump Components

On these model engines, the oil pump is located inside the front gear case cover and is driven by a boss on the front crankshaft gear. You must remove the front gear case cover to gain access to the oil pump.




- 1 – Crankshaft
- 2 – Oil Pump Cover
- 3 – Oil Pressure Regulator
- 4 – Gear Case Cover
- 5 – Outer Rotor
- 6 – Inner Rotor

**Figure 4-5-3**

## 4. ENGINE

### 4-6-5 Starter Motor Components



K0000103A

- 1 – Pinion shaft
- 2 – M4 bolts (3 used)
- 3 – Bearing retainer
- 4 – Pinion clutch assembly
- 5 – Return spring
- 6 – Pinion stop
- 7 – Retaining ring
- 8 – Gear housing
- 9 – Shift lever
- 10 – Torsion spring
- 11 – Plunger
- 12 – Dust covers (shims)

- 13 – Magnetic switch assembly (solenoid)
- 14 – Cover
- 15 – M6 bolts (2 used)
- 16 – Armature assembly
- 17 – Field coil assembly
- 18 – Positive (+) brushes
- 19 – Negative (-) brushes
- 20 – Brush holder assembly
- 21 – Rear cover
- 22 – M5 through bolts (2 used)
- 23 – M4 bolts (2 used)

**Figure 4-6-1**

## 4. ENGINE

### No-Load Test


Test the characteristics of the starter motor by performing a no-load test.

#### NOTICE

The starter motor can be damaged if operated continuously longer than 10 seconds while performing the no-load test.

1. Secure the starting motor in a vise or other suitable fixture.
2. Connect an ammeter (**Figure 4-6-35, (1)**) in series between the battery positive (+) terminal (**Figure 4-6-35, (2)**) and the main positive (+) terminal (**Figure 4-6-35, (3)**) on the starter motor.

*Note: The ammeter and all wire leads used in this test must have a capacity equal to or greater than the amperage draw specification for the starter motor being tested.*




**Figure 4-6-35**

3. Connect a wire lead between the mounting base of the starter motor (**Figure 4-6-35, (4)**) and the battery negative terminal (**Figure 4-6-35, (5)**).
4. Connect a voltmeter (**Figure 4-6-35, (7)**) to the battery negative (-) terminal (**Figure 4-6-35, (5)**) and the main positive (+) battery terminal (**Figure 4-6-35, (3)**) on the starter motor.
5. Install a switch (**Figure 4-6-35, (6)**) in a circuit between the battery positive (+) terminal (**Figure 4-6-35, (2)**) and the starter magnetic switch (solenoid) terminal (**Figure 4-6-35, (8)**) on the starter motor.

6. Use a suitable tachometer to monitor the rpm of the starter.
7. Turn the switch to the ON position. Monitor the rpm, amperage draw and voltage. For test specifications, see *3TNV82A to 4TNV88 - Standard and Optional* and *4TNV94L to 4TNV106T - Standard and Optional* on page 11-4 for the appropriate starter motor.

### Installation of Starter Motor

1. Reinstall the starter motor to the flywheel housing.
2. Reinstall the starter mounting bolts (**Figure 4-6-36, (1)**). Tighten the bolts to specification. See *Tightening Torques for Standard Bolts and Nuts*.




**Figure 4-6-36**

3. Reconnect the electrical wires to the magnetic switch assembly (solenoid). Be sure to place the cover over the battery positive (+) cable connection.
4. Reconnect the battery cables at the battery.


## 4. ENGINE

4. Lubricate the shaft of the rotor assembly (**Figure 4-7-14, (1)**). Press the rotor assembly into the front frame housing (**Figure 4-7-14, (2)**) and rear frame housing (**Figure 4-7-14, (3)**).




**Figure 4-7-14**

5. Align the front frame housing with the rear frame housing. Reinstall the two bolts (**Figure 4-7-15, (1)**) and two nuts (**Figure 4-7-15, (2)**).




**Figure 4-7-15**

6. Reinstall the insulation bushing (**Figure 4-7-16, (4)**) and nut (**Figure 4-7-16, (3)**).



**Figure 4-7-16**

7. Reassemble the regulator assembly (**Figure 4-7-16, (1)**) to the holder (**Figure 4-7-16, (2)**).
8. Reinstall the brush holder (**Figure 4-7-17, (3)**), springs (**Figure 4-7-17, (4)**) and brushes (**Figure 4-7-17, (5)**).
9. Reattach the regulator assembly and holder to the rear frame housing.



**Figure 4-7-17**



## 5. ELECTRIC SYSTEM


### 5-2-4 Electric system description

ITEM	DESCRIPTION	ITEM	DESCRIPTION
A555	GLOW TIMER	X100	CONNECTOR
A556	PULL ELECTROSTOP TIMER	X101.S	CONNECTOR
B0	BATTERY	K201	SAFETY STARTING RELAY
B8	PARKING BRAKE SWITCH	K202	JOYSTICK SUPREY RELAY
B16	OIL FILTER CLOGGING INDICATOR	K203	KICK DOWN RELAY
B21	HYDRAULIC TEMPERATURE INDICATOR	S110.1	JOYSTICK
B22	OIL FILTER CLOGGING INDICATOR	S200	SHIFT SWITCH
B23	STEERING PRESSURE SWITCH	X101.P	CONNECTOR
B24	FUEL LEVEL SENSOR	B2	HORN
B25	AIR FILTER CLOGGING INDICATOR	E1	RIGHT FRONT LIGHT
B26	COOLANT ENGINE TEMPERATURE SENSOR	E3	LEFT FRONT LIGHT
B28	OIL BRAKE LEVEL SENSOR	S110	JOYSTICK
E1	RIGHT REAR LIGHT	Y111	EV. OPTIONAL.1
E10	PLATE LAMP	Y112	EV. OPTIONAL.2
E17	LEFT REAR LIGHT	X101.P	CONNECTOR
F1	+30 CPU AND RELAYS FUSE	A505	RIGHT SPEAKER
F2	+30 GLOW RELAY FUSE	A507	LEFT SPEAKER
F3	+30 ELECTROSTOP FUSE	B513	RADIO
F4	+30 KEY START	E500	LEFT FRONT WORKING LIGHT
F5	+30 STARTING MOTOR RELAY FUSE	E501	ROTARY LAMP
G0	ALTERNATOR	E502	CEILING LIGHT
H19	BACKALLARM BUZZER	E503	RIGHT FRONT WORKING LIGHT
K132.1	GLOW RELAY	E504	RIGHT REAR WORKING LIGHT
K132.2	STARTING MOTOR RELAY	E506	LEFT REAR WORKING LIGHT
K551	ELECTROSTOP REAY	M508	HEATING FAN MOTOR
M0	STARTING MOTOR	M509	WINDSHIELD WASHER PUMP
M18	CLUTCH AIR CONDITIONING	M511	REAR WINDSHIELD WIPER MOTOR
R5	GLOVE	M516	FRONT WINDSHIELD WIPER MOTOR
S0	BATTERY KNIFE SWITCH	S510	HEATING FAN SWITCH
S20	STOP PRESSURE SWITCH	X8	CONNECTOR
Y13	EV. GEAR	X512	CONNECTOR
Y14	EV. REVERSE	X515	PLUG SUPPLY
Y15	EV. FORWARD		
Y30	ELECTROSTOP PULLER		
Y31	ENGINE STOP		
X9	CONNECTOR		
X10	CONNECTOR		
X11	CONNECTOR		

## 6. HYDRAULIC SYSTEM

### 6-3-4 Hydrostatic pump

- A) Hydraulic servo control
- B) Two pressure relief valves :  
one for forward motion and one for reverse motion
- C) Booster pump (filling)
- D) Power absorption control valve
- E) Booster pump valve
- F) Two solenoid valves for motion reversal
- G) Working pressure control valve
- H) Hydraulic pump and steering unit



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL